



| Part No | Part Description                                    | MRP  | HSN      | GST |
|---------|---|------|----------|-----|
| 187104  | Eicher Tractor Snap Ring - Br30 For Rev Gear        | 20   | 73182990 | 18% |
| 256440  | Eicher Tractor Check Valve                          | 185  | 87089900 | 18% |
| 619700  | Eicher Tractor Relay For H/L                        | 197  | 85364900 | 18% |
| 1010116 | Eicher Tractor Needle Roller Bearing Nk 30X32       | 297  | 84824000 | 18% |
| 1010130 | Eicher Tractor Needle Roller Bearing 5020           | 186  | 84824000 | 18% |
| 1010141 | Eicher Tractor Ball Bearing 6210N                   | 609  | 84821011 | 18% |
| 1010153 | Eicher Tractor Cyl. Roller Brg. Nup 208             | 1096 | 84825011 | 18% |
| 1010165 | Eicher Tractor Ndl Bush Brg 2016                    | 70   | 84825011 | 18% |
| 1010177 | Eicher Tractor Ndl Cg Brg 50X55X30                  | 177  | 84824000 | 18% |
| 1010189 | Eicher Tractor Taper Roller Bearing 32211           | 716  | 84822012 | 18% |
| 1010190 | Eicher Tractor Ball Bearing 6206N                   | 374  | 84821011 | 18% |
| 1010207 | Eicher Tractor Deep Groove Ball Bearing 6207        | 460  | 84821011 | 18% |
| 1010220 | Eicher Tractor Deep Groove Ball Bearing 6211-C3     | 716  | 84821012 | 18% |
| 1010232 | Eicher Tractor Ball Bearing 6212-C3                 | 716  | 84821012 | 18% |
| 1010244 | Eicher Tractor Dg Ball Bearing 6213-C3              | 983  | 84821012 | 18% |
| 1010256 | Eicher Tractor Ball Bearing 6212N                   | 970  | 84821012 | 18% |
| 1010311 | Eicher Tractor Ball Bearing 3309                    | 2116 | 84821011 | 18% |
| 1010372 | Eicher Tractor Barrel Bush                          | 91   | 87084000 | 18% |
| 1010384 | Eicher Tractor Reverse Gear Bush                    | 393  | 87084000 | 18% |
| 1010426 | Eicher Tractor Steel Ball 10Mm,Grade-200,Gauge 15   | 5    | 84829119 | 18% |
| 1010578 | Eicher Tractor Reduction Cover-Fin.                 | 3959 | 87084000 | 18% |
| 1010633 | Eicher Tractor Brake Cup                            | 24   | 87083000 | 18% |
| 1010669 | Eicher Tractor Circlip Light A-16                   | 4    | 73182910 | 18% |
| 1010682 | Eicher Tractor Circlip Light B-100                  | 70   | 73182910 | 18% |
| 1010694 | Eicher Tractor Circlip Light B-72                   | 26   | 73182910 | 18% |
| 1010712 | Eicher Tractor Circlip Light A-30                   | 10   | 73182910 | 18% |
| 1010724 | Eicher Tractor Circlip Heavy A-35                   | 23   | 73182910 | 18% |
| 1010748 | Eicher Tractor Ascending Disc 70X50X0.76Mm          | 27   | 87084000 | 18% |
| 1010750 | Eicher Tractor Ascending Disc                       | 14   | 87084000 | 18% |
| 1010761 | Eicher Tractor Ascending Disc 50X20X0.454           | 12   | 87084000 | 18% |
| 1010797 | Eicher Tractor Ascending Disc 50X20X0.607           | 14   | 87084000 | 18% |
| 1010815 | Eicher Tractor Locking Disc                         | 82   | 87084000 | 18% |
| 1010888 | Eicher Tractor Ascending Disc 70X50X0.454Mm         | 18   | 87084000 | 18% |
| 1011029 | Eicher Tractor Reverse Gear Fin                     | 907  | 87084000 | 18% |
| 1011110 | Eicher Tractor Constant Mesh Gear                   | 1274 | 87084000 | 18% |
| 1011145 | Eicher Tractor Gasket F G1 & G2                     | 94   | 68129090 | 18% |
| 1011212 | Eicher Tractor Gasket For Rg. Hsg. & Reduction Cove | 96   | 68129090 | 18% |
| 1011224 | Eicher Tractor Gasket F Cvr Rt & Lt                 | 35   | 68129090 | 18% |
| 1011236 | Eicher Tractor Gasket For Pto Cover & G2 Coupling   | 11   | 68129090 | 18% |
| 1011420 | Eicher Tractor Knob For Pto                         | 38   | 39094020 | 18% |
| 1011467 | Eicher Tractor Lay Shaft Key                        | 26   | 87084000 | 18% |
| 1011546 | Eicher Tractor Brake Lining                         | 29   | 87083000 | 18% |
| 1011558 | Eicher Tractor Lever Diff Lock G 2                  | 38   | 87089900 | 18% |
| 1011613 | Eicher Tractor Nave For Engaging Lever Assy.        | 84   | 87084000 | 18% |
| 1011649 | Eicher Tractor Grooved Nut 40X1.5                   | 109  | 73181500 | 18% |
| 1011716 | Eicher Tractor Guide Pin                            | 11   | 73182100 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1011728 | Eicher Tractor Spring Dowel Sleeve Heavy 14X20 | 20   | 73182100 | 18% |
| 1011730 | Eicher Tractor Spring Dowel Sleeve Heavy 5X40  | 12   | 73182100 | 18% |
| 1011741 | Eicher Tractor Spring Dowel Sleeve Heavy 3X40  | 12   | 73182100 | 18% |
| 1011753 | Eicher Tractor Notched Pin 10X18Mm             | 11   | 73182100 | 18% |
| 1011765 | Eicher Tractor Pin With Head                   | 27   | 73182100 | 18% |
| 1011807 | Eicher Tractor Diamond Pin                     | 30   | 73182100 | 18% |
| 1011868 | Eicher Tractor Retaining Pin                   | 9    | 73182100 | 18% |
| 1011870 | Eicher Tractor Retaining Pin 02312             | 10   | 73182100 | 18% |
| 1011881 | Eicher Tractor Inter Locking Pin (Big)         | 55   | 73182100 | 18% |
| 1011893 | Eicher Tractor Inter Locking Pin (Small)       | 55   | 73182100 | 18% |
| 1011900 | Eicher Tractor Pin For Disc Lock               | 53   | 73182100 | 18% |
| 1012022 | Eicher Tractor Intermediate Ring               | 12   | 87089900 | 18% |
| 1012034 | Eicher Tractor Locking Ring                    | 4    | 73202000 | 18% |
| 1012046 | Eicher Tractor Snap Ring Sp-62                 | 22   | 73182990 | 18% |
| 1012060 | Eicher Tractor O Ring 29Dia                    | 10   | 40169340 | 18% |
| 1012149 | Eicher Tractor Stud M14X35/49,P10.9, (Spl)     | 34   | 73182100 | 18% |
| 1012204 | Eicher Tractor Spcr F Lay Shaft                | 8    | 87084000 | 18% |
| 1012277 | Eicher Tractor Spacer Locating 14.5            | 180  | 73182100 | 18% |
| 1012356 | Eicher Tractor Washer For Disc Lock            | 121  | 73182100 | 18% |
| 1012368 | Eicher Tractor Shim 119X105X0.2                | 12   | 73182100 | 18% |
| 1012370 | Eicher Tractor Shim 119X105X0.3                | 11   | 73182100 | 18% |
| 1012381 | Eicher Tractor Shim 119X105X0.4                | 11   | 73182100 | 18% |
| 1012393 | Eicher Tractor Shim 119X105X0.5                | 18   | 73182100 | 18% |
| 1012400 | Eicher Tractor Shim 119X105X0.9                | 16   | 73182100 | 18% |
| 1012423 | Eicher Tractor Shim 119X105X1.0                | 26   | 73182100 | 18% |
| 1012460 | Eicher Tractor Oil Seal 18X30X7Mm              | 36   | 40169330 | 18% |
| 1012472 | Eicher Tractor Oil Seal 35X56X10Mm             | 55   | 40169990 | 18% |
| 1012496 | Eicher Tractor Oil Seal 45X72X12Mm             | 64   | 40169330 | 18% |
| 1012514 | Eicher Tractor Oil Seal 70X90X13Mm             | 97   | 40169990 | 18% |
| 1012526 | Eicher Tractor G S Rod 1&2                     | 75   | 87084000 | 18% |
| 1012642 | Eicher Tractor Sliding Piece                   | 42   | 87089900 | 18% |
| 1012691 | Eicher Tractor K-Ring Duplx 022423             | 53   | 73182100 | 18% |
| 1012710 | Eicher Tractor Pressure Spring                 | 5    | 73202000 | 18% |
| 1012721 | Eicher Tractor Pressure Spring                 | 7    | 73202000 | 18% |
| 1012746 | Eicher Tractor Conical Spring                  | 32   | 73202000 | 18% |
| 1012770 | Eicher Tractor Shim For Lay Shaft 45X30X4.0    | 28   | 73182100 | 18% |
| 1012885 | Eicher Tractor Lock Washer                     | 6    | 73182100 | 18% |
| 1012897 | Eicher Tractor Lock Washer                     | 9    | 73182100 | 18% |
| 1012903 | Eicher Tractor Lock Washer                     | 10   | 73182100 | 18% |
| 1012915 | Eicher Tractor Lock Washer                     | 22   | 73182100 | 18% |
| 1012927 | Eicher Tractor Lock Washer                     | 7    | 73182100 | 18% |
| 1012939 | Eicher Tractor Lock Washer                     | 6    | 73182100 | 18% |
| 1013191 | Eicher Tractor Shoulder Rivet For Duplex       | 12   | 73182100 | 18% |
| 1013208 | Eicher Tractor Rivet F Duplex                  | 5    | 73182100 | 18% |
| 1013257 | Eicher Tractor Spur Gear 3Rd Fin               | 1245 | 87084000 | 18% |
| 1013269 | Eicher Tractor Spur Gear 4Th Fin               | 1369 | 87084000 | 18% |
| 1013270 | Eicher Tractor Spur Gear 5Th Fin               | 1454 | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1013336 | Eicher Tractor Sliding Gear 5/6Th Fin              | 515   | 87084000 | 18% |
| 1013348 | Eicher Tractor Support Hub Assly                   | 2883  | 87084000 | 18% |
| 1013403 | Eicher Tractor Spring Dowel Sleeve 4X25            | 12    | 73182100 | 18% |
| 1013567 | Eicher Tractor Tension Spring                      | 12    | 73202000 | 18% |
| 1013737 | Eicher Tractor Bearing Flange Modf                 | 375   | 87084000 | 18% |
| 1013956 | Eicher Tractor Shim For Main Shaft 5.4 Mm          | 48    | 73182100 | 18% |
| 1014444 | Eicher Tractor Sliding Gear 3/4 Mod                | 2374  | 87084000 | 18% |
| 1014560 | Eicher Tractor Foot Pedal F Diff Lock              | 245   | 87084000 | 18% |
| 1014584 | Eicher Tractor Lock Plate For A1 A2                | 14    | 87084000 | 18% |
| 1014602 | Eicher Tractor Reverse Gear Shaft                  | 275   | 87084000 | 18% |
| 1014651 | Eicher Tractor Rubber Washer                       | 9     | 40169320 | 18% |
| 1014663 | Eicher Tractor O Ring 12.3X2.4                     | 7     | 40169340 | 18% |
| 1014742 | Eicher Tractor Brake Shoe Assy                     | 119   | 87083000 | 18% |
| 1014778 | Eicher Tractor Sph. Wheel Nut M18X1.5              | 60    | 73181500 | 18% |
| 1014857 | Eicher Tractor Engaging Handle -01                 | 544   | 87084000 | 18% |
| 1014900 | Eicher Tractor Hollow Rivet                        | 5     | 73182100 | 18% |
| 1014912 | Eicher Tractor Spring Dowel Sleeve 13X30           | 24    | 73182100 | 18% |
| 1014950 | Eicher Tractor Stud M14X40/61                      | 32    | 73182100 | 18% |
| 1014961 | Eicher Tractor Stud M14X85,10.9,Bp,                | 66    | 73182100 | 18% |
| 1016544 | Eicher Tractor Spacer For Rear Shaft               | 289   | 73182100 | 18% |
| 1016647 | Eicher Tractor Brake Cam Follower (Upper)          | 22    | 87083000 | 18% |
| 1016659 | Eicher Tractor Brake Cam Follower (Lower)          | 26    | 87083000 | 18% |
| 1016696 | Eicher Tractor Drain Plug M18X1.5(W/O Magnet)      | 56    | 84099941 | 28% |
| 1016702 | Eicher Tractor Drain Plug Assy.(With Magnet)       | 80    | 87084000 | 18% |
| 1016714 | Eicher Tractor C Abrossed Washer(F)                | 15    | 74091100 | 18% |
| 1016787 | Eicher Tractor Brake Drum                          | 1776  | 87083000 | 18% |
| 1017056 | Eicher Tractor Sliding Gear 4/5(5-Sp) -241 (Teeth- | 1049  | 87084000 | 18% |
| 1017068 | Eicher Tractor Spur Gear I St - 241                | 714   | 87084000 | 18% |
| 1017081 | Eicher Tractor Spur Gear 2 Nd - 241                | 1114  | 87084000 | 18% |
| 1017093 | Eicher Tractor Spur Gear 4 Th -241 (Teeth-29)      | 1309  | 87084000 | 18% |
| 1017160 | Eicher Tractor Ags Fork 4/5(5-Sp)                  | 741   | 87084000 | 18% |
| 1017275 | Eicher Tractor Spacer Small (5-Sp)                 | 123   | 73182100 | 18% |
| 1017299 | Eicher Tractor Lock Washer(5-Sp)                   | 13    | 73182100 | 18% |
| 1017603 | Eicher Tractor Bridge (5-Sp)                       | 1452  | 87084000 | 18% |
| 1017615 | Eicher Tractor Gasket For Cover Front              | 54    | 68129090 | 18% |
| 1017743 | Eicher Tractor Gear Final Drive                    | 6267  | 87084000 | 18% |
| 1017767 | Eicher Tractor Shim 98X88X0.2Mm                    | 12    | 73182100 | 18% |
| 1017779 | Eicher Tractor Shim 98X88X0.4Mm                    | 20    | 73182100 | 18% |
| 1017780 | Eicher Tractor Shim 98X88X0.6Mm                    | 14    | 73182100 | 18% |
| 1017809 | Eicher Tractor Lock Nut M50X1.5                    | 186   | 73181500 | 18% |
| 1017822 | Eicher Tractor Shifter Fork Rev 5Sp                | 593   | 87084000 | 18% |
| 1017860 | Eicher Tractor Rear Axle 1920 - 241 - (Teeth-15)   | 4659  | 87084000 | 18% |
| 1017974 | Eicher Tractor Rear Top Cover                      | 2437  | 87084000 | 18% |
| 1017986 | Eicher Tractor Pto Cover                           | 381   | 87084000 | 18% |
| 1018413 | Eicher Tractor Gear Shift Lever Assy Gt-51         | 323   | 87084000 | 18% |
| 1018425 | Eicher Tractor Gear Housing Rear (241)             | 15317 | 87089900 | 18% |
| 1018504 | Eicher Tractor Spline Shaft                        | 1973  | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1018528 | Eicher Tractor Gasket For Guide Bush & G2 Mtg  | 11    | 68129090 | 18% |
| 1018541 | Eicher Tractor Locking Shaft                   | 263   | 87084000 | 18% |
| 1018565 | Eicher Tractor Bracket                         | 32    | 87084000 | 18% |
| 1018577 | Eicher Tractor Shifter Fork Assy               | 1291  | 87084000 | 18% |
| 1018619 | Eicher Tractor Locking Screw M8X30,B8.8,Bp,    | 11    | 73181500 | 18% |
| 1018632 | Eicher Tractor Diff Shaft                      | 287   | 87084000 | 18% |
| 1018644 | Eicher Tractor Steel Shim 41.5X20X1.215        | 12    | 73182100 | 18% |
| 1018656 | Eicher Tractor Steel Shim 41.5X20X0.912        | 10    | 73182100 | 18% |
| 1018668 | Eicher Tractor Steel Shim 41.5X20X0.76         | 7     | 73182100 | 18% |
| 1018670 | Eicher Tractor Steel Shim 41.5X20X0.607        | 8     | 73182100 | 18% |
| 1018681 | Eicher Tractor Steel Shim 41.5X20X0.454        | 5     | 73182100 | 18% |
| 1018693 | Eicher Tractor Ascending Disc                  | 74    | 73182100 | 18% |
| 1018711 | Eicher Tractor Gear Housing Front - 241        | 11602 | 87084000 | 18% |
| 1018735 | Eicher Tractor Sliding Gear1 (5-Sp) - 241      | 1036  | 87084000 | 18% |
| 1018747 | Eicher Tractor Sliding Gear 2/3(5-Sp) - 241    | 2371  | 87084000 | 18% |
| 1018759 | Eicher Tractor Spur Gear 3 Rd - 241 (Teeth-25) | 1143  | 87084000 | 18% |
| 1018760 | Eicher Tractor Shifter Fork 1(5-Sp)            | 784   | 87084000 | 18% |
| 1018772 | Eicher Tractor Shifter Fork 2/3(5Sp)           | 663   | 87084000 | 18% |
| 1018802 | Eicher Tractor Knob (5-Sp)                     | 35    | 87084000 | 18% |
| 1018887 | Eicher Tractor Pin                             | 120   | 73182100 | 18% |
| 1018942 | Eicher Tractor G S Rod 1                       | 199   | 87084000 | 18% |
| 1018954 | Eicher Tractor G S Rod 2/3                     | 199   | 87084000 | 18% |
| 1018966 | Eicher Tractor G S Rod 4/5                     | 199   | 87084000 | 18% |
| 1018978 | Eicher Tractor G S Rod Rev. Gr.                | 199   | 87084000 | 18% |
| 1018980 | Eicher Tractor Primary Shaft                   | 1444  | 87084000 | 18% |
| 1018991 | Eicher Tractor Thrust Washer 23.8X15X2         | 11    | 73182100 | 18% |
| 1019107 | Eicher Tractor Disc Assy (Complete)            | 629   | 87089300 | 18% |
| 1019132 | Eicher Tractor Cam Brake                       | 334   | 87083000 | 18% |
| 1019144 | Eicher Tractor Shoe Assy Brake                 | 359   | 87083000 | 18% |
| 1019170 | Eicher Tractor Lining Brake                    | 51    | 87083000 | 18% |
| 1019200 | Eicher Tractor Pin,Anchor,Brake,               | 35    | 87083900 | 18% |
| 1019211 | Eicher Tractor Tension Spring                  | 26    | 73202000 | 18% |
| 1019302 | Eicher Tractor Thrust Washer 24X18X2           | 11    | 73182100 | 18% |
| 1019314 | Eicher Tractor Cam Brake                       | 609   | 87083000 | 18% |
| 1019340 | Eicher Tractor Shim 119X105X0.15               | 11    | 73182100 | 18% |
| 1019405 | Eicher Tractor Rear Shaft 242                  | 4425  | 87084000 | 18% |
| 1019648 | Eicher Tractor Cover Right & Left - 01         | 1386  | 87084000 | 18% |
| 1019650 | Eicher Tractor Counter Shaft - 241 (Teeth-9)   | 2542  | 87084000 | 18% |
| 1019661 | Eicher Tractor Rear Shaft                      | 7357  | 87084000 | 18% |
| 1020237 | Eicher Tractor Disc Lock                       | 988   | 87084000 | 18% |
| 1040078 | Eicher Tractor Nr Bearing 28/20                | 329   | 84822090 | 18% |
| 1040121 | Eicher Tractor Steel Ball 8Mm Gr-16            | 5     | 84829119 | 18% |
| 1040236 | Eicher Tractor 7.26Lip Light A24               | 38    | 73182100 | 18% |
| 1040418 | Eicher Tractor Gasket For Oil Reservoir        | 22    | 68129090 | 18% |
| 1040613 | Eicher Tractor Magnet                          | 14    | 84099941 | 28% |
| 1040674 | Eicher Tractor Hex Nut 20Mm                    | 17    | 73181500 | 18% |
| 1040686 | Eicher Tractor Securing Nut                    | 12    | 73181500 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1040893 | Eicher Tractor Spring For Loop                   | 2    | 87089900 | 18% |
| 1040911 | Eicher Tractor Supporting Ring                   | 23   | 87089900 | 18% |
| 1040959 | Eicher Tractor Oil Seal 17X32X10                 | 93   | 40169990 | 18% |
| 1040960 | Eicher Tractor Eccentric Shaft                   | 622  | 87084000 | 18% |
| 1040984 | Eicher Tractor Adjusting Screw Ag80F28           | 16   | 73181500 | 18% |
| 1041009 | Eicher Tractor Closing Screw                     | 20   | 73181500 | 18% |
| 1041022 | Eicher Tractor Shim. F. Hyd. Pump Assy           | 10   | 73182100 | 18% |
| 1041060 | Eicher Tractor Piston Spring                     | 35   | 73182100 | 18% |
| 1041083 | Eicher Tractor Spring Ag80F27                    | 16   | 73209090 | 18% |
| 1041095 | Eicher Tractor Spring Tension                    | 11   | 87089900 | 18% |
| 1041101 | Eicher Tractor Valve Spring                      | 4    | 73202000 | 18% |
| 1041113 | Eicher Tractor Spring                            | 5    | 73209090 | 18% |
| 1041125 | Eicher Tractor Pressure Spring                   | 17   | 73202000 | 18% |
| 1041149 | Eicher Tractor Suction Valve                     | 55   | 87089900 | 18% |
| 1041162 | Eicher Tractor Bucket Washer                     | 46   | 40169990 | 18% |
| 1042520 | Eicher Tractor O Ring 25.3X2.4                   | 11   | 40169340 | 18% |
| 1042531 | Eicher Tractor O Ring 119.5X3                    | 15   | 40169340 | 18% |
| 1042555 | Eicher Tractor O Ring 11.3X2.4 Shore A 70 Nbr    | 3    | 40169320 | 18% |
| 1042567 | Eicher Tractor O Ring 18.3X2.4                   | 11   | 40169320 | 18% |
| 1042579 | Eicher Tractor O Rng 54.5X3                      | 5    | 40169990 | 18% |
| 1042580 | Eicher Tractor O Ring 24.2X3                     | 9    | 40169340 | 18% |
| 1043006 | Eicher Tractor Punched Washer B 5.5 (Stat)       | 3    | 73182100 | 18% |
| 1070113 | Eicher Tractor Bush F Fly Spndl Mod              | 60   | 87089400 | 18% |
| 1070162 | Eicher Tractor Cover Top                         | 112  | 87084000 | 18% |
| 1070174 | Eicher Tractor Cover Bottom                      | 104  | 87084000 | 18% |
| 1070332 | Eicher Tractor Fly Spindle                       | 1160 | 87084000 | 18% |
| 1070368 | Eicher Tractor Gasket St-Column                  | 15   | 68129090 | 18% |
| 1070411 | Eicher Tractor Woodruff Key 5X7.5 -Zf-0631511800 | 27   | 73182100 | 18% |
| 1070484 | Eicher Tractor Hex Thin Nut M12X1.5,B8,          | 22   | 73181600 | 18% |
| 1070514 | Eicher Tractor Taper Drain Plug M10X1            | 17   | 87084000 | 18% |
| 1070526 | Eicher Tractor Pin F Fly Spindle                 | 105  | 87084000 | 18% |
| 1070629 | Eicher Tractor Oil Seal 28X42.5X8                | 31   | 40169330 | 18% |
| 1070939 | Eicher Tractor Torque Strut (Nd)Zf243            | 94   | 87089400 | 18% |
| 1070940 | Eicher Tractor Steering Gear Pad                 | 65   | 87089400 | 18% |
| 1070952 | Eicher Tractor Torque Strut(24Hp Round)          | 136  | 87089400 | 18% |
| 1071040 | Eicher Tractor Steering Gear Assy.(Rane)         | 7754 | 87089400 | 18% |
| 1071051 | Eicher Tractor Steering Arm-Rane                 | 1415 | 87089400 | 18% |
| 1071105 | Eicher Tractor Box Sub Assy                      | 4980 | 87089400 | 18% |
| 1071117 | Eicher Tractor Bush                              | 190  | 87089900 | 18% |
| 1071129 | Eicher Tractor Inner Coloumn Assy                | 4700 | 87089400 | 18% |
| 1071142 | Eicher Tractor Steel Ball 5/16                   | 22   | 84829119 | 18% |
| 1071154 | Eicher Tractor Outer Coloumn Sub Assy            | 3733 | 87089400 | 18% |
| 1071166 | Eicher Tractor Nylon Bush                        | 43   | 87089400 | 18% |
| 1071178 | Eicher Tractor Spring Dowel Sleeve               | 8    | 87089900 | 18% |
| 1071180 | Eicher Tractor Ball Cage Assy                    | 228  | 87089400 | 18% |
| 1071191 | Eicher Tractor Adjuster Ball Race                | 499  | 73181500 | 18% |
| 1071208 | Eicher Tractor Inner Race Top                    | 360  | 87089400 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1071210 | Eicher Tractor Inner Top Bottom                    | 283   | 87089400 | 18% |
| 1071221 | Eicher Tractor Shim                                | 14    | 73182100 | 18% |
| 1071233 | Eicher Tractor Shim                                | 13    | 73182100 | 18% |
| 1071245 | Eicher Tractor Shim                                | 13    | 73182100 | 18% |
| 1071257 | Eicher Tractor Joint Washer                        | 9     | 73182100 | 18% |
| 1071269 | Eicher Tractor Oil Plug                            | 45    | 87084000 | 18% |
| 1071282 | Eicher Tractor Rocker Shaft                        | 4280  | 87089900 | 18% |
| 1071294 | Eicher Tractor Cover Plate                         | 689   | 87084000 | 18% |
| 1071300 | Eicher Tractor Adjuster                            | 53    | 73181500 | 18% |
| 1071312 | Eicher Tractor Lock Nut                            | 71    | 73181500 | 18% |
| 1071336 | Eicher Tractor Oil Seal                            | 114   | 40169330 | 18% |
| 1071348 | Eicher Tractor Spring Washer                       | 17    | 73182990 | 18% |
| 1071350 | Eicher Tractor Lock Nut                            | 80    | 73181500 | 18% |
| 1071361 | Eicher Tractor Bolt                                | 22    | 73181500 | 18% |
| 1071373 | Eicher Tractor Spring Washer                       | 8     | 73182990 | 18% |
| 1071385 | Eicher Tractor Torque Sturt                        | 119   | 87089400 | 18% |
| 1071439 | Eicher Tractor Steering Gear Support-Rane          | 1184  | 87089400 | 18% |
| 1073096 | Eicher Tractor Steering Gear Assy.(Zf)             | 12684 | 87089400 | 18% |
| 1073175 | Eicher Tractor Locking Plate For Steering Assly-Zf | 33    | 87089400 | 18% |
| 1073187 | Eicher Tractor Worm Column Assy 1073096 Stg. Assly | 2858  | 87089400 | 18% |
| 1073199 | Eicher Tractor Jacket Bearing Bush (7316134804)    | 192   | 87089400 | 18% |
| 1073205 | Eicher Tractor Dust Seal For Steering Assly-Zf     | 56    | 87089400 | 18% |
| 1073217 | Eicher Tractor Hex Nut M30 For Steering Assly-Zf   | 92    | 73181500 | 18% |
| 1073229 | Eicher Tractor Shaft Seal For Steering Assly-Zf    | 74    | 87089400 | 18% |
| 1073230 | Eicher Tractor Bearing Race For Steering Assly-Zf  | 382   | 84822090 | 18% |
| 1073242 | Eicher Tractor Bearing Cage For Steering Assly-Zf  | 190   | 84822090 | 18% |
| 1073254 | Eicher Tractor Oil Plug For Steering Assly-Zf      | 56    | 87089400 | 18% |
| 1073280 | Eicher Tractor Retaining Cap                       | 29    | 73182100 | 18% |
| 1073291 | Eicher Tractor Jacket Tube W/Hsg For Zf 485 Sdi    | 1009  | 87083000 | 18% |
| 1073308 | Eicher Tractor Housing For Steering Assly-Zf       | 11297 | 87084000 | 18% |
| 1073310 | Eicher Tractor Shim For Steering Assly-Zf          | 65    | 73182100 | 18% |
| 1073345 | Eicher Tractor Shim For Steering Assly-Zf          | 1     | 73182100 | 18% |
| 1073357 | Eicher Tractor Flange For Steering Assly-Zf        | 544   | 87089900 | 18% |
| 1073369 | Eicher Tractor Spring Washer                       | 42    | 73182990 | 18% |
| 1073382 | Eicher Tractor Hex Nut                             | 146   | 73181500 | 18% |
| 1073394 | Eicher Tractor Housing Cover For Steering Assly-Zf | 303   | 87089400 | 18% |
| 1073400 | Eicher Tractor Circlip For Steering Assly-Zf       | 42    | 73182910 | 18% |
| 1073412 | Eicher Tractor Guide Washer -Zf                    | 79    | 87089400 | 18% |
| 1073424 | Eicher Tractor Backlash Adjuster For Steering Assl | 106   | 87089400 | 18% |
| 1073436 | Eicher Tractor Sector Shaft Assly For Steering Ass | 10661 | 87084000 | 18% |
| 1073448 | Eicher Tractor Bearing Bush For Steering Assly-Zf  | 114   | 87089400 | 18% |
| 1073760 | Eicher Tractor Gasket Washer-11                    | 40    | 68129090 | 18% |
| 1073953 | Eicher Tractor Steering Wheel 485                  | 2196  | 87089400 | 18% |
| 1080404 | Eicher Tractor Bush F Stg. Hsg(Modf)               | 143   | 87089900 | 18% |
| 1110081 | Eicher Tractor Connecting Rod Bolt                 | 102   | 73181500 | 18% |
| 1110160 | Eicher Tractor Bush For Rocker Arm                 | 238   | 84099941 | 28% |
| 1110664 | Eicher Tractor Cooling Jacket(Spd)                 | 6576  | 84099941 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1110810 | Eicher Tractor Nut Ed13006.5                 | 13   | 84099941 | 28% |
| 1111097 | Eicher Tractor Rod For D/C                   | 36   | 84099941 | 28% |
| 1111190 | Eicher Tractor Roller For Tappet             | 120  | 84824000 | 18% |
| 1111206 | Eicher Tractor Roller Pin                    | 77   | 73181500 | 18% |
| 1111231 | Eicher Tractor Roller Bush                   | 100  | 84833000 | 18% |
| 1111243 | Eicher Tractor Adjusting Screw               | 24   | 73181500 | 18% |
| 1111292 | Eicher Tractor Side For Cool Panel           | 228  | 84099990 | 28% |
| 1111413 | Eicher Tractor Valve Seat Exhaust            | 199  | 84099941 | 28% |
| 1111425 | Eicher Tractor Valve Seat Inlet              | 199  | 84099941 | 28% |
| 1111759 | Eicher Tractor Balance Wt M/Cd               | 1641 | 84099941 | 28% |
| 1111863 | Eicher Tractor Nozzle                        | 1239 | 84099941 | 28% |
| 1111905 | Eicher Tractor Pump Element Mico O/M         | 1150 | 84099941 | 28% |
| 1111917 | Eicher Tractor Delevery Valve                | 574  | 84099941 | 28% |
| 1111929 | Eicher Tractor Control Rack                  | 199  | 84099941 | 28% |
| 1111942 | Eicher Tractor Piston Ring 10 O/S L          | 815  | 84099913 | 28% |
| 1120013 | Eicher Tractor Link                          | 231  | 84099941 | 28% |
| 1120116 | Eicher Tractor Cyl. Roller Brg. Front N314   | 3509 | 84825011 | 18% |
| 1120141 | Eicher Tractor Ball Bearing 6305-115         | 347  | 84821011 | 18% |
| 1120153 | Eicher Tractor Cyl. Roller Brg. Rear Nup315  | 3540 | 84825011 | 18% |
| 1120268 | Eicher Tractor Steel Ball 9.525 Dia,Grade-3, | 7    | 84829119 | 18% |
| 1120270 | Eicher Tractor Big And Brg. 115(0.50)        | 1838 | 84821011 | 18% |
| 1120281 | Eicher Tractor Big & Brg 1Mm                 | 1960 | 84821011 | 18% |
| 1120293 | Eicher Tractor Big End Brg. 2 Mm             | 1979 | 84821011 | 18% |
| 1120300 | Eicher Tractor Big End Bearing               | 1840 | 84821011 | 18% |
| 1120384 | Eicher Tractor Actuating Pin                 | 30   | 84129090 | 18% |
| 1120517 | Eicher Tractor Closing Cap Assy.             | 102  | 84099941 | 28% |
| 1120530 | Eicher Tractor Cover Left-115                | 38   | 84099941 | 28% |
| 1120542 | Eicher Tractor Cover Right                   | 33   | 84129090 | 18% |
| 1120554 | Eicher Tractor Inspection Cover-115          | 498  | 84099941 | 28% |
| 1120566 | Eicher Tractor Lid Assembly-115              | 292  | 84099941 | 28% |
| 1120645 | Eicher Tractor Hose Clamp A80                | 31   | 73269099 | 18% |
| 1120657 | Eicher Tractor Starting Cam                  | 103  | 84099941 | 28% |
| 1120670 | Eicher Tractor Circlip 160X4                 | 221  | 73182910 | 18% |
| 1120682 | Eicher Tractor Circlip B 62X2                | 31   | 73182910 | 18% |
| 1120694 | Eicher Tractor Circlip Light B-40            | 12   | 73182910 | 18% |
| 1120750 | Eicher Tractor Deflector Assy                | 200  | 84099990 | 28% |
| 1120761 | Eicher Tractor Spacer Rear                   | 196  | 73182100 | 18% |
| 1120773 | Eicher Tractor Spacer Front                  | 286  | 73182100 | 18% |
| 1120920 | Eicher Tractor Governor Flange 115           | 1242 | 84099941 | 28% |
| 1121017 | Eicher Tractor Cam Shaft Gear                | 2142 | 87084000 | 18% |
| 1121042 | Eicher Tractor Rod Guide                     | 33   | 84099941 | 28% |
| 1121078 | Eicher Tractor Gasket For L.O.F.Pump         | 4    | 68129922 | 18% |
| 1121080 | Eicher Tractor Gasket Pump Base              | 10   | 68129922 | 18% |
| 1121108 | Eicher Tractor Gasket Kit Engine             | 354  | 84841090 | 18% |
| 1121110 | Eicher Tractor Gasket For Control Hsg 115 Nc | 70   | 68129922 | 18% |
| 1121121 | Eicher Tractor Gasket For Lid                | 89   | 45019000 | 12% |
| 1121133 | Eicher Tractor Gasket Exhaust Duct(F)        | 19   | 84841010 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1121145 | Eicher Tractor Gasket For O.F.Pot               | 11   | 68129922 | 18% |
| 1121157 | Eicher Tractor Gasket For Protection Sleeve     | 13   | 45019000 | 12% |
| 1121169 | Eicher Tractor Gasket For Brg Flange            | 8    | 68129922 | 18% |
| 1121170 | Eicher Tractor Gasket For Carter Face           | 5    | 84099941 | 28% |
| 1121182 | Eicher Tractor Gasket Brg Cover-115             | 20   | 68129922 | 18% |
| 1121194 | Eicher Tractor Gasket Brg. Hsg.                 | 79   | 68129922 | 18% |
| 1121200 | Eicher Tractor Gasket For Inspection Cover      | 95   | 45039090 | 18% |
| 1121285 | Eicher Tractor Rocker Arm Hsg. M/C              | 2136 | 84099941 | 28% |
| 1121297 | Eicher Tractor Bearing Housing                  | 1200 | 84099941 | 28% |
| 1121339 | Eicher Tractor Hook For Cool Panel              | 18   | 84099941 | 28% |
| 1121340 | Eicher Tractor Hose For Protection Sleeve(115)  | 144  | 40093100 | 18% |
| 1121455 | Eicher Tractor Woodruff Key 5X9                 | 15   | 73182990 | 18% |
| 1121467 | Eicher Tractor Parallel Key 8X7X15              | 16   | 73182990 | 18% |
| 1121479 | Eicher Tractor Woodruff Key 4X5                 | 11   | 73182990 | 18% |
| 1121595 | Eicher Tractor Control Rod Assy.                | 24   | 84099941 | 28% |
| 1121649 | Eicher Tractor Lock Plate                       | 11   | 84099941 | 28% |
| 1121698 | Eicher Tractor Hex Thin Nut M22X1.5,B8,Bp,      | 47   | 84099941 | 28% |
| 1121728 | Eicher Tractor Fly Wheel Nut                    | 431  | 84099941 | 28% |
| 1121730 | Eicher Tractor Nylock Nut M16X2                 | 33   | 73181600 | 18% |
| 1121741 | Eicher Tractor Special Nut                      | 77   | 73181500 | 18% |
| 1121753 | Eicher Tractor Threaded Eye                     | 13   | 84099941 | 28% |
| 1121777 | Eicher Tractor O Ring 9X2                       | 3    | 40169990 | 18% |
| 1121789 | Eicher Tractor O'Ring 12X2                      | 3    | 40169990 | 18% |
| 1121790 | Eicher Tractor Washer Dipstick                  | 3    | 73182100 | 18% |
| 1121807 | Eicher Tractor O Ring 17X3                      | 4    | 84099941 | 28% |
| 1121819 | Eicher Tractor O Ring 123X2.5                   | 34   | 40169320 | 18% |
| 1121870 | Eicher Tractor Rocker Shaft                     | 161  | 84099941 | 28% |
| 1121881 | Eicher Tractor Slide Pin                        | 33   | 84129090 | 18% |
| 1121893 | Eicher Tractor Thrust Pin                       | 33   | 73182100 | 18% |
| 1121900 | Eicher Tractor Spring Dowel Sleeve Heavy 4X20-F | 13   | 73182990 | 18% |
| 1121911 | Eicher Tractor Spring Dowel Sleeve Light 4X36,  | 12   | 40169990 | 18% |
| 1121923 | Eicher Tractor Spring Dowel Sleeve Heavy 6X50   | 16   | 73182100 | 18% |
| 1122320 | Eicher Tractor Con Rod W/Bush                   | 2463 | 84099941 | 28% |
| 1122370 | Eicher Tractor Felt Ring For Bearing Cover      | 50   | 84099941 | 28% |
| 1122423 | Eicher Tractor Piston Ring Set                  | 802  | 84099913 | 28% |
| 1122460 | Eicher Tractor Ring Nut M75                     | 335  | 84091000 | 28% |
| 1122563 | Eicher Tractor Rubber Boot (Mico)               | 13   | 40169320 | 18% |
| 1122575 | Eicher Tractor Dust Cap(Protection Cap)         | 8    | 40169320 | 18% |
| 1122630 | Eicher Tractor Spl. Hex Bolt                    | 23   | 73181500 | 18% |
| 1122654 | Eicher Tractor Governor Setting Bolt            | 30   | 73181500 | 18% |
| 1122666 | Eicher Tractor Spl. Bolt For R.A                | 22   | 73181500 | 18% |
| 1122721 | Eicher Tractor Governor Sleeve 115              | 589  | 84099941 | 28% |
| 1122745 | Eicher Tractor Protection Sleeve (Hs & Es)      | 571  | 84099990 | 28% |
| 1122757 | Eicher Tractor Shim F Gov. Shaft. 15 Mm         | 2    | 73182100 | 18% |
| 1122769 | Eicher Tractor Shim 0.20Mm                      | 2    | 73182100 | 18% |
| 1122800 | Eicher Tractor Shim F Cyl 3M                    | 17   | 73182100 | 18% |
| 1122850 | Eicher Tractor Shim F Drvg. Jaw                 | 5    | 73182100 | 18% |





|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1122885 | Eicher Tractor Guide Pin                     | 91   | 73181600 | 18% |
| 1122940 | Eicher Tractor Suction Screen                | 191  | 84099990 | 28% |
| 1122952 | Eicher Tractor Strip For Cool Panel          | 5    | 73011000 | 18% |
| 1122976 | Eicher Tractor Stopper                       | 19   | 84099941 | 28% |
| 1123026 | Eicher Tractor Oil Seal 40X60X13             | 60   | 40169990 | 18% |
| 1123051 | Eicher Tractor Pressure Spring               | 4    | 73202000 | 18% |
| 1123075 | Eicher Tractor Spring (Decompression)        | 4    | 73209090 | 18% |
| 1123087 | Eicher Tractor Spring (For Support Plate)    | 5    | 73209090 | 18% |
| 1123105 | Eicher Tractor Tension Spring                | 12   | 73202000 | 18% |
| 1123117 | Eicher Tractor Valve Spring Inner            | 66   | 73202000 | 18% |
| 1123129 | Eicher Tractor Valve Spring Outer-115 Auto   | 157  | 73202000 | 18% |
| 1123180 | Eicher Tractor Shim F Gov.Shaft.2Mm          | 2    | 73182100 | 18% |
| 1123191 | Eicher Tractor Shim F Gov.Shaft.5Mm          | 2    | 73182100 | 18% |
| 1123208 | Eicher Tractor Shim F Gov.Shaft 1.0Mm        | 3    | 73182100 | 18% |
| 1123210 | Eicher Tractor Shim Gov.Shaft 1.5Mm          | 3    | 73182100 | 18% |
| 1123221 | Eicher Tractor Shim Gov.Shaft 2 Mm           | 3    | 73182100 | 18% |
| 1123269 | Eicher Tractor Shim For Blower 1.21 Mm       | 25   | 73182100 | 18% |
| 1123270 | Eicher Tractor Shim For Blower 1.016         | 5    | 73182100 | 18% |
| 1123294 | Eicher Tractor Breather Valve                | 10   | 73011000 | 18% |
| 1123324 | Eicher Tractor Washer 38 Dia                 | 15   | 73182100 | 18% |
| 1123348 | Eicher Tractor Governor Weight(Auto/ Jbm)    | 234  | 84099941 | 28% |
| 1123427 | Eicher Tractor Gasket For Hour Meter         | 5    | 90292020 | 18% |
| 1123452 | Eicher Tractor Gasket Inlet                  | 6    | 68129922 | 18% |
| 1123567 | Eicher Tractor Diamond Pin                   | 31   | 84099941 | 28% |
| 1123579 | Eicher Tractor Cylindrical Pin 10*20         | 19   | 84099941 | 28% |
| 1123592 | Eicher Tractor Lof Pump Modf.                | 2373 | 84099941 | 28% |
| 1123609 | Eicher Tractor Support Tube                  | 844  | 84099941 | 28% |
| 1123610 | Eicher Tractor Outer Ring                    | 202  | 84099941 | 28% |
| 1123622 | Eicher Tractor Inner Ring                    | 163  | 84099941 | 28% |
| 1123671 | Eicher Tractor Inserts                       | 9    | 84099941 | 28% |
| 1123719 | Eicher Tractor Governor Shaft                | 118  | 84099941 | 28% |
| 1123751 | Eicher Tractor Valve Exhaust (Af)            | 221  | 84099941 | 28% |
| 1123763 | Eicher Tractor Valve Inlet (Af)              | 239  | 84099941 | 28% |
| 1123770 | Eicher Tractor Valve Spring Retainer Old-115 | 105  | 73202000 | 18% |
| 1123841 | Eicher Tractor Governor Fork 115             | 615  | 84099941 | 28% |
| 1124377 | Eicher Tractor Blower Shaft (Mod)            | 494  | 84099941 | 28% |
| 1124389 | Eicher Tractor Spacer For Blower             | 26   | 73182100 | 18% |
| 1124717 | Eicher Tractor Shim F Drgv. Jaw .4 Mm        | 5    | 73182100 | 18% |
| 1124729 | Eicher Tractor Shim F Drgv. Jaw 0.60 Mm      | 4    | 73182100 | 18% |
| 1124730 | Eicher Tractor Shim F Drgv. Jaw .5 Mm        | 5    | 73182100 | 18% |
| 1125035 | Eicher Tractor O-Ring 7.3X2.4Mm(Gov Shaft)   | 18   | 40169320 | 18% |
| 1125151 | Eicher Tractor Cooling Impellor-115          | 608  | 84099941 | 28% |
| 1125205 | Eicher Tractor Lower Impeller Hsg. 115       | 311  | 84099941 | 28% |
| 1125552 | Eicher Tractor Nylon Washer                  | 4    | 87089900 | 18% |
| 1125590 | Eicher Tractor Oil Filter Element            | 69   | 84219900 | 18% |
| 1125606 | Eicher Tractor Gasket O.F.Head               | 7    | 68129922 | 18% |
| 1125607 | Eicher Tractor Gasket For O F Head           | 12   | 68129922 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1125644 | Eicher Tractor Spring For O.F.Hd                 | 7    | 73202000 | 18% |
| 1125801 | Eicher Tractor Strip For Tappet                  | 64   | 84099941 | 28% |
| 1125813 | Eicher Tractor Clamp For Choke Wire              | 8    | 73011000 | 18% |
| 1126740 | Eicher Tractor Blower Assy                       | 4289 | 84099941 | 28% |
| 1127457 | Eicher Tractor By Pass Valve Cap                 | 48   | 84099941 | 28% |
| 1127482 | Eicher Tractor Piston Small                      | 12   | 84129090 | 18% |
| 1127494 | Eicher Tractor Cap                               | 137  | 84099941 | 28% |
| 1127676 | Eicher Tractor Bearing Thin Walled (For Rod)     | 175  | 84822090 | 18% |
| 1127860 | Eicher Tractor Spring Bypass Valve               | 7    | 73209090 | 18% |
| 1128139 | Eicher Tractor Adopter-115                       | 297  | 84099941 | 28% |
| 1128152 | Eicher Tractor Oil Tube                          | 67   | 84099941 | 28% |
| 1128164 | Eicher Tractor Special Plug                      | 22   | 84129090 | 18% |
| 1128188 | Eicher Tractor O F Pot                           | 438  | 84099941 | 28% |
| 1128437 | Eicher Tractor Gear Ring                         | 2384 | 84835090 | 18% |
| 1128577 | Eicher Tractor Hook Bolt                         | 25   | 73181500 | 18% |
| 1128670 | Eicher Tractor Spacer                            | 97   | 73182100 | 18% |
| 1128838 | Eicher Tractor Thin Walled Bearing (For Cap)     | 177  | 84825011 | 18% |
| 1128840 | Eicher Tractor Gasket For Oil Filter Pot         | 11   | 45049000 | 18% |
| 1128917 | Eicher Tractor Pin Piston (Gudgen)               | 501  | 84099112 | 28% |
| 1128991 | Eicher Tractor Adjusting Screw                   | 44   | 73181500 | 18% |
| 1129041 | Eicher Tractor O Ring 16X3                       | 32   | 40169320 | 18% |
| 1129077 | Eicher Tractor Rocker Arm Exhaust Assly(Hs / Es) | 487  | 84099941 | 28% |
| 1129107 | Eicher Tractor Spring Disc Mod.                  | 90   | 73209090 | 18% |
| 1129119 | Eicher Tractor Spring Plate (Mod)                | 108  | 84099941 | 28% |
| 1129156 | Eicher Tractor Spring Hsg.-115                   | 399  | 84099941 | 28% |
| 1129272 | Eicher Tractor Pump Driving Gear                 | 1497 | 87084000 | 18% |
| 1129284 | Eicher Tractor Cylinder Assy                     | 8972 | 84099941 | 28% |
| 1129296 | Eicher Tractor Nozzle                            | 47   | 84129090 | 18% |
| 1140322 | Eicher Tractor Bush F Rigid Axle                 | 302  | 87085000 | 18% |
| 1140450 | Eicher Tractor Spring Dowel Sleeve 6X32          | 13   | 73182100 | 18% |
| 1140553 | Eicher Tractor Uncoupling Fork                   | 400  | 87084000 | 18% |
| 1140899 | Eicher Tractor Linch Pin                         | 75   | 73182100 | 18% |
| 1141120 | Eicher Tractor Driver Seat Spring                | 113  | 94012000 | 18% |
| 1141510 | Eicher Tractor Tooth Selector Complete           | 306  | 87089400 | 18% |
| 1141715 | Eicher Tractor Rubber Ring 0.5Mm                 | 20   | 84099941 | 28% |
| 1141820 | Eicher Tractor Release Lever Plate               | 293  | 87089900 | 18% |
| 1141843 | Eicher Tractor Retainer Wire                     | 15   | 87089900 | 18% |
| 1141867 | Eicher Tractor Thrust Spring                     | 59   | 87084000 | 18% |
| 1141879 | Eicher Tractor Strut                             | 13   | 87089400 | 18% |
| 1141880 | Eicher Tractor R.L. Pin                          | 14   | 73182100 | 18% |
| 1141892 | Eicher Tractor Pressure Plate                    | 1639 | 87089900 | 18% |
| 1141909 | Eicher Tractor Spring                            | 15   | 73209090 | 18% |
| 1141910 | Eicher Tractor Eye Bolt                          | 58   | 73181500 | 18% |
| 1141922 | Eicher Tractor Release Lever                     | 72   | 87089900 | 18% |
| 1141934 | Eicher Tractor Eye Bolt Nut                      | 16   | 73181500 | 18% |
| 1141983 | Eicher Tractor Knob F Hand Bk Lvr                | 29   | 87083000 | 18% |
| 1141995 | Eicher Tractor Compr. Spring                     | 10   | 73202000 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1142331 | Eicher Tractor Cover Ful Filter              | 861  | 84219900 | 18% |
| 1142483 | Eicher Tractor Rubber Boot Ftr/DI            | 29   | 40169320 | 18% |
| 1142720 | Eicher Tractor Tie Rod End -Right (Bsw)      | 584  | 87089400 | 18% |
| 1142732 | Eicher Tractor Tie Rod End Left (Bsw)        | 552  | 87089400 | 18% |
| 1150248 | Eicher Tractor Bush F Brk Hand Pin           | 24   | 87089900 | 18% |
| 1150297 | Eicher Tractor Taper Roller Bearing 32207A   | 549  | 84822090 | 18% |
| 1150303 | Eicher Tractor Taper Roller Bearing 30305A   | 405  | 84822011 | 18% |
| 1150327 | Eicher Tractor Ball Bearing 6208N            | 533  | 84821011 | 18% |
| 1150431 | Eicher Tractor Circlip Light A-25(F)         | 11   | 73182910 | 18% |
| 1150443 | Eicher Tractor Circlip Light A-20            | 10   | 73182910 | 18% |
| 1150492 | Eicher Tractor Hose Clamp A60                | 24   | 73269099 | 18% |
| 1150571 | Eicher Tractor Cover Stub Axle               | 39   | 87085000 | 18% |
| 1150807 | Eicher Tractor Disc.Assy.                    | 76   | 87089300 | 18% |
| 1150960 | Eicher Tractor Fuel Duct Assly (Ff To Fp)    | 276  | 40092200 | 18% |
| 1151060 | Eicher Tractor Gasket For G.B.Hsg.           | 56   | 68129090 | 18% |
| 1151071 | Eicher Tractor Gasket For Hub Cap            | 12   | 68129090 | 18% |
| 1151216 | Eicher Tractor Air Inlet Hose                | 150  | 40093100 | 18% |
| 1151289 | Eicher Tractor Woodruff Key 13X8             | 27   | 73182100 | 18% |
| 1151319 | Eicher Tractor Accelerator Lever             | 314  | 87085000 | 18% |
| 1151356 | Eicher Tractor Hand Brake Lever Finish       | 733  | 87083000 | 18% |
| 1151502 | Eicher Tractor O Ring 59.2X5.7               | 14   | 40169320 | 18% |
| 1151514 | Eicher Tractor O Ring 40.2X3                 | 11   | 40169340 | 18% |
| 1151551 | Eicher Tractor Cushioning Pad                | 30   | 40169990 | 18% |
| 1151733 | Eicher Tractor Oil Pressure Guage            | 512  | 90262000 | 18% |
| 1151769 | Eicher Tractor Pin For Bonnet Assy           | 15   | 87089900 | 18% |
| 1151915 | Eicher Tractor Emblem (Stg.Wheel Cap)        | 19   | 39199090 | 18% |
| 1152154 | Eicher Tractor Groove Nut 40X1.5 Rh          | 93   | 73181500 | 18% |
| 1152403 | Eicher Tractor Stopper Plate                 | 20   | 87084000 | 18% |
| 1152490 | Eicher Tractor Aluminium Strip Front-Bonnet  | 401  | 87081010 | 18% |
| 1152610 | Eicher Tractor Banjo Union Bolt 6 (M10X1),Zp | 40   | 73181500 | 18% |
| 1152646 | Eicher Tractor Form Spring For Graphite Ring | 6    | 73202000 | 18% |
| 1153134 | Eicher Tractor Rear Wheel Weight             | 5776 | 87087000 | 18% |
| 1153183 | Eicher Tractor Cup Spring                    | 18   | 73202000 | 18% |
| 1153195 | Eicher Tractor Washer Fuel Tank Cap          | 13   | 73182100 | 18% |
| 1153201 | Eicher Tractor Locking Washer                | 24   | 73182100 | 18% |
| 1153225 | Eicher Tractor Washer 05.731.5               | 14   | 73182100 | 18% |
| 1153523 | Eicher Tractor High Pressure Hose Assly      | 853  | 40093100 | 18% |
| 1153596 | Eicher Tractor Element Primary F.F.          | 111  | 84212300 | 18% |
| 1153602 | Eicher Tractor Element Secondary F.F.        | 113  | 84212300 | 18% |
| 1154990 | Eicher Tractor Lock Plate                    | 4    | 87084000 | 18% |
| 1155374 | Eicher Tractor Ornamental Section            | 285  | 76169990 | 18% |
| 1155428 | Eicher Tractor Driven Disc 9-1/4"            | 893  | 87089300 | 18% |
| 1157279 | Eicher Tractor Hylem Bush Flftg Gr           | 38   | 87089900 | 18% |
| 1158466 | Eicher Tractor Pin For Hand Brk Lvr.         | 66   | 73182100 | 18% |
| 1158508 | Eicher Tractor Hand Accelerator Lever Assy.  | 353  | 87089900 | 18% |
| 1158600 | Eicher Tractor Special Bolt 14X35 W/Hole     | 33   | 73181500 | 18% |
| 1158703 | Eicher Tractor Circlip Light A-10            | 3    | 73182910 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1159628 | Eicher Tractor Stud M16X70.5,A8.8,Bp,              | 61   | 73182100 | 18% |
| 1159770 | Eicher Tractor Clutch Cover Assy 9-1/4"            | 3188 | 87089300 | 18% |
| 1160011 | Eicher Tractor Hshc Screw M8X20,B12.9,Bp           | 13   | 73181500 | 18% |
| 1160023 | Eicher Tractor Hshc Screw M8X25,B12.9,Bp           | 14   | 73181500 | 18% |
| 1160047 | Eicher Tractor Hshc Screw M10X40,B12.9,Bp,         | 23   | 73181500 | 18% |
| 1160059 | Eicher Tractor Hshc Screw M8X35,B12.9,Bp           | 16   | 73181500 | 18% |
| 1160060 | Eicher Tractor Hshc Screw M10X35B12.9,Bp,(F)       | 19   | 73181500 | 18% |
| 1160072 | Eicher Tractor Hshc Screw M8X30,B10.9,Zp           | 16   | 73181500 | 18% |
| 1160102 | Eicher Tractor Hshc Screw M10X50,B12.9,Bp(Is 2269- | 28   | 73181500 | 18% |
| 1160114 | Eicher Tractor Hshc Screw M6X25,B12.9,Bp           | 13   | 73181500 | 18% |
| 1160126 | Eicher Tractor Hshc Screw M6X12,B12.9,Bp           | 13   | 73181500 | 18% |
| 1160140 | Eicher Tractor Hex Socket Grub Screw M8*25,B10.9,  | 40   | 73181500 | 18% |
| 1160151 | Eicher Tractor Hshc Screw M5X30,B12.9,Bp,          | 13   | 73181500 | 18% |
| 1160205 | Eicher Tractor Hex Head Screw M6*25                | 5    | 73181500 | 18% |
| 1160217 | Eicher Tractor Hex Screw M5X16, B8.8, Zn           | 3    | 73181500 | 18% |
| 1160229 | Eicher Tractor Hex Head Screw M6*30                | 5    | 73181500 | 18% |
| 1160245 | Eicher Tractor Bolt M8X35 - A/C Mounting Clamp     | 23   | 73181500 | 18% |
| 1160254 | Eicher Tractor Hex Bolt M8X35                      | 9    | 73181500 | 18% |
| 1160280 | Eicher Tractor Hex Bolt M8X50,B8.8,Bp,             | 14   | 73181500 | 18% |
| 1160351 | Eicher Tractor Hshc Screw M10X35.B12.9,Bp,         | 15   | 73181500 | 18% |
| 1160357 | Eicher Tractor Hshc Screw M10X35,B12.9,Bp,         | 17   | 73181500 | 18% |
| 1160369 | Eicher Tractor Hex Bolt M10X40,B8.8,Bp,            | 16   | 73181500 | 18% |
| 1160370 | Eicher Tractor Hex Bolt M10X45                     | 18   | 73181500 | 18% |
| 1160382 | Eicher Tractor Hex Bolt 10X50                      | 19   | 73181500 | 18% |
| 1160400 | Eicher Tractor Hex Bolt 10X65                      | 21   | 73181500 | 18% |
| 1160497 | Eicher Tractor Hex Screw M12X50,B8.8.Bp.           | 22   | 73181500 | 18% |
| 1160503 | Eicher Tractor Hex Bolt M12X1.5X60,B8.8,Yp,        | 21   | 73181500 | 18% |
| 1160515 | Eicher Tractor Hex Bolt M12X110,B8.8,Bp,           | 45   | 73181500 | 18% |
| 1160540 | Eicher Tractor Hex Bolt M12X50,B8.8,Zp,            | 18   | 73181500 | 18% |
| 1160620 | Eicher Tractor Hex Bolt M16*45                     | 50   | 73181500 | 18% |
| 1160631 | Eicher Tractor Hex Bolt M16X55                     | 35   | 73181500 | 18% |
| 1160643 | Eicher Tractor Hex Bolt M16X1.5X100,B8.8,Bp        | 77   | 73181500 | 18% |
| 1160710 | Eicher Tractor Hex Bolt M10X70,B8.8,Zp,            | 19   | 73181500 | 18% |
| 1160722 | Eicher Tractor Hex Screw M4X20,B8.8,Bp,            | 11   | 73181500 | 18% |
| 1160734 | Eicher Tractor Hex Screw M12X40,B8.8,Zpw,          | 23   | 73181500 | 18% |
| 1160746 | Eicher Tractor Hex Bolt M12X55,B8.8,Zp,            | 22   | 73181500 | 18% |
| 1160771 | Eicher Tractor Hex Screw 6X12                      | 4    | 73181500 | 18% |
| 1160783 | Eicher Tractor Hex Screw M6X15                     | 5    | 73181500 | 18% |
| 1160801 | Eicher Tractor Hex Screw M6X20                     | 4    | 73181500 | 18% |
| 1160837 | Eicher Tractor Hex Screw M8X16,B8.8,Bp,            | 7    | 73181500 | 18% |
| 1160849 | Eicher Tractor Hex Screw M8X18,Bp,B8.8,            | 9    | 73181500 | 18% |
| 1160862 | Eicher Tractor Hex Screw M8X20,B8.8,Bp,            | 12   | 73181500 | 18% |
| 1160886 | Eicher Tractor Hex Screw M8X25,B8.8,Bp,(F)         | 7    | 73181500 | 18% |
| 1160904 | Eicher Tractor Hex Screw M8*30                     | 7    | 73181500 | 18% |
| 1160953 | Eicher Tractor Hex Screw M10X16                    | 12   | 73181500 | 18% |
| 1160965 | Eicher Tractor Hex Screw M10X20,B8.8,Bp,           | 12   | 73181500 | 18% |
| 1160977 | Eicher Tractor Hex Screw M10X25                    | 14   | 73181500 | 18% |



|         |  |    |          |     |
|---------|--|----|----------|-----|
| 1161027 | Eicher Tractor Hex Screw M8X25,B8.8,Zpw            | 11 | 73181500 | 18% |
| 1161039 | Eicher Tractor Hex Screw M8X80,B8.8,Bp,            | 9  | 73181500 | 18% |
| 1161076 | Eicher Tractor Hex Screw M5X12,B8.8,Zp,            | 5  | 73181500 | 18% |
| 1161088 | Eicher Tractor Hex Screw M6X16,B8.8,Zp,            | 5  | 73181500 | 18% |
| 1161167 | Eicher Tractor Hex Screw M16X35                    | 33 | 73181500 | 18% |
| 1161246 | Eicher Tractor Hex Nut M5,B8,Zp,(Is 1364-1992 )    | 3  | 73181500 | 18% |
| 1161260 | Eicher Tractor Hex Screw M6X25,B8.8,Zp,            | 6  | 73181500 | 18% |
| 1161271 | Eicher Tractor Hex Screw M12X30,B8.8,Zp,           | 18 | 73181500 | 18% |
| 1161349 | Eicher Tractor Square Head Bolt M6*25,Zp,          | 5  | 73181500 | 18% |
| 1161350 | Eicher Tractor Hex Thin Nut M12,B8,Zp,             | 12 | 73181500 | 18% |
| 1161398 | Eicher Tractor Hex Lock Nut M8                     | 12 | 73181500 | 18% |
| 1161441 | Eicher Tractor Hex Nut M6,B8,Bp,                   | 5  | 84099941 | 28% |
| 1161453 | Eicher Tractor Hex Nut M8                          | 5  | 73181600 | 18% |
| 1161465 | Eicher Tractor Hex Nut M10,B8,Bp,                  | 12 | 84099941 | 28% |
| 1161477 | Eicher Tractor Hex Nut M12,B8,Bp,                  | 14 | 84099941 | 28% |
| 1161490 | Eicher Tractor Hex Nut M16X2,B8,Bp,                | 24 | 84099941 | 28% |
| 1161544 | Eicher Tractor Hex Nut M14X1.5                     | 19 | 84099941 | 28% |
| 1161575 | Eicher Tractor Stud M10X45                         | 19 | 73182100 | 18% |
| 1161581 | Eicher Tractor Nylock Nut Am6X1.0X6X10 A/F         | 5  | 73181500 | 18% |
| 1161623 | Eicher Tractor Nylock Nut M18X1.5                  | 47 | 73181500 | 18% |
| 1161672 | Eicher Tractor Grease Nipple Am8X1                 | 13 | 73181500 | 18% |
| 1161684 | Eicher Tractor Grease Nipple Am10X1                | 13 | 73181500 | 18% |
| 1161696 | Eicher Tractor Grease Nipple-A8                    | 12 | 84099941 | 28% |
| 1161714 | Eicher Tractor Hex Nut M6,B8,Zp,                   | 4  | 87089900 | 18% |
| 1161726 | Eicher Tractor Hex Nut M8,B8,Zp,                   | 6  | 73181500 | 18% |
| 1161751 | Eicher Tractor Hex Nut M10,B8,Zp,(Is 1364-1982)    | 10 | 73181500 | 18% |
| 1161763 | Eicher Tractor Hex Nut M12,B8,Zp,                  | 13 | 73181500 | 18% |
| 1161787 | Eicher Tractor Split Pin 1.6 X 10                  | 2  | 73182100 | 18% |
| 1161799 | Eicher Tractor Split Pin 2X16                      | 2  | 73182100 | 18% |
| 1161817 | Eicher Tractor Split Pin 2X25                      | 2  | 73182100 | 18% |
| 1161829 | Eicher Tractor Split Pin 2X20                      | 2  | 73182100 | 18% |
| 1161878 | Eicher Tractor Split Pin 3.2X25                    | 6  | 73182100 | 18% |
| 1162135 | Eicher Tractor Alu. Rivet 4X8Mm                    | 2  | 73182100 | 18% |
| 1162159 | Eicher Tractor Aluminium Rivit                     | 2  | 76161000 | 18% |
| 1162408 | Eicher Tractor Cheese Head Screw M8X15             | 11 | 73181500 | 18% |
| 1162500 | Eicher Tractor Cross Recessed Pan Hd.Screw M6X25-B | 13 | 73181500 | 18% |
| 1162548 | Eicher Tractor Sealing Washer 6X10                 | 6  | 73182990 | 18% |
| 1162550 | Eicher Tractor Sealing Washer 8X14                 | 7  | 73182990 | 18% |
| 1162561 | Eicher Tractor Sealing Washer 10X14 Is-3175-1974   | 4  | 73182990 | 18% |
| 1162573 | Eicher Tractor Sealing Washer 12X16 Is-3175-1974   | 13 | 73182990 | 18% |
| 1162585 | Eicher Tractor Sealing Washer 12X18 (Cu)           | 7  | 73182990 | 18% |
| 1162597 | Eicher Tractor Sealing Washer 14X18 Is-3175-1974   | 9  | 73182990 | 18% |
| 1162603 | Eicher Tractor Sealing Washer 14X20                | 12 | 73182990 | 18% |
| 1162652 | Eicher Tractor Sealing Washer 18X24,Cu (Is:3175)   | 16 | 73182990 | 18% |
| 1162664 | Eicher Tractor Sealing Washer 20*26 (398)          | 10 | 73182990 | 18% |
| 1162690 | Eicher Tractor Sealing Washer 18X22 Is-3175-1974   | 13 | 73182990 | 18% |
| 1162718 | Eicher Tractor Sealing Washer 24X30                | 11 | 73182990 | 18% |



|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 1162731 | Eicher Tractor Sealing Washer Cu Is:1375 , Dia 22X | 17  | 73182990 | 18% |
| 1162743 | Eicher Tractor Sealing Washer 30X36                | 23  | 73182990 | 18% |
| 1162822 | Eicher Tractor M/Cd Washer 5.3 Dia                 | 6   | 73182100 | 18% |
| 1162846 | Eicher Tractor Machined Washer 6.4                 | 9   | 73182100 | 18% |
| 1162858 | Eicher Tractor Plain Washer 8.4                    | 3   | 73182100 | 18% |
| 1162895 | Eicher Tractor Mcd Washer 10.5                     | 4   | 73182100 | 18% |
| 1162925 | Eicher Tractor Plain Washer 13 Mm                  | 5   | 73182100 | 18% |
| 1162949 | Eicher Tractor Machined Washer 15                  | 8   | 73182100 | 18% |
| 1162950 | Eicher Tractor Machined Washer 13 St -Zn           | 11  | 73182100 | 18% |
| 1162974 | Eicher Tractor Plain Washer 17 Mm                  | 9   | 73182100 | 18% |
| 1163000 | Eicher Tractor Sealing Washer 8X12                 | 9   | 73182990 | 18% |
| 1163004 | Eicher Tractor Sealing Washer 8X12                 | 5   | 73182990 | 18% |
| 1163012 | Eicher Tractor Spring Washer 'Square'-8            | 2   | 73182990 | 18% |
| 1163024 | Eicher Tractor Lock Washer                         | 13  | 73182100 | 18% |
| 1163085 | Eicher Tractor M/Cd Washer 8.4 Dia                 | 9   | 73182100 | 18% |
| 1163100 | Eicher Tractor Spring Washer 'Square'-6,'Zp',      | 2   | 73182990 | 18% |
| 1163188 | Eicher Tractor Spring Washer A-6 'Flat',Bp,        | 2   | 73182990 | 18% |
| 1163190 | Eicher Tractor Spring Washer A-8 'Flat',Bp,        | 4   | 73182990 | 18% |
| 1163218 | Eicher Tractor Spring Washer A-10 'Flat',Bp,       | 3   | 73182990 | 18% |
| 1163220 | Eicher Tractor Spring Washer A-12 'Flat',Bp,       | 4   | 73182990 | 18% |
| 1163231 | Eicher Tractor Spring Washer A-14 'Flat',Bp,       | 8   | 73182990 | 18% |
| 1163243 | Eicher Tractor Spring Washer A-16 'Flat',Bp,       | 9   | 73182990 | 18% |
| 1163280 | Eicher Tractor Spring Washer A-8 'Flat',Zp,        | 1   | 73182990 | 18% |
| 1163309 | Eicher Tractor Alu. Washer M6X18                   | 6   | 76169990 | 18% |
| 1163310 | Eicher Tractor Spring Washer A-12 'Flat',Zpw,      | 5   | 73182990 | 18% |
| 1163437 | Eicher Tractor Spring Washer A-14 'Flat',Zp,       | 6   | 73182990 | 18% |
| 1163504 | Eicher Tractor Heli Coil Insert                    | 15  | 73182990 | 18% |
| 1163632 | Eicher Tractor Hex Nylock Nut M8 Din 980 M8 Zne    | 13  | 73181500 | 18% |
| 1163656 | Eicher Tractor Hex Nut M18X2.5,B8,Zp,              | 54  | 73181500 | 18% |
| 1163668 | Eicher Tractor Oil Seal 65X90X13                   | 123 | 40169990 | 18% |
| 1163670 | Eicher Tractor Hex Screw M8*10,8.8,Bp,             | 7   | 73181500 | 18% |
| 1163681 | Eicher Tractor Hex Screw M10X25,B8.8,Zpw,(Is 1364- | 13  | 73181500 | 18% |
| 1163747 | Eicher Tractor Grooved Nut 45X1.5                  | 112 | 73181500 | 18% |
| 1163760 | Eicher Tractor Circlip Light A-45                  | 14  | 73182910 | 18% |
| 1163784 | Eicher Tractor Circlip Light A-55                  | 24  | 73182910 | 18% |
| 1163802 | Eicher Tractor Circlip A8                          | 3   | 73182910 | 18% |
| 1163814 | Eicher Tractor Circlip Light A-12                  | 5   | 73182910 | 18% |
| 1163826 | Eicher Tractor Circlip Heavy A-30                  | 15  | 73182910 | 18% |
| 1163838 | Eicher Tractor Circlip Light A-80                  | 64  | 73182910 | 18% |
| 1163840 | Eicher Tractor Circlip Light A-14                  | 5   | 73182910 | 18% |
| 1163851 | Eicher Tractor Circlip A-17                        | 5   | 73182910 | 18% |
| 1163917 | Eicher Tractor Circlip B-90                        | 57  | 73182910 | 18% |
| 1163929 | Eicher Tractor Circlip B-110                       | 85  | 73182910 | 18% |
| 1163966 | Eicher Tractor Circlip Light B-140                 | 138 | 73182910 | 18% |
| 1163978 | Eicher Tractor Circlip Light B-42                  | 13  | 73182910 | 18% |
| 1163980 | Eicher Tractor Circlip Light B-35                  | 12  | 73182910 | 18% |
| 1163991 | Eicher Tractor Circlip Light B-47(F)               | 14  | 73182910 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1164004 | Eicher Tractor Lock Ring Sp-90                     | 29   | 73182990 | 18% |
| 1164016 | Eicher Tractor Snap Ring Sp110                     | 44   | 73182990 | 18% |
| 1164077 | Eicher Tractor Spg Washer 12                       | 5    | 73182990 | 18% |
| 1164107 | Eicher Tractor Hex Thin Nut M10X1.25,Rh,B8,Zp(Whit | 18   | 73181500 | 18% |
| 1164119 | Eicher Tractor Hex Lock Nut M6                     | 6    | 73181500 | 18% |
| 1164132 | Eicher Tractor Snap Ring Sp-80                     | 27   | 73182990 | 18% |
| 1164200 | Eicher Tractor Hshc Screw M6X16,B12.9,Zp           | 12   | 73181500 | 18% |
| 1164247 | Eicher Tractor Hshc Screw M10X25,B12.9,Zpw,        | 19   | 73181500 | 18% |
| 1164261 | Eicher Tractor Hshc Screw M12X1.5X65,B12.9,Bp,     | 55   | 73181500 | 18% |
| 1164284 | Eicher Tractor Hex Screw M8X35,B8.8,Zp             | 12   | 73181500 | 18% |
| 1164326 | Eicher Tractor Grub Screw M6X16                    | 18   | 73181500 | 18% |
| 1164338 | Eicher Tractor Hshc Screw M8X55,B12.9,Bp           | 25   | 73181500 | 18% |
| 1164375 | Eicher Tractor Banjo Bolt M12*1.5                  | 33   | 73181500 | 18% |
| 1164399 | Eicher Tractor Pipe Union Bolt-5, (M8X1)           | 18   | 73181500 | 18% |
| 1164405 | Eicher Tractor Hex Bolt M16X1.5X140,B8.8,Bp,Is1364 | 78   | 73181500 | 18% |
| 1164466 | Eicher Tractor Pipe Union Bolt-15,(M18*1.5)        | 112  | 73181500 | 18% |
| 1164510 | Eicher Tractor Hshc Screw M6X20,B12.9,Bp           | 13   | 73181500 | 18% |
| 1164521 | Eicher Tractor Hex Screw M8X12,B8.8.Zp,            | 11   | 73181500 | 18% |
| 1164545 | Eicher Tractor Hex Screw M12X25,B8.8,Bp,           | 3    | 73181500 | 18% |
| 1164570 | Eicher Tractor C.S.Screw M5X12(F)                  | 4    | 73181500 | 18% |
| 1164594 | Eicher Tractor Grooved Nut 55X1.5                  | 183  | 73181500 | 18% |
| 1164636 | Eicher Tractor Hex Bolt M12X90,B8.8-Zn             | 37   | 73181500 | 18% |
| 1164673 | Eicher Tractor Hex Bolt M10X120,B8.8,Zp,           | 43   | 73181500 | 18% |
| 1164740 | Eicher Tractor Hex Nut M8X1,B8,Lb,                 | 5    | 73181600 | 18% |
| 1164752 | Eicher Tractor Sealing Wshr 12X15.5(F)             | 6    | 74091100 | 18% |
| 1164764 | Eicher Tractor Sealing Washer 36X42                | 25   | 73182990 | 18% |
| 1164867 | Eicher Tractor Plain Washer A6 (Y)                 | 1    | 73182100 | 18% |
| 1164880 | Eicher Tractor Hex Screw M12X25,B8.8,Zp,           | 17   | 73181500 | 18% |
| 1164946 | Eicher Tractor Spring Dowel Sleeve Heavy 3X16      | 3    | 73182990 | 18% |
| 1164958 | Eicher Tractor Spg Dowel Sleeve 1.5X10.4           | 3    | 73182910 | 18% |
| 1164971 | Eicher Tractor Spring Dowel Sleeve Heavy 4X16      | 10   | 73182100 | 18% |
| 1165008 | Eicher Tractor Cyl Roller Bearing Nj 309           | 1026 | 84825011 | 18% |
| 1165057 | Eicher Tractor Bearing 313                         | 5263 | 84825011 | 18% |
| 1165070 | Eicher Tractor Bearing 16016-298                   | 1763 | 84821020 | 18% |
| 1165094 | Eicher Tractor Bearing 2203-C3-298                 | 388  | 84821020 | 18% |
| 1165136 | Eicher Tractor Deep Groove Ball Bearing 6208       | 545  | 84821011 | 18% |
| 1165161 | Eicher Tractor Bearing 6005 Rz (F)-115             | 350  | 84821011 | 18% |
| 1165185 | Eicher Tractor Thrust Brg.Fag 51107                | 355  | 84821051 | 18% |
| 1165239 | Eicher Tractor Cyl Pin 6X20                        | 13   | 84129090 | 18% |
| 1165290 | Eicher Tractor Hex Screw M6X40,B8.8,Zp,            | 8    | 73181500 | 18% |
| 1165306 | Eicher Tractor Hex Screw M6X30,B8.8,Zp,            | 8    | 73181500 | 18% |
| 1165331 | Eicher Tractor Spring Washer A-16 'Flat',Zp,       | 9    | 73182990 | 18% |
| 1165380 | Eicher Tractor Spring Dowel Sleeve 2.5X22          | 11   | 73182100 | 18% |
| 1165392 | Eicher Tractor Spring Dowel Sleeve Heavy 6X16      | 14   | 73182990 | 18% |
| 1165409 | Eicher Tractor Spring Dowel Sleeve Heavy 3X24      | 13   | 73182100 | 18% |
| 1165495 | Eicher Tractor Hex Screw M6X12,B8.8,Zp,            | 6    | 73181500 | 18% |
| 1165598 | Eicher Tractor H.Skt Set Screw M10X12-Fp,B12.9,Bp, | 14   | 73181500 | 18% |



|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 1165811 | Eicher Tractor Cylindrical Pin 3X12            | 9   | 84099941 | 28% |
| 1165835 | Eicher Tractor Cyl Pin 4X14                    | 12  | 73182990 | 18% |
| 1165860 | Eicher Tractor Cylindrical Pin 6 X 12          | 13  | 73182990 | 18% |
| 1165914 | Eicher Tractor Hex Screw M18X50,B8.8,Bp,       | 65  | 73181500 | 18% |
| 1165938 | Eicher Tractor Steel Ball 3.175 Dia            | 2   | 84829119 | 18% |
| 1165963 | Eicher Tractor Steel Ball 7 Dia,Grade 3,       | 4   | 84829119 | 18% |
| 1166128 | Eicher Tractor Oil Seal 10X19X7                | 61  | 40169330 | 18% |
| 1166141 | Eicher Tractor Hex Bolt M14X2X95,B8.8,Zp,      | 44  | 73181500 | 18% |
| 1166153 | Eicher Tractor Hex Bolt M10X40,B8.8,Zp,        | 16  | 73181500 | 18% |
| 1166189 | Eicher Tractor O Ring 10X2                     | 8   | 84099941 | 28% |
| 1166530 | Eicher Tractor Parallel Key A-8X7X36           | 23  | 73182990 | 18% |
| 1166542 | Eicher Tractor Parallel Key A-6X6X16           | 15  | 73182100 | 18% |
| 1166657 | Eicher Tractor Woodruff Key 8X11               | 20  | 73182100 | 18% |
| 1166669 | Eicher Tractor Wooruff Key 5X6                 | 15  | 73182990 | 18% |
| 1166670 | Eicher Tractor W/R Key 3X3.7                   | 15  | 73182990 | 18% |
| 1166827 | Eicher Tractor Hex Bolt M20X1.5X55, B10.9,Bp,  | 93  | 73181500 | 18% |
| 1166840 | Eicher Tractor Hose Clip A22                   | 124 | 40093100 | 18% |
| 1166853 | Eicher Tractor Hose Clip 20 Dia                | 18  | 40093100 | 18% |
| 1166864 | Eicher Tractor Hose Clip A 35                  | 42  | 40093100 | 18% |
| 1166891 | Eicher Tractor Grub Screw M8*1                 | 23  | 73181500 | 18% |
| 1166931 | Eicher Tractor Hex Screw M14X30,B8.8,Zp        | 27  | 73181500 | 18% |
| 1166980 | Eicher Tractor Hex Bolt M18X2.5X100,B8.8,Zp,   | 129 | 73181500 | 18% |
| 1167030 | Eicher Tractor Spring Washer 'Square. 10,'Zp', | 3   | 73182990 | 18% |
| 1167078 | Eicher Tractor Multi Tooth Washer B10.5        | 10  | 73182100 | 18% |
| 1167080 | Eicher Tractor Spring Washer 'Square 10, Zpw   | 3   | 73182990 | 18% |
| 1167106 | Eicher Tractor Spring Washer A-5 'Flat',Zp,    | 2   | 73182990 | 18% |
| 1167169 | Eicher Tractor Punched Washer A9-Zpw           | 4   | 73182100 | 18% |
| 1167182 | Eicher Tractor Machined Washer 15-Zp           | 8   | 73182100 | 18% |
| 1167248 | Eicher Tractor Spring Dowel Sleeve 18X18       | 43  | 73182100 | 18% |
| 1167261 | Eicher Tractor Hex Screw M16X2X35,B8.8,Zp,     | 29  | 73181500 | 18% |
| 1167285 | Eicher Tractor Spring Dowel Sleeve Heavy 6X45  | 15  | 73182100 | 18% |
| 1167303 | Eicher Tractor Spring Dowel Sleeve Heavy 8X30  | 15  | 73182100 | 18% |
| 1167455 | Eicher Tractor Split Pin 5X45                  | 12  | 73182100 | 18% |
| 1167480 | Eicher Tractor Split Pin 2.5X32                | 3   | 73182100 | 18% |
| 1167807 | Eicher Tractor Circlip C8                      | 5   | 73182910 | 18% |
| 1167819 | Eicher Tractor Circlip Light A-15              | 5   | 73182910 | 18% |
| 1167820 | Eicher Tractor Circlip Heavy A-34              | 22  | 73182910 | 18% |
| 1167972 | Eicher Tractor Hex Screw M8X60,B8.8-Zp         | 14  | 73181500 | 18% |
| 1168046 | Eicher Tractor Hex Bolt M20X1.5X50,B10.9,Bp,   | 109 | 73181500 | 18% |
| 1168060 | Eicher Tractor D.G.Ball Bearing 6309N          | 999 | 84821011 | 18% |
| 1168228 | Eicher Tractor Spring Dowel Sleeve Heavy 5X24  | 13  | 73182100 | 18% |
| 1168230 | Eicher Tractor Hex Screw M8X30,B8.8,Zp,        | 11  | 73181500 | 18% |
| 1168320 | Eicher Tractor Washer A13,Steel(Is:5370) -Zn   | 10  | 73182100 | 18% |
| 1168400 | Eicher Tractor Hex Bolt M10X80 Grade 10.9,Yp   | 34  | 73181500 | 18% |
| 1168460 | Eicher Tractor Slot Cheese Head Screw M4*12 Zp | 6   | 73181500 | 18% |
| 1168502 | Eicher Tractor Hshc Screw M6X16,B12.9,Bp       | 13  | 73181500 | 18% |
| 1168575 | Eicher Tractor Hshc Screw M8X80,B12.9,Bp       | 28  | 73181500 | 18% |





|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1168587 | Eicher Tractor Hshc Screw M8X40,B12.9,Bp           | 16   | 73181500 | 18% |
| 1168629 | Eicher Tractor Hshc Screw M10X75,B12.9,Bp,         | 31   | 73181500 | 18% |
| 1168680 | Eicher Tractor Hshc Screw M6X50,B12.9,Bp           | 24   | 73181500 | 18% |
| 1168691 | Eicher Tractor Sh Cap Screw M8X50                  | 22   | 73181500 | 18% |
| 1168708 | Eicher Tractor S.H.C.Screw M8*60                   | 28   | 73181500 | 18% |
| 1168964 | Eicher Tractor Hex Bolt M10X75,B8.8,Zp             | 22   | 73181500 | 18% |
| 1169002 | Eicher Tractor Hex Screw M10X30,B8.8,Zpw,Valtra 62 | 16   | 73181500 | 18% |
| 1169014 | Eicher Tractor Hex.Screw M14X2X35, Is:1364(P-2)198 | 32   | 73181500 | 18% |
| 1169130 | Eicher Tractor Hex Screw M8X20,B8.8,Zpw,           | 11   | 73181500 | 18% |
| 1169142 | Eicher Tractor Snap Ring Sp 100 (485)              | 40   | 73182990 | 18% |
| 1169191 | Eicher Tractor H.R.Head Screw Am 6X20-Zp White     | 5    | 73181500 | 18% |
| 1169233 | Eicher Tractor Ball Bearing 6302-2Rs C3            | 295  | 84822090 | 18% |
| 1169350 | Eicher Tractor Ball Bearing 6206                   | 622  | 84822090 | 18% |
| 1169518 | Eicher Tractor Hex Bolt M8X40                      | 11   | 73181500 | 18% |
| 1169520 | Eicher Tractor Hex Bolt M8 X 100,B8.8,Zp,          | 21   | 73181500 | 18% |
| 1170855 | Eicher Tractor Disc                                | 24   | 87089300 | 18% |
| 1172657 | Eicher Tractor Shim                                | 16   | 73182100 | 18% |
| 1180370 | Eicher Tractor Instruction Plate (Stat)            | 15   | 84099941 | 28% |
| 1180915 | Eicher Tractor Spindle (Stat)                      | 286  | 84129090 | 18% |
| 1180927 | Eicher Tractor Gasket For Idler Pully(F)           | 8    | 68129922 | 18% |
| 1180939 | Eicher Tractor Cover For Idler Pully (Stat)(F)     | 13   | 39021000 | 18% |
| 1181257 | Eicher Tractor Hand Accelator Lever                | 196  | 84099941 | 28% |
| 1182602 | Eicher Tractor Starting Crank Assly (Stat)         | 961  | 84099941 | 28% |
| 1182626 | Eicher Tractor Supt. For St. Handle (Stat)         | 783  | 84129090 | 18% |
| 1184260 | Eicher Tractor Pedestal Rear M/Cd (Stat)           | 3637 | 84099941 | 28% |
| 1184271 | Eicher Tractor Pedestal Front M/Cd (Stat)          | 3189 | 84099941 | 28% |
| 1184374 | Eicher Tractor Flange (Muffler Mtg.Extension)      | 243  | 84099941 | 28% |
| 1184726 | Eicher Tractor Idler Pulley                        | 542  | 84099941 | 28% |
| 1184751 | Eicher Tractor Fuel Tank Stand (Stat)              | 2138 | 84099941 | 28% |
| 1184763 | Eicher Tractor Fuel Tank W/O Cap (Stat)            | 4210 | 84129090 | 18% |
| 1184787 | Eicher Tractor Fuel Duct Ret.St-Eng                | 199  | 40094200 | 18% |
| 1184805 | Eicher Tractor Temp. Gauge (Stat)                  | 872  | 90268010 | 18% |
| 1184817 | Eicher Tractor Fuel Duct Assly. Big Mod.           | 306  | 40092200 | 18% |
| 1184854 | Eicher Tractor Gov. Weight 'A' Class Gov.(Hs/Es/Es | 306  | 84099941 | 28% |
| 1184880 | Eicher Tractor Actuating Lever Assly.              | 182  | 84099941 | 28% |
| 1185019 | Eicher Tractor Belt And Pully Guard (Stat)         | 1328 | 84099941 | 28% |
| 1185020 | Eicher Tractor Fly Wheel Casing                    | 5033 | 84099941 | 28% |
| 1185044 | Eicher Tractor Control Pannel (Stat)(298/398 Model | 881  | 84091000 | 28% |
| 1185299 | Eicher Tractor Spg.Lever (Stat)                    | 281  | 84099941 | 28% |
| 1185561 | Eicher Tractor Muffler Assy                        | 637  | 84099941 | 28% |
| 1185640 | Eicher Tractor Control Panel (222Hs)               | 493  | 84099941 | 28% |
| 1185652 | Eicher Tractor Control Pannel (222Es)              | 781  | 84099941 | 28% |
| 1185706 | Eicher Tractor Wire Rod Assly.(222 Hs/222 Es)      | 176  | 84099941 | 28% |
| 1185731 | Eicher Tractor Strip For Control Hsg.              | 8    | 73011000 | 18% |
| 1220070 | Eicher Tractor O Ring 19.2X3                       | 12   | 40169320 | 18% |
| 1220135 | Eicher Tractor O Ring 27.3X2.4                     | 13   | 40169320 | 18% |
| 1229308 | Eicher Tractor Hydraulic Gear Pump                 | 5841 | 84138190 | 18% |



|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 1234569 | Eicher Tractor Starter Relay                       | 457 | 85369090 | 18% |
| 1240328 | Eicher Tractor Hex Thin Nut M10X1.5,B8,Bp,         | 9   | 73181500 | 18% |
| 1240330 | Eicher Tractor Cap Nut M8X1                        | 16  | 73181500 | 18% |
| 1240407 | Eicher Tractor Hex Nut M10X1,B8,Lb,                | 6   | 73181600 | 18% |
| 1240626 | Eicher Tractor Hshc Screw M6X50,B12.9,Zp           | 13  | 73181500 | 18% |
| 1240675 | Eicher Tractor Hshc Screw 16X40,B12.9              | 54  | 73181500 | 18% |
| 1240699 | Eicher Tractor Hshc Screw M6X35,B12.9,Bp           | 12  | 73181500 | 18% |
| 1240717 | Eicher Tractor Hshc Screw M6X30,B12.9,Bp           | 12  | 73181500 | 18% |
| 1240742 | Eicher Tractor Hshc Screw M8X16,B12.9,Bp           | 14  | 73181500 | 18% |
| 1240780 | Eicher Tractor Hshc Screw M6X40.Is:2269-12.9 Zn    | 18  | 73181500 | 18% |
| 1240791 | Eicher Tractor Hshc Screw M8X45,B12.9,Bp           | 17  | 73181500 | 18% |
| 1241011 | Eicher Tractor Ball Bearing 6004 R C 3-298         | 266 | 84821020 | 18% |
| 1241280 | Eicher Tractor H.Skt Set Screw M10X30-Em.B12.9,Bp, | 22  | 73181500 | 18% |
| 1241382 | Eicher Tractor Sealing Washer 27X32                | 17  | 73182990 | 18% |
| 1241643 | Eicher Tractor Circlip Light A-40                  | 11  | 73182910 | 18% |
| 1241692 | Eicher Tractor Circlip                             | 6   | 73182910 | 18% |
| 1241734 | Eicher Tractor Circlip Light A-32                  | 11  | 73182910 | 18% |
| 1241825 | Eicher Tractor Circlip C4                          | 3   | 73182910 | 18% |
| 1241837 | Eicher Tractor Circlip C-6X0.7                     | 5   | 73182910 | 18% |
| 1241850 | Eicher Tractor Circlip C7                          | 4   | 73182910 | 18% |
| 1241892 | Eicher Tractor Circlip B22X1N                      | 5   | 73182910 | 18% |
| 1242210 | Eicher Tractor O Ring 5X1.5                        | 8   | 40169320 | 18% |
| 1242222 | Eicher Tractor O Ring 7.1X1.6                      | 11  | 40169340 | 18% |
| 1242234 | Eicher Tractor O Ring 13.3X2.4                     | 11  | 40169340 | 18% |
| 1242258 | Eicher Tractor O Ring 44.2X3                       | 12  | 40169320 | 18% |
| 1242453 | Eicher Tractor Hex Screw M10X35,B8.8,Zp,           | 15  | 73181500 | 18% |
| 1242465 | Eicher Tractor Hex Bolt M10X50,B8.8,Zp,            | 18  | 73181500 | 18% |
| 1242477 | Eicher Tractor Hex Bolt M10X60,B8.8,Zp,            | 17  | 73181500 | 18% |
| 1242490 | Eicher Tractor Hex Bolt M16X1.5X100,B8.8,Zp,       | 66  | 73181500 | 18% |
| 1242507 | Eicher Tractor Hex Screw M12X20,B8.8,Zp,           | 16  | 73181500 | 18% |
| 1242556 | Eicher Tractor Hex Screw M12X1.5X25                | 22  | 73181500 | 18% |
| 1242593 | Eicher Tractor Split Pin 1.6X14                    | 2   | 73182100 | 18% |
| 1242635 | Eicher Tractor Split Pin 2.5X12                    | 2   | 73182100 | 18% |
| 1242684 | Eicher Tractor Spring Dowel Sleeve Heavy 8X55      | 20  | 73182100 | 18% |
| 1242738 | Eicher Tractor Spg Dowel Sleeve 4X40 H             | 5   | 73182910 | 18% |
| 1242751 | Eicher Tractor Spring Dowel Sleeve 6X38H           | 14  | 73182100 | 18% |
| 1242842 | Eicher Tractor Deep Groove Ball Bearing 6306 C3-29 | 506 | 84821011 | 18% |
| 1242854 | Eicher Tractor Ball Bearing 6209N                  | 603 | 84821011 | 18% |
| 1242878 | Eicher Tractor Deep Groove Ball Bearing 6006-Zz    | 294 | 84822090 | 18% |
| 1243007 | Eicher Tractor Self Tapping Insert 20Mm            | 53  | 73181190 | 18% |
| 1243019 | Eicher Tractor Self Tapping Insert 14 Mm           | 39  | 73181190 | 18% |
| 1243214 | Eicher Tractor Oil Seal 40X62X7                    | 92  | 40169990 | 18% |
| 1243263 | Eicher Tractor Oil Seal                            | 61  | 40169330 | 18% |
| 1243275 | Eicher Tractor Oil Seal                            | 28  | 40169330 | 18% |
| 1243299 | Eicher Tractor Oil Seal 22X35X7                    | 26  | 40169330 | 18% |
| 1243305 | Eicher Tractor Hose Clamp A70                      | 26  | 73269099 | 18% |
| 1243524 | Eicher Tractor Punched Washer B5.5-Zp              | 3   | 73182100 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1243561 | Eicher Tractor Punched Washer B6.6-Zp              | 3    | 73182100 | 18% |
| 1243755 | Eicher Tractor Plain Washer 10.5                   | 8    | 73182100 | 18% |
| 1243767 | Eicher Tractor Plain Washer 8.4-Is:5370-1969       | 5    | 73182100 | 18% |
| 1243779 | Eicher Tractor Hex Bolt M10X65,B8.8.Zp,            | 17   | 73181500 | 18% |
| 1244028 | Eicher Tractor Snap Ring Sp 85                     | 28   | 73182990 | 18% |
| 1244140 | Eicher Tractor Hex Thin Nut M6,B8,Zp,              | 7    | 73181500 | 18% |
| 1244152 | Eicher Tractor Hex Nut M14X1.5,B8,Zp-White         | 15   | 73181500 | 18% |
| 1244188 | Eicher Tractor Wing Nut                            | 19   | 73181500 | 18% |
| 1244346 | Eicher Tractor Steel Ball 5/8", (Dia 15.875 Mm)    | 13   | 84829119 | 18% |
| 1244371 | Eicher Tractor Taper Roll. Brg 30213               | 1284 | 84822012 | 18% |
| 1244425 | Eicher Tractor Hex Screw M10X20,B8.8,Zp,           | 15   | 73181500 | 18% |
| 1244437 | Eicher Tractor Hex Screw M8X16,B8.8-Zp             | 9    | 73181500 | 18% |
| 1244498 | Eicher Tractor Hex Screw M6X20,B8.8,Zp,            | 5    | 73181500 | 18% |
| 1244784 | Eicher Tractor Hex Nut M16X1.5,B8,Zp               | 17   | 73181500 | 18% |
| 1244838 | Eicher Tractor Hex Thin Nut M20X1.5,B8,Zp,         | 26   | 73181500 | 18% |
| 1244851 | Eicher Tractor Punched Washer A11-Zpw              | 4    | 73182100 | 18% |
| 1244863 | Eicher Tractor Slot. Grub Screw Em6X18-Zp,A6.6,    | 29   | 73181500 | 18% |
| 1244929 | Eicher Tractor Hshc Screw M10X20,B12.9,Bp,         | 19   | 73181500 | 18% |
| 1245030 | Eicher Tractor Hex Bolt M14X2X70,B8.8,Zp,          | 53   | 73181500 | 18% |
| 1245089 | Eicher Tractor Hex. Bolt M14X2X65,Is:1364-1967,B8. | 40   | 73181500 | 18% |
| 1245155 | Eicher Tractor Taper Roller Bearing 32212          | 1057 | 84822012 | 18% |
| 1245193 | Eicher Tractor Hex Bolt M8X45,B10.9,Bp.            | 13   | 73181500 | 18% |
| 1245375 | Eicher Tractor Hex Bolt M6X45,B8.8,Zp,             | 11   | 73181500 | 18% |
| 1245387 | Eicher Tractor Hex Nut M14X2,B8,Zp,                | 15   | 73181500 | 18% |
| 1245399 | Eicher Tractor Hex Nut M16X2,B8,Zp,                | 18   | 73181500 | 18% |
| 1245478 | Eicher Tractor Bifurcated Rivet 3.5X12             | 4    | 73182100 | 18% |
| 1245510 | Eicher Tractor Punched Washer 17 (Is:2016)         | 6    | 73182100 | 18% |
| 1245570 | Eicher Tractor Hex Screw M8X90,B8.8,Zp,            | 22   | 73181500 | 18% |
| 1245582 | Eicher Tractor Hex Thin Nut M16X1.5,B8,Zp,         | 15   | 73181500 | 18% |
| 1245600 | Eicher Tractor Hex Bolt M10X90,B8.8,Zp,            | 30   | 73181500 | 18% |
| 1245624 | Eicher Tractor Hex Bolt M14X2X85,B8.8,Zp,          | 49   | 73181500 | 18% |
| 1245636 | Eicher Tractor Hex Screw M12X35,B8.8,Zp,(F)        | 24   | 73181500 | 18% |
| 1245648 | Eicher Tractor Hex Screw M6X10,B8.8,Zp,Es 01       | 5    | 73181500 | 18% |
| 1245661 | Eicher Tractor Hex Screw M14X40,B8.8,Zp,           | 25   | 73181500 | 18% |
| 1245673 | Eicher Tractor Hex Screw M16X2X40,B8.8,Zp,         | 40   | 73181500 | 18% |
| 1245685 | Eicher Tractor Hex Screw M16X2X45,B8.8,Bp          | 41   | 73181500 | 18% |
| 1245755 | Eicher Tractor Hex Screw M12X40,B10.9,Bp           | 29   | 73181500 | 18% |
| 1245946 | Eicher Tractor Hex Bolt M10X55,B8.8,Zp,            | 15   | 73181500 | 18% |
| 1245958 | Eicher Tractor Hex Bolt M14X50,B8.8,Zp,            | 31   | 73181500 | 18% |
| 1245960 | Eicher Tractor Hex Bolt M14X55,B8.8,Zp,            | 34   | 73181500 | 18% |
| 1245971 | Eicher Tractor Hex Bolt M14X75,B8.8,Zp,            | 48   | 73181500 | 18% |
| 1245983 | Eicher Tractor Hex Bolt M8X65,B8.8,Zp,             | 13   | 73181500 | 18% |
| 1245995 | Eicher Tractor Hex Bolt M8X45,B8.8,Zp,             | 12   | 73181500 | 18% |
| 1246008 | Eicher Tractor Hex Bolt M8X90,B8.8,Zp,             | 17   | 73181500 | 18% |
| 1246288 | Eicher Tractor Hex Screw M8X50,B8.8-Bp             | 12   | 73181500 | 18% |
| 1246367 | Eicher Tractor Cable Tie Clip 200Mm(A-5/36) F      | 11   | 84833000 | 18% |
| 1246379 | Eicher Tractor V Belt B-35                         | 344  | 40101290 | 18% |



|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 1246501 | Eicher Tractor D.G.Ball Brg. 63032 Rs-243          | 358 | 84822090 | 18% |
| 1246604 | Eicher Tractor Deep Grooved Ball Bearing 6203 Zzc3 | 236 | 84821011 | 18% |
| 1246951 | Eicher Tractor V Belt Cogged Trw 1185(Hs,322Esg,42 | 443 | 40101290 | 18% |
| 1247275 | Eicher Tractor V Belt 33"Cogged                    | 435 | 40101290 | 18% |
| 1247451 | Eicher Tractor Circlip Heavy A-16                  | 7   | 73182910 | 18% |
| 1247967 | Eicher Tractor Banjo Bolt M14X1.5,Zp,              | 74  | 73181500 | 18% |
| 1247979 | Eicher Tractor Banjo Bolt M10X1.5-Zp               | 11  | 73181500 | 18% |
| 1248145 | Eicher Tractor Spherical Washer M10                | 15  | 73182990 | 18% |
| 1248200 | Eicher Tractor H.Skt Set Screw M8X10-Hdp,B12.9,Bpi | 32  | 73181500 | 18% |
| 1248212 | Eicher Tractor Hex Bolt 20X100,B8.8-Zn             | 119 | 73181500 | 18% |
| 1248236 | Eicher Tractor Sphrical Washer 8.4 Dia (Inj.Clamp) | 16  | 73182990 | 18% |
| 1248684 | Eicher Tractor Spring Washer A-4 'Flat',Zp,        | 2   | 73182990 | 18% |
| 1248716 | Eicher Tractor Hex Thin Nut M18X2.5,B8,Zp,         | 19  | 73181500 | 18% |
| 1248870 | Eicher Tractor C'Sk Skt Screw M5X30,B12.9,Bp,      | 28  | 73181500 | 18% |
| 1248911 | Eicher Tractor Ball Bearing 306445C(Clutch Release | 759 | 84821011 | 18% |
| 1249149 | Eicher Tractor Breather Mico                       | 126 | 84133090 | 28% |
| 1249174 | Eicher Tractor Pop Rivets 3X8                      | 3   | 73182100 | 18% |
| 1249277 | Eicher Tractor H.Skt Set Screw M12X12-Kcp,B12.9,Bp | 20  | 73181500 | 18% |
| 1249307 | Eicher Tractor Bearing Ndl.Cage 18X24X20(O.D.Cente | 62  | 84822090 | 18% |
| 1249368 | Eicher Tractor Oil Seal A45*60*7 Polyac            | 140 | 40169320 | 18% |
| 1249381 | Eicher Tractor Pop Rivet 5X10                      | 4   | 73182100 | 18% |
| 1249501 | Eicher Tractor Hex Bolt M16X1.5X70,B8.8,Zp,        | 49  | 73181500 | 18% |
| 1249543 | Eicher Tractor Spring Dowel Sleeve 8X40            | 18  | 73182100 | 18% |
| 1249555 | Eicher Tractor Sp.Dowel Sleeve Heavy 5X70          | 17  | 73182100 | 18% |
| 1249567 | Eicher Tractor Spring Dowel Sleeve Heavy 8X70      | 24  | 73182100 | 18% |
| 1249611 | Eicher Tractor Oil Seal As48X65X10                 | 69  | 40169330 | 18% |
| 1249672 | Eicher Tractor Sealing Washer 10X16                | 4   | 73182990 | 18% |
| 1249740 | Eicher Tractor Cross Recessed Pan Hd.Screw M6X16-B | 12  | 73181500 | 18% |
| 1249763 | Eicher Tractor Punched Washer A6.6 Steel-Zp        | 4   | 73182100 | 18% |
| 1249787 | Eicher Tractor Hex Bolt M16X1.5X110,B8.8,Bp,       | 69  | 73181500 | 18% |
| 1249855 | Eicher Tractor Multi Tooth Lock Washer A10.5       | 12  | 73182100 | 18% |
| 1249964 | Eicher Tractor Hex Bolt M16X1.5X120.B8.8,Zp,       | 82  | 73181500 | 18% |
| 1249976 | Eicher Tractor Hex Screw M8X40 8.8 Zp              | 13  | 73181500 | 18% |
| 1249988 | Eicher Tractor Oil Seal 45X32X8                    | 146 | 84099941 | 28% |
| 1260492 | Eicher Tractor Grommet                             | 11  | 40169990 | 18% |
| 1260868 | Eicher Tractor Hub Cap                             | 284 | 87085000 | 18% |
| 1260881 | Eicher Tractor Nut Hexageon Slotted M24X1.5-Zp     | 100 | 73181500 | 18% |
| 1261204 | Eicher Tractor Guard Plate                         | 53  | 87089900 | 18% |
| 1261319 | Eicher Tractor Washer                              | 120 | 73182100 | 18% |
| 1261678 | Eicher Tractor Clamp Dia 9                         | 19  | 87084000 | 18% |
| 1261691 | Eicher Tractor Clamp Dia 13                        | 14  | 87084000 | 18% |
| 1261708 | Eicher Tractor Clamp Dia 15                        | 11  | 87084000 | 18% |
| 1261903 | Eicher Tractor Front Wheel Bolt M14X1.5X46,B8.8,Bp | 35  | 73181500 | 18% |
| 1262051 | Eicher Tractor Tension Tie Assy Lt&Rt              | 200 | 87083000 | 18% |
| 1262063 | Eicher Tractor Tension Tie Assy                    | 71  | 87083000 | 18% |
| 1262294 | Eicher Tractor Clamp For Mirror                    | 69  | 70060000 | 18% |
| 1262415 | Eicher Tractor Lead Assy                           | 209 | 85441920 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1262713 | Eicher Tractor Pin                                 | 937   | 73182100 | 18% |
| 1262786 | Eicher Tractor Pin Assy                            | 118   | 73182100 | 18% |
| 1262816 | Eicher Tractor Pin                                 | 204   | 73182100 | 18% |
| 1262956 | Eicher Tractor Coupling Mouth                      | 4113  | 87089900 | 18% |
| 1263031 | Eicher Tractor Lower Link                          | 2569  | 87089900 | 18% |
| 1263067 | Eicher Tractor Upper Link                          | 1407  | 87089900 | 18% |
| 1263122 | Eicher Tractor Battery Box                         | 363   | 85079090 | 28% |
| 1263419 | Eicher Tractor Graphics Left 242 Nc                | 109   | 39199090 | 18% |
| 1263420 | Eicher Tractor Graphics Right 242 Nc.              | 108   | 39199090 | 18% |
| 1263470 | Eicher Tractor Fork                                | 369   | 87084000 | 18% |
| 1263973 | Eicher Tractor Label Hydraulic                     | 137   | 39199090 | 18% |
| 1263997 | Eicher Tractor Sticker-Battery Box                 | 13    | 39199090 | 18% |
| 1264010 | Eicher Tractor Sticker Bowl (Air Cleaner)          | 10    | 39199090 | 18% |
| 1264084 | Eicher Tractor Axle                                | 167   | 87085000 | 18% |
| 1264096 | Eicher Tractor Foot Accelerator Pedal              | 62    | 87089900 | 18% |
| 1264102 | Eicher Tractor Foot Accelerator Pedal              | 233   | 87089900 | 18% |
| 1264140 | Eicher Tractor Wire Rod Assy.(Mds)                 | 83    | 85122010 | 18% |
| 1264175 | Eicher Tractor Spindle Assy.                       | 473   | 87089900 | 18% |
| 1264266 | Eicher Tractor Lower Bracket                       | 4040  | 87089900 | 18% |
| 1264382 | Eicher Tractor Sticker Disc Brake                  | 64    | 39199090 | 18% |
| 1264394 | Eicher Tractor Oil Seal Type-C 55X80X13            | 213   | 40169990 | 18% |
| 1264412 | Eicher Tractor Oil Seal Type-C 40X60X13            | 128   | 40169330 | 18% |
| 1264448 | Eicher Tractor Spindle & Guide Assy.               | 575   | 87089900 | 18% |
| 1264450 | Eicher Tractor Fork & Guide Assy.                  | 544   | 87089900 | 18% |
| 1264485 | Eicher Tractor Foot Board Right                    | 559   | 87089900 | 18% |
| 1264515 | Eicher Tractor Rod                                 | 76    | 87089900 | 18% |
| 1264539 | Eicher Tractor Top Link End Right -242(C.P )       | 795   | 87089900 | 18% |
| 1264540 | Eicher Tractor Top Link End Left-242(C.P )         | 1024  | 87089900 | 18% |
| 1264564 | Eicher Tractor Upper Link Assy-Grey                | 2833  | 87089900 | 18% |
| 1264667 | Eicher Tractor Chain Mounting Bracket Left         | 362   | 87089900 | 18% |
| 1264679 | Eicher Tractor Chain Mounting Bracket Right        | 378   | 87089900 | 18% |
| 1264801 | Eicher Tractor Shim                                | 11    | 73182100 | 18% |
| 1264825 | Eicher Tractor Graphics Right 241                  | 179   | 39199090 | 18% |
| 1264850 | Eicher Tractor Rivet For Friction Disc             | 4     | 73182100 | 18% |
| 1264941 | Eicher Tractor Pedal Shaft                         | 1164  | 87084000 | 18% |
| 1265015 | Eicher Tractor Rear Wheel Bolt M18X1.5X60,B10.9,Bp | 69    | 73181500 | 18% |
| 1265106 | Eicher Tractor Stub Axle                           | 3290  | 87085000 | 18% |
| 1265271 | Eicher Tractor Wheel (W11) Welded                  | 8798  | 87087000 | 18% |
| 1265313 | Eicher Tractor Clutch Pedal Assy.                  | 1574  | 87089300 | 18% |
| 1265465 | Eicher Tractor Flywheel Housing M/C-242            | 27231 | 87084000 | 18% |
| 1265593 | Eicher Tractor Cover Right                         | 225   | 87084000 | 18% |
| 1265659 | Eicher Tractor Cover - Brake Pedal(2 Holes)        | 143   | 87083000 | 18% |
| 1265660 | Eicher Tractor Gasket-Brake Pedal Cover(2 Holes)   | 6     | 68129090 | 18% |
| 1265738 | Eicher Tractor Sticker 242 Left                    | 233   | 39199090 | 18% |
| 1265740 | Eicher Tractor Sticker 242 Right                   | 233   | 39199090 | 18% |
| 1265751 | Eicher Tractor Eicher Monogram Left                | 123   | 39199090 | 18% |
| 1265763 | Eicher Tractor Eicher Monogram Right               | 143   | 39199090 | 18% |



|         |  |        |          |     |
|---------|--|--------|----------|-----|
| 1265775 | Eicher Tractor Double Triangle Sticker Right       | 405    | 39199090 | 18% |
| 1265787 | Eicher Tractor Super Star Al.Plate Left            | 407    | 39199090 | 18% |
| 1269240 | Eicher Tractor Indicator Charge                    | 96     | 85311010 | 18% |
| 1269252 | Eicher Tractor Starter Switch + Key Pair(F)        | 324    | 85365090 | 18% |
| 1269318 | Eicher Tractor Indicator Pressure                  | 85     | 85311010 | 18% |
| 1269320 | Eicher Tractor Indicator Turn                      | 65     | 85369090 | 18% |
| 1269583 | Eicher Tractor Lead Assy +Ve                       | 329    | 85112090 | 28% |
| 1269598 | Eicher Tractor Dynamo (Auto Lek)                   | 7640   | 85112090 | 28% |
| 1269604 | Eicher Tractor Lamp Head Light Hologen             | 220    | 85122010 | 18% |
| 1269665 | Eicher Tractor Brake Switch                        | 163    | 85365090 | 18% |
| 1269690 | Eicher Tractor Oil Pressure Switch(F)              | 196    | 84099941 | 28% |
| 1269707 | Eicher Tractor Adaptor 1/8X28Bsp                   | 48     | 84099941 | 28% |
| 1269756 | Eicher Tractor Rear Light Assy Left                | 599    | 85122010 | 18% |
| 1269768 | Eicher Tractor Rear Light Assy Right               | 604    | 85122010 | 18% |
| 1269770 | Eicher Tractor Front Light Assy-Left               | 321    | 85122010 | 18% |
| 1269781 | Eicher Tractor Front Light Assy-Right              | 366    | 85122010 | 18% |
| 1269835 | Eicher Tractor Horn                                | 290    | 85123010 | 18% |
| 1269902 | Eicher Tractor Bulb 12V-21W                        | 31     | 85122010 | 18% |
| 1269914 | Eicher Tractor Bulb 12V-21/5W                      | 35     | 85122010 | 18% |
| 1292008 | Eicher Tractor Trans. Assy 480 Sc Wdb Sth Mspto E  | 365462 | 87089900 | 18% |
| 1292020 | Eicher Tractor Trans. Hyd Sc Wdb Ss Mspto Mech Stg | 360601 | 87085000 | 18% |
| 1292054 | Eicher Tractor Trans.Assy-T557 Sc, Wdb, Ps, SI16   | 418976 | 87089900 | 18% |
| 1292066 | Eicher Tractor Trans-551 Dc Wdb Hd Ss Mstg Mspto   | 285880 | 87089900 | 18% |
| 1292766 | Eicher Tractor Piston With Piston Pin-115 (222Hs/2 | 5160   | 84099112 | 28% |
| 1293254 | Eicher Tractor P R Sleeve Assy (298)               | 353    | 84099941 | 28% |
| 1293255 | Eicher Tractor P R Sleeve Assy (290)               | 261    | 84831099 | 18% |
| 1293318 | Eicher Tractor Single Valve Spring (115E)          | 70     | 73202000 | 18% |
| 1293320 | Eicher Tractor Valve Spring Retainer (115E)        | 54     | 73202000 | 18% |
| 1293692 | Eicher Tractor 115Nc Engine O/H Kit (Menon)        | 7536   | 84099941 | 28% |
| 1293989 | Eicher Tractor Cyliner Liner Finish 115 Ricaro     | 2756   | 84099941 | 28% |
| 1293990 | Eicher Tractor Cylinder Assy-115E                  | 9964   | 84099941 | 28% |
| 1294015 | Eicher Tractor Valve Guide Inlet Reamed            | 71     | 84099111 | 28% |
| 1294027 | Eicher Tractor Valve Guide Exh.Reamed              | 71     | 84099111 | 28% |
| 1294039 | Eicher Tractor Guide Inlet Reamed                  | 60     | 84099111 | 28% |
| 1294040 | Eicher Tractor Valve Guide Exh.Reamed              | 60     | 84099111 | 28% |
| 1298001 | Eicher Tractor Fork & Guide Mech 241/242R/242Jbm/3 | 1758   | 87089900 | 18% |
| 1298002 | Eicher Tractor Spindle & Guide Mech 241/242R/242J/ | 2264   | 87089900 | 18% |
| 1298003 | Eicher Tractor Fork & Guide Mech 368Sdi,380,480,48 | 3020   | 87089900 | 18% |
| 1298004 | Eicher Tractor Lifting Gear Mech 368Sdi,380,480,48 | 4301   | 87089900 | 18% |
| 1298005 | Eicher Tractor Fork & Guide Mech 50 Hp             | 2661   | 87089900 | 18% |
| 1298007 | Eicher Tractor Brake Mech 242,312,333 Portal,364Nc | 665    | 87083000 | 18% |
| 1298008 | Eicher Tractor Brake Mech 312P,368,333,380,480     | 495    | 87083000 | 18% |
| 1298010 | Eicher Tractor Fork & Guide Mech 312               | 1738   | 87089900 | 18% |
| 1298011 | Eicher Tractor Fork & Guide Mech 312P/364P/333     | 1756   | 87089900 | 18% |
| 1298012 | Eicher Tractor Spindle & Guide Mech 312            | 2626   | 87089900 | 18% |
| 1298013 | Eicher Tractor Spindle & Guide Mech 312P/364P/333  | 2264   | 87089900 | 18% |
| 1299134 | Eicher Tractor Fas Assy -333/380/480Hyd/5150 North | 35968  | 87089900 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1300349 | Eicher Tractor Cable Clip 9                        | 8     | 84099941 | 28% |
| 1300647 | Eicher Tractor Lever                               | 305   | 87089900 | 18% |
| 1300994 | Eicher Tractor Mounting Angle Left                 | 845   | 87089900 | 18% |
| 1301056 | Eicher Tractor O Ring 39.2X3                       | 11    | 40169990 | 18% |
| 1301354 | Eicher Tractor Pedal Shaft                         | 993   | 87084000 | 18% |
| 1301380 | Eicher Tractor Clutch Pedal Assy                   | 792   | 87089300 | 18% |
| 1301391 | Eicher Tractor Brake Lever Rt                      | 308   | 87083000 | 18% |
| 1301408 | Eicher Tractor Brake Lever Lt                      | 332   | 87083000 | 18% |
| 1301720 | Eicher Tractor Thrust Bush                         | 989   | 87085000 | 18% |
| 1302267 | Eicher Tractor Fuel Duct                           | 108   | 84099941 | 28% |
| 1302541 | Eicher Tractor Sph. Wheel Nut M14X1.5              | 55    | 73181500 | 18% |
| 1302802 | Eicher Tractor Bonnet Fastener                     | 97    | 73181500 | 18% |
| 1303247 | Eicher Tractor Starting Handle Assy. 243           | 749   | 84099941 | 28% |
| 1303478 | Eicher Tractor Centre Pin                          | 1406  | 87085000 | 18% |
| 1304045 | Eicher Tractor Pin Assy. Comm.                     | 241   | 73182100 | 18% |
| 1304331 | Eicher Tractor Bracket                             | 70    | 87089900 | 18% |
| 1304392 | Eicher Tractor Stud M16X22/62.5,A8.8,Bp,           | 51    | 73182100 | 18% |
| 1304889 | Eicher Tractor Rear Wheel Rim -W11-Bolted,8 Hole,W | 13900 | 87087000 | 18% |
| 1305633 | Eicher Tractor Upper Hitch Pin                     | 134   | 73182100 | 18% |
| 1305645 | Eicher Tractor Upper Link Pin                      | 134   | 87089900 | 18% |
| 1305670 | Eicher Tractor Holder                              | 146   | 85122010 | 18% |
| 1305773 | Eicher Tractor Chain Mounting Bracket Left         | 189   | 87089900 | 18% |
| 1305890 | Eicher Tractor Tube                                | 84    | 87083000 | 18% |
| 1305931 | Eicher Tractor Steering Wheel 242                  | 1166  | 87089400 | 18% |
| 1306108 | Eicher Tractor Ring Housing Assy                   | 630   | 87084000 | 18% |
| 1306212 | Eicher Tractor Pin                                 | 154   | 73182100 | 18% |
| 1306261 | Eicher Tractor Bush                                | 484   | 87089400 | 18% |
| 1306339 | Eicher Tractor Upper Fork                          | 112   | 87084000 | 18% |
| 1306340 | Eicher Tractor Shoulder Bush                       | 775   | 87085000 | 18% |
| 1307411 | Eicher Tractor Steering Arm-Zf -7348012480         | 1596  | 87089400 | 18% |
| 1307691 | Eicher Tractor Foot Rest Assy                      | 404   | 87089900 | 18% |
| 1307769 | Eicher Tractor Hydraulic Shaft                     | 879   | 87089900 | 18% |
| 1307848 | Eicher Tractor Foot Rest 241                       | 279   | 87089900 | 18% |
| 1307976 | Eicher Tractor Steering Lever Single               | 1018  | 87089400 | 18% |
| 1308180 | Eicher Tractor Spacer                              | 27    | 73182100 | 18% |
| 1308660 | Eicher Tractor Flywheel Housing - 241Nc            | 28430 | 87084000 | 18% |
| 1309328 | Eicher Tractor Head Light Assy                     | 413   | 85122010 | 18% |
| 1309640 | Eicher Tractor Flasher Unit                        | 171   | 85122010 | 18% |
| 1309675 | Eicher Tractor On-Off Switch                       | 176   | 85122010 | 18% |
| 1309687 | Eicher Tractor Toggle Switch One Way               | 125   | 85369090 | 18% |
| 1309699 | Eicher Tractor Toggle Switch Two Way               | 179   | 85369090 | 18% |
| 1309705 | Eicher Tractor ORake Switch                        | 127   | 85369090 | 18% |
| 1340529 | Eicher Tractor Pin For Lifting Gear Assy           | 145   | 87089900 | 18% |
| 1340542 | Eicher Tractor Cover                               | 15    | 87089900 | 18% |
| 1340554 | Eicher Tractor Block - 3Pt Linkage (485            | 148   | 87083000 | 18% |
| 1340566 | Eicher Tractor Spacer                              | 40    | 73182100 | 18% |
| 1340591 | Eicher Tractor Handle                              | 173   | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1340608 | Eicher Tractor Lift Arm (M)(485)                   | 3460  | 87089900 | 18% |
| 1340610 | Eicher Tractor Housing                             | 386   | 87084000 | 18% |
| 1340700 | Eicher Tractor Plate For Hyd.Shaft (485            | 55    | 87084000 | 18% |
| 1340839 | Eicher Tractor Rear Wheel Bolt M16X1.5X50,B10.9,Bp | 44    | 73181500 | 18% |
| 1340906 | Eicher Tractor Foot Board Rt.(485)                 | 674   | 87089900 | 18% |
| 1340943 | Eicher Tractor Brake Pedal Lt.(485)                | 791   | 87083000 | 18% |
| 1340955 | Eicher Tractor Brake Pedal Rt.(485)                | 962   | 87083000 | 18% |
| 1341029 | Eicher Tractor Fuel Tank Graphics Lt (485)         | 116   | 39199090 | 18% |
| 1341030 | Eicher Tractor Fuel Tank Graphics Rt.              | 116   | 87089900 | 18% |
| 1341271 | Eicher Tractor Rear Wheel Rim-W12-13.6,Silver      | 12000 | 87087000 | 18% |
| 1341352 | Eicher Tractor Fork And Guide Assy(485)            | 1462  | 87089900 | 18% |
| 1341431 | Eicher Tractor Battery Cover (485)                 | 414   | 85079090 | 28% |
| 1341510 | Eicher Tractor Lever For Clutch(485)               | 213   | 87089300 | 18% |
| 1341522 | Eicher Tractor 342344Oard Lt.(485)                 | 530   | 87089900 | 18% |
| 1341674 | Eicher Tractor Foot Rest(485)                      | 847   | 87089900 | 18% |
| 1341765 | Eicher Tractor Battery Mounting Bkt. (485)         | 768   | 85079090 | 28% |
| 1341777 | Eicher Tractor Bush (Coupling Mouth) (485)         | 269   | 87089900 | 18% |
| 1341844 | Eicher Tractor Coupling Bolt                       | 323   | 73181500 | 18% |
| 1341911 | Eicher Tractor Spindle Guide                       | 1681  | 73269099 | 18% |
| 1342174 | Eicher Tractor Special Screw 10*30                 | 14    | 73181500 | 18% |
| 1343002 | Eicher Tractor Tention Tie Assy - Acc.             | 192   | 87083000 | 18% |
| 1343075 | Eicher Tractor Clutch Pedal 485                    | 775   | 87089300 | 18% |
| 1343156 | Eicher Tractor Spacer                              | 161   | 73182100 | 18% |
| 1343183 | Eicher Tractor Drag Link 485                       | 1486  | 87089400 | 18% |
| 1343233 | Eicher Tractor Pin - Bracket Lower Link 485        | 257   | 73182100 | 18% |
| 1343518 | Eicher Tractor Upper Link End Left-485             | 1190  | 87089900 | 18% |
| 1343520 | Eicher Tractor Upper Link End Right                | 1471  | 87089900 | 18% |
| 1343531 | Eicher Tractor Spring(Helical Torsion)             | 26    | 73202000 | 18% |
| 1343683 | Eicher Tractor Wire Rod Assy-910Mm(660Mm)          | 120   | 85122010 | 18% |
| 1344420 | Eicher Tractor Steering Unit                       | 9566  | 87089400 | 18% |
| 1344444 | Eicher Tractor Cover Lt                            | 82    | 87084000 | 18% |
| 1345023 | Eicher Tractor Cover                               | 90    | 87084000 | 18% |
| 1345035 | Eicher Tractor Cover                               | 80    | 87084000 | 18% |
| 1345059 | Eicher Tractor Foot Board Left                     | 969   | 87089900 | 18% |
| 1345084 | Eicher Tractor Fork & Guide Assy                   | 2492  | 87089900 | 18% |
| 1345138 | Eicher Tractor Chain Mtg Bkt Lt                    | 489   | 87089900 | 18% |
| 1345266 | Eicher Tractor Lifting Gear Assy                   | 3769  | 87089900 | 18% |
| 1345345 | Eicher Tractor Top Link Assy 485                   | 2657  | 87089900 | 18% |
| 1345473 | Eicher Tractor Lower Link Assy Lt                  | 2269  | 87089900 | 18% |
| 1345890 | Eicher Tractor Hand Acc.Rod - 485                  | 205   | 84099941 | 28% |
| 1345916 | Eicher Tractor Foot Board Left Pad                 | 270   | 40169990 | 18% |
| 1346052 | Eicher Tractor Mudguard Graphics "368"             | 81    | 39199090 | 18% |
| 1346088 | Eicher Tractor Shoulder Bush                       | 817   | 87085000 | 18% |
| 1346568 | Eicher Tractor Sticker-Horn                        | 3     | 39199090 | 18% |
| 1346581 | Eicher Tractor Sticker-Choke                       | 4     | 39199090 | 18% |
| 1346593 | Eicher Tractor Sticker Starter Switch              | 2     | 39199090 | 18% |
| 1346659 | Eicher Tractor Sticker Plough Light                | 5     | 39199090 | 18% |





|         |   |       |          |     |
|---------|---|-------|----------|-----|
| 1346933 | Eicher Tractor Steering Lever Double            | 2032  | 87089400 | 18% |
| 1347019 | Eicher Tractor Clutch Pedal Assy.               | 1042  | 87089300 | 18% |
| 1347202 | Eicher Tractor Chain Mounting Bracket Right     | 555   | 87089900 | 18% |
| 1347378 | Eicher Tractor Foot Board Right                 | 530   | 87089900 | 18% |
| 1347391 | Eicher Tractor Hand Accelerator Rod             | 249   | 84099941 | 28% |
| 1347731 | Eicher Tractor Clutch Pedal 485 (Delux)         | 1004  | 87089300 | 18% |
| 1347895 | Eicher Tractor Tool Box Mtg. Bracket            | 177   | 87089900 | 18% |
| 1348048 | Eicher Tractor Pad                              | 103   | 40169990 | 18% |
| 1348103 | Eicher Tractor Front Axle Assy                  | 10925 | 87085000 | 18% |
| 1348292 | Eicher Tractor Stub Axle 380 Normal             | 3357  | 87085000 | 18% |
| 1348620 | Eicher Tractor Graphics (Right)                 | 704   | 39199090 | 18% |
| 1348632 | Eicher Tractor Graphics (Left)                  | 701   | 39199090 | 18% |
| 1348656 | Eicher Tractor Graphics Model 368 (Dual Clutch) | 463   | 39199090 | 18% |
| 1348668 | Eicher Tractor Graphics (Fuel Tank)             | 158   | 39199090 | 18% |
| 1348851 | Eicher Tractor Grommet-Medallian                | 59    | 40169990 | 18% |
| 1348966 | Eicher Tractor Steering Arm                     | 941   | 87089400 | 18% |
| 1349119 | Eicher Tractor Front Light Assy Lt.             | 347   | 85122010 | 18% |
| 1349170 | Eicher Tractor Wiring Harness Main              | 330   | 85441920 | 18% |
| 1349181 | Eicher Tractor Bracket For Brake Switch         | 66    | 87083000 | 18% |
| 1349271 | Eicher Tractor Stub Axle R5S                    | 1817  | 87085000 | 18% |
| 1360048 | Eicher Tractor Speacial Nut 398                 | 212   | 84099941 | 28% |
| 1360061 | Eicher Tractor Parallel Key 38X5                | 44    | 73182990 | 18% |
| 1360085 | Eicher Tractor Clamping Strip                   | 13    | 84099941 | 28% |
| 1360097 | Eicher Tractor Spl Hex Nut                      | 28    | 73181500 | 18% |
| 1360152 | Eicher Tractor Oil Gallery Tube Assy. -398      | 246   | 84314930 | 18% |
| 1360164 | Eicher Tractor Cam Shaft Gear                   | 2731  | 87084000 | 18% |
| 1360176 | Eicher Tractor Suction Tube Assly               | 284   | 84099941 | 28% |
| 1360206 | Eicher Tractor Screen Assly.(Malti)             | 179   | 84099941 | 28% |
| 1360231 | Eicher Tractor Connecting Pipe Assy.            | 153   | 84099941 | 28% |
| 1360243 | Eicher Tractor L.O.Pump Driving Gear            | 983   | 87084000 | 18% |
| 1360309 | Eicher Tractor Fuel Pump Drvg Gear              | 1161  | 87084000 | 18% |
| 1360394 | Eicher Tractor Air Inlet Hose (A/C Side)        | 160   | 40093100 | 18% |
| 1360413 | Eicher Tractor A/C Mtg Bracket(485)             | 399   | 87089900 | 18% |
| 1360450 | Eicher Tractor Exhaust Mainfold 313/398         | 2082  | 84099941 | 28% |
| 1360462 | Eicher Tractor Fuel Pump Gear                   | 1250  | 87084000 | 18% |
| 1360474 | Eicher Tractor Spl Hex Nut M14X1.5              | 70    | 73181500 | 18% |
| 1360668 | Eicher Tractor Blower Pully M/Cd (D)421/422 Es  | 445   | 84835010 | 18% |
| 1360826 | Eicher Tractor Inspection Cover Middle          | 314   | 84099941 | 28% |
| 1360838 | Eicher Tractor Cam Bush                         | 212   | 84833000 | 18% |
| 1360899 | Eicher Tractor Cover For Cont.Hsg M/Cg          | 431   | 84099941 | 28% |
| 1360905 | Eicher Tractor Gasket For Hyd.Gear Pump Assy    | 42    | 68129922 | 18% |
| 1360917 | Eicher Tractor Cover - Pump Mtg. Hole           | 306   | 84099941 | 28% |
| 1360929 | Eicher Tractor Gasket For Cover -398            | 26    | 68129922 | 18% |
| 1360954 | Eicher Tractor Angle Bracket                    | 165   | 84099941 | 28% |
| 1360966 | Eicher Tractor Gasket For Insp. Cover Ft.-398   | 43    | 68129922 | 18% |
| 1360991 | Eicher Tractor Fuel Inj. Pump Assy              | 34199 | 84133090 | 28% |
| 1361041 | Eicher Tractor Clamping Strip                   | 62    | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1361107 | Eicher Tractor Rigid Fuel Pipe Line Assly          | 244   | 40094200 | 18% |
| 1361168 | Eicher Tractor Oil Filter Element Assy. -398       | 332   | 84219900 | 18% |
| 1361284 | Eicher Tractor Blower Shaft Assly.                 | 8715  | 84099941 | 28% |
| 1361351 | Eicher Tractor Spring For Of Head Cum Insp.Cover 3 | 9     | 73202000 | 18% |
| 1361363 | Eicher Tractor Steel Ball 11 Dia                   | 19    | 84829119 | 18% |
| 1361375 | Eicher Tractor Adopter O F Head                    | 94    | 73181500 | 18% |
| 1361387 | Eicher Tractor Check Valve                         | 71    | 84099941 | 28% |
| 1361521 | Eicher Tractor F.I. Pipe Assy. Front -398          | 569   | 84099941 | 28% |
| 1361533 | Eicher Tractor F.I Pipe Assy. Middle 398           | 569   | 84099941 | 28% |
| 1361545 | Eicher Tractor Fuel Inj Pipe Assly                 | 569   | 84099941 | 28% |
| 1361650 | Eicher Tractor Gasket For Cont. Hsg.               | 95    | 68129922 | 18% |
| 1361697 | Eicher Tractor Extension Tube                      | 119   | 84099941 | 28% |
| 1361739 | Eicher Tractor Speedo Cable Assy(485)              | 236   | 85443000 | 18% |
| 1361776 | Eicher Tractor Crank Pulley (22")(321Es/322Es/421E | 1834  | 84835010 | 18% |
| 1361790 | Eicher Tractor Inner Shaft(2065+/-10Mm 368 & 485)  | 46    | 87084000 | 18% |
| 1361843 | Eicher Tractor Clamp Rigid Pipe                    | 15    | 84099941 | 28% |
| 1361855 | Eicher Tractor Spl Clamp                           | 19    | 84099941 | 28% |
| 1361879 | Eicher Tractor Pointer Alt.                        | 18    | 84099941 | 28% |
| 1361880 | Eicher Tractor Fuel Injection Pump (421 Es)        | 39869 | 84133010 | 28% |
| 1361934 | Eicher Tractor Stud M8*28                          | 15    | 73182100 | 18% |
| 1361946 | Eicher Tractor Adopter (Pr Switch)                 | 50    | 84099941 | 28% |
| 1361958 | Eicher Tractor Push Rod Assly (Steel)              | 145   | 84099990 | 28% |
| 1361960 | Eicher Tractor Fip O'Ring                          | 82    | 40169990 | 18% |
| 1361971 | Eicher Tractor Oil Gallery Plug 398/298            | 43    | 84099941 | 28% |
| 1362057 | Eicher Tractor I.B.H. M/Cg                         | 2505  | 84099941 | 28% |
| 1362148 | Eicher Tractor Wire Rod Assy (421Es/422Es)         | 108   | 84099941 | 28% |
| 1362203 | Eicher Tractor Element                             | 1875  | 84099941 | 28% |
| 1362215 | Eicher Tractor Delivery Valve                      | 537   | 84099941 | 28% |
| 1362227 | Eicher Tractor Delivery Valve Holder               | 1658  | 84099941 | 28% |
| 1362239 | Eicher Tractor Over Flow Valve                     | 317   | 84099941 | 28% |
| 1362240 | Eicher Tractor Feed Pump                           | 3890  | 84099941 | 28% |
| 1362276 | Eicher Tractor Accelerator Lever Assly. -398St     | 360   | 84099941 | 28% |
| 1362290 | Eicher Tractor Rigid Fuel Line Assy (Ffp To W.S.)  | 333   | 84099941 | 28% |
| 1362304 | Eicher Tractor Bracket For Water Seperator         | 102   | 84099941 | 28% |
| 1362306 | Eicher Tractor Mtg. Bkt 485(Water Separator)       | 95    | 84099941 | 28% |
| 1362458 | Eicher Tractor Oil Feed Pipe Assly                 | 1284  | 84099941 | 28% |
| 1362653 | Eicher Tractor Adjusting Latch                     | 184   | 87085000 | 18% |
| 1362665 | Eicher Tractor Fuel Inj. Pump Assy - 398Edd        | 86601 | 84133010 | 28% |
| 1362719 | Eicher Tractor Breather Tube                       | 298   | 40092200 | 18% |
| 1362744 | Eicher Tractor Bracket (For Breather Tube)         | 26    | 84099941 | 28% |
| 1362800 | Eicher Tractor Fuel Inj. Pipe -Middle 398Exp       | 450   | 84099941 | 28% |
| 1362847 | Eicher Tractor Air Cleaner Mounting Bracket        | 483   | 84099941 | 28% |
| 1362860 | Eicher Tractor Rigid Fuel Line Assy(Fip To Ft)     | 277   | 84099941 | 28% |
| 1362872 | Eicher Tractor Crank Case                          | 48165 | 84099941 | 28% |
| 1362884 | Eicher Tractor Mounting Bracket - Alternator       | 561   | 87085000 | 18% |
| 1362902 | Eicher Tractor Fuel Pipe Line Assy(Fip-Overflow To | 402   | 84099941 | 28% |
| 1362938 | Eicher Tractor Knurrelled Nut                      | 26    | 73181500 | 18% |



|         |   |       |          |     |
|---------|---|-------|----------|-----|
| 1366272 | Eicher Tractor Liner With Ring (Conf.)          | 3106  | 84099941 | 28% |
| 1380096 | Eicher Tractor Shim For Blower 0.5Mm            | 5     | 73182100 | 18% |
| 1380266 | Eicher Tractor Upper Housing Assly              | 510   | 84099990 | 28% |
| 1380370 | Eicher Tractor Flat Tappet                      | 272   | 84099949 | 28% |
| 1380590 | Eicher Tractor Gasket For Adopter               | 25    | 68129922 | 18% |
| 1380667 | Eicher Tractor Startor Motor Assy.(115Es/Esg)   | 14959 | 85114000 | 28% |
| 1380710 | Eicher Tractor Push Rod Modified (Hs / Es)      | 526   | 84099990 | 28% |
| 1380989 | Eicher Tractor Piston Ring Set 2Nd O/S          | 802   | 84099941 | 28% |
| 1380990 | Eicher Tractor Piston Ring Set 4Th O/S          | 823   | 84099941 | 28% |
| 1381003 | Eicher Tractor Wire Clamp 75 Mm Dia             | 43    | 82057000 | 18% |
| 1381088 | Eicher Tractor Pre Cleaner                      | 160   | 84213100 | 18% |
| 1381120 | Eicher Tractor Rubber Seal                      | 71    | 40169990 | 18% |
| 1381131 | Eicher Tractor Strainer                         | 100   | 84219900 | 18% |
| 1381271 | Eicher Tractor Air Inlet Hose                   | 136   | 40093100 | 18% |
| 1381301 | Eicher Tractor Dynamo Pulley                    | 161   | 84099941 | 28% |
| 1381325 | Eicher Tractor Yoke Mod.                        | 53    | 84129090 | 18% |
| 1381374 | Eicher Tractor Bearing Flange (Hs/Es & Esg)     | 417   | 84099941 | 28% |
| 1381441 | Eicher Tractor Valve Seat Inlet                 | 176   | 84099941 | 28% |
| 1381519 | Eicher Tractor Valve Spring Retainer Nc         | 153   | 73202000 | 18% |
| 1381544 | Eicher Tractor Rocker Arm Inlet Assly (Hs /Es)  | 468   | 84099941 | 28% |
| 1381556 | Eicher Tractor Special Stud                     | 48    | 84099941 | 28% |
| 1381593 | Eicher Tractor Fuel Injector Assy               | 4676  | 84099941 | 28% |
| 1381600 | Eicher Tractor Nozzle For Injector              | 2767  | 84099941 | 28% |
| 1381610 | Eicher Tractor Delivery Valve-Mico              | 646   | 84099941 | 28% |
| 1381623 | Eicher Tractor Sealing Washer                   | 45    | 73182990 | 18% |
| 1381702 | Eicher Tractor Wire Basket Assly Rt. ( W. Hole) | 272   | 84099941 | 28% |
| 1381714 | Eicher Tractor Wire Mesh (L) (With Out Hole)    | 307   | 84099990 | 28% |
| 1381787 | Eicher Tractor Bearing For Cap 0.25             | 101   | 84821020 | 18% |
| 1381799 | Eicher Tractor Bearing For Cap 0.50             | 112   | 84821020 | 18% |
| 1381805 | Eicher Tractor B E'Brg U/S .75Mm (For Cap)      | 112   | 84821020 | 18% |
| 1381817 | Eicher Tractor B E'Brg U/S 1.0Mm (For Cap)      | 97    | 84821020 | 18% |
| 1381829 | Eicher Tractor Bearing For Rod 0.25             | 112   | 84821020 | 18% |
| 1381830 | Eicher Tractor Bearing For Rod 0.50             | 112   | 84821020 | 18% |
| 1381842 | Eicher Tractor B E'Brg U/S .75Mm (For Rod)      | 112   | 84821020 | 18% |
| 1381854 | Eicher Tractor B E'Brg U/S 1.0Mm (For Rod)      | 112   | 84821020 | 18% |
| 1382020 | Eicher Tractor Actuating Lever                  | 172   | 84099941 | 28% |
| 1382044 | Eicher Tractor Torsional Spring                 | 14    | 73202000 | 18% |
| 1382111 | Eicher Tractor Blower Pulley Mod.115Auto        | 252   | 84099941 | 28% |
| 1382123 | Eicher Tractor M/Cd Washer                      | 11    | 73182100 | 18% |
| 1382147 | Eicher Tractor Taper Screw Plug 1/2             | 55    | 73181500 | 18% |
| 1382160 | Eicher Tractor Valve Guide Inlet Nc (115)       | 77    | 84099111 | 28% |
| 1382196 | Eicher Tractor Valve Stem Oil Seal (Imp)        | 67    | 40169320 | 18% |
| 1382317 | Eicher Tractor Support                          | 258   | 84099941 | 28% |
| 1382330 | Eicher Tractor Spring Bolt                      | 17    | 73181500 | 18% |
| 1382342 | Eicher Tractor Rocker Arm Housing               | 2254  | 84099941 | 28% |
| 1382354 | Eicher Tractor Fuel Duct Return Assy(F)         | 139   | 40092200 | 18% |
| 1382408 | Eicher Tractor Union                            | 31    | 84099941 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1382421 | Eicher Tractor Injector Clamp Old                  | 236  | 84099941 | 28% |
| 1382536 | Eicher Tractor Extension                           | 262  | 84099941 | 28% |
| 1382548 | Eicher Tractor Insert Bush                         | 257  | 84099941 | 28% |
| 1382561 | Eicher Tractor Closing Cap Assly.                  | 186  | 84099941 | 28% |
| 1382585 | Eicher Tractor Flange (Nc)                         | 216  | 84099941 | 28% |
| 1382597 | Eicher Tractor Gasket For Flange                   | 5    | 68129922 | 18% |
| 1382603 | Eicher Tractor Square Sleeve For Cam Shaft 115     | 35   | 84099941 | 28% |
| 1382615 | Eicher Tractor Speedo Cable Assy                   | 168  | 85443000 | 18% |
| 1382664 | Eicher Tractor Rubber Flap                         | 152  | 40169320 | 18% |
| 1382731 | Eicher Tractor Engine Overhauling Kit              | 6618 | 84099941 | 28% |
| 1382743 | Eicher Tractor Bundy Tube                          | 24   | 84099941 | 28% |
| 1382779 | Eicher Tractor Dynamo Pulley                       | 219  | 84099941 | 28% |
| 1382834 | Eicher Tractor Silencer Jacket                     | 1163 | 87089200 | 18% |
| 1382858 | Eicher Tractor Exhaust Tube Of Silencer Upper      | 849  | 87089200 | 18% |
| 1382950 | Eicher Tractor O Ring 99X3.3                       | 19   | 40169990 | 18% |
| 1383012 | Eicher Tractor Oiling Ring                         | 349  | 84099941 | 28% |
| 1383048 | Eicher Tractor Copper Gasket 0.9                   | 152  | 84099941 | 28% |
| 1383061 | Eicher Tractor Copper Gasket 0.75                  | 141  | 84099941 | 28% |
| 1383073 | Eicher Tractor Copper Gasket 0.60                  | 98   | 84099941 | 28% |
| 1383085 | Eicher Tractor Copper Gasket 0.45                  | 79   | 84099941 | 28% |
| 1383553 | Eicher Tractor Air Intake Pipe                     | 318  | 40093100 | 18% |
| 1383632 | Eicher Tractor Bearing Cover                       | 390  | 84099941 | 28% |
| 1383693 | Eicher Tractor D/C Lever                           | 114  | 84099941 | 28% |
| 1383735 | Eicher Tractor Driving Jaw                         | 381  | 84099941 | 28% |
| 1383814 | Eicher Tractor Guide Pin                           | 127  | 84099941 | 28% |
| 1383887 | Eicher Tractor Fuel Injection Duct Assly           | 538  | 84099941 | 28% |
| 1383980 | Eicher Tractor Cable Clamp                         | 12   | 87089900 | 18% |
| 1384070 | Eicher Tractor Piston (Menon)                      | 3246 | 84099941 | 28% |
| 1384079 | Eicher Tractor Piston (Escorts)                    | 1938 | 84099941 | 28% |
| 1384166 | Eicher Tractor Gasket Fuel Pump                    | 12   | 68129922 | 18% |
| 1384193 | Eicher Tractor Inner Shaft                         | 27   | 87084000 | 18% |
| 1384200 | Eicher Tractor Cyl. Head Sub Assly.                | 4720 | 76169990 | 18% |
| 1384211 | Eicher Tractor Inlet Masked Valve                  | 603  | 84099941 | 28% |
| 1384223 | Eicher Tractor Exhaust Valve                       | 299  | 84099941 | 28% |
| 1384235 | Eicher Tractor Inlet Valve Seat Nc.                | 234  | 84099941 | 28% |
| 1384247 | Eicher Tractor Exhaust Valve Seat                  | 235  | 84099941 | 28% |
| 1384375 | Eicher Tractor Special Stud Nc                     | 78   | 73181500 | 18% |
| 1384391 | Eicher Tractor Piston Second Over Size             | 3324 | 84099941 | 28% |
| 1384419 | Eicher Tractor Piston Fourth Over Size Menon       | 3128 | 84099941 | 28% |
| 1384480 | Eicher Tractor Pin For Governor Weight             | 54   | 84129090 | 18% |
| 1384521 | Eicher Tractor Oil Filter Pot Assly.               | 545  | 84219900 | 18% |
| 1384545 | Eicher Tractor Sealing Ring (F)                    | 19   | 40169320 | 18% |
| 1384557 | Eicher Tractor O.F. Assly                          | 3109 | 84099941 | 28% |
| 1384569 | Eicher Tractor Special Washer 9X21X3               | 6    | 73182990 | 18% |
| 1384594 | Eicher Tractor Screwed Plug M14X1.5                | 31   | 73181500 | 18% |
| 1384685 | Eicher Tractor Clamp For Air Cleaner               | 148  | 84099941 | 28% |
| 1384703 | Eicher Tractor Valve Guide Nc Mod. (Exhaust-115) N | 72   | 84099111 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1384715 | Eicher Tractor Stopper (Mod)                       | 24   | 84129090 | 18% |
| 1384764 | Eicher Tractor Benjo Bolt M10X1.5X19,Zp            | 26   | 73181500 | 18% |
| 1384818 | Eicher Tractor Speedo Cable Assy.                  | 184  | 85443000 | 18% |
| 1385290 | Eicher Tractor Inner Shaft(1656+/-10Mm 243,312,364 | 33   | 87084000 | 18% |
| 1385446 | Eicher Tractor Gasket For Pump Base                | 5    | 84841090 | 18% |
| 1385471 | Eicher Tractor Intgl Cyl. Liner Std                | 7843 | 84099941 | 28% |
| 1385537 | Eicher Tractor O Ring For Breather 22X3            | 5    | 40169320 | 18% |
| 1385598 | Eicher Tractor Cylinder Clamping Rod               | 399  | 84099941 | 28% |
| 1385768 | Eicher Tractor Belt Guard Assy                     | 275  | 84099941 | 28% |
| 1385770 | Eicher Tractor Adjusting Latch                     | 211  | 84099941 | 28% |
| 1385800 | Eicher Tractor Oil Filter Head                     | 684  | 84219900 | 18% |
| 1385811 | Eicher Tractor Oil Pump-115                        | 2261 | 84099941 | 28% |
| 1385872 | Eicher Tractor Breather Tube-115                   | 145  | 85462019 | 28% |
| 1385975 | Eicher Tractor Rubber Washer 10X17                 | 5    | 40169320 | 18% |
| 1385987 | Eicher Tractor Cyclopack Ring (Nylon-6)            | 185  | 87089900 | 18% |
| 1386013 | Eicher Tractor Bush For Conn Rod                   | 269  | 84833000 | 18% |
| 1386098 | Eicher Tractor Guiding Lever                       | 229  | 84099941 | 28% |
| 1386130 | Eicher Tractor 'O' Ring 16.5X2.6                   | 59   | 40169320 | 18% |
| 1386141 | Eicher Tractor Silencer Assy                       | 2789 | 87089200 | 18% |
| 1386165 | Eicher Tractor Cap Nut-Lid Cvr                     | 39   | 73181500 | 18% |
| 1386177 | Eicher Tractor Rubber Washer-Capnut(F)             | 5    | 40169320 | 18% |
| 1386244 | Eicher Tractor Gasket For Insp. Cover              | 94   | 68129922 | 18% |
| 1386272 | Eicher Tractor Lp Set With Ring (Conf.)            | 4983 | 84099941 | 28% |
| 1386293 | Eicher Tractor Oring Kit 24Hp                      | 231  | 84099941 | 28% |
| 1386955 | Eicher Tractor Oil Bowl Assy.                      | 573  | 84099941 | 28% |
| 1386967 | Eicher Tractor Strainer C. P Air Cleaner Assly     | 125  | 84219900 | 18% |
| 1386979 | Eicher Tractor Hr/Rpm Meter(Pricol)                | 632  | 90292020 | 18% |
| 1386980 | Eicher Tractor Hr/Rpm Meter(Indication)            | 1171 | 90292090 | 18% |
| 1387078 | Eicher Tractor Special Washer 11X25X4              | 11   | 73182990 | 18% |
| 1387157 | Eicher Tractor Cap Nut M10                         | 46   | 73181500 | 18% |
| 1387339 | Eicher Tractor Bearing Cover M/Cd 115              | 560  | 84822090 | 18% |
| 1387420 | Eicher Tractor Crank Shaft Gear 115                | 1001 | 87084000 | 18% |
| 1387431 | Eicher Tractor Crank Pully-115                     | 1693 | 84835010 | 18% |
| 1387467 | Eicher Tractor Gasket For Starter Motor & Eng Mtg  | 55   | 68129922 | 18% |
| 1387479 | Eicher Tractor Spring Lever Sub Assy. Auto         | 304  | 84099941 | 28% |
| 1387492 | Eicher Tractor R.P.M. Setting Bolt 6X25            | 17   | 73181500 | 18% |
| 1387510 | Eicher Tractor Cam Shaft                           | 1847 | 84831092 | 18% |
| 1387546 | Eicher Tractor Oil Seal 40X60X13 Viton             | 253  | 40169330 | 18% |
| 1387560 | Eicher Tractor Belt Strip                          | 47   | 87089200 | 18% |
| 1387595 | Eicher Tractor Oil Seal 70X85X8                    | 376  | 40169330 | 18% |
| 1387601 | Eicher Tractor Crank Shaft W/O Wts                 | 5626 | 84831092 | 18% |
| 1387650 | Eicher Tractor Piston Ring Set 115Es/Hs            | 695  | 84099913 | 28% |
| 1387730 | Eicher Tractor Bearing 6009W                       | 452  | 84822090 | 18% |
| 1387820 | Eicher Tractor Gov Lever-115                       | 245  | 84099941 | 28% |
| 1387832 | Eicher Tractor Fuel Pipe Assy (Ft To Ws/Ffp) (F)   | 258  | 40092200 | 18% |
| 1387959 | Eicher Tractor Inlet Valve                         | 295  | 84099941 | 28% |
| 1387960 | Eicher Tractor Exhaust Valve                       | 288  | 84099941 | 28% |



|         |   |       |          |     |
|---------|---|-------|----------|-----|
| 1387972 | Eicher Tractor Inlet Valve Seat (115 Esg)           | 171   | 84099941 | 28% |
| 1387984 | Eicher Tractor Exhaust Valve Seat(115 Esg )         | 171   | 84099941 | 28% |
| 1388010 | Eicher Tractor Rocker Support &                     | 904   | 84099941 | 28% |
| 1388022 | Eicher Tractor Injector Clamp-115Auto               | 244   | 84099941 | 28% |
| 1388043 | Eicher Tractor Lid Gasket-115 Auto                  | 64    | 68129922 | 18% |
| 1388071 | Eicher Tractor Rubber Gromet 115 Auto/Jbm           | 20    | 40169320 | 18% |
| 1388137 | Eicher Tractor Inlet Rocker Arm Assly. (Auto./Esg)  | 474   | 84099941 | 28% |
| 1388149 | Eicher Tractor Exhaust Rocker Arm Assly. (Auto./Esg | 474   | 84099941 | 28% |
| 1388150 | Eicher Tractor Cyl Head Sub Assly. -115E            | 6220  | 76169990 | 18% |
| 1388198 | Eicher Tractor 115 Cam Shaft                        | 1377  | 84831092 | 18% |
| 1388228 | Eicher Tractor Spl Hex Screw 6X35                   | 17    | 73181500 | 18% |
| 1388253 | Eicher Tractor Valve Guide (115E Auto And Esg)      | 68    | 84099111 | 28% |
| 1388307 | Eicher Tractor Banjo Bolt 1/8X28 Bsp (Stat)(F)      | 27    | 73181500 | 18% |
| 1388320 | Eicher Tractor Decompression Screw                  | 21    | 73181500 | 18% |
| 1388332 | Eicher Tractor Conn.Rod M/Cd 115                    | 3954  | 84834000 | 18% |
| 1388344 | Eicher Tractor Special Washer-115Auto               | 48    | 73182990 | 18% |
| 1388368 | Eicher Tractor Governor Lever                       | 241   | 84099941 | 28% |
| 1388381 | Eicher Tractor 115Nc Engine O/H Kit                 | 12542 | 84099941 | 28% |
| 1388393 | Eicher Tractor 115 O/H Kit (Mod)                    | 7094  | 84099941 | 28% |
| 1388400 | Eicher Tractor Protection Sleeve (Auto & Esg)       | 617   | 84099941 | 28% |
| 1388502 | Eicher Tractor Top Bracket-115Auto                  | 251   | 84099941 | 28% |
| 1388514 | Eicher Tractor Upper Housing                        | 654   | 84099941 | 28% |
| 1388540 | Eicher Tractor Actuating Lever                      | 173   | 84099941 | 28% |
| 1388551 | Eicher Tractor Special Screw                        | 25    | 73181500 | 18% |
| 1388587 | Eicher Tractor Link Pin                             | 31    | 84099941 | 28% |
| 1388629 | Eicher Tractor Lid Assy                             | 185   | 84099941 | 28% |
| 1388654 | Eicher Tractor Gasket For Inlet                     | 16    | 68129922 | 18% |
| 1388691 | Eicher Tractor Shim For Fuel Pump 0.16 Mm           | 24    | 73182100 | 18% |
| 1388703 | Eicher Tractor Shim For Fuel Pump 0.30 Mm           | 28    | 73182100 | 18% |
| 1388715 | Eicher Tractor Shim For Fuel Pump 0.50 Mm           | 32    | 73182100 | 18% |
| 1388727 | Eicher Tractor Or Fuel Pump 0.70 Mm                 | 57    | 84099941 | 28% |
| 1388757 | Eicher Tractor Push Rod Assy (Auto)                 | 468   | 84099990 | 28% |
| 1388824 | Eicher Tractor Gasket (Exhaust)                     | 14    | 40169990 | 18% |
| 1388915 | Eicher Tractor Support Assly                        | 445   | 84099941 | 28% |
| 1388942 | Eicher Tractor Air Cleaner Assy. (Blue) W/Foam+Ring | 4139  | 84099941 | 28% |
| 1388964 | Eicher Tractor Rubber Seal                          | 62    | 40169990 | 18% |
| 1388976 | Eicher Tractor Rubber Ring                          | 64    | 40169990 | 18% |
| 1388988 | Eicher Tractor Cartige Assy.                        | 1200  | 84099941 | 28% |
| 1389002 | Eicher Tractor Foam                                 | 180   | 84099941 | 28% |
| 1389051 | Eicher Tractor Injector Assy-271                    | 4095  | 84099990 | 28% |
| 1389063 | Eicher Tractor Fuel Injection Duct Assy             | 346   | 84099941 | 28% |
| 1389087 | Eicher Tractor Coller Bolt                          | 34    | 73181500 | 18% |
| 1389117 | Eicher Tractor Pump Base 115                        | 758   | 84099941 | 28% |
| 1389129 | Eicher Tractor Control Housing Machined             | 7474  | 84099941 | 28% |
| 1389130 | Eicher Tractor Gasket For Pump Base                 | 6     | 68129922 | 18% |
| 1389166 | Eicher Tractor Inner Shaft(241/242.1356+/-10 Mm )   | 33    | 87084000 | 18% |
| 1389210 | Eicher Tractor Adjusting Latch 321Es/322Es/322Esg   | 127   | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1389221 | Eicher Tractor Belt Guard Assy (222Hs)             | 349   | 84099941 | 28% |
| 1389233 | Eicher Tractor Spacer                              | 79    | 73182100 | 18% |
| 1389269 | Eicher Tractor Alternator Assy (Mico)              | 5546  | 85115000 | 28% |
| 1389282 | Eicher Tractor Shim For Alternator                 | 5     | 73182100 | 18% |
| 1389294 | Eicher Tractor Shim For Alternator                 | 5     | 73182100 | 18% |
| 1389336 | Eicher Tractor Sticker For Air Cleaner             | 76    | 39199090 | 18% |
| 1389348 | Eicher Tractor Cylinder Liner Honned               | 2574  | 84099941 | 28% |
| 1389350 | Eicher Tractor Cap For Flange                      | 4     | 39021000 | 18% |
| 1389555 | Eicher Tractor Fuel Injection Pipe Assy-115E Gense | 423   | 84099990 | 28% |
| 1389634 | Eicher Tractor Cylinder Clamping Rod (Hs/Es)       | 447   | 84129090 | 18% |
| 1389646 | Eicher Tractor Air Inlet Hose                      | 144   | 40093100 | 18% |
| 1389658 | Eicher Tractor Bracket For Air Cleaner (F)         | 273   | 84099990 | 28% |
| 1389695 | Eicher Tractor Copper Gasket 0.3                   | 64    | 84099941 | 28% |
| 1390077 | Eicher Tractor Valve Guide Reamed                  | 71    | 84099111 | 28% |
| 1440056 | Eicher Tractor Guide Brg Cap Cast                  | 1059  | 87089400 | 18% |
| 1440068 | Eicher Tractor Main Bearing Cap Cast               | 887   | 84822090 | 18% |
| 1440380 | Eicher Tractor Valve Guide                         | 37    | 84099111 | 28% |
| 1440391 | Eicher Tractor Valve Seat (Exhaust Valtra)         | 194   | 84099941 | 28% |
| 1440780 | Eicher Tractor Crank Shaft Forging                 | 21731 | 84831092 | 18% |
| 1441085 | Eicher Tractor Front Cover Cast                    | 2490  | 73181500 | 18% |
| 1460018 | Eicher Tractor Draw Bar                            | 5303  | 87089900 | 18% |
| 1460122 | Eicher Tractor Pin Assly.                          | 237   | 73182100 | 18% |
| 1460195 | Eicher Tractor Spring                              | 191   | 73209090 | 18% |
| 1460729 | Eicher Tractor Coupling Mouth Valtra               | 2745  | 87089900 | 18% |
| 1460780 | Eicher Tractor Circlip 40X1.75 Din 472             | 15    | 73182910 | 18% |
| 1460900 | Eicher Tractor Air Pipe                            | 286   | 40092200 | 18% |
| 1460973 | Eicher Tractor Instrument Panel Assembly           | 2561  | 85122010 | 18% |
| 1461060 | Eicher Tractor Starter Motor (0686 Ye)(Valtra)     | 11397 | 85114000 | 28% |
| 1461072 | Eicher Tractor Alternator                          | 8012  | 85122010 | 18% |
| 1461138 | Eicher Tractor Water Pump Outlet Cap(Valtra)       | 8     | 39021000 | 18% |
| 1461140 | Eicher Tractor Water Pump Inlet Cap(Valtra)        | 7     | 39021000 | 18% |
| 1461151 | Eicher Tractor Exhaust Manifold Cap(Valtra)        | 13    | 39021000 | 18% |
| 1461163 | Eicher Tractor Inlet Manifold Cap(Valtra)          | 13    | 39011010 | 18% |
| 1461254 | Eicher Tractor Belt Tightner (Valtra)              | 132   | 84099941 | 28% |
| 1461645 | Eicher Tractor Water Temperature Sensor            | 283   | 90269000 | 18% |
| 1461890 | Eicher Tractor Spring                              | 4     | 73209090 | 18% |
| 1461930 | Eicher Tractor Bush                                | 22    | 87089900 | 18% |
| 1461977 | Eicher Tractor Nut(Parking Brake)                  | 16    | 73181500 | 18% |
| 1462192 | Eicher Tractor Bolt Assy                           | 85    | 73181500 | 18% |
| 1462337 | Eicher Tractor Hose - Brake Pedal                  | 17    | 40093100 | 18% |
| 1462398 | Eicher Tractor Spring                              | 10    | 73209090 | 18% |
| 1462416 | Eicher Tractor Steering Column Assy                | 5006  | 87089400 | 18% |
| 1462532 | Eicher Tractor Steering Valve                      | 23659 | 87089400 | 18% |
| 1462544 | Eicher Tractor Lock Washer                         | 14    | 73182100 | 18% |
| 1462611 | Eicher Tractor Steering Leverl.H.                  | 721   | 87089400 | 18% |
| 1462647 | Eicher Tractor Klm 806649                          | 1419  | 84822090 | 18% |
| 1462659 | Eicher Tractor Bearing Klm 603049                  | 623   | 84822011 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1462660 | Eicher Tractor Bearing Klm 48548            | 540  | 84822011 | 18% |
| 1462672 | Eicher Tractor Washer                       | 17   | 73182100 | 18% |
| 1462696 | Eicher Tractor Split Pin 6X40               | 31   | 73182100 | 18% |
| 1462702 | Eicher Tractor Cap                          | 227  | 87085000 | 18% |
| 1462714 | Eicher Tractor Gasket 6100                  | 13   | 68129090 | 18% |
| 1462726 | Eicher Tractor Front Wheel Hub              | 2405 | 87087000 | 18% |
| 1462738 | Eicher Tractor Dust Cover                   | 72   | 87084000 | 18% |
| 1462763 | Eicher Tractor Steering Lever R. H.         | 1086 | 87089400 | 18% |
| 1463056 | Eicher Tractor Dowel Pin                    | 35   | 73182990 | 18% |
| 1463330 | Eicher Tractor Tank Unit                    | 492  | 90268090 | 18% |
| 1463342 | Eicher Tractor Fuel Tank Cap 6100           | 183  | 84099941 | 28% |
| 1463482 | Eicher Tractor Front Wheel Bolted 5.50X16   | 4704 | 87087000 | 18% |
| 1463512 | Eicher Tractor Wheel Bolt M20*1.5           | 66   | 73181500 | 18% |
| 1463597 | Eicher Tractor Bolt M20*410                 | 456  | 73181500 | 18% |
| 1463603 | Eicher Tractor Pin Assy.                    | 492  | 73182100 | 18% |
| 1463639 | Eicher Tractor Tension Pin 6100             | 16   | 73182100 | 18% |
| 1463720 | Eicher Tractor Cover                        | 25   | 87084000 | 18% |
| 1463743 | Eicher Tractor Body Of The Knob             | 44   | 87084000 | 18% |
| 1463755 | Eicher Tractor Spring                       | 26   | 73202000 | 18% |
| 1463767 | Eicher Tractor Lock Washer                  | 37   | 73182100 | 18% |
| 1463779 | Eicher Tractor Friction Disc                | 40   | 73182100 | 18% |
| 1463834 | Eicher Tractor Stop Control Cabel           | 434  | 85122010 | 18% |
| 1463858 | Eicher Tractor Wire Holder                  | 10   | 87089900 | 18% |
| 1464309 | Eicher Tractor Side Plate R.H               | 198  | 87089900 | 18% |
| 1464449 | Eicher Tractor Ring (Rubber) 61402 Sis62610 | 93   | 40169320 | 18% |
| 1464450 | Eicher Tractor Cup                          | 58   | 87089900 | 18% |
| 1464474 | Eicher Tractor Plate                        | 51   | 39199090 | 18% |
| 1465284 | Eicher Tractor Spring                       | 51   | 73209090 | 18% |
| 1465302 | Eicher Tractor Seat                         | 77   | 94012000 | 18% |
| 1465314 | Eicher Tractor Knob                         | 28   | 87084000 | 18% |
| 1465594 | Eicher Tractor O Ring 49.2X5.7, Sms 1586    | 33   | 40169320 | 18% |
| 1465739 | Eicher Tractor Lower Link Assy.             | 4295 | 87089900 | 18% |
| 1465764 | Eicher Tractor Strut Stabliser Assy         | 1363 | 87089900 | 18% |
| 1465818 | Eicher Tractor Bracket                      | 380  | 87089900 | 18% |
| 1465820 | Eicher Tractor Pin Dia 24.1                 | 206  | 73182100 | 18% |
| 1465831 | Eicher Tractor Pin Dia 19                   | 144  | 73182100 | 18% |
| 1465843 | Eicher Tractor Top Link Assy                | 3349 | 87089900 | 18% |
| 1465855 | Eicher Tractor Top Link Pin                 | 339  | 87089900 | 18% |
| 1465867 | Eicher Tractor Link Pin                     | 195  | 73182100 | 18% |
| 1465879 | Eicher Tractor Lift Rod Assy.               | 4334 | 87089900 | 18% |
| 1466057 | Eicher Tractor Sleeve (Bushing)             | 323  | 87089400 | 18% |
| 1466069 | Eicher Tractor Bush                         | 173  | 87089900 | 18% |
| 1466173 | Eicher Tractor Axle Pin                     | 546  | 87085000 | 18% |
| 1466318 | Eicher Tractor Front Plate                  | 471  | 87081010 | 18% |
| 1466337 | Eicher Tractor Moulded Screw 6*12           | 9    | 73181500 | 18% |
| 1466811 | Eicher Tractor Sleeve                       | 40   | 87089900 | 18% |
| 1467153 | Eicher Tractor Clamp For Rod(Right)         | 27   | 87089900 | 18% |





|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1467177 | Eicher Tractor Graphics 6100 (Euro Power 6100)      | 680  | 39199090 | 18% |
| 1467694 | Eicher Tractor Registration Shield Base             | 290  | 39199090 | 18% |
| 1469058 | Eicher Tractor Tail Lamp Assy.                      | 463  | 85122010 | 18% |
| 1469071 | Eicher Tractor Number Plate Lamp Assy.              | 147  | 85122090 | 18% |
| 1469083 | Eicher Tractor Dual Gauge(Combi Gauge)              | 1233 | 85122010 | 18% |
| 1469113 | Eicher Tractor Tachometer                           | 1934 | 90292020 | 18% |
| 1469137 | Eicher Tractor Horn Common                          | 371  | 85122010 | 18% |
| 1469149 | Eicher Tractor Running Hour Meter                   | 1733 | 90292020 | 18% |
| 1469150 | Eicher Tractor Valtra Wiring Harness Dashboard      | 1117 | 85441920 | 18% |
| 1469174 | Eicher Tractor Wiring Harness Rear Valtra           | 974  | 85441920 | 18% |
| 1469186 | Eicher Tractor Cable Assy Battery(+Ve)              | 266  | 85443000 | 18% |
| 1469198 | Eicher Tractor Cable Assy Battery(-Ve)Ground Strap  | 218  | 85443000 | 18% |
| 1469228 | Eicher Tractor Signal Light , Turn                  | 66   | 85122010 | 18% |
| 1469265 | Eicher Tractor Working Light                        | 581  | 85122090 | 18% |
| 1469368 | Eicher Tractor Switch Noc(Neutral Safety)           | 389  | 85369090 | 18% |
| 1469381 | Eicher Tractor Switch                               | 2200 | 85122020 | 18% |
| 1469460 | Eicher Tractor Head Light Bulb 12V-60/55W           | 229  | 85122020 | 18% |
| 1469587 | Eicher Tractor Turning Indicator Switch             | 586  | 85369090 | 18% |
| 1469599 | Eicher Tractor Combination Switch                   | 461  | 85369090 | 18% |
| 1480157 | Eicher Tractor Pressed Cup                          | 11   | 87089900 | 18% |
| 1484163 | Eicher Tractor Bevel Gear                           | 2976 | 87084000 | 18% |
| 1510241 | Eicher Tractor Hi/Low Cluster Gear- 242 (Teeth-45)  | 3938 | 87084000 | 18% |
| 1510368 | Eicher Tractor Constant Mesh Gear - 242 (Teeth-42)  | 1110 | 87084000 | 18% |
| 1510370 | Eicher Tractor Spur Pinion 1st - 242 (Teeth-27)     | 824  | 87084000 | 18% |
| 1510381 | Eicher Tractor Sliding Gear 1St/2Nd - 242 (Teeth-3) | 2376 | 87084000 | 18% |
| 1510393 | Eicher Tractor Spur Pinion 2Nd - 242 (Teeth-32)     | 987  | 87084000 | 18% |
| 1510400 | Eicher Tractor Spur Pinion 3Rd - 242 (Teeth-37)     | 1035 | 87084000 | 18% |
| 1510411 | Eicher Tractor Sliding Gear 3Rd/4Th - 242 (Teeth-3) | 1251 | 87084000 | 18% |
| 1510435 | Eicher Tractor Sliding Gear Hilo - 242 (Teeth-41)   | 2226 | 87084000 | 18% |
| 1510630 | Eicher Tractor Gasket For G1 & Fw Hsg Joint         | 56   | 68129090 | 18% |
| 1510666 | Eicher Tractor Gasket For Upper Cover Of Fd Hsg.    | 15   | 68129090 | 18% |
| 1510678 | Eicher Tractor Gasket For Lower Cover A2 Of Fd Hsg  | 14   | 68129090 | 18% |
| 1510680 | Eicher Tractor Gasket For Oil Seal Hsg. Of Axle Tub | 14   | 68129090 | 18% |
| 1510721 | Eicher Tractor Spacer For Lay Shaft                 | 199  | 73182100 | 18% |
| 1510733 | Eicher Tractor Spacer(S)Lay Shaft                   | 155  | 73182100 | 18% |
| 1510745 | Eicher Tractor Spacer Thrust 71X8Lt                 | 140  | 73182100 | 18% |
| 1510757 | Eicher Tractor Spacer Thrust 71X10 Rt               | 239  | 73182100 | 18% |
| 1510824 | Eicher Tractor Lock Plate Hi/Lo Fork                | 10   | 87084000 | 18% |
| 1510836 | Eicher Tractor Lock Plate Hilo Rod                  | 10   | 87084000 | 18% |
| 1510848 | Eicher Tractor Lock Plate 1.0 Mm                    | 13   | 87084000 | 18% |
| 1510861 | Eicher Tractor Lock Washer 45 Dia                   | 13   | 73182100 | 18% |
| 1511117 | Eicher Tractor Primary Shaft - 242 (Teeth-26)       | 3493 | 87084000 | 18% |
| 1511154 | Eicher Tractor Diamond Pin                          | 34   | 73182100 | 18% |
| 1511178 | Eicher Tractor Cover Rt & Lt                        | 342  | 87084000 | 18% |
| 1511182 | Eicher Tractor Gasket For G2. E                     | 62   | 68129090 | 18% |
| 1511233 | Eicher Tractor Rod Shifting 1/2                     | 214  | 87089900 | 18% |
| 1511245 | Eicher Tractor Rod Shifting 3Rd/4Th                 | 140  | 87084000 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1511257 | Eicher Tractor Rod Shifting Rev Gear               | 215  | 87084000 | 18% |
| 1511269 | Eicher Tractor Rod Shifting H1/Lo                  | 209  | 87089900 | 18% |
| 1511270 | Eicher Tractor Reverse Gear Shaft                  | 281  | 87084000 | 18% |
| 1511294 | Eicher Tractor Lock Plate F R Shaft                | 11   | 87084000 | 18% |
| 1511350 | Eicher Tractor G.S.Fork H/L                        | 728  | 87084000 | 18% |
| 1511403 | Eicher Tractor Locking Screw 8X22                  | 22   | 73181500 | 18% |
| 1511695 | Eicher Tractor Spacer For Rear A                   | 71   | 73182100 | 18% |
| 1511737 | Eicher Tractor Clamping Plate                      | 292  | 87084000 | 18% |
| 1511774 | Eicher Tractor Outer Spacer                        | 444  | 87084000 | 18% |
| 1511956 | Eicher Tractor O Ring 129.5X3                      | 17   | 40169340 | 18% |
| 1511993 | Eicher Tractor Shim 0.5 Mm                         | 13   | 73182100 | 18% |
| 1512043 | Eicher Tractor Gasket For G1 Top Cover Ft.         | 30   | 68129090 | 18% |
| 1512160 | Eicher Tractor Lock Washer                         | 19   | 73182100 | 18% |
| 1512547 | Eicher Tractor G.S.Fork 1/2                        | 812  | 87084000 | 18% |
| 1512640 | Eicher Tractor Intermediate Ring                   | 23   | 87089900 | 18% |
| 1512651 | Eicher Tractor End Ring                            | 26   | 87089900 | 18% |
| 1512687 | Eicher Tractor Bellow Assy F/With Cover            | 44   | 40169990 | 18% |
| 1512742 | Eicher Tractor Gear Shift Lever Assy 242           | 313  | 87084000 | 18% |
| 1512764 | Eicher Tractor Drain Plug Mod.                     | 41   | 84099941 | 28% |
| 1512900 | Eicher Tractor Knob                                | 42   | 87084000 | 18% |
| 1512973 | Eicher Tractor Reverse Gear Bush                   | 162  | 87084000 | 18% |
| 1512985 | Eicher Tractor Reverse Gear Assy - 242 (Teeth-25)  | 1900 | 87084000 | 18% |
| 1513175 | Eicher Tractor Locking Screw M10X24.5              | 29   | 73181500 | 18% |
| 1513217 | Eicher Tractor Engaging Handle - 02                | 525  | 87084000 | 18% |
| 1513254 | Eicher Tractor Top Cover Front                     | 2225 | 87084000 | 18% |
| 1513497 | Eicher Tractor Flange For Flywheel.Housing         | 374  | 87084000 | 18% |
| 1513503 | Eicher Tractor Lever-Left                          | 300  | 87084000 | 18% |
| 1513515 | Eicher Tractor Lever - Right                       | 267  | 87084000 | 18% |
| 1513527 | Eicher Tractor Link                                | 232  | 87084000 | 18% |
| 1513539 | Eicher Tractor Centre Pin                          | 253  | 87085000 | 18% |
| 1513644 | Eicher Tractor Protective Cap For Pto Shaft        | 56   | 87084000 | 18% |
| 1513655 | Eicher Tractor Axial Star Pinion                   | 1745 | 87084000 | 18% |
| 1513758 | Eicher Tractor Final Drive Gear - High Speed       | 5501 | 87084000 | 18% |
| 1513760 | Eicher Tractor Rear Axle-(Hs/Db - 242 (Teeth-16)   | 5259 | 87084000 | 18% |
| 1513771 | Eicher Tractor Rear Axle-High Speed (16T)          | 4234 | 87084000 | 18% |
| 1513990 | Eicher Tractor Spring Dowel Sleeve Heavy           | 13   | 73182100 | 18% |
| 1514003 | Eicher Tractor Spring Dowel Sleeve 17/64"X22Mm     | 15   | 73182100 | 18% |
| 1514052 | Eicher Tractor Top Cover Front                     | 2713 | 87084000 | 18% |
| 1514064 | Eicher Tractor Oil Dipstick                        | 133  | 87084000 | 18% |
| 1514076 | Eicher Tractor Rear Axle Intg. H/S- 368 (Teeth-16) | 6641 | 87084000 | 18% |
| 1514143 | Eicher Tractor Gasket G2 Top Cover                 | 272  | 68129090 | 18% |
| 1514192 | Eicher Tractor Diff. Star Pinion (M)               | 903  | 87084000 | 18% |
| 1514360 | Eicher Tractor Bearing Housing                     | 1230 | 84099941 | 28% |
| 1514660 | Eicher Tractor Breather Adopter 242/312/364/333P   | 25   | 87089900 | 18% |
| 1514738 | Eicher Tractor Breather Tube Assy-Disc Brake Hsg   | 36   | 87083000 | 18% |
| 1514787 | Eicher Tractor Reduction Gear Housing              | 9482 | 87084000 | 18% |
| 1514805 | Eicher Tractor Cover Upper                         | 70   | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1514945 | Eicher Tractor Fork (M)                            | 467   | 87089900 | 18% |
| 1514970 | Eicher Tractor Assy. Coupling Shaft & Fork         | 1038  | 87084000 | 18% |
| 1515305 | Eicher Tractor Cover Upper                         | 69    | 87084000 | 18% |
| 1515317 | Eicher Tractor Gasket For Cover Upper (Brake Hsg.T | 40    | 68129090 | 18% |
| 1515330 | Eicher Tractor Bottom Cover For A2                 | 1666  | 87084000 | 18% |
| 1515482 | Eicher Tractor Diff. Star Pinion                   | 815   | 87084000 | 18% |
| 1515536 | Eicher Tractor Rear Axle-High Speed - 312 (Teeth-  | 4817  | 87084000 | 18% |
| 1515548 | Eicher Tractor Final Drive Gear - High Speed       | 7762  | 87084000 | 18% |
| 1515787 | Eicher Tractor Gasket Axle Tube And G2 Mtg         | 100   | 68129090 | 18% |
| 1515799 | Eicher Tractor Axial Star Pinion                   | 1448  | 87084000 | 18% |
| 1515817 | Eicher Tractor Spacer For Mudshield                | 25    | 73182100 | 18% |
| 1515846 | Eicher Tractor Gasket Oil Seal Hsg. Of Axle Tube   | 15    | 40169990 | 18% |
| 1515858 | Eicher Tractor Axle Tube Lt(M) Dr 2519             | 4406  | 87084000 | 18% |
| 1515895 | Eicher Tractor Felt Ring (For Oil Seal Hsg)        | 47    | 87084000 | 18% |
| 1515925 | Eicher Tractor Gasket G1 & G2 Coupling             | 49    | 68129090 | 18% |
| 1516206 | Eicher Tractor Shifter Fork 3/4                    | 922   | 87084000 | 18% |
| 1516220 | Eicher Tractor Rod Shifting 3/4                    | 209   | 87089900 | 18% |
| 1516413 | Eicher Tractor Sliding Gear 1/2 - 2686 (Teeth-46/  | 2781  | 87084000 | 18% |
| 1516425 | Eicher Tractor Spur Pinion 1s - 2686 (Teeth-22)    | 884   | 87084000 | 18% |
| 1516449 | Eicher Tractor Reverse Gear Assy - 2686            | 1946  | 87084000 | 18% |
| 1516462 | Eicher Tractor Knob                                | 34    | 87084000 | 18% |
| 1516474 | Eicher Tractor Spacer For Lay Shaft                | 168   | 73182100 | 18% |
| 1516504 | Eicher Tractor Shifter Rod R.G                     | 215   | 87084000 | 18% |
| 1516528 | Eicher Tractor Shifter Fork 3/4                    | 869   | 87084000 | 18% |
| 1516530 | Eicher Tractor Shifter Fork - Rev. Gear            | 872   | 87084000 | 18% |
| 1516541 | Eicher Tractor Lay Shaft - 242 (Teeth-9)           | 3861  | 87084000 | 18% |
| 1516553 | Eicher Tractor Intermediate Shaft - 242 (Teeth-23) | 2229  | 87084000 | 18% |
| 1516565 | Eicher Tractor Shifter Rod 1/2                     | 302   | 87084000 | 18% |
| 1516577 | Eicher Tractor Shifter Rod 3/4                     | 311   | 87084000 | 18% |
| 1516590 | Eicher Tractor Gear Housing Front - 364            | 22341 | 87084000 | 18% |
| 1516619 | Eicher Tractor Upper Cover For A2                  | 550   | 87084000 | 18% |
| 1516620 | Eicher Tractor Yoke                                | 118   | 84321090 | 12% |
| 1516632 | Eicher Tractor Assy. Coupling Shaft & Fork 241     | 965   | 87084000 | 18% |
| 1516656 | Eicher Tractor Spur Pinion 1St - 485 Dlx (Teeth-2  | 1180  | 87084000 | 18% |
| 1516668 | Eicher Tractor Spur Pinion 2Nd (Teeth-32)          | 1382  | 87084000 | 18% |
| 1516670 | Eicher Tractor Spur Gear 3Rd (Teeth-32)            | 1383  | 87084000 | 18% |
| 1516681 | Eicher Tractor Sliding Pinion 3 & 4 (Teeth-27)     | 1468  | 87084000 | 18% |
| 1516693 | Eicher Tractor Sliding Gear 1&2 Dlx -50Hp (Teeth-4 | 3137  | 87084000 | 18% |
| 1516723 | Eicher Tractor Intermediate Shaft485 Dlx (Teeth-2  | 2781  | 87084000 | 18% |
| 1516747 | Eicher Tractor Sliding Gear Hi/Lo - 485 Dlx (Teet  | 1854  | 87084000 | 18% |
| 1516942 | Eicher Tractor Intermediate Lever For Hi/Low       | 412   | 87089900 | 18% |
| 1517181 | Eicher Tractor Friction Plate                      | 1070  | 87083000 | 18% |
| 1517223 | Eicher Tractor Pin Small                           | 29    | 73182100 | 18% |
| 1517235 | Eicher Tractor Lock Pin                            | 12    | 73202000 | 18% |
| 1518021 | Eicher Tractor Oil Dipstick                        | 97    | 87084000 | 18% |
| 1518112 | Eicher Tractor Operating Rod                       | 65    | 87084000 | 18% |
| 1518124 | Eicher Tractor Washer 25X12X5,Zp,                  | 13    | 73182100 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1518136 | Eicher Tractor Gasket Brake Hsg & Axle Tube Mtg    | 14    | 68129090 | 18% |
| 1518150 | Eicher Tractor Gasket Axle Tube & G2 Mtg           | 64    | 68129090 | 18% |
| 1518264 | Eicher Tractor Output Gear                         | 798   | 87084000 | 18% |
| 1518290 | Eicher Tractor Spacer                              | 102   | 73182100 | 18% |
| 1518355 | Eicher Tractor Gasket For Pto Hsg                  | 51    | 68129090 | 18% |
| 1518410 | Eicher Tractor Stud M14X35/63,P10.9,Bp,            | 36    | 73182100 | 18% |
| 1518460 | Eicher Tractor G.S.Fork-R.G.                       | 871   | 87084000 | 18% |
| 1518562 | Eicher Tractor Gear Final Drive                    | 10507 | 87084000 | 18% |
| 1518598 | Eicher Tractor Washer For Disc Lock                | 176   | 73182100 | 18% |
| 1518768 | Eicher Tractor Gasket For Cover Lt & Rt            | 70    | 68129090 | 18% |
| 1518800 | Eicher Tractor Gasket For Brake Hsg                | 71    | 68129090 | 18% |
| 1518948 | Eicher Tractor Guide Bush 369                      | 306   | 87084000 | 18% |
| 1519049 | Eicher Tractor Shim 0.1Mm                          | 13    | 73182100 | 18% |
| 1519189 | Eicher Tractor Shim Oil Seal Hsg 106X96X0.5        | 19    | 73182100 | 18% |
| 1519207 | Eicher Tractor Shim Oil Seal Hsg 106X96X0.80       | 17    | 73182100 | 18% |
| 1519220 | Eicher Tractor Gasket For Bottom Cover A2 Of Fd Hs | 89    | 68129090 | 18% |
| 1519293 | Eicher Tractor Gasket For Guide Bush & G2 Coupling | 5     | 68129090 | 18% |
| 1519530 | Eicher Tractor Shim 0.1                            | 44    | 73182100 | 18% |
| 1519554 | Eicher Tractor Shim 0.20                           | 47    | 73182100 | 18% |
| 1519566 | Eicher Tractor Shim 0.30                           | 47    | 73182100 | 18% |
| 1519578 | Eicher Tractor Shim 0.50 (369)                     | 60    | 73182100 | 18% |
| 1519580 | Eicher Tractor Shim 1 (369)                        | 88    | 73182100 | 18% |
| 1519615 | Eicher Tractor Rear Axle - 04 (Teeth-15)           | 6016  | 87084000 | 18% |
| 1519694 | Eicher Tractor Strut                               | 86    | 87089400 | 18% |
| 1519906 | Eicher Tractor Dowel Pin (30 Mm)                   | 66    | 73182100 | 18% |
| 1519943 | Eicher Tractor Shim (53X22X0.1 Thk)-Aluminium      | 7     | 73182100 | 18% |
| 1519955 | Eicher Tractor Shim (53X22X0.2 Thk)-Grade O (Cr)   | 10    | 73182100 | 18% |
| 1519967 | Eicher Tractor Shim (53X22X0.3 Thk)-Grade O (Cr)   | 10    | 73182100 | 18% |
| 1519979 | Eicher Tractor Shim (53X22X0.5 Thk)-Grade O (Cr)   | 11    | 73182100 | 18% |
| 1519980 | Eicher Tractor Lock Washer                         | 20    | 73182100 | 18% |
| 1540294 | Eicher Tractor Banjo Bolt 22                       | 180   | 73181500 | 18% |
| 1541353 | Eicher Tractor Pin(485)                            | 23    | 73182100 | 18% |
| 1541444 | Eicher Tractor Back Up Ring 25Dia                  | 4     | 87089900 | 18% |
| 1541584 | Eicher Tractor Retainer                            | 11    | 87089900 | 18% |
| 1541626 | Eicher Tractor Adjusting Screw                     | 14    | 73181500 | 18% |
| 1541638 | Eicher Tractor Chuck Nut M 20X1                    | 14    | 73181500 | 18% |
| 1541651 | Eicher Tractor O Ring 17.3X2.4                     | 10    | 40169340 | 18% |
| 1541821 | Eicher Tractor Guide Flange                        | 119   | 87089900 | 18% |
| 1541857 | Eicher Tractor Guide Ring (Piston)                 | 252   | 84099112 | 28% |
| 1541870 | Eicher Tractor Bucket Washer                       | 178   | 40169990 | 18% |
| 1542424 | Eicher Tractor Handle                              | 418   | 84099941 | 28% |
| 1542540 | Eicher Tractor Conn.Pipe Assy.Rear                 | 82    | 87089900 | 18% |
| 1543593 | Eicher Tractor Banjo Bolt M14X1.5X36,Zp            | 28    | 73181500 | 18% |
| 1543829 | Eicher Tractor Spring (Relief Valve)               | 13    | 73209090 | 18% |
| 1544238 | Eicher Tractor Pressure Pipe Assy                  | 121   | 87089900 | 18% |
| 1544251 | Eicher Tractor Bottom Plug                         | 53    | 87084000 | 18% |
| 1544263 | Eicher Tractor Valve Casing                        | 866   | 87089900 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1544287 | Eicher Tractor Pump Housing Mcd                   | 915  | 87084000 | 18% |
| 1544330 | Eicher Tractor Valve Spring                       | 3    | 73202000 | 18% |
| 1544342 | Eicher Tractor Pressure Spring                    | 5    | 73182100 | 18% |
| 1544627 | Eicher Tractor O Ring 17.5X1.3                    | 8    | 40169340 | 18% |
| 1545553 | Eicher Tractor Back Up Ring                       | 4    | 87089900 | 18% |
| 1546028 | Eicher Tractor Dust Wiper                         | 4    | 87089900 | 18% |
| 1546077 | Eicher Tractor Back Up Ring                       | 4    | 87089900 | 18% |
| 1547392 | Eicher Tractor Hose Pipe                          | 106  | 40093100 | 18% |
| 1548232 | Eicher Tractor Check Valve Assy                   | 170  | 87089900 | 18% |
| 1548750 | Eicher Tractor Valve Spring                       | 9    | 73202000 | 18% |
| 1548761 | Eicher Tractor Plug                               | 236  | 87084000 | 18% |
| 1548827 | Eicher Tractor Dust Cover Front.                  | 14   | 87084000 | 18% |
| 1548876 | Eicher Tractor Stopped Pin                        | 13   | 73182100 | 18% |
| 1548980 | Eicher Tractor Ring F Lift Stop.                  | 25   | 87089900 | 18% |
| 1573305 | Eicher Tractor Rear Latch                         | 36   | 84099941 | 28% |
| 1580929 | Eicher Tractor Fulcrum Pin                        | 40   | 87089900 | 18% |
| 1581650 | Eicher Tractor Pin For Resting Rod 243            | 10   | 73182100 | 18% |
| 1584352 | Eicher Tractor Bkt For Accl. 243                  | 104  | 87089900 | 18% |
| 1584376 | Eicher Tractor Accelerator Lever 243              | 62   | 87085000 | 18% |
| 1584650 | Eicher Tractor Special Washer With Nut 40X16.5    | 38   | 73182990 | 18% |
| 1585526 | Eicher Tractor Bonnet Hinge Assy.                 | 184  | 87089900 | 18% |
| 1586040 | Eicher Tractor Clamp Lower                        | 32   | 87089900 | 18% |
| 1586051 | Eicher Tractor Clamp Upper                        | 29   | 87089900 | 18% |
| 1586967 | Eicher Tractor Bonnet Resting Rod 243             | 88   | 87089900 | 18% |
| 1587791 | Eicher Tractor Heel Rest                          | 68   | 87085000 | 18% |
| 1587961 | Eicher Tractor Side Pad 243                       | 27   | 40169320 | 18% |
| 1589155 | Eicher Tractor Front Axle Support                 | 9086 | 87089900 | 18% |
| 1589416 | Eicher Tractor Lead Assy I (350 Mm)               | 593  | 85441920 | 18% |
| 1611100 | Eicher Tractor Clamping Bracket                   | 30   | 87089900 | 18% |
| 1611574 | Eicher Tractor Stud M10X45,A8.8,Bp,(F)            | 24   | 73182100 | 18% |
| 1611847 | Eicher Tractor Pin Small                          | 30   | 73182100 | 18% |
| 1611896 | Eicher Tractor Lever Lower Left & Right           | 118  | 87084000 | 18% |
| 1611902 | Eicher Tractor Tension Tie Lt & Rt                | 404  | 87083000 | 18% |
| 1611999 | Eicher Tractor Pin Big                            | 40   | 73182100 | 18% |
| 1612414 | Eicher Tractor Head Light Assy Rt 243             | 599  | 85122010 | 18% |
| 1613583 | Eicher Tractor Face Seal                          | 34   | 87089900 | 18% |
| 1613595 | Eicher Tractor Cover For Face Seal                | 97   | 87089900 | 18% |
| 1613972 | Eicher Tractor Tension Spring                     | 102  | 73202000 | 18% |
| 1614034 | Eicher Tractor Oil Seal                           | 110  | 40169330 | 18% |
| 1614630 | Eicher Tractor Shim 0.2Mm                         | 5    | 73182100 | 18% |
| 1614721 | Eicher Tractor Clamping Stud                      | 101  | 73181500 | 18% |
| 1615427 | Eicher Tractor Sleeve                             | 253  | 87084000 | 18% |
| 1615555 | Eicher Tractor Pin                                | 26   | 73182100 | 18% |
| 1615798 | Eicher Tractor V Ring                             | 23   | 40169990 | 18% |
| 1615804 | Eicher Tractor V Ring Guard                       | 25   | 87089900 | 18% |
| 1615877 | Eicher Tractor Shim 32X25.5X.032                  | 5    | 73182100 | 18% |
| 1615889 | Eicher Tractor Gasket For Brake Pedal & Cover Mtg | 9    | 68129090 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1616316 | Eicher Tractor Spacer                          | 83   | 73182100 | 18% |
| 1616705 | Eicher Tractor V Ring V-50                     | 28   | 40169990 | 18% |
| 1616791 | Eicher Tractor V Ring V-65                     | 39   | 40169990 | 18% |
| 1616870 | Eicher Tractor V Ring V-60A                    | 25   | 87089900 | 18% |
| 1617242 | Eicher Tractor V Ring Guard                    | 39   | 87089900 | 18% |
| 1617448 | Eicher Tractor Top Link End Left               | 288  | 87089900 | 18% |
| 1617540 | Eicher Tractor Foot Rest Assy.                 | 369  | 87089900 | 18% |
| 1617590 | Eicher Tractor Plastic Strainer                | 114  | 39021000 | 18% |
| 1617631 | Eicher Tractor Bush Shoulder                   | 142  | 87085000 | 18% |
| 1617643 | Eicher Tractor Bush                            | 607  | 87085000 | 18% |
| 1618015 | Eicher Tractor Pawl Link                       | 62   | 87089900 | 18% |
| 1618040 | Eicher Tractor Gasket-Engine/Flywheel Hsg Mtg. | 213  | 84099990 | 28% |
| 1618842 | Eicher Tractor Pedal Shaft                     | 727  | 87084000 | 18% |
| 1618878 | Eicher Tractor Cover                           | 96   | 87084000 | 18% |
| 1618982 | Eicher Tractor Rod Assy                        | 90   | 87084000 | 18% |
| 1619585 | Eicher Tractor Pin For Pawl                    | 53   | 73182100 | 18% |
| 1619597 | Eicher Tractor Pin                             | 37   | 73182100 | 18% |
| 1619603 | Eicher Tractor Pawl                            | 244  | 87084000 | 18% |
| 1619627 | Eicher Tractor Spindle Fork 241/242/312/364    | 434  | 87089900 | 18% |
| 1619639 | Eicher Tractor Fork                            | 1045 | 87084000 | 18% |
| 1619640 | Eicher Tractor Adoptor                         | 1075 | 87089900 | 18% |
| 1619652 | Eicher Tractor Double Pin                      | 75   | 73182100 | 18% |
| 1619664 | Eicher Tractor Pin                             | 83   | 73182100 | 18% |
| 1619676 | Eicher Tractor Link Plate                      | 85   | 87089900 | 18% |
| 1619688 | Eicher Tractor Clutch Cover Assly-10"          | 4115 | 87089300 | 18% |
| 1619690 | Eicher Tractor Driven Disc-10"                 | 1260 | 87089300 | 18% |
| 1619706 | Eicher Tractor Steering Lever Single           | 1054 | 87089400 | 18% |
| 1619718 | Eicher Tractor Steering Lever Double           | 2292 | 87089400 | 18% |
| 1655802 | Eicher Tractor Spacer For Pedal Shaft          | 70   | 73182100 | 18% |
| 1655980 | Eicher Tractor Knob For Hand Brake             | 94   | 87083000 | 18% |
| 1656065 | Eicher Tractor Spacer                          | 86   | 73182100 | 18% |
| 1656089 | Eicher Tractor Dowel Pin Fw Hsg(F)             | 29   | 84099949 | 28% |
| 1656090 | Eicher Tractor Diamond Pin(F)                  | 36   | 84099949 | 28% |
| 1656119 | Eicher Tractor Clutch Pedal                    | 408  | 87089300 | 18% |
| 1656120 | Eicher Tractor Tension Spring                  | 55   | 73202000 | 18% |
| 1656430 | Eicher Tractor Fork                            | 56   | 87084000 | 18% |
| 1659686 | Eicher Tractor Brake Pedal Left                | 667  | 87083000 | 18% |
| 1659819 | Eicher Tractor Stud M10X53,A8.8,Bp,            | 36   | 73182100 | 18% |
| 1659870 | Eicher Tractor Rod Assy                        | 58   | 87089900 | 18% |
| 1670037 | Eicher Tractor Bearing Bush                    | 265  | 84833000 | 18% |
| 1670049 | Eicher Tractor Plug                            | 23   | 84099941 | 28% |
| 1670050 | Eicher Tractor Guide Bearing Cap               | 1392 | 84099941 | 28% |
| 1670062 | Eicher Tractor Main Bearing Cap                | 1168 | 84822090 | 18% |
| 1670074 | Eicher Tractor Guidance Bush                   | 29   | 84099941 | 28% |
| 1670086 | Eicher Tractor Main Bearing (Grooved)          | 204  | 84825011 | 18% |
| 1670098 | Eicher Tractor Main Bearing                    | 163  | 84822090 | 18% |
| 1670104 | Eicher Tractor Cylinder Liner M/Cd             | 3520 | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1670116 | Eicher Tractor O-Ring For Cyl Liner                | 39    | 40169320 | 18% |
| 1670128 | Eicher Tractor O-Ring For Cyl Liner                | 186   | 40169320 | 18% |
| 1670130 | Eicher Tractor Pipe For Dipstick                   | 33    | 84099941 | 28% |
| 1670141 | Eicher Tractor Oil Pressure Switch                 | 207   | 85361010 | 18% |
| 1670153 | Eicher Tractor Cover                               | 122   | 84099941 | 28% |
| 1670177 | Eicher Tractor Plug                                | 66    | 84099941 | 28% |
| 1670189 | Eicher Tractor Union Valtra                        | 76    | 84099941 | 28% |
| 1670232 | Eicher Tractor Gasket For Cover                    | 12    | 48239030 | 18% |
| 1670359 | Eicher Tractor Starter Rim                         | 2056  | 84833000 | 18% |
| 1670402 | Eicher Tractor Plug B-36                           | 43    | 84099941 | 28% |
| 1670414 | Eicher Tractor Cylinder Head Gasket (Valtra)       | 1730  | 84841090 | 18% |
| 1670426 | Eicher Tractor Cyl. Head Screw (12X140 )           | 171   | 73181500 | 18% |
| 1670438 | Eicher Tractor Cover For Cyl. Head                 | 118   | 84099941 | 28% |
| 1670440 | Eicher Tractor Gasket For Cyl Head Cover           | 17    | 48239030 | 18% |
| 1670451 | Eicher Tractor Stud Bolt Bm8*40 Din 939-10K        | 20    | 73181500 | 18% |
| 1670463 | Eicher Tractor Lifting Eye For Cyl. Head           | 196   | 84099941 | 28% |
| 1670487 | Eicher Tractor Extension For Lifting               | 273   | 73182990 | 18% |
| 1670499 | Eicher Tractor Screw M12*142 For Cyl Head          | 197   | 73181500 | 18% |
| 1670505 | Eicher Tractor Nut M12                             | 44    | 73181600 | 18% |
| 1670517 | Eicher Tractor Rocker Cover Assy                   | 1115  | 84099941 | 28% |
| 1670530 | Eicher Tractor Gasket For Rocker Cover             | 216   | 45049000 | 18% |
| 1670542 | Eicher Tractor Washer For Tappet Cover             | 12    | 73182100 | 18% |
| 1670554 | Eicher Tractor Rubber Washer For Tappet Cover      | 12    | 40169320 | 18% |
| 1670566 | Eicher Tractor Breathing Pipe                      | 757   | 40092200 | 18% |
| 1670578 | Eicher Tractor Coil L=200                          | 17    | 73202000 | 18% |
| 1670608 | Eicher Tractor Rocker Arm (Valtra)                 | 520   | 84099941 | 28% |
| 1670610 | Eicher Tractor Adjusting Screw                     | 49    | 73181500 | 18% |
| 1670621 | Eicher Tractor Plug With Flange                    | 82    | 84099941 | 28% |
| 1670633 | Eicher Tractor Support For Rocker Shaft            | 417   | 84099941 | 28% |
| 1670645 | Eicher Tractor Compression Spring (For Rocker Shaf | 17    | 73202000 | 18% |
| 1670657 | Eicher Tractor Rocker Arm Shaft                    | 1305  | 84099990 | 28% |
| 1670669 | Eicher Tractor Nut,M10 L=25                        | 36    | 84099941 | 28% |
| 1670670 | Eicher Tractor Valve Spring Cotter                 | 11    | 73202000 | 18% |
| 1670682 | Eicher Tractor Valve Spring Cap (Valtra)           | 100   | 73202000 | 18% |
| 1670694 | Eicher Tractor Valve Spring (Valtra)               | 121   | 73202000 | 18% |
| 1670700 | Eicher Tractor Exhaust Valve                       | 476   | 84099111 | 28% |
| 1670712 | Eicher Tractor Inlet Valve                         | 289   | 84099941 | 28% |
| 1670724 | Eicher Tractor Push Rod (Valtra)                   | 161   | 84099990 | 28% |
| 1670736 | Eicher Tractor Tappet (Valtra)                     | 750   | 84099990 | 28% |
| 1670748 | Eicher Tractor Cam Shaft - Valtra                  | 9053  | 84831099 | 18% |
| 1670761 | Eicher Tractor Crank Shaft Assy.                   | 27023 | 84831092 | 18% |
| 1670797 | Eicher Tractor Counter Weight For Cr Shaft(Big)    | 761   | 84099941 | 28% |
| 1670809 | Eicher Tractor Counter Weight For Cr Shaft(Small)  | 879   | 84099941 | 28% |
| 1670815 | Eicher Tractor Parallel Key                        | 52    | 73182990 | 18% |
| 1670839 | Eicher Tractor Piston Pin (Auto /30Kva /45 Kva)    | 540   | 84099913 | 28% |
| 1670840 | Eicher Tractor Conrod Assy Valtra                  | 3743  | 84834000 | 18% |
| 1670864 | Eicher Tractor Screw For Connecting Rod            | 145   | 73181500 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1670876 | Eicher Tractor Nut For Con Rod                     | 46   | 84099941 | 28% |
| 1670888 | Eicher Tractor Bushing                             | 314  | 84833000 | 18% |
| 1670890 | Eicher Tractor Big End Bearing                     | 201  | 84099941 | 28% |
| 1670918 | Eicher Tractor Thrust Washer With Out Lug.         | 136  | 73182100 | 18% |
| 1670920 | Eicher Tractor Thrust Washer With Lug.             | 138  | 73182100 | 18% |
| 1670931 | Eicher Tractor Gear For Crank Shaft                | 2088 | 87084000 | 18% |
| 1670943 | Eicher Tractor Crank Gear (Vltra)                  | 1811 | 87084000 | 18% |
| 1670955 | Eicher Tractor Oil Deflector                       | 69   | 84099990 | 28% |
| 1670967 | Eicher Tractor Dust Shield                         | 54   | 40169990 | 18% |
| 1670979 | Eicher Tractor Hub For Crank Shaft                 | 1946 | 87084000 | 18% |
| 1670980 | Eicher Tractor V-Belt Pulley (Crank)               | 1355 | 40101290 | 18% |
| 1671005 | Eicher Tractor Gasket For Gear Hsg                 | 172  | 48239030 | 18% |
| 1671017 | Eicher Tractor Gear Housing M/Cd                   | 7856 | 84834000 | 18% |
| 1671030 | Eicher Tractor Shaft (Valtra)                      | 1990 | 84099990 | 28% |
| 1671042 | Eicher Tractor Idler Gear                          | 5479 | 87084000 | 18% |
| 1671066 | Eicher Tractor Bearing                             | 407  | 84824000 | 18% |
| 1671080 | Eicher Tractor Front Cover M/Cd                    | 5213 | 84099941 | 28% |
| 1671091 | Eicher Tractor Gasket For Front Cover (Vltra)      | 217  | 48239030 | 18% |
| 1671108 | Eicher Tractor Shield For Oil Seal                 | 32   | 84099990 | 28% |
| 1671110 | Eicher Tractor Gasket For Oil Filling Pipe         | 16   | 45049000 | 18% |
| 1671121 | Eicher Tractor Oil Filling Pipe                    | 579  | 84099941 | 28% |
| 1671133 | Eicher Tractor Oil Filler Plug                     | 34   | 39269099 | 18% |
| 1671145 | Eicher Tractor Washer For Front Cover              | 22   | 73182100 | 18% |
| 1671170 | Eicher Tractor Bearing Housing                     | 972  | 84099941 | 28% |
| 1671194 | Eicher Tractor Gasket For Bearing Hsg.             | 49   | 48239030 | 18% |
| 1671200 | Eicher Tractor Fastner                             | 13   | 84099941 | 28% |
| 1671236 | Eicher Tractor Hyd.Pump Cover(Valtra)              | 26   | 39021000 | 18% |
| 1671250 | Eicher Tractor Gasket                              | 151  | 84099941 | 28% |
| 1671261 | Eicher Tractor Seal Ring A 18X26 Din 7603 Cu       | 15   | 84099941 | 28% |
| 1671297 | Eicher Tractor Oil Dipstick                        | 73   | 84099941 | 28% |
| 1671303 | Eicher Tractor Oil Pump Assly.                     | 6280 | 84133020 | 28% |
| 1671327 | Eicher Tractor Gear Wheel (Gear For Oil Pump)      | 1634 | 87084000 | 18% |
| 1671339 | Eicher Tractor Washer For Oil Pump                 | 27   | 73182100 | 18% |
| 1671390 | Eicher Tractor Gasket                              | 8    | 68129922 | 18% |
| 1671418 | Eicher Tractor Nut For Section Pipe                | 225  | 84099941 | 28% |
| 1671420 | Eicher Tractor Adjusting Shim                      | 12   | 73182100 | 18% |
| 1671431 | Eicher Tractor Gasket For Oil Pump                 | 33   | 48239030 | 18% |
| 1671443 | Eicher Tractor Pressure Pipe                       | 316  | 84099941 | 28% |
| 1671479 | Eicher Tractor Suction Pipe Assly 6100             | 218  | 84099941 | 28% |
| 1671510 | Eicher Tractor Filter (Vltra)                      | 384  | 84219900 | 18% |
| 1671522 | Eicher Tractor Exhaust Manifold (30Kva)            | 2782 | 84099941 | 28% |
| 1671534 | Eicher Tractor Intake Manifold (30Kva / 45Kva /62. | 2156 | 84099941 | 28% |
| 1671546 | Eicher Tractor Gasket For Inlet Manifold           | 33   | 48239030 | 18% |
| 1671558 | Eicher Tractor Plug 7/8-14 Unf For Inlet Manifold  | 55   | 84099941 | 28% |
| 1671595 | Eicher Tractor Thermostat (Vltra)                  | 739  | 90321090 | 18% |
| 1671613 | Eicher Tractor Union M14*1.5                       | 67   | 84099941 | 28% |
| 1671698 | Eicher Tractor Fuel Inj. Pipe Assy. (Set)          | 765  | 84099941 | 28% |





|         |   |       |          |     |
|---------|---|-------|----------|-----|
| 1671741 | Eicher Tractor Washer Forinjector(Steel)            | 12    | 73182100 | 18% |
| 1671753 | Eicher Tractor Rubber Ring (St. Model For Injector) | 12    | 40169990 | 18% |
| 1671765 | Eicher Tractor Washer For Injector (30Kva/45Kva)    | 24    | 73182100 | 18% |
| 1671777 | Eicher Tractor Overflow Pipe                        | 125   | 40092200 | 18% |
| 1671789 | Eicher Tractor Screw (For Over Flow Pipe)           | 24    | 73181500 | 18% |
| 1671790 | Eicher Tractor Hollow Screw (For Overflow Pipe)     | 23    | 73181500 | 18% |
| 1671807 | Eicher Tractor Over Flow Pipe Assy                  | 46    | 84099941 | 28% |
| 1671844 | Eicher Tractor Screw M6*16                          | 7     | 73181500 | 18% |
| 1671868 | Eicher Tractor Screw M6*16                          | 19    | 73181500 | 18% |
| 1671935 | Eicher Tractor Gasket For Water Pump                | 14    | 68129922 | 18% |
| 1671947 | Eicher Tractor Gasket For Water Pump                | 47    | 48239030 | 18% |
| 1671972 | Eicher Tractor Water Retun Pipe                     | 375   | 84099941 | 28% |
| 1671984 | Eicher Tractor Gasket For Water Ret. Pipe           | 10    | 68129922 | 18% |
| 1671996 | Eicher Tractor Thermostat Housing                   | 1700  | 84099941 | 28% |
| 1672009 | Eicher Tractor Gasket For Thermo State Hsg          | 6     | 68129922 | 18% |
| 1672010 | Eicher Tractor Pipe By Pass                         | 264   | 84099941 | 28% |
| 1672034 | Eicher Tractor Oil Seal (Valtra)                    | 1562  | 40169330 | 18% |
| 1672046 | Eicher Tractor Piston Ring Set                      | 917   | 84099913 | 28% |
| 1672083 | Eicher Tractor Oil Seal (Front)                     | 449   | 40169320 | 18% |
| 1672095 | Eicher Tractor Ball Bearing 6009-115                | 603   | 84821011 | 18% |
| 1672113 | Eicher Tractor Dual Fuel Filter                     | 1750  | 84219900 | 18% |
| 1672228 | Eicher Tractor Hose                                 | 156   | 40093100 | 18% |
| 1672241 | Eicher Tractor Hose Lower 6100                      | 370   | 40093100 | 18% |
| 1672253 | Eicher Tractor Upper Water Pipe                     | 152   | 40092200 | 18% |
| 1672265 | Eicher Tractor Gasket For Exhaust Muffler           | 60    | 68129090 | 18% |
| 1672319 | Eicher Tractor Spring 6100                          | 13    | 73209090 | 18% |
| 1672320 | Eicher Tractor Strainer For Fuel Tank               | 185   | 84219900 | 18% |
| 1672356 | Eicher Tractor End Pipe                             | 178   | 87089900 | 18% |
| 1672393 | Eicher Tractor Seal                                 | 123   | 40169990 | 18% |
| 1672400 | Eicher Tractor Ffan Dia.431                         | 3666  | 84099990 | 28% |
| 1672447 | Eicher Tractor Packing                              | 233   | 84099941 | 28% |
| 1672581 | Eicher Tractor Rigid Fuel Pipe (Feed Pump)          | 672   | 40094200 | 18% |
| 1672599 | Eicher Tractor Rigid Fuel Pipe (Fuel Filter)        | 593   | 40094200 | 18% |
| 1672654 | Eicher Tractor Radiator Cap 0.9 Bar                 | 208   | 87087000 | 18% |
| 1672691 | Eicher Tractor Filter Connecting Pipe               | 114   | 84219900 | 18% |
| 1672757 | Eicher Tractor Cover                                | 118   | 84091000 | 28% |
| 1672769 | Eicher Tractor Oil Pressure Valve                   | 214   | 84099941 | 28% |
| 1672770 | Eicher Tractor Valve Seat                           | 214   | 84099941 | 28% |
| 1672782 | Eicher Tractor Spring                               | 31    | 73209090 | 18% |
| 1672824 | Eicher Tractor Union For Feed Pump                  | 66    | 84099990 | 28% |
| 1673099 | Eicher Tractor Gasket For Oil Pan (Vltra)           | 173   | 45049000 | 18% |
| 1673142 | Eicher Tractor Cylinder Block M/Cd                  | 67186 | 84099941 | 28% |
| 1673397 | Eicher Tractor Nut For Crank Shaft                  | 302   | 84099941 | 28% |
| 1680470 | Eicher Tractor Mounting Bracket Clamp               | 48    | 87089900 | 18% |
| 1680559 | Eicher Tractor Link Upper                           | 106   | 87089900 | 18% |
| 1680729 | Eicher Tractor Spacer For Accl. Shaft 243           | 15    | 73182100 | 18% |
| 1680742 | Eicher Tractor Accelerator Lever 312                | 166   | 87084000 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1681047 | Eicher Tractor Monogram Lt 243 New          | 84   | 39199090 | 18% |
| 1681059 | Eicher Tractor Monogram Rt 243 New          | 84   | 39199090 | 18% |
| 1681060 | Eicher Tractor Monogram 243 (Lt&Rt)         | 31   | 39199090 | 18% |
| 1681230 | Eicher Tractor Bracket For Brake Switch     | 130  | 87083000 | 18% |
| 1681394 | Eicher Tractor Brake Pedal Right-241        | 722  | 87083000 | 18% |
| 1682283 | Eicher Tractor Label For Turning Switch     | 11   | 83100090 | 18% |
| 1682325 | Eicher Tractor Coupling Mouth 364Exp        | 2036 | 87084000 | 18% |
| 1682829 | Eicher Tractor Mirror 242/241 Round         | 106  | 70060000 | 18% |
| 1683123 | Eicher Tractor Hazard Switch                | 281  | 85365090 | 18% |
| 1683299 | Eicher Tractor Horn                         | 270  | 85122010 | 18% |
| 1683342 | Eicher Tractor Horn Push Button Assy        | 56   | 85123010 | 18% |
| 1683366 | Eicher Tractor Lens For Front Light Assy    | 87   | 85123010 | 18% |
| 1683378 | Eicher Tractor Lens For Rear Light Assy Lt. | 149  | 85122090 | 18% |
| 1683380 | Eicher Tractor Lens For Rear Light Assy Rt. | 160  | 85123010 | 18% |
| 1683524 | Eicher Tractor Grommet                      | 12   | 40169990 | 18% |
| 1710126 | Eicher Tractor Sealing Cup                  | 68   | 84099941 | 28% |
| 1710163 | Eicher Tractor Oil Tube                     | 54   | 84099941 | 28% |
| 1710199 | Eicher Tractor Gasket Fuel Feed Pump        | 8    | 68129922 | 18% |
| 1710266 | Eicher Tractor Gasket Insp Cov/Rear         | 35   | 68129922 | 18% |
| 1710278 | Eicher Tractor Suction Screen Assy          | 330  | 84099941 | 28% |
| 1710321 | Eicher Tractor Main Bearing Front           | 837  | 84822090 | 18% |
| 1710448 | Eicher Tractor Big End Bearing              | 648  | 84821011 | 18% |
| 1710485 | Eicher Tractor Main Brg. Middle Std         | 748  | 84822090 | 18% |
| 1710515 | Eicher Tractor Shim 0.16Mm (Rocker Arm)     | 5    | 73182100 | 18% |
| 1710552 | Eicher Tractor Spacer Rear                  | 198  | 73182100 | 18% |
| 1710564 | Eicher Tractor Gasket Bearing Housing       | 65   | 68129922 | 18% |
| 1710606 | Eicher Tractor Gasket Brg Hsg Cover         | 49   | 68129922 | 18% |
| 1710618 | Eicher Tractor Gear Ring                    | 1905 | 84835090 | 18% |
| 1710631 | Eicher Tractor Fly Wheel Nut                | 289  | 84099941 | 28% |
| 1710643 | Eicher Tractor Cylinder Head Cover          | 240  | 84099941 | 28% |
| 1710746 | Eicher Tractor Pin Block                    | 1074 | 84099941 | 28% |
| 1710771 | Eicher Tractor Cyl. Temp. Gauge             | 781  | 85118000 | 28% |
| 1710813 | Eicher Tractor Clamping Cone                | 6    | 84099941 | 28% |
| 1710825 | Eicher Tractor V S Retainer                 | 95   | 84099941 | 28% |
| 1710965 | Eicher Tractor Gasket Inlet                 | 12   | 68129922 | 18% |
| 1710990 | Eicher Tractor Grooved Disc                 | 17   | 84099941 | 28% |
| 1711064 | Eicher Tractor Decompression Rod            | 11   | 87089900 | 18% |
| 1711106 | Eicher Tractor Shim 0.16Mm                  | 5    | 73182100 | 18% |
| 1711167 | Eicher Tractor Shim 0.45Mm                  | 5    | 73182100 | 18% |
| 1711179 | Eicher Tractor Banjo Bolt M8X30             | 24   | 73181500 | 18% |
| 1711246 | Eicher Tractor Shim 0.20Mm                  | 5    | 73182100 | 18% |
| 1711260 | Eicher Tractor Spring Retainer              | 103  | 84099941 | 28% |
| 1711283 | Eicher Tractor Spring                       | 44   | 73209090 | 18% |
| 1711295 | Eicher Tractor Governor Sleeve              | 910  | 84099941 | 28% |
| 1711313 | Eicher Tractor Governor Weight              | 235  | 84099941 | 28% |
| 1711325 | Eicher Tractor Governor Fork                | 421  | 84099941 | 28% |
| 1711337 | Eicher Tractor Governor Lever               | 244  | 84099941 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1711349 | Eicher Tractor Accelerator Shaft                   | 355  | 84099941 | 28% |
| 1711374 | Eicher Tractor Control Rod                         | 77   | 84099941 | 28% |
| 1711386 | Eicher Tractor Spring For Cont.Rod. 298 St. Model  | 6    | 73202000 | 18% |
| 1711453 | Eicher Tractor Gasket For Gov. Cover               | 12   | 68129922 | 18% |
| 1711465 | Eicher Tractor Governor Cover                      | 339  | 40169320 | 18% |
| 1711489 | Eicher Tractor Accelerator Lever                   | 146  | 84099941 | 28% |
| 1711726 | Eicher Tractor Lifter Guide For 298 Old/Esg        | 266  | 84099941 | 28% |
| 1711817 | Eicher Tractor Pump Driving Gear                   | 958  | 87084000 | 18% |
| 1711866 | Eicher Tractor Dual Fuel Filter Assly.             | 4464 | 84219900 | 18% |
| 1711880 | Eicher Tractor Fuel Feed Pump (Mico)               | 3586 | 84133010 | 28% |
| 1711891 | Eicher Tractor Lifting Hook                        | 250  | 84099941 | 28% |
| 1711908 | Eicher Tractor Gasket Extt Mani                    | 40   | 84099941 | 28% |
| 1711910 | Eicher Tractor Cooling Impeller                    | 374  | 84099941 | 28% |
| 1711994 | Eicher Tractor Cylindrical Pin 4X8                 | 14   | 73182990 | 18% |
| 1712202 | Eicher Tractor Impellor Housing                    | 420  | 84099941 | 28% |
| 1712240 | Eicher Tractor Clamping Bracket                    | 164  | 73182990 | 18% |
| 1712251 | Eicher Tractor Clamping Pin                        | 12   | 84129090 | 18% |
| 1712263 | Eicher Tractor Clamping Strip                      | 42   | 84099941 | 28% |
| 1712287 | Eicher Tractor Hex Bolt 6X150                      | 41   | 73181500 | 18% |
| 1712330 | Eicher Tractor Clamp                               | 25   | 84099941 | 28% |
| 1712380 | Eicher Tractor Governor Flange                     | 747  | 84099941 | 28% |
| 1712391 | Eicher Tractor Shim                                | 3    | 73182100 | 18% |
| 1712410 | Eicher Tractor Breather Assy                       | 115  | 84099941 | 28% |
| 1712494 | Eicher Tractor Pin Governor Lever                  | 16   | 84129090 | 18% |
| 1712718 | Eicher Tractor Thin Washer                         | 5    | 73182100 | 18% |
| 1712810 | Eicher Tractor Rubber Washer                       | 5    | 40169320 | 18% |
| 1712822 | Eicher Tractor Spring For Fule Stop Rod. 298 Model | 3    | 73202000 | 18% |
| 1713097 | Eicher Tractor L O Pump 298                        | 2059 | 84099941 | 28% |
| 1713577 | Eicher Tractor Pointer                             | 16   | 84129090 | 18% |
| 1713644 | Eicher Tractor Nozzle Head                         | 15   | 84099941 | 28% |
| 1713656 | Eicher Tractor Spring For Nozzle Assly             | 2    | 73202000 | 18% |
| 1713700 | Eicher Tractor Adopter                             | 50   | 84099941 | 28% |
| 1714016 | Eicher Tractor Stud M 8X44 A 8.8 ,B P              | 26   | 73182100 | 18% |
| 1714077 | Eicher Tractor Star Tol. Ring (I)                  | 241  | 84099941 | 28% |
| 1714247 | Eicher Tractor Piston Pin                          | 381  | 84099913 | 28% |
| 1714326 | Eicher Tractor Driving Plate                       | 15   | 84099941 | 28% |
| 1714892 | Eicher Tractor Impellor Housing Assy               | 421  | 84099941 | 28% |
| 1714983 | Eicher Tractor Special Banjo Bolt                  | 24   | 73181500 | 18% |
| 1714995 | Eicher Tractor Adopter For Breather M/Cd           | 136  | 84099941 | 28% |
| 1715112 | Eicher Tractor Extension Tube                      | 112  | 87089900 | 18% |
| 1715173 | Eicher Tractor Sealing Washer                      | 8    | 73182990 | 18% |
| 1715185 | Eicher Tractor Cyl Pin 7 Dia                       | 9    | 84099941 | 28% |
| 1715215 | Eicher Tractor Hollow Stud                         | 33   | 84099941 | 28% |
| 1715355 | Eicher Tractor Inlet Mainfold M/Cd Frt             | 429  | 84099941 | 28% |
| 1715367 | Eicher Tractor Inlet Mainfold M/Cd Rear            | 280  | 84099941 | 28% |
| 1715380 | Eicher Tractor Gkt F Mounting Base                 | 9    | 84099941 | 28% |
| 1715392 | Eicher Tractor Driving Jaw                         | 301  | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1715410 | Eicher Tractor Rubber Hose                         | 63    | 40093100 | 18% |
| 1715689 | Eicher Tractor Valve Seat Exhaust                  | 148   | 84099941 | 28% |
| 1715690 | Eicher Tractor Valve Seat Inlet                    | 148   | 84099941 | 28% |
| 1715707 | Eicher Tractor Inlet Masked Valve                  | 558   | 84099941 | 28% |
| 1715719 | Eicher Tractor Exhaust Valve                       | 289   | 84099941 | 28% |
| 1715720 | Eicher Tractor V S Retainer                        | 212   | 84099941 | 28% |
| 1715774 | Eicher Tractor O' Ring 17.3X3.5                    | 28    | 40169320 | 18% |
| 1715835 | Eicher Tractor Cam Follower \$                     | 220   | 84099949 | 28% |
| 1716128 | Eicher Tractor Lifter Guide Retainer               | 19    | 84099941 | 28% |
| 1716530 | Eicher Tractor Pulley Adj Shim .5Mm                | 5     | 73182100 | 18% |
| 1716542 | Eicher Tractor Pulley Adj Shim 1Mm                 | 5     | 73182100 | 18% |
| 1716608 | Eicher Tractor Felt Ring 33X22X4                   | 8     | 59113120 | 18% |
| 1716610 | Eicher Tractor Dust Cover                          | 67    | 84099941 | 28% |
| 1716645 | Eicher Tractor O Ring 36X2                         | 6     | 40169320 | 18% |
| 1716669 | Eicher Tractor Outer Ring                          | 133   | 84099941 | 28% |
| 1716682 | Eicher Tractor Blower Supp.Rear                    | 622   | 84099941 | 28% |
| 1716724 | Eicher Tractor Spl Screw 8X20                      | 14    | 73181500 | 18% |
| 1716748 | Eicher Tractor Gasket Elbow Assy                   | 5     | 68129922 | 18% |
| 1716750 | Eicher Tractor Mounting Base                       | 87    | 84099941 | 28% |
| 1716967 | Eicher Tractor Gasket                              | 8     | 68129922 | 18% |
| 1717091 | Eicher Tractor Washer Push Rod Sleeve              | 16    | 73182100 | 18% |
| 1717110 | Eicher Tractor Spring( For 298 Push Rod Sleeve)    | 26    | 73202000 | 18% |
| 1717169 | Eicher Tractor Nut Push Rod Sleeve                 | 49    | 73181500 | 18% |
| 1717182 | Eicher Tractor Con Rod Bolt                        | 81    | 73181500 | 18% |
| 1717224 | Eicher Tractor Small End Bush                      | 203   | 84099941 | 28% |
| 1717303 | Eicher Tractor Stopping Lever                      | 22    | 84219900 | 18% |
| 1717315 | Eicher Tractor Locating Pin                        | 16    | 84099941 | 28% |
| 1717327 | Eicher Tractor Hinge Block M/Cd                    | 476   | 84099941 | 28% |
| 1717388 | Eicher Tractor Cyl. Liner 100.0                    | 3871  | 84099941 | 28% |
| 1717467 | Eicher Tractor Valve Guide (Multi)                 | 72    | 84099111 | 28% |
| 1717492 | Eicher Tractor Oil Seal Valve Stem Imported No Ind | 50    | 40169990 | 18% |
| 1717509 | Eicher Tractor Special Washer For Cyl Head 398     | 12    | 73182990 | 18% |
| 1717534 | Eicher Tractor Rigid Fuel Line Assy                | 151   | 84099941 | 28% |
| 1717704 | Eicher Tractor Blower Pulley(321/322 Es/Inline)    | 271   | 84099941 | 28% |
| 1717728 | Eicher Tractor Starter Motor Assy.(298/398)        | 14673 | 85114000 | 28% |
| 1717777 | Eicher Tractor O Ring 6 X 2                        | 10    | 40169320 | 18% |
| 1718022 | Eicher Tractor Valve                               | 31    | 84099941 | 28% |
| 1718034 | Eicher Tractor Spring                              | 13    | 73209090 | 18% |
| 1718046 | Eicher Tractor Hand Primer                         | 447   | 84099941 | 28% |
| 1718095 | Eicher Tractor Clamping Nut Ffp Mico P.2453345000  | 38    | 84099941 | 28% |
| 1718101 | Eicher Tractor Stud                                | 42    | 73182100 | 18% |
| 1718113 | Eicher Tractor Clip (Mico)                         | 29    | 84099941 | 28% |
| 1718125 | Eicher Tractor Sealing Ring (Mico)                 | 6     | 84099941 | 28% |
| 1718216 | Eicher Tractor Delivery Valve (Mico)               | 653   | 84099941 | 28% |
| 1718241 | Eicher Tractor Sealing Washer (Mico)               | 7     | 73182990 | 18% |
| 1718253 | Eicher Tractor Air Vent Screw                      | 44    | 73181500 | 18% |
| 1718265 | Eicher Tractor Sealing Washer                      | 12    | 73182990 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1718277 | Eicher Tractor Benjo Bolt                          | 311  | 73181500 | 18% |
| 1718289 | Eicher Tractor Main Brg Ft 0.25Mm U/S              | 1081 | 84099941 | 28% |
| 1718290 | Eicher Tractor Mbf Bush (Thick) 0.5 U/S            | 1297 | 84099941 | 28% |
| 1718307 | Eicher Tractor Mbf Bush (Thick) 0.75 U/S           | 1134 | 84099941 | 28% |
| 1718319 | Eicher Tractor Mbf Bush (Thick) 1.00 U/S           | 1206 | 84099941 | 28% |
| 1718320 | Eicher Tractor Big End Brg. (Thick)0.25 U/S        | 957  | 84821011 | 18% |
| 1718332 | Eicher Tractor Big End Brg.5Mm U/S                 | 844  | 84821011 | 18% |
| 1718344 | Eicher Tractor Big End Brg (Thick)0.75 U/S         | 1038 | 84821011 | 18% |
| 1718356 | Eicher Tractor Main Brg Middle 0.25Mm U/S          | 1018 | 84099941 | 28% |
| 1718368 | Eicher Tractor Main Brg. Needle.5                  | 1167 | 84099941 | 28% |
| 1718370 | Eicher Tractor Main Brg. Middle .75Mm              | 1195 | 84822090 | 18% |
| 1718381 | Eicher Tractor Main Brg. Middle 2Mm U/S            | 1100 | 84822090 | 18% |
| 1718459 | Eicher Tractor Overflow Valve                      | 354  | 84818090 | 18% |
| 1718503 | Eicher Tractor Big End Brg (Thick)1.0 U/S-Set      | 1074 | 84821011 | 18% |
| 1719014 | Eicher Tractor O Ring 8.3X1.78                     | 12   | 40169990 | 18% |
| 1719026 | Eicher Tractor O Ring 29.2X3                       | 23   | 40169320 | 18% |
| 1719038 | Eicher Tractor O Ring 109X4                        | 74   | 40169320 | 18% |
| 1719040 | Eicher Tractor O Ring 36.2X3                       | 19   | 40169320 | 18% |
| 1741070 | Eicher Tractor Cover For Starter Hole(F)           | 18   | 39021000 | 18% |
| 1771218 | Eicher Tractor Pedestal Front M/Cd (Stat)          | 2295 | 84099941 | 28% |
| 1771243 | Eicher Tractor Hour Cum Rpm Meter (Stat)           | 805  | 90292090 | 18% |
| 1771292 | Eicher Tractor Compression Spring (Gov)            | 82   | 73202000 | 18% |
| 1771310 | Eicher Tractor Gov Weight M/Cd (Stat)              | 429  | 84099941 | 28% |
| 1771413 | Eicher Tractor Compression Spring (Gov)            | 63   | 73202000 | 18% |
| 1771462 | Eicher Tractor Fly Wheel Cover 2000 Rpm (Stat)     | 1609 | 84099941 | 28% |
| 1771474 | Eicher Tractor Fuel Pipe Assy.                     | 262  | 40092200 | 18% |
| 1771498 | Eicher Tractor Pedestal Rear M/Cd (Stat)           | 1942 | 84099941 | 28% |
| 1771530 | Eicher Tractor Fuel Pipe Assy 421,322Es&321Es (F)  | 406  | 40092200 | 18% |
| 1771541 | Eicher Tractor Fuel Return Pipe Assy(Agro Fuel Tan | 168  | 40092200 | 18% |
| 1771589 | Eicher Tractor Support For Accl. Rod (Stat)        | 84   | 84099941 | 28% |
| 1771619 | Eicher Tractor Spl Banjo Bolt M10X1 (Stat)         | 44   | 73181500 | 18% |
| 1771620 | Eicher Tractor Fly Wheel Cover 1500 Rpm (Stat      | 1775 | 84091000 | 28% |
| 1771693 | Eicher Tractor Fuel Pipe Assy 398St(F)             | 430  | 40092200 | 18% |
| 1771760 | Eicher Tractor Alternator Bracket(421Es/422Es)     | 263  | 84099941 | 28% |
| 1771772 | Eicher Tractor Adjusting Latch 421Es/422Es/422Esg  | 116  | 84099941 | 28% |
| 1781467 | Eicher Tractor Crank Pully M/Cd W/O Keyway         | 972  | 84099941 | 28% |
| 1875047 | Eicher Tractor Spt-181=Center Pin Puller           | 2409 | 82060090 | 18% |
| 1895059 | Eicher Tractor Liner                               | 3872 | 84099941 | 28% |
| 1895230 | Eicher Tractor Rear Deflector 290                  | 877  | 84099990 | 28% |
| 1895539 | Eicher Tractor Air Inlet Hose                      | 198  | 40093100 | 18% |
| 1895758 | Eicher Tractor Blower Support Ft.                  | 2094 | 84099941 | 28% |
| 1895886 | Eicher Tractor Piston 290 Nc                       | 2105 | 84099941 | 28% |
| 1895904 | Eicher Tractor Piston 1Mm-290                      | 2455 | 84099941 | 28% |
| 1896120 | Eicher Tractor Lock Nut                            | 29   | 73181500 | 18% |
| 1896131 | Eicher Tractor Nut For P R Sleeve                  | 62   | 84099941 | 28% |
| 1896209 | Eicher Tractor Delivery Valve                      | 685  | 84099941 | 28% |
| 1896222 | Eicher Tractor F I Pipe Ft                         | 301  | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1896349 | Eicher Tractor Piston-290E                         | 3163  | 84099112 | 28% |
| 1896350 | Eicher Tractor Piston 1St Over Size                | 2105  | 84099941 | 28% |
| 1896362 | Eicher Tractor Piston 2Nd Over Size                | 2608  | 84099941 | 28% |
| 1896507 | Eicher Tractor Front Deflector-290E Assy           | 718   | 84099941 | 28% |
| 1896519 | Eicher Tractor Rear Deflector-290E Assy            | 734   | 84099941 | 28% |
| 1896520 | Eicher Tractor Intermediate Deflector-290E Assy    | 937   | 84099941 | 28% |
| 1896556 | Eicher Tractor Push Rod Assy 290                   | 399   | 84099941 | 28% |
| 1896568 | Eicher Tractor Cyl Liner                           | 3795  | 84099941 | 28% |
| 1910024 | Eicher Tractor Double Clutch Assy.- 202819100      | 29763 | 87089300 | 18% |
| 1910073 | Eicher Tractor Ber Damper                          | 50    | 40169990 | 18% |
| 1910085 | Eicher Tractor Spring                              | 26    | 73209090 | 18% |
| 1910164 | Eicher Tractor 1910164Guide Sleeve Big(Thrust Slee | 1205  | 87085000 | 18% |
| 1910190 | Eicher Tractor Bush-Guide Sleeve Small             | 956   | 87089900 | 18% |
| 1910206 | Eicher Tractor Cover-Guide Sleeve Small(Thrust Sle | 69    | 87084000 | 18% |
| 1910218 | Eicher Tractor Thrust Brg Guide                    | 1192  | 87089900 | 18% |
| 1910243 | Eicher Tractor Outer Guide                         | 453   | 87089900 | 18% |
| 1910255 | Eicher Tractor Pin                                 | 14    | 73182100 | 18% |
| 1910267 | Eicher Tractor Knob                                | 50    | 87084000 | 18% |
| 1910280 | Eicher Tractor Rubber                              | 55    | 40169320 | 18% |
| 1910360 | Eicher Tractor Disengaging Shaft Formost           | 317   | 87084000 | 18% |
| 1910401 | Eicher Tractor Hand Lever Assy                     | 411   | 87089900 | 18% |
| 1910875 | Eicher Tractor Locking Plate                       | 10    | 87084000 | 18% |
| 1910929 | Eicher Tractor Gear Box Hsg (M) 586                | 47843 | 87084000 | 18% |
| 1910978 | Eicher Tractor Sleeve                              | 268   | 87084000 | 18% |
| 1910980 | Eicher Tractor Gear Z 38                           | 4777  | 87084000 | 18% |
| 1910991 | Eicher Tractor Spacer Bush                         | 881   | 87089400 | 18% |
| 1911004 | Eicher Tractor Synchro Asyy Dia 82                 | 10285 | 87084000 | 18% |
| 1911107 | Eicher Tractor Guard                               | 84    | 87089900 | 18% |
| 1911119 | Eicher Tractor Spacer Bush                         | 1952  | 87089400 | 18% |
| 1911120 | Eicher Tractor Gear Z 59                           | 5940  | 87084000 | 18% |
| 1911132 | Eicher Tractor Synchro Assy Dia 82                 | 9252  | 87084000 | 18% |
| 1911223 | Eicher Tractor Gear Z 58                           | 9864  | 87084000 | 18% |
| 1911247 | Eicher Tractor Spacing Ring 35X44X5.05 Thk         | 121   | 87089900 | 18% |
| 1911405 | Eicher Tractor Lock Washer                         | 49    | 73182100 | 18% |
| 1911442 | Eicher Tractor Shim Thk .015                       | 4     | 73182100 | 18% |
| 1911533 | Eicher Tractor Spacing Ring35X50X2Thk              | 199   | 87089900 | 18% |
| 1911545 | Eicher Tractor Gear Z-19                           | 3584  | 87084000 | 18% |
| 1911557 | Eicher Tractor Spacer Bush                         | 768   | 87089400 | 18% |
| 1911569 | Eicher Tractor Synchro. Assy Dia 68                | 9499  | 87084000 | 18% |
| 1911636 | Eicher Tractor Gear Z-23                           | 3607  | 87084000 | 18% |
| 1911648 | Eicher Tractor Spacer Bush                         | 787   | 87089400 | 18% |
| 1911650 | Eicher Tractor Spacing Ring                        | 214   | 87089900 | 18% |
| 1911661 | Eicher Tractor Sleeve                              | 705   | 87084000 | 18% |
| 1911673 | Eicher Tractor Gear Z-29/25                        | 5143  | 87084000 | 18% |
| 1911752 | Eicher Tractor Gear Z -32                          | 3272  | 87084000 | 18% |
| 1911806 | Eicher Tractor Shim 66.8X74X0 .1Thk                | 9     | 73182100 | 18% |
| 1911831 | Eicher Tractor Locking Pin                         | 40    | 73182100 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1911879 | Eicher Tractor Adjusting Screw (M) 586       | 666   | 73181500 | 18% |
| 1911880 | Eicher Tractor Flange                        | 1382  | 87089900 | 18% |
| 1911892 | Eicher Tractor Shaft                         | 432   | 87084000 | 18% |
| 1911909 | Eicher Tractor Differential Hsg (M) 586      | 3034  | 87084000 | 18% |
| 1911934 | Eicher Tractor Side Gear(Asp)                | 6891  | 87084000 | 18% |
| 1911946 | Eicher Tractor Differential Gear Large Right | 6219  | 87084000 | 18% |
| 1911958 | Eicher Tractor Side Gear (Dsp)               | 2724  | 87084000 | 18% |
| 1911960 | Eicher Tractor Pressure Plate                | 71    | 87089900 | 18% |
| 1912010 | Eicher Tractor Clutch Sleeve                 | 7152  | 87089300 | 18% |
| 1912021 | Eicher Tractor Diff Pin.                     | 44    | 73182100 | 18% |
| 1912045 | Eicher Tractor Shaft Short                   | 253   | 87084000 | 18% |
| 1912069 | Eicher Tractor Oil Pump Assy                 | 5507  | 84133090 | 28% |
| 1912136 | Eicher Tractor Pipe                          | 146   | 87089900 | 18% |
| 1912148 | Eicher Tractor Ipe Main Shaft                | 115   | 87084000 | 18% |
| 1912150 | Eicher Tractor Suction Pipe                  | 191   | 87089900 | 18% |
| 1912252 | Eicher Tractor Oil Filter Assy [ Trans]      | 293   | 84219900 | 18% |
| 1912264 | Eicher Tractor Seat /Oil Filter Head (M) 586 | 631   | 87089900 | 18% |
| 1912276 | Eicher Tractor Pipe Pto                      | 77    | 87084000 | 18% |
| 1912288 | Eicher Tractor Dowel Pin                     | 38    | 73182100 | 18% |
| 1912318 | Eicher Tractor Gear Lever                    | 151   | 87084000 | 18% |
| 1912343 | Eicher Tractor Shield Rubber                 | 151   | 40169990 | 18% |
| 1912355 | Eicher Tractor Ball Stud                     | 185   | 87089400 | 18% |
| 1912367 | Eicher Tractor Selec Lever H-L-R (M) 586     | 648   | 87089900 | 18% |
| 1912379 | Eicher Tractor Lock Washer                   | 12    | 73182100 | 18% |
| 1912392 | Eicher Tractor Selector Rod                  | 479   | 87084000 | 18% |
| 1912410 | Eicher Tractor Slide Peice                   | 9     | 87089900 | 18% |
| 1912422 | Eicher Tractor Selector Fork 1-2 (M) 586     | 592   | 73259999 | 18% |
| 1912460 | Eicher Tractor Gear Lever 1 To 4             | 208   | 87084000 | 18% |
| 1912501 | Eicher Tractor Selector Fork L-R             | 894   | 87084000 | 18% |
| 1912550 | Eicher Tractor Gasket                        | 23    | 68129090 | 18% |
| 1912562 | Eicher Tractor Pin                           | 29    | 73182100 | 18% |
| 1912616 | Eicher Tractor Mounting Flange               | 55    | 87089900 | 18% |
| 1912628 | Eicher Tractor Shield Rubber                 | 96    | 40169990 | 18% |
| 1912630 | Eicher Tractor Joint Casing                  | 71    | 87089900 | 18% |
| 1912641 | Eicher Tractor Joint Ball                    | 17    | 87089900 | 18% |
| 1912653 | Eicher Tractor Ball Joint                    | 28    | 87089400 | 18% |
| 1912665 | Eicher Tractor Slide                         | 349   | 87089900 | 18% |
| 1912689 | Eicher Tractor Gear Lever                    | 160   | 87084000 | 18% |
| 1912719 | Eicher Tractor Drive Shaft                   | 20811 | 87084000 | 18% |
| 1912720 | Eicher Tractor Wear Ring                     | 1069  | 87089900 | 18% |
| 1912732 | Eicher Tractor Gasket (Oil Seal 130X160X20)  | 2610  | 68129090 | 18% |
| 1912744 | Eicher Tractor Axle Tube (M) 6100            | 22582 | 87084000 | 18% |
| 1912756 | Eicher Tractor Ring Gear Z-69                | 12485 | 87084000 | 18% |
| 1912781 | Eicher Tractor Sealing Washer 24*29          | 25    | 73182990 | 18% |
| 1912811 | Eicher Tractor Gear Z-26                     | 2694  | 87084000 | 18% |
| 1912835 | Eicher Tractor Planet Carrier                | 3787  | 87084000 | 18% |
| 1912884 | Eicher Tractor Drive Shaft Z 15              | 4574  | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1912902 | Eicher Tractor Spacing Plate (Intermediate Disc) | 712   | 87084000 | 18% |
| 1912914 | Eicher Tractor Friction Plate Z-27               | 1757  | 87083000 | 18% |
| 1912999 | Eicher Tractor Shield                            | 184   | 87089900 | 18% |
| 1913001 | Eicher Tractor Sealing Rubber                    | 176   | 87089900 | 18% |
| 1913013 | Eicher Tractor Gasket                            | 7     | 40169990 | 18% |
| 1913049 | Eicher Tractor Lever                             | 594   | 87089900 | 18% |
| 1913098 | Eicher Tractor Shield Cup                        | 36    | 87089900 | 18% |
| 1913130 | Eicher Tractor Gasket                            | 33    | 68129090 | 18% |
| 1913141 | Eicher Tractor Gear Z 63                         | 4776  | 87084000 | 18% |
| 1913177 | Eicher Tractor Gear Z 18                         | 2012  | 87084000 | 18% |
| 1913189 | Eicher Tractor Shaft                             | 10302 | 87084000 | 18% |
| 1913220 | Eicher Tractor Selector Fork Pto (M) 586         | 422   | 73259999 | 18% |
| 1913232 | Eicher Tractor Selector Shaft                    | 295   | 87084000 | 18% |
| 1913244 | Eicher Tractor Spring-Selector                   | 12    | 73202000 | 18% |
| 1913300 | Eicher Tractor Spring                            | 14    | 73209090 | 18% |
| 1913347 | Eicher Tractor Lever Assy(Rod +Plate Assy )      | 147   | 87084000 | 18% |
| 1913372 | Eicher Tractor Rod Assy Pto                      | 77    | 87084000 | 18% |
| 1913438 | Eicher Tractor Inner Pipe Assy                   | 1172  | 87089900 | 18% |
| 1913475 | Eicher Tractor Pin                               | 33    | 87089900 | 18% |
| 1913487 | Eicher Tractor Sleeve(Valtra)                    | 36    | 87089900 | 18% |
| 1913517 | Eicher Tractor Spring                            | 23    | 73209090 | 18% |
| 1913542 | Eicher Tractor Knob For Pto Engaging Lever       | 32    | 87084000 | 18% |
| 1913554 | Eicher Tractor Inlet Ring                        | 21    | 87089900 | 18% |
| 1913580 | Eicher Tractor Brake Kit (Right)                 | 2833  | 87083000 | 18% |
| 1913591 | Eicher Tractor Brake Kit (Left)                  | 2834  | 87083000 | 18% |
| 1914261 | Eicher Tractor Inner Drive Shaft                 | 4201  | 87084000 | 18% |
| 1914523 | Eicher Tractor Drain Plug                        | 76    | 87084000 | 18% |
| 1914789 | Eicher Tractor Rear Housing (M)                  | 4241  | 87084000 | 18% |
| 1914790 | Eicher Tractor Gear Z 63                         | 2025  | 87084000 | 18% |
| 1914807 | Eicher Tractor Gear Z 18                         | 2874  | 87084000 | 18% |
| 1914832 | Eicher Tractor Coupling Sleeve                   | 323   | 87084000 | 18% |
| 1915009 | Eicher Tractor Clutch Fork                       | 731   | 87089300 | 18% |
| 1915010 | Eicher Tractor Special Key                       | 48    | 73181500 | 18% |
| 1915149 | Eicher Tractor Axle Tube (M)                     | 10112 | 87084000 | 18% |
| 1930072 | Eicher Tractor Cylinder Assy Addc                | 1976  | 87089900 | 18% |
| 1930278 | Eicher Tractor Gasket For Cover Addc             | 32    | 68129922 | 18% |
| 1930308 | Eicher Tractor Crank                             | 1786  | 84831092 | 18% |
| 1930310 | Eicher Tractor Hydraulic Shaft                   | 5795  | 87089900 | 18% |
| 1930412 | Eicher Tractor O Ring 42X3.5                     | 27    | 40169340 | 18% |
| 1930424 | Eicher Tractor O Ring 9.2X1.8                    | 7     | 40169340 | 18% |
| 1930485 | Eicher Tractor Stud M14X1.5X70,Bp,               | 41    | 73182100 | 18% |
| 1930497 | Eicher Tractor Feed Bush Rod 12X72               | 21    | 87089400 | 18% |
| 1930552 | Eicher Tractor Power Feed Back Rod               | 58    | 87089900 | 18% |
| 1930564 | Eicher Tractor Lever Isf 20X4X102                | 28    | 87089900 | 18% |
| 1930576 | Eicher Tractor 7Ower Input Rod                   | 29    | 87084000 | 18% |
| 1930590 | Eicher Tractor Valve Input Rod                   | 31    | 87089900 | 18% |
| 1930606 | Eicher Tractor Valve Input Stud                  | 25    | 73182100 | 18% |





|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 1930618 | Eicher Tractor Spacer Tube                 | 33  | 73182100 | 18% |
| 1930620 | Eicher Tractor Spring For Linkage (1.6)    | 23  | 73209090 | 18% |
| 1930631 | Eicher Tractor Lever Isf 20X4X58           | 22  | 87089900 | 18% |
| 1930667 | Eicher Tractor Guide Support               | 32  | 87089900 | 18% |
| 1930679 | Eicher Tractor Roller                      | 36  | 84824000 | 18% |
| 1930680 | Eicher Tractor Position Input Rod          | 37  | 87089900 | 18% |
| 1930710 | Eicher Tractor 'O'Ring 11.3X2.4            | 4   | 84099941 | 28% |
| 1930722 | Eicher Tractor O Ring 18.8X1.8(Drain Plug) | 19  | 40169320 | 18% |
| 1930795 | Eicher Tractor Shield                      | 231 | 87089900 | 18% |
| 1930801 | Eicher Tractor Metal Washer 25X6.1X0.5     | 11  | 73182100 | 18% |
| 1930813 | Eicher Tractor Friction Washer 25X6.1X2.0  | 9   | 87083000 | 18% |
| 1930825 | Eicher Tractor Spring For Control Lever    | 8   | 73202000 | 18% |
| 1930874 | Eicher Tractor O Ring 25X3.5               | 29  | 40169320 | 18% |
| 1931258 | Eicher Tractor O Ring 12.4X2.6             | 12  | 40169340 | 18% |
| 1931260 | Eicher Tractor O Ring 14X18                | 10  | 40169340 | 18% |
| 1931271 | Eicher Tractor O Ring 56.8X2.6             | 28  | 40169340 | 18% |
| 1931600 | Eicher Tractor Rubber Ring                 | 13  | 40169990 | 18% |
| 1931647 | Eicher Tractor Gasket For Top Cover Rear   | 37  | 68129922 | 18% |
| 1931775 | Eicher Tractor Breather Cum Dipstick Assy  | 141 | 87084000 | 18% |
| 1931866 | Eicher Tractor Nut For Delivery Pipe       | 77  | 73181500 | 18% |
| 1931878 | Eicher Tractor Ferrule Small               | 20  | 87089900 | 18% |
| 1931969 | Eicher Tractor Delivery Elbow              | 459 | 87089900 | 18% |
| 1932548 | Eicher Tractor Hanger Plate                | 19  | 87089900 | 18% |
| 1932706 | Eicher Tractor Back Up Ring Big            | 10  | 39269099 | 18% |
| 1932731 | Eicher Tractor O Ring 49X53                | 61  | 40169320 | 18% |
| 1932743 | Eicher Tractor O Ring 44X5.5               | 71  | 40169320 | 18% |
| 1932755 | Eicher Tractor End Cover Rt                | 205 | 87084000 | 18% |
| 1932767 | Eicher Tractor End Cover Lt                | 202 | 87084000 | 18% |
| 1932780 | Eicher Tractor Back Up Ring Small          | 10  | 39269099 | 18% |
| 1933085 | Eicher Tractor Oring 15.3X2.4              | 11  | 40169990 | 18% |
| 1933103 | Eicher Tractor Back Up Ring 20X1X1.8 Mm    | 4   | 87089900 | 18% |
| 1933176 | Eicher Tractor Stud M16X24/79,A8.8,Bp,     | 59  | 73182100 | 18% |
| 1933243 | Eicher Tractor Strainer                    | 135 | 84219900 | 18% |
| 1933255 | Eicher Tractor Gasket For Mtg Plate        | 9   | 87089900 | 18% |
| 1933279 | Eicher Tractor Rubber Washer               | 10  | 40169320 | 18% |
| 1933309 | Eicher Tractor O Ring 62.5X3               | 12  | 40169340 | 18% |
| 1933360 | Eicher Tractor Valve Lifter                | 180 | 87089900 | 18% |
| 1933371 | Eicher Tractor Washer                      | 12  | 73182100 | 18% |
| 1933383 | Eicher Tractor Spg. For Spool              | 8   | 73182100 | 18% |
| 1933395 | Eicher Tractor Retainer                    | 72  | 87089900 | 18% |
| 1933413 | Eicher Tractor Plug M14X1.5                | 66  | 84099941 | 28% |
| 1933425 | Eicher Tractor Spacer Guide                | 29  | 73182100 | 18% |
| 1933462 | Eicher Tractor Spg. For Cyl.Release        | 7   | 87089900 | 18% |
| 1933474 | Eicher Tractor Valve Retainer              | 69  | 87089900 | 18% |
| 1933504 | Eicher Tractor Valve Assy.                 | 645 | 84099941 | 28% |
| 1933516 | Eicher Tractor Seat Retainer               | 66  | 87089900 | 18% |
| 1933530 | Eicher Tractor Spring For Check Valve      | 5   | 73209090 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1933553 | Eicher Tractor Plug M6X1                           | 20   | 87084000 | 18% |
| 1933607 | Eicher Tractor Clamp                               | 23   | 87089900 | 18% |
| 1933620 | Eicher Tractor O Ring 5.1X1.6                      | 12   | 40169340 | 18% |
| 1933632 | Eicher Tractor O Ring 69.5X3                       | 20   | 40169340 | 18% |
| 1933644 | Eicher Tractor O Ring 10.1X1.6                     | 13   | 40169340 | 18% |
| 1933670 | Eicher Tractor Spg. For Diff. Valve                | 10   | 87089900 | 18% |
| 1933760 | Eicher Tractor Clamp For 24 Hp                     | 127  | 87089900 | 18% |
| 1933802 | Eicher Tractor Hose Pipe                           | 123  | 40093100 | 18% |
| 1933991 | Eicher Tractor Spring Link Assy.                   | 23   | 73209090 | 18% |
| 1934480 | Eicher Tractor U Cup Seal                          | 442  | 40169990 | 18% |
| 1934491 | Eicher Tractor Stud 14X28/46,B8.8,Bp,              | 27   | 73182100 | 18% |
| 1934545 | Eicher Tractor Magnet Cum Banjo Bolt M18X1.5,      | 76   | 73181500 | 18% |
| 1934582 | Eicher Tractor Bush                                | 10   | 87089900 | 18% |
| 1934594 | Eicher Tractor Spring Plate                        | 1148 | 87089900 | 18% |
| 1934740 | Eicher Tractor Cylinder Release Valve Assy         | 458  | 87089900 | 18% |
| 1934741 | Eicher Tractor Cylinder Release Valve Assy W/Rings | 492  | 87089900 | 18% |
| 1934776 | Eicher Tractor Valve                               | 223  | 84099941 | 28% |
| 1934788 | Eicher Tractor Shim                                | 7    | 73182100 | 18% |
| 1934790 | Eicher Tractor Special Nut                         | 14   | 73181500 | 18% |
| 1934806 | Eicher Tractor Lever                               | 37   | 87089900 | 18% |
| 1934909 | Eicher Tractor Spring Safety Valve                 | 14   | 87089900 | 18% |
| 1934934 | Eicher Tractor Guide Tube                          | 26   | 73182100 | 18% |
| 1934946 | Eicher Tractor Plug M12X1.5                        | 35   | 87084000 | 18% |
| 1934995 | Eicher Tractor Drain Pipe                          | 187  | 87089900 | 18% |
| 1935021 | Eicher Tractor Special Screw                       | 57   | 73181500 | 18% |
| 1935094 | Eicher Tractor Mode Selector Valve                 | 221  | 87089900 | 18% |
| 1935136 | Eicher Tractor Lever                               | 23   | 87089900 | 18% |
| 1935161 | Eicher Tractor Special Bolt                        | 96   | 73181500 | 18% |
| 1935495 | Eicher Tractor Special Bolt                        | 89   | 73181500 | 18% |
| 1935501 | Eicher Tractor Special Bolt                        | 51   | 73181500 | 18% |
| 1935586 | Eicher Tractor O Ring 5.6X2.25                     | 11   | 40169340 | 18% |
| 1935598 | Eicher Tractor Back Up Ring 10X1X1.15 Mm           | 11   | 40169990 | 18% |
| 1935604 | Eicher Tractor Back Up Ring 12.4X16X1 Pffe         | 31   | 39269099 | 18% |
| 1935616 | Eicher Tractor Back Up Ring 18X1X1.8 Mm            | 15   | 40169990 | 18% |
| 1935630 | Eicher Tractor Cap Nut M22X1                       | 171  | 73181500 | 18% |
| 1935653 | Eicher Tractor Back Up Ring 10X1X2.0 Mm            | 12   | 40169990 | 18% |
| 1935859 | Eicher Tractor Bush(485)                           | 25   | 87089900 | 18% |
| 1936438 | Eicher Tractor Idler Pulley                        | 289  | 84099941 | 28% |
| 1936682 | Eicher Tractor Clamp For -352                      | 84   | 87089900 | 18% |
| 1936724 | Eicher Tractor Difference Valve Assy.              | 384  | 87084000 | 18% |
| 1937065 | Eicher Tractor Pin For Idler Pulley                | 66   | 73182100 | 18% |
| 1937110 | Eicher Tractor Cover For Addc                      | 1220 | 87089900 | 18% |
| 1937133 | Eicher Tractor Plug                                | 23   | 87084000 | 18% |
| 1937182 | Eicher Tractor Connecting Pipe Assy                | 131  | 87089900 | 18% |
| 1937248 | Eicher Tractor Gear For Hydraulic Pump             | 885  | 84133090 | 28% |
| 1937420 | Eicher Tractor Felt Ring 42X30X5                   | 10   | 59119090 | 12% |
| 1937431 | Eicher Tractor Copper Asbestos Washer              | 13   | 74091100 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1937467 | Eicher Tractor Plain Washer 25X8.4X3,Zp,           | 12   | 73182100 | 18% |
| 1937558 | Eicher Tractor Hyd Gear Pump Oil Seal              | 69   | 87089900 | 18% |
| 1937560 | Eicher Tractor Bracket                             | 283  | 87089900 | 18% |
| 1937601 | Eicher Tractor Intermediate Plate                  | 220  | 87089900 | 18% |
| 1937613 | Eicher Tractor Difference Valve Assy               | 341  | 87084000 | 18% |
| 1937625 | Eicher Tractor Wire Lock                           | 14   | 73202000 | 18% |
| 1937686 | Eicher Tractor Gasket For Int. Hsg. Of Big Addc    | 53   | 68129090 | 18% |
| 1937741 | Eicher Tractor T.T. Supply Hose                    | 443  | 40093100 | 18% |
| 1937832 | Eicher Tractor Spt-179=Mandrel Oil Seal Fitment-Ge | 559  | 82060090 | 18% |
| 1938060 | Eicher Tractor Extension Shaft                     | 396  | 87089900 | 18% |
| 1938071 | Eicher Tractor Locating Spacer                     | 107  | 87084000 | 18% |
| 1938459 | Eicher Tractor Bush                                | 24   | 87089900 | 18% |
| 1938514 | Eicher Tractor Retainer                            | 151  | 87084000 | 18% |
| 1938526 | Eicher Tractor Valve Assy                          | 504  | 84099941 | 28% |
| 1938654 | Eicher Tractor Strainer Assy                       | 343  | 84219900 | 18% |
| 1938680 | Eicher Tractor Spring Retainer                     | 118  | 73202000 | 18% |
| 1938691 | Eicher Tractor Spring (Safty Valve)                | 48   | 73209090 | 18% |
| 1938745 | Eicher Tractor Plug                                | 79   | 87084000 | 18% |
| 1938757 | Eicher Tractor Spring Compression                  | 14   | 73209090 | 18% |
| 1938794 | Eicher Tractor Gasket Hsg.                         | 34   | 68129090 | 18% |
| 1938800 | Eicher Tractor Gasket Cover                        | 22   | 40169990 | 18% |
| 1938812 | Eicher Tractor Screen                              | 69   | 84219900 | 18% |
| 1938827 | Eicher Tractor Cover For Power Lift Hsg.           | 1147 | 87089900 | 18% |
| 1938942 | Eicher Tractor Spacer Tube                         | 28   | 73182100 | 18% |
| 1939049 | Eicher Tractor O Rings And B/Up Rings(Kit)         | 333  | 40169320 | 18% |
| 1939221 | Eicher Tractor Spring (Spool)                      | 11   | 73209090 | 18% |
| 1939245 | Eicher Tractor Spacer                              | 24   | 73182100 | 18% |
| 1939294 | Eicher Tractor Washer                              | 16   | 73182100 | 18% |
| 1939373 | Eicher Tractor Piston                              | 782  | 87089900 | 18% |
| 1939415 | Eicher Tractor Flow Control Valve Assy.            | 706  | 87089900 | 18% |
| 1939555 | Eicher Tractor Clamping Plate                      | 183  | 87089900 | 18% |
| 1939592 | Eicher Tractor Slide Ring 80 Dia                   | 140  | 39269099 | 18% |
| 1939610 | Eicher Tractor Drain Pipe                          | 170  | 87089900 | 18% |
| 1939622 | Eicher Tractor Drain Plug                          | 29   | 87084000 | 18% |
| 1939634 | Eicher Tractor Adopter For Tt                      | 145  | 87089900 | 18% |
| 1939707 | Eicher Tractor Piston                              | 810  | 84099112 | 28% |
| 1939866 | Eicher Tractor Slide Ring 90 Dia                   | 186  | 39269099 | 18% |
| 1939907 | Eicher Tractor Kit For Dowty Pump                  | 894  | 84139190 | 28% |
| 1960957 | Eicher Tractor Washer Lock                         | 15   | 73182100 | 18% |
| 1961135 | Eicher Tractor Axle Tube Lt. (M)(485)              | 4308 | 87084000 | 18% |
| 1961172 | Eicher Tractor Brake Housing Rt.                   | 813  | 87083000 | 18% |
| 1961240 | Eicher Tractor Reverse Gear Assy (M)(48            | 1370 | 87084000 | 18% |
| 1961263 | Eicher Tractor Spur Pinion 1St- (485)              | 1043 | 87084000 | 18% |
| 1961275 | Eicher Tractor Spur Pinion 2Nd (485)               | 999  | 87084000 | 18% |
| 1961299 | Eicher Tractor Spacer For Lay Shaft-1(4            | 114  | 73182100 | 18% |
| 1961305 | Eicher Tractor Spacer For Lay Shaft 2(485)         | 154  | 73182100 | 18% |
| 1961329 | Eicher Tractor Sld Gear 1 & 2(485)                 | 3312 | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1961330 | Eicher Tractor Sliding Pinion 3&4(485)             | 2156  | 87084000 | 18% |
| 1961469 | Eicher Tractor Mudshield For Axle Tube             | 242   | 87085000 | 18% |
| 1961585 | Eicher Tractor Cover Left 485                      | 2834  | 87084000 | 18% |
| 1961627 | Eicher Tractor Dowel Pin                           | 29    | 73182100 | 18% |
| 1961676 | Eicher Tractor Spacer For Pto                      | 60    | 73182100 | 18% |
| 1961688 | Eicher Tractor Gasket For Pto Housing & G2 Couplin | 41    | 68129090 | 18% |
| 1961718 | Eicher Tractor Pto Reduction Hsg Machined          | 4783  | 73259999 | 18% |
| 1961720 | Eicher Tractor Flywheel Hsg 485 Dlx M/C            | 24903 | 73259999 | 18% |
| 1961767 | Eicher Tractor Pto Drive Shaft - Dc (Teeth-15)     | 3220  | 87084000 | 18% |
| 1961779 | Eicher Tractor Pto C M Gear -485 Dlx (Teeth-54)    | 2914  | 87084000 | 18% |
| 1961810 | Eicher Tractor Spacer-2                            | 199   | 73182100 | 18% |
| 1961822 | Eicher Tractor Spacer-1                            | 127   | 73182100 | 18% |
| 1961834 | Eicher Tractor End Cover                           | 296   | 87084000 | 18% |
| 1961846 | Eicher Tractor Gasket For End Cover Of Fwh         | 14    | 40169990 | 18% |
| 1961871 | Eicher Tractor Stud M14X38/66,P10.9,Bp             | 40    | 73182100 | 18% |
| 1962085 | Eicher Tractor Assly.Lever For Pto 369             | 258   | 87084000 | 18% |
| 1962437 | Eicher Tractor Gear Housing Front                  | 14256 | 87084000 | 18% |
| 1962449 | Eicher Tractor Cover Right & Left - 02             | 1281  | 87084000 | 18% |
| 1962486 | Eicher Tractor Pressure Spring                     | 10    | 73202000 | 18% |
| 1962504 | Eicher Tractor Shifter Fork 1/2                    | 773   | 87084000 | 18% |
| 1962528 | Eicher Tractor Gear Hsg Front                      | 20920 | 87084000 | 18% |
| 1963119 | Eicher Tractor Guide Sleeve                        | 838   | 87084000 | 18% |
| 1963144 | Eicher Tractor Gasket For Guide Sleeve Of Fwh      | 15    | 40169990 | 18% |
| 1963211 | Eicher Tractor Gasket For Axle Tube & G2 Hsg       | 82    | 68129090 | 18% |
| 1963351 | Eicher Tractor Ball Cup                            | 177   | 87089400 | 18% |
| 1963442 | Eicher Tractor Rear Housing (M) 586                | 11352 | 87084000 | 18% |
| 1963867 | Eicher Tractor Guide Bush For Pto                  | 920   | 87084000 | 18% |
| 1963879 | Eicher Tractor Aging Handle                        | 454   | 87084000 | 18% |
| 1964008 | Eicher Tractor Window Cover                        | 267   | 87084000 | 18% |
| 1964010 | Eicher Tractor Gasket For Window Cover Of Fwh      | 19    | 40169990 | 18% |
| 1964045 | Eicher Tractor Shifter Fork R.G                    | 494   | 87084000 | 18% |
| 1964100 | Eicher Tractor Shifting Rod Rg                     | 262   | 87084000 | 18% |
| 1964112 | Eicher Tractor Spacer For Int Shaft 1              | 44    | 73182100 | 18% |
| 1964124 | Eicher Tractor Spacer For Int Shaft 2              | 44    | 73182100 | 18% |
| 1964136 | Eicher Tractor Spacer For C.P. Shaft 1             | 47    | 73182100 | 18% |
| 1964148 | Eicher Tractor Spacer For C.P. Shaft 2             | 45    | 73182100 | 18% |
| 1964150 | Eicher Tractor Spacer For Lay Shaft                | 200   | 73182100 | 18% |
| 1964161 | Eicher Tractor Spacer For Lay Shaft 2              | 75    | 73182100 | 18% |
| 1964288 | Eicher Tractor Cover Left                          | 1756  | 87084000 | 18% |
| 1964318 | Eicher Tractor Shifting Rod Hi/Lo                  | 183   | 87084000 | 18% |
| 1964367 | Eicher Tractor Plate For Pto                       | 167   | 87084000 | 18% |
| 1964525 | Eicher Tractor Gasket For G1/Fw Hsg Joint          | 67    | 40169990 | 18% |
| 1964537 | Eicher Tractor Oil Dipstic                         | 137   | 87084000 | 18% |
| 1964549 | Eicher Tractor Gasket For G1 Top Cover Front       | 62    | 68129922 | 18% |
| 1964574 | Eicher Tractor Tension Spring                      | 13    | 73202000 | 18% |
| 1964641 | Eicher Tractor Hub                                 | 559   | 87085000 | 18% |
| 1964653 | Eicher Tractor Guide Sleeve                        | 861   | 87084000 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1964699 | Eicher Tractor Axle Tube Machined                  | 6819 | 87084000 | 18% |
| 1964720 | Eicher Tractor Spring Dowel Sleeve 16X32           | 52   | 73182100 | 18% |
| 1964732 | Eicher Tractor Spring Dowel Sleeve 11X32           | 18   | 73182100 | 18% |
| 1964934 | Eicher Tractor Ascending Disc                      | 36   | 87084000 | 18% |
| 1964940 | Eicher Tractor Rubber Washer                       | 10   | 40169320 | 18% |
| 1964951 | Eicher Tractor Rear Shaft                          | 6744 | 87084000 | 18% |
| 1964963 | Eicher Tractor Differential Housing M/C            | 4240 | 87084000 | 18% |
| 1965049 | Eicher Tractor Shim For Alternator                 | 9    | 73182100 | 18% |
| 1965050 | Eicher Tractor Steel Shim                          | 9    | 73182100 | 18% |
| 1965062 | Eicher Tractor Steel Shim                          | 7    | 73182100 | 18% |
| 1965098 | Eicher Tractor Lock Plate                          | 12   | 87084000 | 18% |
| 1965165 | Eicher Tractor Bracket For Lever Assy              | 27   | 87089900 | 18% |
| 1965220 | Eicher Tractor Support Hub                         | 1230 | 87084000 | 18% |
| 1965256 | Eicher Tractor Gasket For Axle Tube - Export       | 44   | 68129090 | 18% |
| 1965268 | Eicher Tractor H.Skt Set Screw M12X20/21 Kcp,B12.9 | 23   | 73181500 | 18% |
| 1965281 | Eicher Tractor Oil Seal 35X25X7                    | 50   | 40169330 | 18% |
| 1965311 | Eicher Tractor Knob                                | 147  | 87084000 | 18% |
| 1965323 | Eicher Tractor Knob                                | 147  | 87084000 | 18% |
| 1965336 | Eicher Tractor Hub                                 | 466  | 87085000 | 18% |
| 1965347 | Eicher Tractor Tension Spring                      | 11   | 73202000 | 18% |
| 1965360 | Eicher Tractor Sleeve                              | 598  | 87084000 | 18% |
| 1965372 | Eicher Tractor Intermediate Ring                   | 15   | 87089900 | 18% |
| 1965403 | Eicher Tractor Gear Shift Lever Assy 485           | 352  | 87084000 | 18% |
| 1965608 | Eicher Tractor Lever Hsg                           | 899  | 87084000 | 18% |
| 1965645 | Eicher Tractor Gasket For Lever Hsg.               | 13   | 40169990 | 18% |
| 1965670 | Eicher Tractor Plug Assy. -485                     | 80   | 87084000 | 18% |
| 1965724 | Eicher Tractor Sealing Washer (485 Drain Plug)     | 13   | 73182990 | 18% |
| 1965736 | Eicher Tractor Sealing Washer(For 485-Dipstick)    | 14   | 73182990 | 18% |
| 1965750 | Eicher Tractor Drain Plug                          | 74   | 87084000 | 18% |
| 1965761 | Eicher Tractor Drain Plug Assy                     | 81   | 87084000 | 18% |
| 1965918 | Eicher Tractor Dipstick                            | 124  | 87084000 | 18% |
| 1965920 | Eicher Tractor Dipstick G1 (485)                   | 101  | 87084000 | 18% |
| 1965931 | Eicher Tractor Axial Diff. Star Pinion             | 1527 | 87084000 | 18% |
| 1965943 | Eicher Tractor Diff. Star Pinion                   | 526  | 87084000 | 18% |
| 1965955 | Eicher Tractor Axial Star Pinion                   | 1225 | 87084000 | 18% |
| 1965979 | Eicher Tractor Ascending Disc .10Thk               | 14   | 87084000 | 18% |
| 1965980 | Eicher Tractor Ascending Disc .20Thk               | 17   | 87084000 | 18% |
| 1966110 | Eicher Tractor C M Gear H/L 485DI (Teeth-45)       | 2087 | 87084000 | 18% |
| 1966121 | Eicher Tractor Spur Pinion Hi-Lo- 485 Dlx (Teeth-2 | 1408 | 87084000 | 18% |
| 1966169 | Eicher Tractor Lay Shaft-1 - 485 Dlx Spline-21     | 2058 | 87084000 | 18% |
| 1966170 | Eicher Tractor Lay Shaft-2 - 485 Dlx Spline-21     | 1765 | 87084000 | 18% |
| 1966212 | Eicher Tractor Diff Shaft (Dia 22)                 | 783  | 87084000 | 18% |
| 1966250 | Eicher Tractor Thrust Washer                       | 81   | 73182100 | 18% |
| 1966273 | Eicher Tractor Axle Tube Lt. (M)(485)              | 2390 | 87084000 | 18% |
| 1966479 | Eicher Tractor Shim For Lay Shaft-2(.1)            | 11   | 73182100 | 18% |
| 1966480 | Eicher Tractor Shim For Lay Shaft-2 (.25)          | 12   | 73182100 | 18% |
| 1966492 | Eicher Tractor Shim For Lay Shaft-2(.5)            | 10   | 73182100 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1966509 | Eicher Tractor Shim For Lay Shaft-2(1.0)           | 16    | 73182100 | 18% |
| 1966560 | Eicher Tractor Shim 0.5                            | 4     | 73182100 | 18% |
| 1966730 | Eicher Tractor H.Socket Set Screw M8X35,B10.9,Bp,  | 49    | 73181500 | 18% |
| 1966789 | Eicher Tractor Lever For Pto                       | 116   | 87084000 | 18% |
| 1967241 | Eicher Tractor Spring For Pto                      | 9     | 73209090 | 18% |
| 1967253 | Eicher Tractor Adjusting Screw                     | 31    | 73181500 | 18% |
| 1967307 | Eicher Tractor Pin For Guide Bush                  | 31    | 73182100 | 18% |
| 1967370 | Eicher Tractor Pto Shaft -540 (Wdb)                | 2677  | 87084000 | 18% |
| 1967393 | Eicher Tractor Gasket For G1 & G2 Joint            | 63    | 68129090 | 18% |
| 1967629 | Eicher Tractor Guide Bush For Pto                  | 927   | 87084000 | 18% |
| 1967630 | Eicher Tractor Engaging Handle                     | 622   | 87084000 | 18% |
| 1967769 | Eicher Tractor COVer Upper                         | 46    | 87089900 | 18% |
| 1967885 | Eicher Tractor Oil Seal 62X45X10                   | 110   | 40169990 | 18% |
| 1967939 | Eicher Tractor Oil Seal Housing                    | 234   | 73259999 | 18% |
| 1967952 | Eicher Tractor Oil Dipstick                        | 105   | 87084000 | 18% |
| 1967976 | Eicher Tractor Rubber Cover                        | 90    | 40169320 | 18% |
| 1968014 | Eicher Tractor Dual Clutch Assy - Luk-202819501    | 25384 | 87089300 | 18% |
| 1968026 | Eicher Tractor Diff O/H Kit(1965955-1965943-936259 | 3034  | 87085000 | 18% |
| 1968117 | Eicher Tractor Locking Screw M8X20                 | 25    | 73181500 | 18% |
| 1968221 | Eicher Tractor Knob-Gs Lever                       | 138   | 87089900 | 18% |
| 1968300 | Eicher Tractor Spring For Pto                      | 12    | 73202000 | 18% |
| 1968348 | Eicher Tractor Crown+ Pinion Kit -242 (1011406+151 | 11281 | 87084000 | 18% |
| 1968403 | Eicher Tractor Crimping Nut                        | 140   | 73181500 | 18% |
| 1968506 | Eicher Tractor Cover G1 Top                        | 1543  | 87084000 | 18% |
| 1968555 | Eicher Tractor Special Nut M18X15                  | 25    | 73181500 | 18% |
| 1968683 | Eicher Tractor Gasket For Brake Hsg                | 90    | 68129090 | 18% |
| 1968750 | Eicher Tractor Clutch Release Bearing Ct 1310      | 1230  | 84822090 | 18% |
| 1968889 | Eicher Tractor Dowel Pin 14X38                     | 36    | 73182100 | 18% |
| 1968890 | Eicher Tractor Slide Sleeve Dual Clutch            | 361   | 87089300 | 18% |
| 1968919 | Eicher Tractor Disc Lock - 368                     | 948   | 87084000 | 18% |
| 1968944 | Eicher Tractor Retaining Pin                       | 11    | 73182100 | 18% |
| 1969110 | Eicher Tractor Shifter Rod Hi - Low                | 404   | 87084000 | 18% |
| 1969122 | Eicher Tractor Shifter Fork Hi-Low                 | 757   | 87084000 | 18% |
| 1969146 | Eicher Tractor Intermediate Lever For Hi/Low       | 382   | 87089900 | 18% |
| 1970160 | Eicher Tractor Distance Ring                       | 142   | 84099941 | 28% |
| 1970171 | Eicher Tractor Adj. Shim                           | 4     | 73182100 | 18% |
| 1970201 | Eicher Tractor Adjusting Shim 0.5 Mm               | 5     | 73182100 | 18% |
| 1970239 | Eicher Tractor Oil Seal Hsg                        | 164   | 40169330 | 18% |
| 1970252 | Eicher Tractor Special Washer                      | 9     | 73182990 | 18% |
| 1970264 | Eicher Tractor Rubber Boot                         | 19    | 40169320 | 18% |
| 1970276 | Eicher Tractor Balance Weight 298                  | 881   | 84099941 | 28% |
| 1970290 | Eicher Tractor Inspection Cover Rear Assy          | 613   | 84099941 | 28% |
| 1970306 | Eicher Tractor Oil Seal 60X75X8                    | 270   | 40169330 | 18% |
| 1970307 | Eicher Tractor Oil Seal 60X75X8 (Imported)         | 585   | 84099941 | 28% |
| 1970320 | Eicher Tractor Crank Gear                          | 1307  | 87084000 | 18% |
| 1970331 | Eicher Tractor Rubber Beading                      | 46    | 40169320 | 18% |
| 1970343 | Eicher Tractor Rubber Bead 87 Mm                   | 37    | 40169320 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 1970367 | Eicher Tractor Gasket For Cover                     | 8    | 68129922 | 18% |
| 1970379 | Eicher Tractor Stud 8X32                            | 14   | 73182100 | 18% |
| 1970392 | Eicher Tractor Special Ring                         | 40   | 84099941 | 28% |
| 1970410 | Eicher Tractor Gasket Inspection Cover Front        | 39   | 68129922 | 18% |
| 1970422 | Eicher Tractor Inspection Cover Front               | 554  | 84099941 | 28% |
| 1970483 | Eicher Tractor Piston Ring Set                      | 439  | 84099913 | 28% |
| 1970513 | Eicher Tractor Piston 298 Edl                       | 2834 | 84099912 | 28% |
| 1970525 | Eicher Tractor Oil Ring                             | 329  | 84099941 | 28% |
| 1970549 | Eicher Tractor Piston 0.5Mm-298                     | 2329 | 84099941 | 28% |
| 1970550 | Eicher Tractor Piston 1Mm-298                       | 2105 | 84099941 | 28% |
| 1970665 | Eicher Tractor Gkt For Silencer Mtg.(222Esg/422/32  | 72   | 84841010 | 18% |
| 1970768 | Eicher Tractor Flexible Inn.Shaft For 312 S. Cable  | 39   | 87084000 | 18% |
| 1970847 | Eicher Tractor Piston Ring Set 0.5Mm-298            | 452  | 84099913 | 28% |
| 1970859 | Eicher Tractor Piston Ring Set 1Mm-298              | 431  | 84099913 | 28% |
| 1970902 | Eicher Tractor Washer For Cyl Head C-80             | 29   | 73182100 | 18% |
| 1970926 | Eicher Tractor Spl. Nut M12                         | 47   | 73181500 | 18% |
| 1970938 | Eicher Tractor Min Speed Cam-298                    | 105  | 84129090 | 18% |
| 1970940 | Eicher Tractor Max Speed Cam-298                    | 116  | 84129090 | 18% |
| 1970987 | Eicher Tractor Dipstick Assly.(321/322 Es)          | 59   | 84099941 | 28% |
| 1970999 | Eicher Tractor Acc Spring(For Gov. Cover 298 Model) | 9    | 73202000 | 18% |
| 1971050 | Eicher Tractor Bearing Cover M/Cd                   | 576  | 84099941 | 28% |
| 1971062 | Eicher Tractor Fuel Stop Rod                        | 155  | 84099941 | 28% |
| 1971098 | Eicher Tractor Spring Compression                   | 39   | 73209090 | 18% |
| 1971116 | Eicher Tractor Cam Gear M/Cd                        | 3046 | 87084000 | 18% |
| 1971220 | Eicher Tractor Gasket P Base                        | 41   | 68129922 | 18% |
| 1971256 | Eicher Tractor A/C Bracket. 421 Es,422Es,321&322 Es | 538  | 84091000 | 28% |
| 1971268 | Eicher Tractor Teflon Washer 18X11X3                | 30   | 39172990 | 18% |
| 1971270 | Eicher Tractor Teflon Washer 37X31X3                | 80   | 39172990 | 18% |
| 1971311 | Eicher Tractor Wire Mesh Assly.                     | 75   | 84099941 | 28% |
| 1971414 | Eicher Tractor Spl Washer For F S Rod               | 6    | 73182990 | 18% |
| 1971426 | Eicher Tractor O Ring 3.3X2.5                       | 2    | 40169320 | 18% |
| 1971438 | Eicher Tractor Head For Fuel St. Rod                | 28   | 84099941 | 28% |
| 1971451 | Eicher Tractor Fuel Inj Pipe Assy Ft                | 320  | 84099990 | 28% |
| 1971463 | Eicher Tractor Fuel Inj Pipe Assy Rear              | 300  | 84099990 | 28% |
| 1971505 | Eicher Tractor Gasket For Liner (White)             | 153  | 84099941 | 28% |
| 1971517 | Eicher Tractor Gasket For Liner-Black               | 129  | 84099941 | 28% |
| 1971529 | Eicher Tractor Gasket For Liner-Red                 | 210  | 84099941 | 28% |
| 1971530 | Eicher Tractor Gasket For Liner-Green               | 214  | 84099941 | 28% |
| 1971554 | Eicher Tractor Flange Type Bolt M10*180             | 127  | 73181500 | 18% |
| 1971578 | Eicher Tractor Dynamo Pulley                        | 179  | 84099941 | 28% |
| 1971580 | Eicher Tractor Adjusting Latch                      | 102  | 84099941 | 28% |
| 1971645 | Eicher Tractor Gasket Exh. Manifold                 | 61   | 84099941 | 28% |
| 1971669 | Eicher Tractor Pin For Gov Weight                   | 38   | 84129090 | 18% |
| 1971712 | Eicher Tractor Spl. Nut Big                         | 54   | 73181500 | 18% |
| 1971724 | Eicher Tractor Oil Gallery Plug 298/115             | 29   | 84099941 | 28% |
| 1971736 | Eicher Tractor Cyl. Clamping Rod M12*332            | 235  | 84129090 | 18% |
| 1971955 | Eicher Tractor Main Brg Middle (Upper)              | 156  | 84821020 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1971967 | Eicher Tractor Main Brg Middle (Lower)             | 156   | 84821020 | 18% |
| 1971979 | Eicher Tractor Thin Wall Big End Brg.              | 121   | 84822090 | 18% |
| 1972029 | Eicher Tractor Ring Nut M/Cd                       | 245   | 84091000 | 28% |
| 1972030 | Eicher Tractor Gasket For Cyl.Head Cover           | 79    | 68129922 | 18% |
| 1972042 | Eicher Tractor Cap For Adj. Cam                    | 5     | 84831092 | 18% |
| 1972066 | Eicher Tractor Pipe Union Bolt-10 (M 14*1.5)       | 19    | 73181500 | 18% |
| 1972091 | Eicher Tractor Intermediate Brg.Hsg. M/C           | 2526  | 84822090 | 18% |
| 1972121 | Eicher Tractor Spl Bolt                            | 159   | 73181500 | 18% |
| 1972133 | Eicher Tractor Spl. Washer                         | 96    | 73182990 | 18% |
| 1972169 | Eicher Tractor Hour Cum Rpm Meter                  | 776   | 90292090 | 18% |
| 1972273 | Eicher Tractor Intake Tube (245Mm)                 | 134   | 84099941 | 28% |
| 1972340 | Eicher Tractor Exhaust ManifOld                    | 1225  | 84099941 | 28% |
| 1972352 | Eicher Tractor Stud 8X36                           | 19    | 73182100 | 18% |
| 1972364 | Eicher Tractor Gasket For Exhaust Manifold         | 53    | 84841090 | 18% |
| 1972376 | Eicher Tractor Gasket For Extension Manifold       | 116   | 84841010 | 18% |
| 1972443 | Eicher Tractor Adjusting Latch                     | 151   | 87085000 | 18% |
| 1972455 | Eicher Tractor Adj. Screw                          | 40    | 84129090 | 18% |
| 1972467 | Eicher Tractor Fuel Pipe Assy                      | 153   | 84099941 | 28% |
| 1972546 | Eicher Tractor Extension-298                       | 828   | 84099941 | 28% |
| 1972583 | Eicher Tractor Crank Hsg M/Cd. (E)                 | 44337 | 84099941 | 28% |
| 1972601 | Eicher Tractor Gasket Pump Base (R)                | 22    | 68129922 | 18% |
| 1972650 | Eicher Tractor Oil Gallery Tube Assly              | 126   | 40092200 | 18% |
| 1972704 | Eicher Tractor Cyl. Head Sub Assy                  | 6822  | 76169990 | 18% |
| 1972730 | Eicher Tractor Valve Exhaust                       | 272   | 84099941 | 28% |
| 1972741 | Eicher Tractor Valve Seat Inlet (E-Multi)          | 199   | 84099941 | 28% |
| 1972753 | Eicher Tractor Valve Seat Exhaust (E-Multi)        | 189   | 84099941 | 28% |
| 1972765 | Eicher Tractor Valve Guide (E-Multi)               | 72    | 84099111 | 28% |
| 1972777 | Eicher Tractor Cyl Head Cover M/Cd                 | 262   | 84099941 | 28% |
| 1972789 | Eicher Tractor Gasket For Cy Head Cover(Multi)     | 51    | 68129922 | 18% |
| 1972790 | Eicher Tractor Injector Clamp 298E                 | 242   | 84099941 | 28% |
| 1972900 | Eicher Tractor Inlet Mainfold M/Cd (E)             | 660   | 84099941 | 28% |
| 1972911 | Eicher Tractor Gasket Inlet Pot (R)                | 13    | 68129922 | 18% |
| 1972923 | Eicher Tractor Sealing Cup (E)                     | 46    | 84099941 | 28% |
| 1972935 | Eicher Tractor O Ring (Inlet Manifold)             | 7     | 40169990 | 18% |
| 1972959 | Eicher Tractor O Ring Kit 35 Hp                    | 364   | 40169990 | 18% |
| 1972960 | Eicher Tractor Gasket Kit Eng 35Hp                 | 717   | 84841090 | 18% |
| 1972984 | Eicher Tractor Shim For Fuel Pump 0.5 Mm           | 37    | 73182100 | 18% |
| 1972996 | Eicher Tractor Shim For Fuel Pump 0.7 Mm           | 37    | 73182100 | 18% |
| 1973022 | Eicher Tractor Gasket For Starter Motor & Engine M | 27    | 68129922 | 18% |
| 1973071 | Eicher Tractor O Ring 14 X 1.8                     | 10    | 40169320 | 18% |
| 1973095 | Eicher Tractor Flange M/Cd 321Es,322Es,421Es&422Es | 239   | 84099941 | 28% |
| 1973113 | Eicher Tractor Cam Shaft Finished                  | 3897  | 84831092 | 18% |
| 1973400 | Eicher Tractor Pre Cleaner Assly.                  | 699   | 84099941 | 28% |
| 1973472 | Eicher Tractor Air Inlet Hose                      | 410   | 40093100 | 18% |
| 1973502 | Eicher Tractor Adjusting Shim                      | 17    | 73182100 | 18% |
| 1973526 | Eicher Tractor Fuel Injector Assy                  | 7510  | 84099990 | 28% |
| 1973563 | Eicher Tractor Sealing Washer                      | 31    | 73182990 | 18% |





|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 1973605 | Eicher Tractor Top Bracket                         | 232   | 84099941 | 28% |
| 1973680 | Eicher Tractor Rubber Pad For Frt Deflector        | 35    | 40169390 | 18% |
| 1973691 | Eicher Tractor Rubber Pad For Rear Side            | 27    | 40169320 | 18% |
| 1973721 | Eicher Tractor Control Fork Assly                  | 48    | 84099941 | 28% |
| 1973770 | Eicher Tractor Front Deflector Assy                | 1282  | 84099941 | 28% |
| 1973782 | Eicher Tractor Rear Deflector Assy                 | 1142  | 84099941 | 28% |
| 1973794 | Eicher Tractor Inter Med.Defl. Assy                | 997   | 84099941 | 28% |
| 1973848 | Eicher Tractor Cam Shaft Finished (E)              | 5123  | 84831099 | 18% |
| 1973873 | Eicher Tractor Big End Brg 0.25 Mm O/S             | 123   | 84821011 | 18% |
| 1973885 | Eicher Tractor Big End Brg 0.50 Mm O/S             | 111   | 84821011 | 18% |
| 1973897 | Eicher Tractor Fuel Pipe Assy -Inj Overflow To Ft  | 155   | 40092200 | 18% |
| 1973903 | Eicher Tractor Clip Hose (Type-A)                  | 15    | 40093100 | 18% |
| 1973915 | Eicher Tractor T Joint (E)                         | 69    | 84099941 | 28% |
| 1973939 | Eicher Tractor Hose (Over Flow-225 Mm)             | 117   | 40093100 | 18% |
| 1973940 | Eicher Tractor Shim Fuel Pump .16 Mm (White)       | 24    | 73182100 | 18% |
| 1973952 | Eicher Tractor Shim Fuel Pump .3 Mm (Black)        | 24    | 73182100 | 18% |
| 1973964 | Eicher Tractor Shim Fuel Pump .5 Mm (Red)          | 37    | 73182100 | 18% |
| 1973990 | Eicher Tractor Fuel Inj. Pipe Front-298E/Ex        | 438   | 84099941 | 28% |
| 1974002 | Eicher Tractor Fuel Inj. Pipe Rear-298E/Ex         | 442   | 84099941 | 28% |
| 1974038 | Eicher Tractor F.I.Pump Assy.(298 Recardo)         | 19719 | 84133010 | 28% |
| 1974040 | Eicher Tractor Injector Nozzle 298Ed               | 3478  | 84133010 | 28% |
| 1974063 | Eicher Tractor Fuel Injection Pump Assy.290-       | 15996 | 84133010 | 28% |
| 1974233 | Eicher Tractor Blower Supt.Frt M/Cd                | 1948  | 84099941 | 28% |
| 1974324 | Eicher Tractor Clamp (Deflector) (E)               | 12    | 84099941 | 28% |
| 1974373 | Eicher Tractor Clamp For Air Cleaner - Big         | 197   | 84099990 | 28% |
| 1974385 | Eicher Tractor Clamp For Air Cleaner - Small       | 131   | 84099990 | 28% |
| 1974397 | Eicher Tractor Bush                                | 15    | 87089900 | 18% |
| 1974415 | Eicher Tractor Control Housing Mod. 298            | 3585  | 84099941 | 28% |
| 1974427 | Eicher Tractor Rubber Flap - Big                   | 246   | 40169320 | 18% |
| 1974439 | Eicher Tractor Rubber Flap - Small                 | 155   | 40169320 | 18% |
| 1974464 | Eicher Tractor M B Middle .25Mm U/S                | 109   | 84821020 | 18% |
| 1974476 | Eicher Tractor Main Brg Middle (Upper)-0.5U/S      | 109   | 84821020 | 18% |
| 1974488 | Eicher Tractor M B Middle .25Mm U/S                | 109   | 84821020 | 18% |
| 1974490 | Eicher Tractor Main Brg Middle (Lower)-0.5 U/S     | 109   | 84821020 | 18% |
| 1974520 | Eicher Tractor Cogged Belt For Alternator 1085 (2  | 528   | 40103999 | 18% |
| 1974555 | Eicher Tractor Fuel Pipe Assy-Ft To Ws             | 360   | 84099941 | 28% |
| 1974580 | Eicher Tractor Hose (Air Cleaner Side)             | 145   | 40093100 | 18% |
| 1974609 | Eicher Tractor Rubber Grommet Fr Air Cleaner       | 131   | 40169320 | 18% |
| 1974713 | Eicher Tractor 364Nc Engine O/H Kit                | 16386 | 84099941 | 28% |
| 1974750 | Eicher Tractor Push Rod Assy.                      | 413   | 84099990 | 28% |
| 1974762 | Eicher Tractor Special Banjo Bolt M10*1.5*36       | 29    | 73181500 | 18% |
| 1974774 | Eicher Tractor Stud 6X30                           | 12    | 73182100 | 18% |
| 1974786 | Eicher Tractor Gasket For Cont. Hsg 298E           | 81    | 68129922 | 18% |
| 1974798 | Eicher Tractor Rubber Pad                          | 13    | 40169320 | 18% |
| 1974816 | Eicher Tractor Tube Assy.                          | 364   | 84099941 | 28% |
| 1974853 | Eicher Tractor Cyl Hd Cover M/Cd (R)               | 378   | 84099941 | 28% |
| 1974865 | Eicher Tractor Piston-298E(321Es/322Es/421Es/422Es | 3225  | 84099112 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1974889 | Eicher Tractor Piston-298E 1St Over Size           | 2834 | 84099912 | 28% |
| 1974890 | Eicher Tractor Piston-298E 2Nd Over Size           | 2834 | 84099912 | 28% |
| 1974907 | Eicher Tractor Air Inlet Hose (Inlet Manifold Side | 200  | 40093100 | 18% |
| 1974932 | Eicher Tractor Bearing Hsg M/Cd                    | 3082 | 84099941 | 28% |
| 1974956 | Eicher Tractor Fuel Pipe Assly (Stat-Agro)         | 500  | 40092200 | 18% |
| 1974968 | Eicher Tractor Bush For Crank Shaft                | 179  | 84839000 | 18% |
| 1974981 | Eicher Tractor Cyl. Liner 298                      | 4297 | 84099941 | 28% |
| 1975018 | Eicher Tractor Blower Support Front M/Cd           | 1868 | 84099941 | 28% |
| 1975020 | Eicher Tractor Pump Base-298E                      | 763  | 84099941 | 28% |
| 1975031 | Eicher Tractor Cover Hyd.Pump Mounting             | 32   | 39021000 | 18% |
| 1975055 | Eicher Tractor Main Bearing Front(Thin Wall) 0.25  | 423  | 84824000 | 18% |
| 1975067 | Eicher Tractor Main Bearing Front(Thin Wall) 0.50  | 433  | 84824000 | 18% |
| 1975079 | Eicher Tractor Main Bearing Front(Thin Wall) 0.75  | 374  | 84824000 | 18% |
| 1975081 | Eicher Tractor Bush For Conn Rod                   | 202  | 84099941 | 28% |
| 1975093 | Eicher Tractor Con Rod M/Cd 298                    | 2821 | 84834000 | 18% |
| 1975110 | Eicher Tractor Pulley                              | 207  | 84099941 | 28% |
| 1975146 | Eicher Tractor Air Cleaner Mounting Bracket        | 444  | 84099941 | 28% |
| 1975158 | Eicher Tractor Cam Shaft 298E (Export)             | 5225 | 84831099 | 18% |
| 1975171 | Eicher Tractor Shim Fuel Pump .3 Mm (Black)        | 24   | 73182100 | 18% |
| 1975328 | Eicher Tractor Cover (Fip)                         | 120  | 84099941 | 28% |
| 1975390 | Eicher Tractor Hose Over Flow-125 Mm               | 39   | 40093100 | 18% |
| 1975420 | Eicher Tractor Element 298E                        | 1769 | 84099941 | 28% |
| 1975456 | Eicher Tractor Delivery Valve 298E                 | 742  | 84099941 | 28% |
| 1975468 | Eicher Tractor Delivery Valve Holder               | 485  | 84099941 | 28% |
| 1975470 | Eicher Tractor Control Sleeve                      | 917  | 84099941 | 28% |
| 1975481 | Eicher Tractor Control Sleeve                      | 743  | 84099941 | 28% |
| 1975500 | Eicher Tractor Roller Tappet                       | 1391 | 84824000 | 18% |
| 1975572 | Eicher Tractor Delivery Valve 290E                 | 613  | 84099941 | 28% |
| 1975894 | Eicher Tractor Rigid Fuel Line Assy(Fip Overflow T | 287  | 84099941 | 28% |
| 1975900 | Eicher Tractor Water Separator Assy                | 964  | 84099990 | 28% |
| 1975936 | Eicher Tractor Inlet Manifold M/Cd                 | 1051 | 84099941 | 28% |
| 1975950 | Eicher Tractor Rubber Hose                         | 72   | 40093100 | 18% |
| 1976096 | Eicher Tractor Rubber Coated Alu. Washer Dia 21X15 | 33   | 40169320 | 18% |
| 1976138 | Eicher Tractor Running In Filter Element           | 74   | 84219900 | 18% |
| 1976175 | Eicher Tractor Case(Bowl F Water Seprator)         | 547  | 84099941 | 28% |
| 1976187 | Eicher Tractor Nut (Ring)                          | 461  | 73181500 | 18% |
| 1976199 | Eicher Tractor Plate (Baffle)                      | 83   | 87089900 | 18% |
| 1976205 | Eicher Tractor Flot For Water Separator            | 80   | 84099941 | 28% |
| 1976217 | Eicher Tractor Drain Plug For Water Separator      | 45   | 87084000 | 18% |
| 1976230 | Eicher Tractor O-Ring For Drain Plug-Water Separat | 19   | 40169320 | 18% |
| 1976254 | Eicher Tractor Plate - Coution                     | 16   | 39199090 | 18% |
| 1976291 | Eicher Tractor Bolt (Connector)                    | 58   | 73181500 | 18% |
| 1976357 | Eicher Tractor Adopter(Breather)M/Cd               | 355  | 84099941 | 28% |
| 1976618 | Eicher Tractor Raintrap Assy                       | 125  | 87089900 | 18% |
| 1976620 | Eicher Tractor Cyl Head Cover Multi                | 379  | 84099941 | 28% |
| 1976679 | Eicher Tractor Shim Fuel Pump (White)              | 8    | 73182100 | 18% |
| 1976680 | Eicher Tractor Shim Fuel Pump (Black)              | 8    | 73182100 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 1976692 | Eicher Tractor Shim Fuel Pump (Red)                | 9    | 73182100 | 18% |
| 1976709 | Eicher Tractor Shim Fuel Pump (Green)              | 11   | 73182100 | 18% |
| 1976722 | Eicher Tractor Adapter Plate                       | 91   | 87085000 | 18% |
| 1976731 | Eicher Tractor Oil Feed Pipe Assly                 | 732  | 84099941 | 28% |
| 1976758 | Eicher Tractor Hour/Rpm Meter(Indication)          | 528  | 90292020 | 18% |
| 1976801 | Eicher Tractor Gudgeon Pin                         | 400  | 84099941 | 28% |
| 1976874 | Eicher Tractor O Ring 42 X 4                       | 11   | 40169320 | 18% |
| 1976886 | Eicher Tractor Breather Assly                      | 190  | 84099941 | 28% |
| 1976904 | Eicher Tractor Extension Tube                      | 324  | 84099941 | 28% |
| 1976930 | Eicher Tractor Strip (Gov. Cover)                  | 23   | 73011000 | 18% |
| 1976941 | Eicher Tractor Sealing Cup (Gov. Cover.)           | 23   | 84099941 | 28% |
| 1976953 | Eicher Tractor Pump Element 290 Ricardo            | 1998 | 84099941 | 28% |
| 1976989 | Eicher Tractor Special Screw                       | 22   | 73181500 | 18% |
| 1977012 | Eicher Tractor Cover (Exhaust Manifold)            | 547  | 87089200 | 18% |
| 1977179 | Eicher Tractor Special Washer For Flang Type Bolt  | 9    | 73182990 | 18% |
| 1977209 | Eicher Tractor Piston Ring Set                     | 622  | 84099913 | 28% |
| 1977260 | Eicher Tractor Breather Tube                       | 213  | 40092200 | 18% |
| 1977295 | Eicher Tractor Hr/Rpm Meter (Int W/1976758 & 19734 | 753  | 90292020 | 18% |
| 1977313 | Eicher Tractor Hinge Block Assly                   | 286  | 84099941 | 28% |
| 1977326 | Eicher Tractor Main Element                        | 814  | 84219900 | 18% |
| 1977489 | Eicher Tractor Big End Brg. Thin-1.0 U/S           | 111  | 84821011 | 18% |
| 1977507 | Eicher Tractor Big End Brg. Thin-0.75 U/S          | 118  | 84821011 | 18% |
| 1979853 | Eicher Tractor Safety Element                      | 990  | 84219900 | 18% |
| 2010010 | Eicher Tractor Ammeter                             | 214  | 85123010 | 18% |
| 2010070 | Eicher Tractor Bulb Head Light 12V                 | 41   | 85122090 | 18% |
| 2010082 | Eicher Tractor Blub Plough Light 12V               | 44   | 85123010 | 18% |
| 2010100 | Eicher Tractor Ulb Tail Light                      | 22   | 85123010 | 18% |
| 2010446 | Eicher Tractor Dynamo 12V                          | 8547 | 85112090 | 28% |
| 2010460 | Eicher Tractor Regulator Boc                       | 744  | 85369090 | 18% |
| 2010975 | Eicher Tractor Knob F Main Switch                  | 19   | 87084000 | 18% |
| 2010987 | Eicher Tractor Glass For Pl Light                  | 26   | 85123010 | 18% |
| 2011001 | Eicher Tractor Glass Hd Light                      | 31   | 85123010 | 18% |
| 2011116 | Eicher Tractor Horn 12V                            | 288  | 85122010 | 18% |
| 2015272 | Eicher Tractor Fuse 8 Amp                          | 9    | 85369090 | 18% |
| 2015302 | Eicher Tractor Lamp For Hazard Switch 12V-2W       | 17   | 85365090 | 18% |
| 2020038 | Eicher Tractor Bevel Gear                          | 3053 | 87084000 | 18% |
| 2020087 | Eicher Tractor Deep Groove Ball Bearing 6010       | 591  | 84821011 | 18% |
| 2020099 | Eicher Tractor Ball Bearing 6210                   | 718  | 84821011 | 18% |
| 2020117 | Eicher Tractor Deep Groove Ball Bearing 6307       | 571  | 84821011 | 18% |
| 2020130 | Eicher Tractor Ball Bearing 6210-C3                | 588  | 84821011 | 18% |
| 2020142 | Eicher Tractor Circlip Light B-80                  | 44   | 73182910 | 18% |
| 2020178 | Eicher Tractor Gasket For Conn. Cover              | 12   | 68129090 | 18% |
| 2020221 | Eicher Tractor Parellel Key                        | 40   | 73182100 | 18% |
| 2020257 | Eicher Tractor Grooved Nut 32X1.5                  | 68   | 73181500 | 18% |
| 2020270 | Eicher Tractor Lock Nut M30X1.5                    | 62   | 73181500 | 18% |
| 2020300 | Eicher Tractor Drain Plug M24X1.5                  | 60   | 87084000 | 18% |
| 2020350 | Eicher Tractor O Ring 33.2X3                       | 10   | 40169340 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2020373 | Eicher Tractor Shim                                | 14   | 73182100 | 18% |
| 2020385 | Eicher Tractor Shim 48X35.5X0.1                    | 4    | 73182100 | 18% |
| 2020397 | Eicher Tractor Shim 48X35.5X0.2                    | 4    | 73182100 | 18% |
| 2020403 | Eicher Tractor Shim 48X35.5X0.3                    | 3    | 73182100 | 18% |
| 2020439 | Eicher Tractor Oil Seal 42X62X10                   | 63   | 40169990 | 18% |
| 2020440 | Eicher Tractor Oil Seal 48X65X10                   | 62   | 40169330 | 18% |
| 2020452 | Eicher Tractor Oil Seal 50X80X8                    | 65   | 40169330 | 18% |
| 2020506 | Eicher Tractor Locking Piece                       | 14   | 87084000 | 18% |
| 2020520 | Eicher Tractor Rear Transmission Hsg               | 3926 | 87089900 | 18% |
| 2020531 | Eicher Tractor Spacer For Bevel Gear               | 180  | 73182100 | 18% |
| 2020543 | Eicher Tractor Spacer For Bevel Pnion              | 195  | 73182100 | 18% |
| 2020592 | Eicher Tractor Circlip Light A-50 (Is:3075)        | 18   | 73182910 | 18% |
| 2020610 | Eicher Tractor Shim For Bevel Pinion 79.5X68X0.1Mm | 8    | 73182100 | 18% |
| 2020622 | Eicher Tractor Shim For Bevel Pinion 79.5X68X0.3Mm | 5    | 73182100 | 18% |
| 2020634 | Eicher Tractor Shim 89X81X0.10Mm                   | 11   | 73182100 | 18% |
| 2020646 | Eicher Tractor Shim 89X81X0.3Mm                    | 10   | 73182100 | 18% |
| 2020660 | Eicher Tractor Shim 89X81X1.0Mm                    | 11   | 73182100 | 18% |
| 2021109 | Eicher Tractor Pto Cover                           | 465  | 87084000 | 18% |
| 2021110 | Eicher Tractor Gasket For Pto Cover                | 24   | 68129090 | 18% |
| 2021249 | Eicher Tractor Bevel Pinion                        | 1785 | 87084000 | 18% |
| 2021250 | Eicher Tractor Belt Pulley                         | 2471 | 40101290 | 18% |
| 2021262 | Eicher Tractor Connection Cover                    | 218  | 87089900 | 18% |
| 2021274 | Eicher Tractor Distance Tube                       | 293  | 87089900 | 18% |
| 2021286 | Eicher Tractor Shim                                | 21   | 73182100 | 18% |
| 2050286 | Eicher Tractor Tool Kit 13 Items                   | 667  | 82060090 | 18% |
| 2063961 | Eicher Tractor Pressure Filter Element             | 927  | 84219900 | 18% |
| 2120707 | Eicher Tractor Tension Spring                      | 13   | 73202000 | 18% |
| 2120963 | Eicher Tractor Wire Lock                           | 23   | 87089900 | 18% |
| 2121050 | Eicher Tractor Rubber Sleeve                       | 26   | 40169990 | 18% |
| 2121062 | Eicher Tractor Rubber Beading For Dash Board       | 283  | 40169320 | 18% |
| 2121086 | Eicher Tractor Pressure Plate 312                  | 1544 | 87089900 | 18% |
| 2121165 | Eicher Tractor Release Lever Plate                 | 241  | 87089900 | 18% |
| 2121177 | Eicher Tractor Release Lever                       | 55   | 87089900 | 18% |
| 2121232 | Eicher Tractor Link(485)                           | 128  | 87089900 | 18% |
| 2121244 | Eicher Tractor Cover                               | 91   | 87084000 | 18% |
| 2121293 | Eicher Tractor Special Nut                         | 29   | 73181500 | 18% |
| 2121414 | Eicher Tractor Washer 30X16.5X3.2                  | 13   | 73182100 | 18% |
| 2121487 | Eicher Tractor Spacer (26Mm)                       | 25   | 73182100 | 18% |
| 2121529 | Eicher Tractor Connecting Link Assy.(Foot Acc.)    | 193  | 87089900 | 18% |
| 2121530 | Eicher Tractor Accelerator Shaft Guide             | 147  | 87084000 | 18% |
| 2121542 | Eicher Tractor Accelerator Shaft                   | 118  | 87084000 | 18% |
| 2121554 | Eicher Tractor Hand Accelerator Rod                | 180  | 84099941 | 28% |
| 2121566 | Eicher Tractor Accelerator Lever Small(Foot Acc)   | 61   | 87084000 | 18% |
| 2121578 | Eicher Tractor Hand Accelerator Link               | 41   | 87085000 | 18% |
| 2121580 | Eicher Tractor Accelerator Lever Big               | 96   | 87084000 | 18% |
| 2121591 | Eicher Tractor Accelerator Lever                   | 61   | 87085000 | 18% |
| 2121621 | Eicher Tractor Rod Assy                            | 65   | 87089900 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 2121645 | Eicher Tractor Lever                        | 235  | 87089900 | 18% |
| 2121670 | Eicher Tractor Lever-Fulcrum Pin            | 77   | 73182100 | 18% |
| 2121736 | Eicher Tractor Al.Strip For Fuel Tank       | 195  | 76169990 | 18% |
| 2121827 | Eicher Tractor Bottom Pad                   | 208  | 40169990 | 18% |
| 2121852 | Eicher Tractor Beading Rear                 | 135  | 40169990 | 18% |
| 2121864 | Eicher Tractor Beading Front                | 53   | 40169990 | 18% |
| 2122017 | Eicher Tractor Bonnet Pad                   | 152  | 87081010 | 18% |
| 2122029 | Eicher Tractor Wire Rod Assy                | 48   | 85122010 | 18% |
| 2122108 | Eicher Tractor Steering Gear Support (312)  | 1312 | 87089400 | 18% |
| 2122359 | Eicher Tractor Fuel Cock Assy.              | 448  | 84099941 | 28% |
| 2122480 | Eicher Tractor Beading Right                | 225  | 40169990 | 18% |
| 2122492 | Eicher Tractor Beading Left                 | 280  | 40169990 | 18% |
| 2122807 | Eicher Tractor Sleeve                       | 535  | 87084000 | 18% |
| 2122893 | Eicher Tractor Link                         | 260  | 87089900 | 18% |
| 2122923 | Eicher Tractor Spring                       | 128  | 73209090 | 18% |
| 2123022 | Eicher Tractor Bracket For Brake Switch     | 148  | 87083000 | 18% |
| 2123058 | Eicher Tractor Pedal Shaft 369              | 1677 | 87084000 | 18% |
| 2123060 | Eicher Tractor Spacer 369                   | 182  | 73182100 | 18% |
| 2123162 | Eicher Tractor Foot Accelerator Shaft       | 57   | 87084000 | 18% |
| 2123186 | Eicher Tractor Pin 369                      | 25   | 73182100 | 18% |
| 2123265 | Eicher Tractor Medallion                    | 287  | 39199090 | 18% |
| 2123356 | Eicher Tractor Seleve 369                   | 341  | 87084000 | 18% |
| 2123526 | Eicher Tractor Chain Assy. 369              | 1136 | 87089900 | 18% |
| 2123538 | Eicher Tractor Battery Mounting Bracket     | 555  | 85079090 | 28% |
| 2124038 | Eicher Tractor Strainer                     | 24   | 84219900 | 18% |
| 2124476 | Eicher Tractor Gasket For Inspection Of Fwh | 25   | 68129090 | 18% |
| 2124592 | Eicher Tractor Pin For Pedal                | 359  | 73182100 | 18% |
| 2124609 | Eicher Tractor Bush                         | 895  | 87085000 | 18% |
| 2125183 | Eicher Tractor J-Bolt                       | 77   | 73181500 | 18% |
| 2125389 | Eicher Tractor Ornamental Section           | 82   | 87089900 | 18% |
| 2125470 | Eicher Tractor Foot Step Sdi /Ddd Dlx       | 437  | 87089900 | 18% |
| 2125663 | Eicher Tractor Rear Wheel Nut M16X1.5,Zp,   | 84   | 73181500 | 18% |
| 2125742 | Eicher Tractor Spring Dowel Sleeve 16X28    | 41   | 73182100 | 18% |
| 2126163 | Eicher Tractor Clutch Pedal Assy            | 1161 | 87089300 | 18% |
| 2126310 | Eicher Tractor Side Grill Left              | 255  | 87089900 | 18% |
| 2126503 | Eicher Tractor Mudguard Handle              | 144  | 87089900 | 18% |
| 2126620 | Eicher Tractor Bracket For Brake Switch     | 66   | 87083000 | 18% |
| 2126631 | Eicher Tractor Pad                          | 16   | 40169320 | 18% |
| 2126783 | Eicher Tractor Dash Board Cover             | 345  | 87089900 | 18% |
| 2126904 | Eicher Tractor Link Wire Rod-398            | 23   | 84099941 | 28% |
| 2126928 | Eicher Tractor Lock Assy - Left             | 203  | 87089900 | 18% |
| 2126930 | Eicher Tractor Lock Assy - Right            | 210  | 87089900 | 18% |
| 2126965 | Eicher Tractor Wire Rod Assy-693Mm(553Mm)   | 90   | 85122010 | 18% |
| 2127090 | Eicher Tractor Mounting Bracket             | 63   | 87089900 | 18% |
| 2127106 | Eicher Tractor Pin Assy Front Weight 36     | 155  | 73182100 | 18% |
| 2127224 | Eicher Tractor Tension Link Left            | 1    | 87089900 | 18% |
| 2127234 | Eicher Tractor Pedal Shaft                  | 1311 | 87084000 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 2127246 | Eicher Tractor Spacer                              | 226   | 73182100 | 18% |
| 2127430 | Eicher Tractor Tool Box Mtg. Bracket               | 96    | 87089900 | 18% |
| 2127489 | Eicher Tractor Pin Assy.                           | 177   | 73182100 | 18% |
| 2127635 | Eicher Tractor Foot Board Left 369                 | 927   | 87089900 | 18% |
| 2127994 | Eicher Tractor Side Cover Left                     | 51    | 87089900 | 18% |
| 2128007 | Eicher Tractor Side Cover Right                    | 52    | 87084000 | 18% |
| 2128019 | Eicher Tractor Lower Cover                         | 77    | 87089900 | 18% |
| 2128042 | Eicher Tractor Graphics Fuel Tank Left             | 147   | 39199090 | 18% |
| 2128044 | Eicher Tractor Graphics Left Fuel Tank             | 135   | 39199090 | 18% |
| 2128056 | Eicher Tractor Graphics Right Fuel Tank            | 140   | 39199090 | 18% |
| 2128251 | Eicher Tractor Rotary Main Switch                  | 288   | 85369090 | 18% |
| 2128354 | Eicher Tractor Plough Light Assy                   | 787   | 85122010 | 18% |
| 2128408 | Eicher Tractor Indicator Turning                   | 64    | 85122010 | 18% |
| 2128410 | Eicher Tractor Indicator Charge                    | 104   | 85311010 | 18% |
| 2128494 | Eicher Tractor Lead Assy(Bat + Ve To St            | 962   | 85122010 | 18% |
| 2128585 | Eicher Tractor F-Mp Plough Light                   | 106   | 85122010 | 18% |
| 2128731 | Eicher Tractor Rear Light Assy Left.               | 667   | 85122010 | 18% |
| 2128743 | Eicher Tractor Rear Light Assy Right               | 652   | 85122010 | 18% |
| 2128962 | Eicher Tractor Plough Light Glass                  | 57    | 85122010 | 18% |
| 2129050 | Eicher Tractor Indicator Dummy                     | 25    | 85122010 | 18% |
| 2129103 | Eicher Tractor Head Light Assy.                    | 557   | 85122010 | 18% |
| 2129152 | Eicher Tractor Side Reflector                      | 93    | 85122010 | 18% |
| 2129206 | Eicher Tractor Battery Lead Black                  | 752   | 85079090 | 28% |
| 2129528 | Eicher Tractor Hazard Switch (Toggle)              | 98    | 85365090 | 18% |
| 2129693 | Eicher Tractor Lead Assy.(+Ve)                     | 974   | 85441920 | 18% |
| 2129711 | Eicher Tractor Temperature Sensor [586]            | 233   | 90268090 | 18% |
| 2129760 | Eicher Tractor Alternator Assy.                    | 8235  | 85115000 | 28% |
| 2129796 | Eicher Tractor Temp. Signaling Device              | 1324  | 85122010 | 18% |
| 2129840 | Eicher Tractor Dash Board Cover                    | 409   | 87089900 | 18% |
| 2129978 | Eicher Tractor Wiring Harness Dashboard            | 237   | 85441920 | 18% |
| 2129991 | Eicher Tractor Pig Tail For Front Light            | 1     | 85122010 | 18% |
| 2210460 | Eicher Tractor Spt-002=Dismantling Stand-Set Of 1  | 40494 | 82060090 | 18% |
| 2210472 | Eicher Tractor Spt-115=Conecting Rod Bend Fixture  | 2585  | 82060090 | 18% |
| 2210484 | Eicher Tractor Spt-005=Fixture-Connecting Rod Bend | 2378  | 82060090 | 18% |
| 2211191 | Eicher Tractor Spt-006=Mask Valve Fixture For 312  | 3251  | 82060090 | 18% |
| 2211270 | Eicher Tractor Spt-009=Puller For Valve -Lift Actu | 201   | 82060090 | 18% |
| 2211889 | Eicher Tractor Spt-008=Mask Valve Fixture 364/369  | 2874  | 82060090 | 18% |
| 2212432 | Eicher Tractor Tool Set                            | 5449  | 82060090 | 18% |
| 2212675 | Eicher Tractor Spt-027=Puller For Puppet Valve     | 98    | 82060090 | 18% |
| 2212730 | Eicher Tractor Sptv - 001,Extractor For Coolent Pu | 3318  | 82060090 | 18% |
| 2212742 | Eicher Tractor Sptv - 002,Mandrel For Pressing Co  | 632   | 82060090 | 18% |
| 2212754 | Eicher Tractor Sptv - 003,Crank Shaft Gear Pressin | 2186  | 82060090 | 18% |
| 2212766 | Eicher Tractor Sptv - 004,Cam Gear Pressing Mandre | 465   | 82060090 | 18% |
| 2212778 | Eicher Tractor Sptv - 005,Oil Pump Driving Pressin | 1269  | 82060090 | 18% |
| 2212780 | Eicher Tractor Sptv - 006,Liner Pressing Fixturepu | 2917  | 82060090 | 18% |
| 2212821 | Eicher Tractor Sptv - 010,Pressing Mandrel For Co  | 924   | 82060090 | 18% |
| 2212833 | Eicher Tractor Sptv - 011,Handle For Using Rotatin | 2342  | 82060090 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 2212845 | Eicher Tractor Sptv - 012,Pressing Mandrel For Fro   | 2196  | 82060090 | 18% |
| 2212857 | Eicher Tractor Sptv - 013,Extractor For Injectorpu   | 733   | 82060090 | 18% |
| 2212882 | Eicher Tractor Sptv - 016,Lever For Compressing Va   | 2320  | 82060090 | 18% |
| 2212894 | Eicher Tractor Sptv - 017,Holder For Dial Gauge To   | 1831  | 82060090 | 18% |
| 2212900 | Eicher Tractor Sptv - 018,Guide Bush For Rear Seal   | 4880  | 82060090 | 18% |
| 2212912 | Eicher Tractor Sptv - 019,Pressing Mandrel For Rea   | 3294  | 82060090 | 18% |
| 2212924 | Eicher Tractor Sptv - 020,Centring Tool For Fly Wh   | 6099  | 82060090 | 18% |
| 2212948 | Eicher Tractor Sptv - 022,Pressing Mandrel For Dow   | 219   | 82060090 | 18% |
| 2212950 | Eicher Tractor Sptv - 023,Pressing Mandrel For Dow   | 219   | 82060090 | 18% |
| 2212961 | Eicher Tractor Sptv - 024,Pressing Mandrel For Brg   | 2320  | 82060090 | 18% |
| 2212973 | Eicher Tractor Sptv - 025,Sizing Mandrel For Dia 1   | 3318  | 82060090 | 18% |
| 2212985 | Eicher Tractor Sptv - 026,Lift Arm Setting Tool Pu   | 2196  | 82060090 | 18% |
| 2212997 | Eicher Tractor Sptv - 027,Mandrel For Locating Cyl   | 2246  | 82060090 | 18% |
| 2213000 | Eicher Tractor Sptv - 028,Mandrel To Press Oil Sea   | 2684  | 82060090 | 18% |
| 2213011 | Eicher Tractor Sptv - 029,Mandrel For Bush Pressin   | 2441  | 82060090 | 18% |
| 2213023 | Eicher Tractor Sptv - 030,Assebley Con For Dia 100   | 2563  | 82060090 | 18% |
| 2213035 | Eicher Tractor Sptv - 031,Clutch Assy. Centring Too  | 2196  | 82060090 | 18% |
| 2213047 | Eicher Tractor Sptv - 032,Tool For Cover Lt/Rt Tig   | 2563  | 82060090 | 18% |
| 2213059 | Eicher Tractor Sptv - 033,P. I. Shaft Spacer Pressin | 8831  | 82060090 | 18% |
| 2213060 | Eicher Tractor Sptv - 034,Special Tool For Tighten   | 2684  | 82060090 | 18% |
| 2213072 | Eicher Tractor Sptv - 035,Tapper & Cylindrical Pin   | 611   | 82060090 | 18% |
| 2213084 | Eicher Tractor Sptv - 036,Oil Seal Pressing Mandre   | 977   | 82060090 | 18% |
| 2213096 | Eicher Tractor Sptv - 037,Actuating Disc Retainer    | 855   | 82060090 | 18% |
| 2213114 | Eicher Tractor Sptv - 039,Ring Pressing Mandrel On   | 2684  | 82060090 | 18% |
| 2213126 | Eicher Tractor Sptv - 040,Mandrel For Tightening G   | 3318  | 82060090 | 18% |
| 2213138 | Eicher Tractor Sptv - 041,Cover Lt/Rt Trb Outer Ra   | 4295  | 82060090 | 18% |
| 2213140 | Eicher Tractor Sptv - 042,Diff. Cover & Diff. Trb I  | 2928  | 82060090 | 18% |
| 2213151 | Eicher Tractor Sptv - 043,Countr Shaft & C. P. Shaf  | 6832  | 82060090 | 18% |
| 2213163 | Eicher Tractor Sptv - 044,For Pressing Inner Race    | 1465  | 82060090 | 18% |
| 2213175 | Eicher Tractor Sptv - 045,Outer Race Pressing Mand   | 6929  | 82060090 | 18% |
| 2213187 | Eicher Tractor Sptv - 046,Axle Tube Centre Oil Sea   | 3903  | 82060090 | 18% |
| 2213229 | Eicher Tractor Spt-48003=Gauge For Spring Length     | 465   | 82060090 | 18% |
| 2213230 | Eicher Tractor Spt-48004=Mandrel For Ring            | 340   | 82060090 | 18% |
| 2213242 | Eicher Tractor Spt-48007=Tube Oil Seal Housing       | 2098  | 82060090 | 18% |
| 2213254 | Eicher Tractor Spt-48005= Tool For F. I. Pump        | 327   | 82060090 | 18% |
| 2213266 | Eicher Tractor Spt-48006= Puller For Cam Gear        | 2001  | 82060090 | 18% |
| 2213280 | Eicher Tractor Spt-018=Dual Clutch Alignment Gauge   | 4148  | 82060090 | 18% |
| 2213291 | Eicher Tractor Spt-006=Special Tool Hyd. Filter Sm   | 556   | 82060090 | 18% |
| 2213310 | Eicher Tractor Spt-015=Addc Piston Seal Assy. Kit 1  | 6343  | 82060090 | 18% |
| 2230033 | Eicher Tractor Bush                                  | 70    | 87089900 | 18% |
| 2230100 | Eicher Tractor Drain Plug M22X1.5                    | 49    | 87084000 | 18% |
| 2230112 | Eicher Tractor Adjusting Axle Assy                   | 451   | 87085000 | 18% |
| 2230161 | Eicher Tractor Friction Washer                       | 12    | 73209090 | 18% |
| 2230185 | Eicher Tractor Piston Rod                            | 1315  | 87089900 | 18% |
| 2230215 | Eicher Tractor Circlip(Dia 68 Wire)                  | 29    | 73182910 | 18% |
| 2230239 | Eicher Tractor Lift Cylinder                         | 18732 | 87089900 | 18% |
| 2230318 | Eicher Tractor Spring                                | 12    | 73209090 | 18% |



|         |   |       |          |     |
|---------|---|-------|----------|-----|
| 2230343 | Eicher Tractor Valve Mechanism Assy.              | 94907 | 87089900 | 18% |
| 2230458 | Eicher Tractor Spring Main Spool                  | 5     | 73202000 | 18% |
| 2230471 | Eicher Tractor Back Up Ring 16X20X2 Ptfе          | 59    | 39269099 | 18% |
| 2230860 | Eicher Tractor Rod                                | 49    | 87084000 | 18% |
| 2230872 | Eicher Tractor Cylindrical Pin                    | 105   | 73182100 | 18% |
| 2230902 | Eicher Tractor Connecting Nut                     | 15    | 73181500 | 18% |
| 2230914 | Eicher Tractor Rod                                | 26    | 87084000 | 18% |
| 2230951 | Eicher Tractor Sleeve                             | 140   | 87084000 | 18% |
| 2230963 | Eicher Tractor Extension Spring-6100              | 13    | 73209090 | 18% |
| 2231049 | Eicher Tractor Safety Clip                        | 45    | 73182100 | 18% |
| 2231050 | Eicher Tractor Safety Valve 18 Mpa                | 828   | 87089900 | 18% |
| 2231062 | Eicher Tractor Inlet Pipe                         | 256   | 87089900 | 18% |
| 2231098 | Eicher Tractor Stud M10*175                       | 84    | 73182100 | 18% |
| 2231130 | Eicher Tractor Cover (Diff Valve)                 | 773   | 87084000 | 18% |
| 2231141 | Eicher Tractor Sleeve                             | 55    | 87084000 | 18% |
| 2231153 | Eicher Tractor Uninion -Triple Lok F870Xs16 M22   | 239   | 73079990 | 18% |
| 2231165 | Eicher Tractor Uninion -Triple Lok V6Xs16 Aset 45 | 1074  | 73079990 | 18% |
| 2231189 | Eicher Tractor Hand Lever                         | 55    | 87089900 | 18% |
| 2231219 | Eicher Tractor Cover For Knob                     | 25    | 87084000 | 18% |
| 2231256 | Eicher Tractor Quick Coupler-Female               | 1662  | 84814000 | 28% |
| 2231281 | Eicher Tractor Pipe Lower 2 Value                 | 491   | 87089900 | 18% |
| 2231402 | Eicher Tractor Double Nipple F870*S12 M18         | 220   | 73072100 | 18% |
| 2231440 | Eicher Tractor Lever Head                         | 49    | 87089900 | 18% |
| 2231463 | Eicher Tractor Conical Washer 51.5*35.5*0.6       | 14    | 73182100 | 18% |
| 2231505 | Eicher Tractor Counter Plate                      | 74    | 87089900 | 18% |
| 2231529 | Eicher Tractor Shim                               | 9     | 73182100 | 18% |
| 2231530 | Eicher Tractor Shim                               | 11    | 73182100 | 18% |
| 2231566 | Eicher Tractor Bearing Mb 2530 Du                 | 241   | 84833000 | 18% |
| 2231578 | Eicher Tractor Stud M12*25                        | 14    | 73182100 | 18% |
| 2231591 | Eicher Tractor Extention                          | 864   | 87089900 | 18% |
| 2231608 | Eicher Tractor Breather Hydraulics                | 253   | 87089900 | 18% |
| 2231610 | Eicher Tractor Plug Dia 40                        | 23    | 87089900 | 18% |
| 2231645 | Eicher Tractor Cylindrical Pin                    | 63    | 73182100 | 18% |
| 2231670 | Eicher Tractor Hyd Tandem Pump                    | 7424  | 84138190 | 18% |
| 2231682 | Eicher Tractor Filter Hsg.                        | 1470  | 84219900 | 18% |
| 2231694 | Eicher Tractor Strainer For Hyd. Pump             | 329   | 84219900 | 18% |
| 2231700 | Eicher Tractor Gasket                             | 12    | 68129090 | 18% |
| 2231712 | Eicher Tractor Pipe                               | 43    | 87089900 | 18% |
| 2231724 | Eicher Tractor Plate                              | 3     | 87089400 | 18% |
| 2231736 | Eicher Tractor Magnet Rivet                       | 37    | 73182100 | 18% |
| 2231748 | Eicher Tractor Joint                              | 200   | 87089900 | 18% |
| 2231750 | Eicher Tractor Suction Elbow(Hose 90 Deg)         | 146   | 40093100 | 18% |
| 2231761 | Eicher Tractor Rubber Bushing                     | 11    | 40169320 | 18% |
| 2231785 | Eicher Tractor Nut                                | 76    | 73181500 | 18% |
| 2231797 | Eicher Tractor Stud                               | 33    | 73182100 | 18% |
| 2231803 | Eicher Tractor Gasket-Hyd Gear Pump               | 16    | 68129090 | 18% |
| 2231815 | Eicher Tractor Coupling Sleeve                    | 1312  | 87084000 | 18% |





|         |   |      |          |     |
|---------|---|------|----------|-----|
| 2231827 | Eicher Tractor Pressure Conect. Flange            | 491  | 87089900 | 18% |
| 2231839 | Eicher Tractor Upper Water Pipe(Hose)             | 121  | 40093100 | 18% |
| 2231840 | Eicher Tractor Suction Pipe                       | 2113 | 87089900 | 18% |
| 2231852 | Eicher Tractor Connecting Hose Assy               | 1149 | 40093100 | 18% |
| 2231888 | Eicher Tractor Hose Assy Pump Prs. Pipe           | 961  | 40093100 | 18% |
| 2231906 | Eicher Tractor Pressure Filter Assy               | 5942 | 84219900 | 18% |
| 2231918 | Eicher Tractor Filter Hsg.                        | 2133 | 87089900 | 18% |
| 2231931 | Eicher Tractor Body, Pressure Filter              | 2611 | 87089900 | 18% |
| 2231943 | Eicher Tractor Union F870*S16*M27                 | 265  | 73072100 | 18% |
| 2231955 | Eicher Tractor By Pass Valve                      | 131  | 73202000 | 18% |
| 2231967 | Eicher Tractor Spring Of Valve                    | 26   | 73202000 | 18% |
| 2231980 | Eicher Tractor Union -Tripple Lok V870Xs16- M22   | 1028 | 84099941 | 28% |
| 2232054 | Eicher Tractor Spring Pin 6*24                    | 219  | 73182100 | 18% |
| 2232091 | Eicher Tractor Mounting Yoke                      | 82   | 87084000 | 18% |
| 2232108 | Eicher Tractor Bush                               | 16   | 87089900 | 18% |
| 2232110 | Eicher Tractor Control Lever Position             | 112  | 87084000 | 18% |
| 2232133 | Eicher Tractor Bow                                | 111  | 87089900 | 18% |
| 2232145 | Eicher Tractor Limiter                            | 45   | 87083000 | 18% |
| 2232169 | Eicher Tractor Limiter                            | 27   | 87083000 | 18% |
| 2232170 | Eicher Tractor Button                             | 26   | 87083000 | 18% |
| 2232182 | Eicher Tractor Knob                               | 41   | 87084000 | 18% |
| 2232194 | Eicher Tractor Protective Rubber                  | 37   | 40169320 | 18% |
| 2232340 | Eicher Tractor Hose                               | 968  | 40093100 | 18% |
| 2232352 | Eicher Tractor Double Nipple M18X1.5-3/4-16Unf(92 | 298  | 73072100 | 18% |
| 2232388 | Eicher Tractor Hose                               | 2339 | 40093100 | 18% |
| 2232390 | Eicher Tractor Hose                               | 2269 | 40093100 | 18% |
| 2232443 | Eicher Tractor Hose Assy                          | 1051 | 40093100 | 18% |
| 2232455 | Eicher Tractor Hose Assy                          | 1243 | 40093100 | 18% |
| 2233292 | Eicher Tractor Support                            | 114  | 87084000 | 18% |
| 2233311 | Eicher Tractor Gear Z 27                          | 2518 | 87084000 | 18% |
| 2233384 | Eicher Tractor V-Belt Xpa 1320                    | 583  | 40101290 | 18% |
| 2233651 | Eicher Tractor Hose Clamp 17                      | 24   | 73269099 | 18% |
| 2233727 | Eicher Tractor Nylock Nut M24                     | 57   | 73181500 | 18% |
| 2233990 | Eicher Tractor Lock Nut                           | 138  | 73181500 | 18% |
| 2234051 | Eicher Tractor Cover                              | 626  | 87084000 | 18% |
| 2360019 | Eicher Tractor Name Plate Eicher Lt               | 855  | 39199090 | 18% |
| 2360020 | Eicher Tractor Name Plate Eicher Rt               | 856  | 39199090 | 18% |
| 2360056 | Eicher Tractor Sticker Double Clutch              | 180  | 39199090 | 18% |
| 2360070 | Eicher Tractor Sticker Fuel Tank Lower            | 131  | 39199090 | 18% |
| 2360214 | Eicher Tractor Tie Rod Assy                       | 1893 | 87089400 | 18% |
| 2360615 | Eicher Tractor Foot Board Rt                      | 632  | 87089900 | 18% |
| 2360720 | Eicher Tractor Pin Mounting Bracket & Link 485    | 342  | 73182100 | 18% |
| 2360777 | Eicher Tractor Hand Acc.Rod                       | 173  | 84099941 | 28% |
| 2360809 | Eicher Tractor Hand Acc.Lever                     | 116  | 87089900 | 18% |
| 2360822 | Eicher Tractor Hand Acc.Mtg.Bkt                   | 84   | 87089900 | 18% |
| 2360846 | Eicher Tractor Knob                               | 38   | 39269099 | 18% |
| 2360986 | Eicher Tractor Steering Lever Single              | 1113 | 87089400 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 2361220 | Eicher Tractor Drag Rod Assy (Sc)                 | 1930 | 87089400 | 18% |
| 2361231 | Eicher Tractor Tie Rod Assy                       | 3279 | 87089400 | 18% |
| 2361243 | Eicher Tractor Drag Link Assy (Dc)                | 2839 | 87089400 | 18% |
| 2361267 | Eicher Tractor Drag Link Assy                     | 1922 | 87089400 | 18% |
| 2361360 | Eicher Tractor Hand Acc. Mtg. Bkt                 | 148  | 87089900 | 18% |
| 2361383 | Eicher Tractor Pin                                | 140  | 73182100 | 18% |
| 2361528 | Eicher Tractor Lower Link Assy Lt                 | 2025 | 87089900 | 18% |
| 2361530 | Eicher Tractor Lower Link Assy Rt                 | 2025 | 87089900 | 18% |
| 2361552 | Eicher Tractor Fork & Guide Assy                  | 2446 | 87089900 | 18% |
| 2361565 | Eicher Tractor Lifting Gear Assy                  | 3423 | 87089900 | 18% |
| 2361577 | Eicher Tractor Foot Board Rt                      | 624  | 87089900 | 18% |
| 2361656 | Eicher Tractor Brake Pedal Rt 485 Sdi             | 978  | 87083000 | 18% |
| 2361717 | Eicher Tractor Spacer (Acc. Mech)                 | 43   | 73182100 | 18% |
| 2361747 | Eicher Tractor Wiring Harness Main                | 1902 | 85441920 | 18% |
| 2361759 | Eicher Tractor Head Light Assy.                   | 489  | 85122010 | 18% |
| 2361784 | Eicher Tractor Hazard Switch                      | 370  | 85122010 | 18% |
| 2361808 | Eicher Tractor Drag Link (Tie Rod Of 50 Hp)       | 2468 | 87089400 | 18% |
| 2530016 | Eicher Tractor Strip                              | 11   | 73011000 | 18% |
| 2530028 | Eicher Tractor Crank Key                          | 142  | 87089900 | 18% |
| 2530090 | Eicher Tractor Chain Mounting Bracket-Left        | 422  | 87089900 | 18% |
| 2530107 | Eicher Tractor Chain Mounting Bracket-Right       | 422  | 87089900 | 18% |
| 2530144 | Eicher Tractor Foot Board Rt. 369                 | 1038 | 87089900 | 18% |
| 2530181 | Eicher Tractor Final Drive Housing                | 9613 | 87084000 | 18% |
| 2530211 | Eicher Tractor Hand Accelerator Rod               | 223  | 84099941 | 28% |
| 2530235 | Eicher Tractor Pin For Lock                       | 40   | 73182100 | 18% |
| 2530247 | Eicher Tractor Lock Handle                        | 245  | 83012000 | 18% |
| 2530399 | Eicher Tractor Grommet Hand Acc.                  | 20   | 40169990 | 18% |
| 2530405 | Eicher Tractor Grommet-Steering                   | 34   | 40169990 | 18% |
| 2530491 | Eicher Tractor Chain Mtg Bkt. Rt                  | 483  | 87089900 | 18% |
| 2530508 | Eicher Tractor Chain Mtg Bkt. Lt                  | 508  | 87089900 | 18% |
| 2530636 | Eicher Tractor Fuel Tank Graphics Left 369 Prem.  | 163  | 39199090 | 18% |
| 2530648 | Eicher Tractor Fuel Tank Graphics Right 369 Prem. | 163  | 39199090 | 18% |
| 2530776 | Eicher Tractor Heel Rest                          | 104  | 87089900 | 18% |
| 2530910 | Eicher Tractor Foot Board Right                   | 578  | 87089900 | 18% |
| 2530922 | Eicher Tractor Cover Left                         | 152  | 87084000 | 18% |
| 2530934 | Eicher Tractor Cover Right                        | 196  | 87084000 | 18% |
| 2531057 | Eicher Tractor Pin Assy.                          | 100  | 73182100 | 18% |
| 2531082 | Eicher Tractor Foot Rest Assy                     | 496  | 87089900 | 18% |
| 2531094 | Eicher Tractor Battery Box 364/333 Dr             | 1782 | 85079090 | 28% |
| 2531124 | Eicher Tractor Cover                              | 114  | 87084000 | 18% |
| 2531239 | Eicher Tractor Shim                               | 29   | 73182100 | 18% |
| 2531240 | Eicher Tractor Spacer                             | 127  | 73182100 | 18% |
| 2531252 | Eicher Tractor Fork Pin                           | 371  | 87084000 | 18% |
| 2531264 | Eicher Tractor Leaf Spring                        | 89   | 73209090 | 18% |
| 2531276 | Eicher Tractor Bush (Hylum)                       | 132  | 87089900 | 18% |
| 2531306 | Eicher Tractor Foot Rest Assy                     | 604  | 87089900 | 18% |
| 2531409 | Eicher Tractor Starter Energization Shield        | 42   | 84099941 | 28% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 2531598 | Eicher Tractor Starter Motor Assy.                 | 9422  | 85114000 | 28% |
| 2531628 | Eicher Tractor Spacer Rod                          | 65    | 73182100 | 18% |
| 2531677 | Eicher Tractor Bonnet Pad                          | 114   | 87081010 | 18% |
| 2531689 | Eicher Tractor Bracket For Mirror                  | 84    | 70060000 | 18% |
| 2531720 | Eicher Tractor Cover Right                         | 145   | 73182100 | 18% |
| 2531975 | Eicher Tractor Washer                              | 5     | 73182100 | 18% |
| 2531987 | Eicher Tractor Foot Board Lt.                      | 760   | 87089900 | 18% |
| 2532013 | Eicher Tractor Rubber Washer                       | 13    | 40169320 | 18% |
| 2532070 | Eicher Tractor Mudguard Left 369/312P/333 /333P Wh | 12048 | 87089900 | 18% |
| 2532080 | Eicher Tractor Mudguard Right - 369/312P/333/333P  | 11393 | 87089900 | 18% |
| 2532359 | Eicher Tractor Front Weight                        | 6628  | 87081010 | 18% |
| 2532402 | Eicher Tractor Spring - 364                        | 160   | 73209090 | 18% |
| 2532440 | Eicher Tractor Front Plate                         | 204   | 87081010 | 18% |
| 2532580 | Eicher Tractor Lower Link                          | 1241  | 87089900 | 18% |
| 2532712 | Eicher Tractor Sticker Bowl Air Cleaner            | 10    | 39199090 | 18% |
| 2533017 | Eicher Tractor Brake Pedal Right                   | 675   | 87083000 | 18% |
| 2533021 | Eicher Tractor Tandem Pump Assembly                | 28623 | 84138190 | 18% |
| 2533066 | Eicher Tractor Mounting Frame                      | 2093  | 87089900 | 18% |
| 2533169 | Eicher Tractor Clutch Pedal Assy.                  | 894   | 87089300 | 18% |
| 2533194 | Eicher Tractor Clutch Pedal Assy.                  | 791   | 87089300 | 18% |
| 2533224 | Eicher Tractor Spacer Rod                          | 53    | 73182100 | 18% |
| 2533420 | Eicher Tractor Cover                               | 265   | 87084000 | 18% |
| 2533650 | Eicher Tractor Clutch Overhauling Kit (35Hp)       | 1642  | 87089300 | 18% |
| 2533716 | Eicher Tractor Clutch Plate Friction Lining(Big)   | 119   | 87089300 | 18% |
| 2533819 | Eicher Tractor Cover For G1 Strainer Hole          | 244   | 87085000 | 18% |
| 2533900 | Eicher Tractor Cap End Adaptor                     | 660   | 87089900 | 18% |
| 2534022 | Eicher Tractor Support                             | 1092  | 87084000 | 18% |
| 2534113 | Eicher Tractor Shoulder Bush                       | 715   | 87085000 | 18% |
| 2534228 | Eicher Tractor Assy.Coupling Shaft&Fork364 Export  | 1287  | 87084000 | 18% |
| 2534691 | Eicher Tractor Lower Bracket                       | 4713  | 87089900 | 18% |
| 2534745 | Eicher Tractor Link Assembly                       | 252   | 87085000 | 18% |
| 2534770 | Eicher Tractor Sticker Safety                      | 98    | 39199090 | 18% |
| 2534782 | Eicher Tractor Sticker Pto                         | 69    | 39199090 | 18% |
| 2534794 | Eicher Tractor Sticker Starter                     | 29    | 39199090 | 18% |
| 2534812 | Eicher Tractor Sticker Fuel Filter                 | 12    | 39199090 | 18% |
| 2534824 | Eicher Tractor Sticker Fuel Filter                 | 12    | 39199090 | 18% |
| 2534836 | Eicher Tractor Sticker Caution                     | 13    | 39199090 | 18% |
| 2534848 | Eicher Tractor Sticker Fuel Filter                 | 9     | 39199090 | 18% |
| 2534850 | Eicher Tractor Sticker Battery                     | 26    | 39199090 | 18% |
| 2534861 | Eicher Tractor Sticker Brake                       | 37    | 39199090 | 18% |
| 2534873 | Eicher Tractor Sticker Caution                     | 17    | 39199090 | 18% |
| 2534885 | Eicher Tractor Sticker Gear Shift                  | 13    | 39199090 | 18% |
| 2534897 | Eicher Tractor Sticker Draw-Bar                    | 25    | 39199090 | 18% |
| 2534915 | Eicher Tractor Sticker Rops                        | 30    | 39199090 | 18% |
| 2534952 | Eicher Tractor Sticker Switch Off                  | 7     | 39199090 | 18% |
| 2534976 | Eicher Tractor Sticker Hi Low                      | 13    | 39199090 | 18% |
| 2534988 | Eicher Tractor Sticker Caution                     | 19    | 39199090 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2535075 | Eicher Tractor Battery Box                         | 1576 | 85079090 | 28% |
| 2535129 | Eicher Tractor Tie Rod Assly-24Hp&Drag Rod 312/364 | 1562 | 87089400 | 18% |
| 2535166 | Eicher Tractor Drag Link Assly 241/242             | 1608 | 87089400 | 18% |
| 2535180 | Eicher Tractor Tie Rod End Left (81 Mm) (Cp2535129 | 260  | 87089400 | 18% |
| 2535191 | Eicher Tractor Tie Rod End Right (81 Mm) (Cp253512 | 528  | 87089400 | 18% |
| 2535221 | Eicher Tractor Sticker Hazard                      | 4    | 39199090 | 18% |
| 2535233 | Eicher Tractor Sticker Accelerator                 | 5    | 39199090 | 18% |
| 2535257 | Eicher Tractor Sticker Blower                      | 13   | 39199090 | 18% |
| 2535280 | Eicher Tractor Tie Rod End Left (81 Mm) (Cp2535129 | 652  | 87089400 | 18% |
| 2535282 | Eicher Tractor 11" Clutch Cover Assy               | 3046 | 87089300 | 18% |
| 2535300 | Eicher Tractor 11" Driven Disc                     | 1859 | 87089300 | 18% |
| 2535312 | Eicher Tractor Dowel Bolt M8X25                    | 29   | 73181500 | 18% |
| 2535336 | Eicher Tractor Fork And Guide Assy.                | 1678 | 87089900 | 18% |
| 2535350 | Eicher Tractor Special Stud                        | 69   | 73182100 | 18% |
| 2535361 | Eicher Tractor Hand Accelerator Rod                | 200  | 84099941 | 28% |
| 2535385 | Eicher Tractor Hand Accelerator Lever              | 83   | 87089900 | 18% |
| 2535403 | Eicher Tractor Spacer                              | 115  | 73182100 | 18% |
| 2535464 | Eicher Tractor Mounting Bracket                    | 110  | 87089900 | 18% |
| 2535476 | Eicher Tractor Foot Accelerator Pedal              | 170  | 87084000 | 18% |
| 2535482 | Eicher Tractor Spindle And Guide Assy.             | 1358 | 87089900 | 18% |
| 2535531 | Eicher Tractor Hub                                 | 456  | 87085000 | 18% |
| 2535609 | Eicher Tractor Pin                                 | 95   | 73182100 | 18% |
| 2535646 | Eicher Tractor Rear Wheel Bolt M16X1.5X56,B10.9,Bp | 70   | 73181500 | 18% |
| 2535658 | Eicher Tractor Rear Wheel Nut M-16X1.5,Zp,         | 59   | 73181500 | 18% |
| 2535968 | Eicher Tractor Washer (Wheel Bolt)                 | 15   | 73182100 | 18% |
| 2536092 | Eicher Tractor Lift Arm Rt.                        | 2659 | 87089900 | 18% |
| 2536109 | Eicher Tractor Lift Arm Lt.                        | 2888 | 87089900 | 18% |
| 2536134 | Eicher Tractor Medallion                           | 263  | 39199090 | 18% |
| 2536249 | Eicher Tractor Washer-Front Wheel Nut              | 12   | 73182100 | 18% |
| 2536250 | Eicher Tractor Front Wheel Bolt M14X1.5X51,B8.8,Bp | 40   | 73181500 | 18% |
| 2536262 | Eicher Tractor Front Wheel Hub                     | 2236 | 87087000 | 18% |
| 2536328 | Eicher Tractor Super Di Plate                      | 269  | 83100090 | 18% |
| 2536389 | Eicher Tractor Connecting Link Assy.               | 177  | 87089900 | 18% |
| 2536470 | Eicher Tractor Pin Assy.                           | 151  | 73182100 | 18% |
| 2536523 | Eicher Tractor Foot Board Right                    | 619  | 87089900 | 18% |
| 2536614 | Eicher Tractor Rigid Pipe Rod End                  | 750  | 87089900 | 18% |
| 2536675 | Eicher Tractor Medallion - 364                     | 119  | 39199090 | 18% |
| 2536780 | Eicher Tractor Plug M16                            | 5    | 87084000 | 18% |
| 2536791 | Eicher Tractor Plastic Plug M14                    | 5    | 39021000 | 18% |
| 2536894 | Eicher Tractor Turn Buckle 368                     | 77   | 87089900 | 18% |
| 2536900 | Eicher Tractor Draw Arm Link End                   | 134  | 87089900 | 18% |
| 2536912 | Eicher Tractor Pin Mounting Bracket End Link       | 285  | 73182100 | 18% |
| 2536936 | Eicher Tractor Front Wheel Nut M14X1.5,B9,Zp,(Flan | 47   | 73181500 | 18% |
| 2536950 | Eicher Tractor Upper Link - Blue                   | 1265 | 87089900 | 18% |
| 2537035 | Eicher Tractor Pin Assy (Export)                   | 110  | 73182100 | 18% |
| 2537175 | Eicher Tractor Lockable Fuel Tank Cap Assly W/Keys | 290  | 87089900 | 18% |
| 2537461 | Eicher Tractor Battery Cover 312                   | 495  | 85079090 | 28% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2537540 | Eicher Tractor Rops Sticker (Ii)                   | 74   | 39199090 | 18% |
| 2537552 | Eicher Tractor Cover Assy                          | 2360 | 87084000 | 18% |
| 2537576 | Eicher Tractor Rear Light Cover                    | 155  | 85123010 | 18% |
| 2537588 | Eicher Tractor Mounting Bracket                    | 246  | 87089900 | 18% |
| 2537590 | Eicher Tractor Cover                               | 201  | 87084000 | 18% |
| 2539159 | Eicher Tractor Wiring Harness Front                | 496  | 85441920 | 18% |
| 2539172 | Eicher Tractor Bulb 12V-21/5W For Front Light      | 99   | 85122010 | 18% |
| 2539184 | Eicher Tractor Bulb 12V-5W                         | 57   | 85122010 | 18% |
| 2539196 | Eicher Tractor 12V-21W For Front Light             | 72   | 85122010 | 18% |
| 2539226 | Eicher Tractor Lead Assy +Ve                       | 611  | 85441920 | 18% |
| 2539238 | Eicher Tractor Lead Assy -Ve                       | 506  | 85123010 | 18% |
| 2539263 | Eicher Tractor Indicator Charge                    | 143  | 85123010 | 18% |
| 2539287 | Eicher Tractor Indicator Turning                   | 144  | 85123010 | 18% |
| 2539317 | Eicher Tractor Wiring Harness Front                | 502  | 85441920 | 18% |
| 2539380 | Eicher Tractor Glass Head Light 364                | 58   | 85123010 | 18% |
| 2539410 | Eicher Tractor Mp Alternator Assy                  | 9466 | 85115000 | 28% |
| 2539421 | Eicher Tractor Flasher                             | 644  | 85122010 | 18% |
| 2539482 | Eicher Tractor Temperature Sensor(115,289 &398)    | 205  | 90268090 | 18% |
| 2539524 | Eicher Tractor Wiring Harness Front                | 456  | 85441920 | 18% |
| 2539536 | Eicher Tractor Lead Assy +Ve-241/242               | 716  | 85441920 | 18% |
| 2539548 | Eicher Tractor Igiton Switch +Fuel Tank Cap+Key P  | 469  | 87089900 | 18% |
| 2539550 | Eicher Tractor Lead Assy +Ve-312/364/368F          | 1306 | 85441920 | 18% |
| 2539561 | Eicher Tractor Sealed Brake Switch                 | 482  | 87083000 | 18% |
| 2560033 | Eicher Tractor Gasket For Suction Adaptor Of Big A | 10   | 68129090 | 18% |
| 2560045 | Eicher Tractor Rubber Washer(485)                  | 18   | 40169320 | 18% |
| 2560100 | Eicher Tractor Hydraulic Gear Pump                 | 4222 | 84138190 | 18% |
| 2560197 | Eicher Tractor Snap Ring                           | 6    | 73182910 | 18% |
| 2560203 | Eicher Tractor Washer                              | 19   | 73182100 | 18% |
| 2560215 | Eicher Tractor Clamp Upper                         | 53   | 87089900 | 18% |
| 2560227 | Eicher Tractor Grommet-Hyd Pipe                    | 34   | 40169990 | 18% |
| 2560240 | Eicher Tractor Hose Pipe-Suction Pipe              | 201  | 40093100 | 18% |
| 2560276 | Eicher Tractor Suction Pipe 28.6 O.D.              | 665  | 87089900 | 18% |
| 2560298 | Eicher Tractor Gasket For Addc Cover               | 55   | 68129090 | 18% |
| 2560300 | Eicher Tractor Cover For Power Lift Hsg.           | 941  | 87089900 | 18% |
| 2560316 | Eicher Tractor Hydraulic Shaft                     | 4521 | 87089900 | 18% |
| 2560320 | Eicher Tractor Suction Elbow                       | 413  | 40093100 | 18% |
| 2560331 | Eicher Tractor Coupling Nut L28                    | 154  | 73181500 | 18% |
| 2560365 | Eicher Tractor Mode Selector Val                   | 209  | 87089900 | 18% |
| 2560389 | Eicher Tractor O Ring 9.1X1.6                      | 13   | 40169340 | 18% |
| 2560390 | Eicher Tractor Back Up Ring 12X1X1.15 Mm           | 17   | 87089900 | 18% |
| 2560446 | Eicher Tractor O- Ring                             | 7    | 40169320 | 18% |
| 2560525 | Eicher Tractor Suction Pipe                        | 517  | 87089900 | 18% |
| 2560604 | Eicher Tractor Crank (M) - 485                     | 2945 | 87089900 | 18% |
| 2560628 | Eicher Tractor Hydraulic Shaft(485)                | 3682 | 87089900 | 18% |
| 2560630 | Eicher Tractor Connecting Rod(485)                 | 809  | 87089900 | 18% |
| 2560665 | Eicher Tractor Cylinder Assly. (Dr 2635            | 2322 | 87089900 | 18% |
| 2560689 | Eicher Tractor Bottom Cover For Addc               | 877  | 87089900 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 2560690 | Eicher Tractor Gasket For Bottom Cover Of Big Addc  | 46   | 68129090 | 18% |
| 2560707 | Eicher Tractor Suction Adaptor(485)                 | 277  | 87089900 | 18% |
| 2560719 | Eicher Tractor Strainer Assly.(485)                 | 262  | 84219900 | 18% |
| 2560732 | Eicher Tractor Value Input Rod 485                  | 53   | 87089900 | 18% |
| 2560744 | Eicher Tractor Lever(485)                           | 41   | 87089900 | 18% |
| 2560756 | Eicher Tractor Power Feed Back Rod(485)             | 152  | 87089900 | 18% |
| 2560781 | Eicher Tractor Special Bolt(485)                    | 120  | 73181500 | 18% |
| 2560793 | Eicher Tractor Special Bolt(485)                    | 112  | 73181500 | 18% |
| 2560811 | Eicher Tractor Lever(485)                           | 65   | 87089900 | 18% |
| 2560902 | Eicher Tractor Position Lever Assly.                | 122  | 87089900 | 18% |
| 2560926 | Eicher Tractor Position Lever Assly                 | 80   | 87089900 | 18% |
| 2560951 | Eicher Tractor Spool Sleeve Assembly                | 960  | 87089900 | 18% |
| 2561098 | Eicher Tractor Special Bolt                         | 90   | 73181500 | 18% |
| 2561566 | Eicher Tractor Sticker Mixed-Mode                   | 106  | 39199090 | 18% |
| 2561580 | Eicher Tractor Special Screw                        | 150  | 73181500 | 18% |
| 2561682 | Eicher Tractor Power Feed Back Rod                  | 123  | 87089900 | 18% |
| 2561700 | Eicher Tractor Lever (Mix Mode)                     | 66   | 87089900 | 18% |
| 2561736 | Eicher Tractor Bush                                 | 27   | 87089900 | 18% |
| 2561750 | Eicher Tractor Valve Input Stud (Mix Mode)          | 57   | 73182100 | 18% |
| 2561815 | Eicher Tractor Special Nut                          | 19   | 73181500 | 18% |
| 2561864 | Eicher Tractor Roller                               | 68   | 84824000 | 18% |
| 2561890 | Eicher Tractor Spt-013=Addc Piston Seal Assy. Kit 8 | 3051 | 82060090 | 18% |
| 2561992 | Eicher Tractor Special Screw                        | 17   | 73181500 | 18% |
| 2562080 | Eicher Tractor Stopper Bolt                         | 46   | 73181500 | 18% |
| 2562091 | Eicher Tractor Draft Lever Assy (Mixed Mode)        | 59   | 87089900 | 18% |
| 2562108 | Eicher Tractor Finger Tip Assy                      | 115  | 87089900 | 18% |
| 2562121 | Eicher Tractor Shaft                                | 50   | 87084000 | 18% |
| 2562145 | Eicher Tractor Lever                                | 168  | 87089900 | 18% |
| 2562194 | Eicher Tractor Feed Back Rod                        | 52   | 87089900 | 18% |
| 2562212 | Eicher Tractor Pin                                  | 30   | 73182100 | 18% |
| 2562224 | Eicher Tractor Spacer                               | 34   | 73182100 | 18% |
| 2562236 | Eicher Tractor Special Screw                        | 29   | 73181500 | 18% |
| 2562285 | Eicher Tractor Bush                                 | 18   | 87089900 | 18% |
| 2562297 | Eicher Tractor Lever Mixed-Mode                     | 23   | 87089900 | 18% |
| 2562327 | Eicher Tractor Valve Input Rod                      | 68   | 87089900 | 18% |
| 2562352 | Eicher Tractor Wood Ruff Key 3X5                    | 13   | 73182990 | 18% |
| 2562364 | Eicher Tractor Top Cover For Addc                   | 483  | 87089900 | 18% |
| 2562373 | Eicher Tractor Gasket                               | 25   | 68129090 | 18% |
| 2562390 | Eicher Tractor Lever Mixed-Mode                     | 32   | 87089900 | 18% |
| 2562595 | Eicher Tractor Cover For Addc                       | 1253 | 87089900 | 18% |
| 2562625 | Eicher Tractor Gasket Addc Top Cover Mtg            | 45   | 68129090 | 18% |
| 2562637 | Eicher Tractor Hydraulic Shaft                      | 6582 | 87089900 | 18% |
| 2562807 | Eicher Tractor Slide Ring 100 Dia                   | 223  | 39269099 | 18% |
| 2562832 | Eicher Tractor O Ring (62.87X5.33)                  | 122  | 40169320 | 18% |
| 2562856 | Eicher Tractor Cover Addc -241                      | 1878 | 87089900 | 18% |
| 2562868 | Eicher Tractor Guide Block                          | 28   | 87089900 | 18% |
| 2562870 | Eicher Tractor Lever                                | 35   | 87089900 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2562881 | Eicher Tractor Special Bolt                    | 163  | 73181500 | 18% |
| 2562893 | Eicher Tractor Special Bolt                    | 92   | 73181500 | 18% |
| 2562900 | Eicher Tractor Bush                            | 17   | 87089900 | 18% |
| 2562984 | Eicher Tractor Stopper                         | 14   | 87084000 | 18% |
| 2563048 | Eicher Tractor Cover Addc                      | 1475 | 87089900 | 18% |
| 2563050 | Eicher Tractor Dipstick Assy.                  | 69   | 87084000 | 18% |
| 2563218 | Eicher Tractor O'Ring Kit For Single Spool Prv | 312  | 40169320 | 18% |
| 2563243 | Eicher Tractor Breather Body 485               | 84   | 87089900 | 18% |
| 2563356 | Eicher Tractor Hose Pipe                       | 1565 | 40093100 | 18% |
| 2563447 | Eicher Tractor Ferrule L-12                    | 28   | 87089900 | 18% |
| 2563460 | Eicher Tractor Coupling Nut L-12               | 36   | 73181500 | 18% |
| 2563587 | Eicher Tractor Delivery Elbow                  | 428  | 87089900 | 18% |
| 2563733 | Eicher Tractor Service Line Rod End            | 479  | 87089900 | 18% |
| 2563757 | Eicher Tractor Pressure Pipe Dia 12, Cew       | 731  | 87089900 | 18% |
| 2563769 | Eicher Tractor Return Line Pipe Dia 15, Cew    | 828  | 87089900 | 18% |
| 2563770 | Eicher Tractor Screw Stud                      | 95   | 73181500 | 18% |
| 2563782 | Eicher Tractor Ball Rod                        | 201  | 87089400 | 18% |
| 2563794 | Eicher Tractor Turn Rod                        | 59   | 87089900 | 18% |
| 2563800 | Eicher Tractor Spring Lock                     | 4    | 73202000 | 18% |
| 2563861 | Eicher Tractor Clamp                           | 97   | 87089900 | 18% |
| 2563873 | Eicher Tractor Sealing Washer 21X26            | 14   | 73182990 | 18% |
| 2563885 | Eicher Tractor Feed Back Stud                  | 172  | 73182100 | 18% |
| 2563915 | Eicher Tractor Filter Adaptor                  | 96   | 84219900 | 18% |
| 2563927 | Eicher Tractor O Ring 17.17X1.78               | 86   | 40169340 | 18% |
| 2563976 | Eicher Tractor Bkt. Assy. (485)                | 1020 | 87089900 | 18% |
| 2564099 | Eicher Tractor O-Ring 16.36X2.2                | 13   | 40169320 | 18% |
| 2564117 | Eicher Tractor Lever                           | 46   | 87089900 | 18% |
| 2564130 | Eicher Tractor Sticker (Top Link Bkt)          | 44   | 39199090 | 18% |
| 2564154 | Eicher Tractor Pin                             | 11   | 73182100 | 18% |
| 2564166 | Eicher Tractor O Ring (72.39 X 5.33) 90 Dia    | 144  | 40169320 | 18% |
| 2564210 | Eicher Tractor Pump Mounting Bracket           | 2043 | 84099941 | 28% |
| 2564221 | Eicher Tractor Locating Spacer                 | 229  | 87089900 | 18% |
| 2564233 | Eicher Tractor Extension Shaft                 | 510  | 87089900 | 18% |
| 2564245 | Eicher Tractor Hydraulic Gear Pump             | 5731 | 84138190 | 18% |
| 2564439 | Eicher Tractor Gasket For G2/Addc Joint        | 36   | 68129090 | 18% |
| 2564440 | Eicher Tractor Check Valve Seat                | 148  | 87089900 | 18% |
| 2564452 | Eicher Tractor Retainer M20X1                  | 116  | 87089900 | 18% |
| 2564555 | Eicher Tractor Snapping                        | 17   | 73182990 | 18% |
| 2564580 | Eicher Tractor Dipstick Addc 485               | 68   | 87089900 | 18% |
| 2564610 | Eicher Tractor Lever                           | 46   | 87089900 | 18% |
| 2564622 | Eicher Tractor Lever                           | 47   | 87089900 | 18% |
| 2564634 | Eicher Tractor Lever Assy                      | 84   | 87089900 | 18% |
| 2564646 | Eicher Tractor Lever                           | 73   | 87089900 | 18% |
| 2564658 | Eicher Tractor Bush                            | 23   | 87089900 | 18% |
| 2564660 | Eicher Tractor Power Feed Back Rod             | 155  | 87089900 | 18% |
| 2564671 | Eicher Tractor Vale Input Rod                  | 77   | 87089900 | 18% |
| 2564695 | Eicher Tractor Guide Block                     | 30   | 87089900 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2564762 | Eicher Tractor Plug                                | 57   | 87084000 | 18% |
| 2564786 | Eicher Tractor Shaft                               | 57   | 87089900 | 18% |
| 2564798 | Eicher Tractor Special Bolt(485)                   | 158  | 73181500 | 18% |
| 2564830 | Eicher Tractor Bush Hyd.Shaft 45*50*50             | 1002 | 87089900 | 18% |
| 2564841 | Eicher Tractor Bush Hyd.Shaft 55*55*50             | 1470 | 87089900 | 18% |
| 2564853 | Eicher Tractor Breather Body 485                   | 94   | 87089900 | 18% |
| 2564877 | Eicher Tractor Sleeve                              | 487  | 87089900 | 18% |
| 2564919 | Eicher Tractor Retainer M16X1                      | 65   | 87089900 | 18% |
| 2564981 | Eicher Tractor Special Bolt                        | 171  | 73181500 | 18% |
| 2565158 | Eicher Tractor Feed Back Rod                       | 58   | 87089900 | 18% |
| 2565164 | Eicher Tractor Power Input Rod                     | 55   | 87089900 | 18% |
| 2565171 | Eicher Tractor Position Input Rod                  | 65   | 87089900 | 18% |
| 2565225 | Eicher Tractor Rod                                 | 245  | 87089900 | 18% |
| 2565304 | Eicher Tractor Bush                                | 23   | 87089900 | 18% |
| 2565330 | Eicher Tractor Bearing Spacer (Outer)              | 83   | 84822090 | 18% |
| 2565341 | Eicher Tractor Deep Grove Ball Bearing 6206 2Zr C3 | 364  | 84822090 | 18% |
| 2565444 | Eicher Tractor Suction Pipe                        | 568  | 87089900 | 18% |
| 2565663 | Eicher Tractor Sleeve                              | 920  | 87084000 | 18% |
| 2565675 | Eicher Tractor Sector Plate Mounting Flange        | 551  | 73259999 | 18% |
| 2565705 | Eicher Tractor Oil Filter Assy(Big)                | 272  | 84219900 | 18% |
| 2565833 | Eicher Tractor Special Bolt                        | 143  | 73181500 | 18% |
| 2565870 | Eicher Tractor Pressure Pipe                       | 651  | 87089900 | 18% |
| 2565882 | Eicher Tractor Progressive Ferrule L-16            | 76   | 73072100 | 18% |
| 2565894 | Eicher Tractor Progressive Ferrule L- 28           | 172  | 87089900 | 18% |
| 2565914 | Eicher Tractor Lever                               | 130  | 87089900 | 18% |
| 2565924 | Eicher Tractor Bracket Assy -485                   | 1165 | 87089900 | 18% |
| 2565973 | Eicher Tractor Gakset For Pump Engine Mtg          | 17   | 68129090 | 18% |
| 2565997 | Eicher Tractor Coupling                            | 214  | 87089900 | 18% |
| 2566072 | Eicher Tractor Bracket Assy .(Mixed Mode)          | 659  | 87089900 | 18% |
| 2566140 | Eicher Tractor Suction Pipe                        | 542  | 87089900 | 18% |
| 2566151 | Eicher Tractor Pressure Pipe                       | 796  | 84099941 | 28% |
| 2566187 | Eicher Tractor Linkage Assy-241                    | 1726 | 87083000 | 18% |
| 2566199 | Eicher Tractor Hydraulic Shaft                     | 3576 | 87089900 | 18% |
| 2566242 | Eicher Tractor V-Seal                              | 52   | 40169990 | 18% |
| 2566291 | Eicher Tractor Bracket                             | 695  | 87089900 | 18% |
| 2566448 | Eicher Tractor Blower Support(Auto)                | 1510 | 84091000 | 28% |
| 2566473 | Eicher Tractor Gear For Hyd Pump-24Hp              | 1012 | 84099941 | 28% |
| 2566527 | Eicher Tractor Coupler (Filter End)                | 288  | 84219900 | 18% |
| 2566539 | Eicher Tractor Reather Body                        | 58   | 87089900 | 18% |
| 2566540 | Eicher Tractor Addc Cover                          | 2476 | 87089900 | 18% |
| 2566552 | Eicher Tractor Breather Adopter                    | 72   | 87089900 | 18% |
| 2566590 | Eicher Tractor Dipstick                            | 66   | 87084000 | 18% |
| 2566886 | Eicher Tractor Lower Plate                         | 37   | 87089900 | 18% |
| 2566899 | Eicher Tractor Clamp Upper                         | 56   | 87089900 | 18% |
| 2567090 | Eicher Tractor Breather                            | 245  | 84212190 | 18% |
| 2567143 | Eicher Tractor Pressure Pipe -312/364              | 1359 | 87089900 | 18% |
| 2567236 | Eicher Tractor Pipe Assy For T.T                   | 702  | 87089900 | 18% |





|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 2567295 | Eicher Tractor Hose Return                         | 102   | 40093100 | 18% |
| 2567313 | Eicher Tractor Axillary Valve                      | 10331 | 87089900 | 18% |
| 2567337 | Eicher Tractor Se Adaptor 3/8"                     | 116   | 87084000 | 18% |
| 2567398 | Eicher Tractor Plug                                | 162   | 87084000 | 18% |
| 2567404 | Eicher Tractor Adopter With Nut                    | 260   | 73181500 | 18% |
| 2567477 | Eicher Tractor Closing Screw                       | 24    | 73181500 | 18% |
| 2567489 | Eicher Tractor Breather Pipe                       | 236   | 87084000 | 18% |
| 2567490 | Eicher Tractor Spool Sleeve Assy.                  | 1216  | 87089900 | 18% |
| 2567507 | Eicher Tractor Spool Sleeve Assy.                  | 1093  | 87089900 | 18% |
| 2567684 | Eicher Tractor Strainer Housing                    | 810   | 84219900 | 18% |
| 2567854 | Eicher Tractor Spring Plate,90                     | 1439  | 87089900 | 18% |
| 2567982 | Eicher Tractor Lift Actuator (With Mode Selector V | 5943  | 84818049 | 28% |
| 2568068 | Eicher Tractor Ale Stud Connector                  | 275   | 87085000 | 18% |
| 2568070 | Eicher Tractor Lever                               | 36    | 87089900 | 18% |
| 2568329 | Eicher Tractor Plastic Bush Small                  | 101   | 39021000 | 18% |
| 2568330 | Eicher Tractor Plastic Bush Big                    | 90    | 39021000 | 18% |
| 2568378 | Eicher Tractor Piston (100 Dia)                    | 1224  | 87089900 | 18% |
| 2568433 | Eicher Tractor Addc Bracket                        | 999   | 87089900 | 18% |
| 2568457 | Eicher Tractor Addc Cover - 242 Super Star         | 2461  | 87089900 | 18% |
| 2568470 | Eicher Tractor Bush Hyd.Shaft-45*50*40             | 984   | 87089900 | 18% |
| 2568482 | Eicher Tractor Bush Hyd.Shaft 50*55*40             | 724   | 87089900 | 18% |
| 2600055 | Eicher Tractor Lay Shaft                           | 2504  | 87084000 | 18% |
| 2600134 | Eicher Tractor Md Plate For Dual Clutch            | 5732  | 87089300 | 18% |
| 2600146 | Eicher Tractor Pto Shaft -368Dc                    | 2029  | 87084000 | 18% |
| 2600183 | Eicher Tractor Engaging Handle                     | 523   | 87084000 | 18% |
| 2600195 | Eicher Tractor Engaging Dog                        | 412   | 87084000 | 18% |
| 2600201 | Eicher Tractor Bush For Crankshaft                 | 235   | 84839000 | 18% |
| 2600213 | Eicher Tractor Sliding Piece                       | 50    | 87089900 | 18% |
| 2600250 | Eicher Tractor Gasket For Window Cover             | 25    | 68129090 | 18% |
| 2600298 | Eicher Tractor Gasket For End Cover                | 14    | 68129090 | 18% |
| 2600304 | Eicher Tractor Gasket For Sleeve                   | 17    | 68129090 | 18% |
| 2600328 | Eicher Tractor Flange For Flywheel Housing         | 249   | 87084000 | 18% |
| 2600377 | Eicher Tractor Steering Gear Support               | 1302  | 87089400 | 18% |
| 2600550 | Eicher Tractor Pto Redn. Assy-540 (364 Exports)    | 14359 | 87084000 | 18% |
| 2653412 | Eicher Tractor O Ring 23.7X2.8                     | 23    | 40169340 | 18% |
| 2654076 | Eicher Tractor Front Cover                         | 179   | 40169330 | 18% |
| 2654349 | Eicher Tractor Tank Top Support                    | 269   | 87089900 | 18% |
| 2654350 | Eicher Tractor Tank Bottom Support                 | 135   | 87089900 | 18% |
| 2654362 | Eicher Tractor Main Mtg. Bracket                   | 539   | 87089900 | 18% |
| 2654374 | Eicher Tractor Tank Cover Support Lt               | 122   | 87089900 | 18% |
| 2654386 | Eicher Tractor Tank Cover Support Rt               | 122   | 87089900 | 18% |
| 2654398 | Eicher Tractor Bonnet Mtg. Bkt.Lt                  | 243   | 87089900 | 18% |
| 2654404 | Eicher Tractor Bonnet Mtg. Bkt.Rt                  | 207   | 87089900 | 18% |
| 2655846 | Eicher Tractor Cover For Brake Hsg                 | 73    | 87083000 | 18% |
| 2670010 | Eicher Tractor Split Pin 2.5X20                    | 2     | 73182100 | 18% |
| 2670033 | Eicher Tractor Needle Bush DI 2820                 | 228   | 87089400 | 18% |
| 2670082 | Eicher Tractor Oil Seal 72X50X10                   | 85    | 40169330 | 18% |



|         |  |     |          |     |
|---------|--|-----|----------|-----|
| 2670197 | Eicher Tractor Needle Roller & Cage Assy(20X28X20. | 140 | 84824000 | 18% |
| 2670203 | Eicher Tractor Ndl Cg Brg 25*33*20                 | 524 | 84824000 | 18% |
| 2670264 | Eicher Tractor Needle Cage B18X25X22.2             | 73  | 84822090 | 18% |
| 2670288 | Eicher Tractor Hose Clamp A45                      | 20  | 73269099 | 18% |
| 2670586 | Eicher Tractor Spring Washer A-20,'Flat',Zp,       | 15  | 73182990 | 18% |
| 2670590 | Eicher Tractor Deep Groove Ball Bearing 6308       | 751 | 84821011 | 18% |
| 2670604 | Eicher Tractor Deep Groove Ball Bearing 6209       | 505 | 84821011 | 18% |
| 2670626 | Eicher Tractor Oil Seal 41X62X11.9                 | 57  | 40169330 | 18% |
| 2670720 | Eicher Tractor Hex Screw M-8X60,B10.9,(4140),Bp    | 15  | 73181500 | 18% |
| 2670732 | Eicher Tractor Hex Thin Nut M10X1.25,Lh,B8,Zp(Gree | 24  | 73181500 | 18% |
| 2670770 | Eicher Tractor Hex Nut M20X2.5,B8,Zp,              | 47  | 73181500 | 18% |
| 2670781 | Eicher Tractor Circlip Light A-18                  | 12  | 73182910 | 18% |
| 2670793 | Eicher Tractor Circlip Light A-22                  | 12  | 73182910 | 18% |
| 2670987 | Eicher Tractor Hex Screw M16X1.5X55,B8.8,Zp,       | 46  | 73181500 | 18% |
| 2671037 | Eicher Tractor O Ring 10X2.4 Shore A 70 Nbr        | 12  | 40169340 | 18% |
| 2671128 | Eicher Tractor Hex Screw M8X65,B8.8,Zp,            | 15  | 73181500 | 18% |
| 2671129 | Eicher Tractor Oil Seal 12*22*7                    | 81  | 40169330 | 18% |
| 2671141 | Eicher Tractor Oil Seal 50X72X8                    | 153 | 40169990 | 18% |
| 2671177 | Eicher Tractor Oil Seal Type Second 63X85X10       | 158 | 40169330 | 18% |
| 2671185 | Eicher Tractor Thrust Bearing 51108                | 449 | 84821051 | 18% |
| 2671232 | Eicher Tractor Hex Bolt M16*130 Sfs 2063 M 10.9    | 113 | 73181500 | 18% |
| 2671256 | Eicher Tractor Core Plug B16 St Zne Din 443        | 15  | 84099941 | 28% |
| 2671268 | Eicher Tractor Seal Ring A 10*13 Din 7603-AI       | 3   | 76061110 | 18% |
| 2671270 | Eicher Tractor Hex Screw M8*16 Sfs 2064 M8.8 Zne   | 7   | 73181500 | 18% |
| 2671293 | Eicher Tractor Core Plug B 40 St Zne Din 443       | 29  | 84099941 | 28% |
| 2671300 | Eicher Tractor Spring Washer B8 Din 137            | 11  | 73182990 | 18% |
| 2671311 | Eicher Tractor Screw M8*35 Sfs 2064 M8.8           | 10  | 73181500 | 18% |
| 2671323 | Eicher Tractor Plug M12X1.5 Din 910-5.8            | 38  | 84099941 | 28% |
| 2671360 | Eicher Tractor Hex Screw M5 Sfs 2064 M8.8 Zne      | 5   | 73181500 | 18% |
| 2671384 | Eicher Tractor Spring Cotter 13X16                 | 27  | 73209090 | 18% |
| 2671396 | Eicher Tractor Hesoc Screw M12*35 Sfs 2219 12.9    | 47  | 73181500 | 18% |
| 2671402 | Eicher Tractor Hex Screw M12*35 Sfs 2064 M 10      | 30  | 73181500 | 18% |
| 2671414 | Eicher Tractor Hex Screw M10*25 Sfs 2064 M 8.8     | 15  | 73181500 | 18% |
| 2671426 | Eicher Tractor Spring Cotter 5*10 Din 1481         | 15  | 73209090 | 18% |
| 2671438 | Eicher Tractor Lifting Eye M12 Din 580             | 245 | 84099941 | 28% |
| 2671440 | Eicher Tractor Hex Screw M10*20 Sfs 2064 M8.8      | 14  | 73181500 | 18% |
| 2671463 | Eicher Tractor Nut For Rocker Secrew               | 14  | 84099941 | 28% |
| 2671475 | Eicher Tractor Stud Bolt M10*75 Din 939 8.8        | 40  | 73181500 | 18% |
| 2671487 | Eicher Tractor Hex Screw M10*80 Sfs 2063 M8.8      | 32  | 73181500 | 18% |
| 2671499 | Eicher Tractor Woodruff Key 6*9 Din 6888           | 31  | 73182990 | 18% |
| 2671505 | Eicher Tractor Hex Bolt M8*45 Sfs 2063 M8.8        | 12  | 73181500 | 18% |
| 2671517 | Eicher Tractor Stud Bolt M8*20 Din 939 8.8         | 16  | 73181500 | 18% |
| 2671529 | Eicher Tractor Hex Bolt M8*50 Sfs 2063 M8.8        | 13  | 73181500 | 18% |
| 2671530 | Eicher Tractor Hex Screw M8*25 Sfs 2064 M8.8       | 5   | 73181500 | 18% |
| 2671554 | Eicher Tractor Hex Bolt M14*85 Din 931 10.0        | 59  | 73181500 | 18% |
| 2671566 | Eicher Tractor O-Ring 15.3 *2.4 Nitrub             | 5   | 40169320 | 18% |
| 2671578 | Eicher Tractor O-Ring For Oil Filling Plug         | 13  | 40169320 | 18% |



|         |   |      |          |     |
|---------|---|------|----------|-----|
| 2671580 | Eicher Tractor Hex Screw M8*20 Sfs 2064 M8.8 Zne  | 9    | 73181500 | 18% |
| 2671591 | Eicher Tractor Hex Bolt M8*60 Sfs 2063 M8.8       | 13   | 73181500 | 18% |
| 2671608 | Eicher Tractor Circlip 31*1.2 Din472              | 13   | 73182910 | 18% |
| 2671610 | Eicher Tractor Hex Bolt M8*55 Din 931 8.8         | 11   | 73181500 | 18% |
| 2671621 | Eicher Tractor Hex Screw M6X10 Sfs 2064 M8.8      | 3    | 73181500 | 18% |
| 2671633 | Eicher Tractor Hex Bolt M8*75 Sfs 2063 M8.8       | 15   | 73181500 | 18% |
| 2671645 | Eicher Tractor Hex Nut M10 Sfs 2067 M10           | 14   | 73181600 | 18% |
| 2671657 | Eicher Tractor Connector L15M Din 3901 Slota      | 167  | 84099941 | 28% |
| 2671669 | Eicher Tractor Connector L22M Din 3901 Slota      | 249  | 84099941 | 28% |
| 2671670 | Eicher Tractor Olive L15 Din 3861-St              | 100  | 84099941 | 28% |
| 2671682 | Eicher Tractor Union Nut Al15 Din 3870-St         | 140  | 73181500 | 18% |
| 2671694 | Eicher Tractor Olive L22 Din 3861                 | 108  | 84099941 | 28% |
| 2671700 | Eicher Tractor Hex Screw M6*20 Sfs 2064 M8.8 Zne  | 5    | 73181500 | 18% |
| 2671724 | Eicher Tractor Stud Bolt M10*110 Din 939 8.8      | 48   | 73181500 | 18% |
| 2671736 | Eicher Tractor Hex Bolt M10*100 Sfs 2063 M 8.8(F) | 45   | 73181500 | 18% |
| 2671748 | Eicher Tractor Hex Bolt M8X70,B8.8-Zn-Sfs 2063    | 21   | 73181500 | 18% |
| 2671750 | Eicher Tractor Hollow Screw Din 7643-10 (St)      | 40   | 73181500 | 18% |
| 2671761 | Eicher Tractor Hex Screw M8*30 Sfs 2064 M 8.8     | 10   | 73181500 | 18% |
| 2671840 | Eicher Tractor Stud Bolt M10*30 Din939 8.8        | 16   | 73181500 | 18% |
| 2671876 | Eicher Tractor Hollow Screw Din 7643-6            | 24   | 73181500 | 18% |
| 2671888 | Eicher Tractor Hex Screw M6*16 Sfs 2064 M8.8      | 5    | 73181500 | 18% |
| 2671918 | Eicher Tractor O-Ring Water Pump                  | 14   | 40169320 | 18% |
| 2671979 | Eicher Tractor Hex Screw M10*55 8.8 Zne           | 16   | 73181500 | 18% |
| 2671980 | Eicher Tractor Hex Screw M10*30 10.9              | 14   | 73181500 | 18% |
| 2671992 | Eicher Tractor Hex Screw M10X35,B10,9,Zp          | 15   | 73181500 | 18% |
| 2672005 | Eicher Tractor Hshc Screw M8X60                   | 16   | 73181500 | 18% |
| 2672091 | Eicher Tractor Split Pin 3.2*20                   | 4    | 73182100 | 18% |
| 2672170 | Eicher Tractor Circlip 52*2                       | 15   | 73182910 | 18% |
| 2672194 | Eicher Tractor Dg Ball Bearing 6304 - 2Zr C3      | 387  | 84821020 | 18% |
| 2672236 | Eicher Tractor Dg Ball Bearing 6011 2Rs           | 727  | 84219900 | 18% |
| 2672327 | Eicher Tractor Grease Nipple Am8*1                | 11   | 87089900 | 18% |
| 2672339 | Eicher Tractor Oil Seal 25X33X4 Ina               | 83   | 87089900 | 18% |
| 2672340 | Eicher Tractor Needle Bearing 25*33*20            | 637  | 84824000 | 18% |
| 2672376 | Eicher Tractor O Ring 44.2X3                      | 23   | 40169320 | 18% |
| 2672388 | Eicher Tractor Oil Seal A25X35X7 Din 3760         | 66   | 40169330 | 18% |
| 2672390 | Eicher Tractor O Ring ( 2X1.0)                    | 15   | 40169340 | 18% |
| 2672406 | Eicher Tractor Tapper Roller Brg 31310            | 2040 | 84822090 | 18% |
| 2672420 | Eicher Tractor Shim 90X110X0.3 Din 988            | 10   | 73182100 | 18% |
| 2672431 | Eicher Tractor Shim 90X110X0.5 Din 988            | 11   | 73182100 | 18% |
| 2672443 | Eicher Tractor Shim 90X110X0.15 Din 988           | 9    | 73182100 | 18% |
| 2672467 | Eicher Tractor Tapper Roller Brg. 31307           | 1298 | 84822090 | 18% |
| 2672479 | Eicher Tractor Lock Nut M35 * 1.5                 | 80   | 73181500 | 18% |
| 2672480 | Eicher Tractor O Ring 24.2X3 -70Sh Sms1586        | 16   | 40169320 | 18% |
| 2672510 | Eicher Tractor Tapper Roller Brg. 32007X          | 760  | 84822090 | 18% |
| 2672560 | Eicher Tractor Needle Bearing 47*53*24.8          | 772  | 84822090 | 18% |
| 2672625 | Eicher Tractor Needle Bush Hk-2520                | 107  | 84822090 | 18% |
| 2672649 | Eicher Tractor Tapper Roller Brg. 32013X          | 1512 | 84822090 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2672662 | Eicher Tractor Spring Dowel 6X50                 | 10   | 73182100 | 18% |
| 2672686 | Eicher Tractor Circlip A22 Light                 | 7    | 73182910 | 18% |
| 2672698 | Eicher Tractor Spring Dowel Sleeve 4X14          | 4    | 73182100 | 18% |
| 2672716 | Eicher Tractor O Ring 84.5X3 Nbr N70             | 73   | 40169340 | 18% |
| 2672807 | Eicher Tractor Union All 6 Din 2353              | 85   | 73079990 | 18% |
| 2672856 | Eicher Tractor O-Ring 89.5X3                     | 26   | 40169320 | 18% |
| 2672868 | Eicher Tractor Union Ell 6 Din2353               | 113  | 73079990 | 18% |
| 2672881 | Eicher Tractor Hex Bolt M16X60,B10.9 -Zn         | 39   | 73181500 | 18% |
| 2672911 | Eicher Tractor Plug M24X1.5 Din 910              | 88   | 85122010 | 18% |
| 2672935 | Eicher Tractor Hex Nut M16X1.5,B10 Din 939       | 29   | 73181500 | 18% |
| 2672996 | Eicher Tractor Spring Dowel 5X36                 | 14   | 73182100 | 18% |
| 2673009 | Eicher Tractor Circlip Rw80                      | 14   | 73182910 | 18% |
| 2673010 | Eicher Tractor Nylock Nut M10                    | 13   | 73181500 | 18% |
| 2673022 | Eicher Tractor Oil Seal 20X30X7                  | 109  | 40169990 | 18% |
| 2673058 | Eicher Tractor Spring Dowel 5X30                 | 7    | 73182100 | 18% |
| 2673083 | Eicher Tractor Spring Dowel 8X30                 | 9    | 73182100 | 18% |
| 2673113 | Eicher Tractor Belliveli Sp.31.5*16.3*0.8        | 13   | 73182910 | 18% |
| 2673137 | Eicher Tractor Spring Dowel 5X24                 | 5    | 73182100 | 18% |
| 2673149 | Eicher Tractor Tapper Rpler Brg. 32016X          | 3705 | 84822090 | 18% |
| 2673162 | Eicher Tractor Taper Roller Brg.30215            | 1568 | 84822090 | 18% |
| 2673186 | Eicher Tractor Needle Rollers 3.5X19.8 Br Nadela | 4    | 84824000 | 18% |
| 2673320 | Eicher Tractor Dg Ball Bearing 6306              | 436  | 84821011 | 18% |
| 2673332 | Eicher Tractor Dg Ball Bearing 6306Rs            | 558  | 84822090 | 18% |
| 2673344 | Eicher Tractor Circlip 20*1                      | 5    | 73182910 | 18% |
| 2673356 | Eicher Tractor O-Ring 17.1X1.6                   | 10   | 40169990 | 18% |
| 2673381 | Eicher Tractor O-Ring 20.1X1.6                   | 13   | 40169320 | 18% |
| 2673400 | Eicher Tractor Hshc Screw M20X160,B12.9          | 286  | 73181500 | 18% |
| 2673423 | Eicher Tractor Support Ring 50X62X3-Din 988      | 78   | 40169320 | 18% |
| 2673435 | Eicher Tractor Support Ring 50X62X0.1-Din 988    | 10   | 40169320 | 18% |
| 2673472 | Eicher Tractor Joint Casing Assy                 | 90   | 87089900 | 18% |
| 2673526 | Eicher Tractor Nylock Nut M5                     | 6    | 73181500 | 18% |
| 2673540 | Eicher Tractor Nylock Nut M8 -Zn                 | 8    | 73181500 | 18% |
| 2673630 | Eicher Tractor Grease Nipple Cm10*1              | 17   | 87089900 | 18% |
| 2673642 | Eicher Tractor Hex Screw M6*40 8.8 Zne           | 5    | 73181500 | 18% |
| 2673708 | Eicher Tractor Hex Screw M16*50 Din 933          | 39   | 73181500 | 18% |
| 2673710 | Eicher Tractor Hex Screw M20X2.5X60,B8.8,Zp,     | 86   | 73181500 | 18% |
| 2673745 | Eicher Tractor Hex Bolt M12*60 8.8 Zne           | 22   | 73181500 | 18% |
| 2673782 | Eicher Tractor Hex Bolt M16*120 8.8 Zne          | 81   | 73181500 | 18% |
| 2673848 | Eicher Tractor Hex Bolt M10*90 8.8 Zne           | 23   | 73181500 | 18% |
| 2674142 | Eicher Tractor Nut M12                           | 15   | 73181500 | 18% |
| 2674154 | Eicher Tractor Nylock Nut M16                    | 31   | 73181500 | 18% |
| 2674166 | Eicher Tractor Nylock Nut M20                    | 63   | 73181500 | 18% |
| 2674233 | Eicher Tractor Castle Nut M14*1.5                | 35   | 73181500 | 18% |
| 2674245 | Eicher Tractor Castle Nut M30*2                  | 176  | 73181500 | 18% |
| 2674350 | Eicher Tractor Split Pin 3.2*28                  | 5    | 73182100 | 18% |
| 2674567 | Eicher Tractor Inlet Ring 37X47X1 - Din 988      | 16   | 87089900 | 18% |
| 2674580 | Eicher Tractor Oil Seals 57*85*12                | 216  | 40169990 | 18% |



|         |  |      |          |     |
|---------|--|------|----------|-----|
| 2674609 | Eicher Tractor O Ring 41.2X3                       | 23   | 40169320 | 18% |
| 2674610 | Eicher Tractor O Ring 48.5X3                       | 22   | 40169320 | 18% |
| 2674695 | Eicher Tractor Needle Cage Lr35*40*20.5            | 491  | 84822090 | 18% |
| 2674713 | Eicher Tractor Needle Bearing Jr 17X22X13          | 250  | 84822090 | 18% |
| 2674725 | Eicher Tractor Hose Clamp 75                       | 24   | 73269099 | 18% |
| 2674737 | Eicher Tractor Hose Clamp A-55                     | 27   | 73269099 | 18% |
| 2674830 | Eicher Tractor Inlet Ring 37X47X2.5 - Din988       | 40   | 87089900 | 18% |
| 2674889 | Eicher Tractor Hex Bolt M8 X 60 Din 9311 Znp       | 12   | 73181500 | 18% |
| 2674970 | Eicher Tractor Hshc Screw M10X30,B12.9             | 18   | 73181500 | 18% |
| 2674981 | Eicher Tractor Cr.Rec.Hd.Screw M16X12              | 19   | 73181500 | 18% |
| 2675031 | Eicher Tractor Spring Dowel Sleeve 6X70            | 19   | 73182100 | 18% |
| 2675079 | Eicher Tractor Circlip 65*2.5                      | 36   | 73182910 | 18% |
| 2675109 | Eicher Tractor Circlip 72*2.5                      | 40   | 73182910 | 18% |
| 2675110 | Eicher Tractor Circlip 24*1.2                      | 7    | 73182910 | 18% |
| 2675122 | Eicher Tractor Circlip 31*1.2                      | 11   | 73182910 | 18% |
| 2675134 | Eicher Tractor Oil Seal A8*22*7                    | 107  | 40169990 | 18% |
| 2675158 | Eicher Tractor Gasket Seal                         | 29   | 40169390 | 18% |
| 2675183 | Eicher Tractor Seal Glyd Ring For Dia 100          | 1395 | 87089900 | 18% |
| 2675213 | Eicher Tractor O Ring 22.2X3-65Sh                  | 13   | 40169320 | 18% |
| 2675249 | Eicher Tractor O Ring 17.3X2.4 Shore 70 Nrb        | 12   | 40169320 | 18% |
| 2675250 | Eicher Tractor Ring 94.5X3                         | 27   | 40169320 | 18% |
| 2675286 | Eicher Tractor O Ring 14.3X2.4                     | 11   | 40169320 | 18% |
| 2675298 | Eicher Tractor O Ring 23X2.5                       | 17   | 40169320 | 18% |
| 2675304 | Eicher Tractor O Ring 15.3X2.4 90Sh                | 19   | 40169320 | 18% |
| 2675330 | Eicher Tractor O Ring 16.3X2.4-90Sh                | 29   | 40169320 | 18% |
| 2675353 | Eicher Tractor Bearing Pm 6560 Dx                  | 1065 | 84822090 | 18% |
| 2675432 | Eicher Tractor Hesoc Plug M10*1-5.8 Din 908        | 25   | 84099941 | 28% |
| 2675444 | Eicher Tractor Hshc Screw M12X1.25X35 Sfs 2219     | 50   | 73181500 | 18% |
| 2675511 | Eicher Tractor Hex Bolt M10X165,B8.8,Zp,(F)        | 66   | 73181500 | 18% |
| 2675535 | Eicher Tractor Hex Screw M10X20,B10.9 Bp           | 10   | 73181500 | 18% |
| 2675547 | Eicher Tractor O Ring 81.92X5.33                   | 109  | 40169320 | 18% |
| 2675584 | Eicher Tractor Multi Tooth Washer B5.3             | 3    | 73182100 | 18% |
| 2675596 | Eicher Tractor Hex Bolt M10X35,B10.9,Zp            | 16   | 73181500 | 18% |
| 2675717 | Eicher Tractor H.Skt Grub Screw M10X30(Type-G,Is60 | 45   | 73181500 | 18% |
| 2675729 | Eicher Tractor Oil Seal 45X62X8                    | 136  | 40169990 | 18% |
| 2675894 | Eicher Tractor Cogged Belt 1100 Mm (3 Cly A/Cooled | 445  | 39199090 | 18% |
| 2675961 | Eicher Tractor Pre Filter Mico Part No(1457434002) | 689  | 84219900 | 18% |
| 2675997 | Eicher Tractor D.G.Ball Bearing 6211N              | 863  | 84821012 | 18% |
| 2676035 | Eicher Tractor Hesoc Screw M10X16 Sfs 2219, 8.8    | 15   | 73181500 | 18% |
| 2676187 | Eicher Tractor Hex Bolt M12X110,B8.8-Zn            | 43   | 73181500 | 18% |
| 2676200 | Eicher Tractor Hex Bolt M12X75 Sfs 2063 M8.8       | 37   | 73181500 | 18% |
| 2676229 | Eicher Tractor Hex Bolt M10X140 Sfs 2063 M8.8      | 46   | 73181500 | 18% |
| 2676230 | Eicher Tractor Hex Bolt M8X140 Sfs 2063 M8.8       | 27   | 73181500 | 18% |
| 3025601 | Eicher Tractor Radiator Coolant                    | 333  | 27101980 | 18% |
| 3051791 | Eicher Tractor Lead Seal 1/2"                      | 1028 | 39269099 | 18% |
| 3052084 | Eicher Tractor Sealing Wire                        | 1028 | 73202000 | 18% |
| 3110059 | Eicher Tractor Vacuator Valve                      | 139  | 87089900 | 18% |



|         |  |       |          |     |
|---------|--|-------|----------|-----|
| 3110060 | Eicher Tractor Adoptor                             | 185   | 87089900 | 18% |
| 3130010 | Eicher Tractor Crank Housing Mcd                   | 40727 | 84831092 | 18% |
| 3150124 | Eicher Tractor Thrasher Guard Straight Bonnet      | 2497  | 87089900 | 18% |
| 3310012 | Eicher Tractor Mudguard Graphic-242                | 93    | 39199090 | 18% |
| 3310061 | Eicher Tractor Double Triangle Sticker Left        | 361   | 39199090 | 18% |
| 3320017 | Eicher Tractor Indicating Unit                     | 463   | 85122010 | 18% |
| 3330060 | Eicher Tractor Bonnet Sticker Front                | 353   | 39199090 | 18% |
| 3330096 | Eicher Tractor Fuel Tank Sticker Lh                | 158   | 39199090 | 18% |
| 3330102 | Eicher Tractor Fuel Tank Sticker Rh                | 158   | 39199090 | 18% |
| 3330114 | Eicher Tractor Name Plate Eicher-364 Lh            | 880   | 39199090 | 18% |
| 3330126 | Eicher Tractor Name Plate Eicher-364 Rh            | 884   | 39199090 | 18% |
| 3340030 | Eicher Tractor Plate For Safety Switch             | 44    | 87083000 | 18% |
| 3550450 | Eicher Tractor Plain Washer 14X28X3                | 10    | 73182100 | 18% |
| 3550953 | Eicher Tractor Bracket Big                         | 123   | 84099941 | 28% |
| 3550965 | Eicher Tractor Bracket Small                       | 77    | 84099941 | 28% |
| 3551519 | Eicher Tractor Plastic Cap Inlet                   | 10    | 39021000 | 18% |
| 3551520 | Eicher Tractor Plastic Cap                         | 7     | 39021000 | 18% |
| 3620153 | Eicher Tractor Breather Tube Assy Lt               | 74    | 87084000 | 18% |
| 3620165 | Eicher Tractor Breather Tube Assy Rt               | 74    | 87084000 | 18% |
| 3620207 | Eicher Tractor Centre Pin                          | 293   | 87085000 | 18% |
| 3620220 | Eicher Tractor Gasket Cover G1 Top                 | 121   | 68129090 | 18% |
| 3620529 | Eicher Tractor Cover G2 Top - Sdi                  | 2706  | 73259999 | 18% |
| 3810010 | Eicher Tractor Instrument Cluster                  | 5776  | 90292020 | 18% |
| 3810021 | Eicher Tractor Fuel Tank Cap Assy                  | 258   | 87089900 | 18% |
| 3810033 | Eicher Tractor Key                                 | 74    | 85122010 | 18% |
| 3810070 | Eicher Tractor Turn Switch                         | 403   | 85122010 | 18% |
| 3810082 | Eicher Tractor Front Light Assy Lt                 | 735   | 85122010 | 18% |
| 3810094 | Eicher Tractor Front Light Assy Rt.                | 740   | 85122010 | 18% |
| 3810101 | Eicher Tractor Tank Unit - Sdi/Wc                  | 278   | 90292020 | 18% |
| 5043773 | Eicher Tractor Spt-012=Mask Valve Fixture - 241 /  | 3730  | 82060090 | 18% |
| 5043827 | Eicher Tractor Spt-176=Puller For Pulley           | 7179  | 82060090 | 18% |
| 5043839 | Eicher Tractor Spt-128=Puller For Reduction Gear   | 4796  | 82060090 | 18% |
| 5045393 | Eicher Tractor Spt-003= Special Spanner-Suction Sc | 311   | 82060090 | 18% |
| 5045472 | Eicher Tractor Spt-020=Fixture Bumping Clearance S | 724   | 82060090 | 18% |
| 5045502 | Eicher Tractor Spt-026=Crank Shaft Fitment Fixture | 2752  | 82060090 | 18% |
| 5045514 | Eicher Tractor Spt-025=Puller-Crank Shaft          | 2178  | 82060090 | 18% |
| 5045538 | Eicher Tractor Spt-127=Fixture Main Shaft Fitment  | 2426  | 82060090 | 18% |
| 5045563 | Eicher Tractor Spt-178=Mandrel Main Shaft Removal  | 2226  | 82060090 | 18% |
| 5045605 | Eicher Tractor Spt-045=Mandrel For Bearing Race Fi | 4178  | 82060090 | 18% |
| 5045629 | Eicher Tractor Spt-044= Mandrel Bearing 6213 Fitme | 753   | 82060090 | 18% |
| 6000083 | Eicher Tractor Plain Washer A10 (Y)                | 3     | 73182100 | 18% |
| 6000133 | Eicher Tractor Hex Nut M8 (Y)                      | 1     | 73181500 | 18% |
| 6000677 | Eicher Tractor Soc. Head Cap.Screw 10*60           | 26    | 73181500 | 18% |
| 6050090 | Eicher Tractor Nylon Hex Screw M8X10               | 2     | 73181500 | 18% |
| 6052086 | Eicher Tractor Cyl Hd Collet Removal Tool-Ac(St-Ac | 3844  | 82060090 | 18% |
| 6052087 | Eicher Tractor Cyl Hd Collet Removal Tool-Wc(St-Ac | 3844  | 82060090 | 18% |
| 6052088 | Eicher Tractor Gov Flange Tightening Tool (St-Agf- | 6802  | 82060090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 6052089  | Eicher Tractor Puller For Crank Gear 322/422(St-Ac | 5553  | 82060090 | 18% |
| 6052090  | Eicher Tractor Mandrel For Loosening Flywheel(St-A | 1773  | 82060090 | 18% |
| 6052091  | Eicher Tractor Ring Nut Tightening Tool-222Es(St-A | 4955  | 82060090 | 18% |
| 6052092  | Eicher Tractor Ring Nut Tightening Tool-Multi(St-A | 4955  | 82060090 | 18% |
| 6052093  | Eicher Tractor Swan Neck Tube(St-Awt-8)            | 1111  | 82060090 | 18% |
| 6052094  | Eicher Tractor Fip Gear Puller For 323/422(St-Afpg | 2456  | 82060090 | 18% |
| 6052095  | Eicher Tractor Fip Gear Puller For Wc Eng (St-Wfpg | 1516  | 82060090 | 18% |
| 6052096  | Eicher Tractor Lub Oil Suction Screen Opener(St-As | 1501  | 82060090 | 18% |
| 6052097  | Eicher Tractor Cylinder Liner Puller(St-Wcl-12)    | 13242 | 82060090 | 18% |
| 6052098  | Eicher Tractor Cylinder Liner Pusher(St-Wcl-13)    | 5767  | 82060090 | 18% |
| 6052099  | Eicher Tractor Oil Seal Pusher Multi Cyl Ac(St-Aos | 4442  | 82060090 | 18% |
| 6052100  | Eicher Tractor Inj Sleeve Tightening Tool (St-Wis- | 4677  | 82060090 | 18% |
| 6052101  | Eicher Tractor Pre-Filter Service Tool(St-Wpf-16)  | 2413  | 82060090 | 18% |
| 6052102  | Eicher Tractor Wtr Collector Bowl Serv Tool(St-Wwb | 2178  | 82060090 | 18% |
| 6052103  | Eicher Tractor Feeler Gauge Set-Mm,5 Strips(St-Awt | 886   | 82060090 | 18% |
| 6109914  | Eicher Tractor Plastic Plug For Gear Hsg. Dia 11Mm | 4     | 39021000 | 18% |
| 6109915  | Eicher Tractor Plastic Plug For Block Dia 12Mm     | 5     | 39021000 | 18% |
| 6109916  | Eicher Tractor Plastic Plug For Cr. Case Hole Dia  | 7     | 39021000 | 18% |
| 6150019  | Eicher Tractor O Ring 77.8X5.7                     | 54    | 40169340 | 18% |
| 6150020  | Eicher Tractor Oil Seal 52X40X7                    | 91    | 40169330 | 18% |
| 6450040  | Eicher Tractor Cable Tie Clip-250Mm                | 13    | 87089900 | 18% |
| 7140323  | Eicher Tractor Cable Tie Clip                      | 23    | 39089020 | 18% |
| 7140325  | Eicher Tractor Plastic Cap For Inlet Mainfold 298/ | 32    | 84099941 | 28% |
| 7140326  | Eicher Tractor Plastic Cap For Inlet Mainfold-320D | 33    | 39041090 | 18% |
| 8020044  | Eicher Tractor Canopy Tent 6X6X7                   | 7110  | 63062990 | 12% |
| 8020045  | Eicher Tractor Standee With Backdrop Kit For Mecha | 3978  | 76169990 | 18% |
| 9247063  | Eicher Tractor Multi Tooth Washer B6.4             | 4     | 73182100 | 18% |
| 9256258  | Eicher Tractor Presure Spring                      | 9     | 73202000 | 18% |
| 9259247  | Eicher Tractor Spool                               | 215   | 87089900 | 18% |
| 9363578  | Eicher Tractor Trb 16150/16282                     | 669   | 84821011 | 18% |
| 9369009  | Eicher Tractor Case, Differential Bearing Rh       | 892   | 84822011 | 18% |
| 9600012  | Eicher Tractor Pump Element (Nc)                   | 1877  | 84099941 | 28% |
| 77000014 | Eicher Tractor 00084955 = Ring Set - Std           | 306   | 84099941 | 28% |
| 77000019 | Eicher Tractor 00070105 = Belt Dynamo/Alternator & | 107   | 84099941 | 28% |
| 77000020 | Eicher Tractor 00070104 = Belt Water Pump Assy     | 98    | 84099941 | 28% |
| 77000034 | Eicher Tractor 00050051 = Sump Gasket Kit P3       | 83    | 84099941 | 28% |
| 77000046 | Eicher Tractor 00030854 = Seal Tachometer Drive    | 27    | 84099941 | 28% |
| 77000060 | Eicher Tractor 00026585 = Fuel Filter Kit (De00511 | 208   | 84219900 | 18% |
| 77000061 | Eicher Tractor 00026584 = Fuel Filter Kit (De00511 | 220   | 84219900 | 18% |
| 77000062 | Eicher Tractor 00026583 = Insert Kit               | 114   | 84212300 | 18% |
| 77000063 | Eicher Tractor 00026582 = Insert Kit               | 133   | 84212300 | 18% |
| 77000070 | Eicher Tractor 00180063 = Clip                     | 39    | 84099941 | 28% |
| 77000116 | Eicher Tractor 00360091 = Fan 17 Dia Pusher Type   | 551   | 84099941 | 28% |
| 77000119 | Eicher Tractor 00410132 = Gear Crank Shaft         | 1063  | 84099941 | 28% |
| 77000131 | Eicher Tractor 00490001 = Gasket Cyl Head          | 614   | 84099941 | 28% |
| 77000140 | Eicher Tractor 00490019 = Joint -Sump Frnt(Ref49S3 | 13    | 84099941 | 28% |
| 77000178 | Eicher Tractor 00490685 = Joint F.I.P. To T.C(17   | 27    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 77000186 | Eicher Tractor 00530002 = Liner Cylinder Block     | 487   | 84099941 | 28% |
| 77000220 | Eicher Tractor 00650710 = Plug Cylinder Block      | 28    | 84099941 | 28% |
| 77000223 | Eicher Tractor 00650722 = Plug Induction Manifold  | 51    | 84099941 | 28% |
| 77000233 | Eicher Tractor 00720677 = Screw Tappet Adjusting   | 31    | 73181500 | 18% |
| 77000234 | Eicher Tractor 00730030 = Seal Timing Case Cover   | 45    | 84099941 | 28% |
| 77000260 | Eicher Tractor 00780007 = Spring Exhaust & Inlet V | 14    | 84099941 | 28% |
| 77000279 | Eicher Tractor 00820607 = Stud Cyl.Hd.7/16Bswx3/4- | 47    | 73182100 | 18% |
| 77000287 | Eicher Tractor 00910002 = Valve Exhaust            | 147   | 84099941 | 28% |
| 77000290 | Eicher Tractor 00920002 = Washer Plain             | 4     | 73182100 | 18% |
| 77000295 | Eicher Tractor 00920106 = Washer                   | 10    | 73182100 | 18% |
| 77000306 | Eicher Tractor 00920798 = Washer Tab Lub.Oil Sucti | 5     | 73182100 | 18% |
| 77000357 | Eicher Tractor 02415343 = Seal Timing Case Front C | 238   | 84099941 | 28% |
| 77000358 | Eicher Tractor 02415503 = Seal Aux Drive Shaft Rea | 42    | 84099941 | 28% |
| 77000424 | Eicher Tractor 31788327 = Dipstick Assy            | 29    | 84099941 | 28% |
| 77000425 | Eicher Tractor 32161114 = Plug Cyl Block Water Gal | 47    | 84099941 | 28% |
| 77000443 | Eicher Tractor 32524148 = Stud Cyl.Block To Cyl.He | 50    | 73182100 | 18% |
| 77000449 | Eicher Tractor 32757416 = Stud Cyl Head To Rocker  | 13    | 73182100 | 18% |
| 77000465 | Eicher Tractor 33261727 = Guide Inlet And Exhaust  | 56    | 84099941 | 28% |
| 77000508 | Eicher Tractor 36812127 = Gasket Cylinder Head     | 345   | 84099941 | 28% |
| 77000512 | Eicher Tractor 36814119 = Joint Timing Case To Cyl | 156   | 84099941 | 28% |
| 77000546 | Eicher Tractor 36862199 = Joint Timing Case To Lub | 21    | 84099941 | 28% |
| 77000551 | Eicher Tractor 36883106 = Rope Seal Cr.Shaft Rear  | 58    | 84099941 | 28% |
| 77000555 | Eicher Tractor 37354312 = Cover Timing Case Bottom | 122   | 84099941 | 28% |
| 77000570 | Eicher Tractor 41152912 = Rod Connecting Assembly  | 2345  | 84099941 | 28% |
| 77000595 | Eicher Tractor 0068083A = Main Brg .010 Pf         | 1145  | 84822090 | 18% |
| 77000596 | Eicher Tractor 0068083B = Main Brg .020 Pf         | 1145  | 84822090 | 18% |
| 77000597 | Eicher Tractor 0068083C = Main Brg .030 Pf         | 1145  | 84822090 | 18% |
| 77000604 | Eicher Tractor 07De0003 = Belt Water Pump Driving  | 306   | 84099941 | 28% |
| 77000608 | Eicher Tractor 07De0017 = Belt (Cogged) Alternator | 440   | 84099941 | 28% |
| 77000609 | Eicher Tractor 07De0018 = Cogged Belt-Fan Belt     | 226   | 40103290 | 18% |
| 77000610 | Eicher Tractor 07De0020 = Belt Fan Driving(Cogged  | 335   | 84099941 | 28% |
| 77000611 | Eicher Tractor 07De0024 = Belt Alternator Driving( | 202   | 84099941 | 28% |
| 77000612 | Eicher Tractor 07De0026 = Belt - Fan Drive ( Cogge | 267   | 84099941 | 28% |
| 77000613 | Eicher Tractor 07De0028 = Fan Belt(Cogged Type)    | 178   | 84099941 | 28% |
| 77000615 | Eicher Tractor 07S30021 = Belt Alternator Driving( | 200   | 84099941 | 28% |
| 77000616 | Eicher Tractor 07S30027 = Belt(Cogged Type) Altern | 302   | 84099941 | 28% |
| 77000619 | Eicher Tractor 08S30019 = Body Cylinder Head Water | 1291  | 84099941 | 28% |
| 77000624 | Eicher Tractor 09De0005 = Bolt Banjo (M.No. 9 411  | 64    | 73181500 | 18% |
| 77000625 | Eicher Tractor 09De0006 = Bolt Banjo(M.No.2 911 20 | 28    | 73181500 | 18% |
| 77000666 | Eicher Tractor 14S20007 = Camshaft                 | 1712  | 84099941 | 28% |
| 77000715 | Eicher Tractor 2313C081 = Stud Cylinder Head To Ex | 12    | 73182100 | 18% |
| 77000798 | Eicher Tractor S318 Crank Shaft                    | 17242 | 84831092 | 18% |
| 77000801 | Eicher Tractor 26S30026 = S324 Crank Shaft         | 15543 | 84099941 | 28% |
| 77000908 | Eicher Tractor 36De0021 = Fan Assembly(Plastic-15  | 368   | 39021000 | 18% |
| 77000924 | Eicher Tractor 3771K111 = Housing Thermostat       | 1444  | 84099941 | 28% |
| 77000991 | Eicher Tractor 44Sg3001 = Case Timing              | 3453  | 84099941 | 28% |
| 77000995 | Eicher Tractor 47Sj3001 = Insert Inlet Valve Seat( | 148   | 84099941 | 28% |





|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 77000996 | Eicher Tractor 47Sj3002 = Insert Exhaust Valve Sea  | 142   | 84099941 | 28% |
| 77000997 | Eicher Tractor 49De0006 = Gasket Exh M/F Outlet Fl  | 22    | 84099941 | 28% |
| 77001024 | Eicher Tractor 49S30120 = Joint Cylinder Head Rear  | 30    | 84099941 | 28% |
| 77001025 | Eicher Tractor 49S30121 = Joint Water Pump Back Pl  | 18    | 84099941 | 28% |
| 77001026 | Eicher Tractor 49S30127 = Gasket Cyl Head           | 759   | 84099941 | 28% |
| 77001028 | Eicher Tractor 49S30142 = Joint - Timing Case To C  | 217   | 84099941 | 28% |
| 77001034 | Eicher Tractor 49Sg3007 = Gasket Cylinder Head      | 660   | 84099941 | 28% |
| 77001047 | Eicher Tractor 52S30078 = Lever Alternator -See S4  | 213   | 84099941 | 28% |
| 77001051 | Eicher Tractor 53De05Pf = Prefinished Liner S325/   | 830   | 84099941 | 28% |
| 77001053 | Eicher Tractor 53De06Pf = Prefinished Liner S324    | 957   | 84099941 | 28% |
| 77001120 | Eicher Tractor 67De0110 = Pulley Crankshaft Spill   | 1933  | 84099941 | 28% |
| 77001139 | Eicher Tractor 73De0014 = Oil Seal- Crankshaft Rea  | 784   | 40169330 | 18% |
| 77001142 | Eicher Tractor 73Sg3001 = Seal Valve Stem           | 49    | 84099941 | 28% |
| 77001143 | Eicher Tractor 73Sg3004 = Rubber Seal - Cyl. Head   | 26    | 40169320 | 18% |
| 77001166 | Eicher Tractor 74S30177 = S.Screw T/C Cover To T/C  | 18    | 73181500 | 18% |
| 77001168 | Eicher Tractor 74S30242 = Setscrew - Sump To Cylin  | 10    | 73181500 | 18% |
| 77001181 | Eicher Tractor 82De0083 = Stud Water Pump To Timin  | 20    | 73182100 | 18% |
| 77001221 | Eicher Tractor 92S30109 = Washer Suction Pipe Reta  | 4     | 73182100 | 18% |
| 77001235 | Eicher Tractor 94S30311 = Bracket Engine Lifting R  | 136   | 84099990 | 28% |
| 77001282 | Eicher Tractor Assembly Tappet Adjusting Screw And  | 44    | 73181110 | 18% |
| 77001313 | Eicher Tractor 99De0978 = Hsg. Rear End Oil Seal As | 876   | 40169330 | 18% |
| 77001351 | Eicher Tractor 99De1249 = Lub.Oil Filler Assembly(  | 265   | 84099941 | 28% |
| 77001367 | Eicher Tractor Piston-H Grade(Ip Drg No.P12325*2-0  | 1819  | 84099112 | 28% |
| 77001374 | Eicher Tractor 99De1455 = Piston Assembly           | 3166  | 84099112 | 28% |
| 77001391 | Eicher Tractor 99S20665 = Piston Assy               | 2824  | 84099112 | 28% |
| 77001396 | Eicher Tractor 99S21047 = Camshaft Assembly(S2 Wi   | 1733  | 84099941 | 28% |
| 77001405 | Eicher Tractor 99S2602B = Main Bearing .020 S2      | 602   | 84822090 | 18% |
| 77001410 | Eicher Tractor 99S30544 = Pump Lub.Oil Assembly     | 1880  | 84099941 | 28% |
| 77001411 | Eicher Tractor 99S30577 = Piston Assembly           | 1825  | 84099112 | 28% |
| 77001412 | Eicher Tractor 99S30578 = Piston Rings Assembly     | 731   | 84099112 | 28% |
| 77001413 | Eicher Tractor 99S30610 = Piston Assembly           | 1745  | 84099112 | 28% |
| 77001414 | Eicher Tractor 99S30611 = Piston Ring Assembly      | 613   | 84099112 | 28% |
| 77001421 | Eicher Tractor 99S30778 = Piston Assembly(S324 Alf  | 2447  | 84099112 | 28% |
| 77001425 | Eicher Tractor 99S30868 = Pipe Lub.Oil Cam Chamber  | 139   | 84099941 | 28% |
| 77001428 | Eicher Tractor 99S30983 = Assembly Camshaft - S3    | 3269  | 84099941 | 28% |
| 77001432 | Eicher Tractor Cylinder Block Assmby S324           | 82247 | 84099941 | 28% |
| 77001435 | Eicher Tractor 99S31106 = Piston Assy.(S325 Pretop  | 2961  | 84099112 | 28% |
| 77001442 | Eicher Tractor 99S31196 = Assembly-Atomiser Leak O  | 181   | 84099941 | 28% |
| 77001443 | Eicher Tractor 99S31203 = Flywheel Assy( Eicher S   | 27740 | 84099941 | 28% |
| 77001444 | Eicher Tractor 99S31214 = Filler Lub.Oil Assembly(  | 829   | 84099941 | 28% |
| 77001449 | Eicher Tractor 99S31243 = Cylinder Block Assembly   | 73916 | 84099941 | 28% |
| 77001450 | Eicher Tractor 99S31244 = Assy - Rockershaft With   | 3146  | 84099941 | 28% |
| 77001462 | Eicher Tractor 99S31396 = Pipe Assy Main Leak Off   | 343   | 84099941 | 28% |
| 77001483 | Eicher Tractor 99Sg3017 = Piston Rings Assembly     | 731   | 84099112 | 28% |
| 77001495 | Eicher Tractor 99Sg3048 = Pipe Fuel Injection No.1  | 410   | 84099941 | 28% |
| 77001496 | Eicher Tractor 99Sg3049 = Pipe Fuel Injection No.2  | 413   | 84099941 | 28% |
| 77001497 | Eicher Tractor 99Sg3050 = Pipe Fuel Injection No.3  | 410   | 84099941 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 77001541 | Eicher Tractor De005150 = Lub.Oil Filter            | 822   | 84219900 | 18% |
| 77001545 | Eicher Tractor De005238 = Major Gasket Kit S3       | 1158  | 84099941 | 28% |
| 77001546 | Eicher Tractor De005239 = Minor Gasket Kit S3       | 863   | 84099941 | 28% |
| 77001562 | Eicher Tractor De005379 = Thermostat(Alt. Part No.D | 538   | 84099941 | 28% |
| 77001567 | Eicher Tractor De005465 = Gasket Kit Minor P3       | 443   | 84099941 | 28% |
| 77001568 | Eicher Tractor De005495 = Waterpump Repairkit       | 1108  | 84099941 | 28% |
| 77001573 | Eicher Tractor De005575 = Tab Washer Kit S324/S325  | 143   | 84099941 | 28% |
| 77001574 | Eicher Tractor De005581 = Engine Major Overhaul Ki  | 14908 | 84099990 | 28% |
| 77001575 | Eicher Tractor De005582 = Engine Major Overhaul Ki  | 15193 | 84099990 | 28% |
| 77001581 | Eicher Tractor De005594 = Joints & Gaskets Major -  | 1072  | 84099941 | 28% |
| 77001589 | Eicher Tractor De005755 = Joints & Gasket Kit Majo  | 1759  | 84099941 | 28% |
| 77001590 | Eicher Tractor De005756 = Joints-Top Overhaul Kit   | 1014  | 84099941 | 28% |
| 77001591 | Eicher Tractor De005757 = Joints Lub.Oil Sump Kit   | 182   | 84099941 | 28% |
| 77001592 | Eicher Tractor De005775 = Engine Overhaul Kit For   | 7590  | 84099990 | 28% |
| 77001602 | Eicher Tractor De005858 = Piston And Liner Kit (S3  | 15741 | 84099112 | 28% |
| 77001604 | Eicher Tractor De005860 = Piston And Liner Kit (S3  | 16120 | 84099112 | 28% |
| 77001605 | Eicher Tractor De005861 = Piston And Liner Kit (S3  | 12644 | 84099112 | 28% |
| 77001608 | Eicher Tractor De005864 = Suction Pipe Kit For S3   | 1078  | 84099941 | 28% |
| 77001609 | Eicher Tractor De005866 = Seal Kit For S Series En  | 1070  | 84099990 | 28% |
| 77001611 | Eicher Tractor De005884 = Thermo Switch (For Ksb-V  | 1024  | 84099941 | 28% |
| 77001626 | Eicher Tractor De006000 = Valve Set For P 3         | 640   | 84099941 | 28% |
| 77001627 | Eicher Tractor De006001 = Valve Set For S3          | 1026  | 84099941 | 28% |
| 77001628 | Eicher Tractor De006002 = Valve Set For Sj3         | 1851  | 84099941 | 28% |
| 77001642 | Eicher Tractor De05581A = Engine Overhaul Kit (S32  | 12124 | 84099990 | 28% |
| 77001644 | Eicher Tractor De05581N = S324 Engine Overhaul Kit  | 17656 | 84099990 | 28% |
| 77001646 | Eicher Tractor De05582A = Engine Overhaul Kit (S32  | 12557 | 84099990 | 28% |
| 77001648 | Eicher Tractor De05582N = S325 Engine Overhaul Kit  | 17943 | 84099990 | 28% |
| 77001651 | Eicher Tractor De05588A = Mf 241 Alfin Reborer Kit  | 13551 | 84099941 | 28% |
| 77001653 | Eicher Tractor De05757A = Sump Kit Joint S3         | 104   | 84099941 | 28% |
| 77001654 | Eicher Tractor De05775N = Engine Overhaul Kit - P3  | 8068  | 73182100 | 18% |
| 77001656 | Eicher Tractor De05872A = Hose Kit Di               | 873   | 40093100 | 18% |
| 77001657 | Eicher Tractor De05873A = Hose Pipe Kit 241         | 991   | 40093100 | 18% |
| 77001659 | Eicher Tractor De5581An = Engine Overhaul Kit - S3  | 14870 | 84099990 | 28% |
| 77001661 | Eicher Tractor De5582An = Engine Overhaul Kit S325  | 14110 | 73182100 | 18% |
| 77001731 | Eicher Tractor S4004454 = Case Timing               | 3704  | 84099941 | 28% |
| 77001733 | Eicher Tractor S4004901 = Joint Sump To Cylinder B  | 98    | 84099941 | 28% |
| 77001765 | Eicher Tractor S4005702 = Nut - Ch.3187             | 5     | 73181500 | 18% |
| 77001766 | Eicher Tractor S4005703 = Nut - Ch.3187             | 5     | 73181500 | 18% |
| 77001770 | Eicher Tractor S4005710 = Nut                       | 23    | 73181500 | 18% |
| 77001771 | Eicher Tractor S4005711 = Gland Nut Lub.Oil Delive  | 60    | 73181500 | 18% |
| 77001775 | Eicher Tractor S4005718 = Nut Atomiser Retaining    | 30    | 73181500 | 18% |
| 77001783 | Eicher Tractor S4006505 = Plug Cylinder Block Dra   | 88    | 84099941 | 28% |
| 77001789 | Eicher Tractor S4006717 = Pulley Cr.Shaft           | 2012  | 84099941 | 28% |
| 77001792 | Eicher Tractor S4007401 = S.Screw Induction Manifo  | 9     | 73181500 | 18% |
| 77001794 | Eicher Tractor S4007403 = Setcrew                   | 11    | 84099941 | 28% |
| 77001795 | Eicher Tractor S4007404 = S.Screw T/C To Cover & A  | 22    | 73181500 | 18% |
| 77001797 | Eicher Tractor S4007406 = Setscrew                  | 11    | 73181500 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 77001798 | Eicher Tractor S4007407 = Setscrew                  | 10    | 73181500 | 18% |
| 77001799 | Eicher Tractor S4007408 = Set Screw                 | 11    | 73181500 | 18% |
| 77001801 | Eicher Tractor S4007410 = Setscrew                  | 9     | 73181500 | 18% |
| 77001802 | Eicher Tractor S4007413 = Setscrew                  | 18    | 73181500 | 18% |
| 77001803 | Eicher Tractor S4007415 = Setscrew                  | 49    | 73181500 | 18% |
| 77001808 | Eicher Tractor S4007426 = Setscrew Crankshaft Pull  | 191   | 73181500 | 18% |
| 77001809 | Eicher Tractor S4007428 = Setscrew Main Brg Cap To  | 60    | 73181500 | 18% |
| 77001816 | Eicher Tractor Setscrew Flywheel To Crankshaft      | 32    | 73181110 | 18% |
| 77001817 | Eicher Tractor S4007451 = S.Screw Induction Manifo  | 22    | 73181500 | 18% |
| 77001822 | Eicher Tractor S4007470 = Setscrew                  | 10    | 73181500 | 18% |
| 77001826 | Eicher Tractor S4008208 = Stud                      | 18    | 73182100 | 18% |
| 77001827 | Eicher Tractor S4008209 = Stud Lifting Plate/Dynam  | 18    | 73182100 | 18% |
| 77001828 | Eicher Tractor S4008210 = Stud F/W Hsg.To Block/Dy  | 15    | 73182100 | 18% |
| 77001829 | Eicher Tractor S4008211 = Stud W/Pump Mounting - C  | 18    | 73182100 | 18% |
| 77001830 | Eicher Tractor S4008212 = Stud Bkt.To Lift Pump -   | 15    | 73182100 | 18% |
| 77001832 | Eicher Tractor S4008214 = Stud                      | 13    | 73182100 | 18% |
| 77001835 | Eicher Tractor S4008217 = Stud                      | 14    | 73182100 | 18% |
| 77001838 | Eicher Tractor S4008220 = Stud Cylinder Head To Ro  | 25    | 73182100 | 18% |
| 77001842 | Eicher Tractor S008243 = Stud                       | 17    | 73182100 | 18% |
| 77001843 | Eicher Tractor S400824 = Stud                       | 28    | 73182100 | 18% |
| 77001844 | Eicher Tractor S4008246 = Stud-Automiser Retaining  | 22    | 73182100 | 18% |
| 77001857 | Eicher Tractor S4009202 = Washer Cylinder Block Dr  | 4     | 84099941 | 28% |
| 77001858 | Eicher Tractor S4009203 = Washer                    | 2     | 84099941 | 28% |
| 77001891 | Eicher Tractor S4009933 = Thrust Washer Assembly    | 344   | 73182100 | 18% |
| 77001892 | Eicher Tractor S4009934 = T Washer Top&Bottom .007  | 356   | 73182990 | 18% |
| 77001904 | Eicher Tractor S4099106 = Piston Assy               | 2514  | 84099112 | 28% |
| 77001905 | Eicher Tractor S4099107 = Piston Rings Assembly     | 549   | 84099112 | 28% |
| 77001928 | Eicher Tractor S4099168 = Pipe Fuel Oil Main Leak   | 150   | 84099941 | 28% |
| 77001935 | Eicher Tractor S4099177 = Piston Assembly Kit       | 2692  | 84099112 | 28% |
| 77001963 | Eicher Tractor Sa063496 = Connecting Rod Assembly   | 2011  | 84099941 | 28% |
| 77001964 | Eicher Tractor Sa94885A = Crank Shaft Rear End Oil  | 1138  | 40169330 | 18% |
| 77001965 | Eicher Tractor Sk003473 = Timing Pointer            | 99    | 84099941 | 28% |
| 77001972 | Eicher Tractor De5582T3 = Engine Overhaul Kit Tmtl  | 15934 | 84099990 | 28% |
| 77001973 | Eicher Tractor De5581T3 = Engine Overhaul Kit Tmtl  | 19061 | 84099990 | 28% |
| 77001978 | Eicher Tractor 20530352 = Connection Cyl. Block Wat | 276   | 84099941 | 28% |
| 77002012 | Eicher Tractor 32813106 = Cap Nut Tacho Meter Driv  | 2     | 73181500 | 18% |
| 77002014 | Eicher Tractor 37736242 = Connection Cylinder Bloc  | 411   | 84099941 | 28% |
| 77002022 | Eicher Tractor 07S30035 = Belt Alternator           | 281   | 84099941 | 28% |
| 77002023 | Eicher Tractor 07S30036 = Belt (Water Pump)         | 318   | 84099941 | 28% |
| 77002055 | Eicher Tractor Cover - Cylinder Head                | 799   | 84099941 | 28% |
| 77002076 | Eicher Tractor 49S30163 = Joint - Oil Filler        | 36    | 84099941 | 28% |
| 77002097 | Eicher Tractor 67De0112 = Pulley Crankshaft(Spill   | 1782  | 84835010 | 18% |
| 77002140 | Eicher Tractor 99S31511 = Timing Case Cover Assly   | 3640  | 84099941 | 28% |
| 77002142 | Eicher Tractor 99S31550 = Lube Oil Filler Assly Me  | 302   | 84099941 | 28% |
| 77002146 | Eicher Tractor 99S31555 = Pipe F.I.No.1 (17 Spill   | 310   | 84099941 | 28% |
| 77002147 | Eicher Tractor 99S31556 = Pipe F.I.No.2(17 Spill)   | 310   | 84099941 | 28% |
| 77002148 | Eicher Tractor 99S31557 = Pipe F.I.No.3(17 Spill)   | 310   | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 77002149 | Eicher Tractor 99S31575 = Water Pump Assy          | 4520  | 84099941 | 28% |
| 77002150 | Eicher Tractor 99S31579 = Tensioner Assy           | 2565  | 84099941 | 28% |
| 77002191 | Eicher Tractor Nma25Kit = S325 Major Kit Nhi       | 14540 | 84099941 | 28% |
| 77002319 | Eicher Tractor 41S30053 = Gear Fip (Delphi)        | 3708  | 84099941 | 28% |
| 77002323 | Eicher Tractor 44S30221 = Timing Case For Tmtl-Tii | 4594  | 84099941 | 28% |
| 77002335 | Eicher Tractor 54S30091 = Manifold Induction(Pdc-N | 798   | 84099941 | 28% |
| 77002336 | Eicher Tractor 54S30099 = Exhaust Manifold         | 2011  | 84099941 | 28% |
| 77002368 | Eicher Tractor 99S31507 = Pipe Fuel Injection Assy | 362   | 84099941 | 28% |
| 77002369 | Eicher Tractor 99S31508 = Pipe Fuel Injection Assy | 362   | 84099941 | 28% |
| 77002370 | Eicher Tractor 99S31509 = Pipe Fuel Injection Assy | 362   | 84099941 | 28% |
| 77002372 | Eicher Tractor 99S31580 = Pipe Lub.Oil Pr.Rail To  | 191   | 84099941 | 28% |
| 77002533 | Eicher Tractor S4007471 = Setscrew-Long            | 30    | 73181500 | 18% |
| 77002609 | Eicher Tractor 26S30011 = Crankshaft(S324/S325 Mac | 25238 | 84099941 | 28% |
| 77002623 | Eicher Tractor 44S30207 = Adaptor Plate Housing Fl | 7952  | 84099941 | 28% |
| 77002711 | Eicher Tractor 99S31671 = High Pressure Pipe No.1  | 296   | 84099941 | 28% |
| 77002712 | Eicher Tractor 99S31672 = High Pressure Pipe No.2  | 296   | 84099941 | 28% |
| 77002713 | Eicher Tractor 99S31673 = High Pressure Pipe No.3  | 296   | 84099941 | 28% |
| 77002717 | Eicher Tractor 99S31727 = Timing Case Cover Assemb | 3128  | 84099941 | 28% |
| 77002739 | Eicher Tractor De009582 = Engine Major Overhaul Ki | 11629 | 84099990 | 28% |
| 77002746 | Eicher Tractor De09581N = S324 Engine Overhaul Kit | 20514 | 84099990 | 28% |
| 77002754 | Eicher Tractor Dem68525 = Simpson Gasket Sealant ( | 50    | 35061000 | 18% |
| 77002759 | Eicher Tractor Df711296 = Rotary Fuel Filter       | 157   | 84219900 | 18% |
| 77002789 | Eicher Tractor 83S30119 = Sump (Modified Front Sup | 24043 | 84099941 | 28% |
| 77002791 | Eicher Tractor 31134151 = Con. Rod Bush            | 98    | 84099941 | 28% |
| 77002792 | Eicher Tractor 37424611 = Re Housing               | 532   | 84099941 | 28% |
| 77002793 | Eicher Tractor 99De9369 = Piston Assembly For 63De | 2085  | 84099112 | 28% |
| 77002795 | Eicher Tractor Sa94885F = Rear End Oil Seal Housin | 1451  | 40169330 | 18% |
| 77002796 | Eicher Tractor De009597 = E.O.H.Kit Minor Tr-I S32 | 15007 | 84099941 | 28% |
| 77002797 | Eicher Tractor De09597N = E.O.H.Kit Major Tr-I S32 | 16409 | 84099941 | 28% |
| 77002798 | Eicher Tractor De009598 = E.O.H.Kit Minor Tr-Ii S3 | 14910 | 84099941 | 28% |
| 77002799 | Eicher Tractor De09598N = E.O.H.Kit Major Tr-Ii S3 | 19100 | 84099941 | 28% |
| 77002800 | Eicher Tractor De009599 = E.O.H.Kit Minor Tr-Iii S | 15845 | 84099941 | 28% |
| 77002801 | Eicher Tractor De09599N = E.O.H.Kit Major Tr-Iii S | 16457 | 84099941 | 28% |
| 77002802 | Eicher Tractor De009600 = E.O.H.Kit Minor Tr-Iii S | 19750 | 84099941 | 28% |
| 77002803 | Eicher Tractor De09600N = E.O.H.Kit Major Tr-Iii S | 21126 | 84099941 | 28% |
| 77002805 | Eicher Tractor De006265 = Hand Priming Unit        | 1063  | 84099941 | 28% |
| 77002806 | Eicher Tractor De006264 = Mechanical Feed Pump     | 2283  | 84099941 | 28% |
| 77002807 | Eicher Tractor Sk004949 = Sediment Bowl With Exten | 1056  | 84099941 | 28% |
| 77002810 | Eicher Tractor 54S30090 = Exhaust Manifold         | 2103  | 84099941 | 28% |
| 77002811 | Eicher Tractor High Pressure Pipe 1St Cylinder     | 439   | 84099941 | 28% |
| 77002812 | Eicher Tractor High Pressure Pipe 2Nd Cylinder     | 439   | 84099941 | 28% |
| 77002813 | Eicher Tractor High Pressure Pipe 3Rd Cylinder     | 439   | 84099941 | 28% |
| 77002814 | Eicher Tractor De009610 = Integrated Sump Gasket K | 556   | 84841090 | 18% |
| 77002815 | Eicher Tractor Piston Rings Assembly               | 549   | 84099112 | 28% |
| 77002816 | Eicher Tractor 14S30022 = Cam Shaft 5150 Mech Feed | 2053  | 84831099 | 18% |
| 77002817 | Eicher Tractor Crankshaft Sleeve With Tool For Fit | 1311  | 84099941 | 28% |
| 77002818 | Eicher Tractor Integrated Rear End Oil Seal        | 1209  | 40169330 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 77002819 | Eicher Tractor Piston Assy                          | 2314  | 84099112 | 28% |
| 77002820 | Eicher Tractor Fitment Tool For Cassette Type Seal  | 14014 | 82079090 | 18% |
| 77002821 | Eicher Tractor 07De0030 = Fan Belt - W/P            | 395   | 40103290 | 18% |
| 77002822 | Eicher Tractor R/E Sealwithhousing-Integratedcassee | 2546  | 40169330 | 18% |
| 77002823 | Eicher Tractor 49S30195 - Joint Cyl. Head Rear And  | 37    | 84099941 | 28% |
| 77002824 | Eicher Tractor 44S30245 = Timing Case               | 5772  | 84099941 | 28% |
| 77002825 | Eicher Tractor 74Sg3074 = Flanged Bolt (M8 X 1.25   | 12    | 73181110 | 18% |
| 77002826 | Eicher Tractor 74Sg3091 = Flanged Bolt (M8 X 1.25   | 34    | 73181110 | 18% |
| 77002827 | Eicher Tractor 74Sg3073 = Flanged Bolt (M8 X 1.25   | 12    | 73181110 | 18% |
| 77002828 | Eicher Tractor 74Sg4067 = Flanged Bolt (M8 X 1.25   | 37    | 73181110 | 18% |
| 77002829 | Eicher Tractor 57Sg4015 = Flanged Nut (M8 X 1.25)   | 12    | 73181500 | 18% |
| 77002830 | Eicher Tractor 57Sg3013 = Flanged Nut ( M8X1)- 8    | 11    | 73181110 | 18% |
| 77002831 | Eicher Tractor 41S30052 = Idler Gear (Sg Iron)      | 2937  | 84834000 | 18% |
| 77002832 | Eicher Tractor 49S30164 = Joint Timing Case To Cov  | 239   | 84841090 | 18% |
| 77002833 | Eicher Tractor 74Sg3094 = Flanged Bolt (M8X1.25X55  | 21    | 73181500 | 18% |
| 77002834 | Eicher Tractor 99S31611 = Flywheel And Ring Assy T  | 29323 | 84835090 | 18% |
| 77002835 | Eicher Tractor 10S30668 = Bracket Alternator        | 1351  | 84099941 | 28% |
| 77002836 | Eicher Tractor 52S30096 = Lever Alternator          | 772   | 84099941 | 28% |
| 77002837 | Eicher Tractor 36Sg3001 = Extension Fan Pulley      | 435   | 84099941 | 28% |
| 77002839 | Eicher Tractor 33423148 = Cap Valve Spring          | 63    | 84099941 | 28% |
| 77002840 | Eicher Tractor 26S30023 = Crankshaft Engine         | 25655 | 84831092 | 18% |
| 77002841 | Eicher Tractor 38S30055 = Adaptor Lub Oil Pressure  | 50    | 84099941 | 28% |
| 77002842 | Eicher Tractor 49S30190 = Joint Rear End Oil Seal   | 93    | 84841090 | 18% |
| 77002843 | Eicher Tractor 49S30192 = Joint Timing Case         | 223   | 84841090 | 18% |
| 77002844 | Eicher Tractor 49S30193 = Joint Water Inlet Connec  | 25    | 84841090 | 18% |
| 77002845 | Eicher Tractor 49S30196 = Joint Water Pump Back Pl  | 33    | 49239030 | 18% |
| 77002846 | Eicher Tractor 49S30197 = Joint Water Outlet Conne  | 33    | 49239030 | 18% |
| 77002847 | Eicher Tractor 49S30198 = Gasket Cylinder Head Rea  | 47    | 84841090 | 18% |
| 77002848 | Eicher Tractor 49S30199 = Joint Tacho Drive         | 30    | 84841090 | 18% |
| 77002849 | Eicher Tractor 49S30201 = Joint Lub Oil Filter      | 17    | 84841090 | 18% |
| 77002850 | Eicher Tractor 49S30203 = Joint Air Intake Manifol  | 77    | 84841090 | 18% |
| 77002851 | Eicher Tractor 49S30266 = Joint Lub Oil Filler      | 45    | 84841090 | 18% |
| 77002852 | Eicher Tractor 49S30277 = Gasket Exhaust Manifold   | 10    | 84841090 | 18% |
| 77002853 | Eicher Tractor 49S30322 = Joint Valve Cover         | 130   | 45041010 | 12% |
| 77002854 | Eicher Tractor 67Sg3004 = Pulley Crankshaft         | 1782  | 84835010 | 18% |
| 77002855 | Eicher Tractor 74S30309 = Setscrew                  | 16    | 73181110 | 18% |
| 77002856 | Eicher Tractor 74S30311 = Bolt                      | 34    | 73181110 | 18% |
| 77002857 | Eicher Tractor 74S30314 = Bolt                      | 27    | 73181110 | 18% |
| 77002858 | Eicher Tractor 74Sg3071 = Setscrew                  | 11    | 73181110 | 18% |
| 77002859 | Eicher Tractor 74Sg3076 = Bolt                      | 17    | 73181110 | 18% |
| 77002860 | Eicher Tractor 74Sg3079 = Setscrew                  | 10    | 73181110 | 18% |
| 77002861 | Eicher Tractor 74Sg3083 = Setscrew                  | 11    | 73181110 | 18% |
| 77002862 | Eicher Tractor 74Sg4065 = Bolt                      | 13    | 73181110 | 18% |
| 77002863 | Eicher Tractor 92De0183 = Washer                    | 17    | 73182200 | 18% |
| 77002864 | Eicher Tractor 99S31252 = Rod Engine Connecting As  | 2528  | 84099941 | 28% |
| 77002865 | Eicher Tractor 99S31863 = Pump Water Assembly       | 4283  | 84133030 | 28% |
| 77002866 | Eicher Tractor De005039 = Pre Filter Fuel           | 813   | 84212300 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 77002867 | Eicher Tractor De005616 = Injector Assembly        | 6236  | 84099941 | 28% |
| 77002868 | Eicher Tractor De005831 = Filter Fuel              | 2962  | 84212300 | 18% |
| 77002869 | Eicher Tractor 99S32032 = Impactor Breather With I | 1967  | 84099941 | 28% |
| 77002870 | Eicher Tractor 24S30129 = Cylinder Head Cover      | 1103  | 84099941 | 28% |
| 77002871 | Eicher Tractor 99S31867 = Pipe Fuel Injector 1     | 371   | 84099941 | 28% |
| 77002872 | Eicher Tractor 99S31868 = Pipe Fuel Injector 2     | 371   | 84099941 | 28% |
| 77002873 | Eicher Tractor 99S31869 = Pipe Fuel Injector 3     | 371   | 84099941 | 28% |
| 77002874 | Eicher Tractor Engine O..Kit (S3-Trem Iii-50+3017+ | 14160 | 84099941 | 28% |
| 77002876 | Eicher Tractor 99S31540 = Cap Lub Oil Filler Assem | 75    | 84099941 | 28% |
| 77002877 | Eicher Tractor 49S30151 = Sac Gasket               | 172   | 84099941 | 28% |
| 77002879 | Eicher Tractor 99S32034 = Cyl. Head Assy           | 19798 | 84099941 | 28% |
| 77002880 | Eicher Tractor S4388233 = Stud                     | 31    | 73181110 | 18% |
| 77002881 | Eicher Tractor 74S30312 = Setscrew                 | 13    | 73181110 | 18% |
| 77002882 | Eicher Tractor 41S30066 = Gear Crank Shaft         | 975   | 73181110 | 18% |
| 77002883 | Eicher Tractor 41S30067 = Gear Idler               | 1928  | 84834000 | 18% |
| 77002884 | Eicher Tractor 99S32172 = Pump Lub.Oil Assy(Flange | 3319  | 73181110 | 28% |
| 77002885 | Eicher Tractor 99S32171 = L.O.Pump Idler Gear Assy | 481   | 84099941 | 28% |
| 77002886 | Eicher Tractor 10S30919 = Clamp Injector Holder    | 180   | 84099941 | 28% |
| 77002887 | Eicher Tractor 57De0103 = Nut                      | 11    | 73181110 | 18% |
| 77002888 | Eicher Tractor 99S32163 = Pump Water Assembly      | 5047  | 84099941 | 28% |
| 77002889 | Eicher Tractor De006975 = Seal Water Pump(Unitised | 2743  | 40169330 | 18% |
| 77002890 | Eicher Tractor 32Sg3003 = Dipstick Assy            | 200   | 90178090 | 18% |
| 77002891 | Eicher Tractor 20Sg3007 = Union Dipstick           | 117   | 84099941 | 28% |
| 77002892 | Eicher Tractor 54S30116 = Manifold Exhaust         | 2723  | 84099941 | 28% |
| 77002894 | Eicher Tractor De006067 = Fuel Injection Pump      | 27639 | 84133010 | 28% |
| 77003093 | Eicher Tractor 83S30130 = Pan Lub Oil              | 32817 | 84099941 | 28% |
| 77003106 | Eicher Tractor 05S30046 = Flywheel Bush S324/S325- | 365   | 84099941 | 28% |
| 77003107 | Eicher Tractor 05S30047 = Flywheel Bush S324/S325- | 365   | 84099941 | 28% |
| 83110012 | Eicher Tractor Gasket For Bearing Hsg Cover        | 79    | 68129922 | 18% |
| 83110013 | Eicher Tractor Carter M/Cd                         | 33749 | 84099941 | 28% |
| 83110014 | Eicher Tractor Gasket For Bearing Flange           | 32    | 68129922 | 18% |
| 83110016 | Eicher Tractor Lid Gasket                          | 127   | 68129922 | 18% |
| 83110017 | Eicher Tractor Gasket For Control Hsg              | 175   | 68129922 | 18% |
| 83110028 | Eicher Tractor Feed Pump Housing Gasket            | 54    | 68129922 | 18% |
| 83110036 | Eicher Tractor Oil Filter Head Assy                | 788   | 84219900 | 18% |
| 83120006 | Eicher Tractor Control Rod Assy - 198/142 & Chotu  | 167   | 84099941 | 28% |
| 83120008 | Eicher Tractor Blower Shaft                        | 765   | 84091000 | 28% |
| 83120009 | Eicher Tractor Blower Support Front                | 1172  | 84099941 | 28% |
| 83120020 | Eicher Tractor Cylinder Liner Finish               | 3888  | 84099941 | 28% |
| 83120040 | Eicher Tractor Cover                               | 2534  | 84099941 | 28% |
| 83120066 | Eicher Tractor Blower Pulley                       | 739   | 84835010 | 18% |
| 83120095 | Eicher Tractor Fuel Pipe Assy (Ff To Fip)          | 563   | 84099990 | 28% |
| 83120099 | Eicher Tractor Cover For Fip Rubber Bellow         | 116   | 84133010 | 28% |
| 83120104 | Eicher Tractor Heat Shield                         | 1437  | 87089900 | 18% |
| 83120106 | Eicher Tractor Dry Type Air Cleaner With Safety El | 3905  | 84213920 | 18% |
| 83120128 | Eicher Tractor Gasket For Inspection Cover Front   | 68    | 68129922 | 18% |
| 83120132 | Eicher Tractor Air Cleaner Safety Element          | 913   | 84213100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 83120205 | Eicher Tractor Wire Harness - 198Es                | 2357  | 85444220 | 18% |
| 83150004 | Eicher Tractor Dipstick Assy                       | 146   | 87084000 | 18% |
| 83150007 | Eicher Tractor O-Ring Dia 6.8 X Dia 1.97           | 14    | 40169320 | 18% |
| 83150010 | Eicher Tractor Stud M10X1.5X70                     | 34    | 73182100 | 18% |
| 83150021 | Eicher Tractor Lifter Guide                        | 253   | 84099941 | 28% |
| 83150022 | Eicher Tractor O - Ring (28.7 X 3)                 | 18    | 40169990 | 18% |
| 83150023 | Eicher Tractor Oil Pressure Switch(F)              | 198   | 84099941 | 28% |
| 83150026 | Eicher Tractor Gasket                              | 95    | 68129922 | 18% |
| 83150027 | Eicher Tractor Gasket For Control Hsg              | 194   | 68129922 | 18% |
| 83150028 | Eicher Tractor Bearing Housing Gasket              | 159   | 68129922 | 18% |
| 83150032 | Eicher Tractor Fuel Pipe Assy (Feed Pump To Fuel F | 405   | 40094200 | 18% |
| 83150033 | Eicher Tractor Fuel Pipe Assy (Ff To Fip)          | 512   | 40094200 | 18% |
| 83150034 | Eicher Tractor Bracket For Fuel Filters            | 850   | 84219900 | 18% |
| 83150035 | Eicher Tractor Fuel Pipe Assy (Feed Pump To Pre Fi | 2711  | 40094200 | 18% |
| 83150036 | Eicher Tractor Fuel Pipe Assy (Pre Filter To Main  | 2732  | 40094200 | 18% |
| 83150037 | Eicher Tractor Fuel Pipe Assy (Main Filter To Fip) | 19060 | 40094200 | 18% |
| 83150061 | Eicher Tractor Clamp -Nylon Pipe                   | 25    | 40094200 | 18% |
| 83170017 | Eicher Tractor Piston Pin- 62.5 Kva (Fm)           | 542   | 84099941 | 28% |
| 83170018 | Eicher Tractor Circlip 40X1.75 N Is:3075 -62.5 Kva | 13    | 73182910 | 18% |
| 83170020 | Eicher Tractor Piston Ring - Middle 62.5Kva (Fm)   | 219   | 84099941 | 28% |
| 83170092 | Eicher Tractor Radiator Assy( Cu ) (461)           | 40752 | 84099199 | 28% |
| 83170165 | Eicher Tractor Air Filter Element - Safety         | 1400  | 84213100 | 18% |
| 83170291 | Eicher Tractor Wire Harness - 621Es                | 3241  | 85444220 | 18% |
| 83170292 | Eicher Tractor Wire Harness - 881Es                | 3396  | 85444220 | 18% |
| 83180002 | Eicher Tractor Rbo Exhaust Extension (60 Hp)       | 2046  | 84099941 | 28% |
| 83180016 | Eicher Tractor Hose - Coolant In Egr Valve         | 164   | 40093100 | 18% |
| 83180017 | Eicher Tractor Union, M18X1.5                      | 106   | 84099941 | 28% |
| 83180024 | Eicher Tractor Crank Shaft Trem Iv                 | 26723 | 84831092 | 18% |
| 83180025 | Eicher Tractor Crank Shaft Assy.                   | 9064  | 84831092 | 18% |
| 83180032 | Eicher Tractor Flywheel Casing (4Wd)               | 7572  | 73251000 | 18% |
| 83180039 | Eicher Tractor Lubrication Pipe - Fip              | 336   | 87089900 | 18% |
| 83180041 | Eicher Tractor Stud M8X1.25X50                     | 19    | 73182100 | 18% |
| 83180042 | Eicher Tractor Stud M8X1.25X75                     | 25    | 73182100 | 18% |
| 83180057 | Eicher Tractor Hose - Coolant Out Egr Valve        | 216   | 40093100 | 18% |
| 83180063 | Eicher Tractor Egr Mixer Housing-Finished          | 1446  | 84099941 | 28% |
| 83180076 | Eicher Tractor Gasket Egr Valve (Exhasut Gas Out)  | 57    | 68129090 | 18% |
| 83180077 | Eicher Tractor Gasket Egr Valve (Exhaust Gas In)   | 42    | 68129090 | 18% |
| 83180078 | Eicher Tractor Clamp For Injector                  | 419   | 84099990 | 28% |
| 83180079 | Eicher Tractor Gasket - Egr Mixer Bottom           | 71    | 68129090 | 18% |
| 83180080 | Eicher Tractor Gasket - Egr Mixer Top              | 71    | 68129090 | 18% |
| 83180092 | Eicher Tractor Running-In Oil Filter               | 166   | 84219900 | 18% |
| 83180093 | Eicher Tractor Plastic Cover                       | 22    | 39021000 | 18% |
| 83180094 | Eicher Tractor Lpp - Over Flow                     | 228   | 40092200 | 18% |
| 83180106 | Eicher Tractor Spacer For Rail Mounting Cyl. Head  | 45    | 73182100 | 18% |
| 83180109 | Eicher Tractor Egr Cooler                          | 34744 | 40093100 | 18% |
| 83180110 | Eicher Tractor Cylinder Block M/Cd (Trem Iv )      | 82827 | 84099941 | 28% |
| 83180127 | Eicher Tractor Hose, Egr Coolant Out Egr Cooler    | 190   | 40093100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 83180145 | Eicher Tractor Cylinder Head                       | 25946 | 84099941 | 28% |
| 83180146 | Eicher Tractor Bracket - Fuel Filter Protect       | 198   | 87089900 | 18% |
| 83180147 | Eicher Tractor Bracket - Main Fuel Filter          | 284   | 87089900 | 18% |
| 83180148 | Eicher Tractor Boost Pipe                          | 2020  | 87089900 | 18% |
| 83180149 | Eicher Tractor Slit Hose                           | 28    | 40093100 | 18% |
| 83180161 | Eicher Tractor Gasket - Perforated Tube            | 38    | 68129090 | 18% |
| 83180162 | Eicher Tractor Perforated Tube, Egr Mixer          | 1260  | 87083000 | 18% |
| 83180163 | Eicher Tractor Stud M8X1.25X175                    | 104   | 73182100 | 18% |
| 83180167 | Eicher Tractor Cylinder Head Assy                  | 25712 | 84099941 | 28% |
| 83180181 | Eicher Tractor FOEI Filter Protect                 | 2812  | 84219900 | 18% |
| 83180182 | Eicher Tractor Fuel Filter - Main                  | 6706  | 84219900 | 18% |
| 83180183 | Eicher Tractor Lpp - Main Fuel Filter To Fip       | 497   | 84219900 | 18% |
| 83180185 | Eicher Tractor Lpp - Protect To Main Fuel Filter   | 514   | 84219900 | 18% |
| 83180224 | Eicher Tractor Hose - Fuel Return                  | 419   | 40093100 | 18% |
| 83180235 | Eicher Tractor Piston - Trem-Iv                    | 2909  | 84099112 | 28% |
| 83180236 | Eicher Tractor Thermostat Housing                  | 1681  | 84099941 | 28% |
| 83180239 | Eicher Tractor Thermostat                          | 968   | 90321090 | 18% |
| 83180241 | Eicher Tractor Flywheel                            | 8751  | 87084000 | 18% |
| 83180249 | Eicher Tractor Bolt Injector Clamp M7X36           | 44    | 73181500 | 18% |
| 83180250 | Eicher Tractor Pulley Water Pump                   | 2865  | 84099941 | 28% |
| 83180261 | Eicher Tractor Ecu                                 | 19157 | 84099941 | 28% |
| 83180262 | Eicher Tractor Pipe For Dipstick                   | 35    | 84099941 | 28% |
| 83180266 | Eicher Tractor Turbo Charger, Tr43-1873 Cxa 4.82,  | 92568 | 84099941 | 28% |
| 83180268 | Eicher Tractor Bracket, Egr Cooler Mntg            | 20    | 87089900 | 18% |
| 83180270 | Eicher Tractor Lm Guide Shs55Lv2Ssshc0E+1860Lp-Ii  | 18714 | 87089900 | 18% |
| 83180284 | Eicher Tractor Common Rail                         | 19971 | 84099941 | 28% |
| 83180285 | Eicher Tractor High Pressure Fuel Pump             | 46678 | 84099941 | 28% |
| 83180286 | Eicher Tractor Electrical Egr Valve,18Mm Dia       | 14458 | 84099941 | 28% |
| 83180287 | Eicher Tractor Cam Sensor                          | 3436  | 87084000 | 18% |
| 83180290 | Eicher Tractor Identification Plate                | 33    | 87089400 | 18% |
| 83180296 | Eicher Tractor Doc Assy - 10 Gm                    | 25966 | 87089400 | 18% |
| 83180301 | Eicher Tractor High Pressure Pipe, Rail To Injecto | 974   | 87089900 | 18% |
| 83180302 | Eicher Tractor High Pressure Pipe, Rail To Injecto | 974   | 87089900 | 18% |
| 83180303 | Eicher Tractor High Pressure Pipe, Rail To Injecto | 974   | 87089900 | 18% |
| 83180304 | Eicher Tractor High Pressure Pipe, Fip To Rail-1   | 1291  | 87089900 | 18% |
| 83180305 | Eicher Tractor High Pressure Pipe, Fip To Rail-2   | 1291  | 87089900 | 18% |
| 83180309 | Eicher Tractor Fuel Return Line                    | 2545  | 40092200 | 18% |
| 83180317 | Eicher Tractor Camshaft Valtra Trem Iv             | 5403  | 84099941 | 28% |
| 83180319 | Eicher Tractor Gear Housing 320D60 Trem Iv         | 6373  | 87084000 | 18% |
| 83180320 | Eicher Tractor Exhaust Adaptor                     | 1423  | 84099941 | 28% |
| 83180323 | Eicher Tractor T-Joint Frl Return                  | 23    | 84099941 | 28% |
| 83180324 | Eicher Tractor T - Joint Fip Return                | 23    | 84099941 | 28% |
| 83180325 | Eicher Tractor Lpp - Over Flow - 2                 | 480   | 40092200 | 18% |
| 83180328 | Eicher Tractor Hose, Egr Cooler, Coolat In         | 175   | 40093100 | 18% |
| 83180332 | Eicher Tractor Tc Oil Drain Pipe, Tel Tc           | 1306  | 87089900 | 18% |
| 83180333 | Eicher Tractor Tc Oil Inlet Pipe, Tel Tc           | 558   | 87089900 | 18% |
| 83180334 | Eicher Tractor Doc Bracket                         | 1452  | 87089900 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 83180337 | Eicher Tractor Cap                                 | 18    | 87085000 | 18% |
| 83180392 | Eicher Tractor Ccv Kit Serviceable                 | 4744  | 84099941 | 28% |
| 83180434 | Eicher Tractor Bracket, Wh, Left Side              | 81    | 87089900 | 18% |
| 83180436 | Eicher Tractor Bracket, Injector Side Wh           | 58    | 87089900 | 18% |
| 83180437 | Eicher Tractor Bracket, Glow Plug                  | 52    | 87089900 | 18% |
| 83180467 | Eicher Tractor Clamp - Hose Ccv To Ac Hose         | 27    | 40093100 | 18% |
| 83180471 | Eicher Tractor Hose - Ccv To Check Valve           | 274   | 40093100 | 18% |
| 83180472 | Eicher Tractor Hose - Ccv Filter To Dry A/C Hose   | 438   | 40093100 | 18% |
| 83180473 | Eicher Tractor Intake Manifold                     | 3165  | 84099941 | 28% |
| 83180475 | Eicher Tractor Hose - Rocker Cover To Ccv          | 198   | 40093100 | 18% |
| 83180476 | Eicher Tractor Rocker Cover                        | 1361  | 84099941 | 28% |
| 83180489 | Eicher Tractor Bracket Ccv                         | 223   | 87089900 | 18% |
| 83180491 | Eicher Tractor Z Bracket For Metering Unit Branch  | 61    | 87089900 | 18% |
| 83180492 | Eicher Tractor U Bracket For Cam & Oil Press Senso | 35    | 87089900 | 18% |
| 83180493 | Eicher Tractor Z Bracket For Crank Sensor          | 37    | 87089900 | 18% |
| 83180494 | Eicher Tractor Z Bracket For Boost Pressure Sensor | 30    | 87089900 | 18% |
| 83180530 | Eicher Tractor Drive Shaft For Hyd. Pump           | 2128  | 87084000 | 18% |
| 83180540 | Eicher Tractor Bracket Alternator                  | 538   | 84099941 | 28% |
| 83180549 | Eicher Tractor Lub. Oil Sump 4Wd                   | 23111 | 73251000 | 18% |
| 83220409 | Eicher Tractor Rain Hood For Ø100Mm Stack Pipe     | 3841  | 85030090 | 18% |
| 83220465 | Eicher Tractor Ss Bellow (5 ~ 7.5 Kva With 198Es)  | 2667  | 83071000 | 18% |
| 83220664 | Eicher Tractor Ss Flex Pipe - 7.5/ 10 Kva With 222 | 2667  | 83071000 | 18% |
| 83220787 | Eicher Tractor Rain Hood For 2.5" (65 Nb) A-Class  | 2936  | 85030090 | 18% |
| 83220931 | Eicher Tractor Door Hinge With Studs - Die Cast -  | 1370  | 85381010 | 18% |
| 83220997 | Eicher Tractor Door Hinge With Studs - Die Cast -  | 1370  | 85381010 | 18% |
| 83220998 | Eicher Tractor Slam Lock With Studs C/W Rubber&Gas | 3260  | 85381010 | 18% |
| 83220999 | Eicher Tractor Slam Lock With Studs C/W Rubber&Gas | 3260  | 85381010 | 18% |
| 83221116 | Eicher Tractor Residential Silencer - Internal Mtg | 14732 | 85030090 | 18% |
| 83221340 | Eicher Tractor Rain Hood For 3" (80 Mm Nb) A-Clas  | 2936  | 85030090 | 18% |
| 83221395 | Eicher Tractor Res. Silencer (Internal) - 50 Inlet | 14732 | 85030090 | 18% |
| 83221421 | Eicher Tractor Residential Silencer 5 ~ 7.5 Kva (1 | 11011 | 85030090 | 18% |
| 83221448 | Eicher Tractor Residential Silencer - 30 ~ 45 Kva  | 19478 | 85030090 | 18% |
| 83221477 | Eicher Tractor Residential Silencer - Rectangular- | 39442 | 85030090 | 18% |
| 83221495 | Eicher Tractor Ss Flexible Pipe Exhaust            | 2108  | 83071000 | 18% |
| 83221505 | Eicher Tractor Ss Flex Pipe - 10 Kva With 222Es -  | 3068  | 83071000 | 18% |
| 83221620 | Eicher Tractor Fuel Filling Cap - Lockable         | 303   | 90261020 | 18% |
| 83221638 | Eicher Tractor Emergency Stop Push Button-Spring R | 303   | 85381010 | 18% |
| 83221639 | Eicher Tractor Nc Element                          | 162   | 85369090 | 18% |
| 83221640 | Eicher Tractor Exhaust Fan (Globe-Hd) 305 Sweep    | 12538 | 84145120 | 18% |
| 83221641 | Eicher Tractor Sweep Exhaust Fan - 380 Mm          | 14937 | 84145120 | 18% |
| 83221642 | Eicher Tractor Sweep Exhaust Fan - 450Mm           | 20271 | 84145120 | 18% |
| 83221643 | Eicher Tractor Gasket Exhaust Pipe Round Od150 Pcd | 282   | 84841010 | 18% |
| 83221648 | Eicher Tractor Avm Pad (Pgs-1-Green)               | 2774  | 40169390 | 18% |
| 83221650 | Eicher Tractor Avm Pad - (Pgs-1-Red)               | 2774  | 40169390 | 18% |
| 83221651 | Eicher Tractor Avm Pad - (Pgs-1-Blue)              | 2774  | 40169990 | 18% |
| 83221652 | Eicher Tractor Avm Pad (Pab-1A)                    | 2147  | 40169390 | 18% |
| 83221653 | Eicher Tractor Avm Pad (P3-D)                      | 2048  | 40169990 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 83221654 | Eicher Tractor Avm Pad (P3-C)                      | 2048  | 40169990 | 18% |
| 83221655 | Eicher Tractor Gasket Exhaust Bellow Square 94X94X | 124   | 84841090 | 18% |
| 83221656 | Eicher Tractor Gasket Fuel Tank Hatch Plate(200X14 | 226   | 84849000 | 18% |
| 83221657 | Eicher Tractor Avm Pads (Engine Side)              | 2159  | 40169990 | 18% |
| 83221658 | Eicher Tractor Avm Pads (Alternator Side)          | 1050  | 40169990 | 18% |
| 83221661 | Eicher Tractor Gasket - Exhaust Pipe (Round, Od-16 | 563   | 84841010 | 18% |
| 83221662 | Eicher Tractor Avm Pad (Pgs-1-White)               | 2740  | 40169330 | 18% |
| 83221664 | Eicher Tractor Combo Fuel Tank Float Unit - Eth-10 | 3141  | 90261020 | 18% |
| 83221665 | Eicher Tractor Combo Fuel Tank Float Unit - Eth-13 | 3000  | 90261020 | 18% |
| 83221666 | Eicher Tractor Combo Fuel Tank Float Unit (Sam) Et | 2975  | 90261020 | 18% |
| 83221667 | Eicher Tractor Combo Fuel Tank Float Unit (Sam) Et | 3167  | 90261020 | 18% |
| 83221668 | Eicher Tractor Residential Silencer - Internal Mtg | 20186 | 85030090 | 18% |
| 83221706 | Eicher Tractor Lock - Genset Control Panel Door    | 337   | 85381010 | 18% |
| 83221707 | Eicher Tractor Hinge - Genset Control Panel Door   | 312   | 85381010 | 18% |
| 83221708 | Eicher Tractor Avm Pad - Control Panel             | 299   | 85030010 | 18% |
| 83221709 | Eicher Tractor Gasket - Diesel Filling Hatch Plate | 316   | 84841010 | 18% |
| 83230017 | Eicher Tractor Spacer                              | 21    | 73182100 | 18% |
| 83230034 | Eicher Tractor Fuel Filter With Hand Primer        | 3701  | 84212900 | 18% |
| 83230084 | Eicher Tractor Solenoid Assy                       | 3523  | 85365090 | 18% |
| 83230151 | Eicher Tractor Relay Card-Mcb/Gcb                  | 708   | 85381010 | 18% |
| 83230154 | Eicher Tractor Spare Coil 63A C&S Contactor        | 728   | 85381010 | 18% |
| 83230157 | Eicher Tractor Fuel Pipe Assy                      | 495   | 40092200 | 18% |
| 83230158 | Eicher Tractor Fuel Pipe Assy                      | 459   | 40092200 | 18% |
| 83230164 | Eicher Tractor Wire Harness - 222Es                | 2623  | 85444220 | 18% |
| 83230165 | Eicher Tractor Digital Hour Cum Rpm Meter Item Cod | 2945  | 90292090 | 18% |
| 83230168 | Eicher Tractor Wiring Harness                      | 986   | 85444220 | 18% |
| 83230180 | Eicher Tractor Engine Fuel Pipe Clamp - 222Es      | 50    | 87089900 | 28% |
| 83230190 | Eicher Tractor Rubber Bellow For Push Type Soleno  | 115   | 85365090 | 18% |
| 83230191 | Eicher Tractor Rubber Bellow For Pull Type Soleno  | 115   | 85365090 | 18% |
| 83230193 | Eicher Tractor Manual To Auto Kit - Rjio           | 4720  | 85381010 | 18% |
| 83230203 | Eicher Tractor Solenoid Assy (222Es)               | 2910  | 85365090 | 18% |
| 83240015 | Eicher Tractor Pedestal Front-Lh                   | 1881  | 85030090 | 18% |
| 83240016 | Eicher Tractor Pedestal Front- Rh                  | 1807  | 85030090 | 18% |
| 83240090 | Eicher Tractor Ind Controller Eiec 4400            | 6227  | 85030010 | 18% |
| 83240133 | Eicher Tractor 100Amps 4Pole L&T Cantactor Mcx22-W | 12197 | 85369090 | 18% |
| 83240136 | Eicher Tractor 63Amps 4Pole L&T Contactor Mcx12    | 5202  | 85369090 | 18% |
| 83240137 | Eicher Tractor Spare Coil Mcx-12                   | 728   | 85381010 | 18% |
| 83240139 | Eicher Tractor 100Amps 4Pole "C&S" Make Contactor  | 10749 | 85369090 | 18% |
| 83240142 | Eicher Tractor Spare Coil, Cat No. "Tx1D6U5"       | 2113  | 85381010 | 18% |
| 83240166 | Eicher Tractor 63Amps 4 Pole "C&S" Contactor       | 5246  | 85369090 | 18% |
| 83240170 | Eicher Tractor Spare Coil Mcx22,240V               | 2012  | 85381010 | 18% |
| 83240178 | Eicher Tractor Temperature Sensor 19.7 Mm          | 179   | 90328990 | 18% |
| 83240179 | Eicher Tractor Oil Pressure Switch                 | 235   | 85361010 | 18% |
| 83240181 | Eicher Tractor Wiring Harness                      | 2698  | 85444220 | 18% |
| 83240186 | Eicher Tractor Start/Stop Relay Card               | 562   | 85381010 | 18% |
| 83240266 | Eicher Tractor Solenoid Assembly-322Es             | 2941  | 85365090 | 18% |
| 83250006 | Eicher Tractor Hour Cum Rpm Meter - 2.15 Pulley Ra | 5731  | 84099120 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 83250031 | Eicher Tractor Amf Controller (Tec - 9900C)        | 15831 | 85030010 | 18% |
| 83250033 | Eicher Tractor Gprs Modem With Antenna             | 8224  | 85176230 | 18% |
| 83250051 | Eicher Tractor Genset Controller (Edgc-6600R)      | 6415  | 85030010 | 18% |
| 83250056 | Eicher Tractor Starter Motor Assy                  | 17892 | 85114000 | 28% |
| 83250126 | Eicher Tractor Static Battery Charger 10A-Smps Ba  | 2208  | 85044090 | 18% |
| 83250205 | Eicher Tractor Engine Fuel Pipe Clamp Type - 1     | 25    | 87089900 | 28% |
| 83250206 | Eicher Tractor Engine Wiring Harness               | 3383  | 85444220 | 18% |
| 83250239 | Eicher Tractor Wire Harness - 323Es                | 3054  | 85444220 | 18% |
| 83250240 | Eicher Tractor Engine Harness Clamp - 1            | 29    | 87089900 | 28% |
| 83250241 | Eicher Tractor Engine Harness Clamp - 2            | 39    | 87089900 | 28% |
| 83250361 | Eicher Tractor Deep Sea Controller: Dse 4522-A1-Ex | 15833 | 85030010 | 18% |
| 83250374 | Eicher Tractor Copper Sealing Washer10*17*3Mm      | 29    | 84099941 | 28% |
| 83250427 | Eicher Tractor Oil Seal 22X35X7                    | 124   | 40169330 | 18% |
| 83250428 | Eicher Tractor O Ring                              | 7     | 40169320 | 18% |
| 83250495 | Eicher Tractor Solenoid Assembly-Pull Type         | 3507  | 85365090 | 18% |
| 83250514 | Eicher Tractor Manual To Auto Retrofitment Kit W/O | 1652  | 85030090 | 18% |
| 83270132 | Eicher Tractor Grid Heater                         | 5987  | 84099990 | 28% |
| 83270178 | Eicher Tractor Deep Sea Controller: Dse 4522-A1    | 11614 | 85030010 | 18% |
| 83270179 | Eicher Tractor Exhaust Fan Failure Safety Module   | 720   | 85381010 | 18% |
| 83270229 | Eicher Tractor Garuda Hardware Set                 | 60354 | 85030010 | 18% |
| 85100001 | Eicher Tractor Rakshak Diesel Filter Primary       | 84    | 84219900 | 18% |
| 85100002 | Eicher Tractor Rakshak Diesel Filt Kit-Prim+Sec    | 143   | 84219900 | 18% |
| 85100003 | Eicher Tractor Rakshak Diesel Filter Element       | 79    | 84219900 | 18% |
| 85100004 | Eicher Tractor Rakshak Diesel Filter Secondary     | 78    | 84219900 | 18% |
| 85100005 | Eicher Tractor Rakshak Diesel Filt -Esc/Mm/Tafe    | 128   | 84219900 | 18% |
| 85100006 | Eicher Tractor Rakshak Lube Oil Filter Spin On     | 161   | 84219900 | 18% |
| 85100007 | Eicher Tractor Rakshak Lube Oil Filter - Mm Di     | 187   | 84219900 | 18% |
| 85100008 | Eicher Tractor Rakshak Diesel Filter Prim - Nh     | 210   | 84219900 | 18% |
| 85100009 | Eicher Tractor Rakshak Oil Filter(Spin On)-Mm      | 216   | 84219900 | 18% |
| 85100010 | Eicher Tractor Rakshak Diesel Filter Sec - Nh      | 299   | 84219900 | 18% |
| 85100011 | Eicher Tractor Rakshak Diesel Spin On Sec - Nh     | 259   | 84219900 | 18% |
| 85100012 | Eicher Tractor Rakshak Oil Filt Spin On-Mm/Fml     | 250   | 84219900 | 18% |
| 85100013 | Eicher Tractor Rakshak Seat Cushion- Back (24 Hp)  | 391   | 94019000 | 18% |
| 85100014 | Eicher Tractor Rakshak Seat Cushion- Bottom (24Hp) | 732   | 94019000 | 18% |
| 85100015 | Eicher Tractor Rakshak Seat Cushion- Back (36/50 H | 699   | 94019000 | 18% |
| 85100016 | Eicher Tractor Rakshak Seat Cushion- Bottom (36/50 | 821   | 94019000 | 18% |
| 85100017 | Eicher Tractor Rakshak Seat Cushion- Back (24 Hp)  | 733   | 94019000 | 18% |
| 85100018 | Eicher Tractor Rakshak Seat Cushion- Bottom (24Hp) | 1035  | 94019000 | 18% |
| 85100019 | Eicher Tractor Rakshak Seat Cushion- Back (36/50 H | 1136  | 94019000 | 18% |
| 85100020 | Eicher Tractor Rakshak Seat Cushion- Bottom (36/50 | 1479  | 94019000 | 18% |
| 85100022 | Eicher Tractor Rakshak Solar Lantern               | 374   | 94055040 | 18% |
| 85100023 | Eicher Tractor Rakshak Metal Valve Caps            | 54    | 84818090 | 18% |
| 85100025 | Eicher Tractor Rakshak Rear Wheel Wt. Kit / 1Wt    | 9603  | 87089900 | 18% |
| 85100026 | Eicher Tractor Rakshak Rear Wheel Wt. Kit / 2Wt    | 18228 | 87089900 | 18% |
| 85100027 | Eicher Tractor Rakshak Hitch - 241/242/312/330     | 3754  | 87089900 | 18% |
| 85100028 | Eicher Tractor Rakshak Driver Leg Guard-650 (Heat  | 2150  | 87089900 | 18% |
| 85100029 | Eicher Tractor Rakshak Pin For Hitch- 24 X 3"      | 76    | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 85100030 | Eicher Tractor Rakshak Pin For Hitch- 30 X 6.5"    | 206   | 87089900 | 18% |
| 85100032 | Eicher Tractor Rakshak Canopy Frame Assy - 776/884 | 15239 | 87089900 | 18% |
| 85100033 | Eicher Tractor Rakshak Head Light With Drl         | 816   | 85122010 | 18% |
| 85100034 | Eicher Tractor Rakshak Wiring Harness For Drl -H/L | 390   | 85443000 | 18% |
| 85100035 | Eicher Tractor Rakshak Head Light/Drl Kit -2Hl & 1 | 1921  | 85122010 | 18% |
| 85100038 | Eicher Tractor Rakshak Front Indicator Guard Set O | 298   | 87089900 | 18% |
| 85100039 | Eicher Tractor Rakshak Rear Indicator Guard Set Of | 391   | 87089900 | 18% |
| 85100040 | Eicher Tractor Rakshak Grease Dispenser- 5 Kgs     | 3177  | 84131110 | 5%  |
| 85100041 | Eicher Tractor Rakshak Adjustable Hitch -242/330   | 6213  | 87089900 | 18% |
| 85100042 | Eicher Tractor Rakshak Oil Tester                  | 232   | 39241090 | 18% |
| 85100047 | Eicher Tractor Rakshak Mudguard Seat Set Of 2      | 1221  | 87089900 | 18% |
| 85100048 | Eicher Tractor Rakshak Driver Leg Guard (Heat Shie | 2278  | 87089900 | 18% |
| 85100049 | Eicher Tractor Rakshak Canopy (Tractor Hood)       | 5057  | 87089900 | 18% |
| 85100050 | Eicher Tractor Rakshak Indicator Guard Set Of 4    | 734   | 87089900 | 18% |
| 85100051 | Eicher Tractor Rakshak Metallic Tool Box For All M | 710   | 87089900 | 18% |
| 85100055 | Eicher Tractor Rakshak Quick Release Coupler - Tt  | 347   | 87089900 | 18% |
| 85100056 | Eicher Tractor Rakshak Premium Seat Cover Dlx      | 251   | 94012000 | 18% |
| 85100057 | Eicher Tractor Rakshak Premium Seat Cover Super Dl | 309   | 94012000 | 18% |
| 85100058 | Eicher Tractor Rakshak Premium Steering Cover/Grip | 189   | 87089400 | 18% |
| 85100059 | Eicher Tractor Rakshak Premium Steering Cover (5S) | 196   | 87089400 | 18% |
| 85100061 | Eicher Tractor Rakshak Premium Steering Cover (3S  | 200   | 87089400 | 18% |
| 85100062 | Eicher Tractor Rakshak Premium Fender Seat (Pu Mol | 1441  | 87089900 | 18% |
| 85100063 | Eicher Tractor Rakshak Premium Fender Support (Pu  | 1394  | 87089900 | 18% |
| 85100064 | Eicher Tractor Rakshak Premium Fender Support      | 1561  | 87089900 | 18% |
| 85100070 | Eicher Tractor Rakshak Premium Seat Cover Super Dl | 309   | 94012000 | 18% |
| 85100071 | Eicher Tractor Rakshak Premium Seat Cover Dlx 2S   | 251   | 94012000 | 18% |
| 85100072 | Eicher Tractor Rakshak Quick Release Coupler - Mal | 253   | 87089900 | 18% |
| 85100073 | Eicher Tractor Rakshak Adjustable Hitch            | 6428  | 87089900 | 18% |
| 85100074 | Eicher Tractor Rakshak Aux Valve Assy (Hyd) Exclud | 11926 | 84818090 | 18% |
| 85100089 | Eicher Tractor Rakshak Premium Seat Cover Dlx - 18 | 301   | 87089400 | 18% |
| 85100091 | Eicher Tractor Rakshak Tyre Polish 5 Kg            | 1089  | 39100090 | 18% |
| 85100099 | Eicher Tractor Hydromatic Auxillary Valve Kit 485  | 9398  | 84818090 | 18% |
| 85100100 | Eicher Tractor Bulb H4 12V 60/55W P43T Blue Kit    | 311   | 85392120 | 18% |
| 85100101 | Eicher Tractor Bulb H4 12V 60/55W P43T Gold Kit    | 354   | 85392120 | 18% |
| 85100102 | Eicher Tractor Rakshak Canopy For 188 (Chotu)      | 3857  | 87089900 | 18% |
| 85100103 | Eicher Tractor Rakshak Grease Gun                  | 704   | 87089900 | 18% |
| 85100104 | Eicher Tractor Rakshak Tyre Pressure Gauge         | 199   | 87089900 | 18% |
| 85100105 | Eicher Tractor Rakshak Fuel Filter Funnel          | 2792  | 87089900 | 18% |
| 85100107 | Eicher Tractor Rakshak Hitch                       | 3338  | 87089900 | 18% |
| 85100108 | Eicher Tractor Rakshak Rakshak Canopy-242          | 4945  | 87089900 | 18% |
| 85100110 | Eicher Tractor 1017056 = Sldg Gear 4/5(5-Sp) T-15  | 633   | 87084000 | 18% |
| 85100111 | Eicher Tractor 1018747 = Sldg Gear 2/3(5-Sp) - 241 | 1576  | 87084000 | 18% |
| 85100112 | Eicher Tractor 1510381 = Sldg Gear 1St/2Nd - 242 T | 1695  | 87084000 | 18% |
| 85100113 | Eicher Tractor 93611565 = Reverse Gear 241         | 1271  | 87084000 | 18% |
| 85100114 | Eicher Tractor 1516693 = Sldg Gear 1&2 Dlx-50Hp T- | 2001  | 87084000 | 18% |
| 85100115 | Eicher Tractor 1018735 = Sliding Gear1 (5-Sp) - 24 | 1192  | 87084000 | 18% |
| 85100116 | Eicher Tractor 1017135 = Constant Mesh Gear - 241  | 1102  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 85100117 | Eicher Tractor Rakshak 93611670 = Driven Disc 11"  | 1601  | 87089300 | 18% |
| 85100118 | Eicher Tractor Rakshak 93675865 = Driven Disc 11"  | 2552  | 87089300 | 18% |
| 85100119 | Eicher Tractor Rakshak 93640565 = Line Friction Di | 626   | 87083000 | 18% |
| 85100120 | Eicher Tractor Rakshak 93640668 = Line Friction Di | 574   | 87083000 | 18% |
| 85100121 | Eicher Tractor Rakshak 1309328=Head Light Assly    | 629   | 85122010 | 18% |
| 85100123 | Eicher Tractor Rakshak Seat Cover-Chotu            | 336   | 94012000 | 18% |
| 85100124 | Eicher Tractor Rakshak Cloth For Roof Canopy       | 721   | 87089900 | 18% |
| 85100125 | Eicher Tractor Rakshak Canopy-242 (Silver)         | 4945  | 87089900 | 18% |
| 85100126 | Eicher Tractor Rakshak 93654898 = Main Driven Plat | 3284  | 87089300 | 18% |
| 85100127 | Eicher Tractor Rakshak 93655192 = Clutch Plate (Pt | 1961  | 87089300 | 18% |
| 85100128 | Eicher Tractor Rakshak 93640294 = Pto Driven Plate | 1901  | 87084000 | 18% |
| 85100131 | Eicher Tractor Rakhsak 93654886 = Main Driven Plat | 4660  | 87089300 | 18% |
| 85100132 | Eicher Tractor Rakshak 93627007 = Main Driven Plat | 4660  | 87089300 | 18% |
| 85100136 | Eicher Tractor Rakshak 93626982 = Driven Plate Pto | 2996  | 87089300 | 18% |
| 85100137 | Eicher Tractor Front Grill - For Low Bumper        | 2395  | 87081010 | 18% |
| 85100138 | Eicher Tractor Front Grill - For High Bumper       | 2395  | 87081010 | 18% |
| 85100139 | Eicher Tractor Rakshak Canopy Frame Assy - 551     | 15940 | 87089900 | 18% |
| 85100141 | Eicher Tractor Rakshak Bowl                        | 116   | 84213100 | 18% |
| 85100142 | Eicher Tractor Rakshak Canopy Cloth Camouflage Ins | 878   | 87089900 | 18% |
| 85100143 | Eicher Tractor Rakshak Cloth For Roof Canopy Blue  | 721   | 87089900 | 18% |
| 85100144 | Eicher Tractor Rakshak Cloth For Roof Canopy Green | 721   | 87089900 | 18% |
| 85100145 | Eicher Tractor Rakshak Cloth For Roof Canopy Red   | 721   | 87089900 | 18% |
| 85100146 | Eicher Tractor Rakshak Canopy Cloth Camouflage Blu | 878   | 87089900 | 18% |
| 85100147 | Eicher Tractor Rakshak Canopy Cloth Camouflage Gre | 878   | 87089900 | 18% |
| 85100148 | Eicher Tractor Rakshak Canopy Cloth Camouflage Red | 878   | 87089900 | 18% |
| 85100149 | Eicher Tractor Rakshak Steering Cover Ps Fl        | 210   | 87089900 | 18% |
| 85100150 | Eicher Tractor Rakshak Repair Kit Grease Disp      | 132   | 40169320 | 18% |
| 85100151 | Eicher Tractor Rakshak Canopy Prima (Tractor Hood) | 5784  | 87089900 | 18% |
| 85100152 | Eicher Tractor Rakshak Trolley Hose- 0.5 M         | 405   | 87089900 | 18% |
| 85100153 | Eicher Tractor Rakshak Trolley Hose- 1.0 M         | 610   | 87089900 | 18% |
| 85100160 | Eicher Tractor Tractor Shining Kit                 | 3413  | 39100090 | 18% |
| 85100161 | Eicher Tractor Rakshak Canopy Red (Tractor Hood    | 5300  | 87089900 | 18% |
| 85100162 | Eicher Tractor Rakshak Canopy (Tractor Hod) Blue   | 5300  | 87089900 | 18% |
| 85100168 | Eicher Tractor Rakshak Bonnet Cover (3S/4S/5S)     | 929   | 87089900 | 18% |
| 85100169 | Eicher Tractor Rakshak Seat Cover(Pocket) -Dt      | 444   | 87089900 | 18% |
| 85100174 | Eicher Tractor Rakshak Filter Element Kit - Wc     | 297   | 84212300 | 18% |
| 85100176 | Eicher Tractor Rakshak Filter Element Kit - Wc     | 302   | 84212300 | 18% |
| 85300001 | Eicher Tractor Spt-003 = Spl Spanner-Suction Scree | 917   | 82060090 | 18% |
| 85300002 | Eicher Tractor Spt-007 = Mandrel-Bearing Nup 313   | 3163  | 82060090 | 18% |
| 85300003 | Eicher Tractor Spt-020 = Fixture Bumping Clearance | 1524  | 82060090 | 18% |
| 85300004 | Eicher Tractor Spt-021 = Box Spanner-Driving Jaw   | 1233  | 82060090 | 18% |
| 85300005 | Eicher Tractor Spt-022 = Fly Wheel Socket-Small- M | 4927  | 82060090 | 18% |
| 85300006 | Eicher Tractor Spt-024 = Tube-Crank Shaft Holding  | 1647  | 82060090 | 18% |
| 85300007 | Eicher Tractor Spt-025 = Puller Crank Shaft Multy  | 4500  | 82060090 | 18% |
| 85300008 | Eicher Tractor Spt-026 = Crank Shaft Fitment Fixtu | 6962  | 82060090 | 18% |
| 85300009 | Eicher Tractor Spt-028 = Mandrel Valve Stem Seal P | 1100  | 82060090 | 18% |
| 85300010 | Eicher Tractor Spt-029 = Mandrel Valve Stem Oil Se | 1100  | 82060090 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 85300011 | Eicher Tractor Spt-112 = Clamping Fixture-Bumping   | 1539  | 82060090 | 18% |
| 85300012 | Eicher Tractor Spt-114 = Fly Wheel Nut Puller       | 6111  | 82060090 | 18% |
| 85300013 | Eicher Tractor Spt-180 = Compression Gauge Assly.   | 9161  | 82060090 | 18% |
| 85300014 | Eicher Tractor Spt-48008 = Puller Fuel Pump Gear-M  | 1838  | 82060090 | 18% |
| 85300015 | Eicher Tractor Spt-018 = Dual Clutch Alignment Gau  | 4893  | 82060090 | 18% |
| 85300016 | Eicher Tractor Spt-038 = Mandral Needle Bush Fitme  | 396   | 82060090 | 18% |
| 85300017 | Eicher Tractor Spt-044 = Mandrel Brg 6213 Fitment   | 1750  | 82060090 | 18% |
| 85300018 | Eicher Tractor Spt-045 = Mandrel Brg Race Fitment   | 7076  | 82060090 | 18% |
| 85300019 | Eicher Tractor Spt-047 = Mandrel Brg 32211 Fitment  | 2296  | 82060090 | 18% |
| 85300020 | Eicher Tractor Spt-049 = Mandrel Ball Brg 6211 Fit  | 1618  | 82060090 | 18% |
| 85300021 | Eicher Tractor Spt-163 = Special Spanner Grooved N  | 1070  | 82060090 | 18% |
| 85300022 | Eicher Tractor Spt-009 = Puller Valve Lift Actuato  | 289   | 82060090 | 18% |
| 85300023 | Eicher Tractor Spt-010 = Prv Pressure Adjusting Ki  | 6103  | 82060090 | 18% |
| 85300024 | Eicher Tractor Spt-015 = Addc Piston Seal Assy. Kit | 9787  | 82060090 | 18% |
| 85300025 | Eicher Tractor Spt-027 = Puller For Puppet Valve    | 167   | 82060090 | 18% |
| 85300026 | Eicher Tractor Spt-179 = Mandrel Oil Seal Fitment-  | 383   | 82060090 | 18% |
| 85300027 | Eicher Tractor Spt-002 = Dismntlling Stand-Set Of   | 39282 | 82060090 | 18% |
| 85300028 | Eicher Tractor Spt-123 = Puller With Knife Jaw      | 12237 | 82060090 | 18% |
| 85300029 | Eicher Tractor Spt-177 = Puller With Arm            | 7641  | 82060090 | 18% |
| 85300030 | Eicher Tractor Spt-181 = Center Pin Puller          | 3683  | 82060090 | 18% |
| 85300031 | Eicher Tractor Sptgo210 = Pin For Ctf-Ctr Allignme  | 1223  | 82060090 | 18% |
| 85300032 | Eicher Tractor Sptgo211 = Mandrel Primary Shaft     | 6936  | 82060090 | 18% |
| 85300033 | Eicher Tractor Sptgo212 = Mandrel Primary Shaft Br  | 9171  | 82060090 | 18% |
| 85300034 | Eicher Tractor Sptgo213 = Check Nut Tighting Tool   | 5802  | 82060090 | 18% |
| 85300035 | Eicher Tractor Sptgo214 = Pto Cm Gear Locating Too  | 3819  | 82060090 | 18% |
| 85300036 | Eicher Tractor Sptgo215 = Dowel Pin Mandrel         | 2661  | 82060090 | 18% |
| 85300037 | Eicher Tractor Sptc102 = Clutch Finger Height Sett  | 4279  | 82060090 | 18% |
| 85300038 | Eicher Tractor Sptws001 = Valve Spring Comop W Ado  | 4590  | 82060090 | 18% |
| 85300039 | Eicher Tractor Sptws002 = Piston Hght & Valve Dept  | 1008  | 82060090 | 18% |
| 85300040 | Eicher Tractor Sptws003 = C Shaft Rear End Oil Sel  | 4295  | 82060090 | 18% |
| 85300041 | Eicher Tractor Sptws004 = Timing Cover Oil Seal Fi  | 2373  | 82060090 | 18% |
| 85300042 | Eicher Tractor Sptws005 = Filter Remover            | 1069  | 82060090 | 18% |
| 85300043 | Eicher Tractor Sptws006 = Injector Puller           | 1604  | 82060090 | 18% |
| 85300044 | Eicher Tractor 1920301 = Mandrel-Brg. 6209 & Nup 20 | 5879  | 82060090 | 18% |
| 85300045 | Eicher Tractor 1920303 = Mmandrel-Brg. 6309 N Prsg. | 10281 | 82060090 | 18% |
| 85300046 | Eicher Tractor 1920304 = Mandrel-Nrb 25X33X20 Prsg  | 1770  | 82060090 | 18% |
| 85300047 | Eicher Tractor 1920305 = Mandrel-Prsg. Oil Seal 18  | 2291  | 82060090 | 18% |
| 85300048 | Eicher Tractor 1920311 = Mandrel-Trb32013X Prsg.    | 5190  | 82060090 | 18% |
| 85300049 | Eicher Tractor 1920312 = Common Mandrel-Trb 32013   | 7635  | 82060090 | 18% |
| 85300050 | Eicher Tractor 1920313 = Fitment Tool-Adj Screw M9  | 4273  | 82060090 | 18% |
| 85300051 | Eicher Tractor 1920320 = Guide Pin For G1+G2 4Nos   | 2937  | 82060090 | 18% |
| 85300052 | Eicher Tractor 1920329 = Mandrel Prsg. 32014 Outer  | 7053  | 82060090 | 18% |
| 85300053 | Eicher Tractor 1920330 = Mandrel Prsg. Oil Seal 80  | 7354  | 82060090 | 18% |
| 85300054 | Eicher Tractor 1920332 = Mandrel Prsg Oil Seal 65X  | 6116  | 82060090 | 18% |
| 85300055 | Eicher Tractor 1920333 = Mandrel Prsg Oil Seal Trb  | 8231  | 82060090 | 18% |
| 85300056 | Eicher Tractor Spt-48001 = Mandrel For Oil Seal     | 3824  | 82060090 | 18% |
| 85300057 | Eicher Tractor Spt-175 = Fixture Bumping Clearance  | 413   | 82060090 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 85300058 | Eicher Tractor Spt-48006 = Puller For Cam Gear      | 2073 | 82060090 | 18% |
| 85300059 | Eicher Tractor Spt-48005 = Tool For F.I.Pump        | 333  | 82060090 | 18% |
| 85300060 | Eicher Tractor Spt-011 = Tool For Prv Spool Snap R  | 382  | 82060090 | 18% |
| 85300061 | Eicher Tractor Spt-48004 = Mandrel For O Ring       | 382  | 82060090 | 18% |
| 85300062 | Eicher Tractor Spt-014 = Addc Piston Seal Assy. Kit | 7517 | 82060090 | 18% |
| 85300063 | Eicher Tractor Distributer'S Pressure Setting Tool  | 7222 | 82060090 | 18% |
| 85300064 | Eicher Tractor Steering Wheel Puller For All Model  | 3694 | 82060090 | 18% |
| 85300065 | Eicher Tractor Puller For Rotor Shaft Check Nut (   | 1755 | 82060090 | 18% |
| 85300066 | Eicher Tractor Puller For Input Shaft Check Nut (R  | 1435 | 82060090 | 18% |
| 85300067 | Eicher Tractor Puller For Reduction Gear Check Nut  | 2874 | 82060090 | 18% |
| 85300068 | Eicher Tractor Mandral For Pto Oil Seal Fitment     | 4790 | 82060090 | 18% |
| 85300069 | Eicher Tractor Filler Guage                         | 479  | 82060090 | 18% |
| 85300070 | Eicher Tractor Injector Puller For Veltra           | 2746 | 82060090 | 18% |
| 85300071 | Eicher Tractor Pto Shaft Bush Fitment Mendral       | 1806 | 82060090 | 18% |
| 85300072 | Eicher Tractor Dual & Single Clutch Dismantle & As  | 2902 | 82060090 | 18% |
| 85300073 | Eicher Tractor Fingers Height & Clutch Disc Alignm  | 6316 | 82060090 | 18% |
| 85300074 | Eicher Tractor Pre Loading Guage For C.P. Shaft     | 3509 | 82060090 | 18% |
| 85300075 | Eicher Tractor Tool Tighting For Crimping Nut M24   | 2339 | 82060090 | 18% |
| 85300076 | Eicher Tractor Tool For Tighting Of Lock Nut M35X1  | 1988 | 82060090 | 18% |
| 85300077 | Eicher Tractor Lockating Pin Set For G.B. Top Cove  | 1287 | 82060090 | 18% |
| 85300078 | Eicher Tractor Guiding Sleeve For Insertion Of Pis  | 2105 | 82060090 | 18% |
| 85300079 | Eicher Tractor Assly Cone To Fitment Of Wynseal &   | 2573 | 82060090 | 18% |
| 85300080 | Eicher Tractor Mandrel For Prsg. Oil Seal (18X30X7  | 2339 | 82060090 | 18% |
| 85300081 | Eicher Tractor Mandrel To Prsg. Small Bush (35X39X  | 3743 | 82060090 | 18% |
| 85300082 | Eicher Tractor Mandrel To Press Big Bush (40X43X30  | 3743 | 82060090 | 18% |
| 85300083 | Eicher Tractor Pin 4Mm                              | 819  | 82060090 | 18% |
| 85300084 | Eicher Tractor Pin 6Mm                              | 819  | 82060090 | 18% |
| 85300085 | Eicher Tractor Pin 8Mm                              | 819  | 82060090 | 18% |
| 85300086 | Eicher Tractor Pin 10Mm                             | 819  | 82060090 | 18% |
| 85300088 | Eicher Tractor Filler Guage With 6 Blades           | 334  | 82060090 | 18% |
| 85300089 | Eicher Tractor Rev Gear Layshaft Spring Dowel       | 1114 | 82060090 | 18% |
| 85300090 | Eicher Tractor Seal 28*35*7 Mandrel Input Shaft     | 4233 | 82060090 | 18% |
| 85300091 | Eicher Tractor Mandrel For Oil Seal 30*18*7         | 1671 | 82060090 | 18% |
| 85300092 | Eicher Tractor Mandrel For Brg 6309 Pressing        | 4010 | 82060090 | 18% |
| 85300093 | Eicher Tractor Mandrel For Main Shaft Rear End      | 4122 | 82060090 | 18% |
| 85300094 | Eicher Tractor Mandrel For Bearing Inner Race       | 3342 | 82060090 | 18% |
| 85300095 | Eicher Tractor Mandrel For Intermediate Plate       | 3342 | 82060090 | 18% |
| 85300096 | Eicher Tractor Cap- Ø17 Mandrel On Front Pin        | 891  | 82060090 | 18% |
| 85300097 | Eicher Tractor Mandrel For Lay Shaft Speef          | 3899 | 82060090 | 18% |
| 85300098 | Eicher Tractor Mandrel Seal55*70*8 Guidesleeve      | 3342 | 82060090 | 18% |
| 85300099 | Eicher Tractor Mandrel Cyl.R Bearing Outer Race     | 3788 | 82060090 | 18% |
| 85300100 | Eicher Tractor Mandrel Oil Seal 18*30*7 G2 Hsg      | 2339 | 82060090 | 18% |
| 85300101 | Eicher Tractor Mandrel Seal Nrb 25*33*20 & Nup      | 5570 | 82060090 | 18% |
| 85300102 | Eicher Tractor Mandrel 6308 In G2 For Pto Shaft     | 8466 | 82060090 | 18% |
| 85300103 | Eicher Tractor Mandrel 6306 In G2 For Pinion        | 7798 | 82060090 | 18% |
| 85300104 | Eicher Tractor Mandrel Oil Seal38*52*7Pto Cover     | 2451 | 82060090 | 18% |
| 85300105 | Eicher Tractor M55*1.5 Groove Nut Tightening        | 4345 | 82060090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 85300106 | Eicher Tractor Fitment Tool Adjust Screw M95*2     | 4010  | 82060090 | 18% |
| 85300107 | Eicher Tractor Assy. Cone For Piston Dia 110       | 4679  | 82060090 | 18% |
| 85300108 | Eicher Tractor Guide Tool For Piston Dia.          | 4456  | 82060090 | 18% |
| 85300109 | Eicher Tractor Tooling For Wynseal (Dia.110)       | 4010  | 82060090 | 18% |
| 85300110 | Eicher Tractor Pin Dia 8Mm                         | 780   | 82060090 | 18% |
| 85300111 | Eicher Tractor Pin Dia 6Mm                         | 780   | 82060090 | 18% |
| 85300112 | Eicher Tractor Pin Dia 4Mm                         | 780   | 82060090 | 18% |
| 85300118 | Eicher Tractor Clutch Centralizer                  | 5947  | 82060090 | 18% |
| 85300119 | Eicher Tractor Handle                              | 2785  | 82060090 | 18% |
| 85300120 | Eicher Tractor Oil Seal Pressing Front Axle        | 5570  | 82060090 | 18% |
| 85300121 | Eicher Tractor Oil Seal Pressing Transmission      | 4456  | 82060090 | 18% |
| 85300122 | Eicher Tractor Lock Nut Tightening Tool            | 5013  | 82060090 | 18% |
| 85300123 | Eicher Tractor Oil Seal Pressing Rear Transimissio | 3788  | 82060090 | 18% |
| 85300124 | Eicher Tractor Hyd. Lift Arm Position Setting Tool | 13925 | 82060090 | 18% |
| 85300125 | Eicher Tractor Steering Wheel & Arm Puller For All | 7115  | 82060090 | 18% |
| 92671136 | Eicher Tractor Housing Cover Front                 | 1438  | 87084000 | 18% |
| 93101078 | Eicher Tractor Alternator With Pulley              | 6556  | 85115000 | 28% |
| 93110059 | Eicher Tractor Indicator Assly. (Elect. Type)      | 609   | 85122010 | 18% |
| 93110126 | Eicher Tractor Blower Support (Stat)               | 1291  | 84091000 | 28% |
| 93110140 | Eicher Tractor Speedo Cable 1316Mm (241/242)       | 317   | 85443000 | 18% |
| 93110199 | Eicher Tractor Valve Guide Inlet-115 Nc(003)       | 66    | 84099111 | 28% |
| 93110205 | Eicher Tractor Valve Guide Inlet-115 Nc(005)       | 54    | 84099111 | 28% |
| 93110217 | Eicher Tractor Valve Guide Inlet-115 Nc(010)       | 59    | 84099111 | 28% |
| 93110242 | Eicher Tractor Valve Guide Exhaust-115 Nc(003)     | 59    | 84099111 | 28% |
| 93110254 | Eicher Tractor Valve Guide Exhaust-115 Nc(005)     | 56    | 84099111 | 28% |
| 93110266 | Eicher Tractor Valve Guide Exhaust-115 Nc(010)     | 56    | 84099111 | 28% |
| 93110291 | Eicher Tractor Valve Guide-115 Old(020)            | 52    | 84099111 | 28% |
| 93110308 | Eicher Tractor Valve Guide-115 Old(015)            | 52    | 84099111 | 28% |
| 93110310 | Eicher Tractor Valve Guide-115 Old(010)            | 52    | 84099111 | 28% |
| 93110321 | Eicher Tractor Valve Guide-115 Old(005)            | 54    | 84099111 | 28% |
| 93110333 | Eicher Tractor Valve Guide-115 Old(003)            | 52    | 84099111 | 28% |
| 93110345 | Eicher Tractor Cylinder Clamping Rod               | 440   | 84129090 | 18% |
| 93110357 | Eicher Tractor Fuel Pipe(Filter To Pump)           | 266   | 84219900 | 18% |
| 93110369 | Eicher Tractor Wire Basket Assly. Right            | 275   | 84099941 | 28% |
| 93110370 | Eicher Tractor Wire Basket Assly. Left             | 299   | 84099941 | 28% |
| 93110382 | Eicher Tractor Inlet Valve Seat                    | 246   | 84099941 | 28% |
| 93110394 | Eicher Tractor Exhaust Valve Seat                  | 216   | 84099941 | 28% |
| 93110400 | Eicher Tractor Fly Wheel-115                       | 19529 | 84835010 | 18% |
| 93110412 | Eicher Tractor Ring Gear (115)                     | 2966  | 84835090 | 18% |
| 93110461 | Eicher Tractor Air Inlet Hose                      | 108   | 40093100 | 18% |
| 93110564 | Eicher Tractor Air Intake Pipe                     | 317   | 40093100 | 18% |
| 93110606 | Eicher Tractor O Ring For D.C.Lever (115E)         | 4     | 40169320 | 18% |
| 93110620 | Eicher Tractor Control Hsg Machined                | 6135  | 84099941 | 28% |
| 93110631 | Eicher Tractor Special Bolt M8X45                  | 17    | 73181500 | 18% |
| 93110667 | Eicher Tractor Side (115 Ricardo)                  | 261   | 84099941 | 28% |
| 93110679 | Eicher Tractor Decompression Rod Assy              | 74    | 84099941 | 28% |
| 93110680 | Eicher Tractor Fuel Injection Duct Assly.-115      | 523   | 84099941 | 28% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93110692 | Eicher Tractor D.C. Lever Assly.                   | 207   | 84099941 | 28% |
| 93110746 | Eicher Tractor Hour Cum Rpm Meter-Indication       | 1094  | 85122010 | 18% |
| 93110801 | Eicher Tractor Plastic Cover (Hyd.Pump Mtg.Hole)   | 33    | 39021000 | 18% |
| 93110837 | Eicher Tractor Gasket For Cover                    | 14    | 68129922 | 18% |
| 93110849 | Eicher Tractor Bush For Cont.Hsg                   | 254   | 84099941 | 28% |
| 93110850 | Eicher Tractor Special Screw                       | 26    | 73181500 | 18% |
| 93110904 | Eicher Tractor Adaptor Plate                       | 90    | 87085000 | 18% |
| 93110916 | Eicher Tractor Dipstick Assly.-115                 | 67    | 84099941 | 28% |
| 93110928 | Eicher Tractor Speedo Cable (Engine Side)          | 179   | 84099990 | 28% |
| 93110930 | Eicher Tractor Speedo Cable (Dashboard Side)       | 147   | 84099990 | 28% |
| 93110965 | Eicher Tractor Pump Driving Gear                   | 726   | 87084000 | 18% |
| 93110989 | Eicher Tractor Carter M/Cd                         | 30062 | 84831099 | 18% |
| 93110990 | Eicher Tractor Oil Filter Head 115                 | 553   | 84219900 | 18% |
| 93111003 | Eicher Tractor Carter Machined                     | 32174 | 84831099 | 18% |
| 93111040 | Eicher Tractor Gasket For Oil Filter Head          | 16    | 84219900 | 18% |
| 93111064 | Eicher Tractor Suction Screen Assy                 | 251   | 84099941 | 28% |
| 93111076 | Eicher Tractor Gasket For Control Hsg.             | 130   | 68129922 | 18% |
| 93111088 | Eicher Tractor Crank Shaft Gear-115                | 970   | 87084000 | 18% |
| 93111118 | Eicher Tractor Oil Pump Assly.                     | 2074  | 84099941 | 28% |
| 93111167 | Eicher Tractor Control Hsg. M/Cd-115E              | 7690  | 84099941 | 28% |
| 93111192 | Eicher Tractor Special Washer Ø44                  | 31    | 73182990 | 18% |
| 93111295 | Eicher Tractor Oil Filter Element Kit              | 91    | 84219900 | 18% |
| 93111313 | Eicher Tractor Cyclopack Ring M8                   | 214   | 84099941 | 28% |
| 93111325 | Eicher Tractor Lid Assly M8                        | 238   | 84099941 | 28% |
| 93111349 | Eicher Tractor Cap Nut M8                          | 30    | 73181500 | 18% |
| 93111350 | Eicher Tractor Stud For Cyclopack Ring (M8)        | 24    | 73182100 | 18% |
| 93111362 | Eicher Tractor Gasket (Control Hsg.)               | 137   | 68129922 | 18% |
| 93111374 | Eicher Tractor Stopper                             | 69    | 84099941 | 28% |
| 93111398 | Eicher Tractor Special Bolt M12X1.5X50             | 109   | 73181500 | 18% |
| 93111489 | Eicher Tractor Fuel Injection Pipe Assy.-115E      | 415   | 84099990 | 28% |
| 93111490 | Eicher Tractor Bush For Cont Hsg                   | 221   | 84099941 | 28% |
| 93111519 | Eicher Tractor Pointer (115)                       | 18    | 84099941 | 28% |
| 93111600 | Eicher Tractor Bearing Flange                      | 277   | 84099941 | 28% |
| 93111623 | Eicher Tractor Link                                | 307   | 84099941 | 28% |
| 93111635 | Eicher Tractor Torsion Spring                      | 12    | 73202000 | 18% |
| 93111805 | Eicher Tractor Fuel Duct Assy (With Protection Tub | 465   | 84099941 | 28% |
| 93111817 | Eicher Tractor Fuel Injection Pump .-115E Trem -3  | 11508 | 84133010 | 28% |
| 93111829 | Eicher Tractor Roller Tappet .                     | 1432  | 84824000 | 18% |
| 93111878 | Eicher Tractor PECIAL Nut (For Cyl Clamping Rod)   | 91    | 84099941 | 28% |
| 93111891 | Eicher Tractor Special Washer                      | 84    | 73182990 | 18% |
| 93111908 | Eicher Tractor Special Flange Bolt (For Idler Shaf | 66    | 73181500 | 18% |
| 93111921 | Eicher Tractor Idler Gear Sub-Assly.               | 968   | 84831099 | 18% |
| 93111982 | Eicher Tractor Bearing Flange                      | 245   | 84099941 | 28% |
| 93111994 | Eicher Tractor Hour Meter Flange                   | 75    | 84099941 | 28% |
| 93112019 | Eicher Tractor Gasket For Exhaust                  | 36    | 73182200 | 18% |
| 93112135 | Eicher Tractor Decompression Lever                 | 325   | 84099941 | 28% |
| 93112147 | Eicher Tractor Blower Support                      | 1338  | 84091000 | 28% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93112159 | Eicher Tractor Silencer 24Hp                   | 2845 | 87089200 | 18% |
| 93112172 | Eicher Tractor Intake Pipe                     | 755  | 87089900 | 18% |
| 93112184 | Eicher Tractor Air Inlet Hose (A/C Side)       | 179  | 40093100 | 18% |
| 93112196 | Eicher Tractor Air Inlet Hose (Cly Head Side)  | 313  | 40093100 | 18% |
| 93112214 | Eicher Tractor Exhaust Manifold                | 622  | 84099941 | 28% |
| 93112299 | Eicher Tractor Governor Lever                  | 184  | 84099941 | 28% |
| 93112305 | Eicher Tractor Governor Shaft                  | 139  | 84099941 | 28% |
| 93112354 | Eicher Tractor Air Intake Pipe 115 Ve          | 534  | 40093100 | 18% |
| 93112378 | Eicher Tractor Blower Shaft- 115Ve             | 533  | 84099941 | 28% |
| 93112482 | Eicher Tractor Oil Filter Element Small        | 309  | 84219900 | 18% |
| 93112500 | Eicher Tractor Insert Bush 115 Ve              | 246  | 84831099 | 18% |
| 93112548 | Eicher Tractor Extension-115Ve                 | 350  | 84099941 | 28% |
| 93112597 | Eicher Tractor Closing Cap Assly. -115 Ve      | 234  | 84099941 | 28% |
| 93112640 | Eicher Tractor Control Housing Machined 115E   | 8385 | 84099941 | 28% |
| 93112755 | Eicher Tractor Idler Shaft                     | 551  | 84099941 | 28% |
| 93112779 | Eicher Tractor Idler Gear Sub-Assly.           | 1255 | 87084000 | 18% |
| 93112792 | Eicher Tractor Support Tube-115 Ve             | 1060 | 84099941 | 28% |
| 93112822 | Eicher Tractor Cam Shaft Sub Assy              | 2136 | 84831092 | 18% |
| 93112846 | Eicher Tractor Fuel Injection Pipe Assy-115E   | 546  | 84099990 | 28% |
| 93112858 | Eicher Tractor Cam Shaft                       | 1314 | 84831092 | 18% |
| 93112883 | Eicher Tractor Air Cleaner Assy (Round)        | 4342 | 84099941 | 28% |
| 93112895 | Eicher Tractor Air Cleaner Assy (Jbm)          | 4999 | 84099941 | 28% |
| 93112913 | Eicher Tractor Cyclopack Ring                  | 235  | 84099941 | 28% |
| 93112949 | Eicher Tractor Tube Assy.                      | 429  | 84099941 | 28% |
| 93112950 | Eicher Tractor Pre Cleaner Assy.               | 585  | 84099941 | 28% |
| 93113036 | Eicher Tractor Fuel Injection Pump .-115E      | 2432 | 84133010 | 28% |
| 93113048 | Eicher Tractor Injector Assy-115E              | 6992 | 84099990 | 28% |
| 93113061 | Eicher Tractor Crank Pulley 115 Ricardo (15")  | 974  | 84835010 | 18% |
| 93113115 | Eicher Tractor Plastic Cover For O.F. Head     | 19   | 39021000 | 18% |
| 93113140 | Eicher Tractor Bearing Housing                 | 4267 | 84099941 | 28% |
| 93113164 | Eicher Tractor Control Rod Assy.               | 27   | 84099941 | 28% |
| 93113176 | Eicher Tractor Gasket For Silencer             | 75   | 68129090 | 18% |
| 93113188 | Eicher Tractor Tappet Body Sub Assy            | 217  | 84099941 | 28% |
| 93113255 | Eicher Tractor Crank Pulley                    | 1170 | 84835010 | 18% |
| 93113267 | Eicher Tractor Blower Pulley                   | 515  | 84099941 | 28% |
| 93113279 | Eicher Tractor Pointer                         | 35   | 84099941 | 28% |
| 93113310 | Eicher Tractor Inlet Valve 115 ( Trem3 A) \$   | 276  | 84099111 | 28% |
| 93113323 | Eicher Tractor Exhaust Valve 115(Trem-3A) \$   | 242  | 84099111 | 28% |
| 93113334 | Eicher Tractor Cyliner Liner Finish 115 Ricaro | 2648 | 84099941 | 28% |
| 93113383 | Eicher Tractor Plug For Support Tube           | 2    | 84099941 | 28% |
| 93113401 | Eicher Tractor R.P.M.Setting Bolt 6X40         | 32   | 73181500 | 18% |
| 93113425 | Eicher Tractor Torsion Spring                  | 11   | 73202000 | 18% |
| 93113486 | Eicher Tractor Cylindrical Pin \$              | 14   | 84129090 | 18% |
| 93113498 | Eicher Tractor Lid \$                          | 1704 | 84099941 | 28% |
| 93113504 | Eicher Tractor Blower Shaft Assly.             | 3574 | 84099941 | 28% |
| 93113528 | Eicher Tractor Exhaust Valve                   | 240  | 84099941 | 28% |
| 93113530 | Eicher Tractor Special Hex Screw               | 14   | 73181500 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93113541 | Eicher Tractor Inlet Valve                         | 287   | 84099941 | 28% |
| 93113589 | Eicher Tractor Cyl.Head Sub Assly.                 | 5509  | 76169990 | 18% |
| 93113607 | Eicher Tractor Rocker Arm Housing \$               | 2185  | 84099941 | 28% |
| 93113656 | Eicher Tractor Cam Shaft Sub Assy 115 (Trem-3A) \$ | 2230  | 84831099 | 18% |
| 93113668 | Eicher Tractor Inlet Valve Seat 115(-Trem3 A) \$   | 228   | 84099941 | 28% |
| 93113670 | Eicher Tractor Exhaust Valve Seat 115 (Trem3 A)\$  | 216   | 84099941 | 28% |
| 93113693 | Eicher Tractor Injector Assy-115 (Trem 3 A) \$     | 4995  | 84099990 | 28% |
| 93113707 | Eicher Tractor Fuel Injection Pipe Assy-115 (Trem- | 568   | 84099990 | 28% |
| 93113723 | Eicher Tractor Cyl Head Sub Assly.-115E (Trem-3)   | 10838 | 76169990 | 18% |
| 93113735 | Eicher Tractor Fuel Injection Pump.-115(Trem-3A)\$ | 4924  | 84133010 | 28% |
| 93113784 | Eicher Tractor Crank Pulley 115 (Trem-3A) \$-(9")  | 1038  | 84835010 | 18% |
| 93113838 | Eicher Tractor Idler Pulley Bracket                | 156   | 84099941 | 28% |
| 93113863 | Eicher Tractor Solenoid Assy (222Es)Long Couple \$ | 2171  | 85365090 | 18% |
| 93113966 | Eicher Tractor Cyl Head Gasket 0.30(Yellow)        | 68    | 74152900 | 18% |
| 93113978 | Eicher Tractor Cyl Head Gasket 0.45(Green)         | 97    | 74152900 | 18% |
| 93113980 | Eicher Tractor Cyl Head Gasket 0.60(Red)           | 119   | 74152900 | 18% |
| 93113991 | Eicher Tractor Cyl Head Gasket 0.75(Black)         | 163   | 74152900 | 18% |
| 93114004 | Eicher Tractor Cyl Head Gasket 0.90(White)         | 188   | 74152900 | 18% |
| 93114119 | Eicher Tractor Crank Shaft W/O Wts                 | 10967 | 84831092 | 18% |
| 93114120 | Eicher Tractor Spacer Rear                         | 361   | 73182100 | 18% |
| 93114132 | Eicher Tractor Crank Shaft Sub Assly.              | 14206 | 84831092 | 18% |
| 93114259 | Eicher Tractor Carter M/Cd(115R/Esg)(Vave) (Finesh | 28021 | 84831099 | 18% |
| 93114260 | Eicher Tractor Upper Housing Assy.222Esg(Vave)     | 675   | 84099990 | 28% |
| 93114284 | Eicher Tractor Fly Wheel-115                       | 29237 | 84099941 | 28% |
| 93114338 | Eicher Tractor Carter Machined(115Es/Hs)           | 33463 | 84099941 | 28% |
| 93114521 | Eicher Tractor Extension Tube(Hs/Es Vave Model)    | 389   | 84099941 | 28% |
| 93114533 | Eicher Tractor Crank Pulley                        | 1131  | 84835010 | 18% |
| 93114557 | Eicher Tractor Lid 115 Auto                        | 1560  | 84099941 | 28% |
| 93114569 | Eicher Tractor Plug For Lid                        | 111   | 84099941 | 28% |
| 93114715 | Eicher Tractor Insert Bush Assly 222Esg            | 448   | 84099941 | 28% |
| 93114855 | Eicher Tractor Insert Bush Assy                    | 396   | 84099941 | 28% |
| 93120119 | Eicher Tractor Air Intake Tube(315Mm)              | 289   | 84099941 | 28% |
| 93120286 | Eicher Tractor 54S30034 = Manifold, Exhaust        | 1324  | 84099941 | 28% |
| 93121045 | Eicher Tractor Piston -98 Series (Trem-3A)198      | 2487  | 84099112 | 28% |
| 93121148 | Eicher Tractor Crank Shaft Sub Assy-198            | 13364 | 84831092 | 18% |
| 93121185 | Eicher Tractor Push Rod Tube Assy-198              | 169   | 84099941 | 28% |
| 93121227 | Eicher Tractor Push Rod Assy (Steel)198            | 127   | 84099990 | 28% |
| 93121239 | Eicher Tractor Bracket For Adjusting Latch-198     | 247   | 84099941 | 28% |
| 93121240 | Eicher Tractor Bracket, Alternator Mounting-198    | 889   | 84099941 | 28% |
| 93121276 | Eicher Tractor Oil Gallery Tube Assy-198           | 225   | 84099941 | 28% |
| 93121343 | Eicher Tractor Dipstick Assy (198 Esg)             | 64    | 84099941 | 28% |
| 93121380 | Eicher Tractor Cylinder Clamping Rod198            | 212   | 84099941 | 28% |
| 93121434 | Eicher Tractor Starter Motor Assembly (Panalfa Mak | 11570 | 85114000 | 28% |
| 93121458 | Eicher Tractor Adjusting Latch198                  | 346   | 84099941 | 28% |
| 93121677 | Eicher Tractor Cylinder Liner-198                  | 4414  | 84099941 | 28% |
| 93121690 | Eicher Tractor Flywheel M/C-198                    | 20321 | 84835010 | 18% |
| 93121707 | Eicher Tractor Flywheel Casing M/C-198Esg/322Esg/4 | 8327  | 84099949 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93121732 | Eicher Tractor Oil Feed Pipe Assy198               | 354   | 84099941 | 28% |
| 93121951 | Eicher Tractor Fuel Pipe Assy (Fuel Tank To Feed P | 469   | 84099941 | 28% |
| 93122141 | Eicher Tractor Governor Sleeve198                  | 842   | 84099941 | 28% |
| 93122153 | Eicher Tractor Governor Flange-198                 | 702   | 84099941 | 28% |
| 93122177 | Eicher Tractor Governor Cover-142/198              | 904   | 84099941 | 28% |
| 93122219 | Eicher Tractor Gasket For Pump Base-198            | 8     | 68129922 | 18% |
| 93122220 | Eicher Tractor Pump Base198                        | 1978  | 84099941 | 28% |
| 93122256 | Eicher Tractor Spring Housing Bracket-142 Hs/Es    | 333   | 73209090 | 18% |
| 93122268 | Eicher Tractor Bracket For Gov. Setting Bolt-198   | 446   | 84099941 | 28% |
| 93122323 | Eicher Tractor Balance Weight-198                  | 1086  | 84099941 | 28% |
| 93122396 | Eicher Tractor Tappet Body Sub Assy 198Esg/Es      | 204   | 84099941 | 28% |
| 93122402 | Eicher Tractor Control Housing M/C 198Es/Esg       | 3181  | 84099941 | 28% |
| 93122438 | Eicher Tractor Bearing Housing Rear-198            | 2292  | 84099941 | 28% |
| 93122440 | Eicher Tractor Lifter Guide-198                    | 262   | 84099941 | 28% |
| 93122487 | Eicher Tractor Governor Fork Assembly-198          | 628   | 84099941 | 28% |
| 93122499 | Eicher Tractor Gasket For Governor Cover-198       | 15    | 68129922 | 18% |
| 93122517 | Eicher Tractor Control Rod Assembly-198            | 154   | 84099941 | 28% |
| 93122566 | Eicher Tractor Fuel Feed Pump Assembly (Sonic Make | 1394  | 84133010 | 28% |
| 93122608 | Eicher Tractor Solenoid Assy198                    | 2748  | 84818050 | 18% |
| 93122610 | Eicher Tractor Governor Lever Assy-198             | 397   | 84099941 | 28% |
| 93122657 | Eicher Tractor Spring Lever Sub. Assembly-198      | 271   | 84099941 | 28% |
| 93122669 | Eicher Tractor Bracket For Hand Accelerator-198    | 157   | 84099941 | 28% |
| 93122670 | Eicher Tractor Hand Accelerator Rod-198            | 260   | 84099941 | 28% |
| 93122682 | Eicher Tractor Adjusting Nut (For Hand Accelerator | 173   | 73181500 | 18% |
| 93122694 | Eicher Tractor Rigid Fuel Pipe Assembly With Clamp | 635   | 40094200 | 18% |
| 93122712 | Eicher Tractor Suction Screen Assy-198             | 212   | 84099941 | 28% |
| 93122761 | Eicher Tractor Governor Weight-198                 | 1069  | 84099941 | 28% |
| 93122852 | Eicher Tractor Cam Shaft-142Es/Hs(Agro)            | 2051  | 84831099 | 18% |
| 93122876 | Eicher Tractor Camshaft M/C 9 Deg                  | 2830  | 84831099 | 18% |
| 93122906 | Eicher Tractor Gasket For Spacer (Feed Pump)-198   | 9     | 68129922 | 18% |
| 93122955 | Eicher Tractor Compression Spring - Spring Hsg(1   | 30    | 73202000 | 18% |
| 93122967 | Eicher Tractor Compression Spring – Gov. Sleeve-19 | 29    | 73202000 | 18% |
| 93122992 | Eicher Tractor Flywheel -142Es/Hs(Agro)            | 14527 | 84835010 | 18% |
| 93123005 | Eicher Tractor Exhaust Manifold-198Es/Esg          | 597   | 84099941 | 28% |
| 93123029 | Eicher Tractor Control Panel-198                   | 752   | 84099941 | 28% |
| 93123030 | Eicher Tractor Nlet Hose - Wet Air Cleaner-198     | 586   | 40093100 | 18% |
| 93123042 | Eicher Tractor Bracket Cum Lifting Hook(198)       | 1452  | 84099941 | 28% |
| 93123054 | Eicher Tractor Bracket For Air Cleaner (F)198      | 538   | 84099990 | 28% |
| 93123078 | Eicher Tractor Fuel Tank Assy-142Es/Hs(Agro)       | 4275  | 84099941 | 28% |
| 93123080 | Eicher Tractor Flywheel Casing -142Es/Hs(Agro)     | 6227  | 84099941 | 28% |
| 93123091 | Eicher Tractor Blower Fan Assembly-198             | 3763  | 84099941 | 28% |
| 93123110 | Eicher Tractor Crank Pulley - 142 (Hs/Es ) 24"     | 1659  | 84835010 | 18% |
| 93123145 | Eicher Tractor V-Belt Cogged Type Xpa 882(198)     | 313   | 40101290 | 18% |
| 93123157 | Eicher Tractor Fuel Pipe Assy (Ff To Fip)          | 263   | 40092200 | 18% |
| 93123170 | Eicher Tractor Fuel Injection Pump-198             | 5277  | 84133010 | 28% |
| 93123194 | Eicher Tractor Air Cleaner Mtg. Clamp              | 668   | 84219900 | 18% |
| 93123200 | Eicher Tractor A/C Assembly With Clamp198          | 3598  | 84213920 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93123212 | Eicher Tractor Spring Housing-198                   | 446  | 84099941 | 28% |
| 93123224 | Eicher Tractor Inlet Hose - Dry Air Cleaner-198     | 520  | 40093100 | 18% |
| 93123236 | Eicher Tractor Mounting Clamp For Wet A/C           | 158  | 84099990 | 28% |
| 93123248 | Eicher Tractor Fuel Injection Pipe Assy (198)       | 738  | 84099941 | 28% |
| 93123261 | Eicher Tractor Starting Handle Adaptor -142Es/Hs(A) | 1488 | 84099941 | 28% |
| 93123273 | Eicher Tractor Wet Air Cleaner -198                 | 1863 | 84099941 | 28% |
| 93123285 | Eicher Tractor Rubber Flap-198                      | 111  | 40169320 | 18% |
| 93123297 | Eicher Tractor Starting Handle(142Es/Hs)-198        | 487  | 84099941 | 28% |
| 93123303 | Eicher Tractor Decompression Lever 142Es/Hs         | 340  | 84099941 | 28% |
| 93123315 | Eicher Tractor Cylinder Head Cover-198              | 1204 | 84099941 | 28% |
| 93123340 | Eicher Tractor Belt Guard Assembly-198              | 1305 | 85030090 | 18% |
| 93123352 | Eicher Tractor Fan Cover Front Assembly-198         | 4416 | 85030090 | 18% |
| 93123388 | Eicher Tractor Exhaust Extension-198G/S             | 628  | 84099949 | 28% |
| 93123443 | Eicher Tractor Timing Pointer-198                   | 157  | 84099941 | 28% |
| 93123480 | Eicher Tractor Fuel Filter Mtg. Bracket-198         | 176  | 84219900 | 18% |
| 93123492 | Eicher Tractor Wiring Harness 142Ag198              | 367  | 85444220 | 18% |
| 93123534 | Eicher Tractor Spindle-198                          | 402  | 84099941 | 28% |
| 93123546 | Eicher Tractor Plug-198                             | 371  | 84099941 | 28% |
| 93123558 | Eicher Tractor Holding Flange                       | 378  | 84099941 | 28% |
| 93123571 | Eicher Tractor Cover Control Panel                  | 337  | 84099941 | 28% |
| 93123583 | Eicher Tractor Idler Pulley(198)                    | 290  | 84099941 | 28% |
| 93123595 | Eicher Tractor Bracket Idler198                     | 468  | 84099941 | 28% |
| 93123601 | Eicher Tractor Breather Pipe-198Es(198)             | 141  | 85462019 | 28% |
| 93123625 | Eicher Tractor Speedo Cable Assly-198               | 202  | 90299000 | 18% |
| 93123637 | Eicher Tractor Hour Meter 198                       | 633  | 90292090 | 18% |
| 93123649 | Eicher Tractor Oil Seal 20*42*6                     | 65   | 84099941 | 28% |
| 93123674 | Eicher Tractor Strip For Stopping Wire-198          | 209  | 84099941 | 28% |
| 93123765 | Eicher Tractor Evacuator Valve                      | 85   | 84219900 | 18% |
| 93123777 | Eicher Tractor Cover Assy                           | 599  | 84219900 | 18% |
| 93123790 | Eicher Tractor Air Cleaner Element                  | 983  | 84219900 | 18% |
| 93123807 | Eicher Tractor Dust Valve Cap                       | 35   | 40169320 | 18% |
| 93123819 | Eicher Tractor Oil Pan With Pan Bracket             | 349  | 84099941 | 28% |
| 93123820 | Eicher Tractor Main Body Assembly ( With Tube Inle  | 1063 | 84099941 | 28% |
| 93123870 | Eicher Tractor Wire Mesh Assembly For Oil Pan       | 494  | 84099941 | 28% |
| 93123881 | Eicher Tractor Pre Cleaner Assembly With Bowl And   | 476  | 84099941 | 28% |
| 93123893 | Eicher Tractor Gasket                               | 68   | 68129922 | 18% |
| 93123900 | Eicher Tractor C Lamp For Pre Cleaner               | 51   | 84219900 | 18% |
| 93124010 | Eicher Tractor Anjo Bolt Front)-198                 | 59   | 73181500 | 18% |
| 93124022 | Eicher Tractor Fuel Pipe Assly-198                  | 379  | 84099941 | 28% |
| 93124058 | Eicher Tractor Single Row Deep Groove Ball Bearing  | 381  | 84822090 | 18% |
| 93124204 | Eicher Tractor Split Pin 3X37 142Hs                 | 5    | 84099941 | 28% |
| 93124228 | Eicher Tractor Spool Pin (For Starting Handle)      | 45   | 84099941 | 28% |
| 93124230 | Eicher Tractor Spring (For Spool Pin) 142Hs         | 9    | 84099941 | 28% |
| 93124253 | Eicher Tractor Compression Spring-Gov Sleeve 198Es  | 40   | 73202000 | 18% |
| 93124265 | Eicher Tractor Compression Spring -Spring Hsg 198   | 37   | 73202000 | 18% |
| 93124332 | Eicher Tractor Spring Disc(198)                     | 274  | 84099990 | 28% |
| 93124381 | Eicher Tractor Crank Pulley - 198Es Genset(13")     | 1737 | 84835010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93124526 | Eicher Tractor Hex Bolt M6 For Cowling             | 78    | 73181500 | 18% |
| 93124617 | Eicher Tractor Hour Cum Rpm Meter 142Es-Hs         | 2467  | 90292090 | 18% |
| 93124629 | Eicher Tractor Control Panel                       | 742   | 84099941 | 28% |
| 93124691 | Eicher Tractor Control Housing M/C 142 Hs          | 3629  | 84099941 | 28% |
| 93124708 | Eicher Tractor Gasket For Cover 142Hs              | 67    | 68129090 | 18% |
| 93124721 | Eicher Tractor Cover                               | 2143  | 84099941 | 28% |
| 93124733 | Eicher Tractor Drive Shaft 142Hs                   | 1138  | 84099941 | 28% |
| 93124745 | Eicher Tractor Gear Drive 142Hs                    | 2985  | 84099941 | 28% |
| 93124757 | Eicher Tractor Timing Pointer-142Hs                | 76    | 84099941 | 28% |
| 93124873 | Eicher Tractor Foam                                | 119   | 39219099 | 18% |
| 93124885 | Eicher Tractor Oil Bath Air Cleaner Assembly       | 2508  | 84099990 | 28% |
| 93124952 | Eicher Tractor Fuel Filter Bracket Mtg Brkt Cum Co | 153   | 84219900 | 18% |
| 93124988 | Eicher Tractor Control Panel 142Hs                 | 830   | 84099941 | 28% |
| 93124990 | Eicher Tractor Crank Shaft Sub Assly               | 4318  | 84831092 | 18% |
| 93125038 | Eicher Tractor Balance Weight                      | 943   | 84099941 | 28% |
| 93125063 | Eicher Tractor Adaptor For Oil Filter              | 132   | 87089900 | 18% |
| 93125075 | Eicher Tractor Gasket For Control Housing          | 130   | 68129922 | 18% |
| 93125099 | Eicher Tractor Dust Cap 142Hs                      | 37    | 84099941 | 28% |
| 93125117 | Eicher Tractor Locking Knob 142Hs                  | 113   | 84099941 | 28% |
| 93125142 | Eicher Tractor Big End Bearing 422Es(T.C)          | 228   | 84821011 | 18% |
| 93125178 | Eicher Tractor Crank Shaft Gear Chotu              | 1063  | 87084000 | 18% |
| 93125208 | Eicher Tractor Gasket For Bearing Housing          | 50    | 68129922 | 18% |
| 93125210 | Eicher Tractor L.O.P Driving Gear Chotu            | 696   | 87084000 | 18% |
| 93125257 | Eicher Tractor Cam Shaft Chotu                     | 2742  | 84831092 | 18% |
| 93125269 | Eicher Tractor Cylinder Clamping Rod               | 232   | 84099941 | 28% |
| 93125336 | Eicher Tractor Cylinder Liner Finish               | 3968  | 84099941 | 28% |
| 93125348 | Eicher Tractor Piston -98 Series Chotu             | 2866  | 84099112 | 28% |
| 93125415 | Eicher Tractor Flywheel -142 Hs(Agro)              | 11825 | 84835010 | 18% |
| 93125427 | Eicher Tractor L.O.P Driven Gear Chotu             | 749   | 87084000 | 18% |
| 93125439 | Eicher Tractor Push Rod Tube Assy                  | 159   | 84099941 | 28% |
| 93125452 | Eicher Tractor Push Rod Assy ( Steel )(Chhotu)     | 151   | 84099990 | 28% |
| 93125490 | Eicher Tractor Adjusting Shim, 0.2 Mm Thk.         | 8     | 73182100 | 18% |
| 93125518 | Eicher Tractor Ring For Felt Ring                  | 179   | 40169340 | 18% |
| 93125520 | Eicher Tractor Felt Ring Chotu                     | 10    | 40169340 | 18% |
| 93125531 | Eicher Tractor Distance Ring                       | 226   | 40169340 | 18% |
| 93125555 | Eicher Tractor Blower Shaft                        | 669   | 84091000 | 28% |
| 93125579 | Eicher Tractor Collar Ring                         | 209   | 40169340 | 18% |
| 93125609 | Eicher Tractor Top Bracket                         | 211   | 84099941 | 28% |
| 93125610 | Eicher Tractor Front Deflector Assembly Chotu      | 572   | 84099941 | 28% |
| 93125695 | Eicher Tractor Flywheel M/C (Chotu Eng.)           | 9520  | 84835010 | 18% |
| 93125701 | Eicher Tractor Ring Gear (Chotu Eng.)              | 1173  | 84099941 | 28% |
| 93125749 | Eicher Tractor Oil Feed Pipe Assembly (Crankcase T | 274   | 84099941 | 28% |
| 93125750 | Eicher Tractor Wire Rod Assy                       | 108   | 84099941 | 28% |
| 93125762 | Eicher Tractor Bracket For Hand Accelerator Chottu | 173   | 84099941 | 28% |
| 93125798 | Eicher Tractor Piston Pin Chotu                    | 390   | 84099941 | 28% |
| 93125804 | Eicher Tractor Circlip Light B-32, Is:3075-1965 Ch | 10    | 73182910 | 18% |
| 93125816 | Eicher Tractor Piston Ring Set Chotu               | 948   | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93125828 | Eicher Tractor Bush For Conn Rod                   | 1391  | 84099941 | 28% |
| 93125853 | Eicher Tractor Outer Spring (Gov) Chotu            | 206   | 73209090 | 18% |
| 93125907 | Eicher Tractor O-Ring I.D. 43 X Dia 2Mm Chotu      | 12    | 40169340 | 18% |
| 93125920 | Eicher Tractor Adjusting Shim, 0.5 Mm Thk          | 9     | 73182100 | 18% |
| 93125968 | Eicher Tractor Lifter Guide Retainer               | 22    | 84099941 | 28% |
| 93125970 | Eicher Tractor Hshc M12X1.5X60(Grade 12.9          | 45    | 73181500 | 18% |
| 93126092 | Eicher Tractor Exhaust Manifold                    | 358   | 84099941 | 28% |
| 93126146 | Eicher Tractor Spring Housing                      | 462   | 84099941 | 28% |
| 93126377 | Eicher Tractor Gasket Bottom Plate                 | 47    | 45039090 | 18% |
| 93126389 | Eicher Tractor Bottom Plate                        | 374   | 87081010 | 18% |
| 93126602 | Eicher Tractor Bush For Crank Shaft                | 136   | 84839000 | 18% |
| 93126614 | Eicher Tractor Valve Spring Retainer Chotu         | 186   | 73202000 | 18% |
| 93126638 | Eicher Tractor Valve Spring Outer                  | 265   | 73202000 | 18% |
| 93126643 | Eicher Tractor Valve Spring - Inner                | 203   | 73202000 | 18% |
| 93126742 | Eicher Tractor Oil Pump Assy (Chhotu Model)        | 2317  | 84099941 | 28% |
| 93126821 | Eicher Tractor Fuel Injection Pipe Assembly Chotu  | 366   | 84099941 | 28% |
| 93126912 | Eicher Tractor Crank Housing Machined (Chotu Model | 20477 | 84831092 | 18% |
| 93126961 | Eicher Tractor Governor Cover Chotu                | 898   | 40169320 | 18% |
| 93126985 | Eicher Tractor Gasket For Pump Base Chotu          | 7     | 68129922 | 18% |
| 93126997 | Eicher Tractor Pump Base                           | 1373  | 68129922 | 18% |
| 93127000 | Eicher Tractor Gasket For Fuel Feed Pump Chottu    | 5     | 68129922 | 18% |
| 93127060 | Eicher Tractor Cylinder Head Sub Assy              | 6956  | 84099941 | 28% |
| 93127096 | Eicher Tractor Strip For Sealing Cup               | 20    | 73011000 | 18% |
| 93127114 | Eicher Tractor Spring Lever Sub Assy               | 291   | 84099941 | 28% |
| 93127126 | Eicher Tractor Spring Housing Bracket              | 325   | 84099941 | 28% |
| 93127138 | Eicher Tractor Bearing Housing Rear Chotu          | 2594  | 84099941 | 28% |
| 93127175 | Eicher Tractor Rear Deflector Assy Chotu           | 547   | 84099941 | 28% |
| 93127187 | Eicher Tractor Impeller Housing Assy.              | 321   | 84099941 | 28% |
| 93127217 | Eicher Tractor Connecting Rod Sub Assy             | 2970  | 87089900 | 18% |
| 93127254 | Eicher Tractor Governor Sleeve                     | 767   | 84099941 | 28% |
| 93127266 | Eicher Tractor Ring For Governor Sleeve            | 397   | 40169340 | 18% |
| 93127280 | Eicher Tractor Deep Groove Ball Bearing            | 580   | 84821011 | 18% |
| 93127291 | Eicher Tractor Circlip 35 X 1.5 N Is:3075 (Part 1) | 14    | 73182910 | 18% |
| 93127308 | Eicher Tractor Circlip 55 X 2 N Is:3075 (Part 2    | 17    | 73182910 | 18% |
| 93127400 | Eicher Tractor Fuel Feed Pump Chotu                | 2676  | 84133010 | 28% |
| 93127424 | Eicher Tractor Blower Pulley                       | 601   | 84099941 | 28% |
| 93127436 | Eicher Tractor Wiring Harness -142Es               | 570   | 85444220 | 18% |
| 93127461 | Eicher Tractor Fuel Injection Pump (Chotu Eng.)    | 6200  | 84133010 | 28% |
| 93127473 | Eicher Tractor Csk Screw M8X1.25X16                | 8     | 73181500 | 18% |
| 93127485 | Eicher Tractor Oil Suction Screen Assy             | 446   | 84099941 | 28% |
| 93127497 | Eicher Tractor Hex Thin Nut M20X1.5                | 39    | 73181500 | 18% |
| 93127564 | Eicher Tractor Starter Motor-Chhotu                | 10938 | 85114000 | 28% |
| 93127576 | Eicher Tractor Governor Weight                     | 1170  | 84099941 | 28% |
| 93127588 | Eicher Tractor Governor Fork                       | 561   | 84099941 | 28% |
| 93127606 | Eicher Tractor Sealing Washer 22X27                | 10    | 73182990 | 18% |
| 93127618 | Eicher Tractor Cylinder Head Cover                 | 1038  | 84099941 | 28% |
| 93127620 | Eicher Tractor Governor Lever Assy.                | 290   | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93127679 | Eicher Tractor Injector Assembly(Chhotu) 6Ye       | 5014  | 84099990 | 28% |
| 93127760 | Eicher Tractor Identification Plate                | 41    | 87089400 | 18% |
| 93127795 | Eicher Tractor Front Blower Support-Chhotu         | 1154  | 84099941 | 28% |
| 93127813 | Eicher Tractor Breather Assembly-Chhotu            | 1426  | 84099941 | 28% |
| 93127837 | Eicher Tractor Sticker Hand Start 142Hs            | 25    | 48114100 | 18% |
| 93127862 | Eicher Tractor Cooling Impeller-Chhotu             | 460   | 84099941 | 28% |
| 93127953 | Eicher Tractor Insert Bush Assy-Chhotu             | 369   | 84099941 | 28% |
| 93127977 | Eicher Tractor Baffle For Breather Assy            | 65    | 39021000 | 18% |
| 93128003 | Eicher Tractor Plastic Plug For Size -M12-Chhotu   | 7     | 39021000 | 18% |
| 93128015 | Eicher Tractor Plastic Plug For Size -M10-Chhotu   | 6     | 39021000 | 18% |
| 93128027 | Eicher Tractor Plastic Plug For Size -M14-Chhotu   | 5     | 39021000 | 18% |
| 93128088 | Eicher Tractor Governor Lever-Chhotu               | 297   | 84099941 | 28% |
| 93128090 | Eicher Tractor Crank Pulley Chhotu                 | 1709  | 84835010 | 18% |
| 93128106 | Eicher Tractor Bracket For Gov. Setting Bolt-Chhot | 49    | 87089900 | 18% |
| 93128118 | Eicher Tractor Control Housing(Chhotu)             | 4537  | 84099941 | 28% |
| 93128143 | Eicher Tractor Governor Shaft(Chhotu)              | 329   | 84099941 | 28% |
| 93128180 | Eicher Tractor Temperature Sensor-Chhotu           | 160   | 90268090 | 18% |
| 93128246 | Eicher Tractor Exhaust Manifold(Chhotu)            | 534   | 84099941 | 28% |
| 93128350 | Eicher Tractor Dipstick Assy(Chhotu)               | 135   | 87084000 | 18% |
| 93128362 | Eicher Tractor Flange For Dipstick Assly(Chhotu)   | 257   | 84099941 | 28% |
| 93128568 | Eicher Tractor Deep Groove Ball Bearing 6005-2Rsr  | 332   | 84821011 | 18% |
| 93128593 | Eicher Tractor Starter Motor Assy                  | 8962  | 85114000 | 28% |
| 93130058 | Eicher Tractor Inlet Manifold Rear                 | 711   | 84099941 | 28% |
| 93130113 | Eicher Tractor Speedo Cable 1616Mm (243,312,364,36 | 302   | 85443000 | 18% |
| 93130204 | Eicher Tractor Fly Wheel-298                       | 14659 | 84835010 | 18% |
| 93130265 | Eicher Tractor Inlet Manifold Front                | 669   | 84099941 | 28% |
| 93130289 | Eicher Tractor Rubber Hose                         | 93    | 40093100 | 18% |
| 93130319 | Eicher Tractor Fuel Inj. Pump-298Ei                | 30377 | 84099941 | 28% |
| 93130344 | Eicher Tractor Cam Shaft M/C-298 (Chilled)         | 5588  | 84831099 | 18% |
| 93130370 | Eicher Tractor Bracket For Air Cleaner             | 220   | 84099941 | 28% |
| 93130411 | Eicher Tractor Lifter Guide                        | 279   | 84099941 | 28% |
| 93130538 | Eicher Tractor Dipstick Assly.-298Ei               | 77    | 84099941 | 28% |
| 93130575 | Eicher Tractor Special Washer (Push Rod Tube)      | 4     | 73182990 | 18% |
| 93130654 | Eicher Tractor Inlet Rocker Arm Assly.             | 617   | 84099941 | 28% |
| 93130680 | Eicher Tractor Exhaust Rocker Arm Assly.           | 473   | 84099941 | 28% |
| 93130770 | Eicher Tractor Driving Gear (Crank Shaft)          | 1225  | 87084000 | 18% |
| 93130824 | Eicher Tractor Rigid Fuel Pipe Assy(Fip Over Flow- | 463   | 40094200 | 18% |
| 93130885 | Eicher Tractor Fuel Inj. Pipe Assly. Set-298Ei     | 695   | 84099990 | 28% |
| 93130952 | Eicher Tractor Control Hsg M/Cd                    | 4086  | 84099941 | 28% |
| 93130964 | Eicher Tractor Cover For Cont. Hsg.                | 141   | 84099941 | 28% |
| 93130976 | Eicher Tractor Gasket (Cover For Cont. Hsg.)       | 14    | 68129922 | 18% |
| 93130988 | Eicher Tractor Gasket-Fuel Pump(Ei)                | 16    | 68129922 | 18% |
| 93131002 | Eicher Tractor Valve Spring Retainer               | 80    | 73202000 | 18% |
| 93131014 | Eicher Tractor Link For Wire Rod-298Ei             | 29    | 84099941 | 28% |
| 93131052 | Eicher Tractor Rigid Fuel Line (W. Separator To F. | 403   | 84099941 | 28% |
| 93131075 | Eicher Tractor Rigid Fuel Line (Filter To F.I.P)   | 307   | 84219900 | 18% |
| 93131105 | Eicher Tractor Bracket For Fuel Filter             | 256   | 84219900 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93131180 | Eicher Tractor Clamp Set Assy                      | 17    | 84099941 | 28% |
| 93131191 | Eicher Tractor Blower Support Front M/C            | 1504  | 84099941 | 28% |
| 93131208 | Eicher Tractor Blower Support Rear M/C             | 783   | 84099941 | 28% |
| 93131210 | Eicher Tractor Shim 0.16Mm (Rocker Arm)            | 4     | 73182100 | 18% |
| 93131221 | Eicher Tractor Thrust Washer With Lug              | 105   | 73182100 | 18% |
| 93131233 | Eicher Tractor Front Deflector                     | 766   | 84099990 | 28% |
| 93131245 | Eicher Tractor Rear Deflector                      | 582   | 84099990 | 28% |
| 93131257 | Eicher Tractor Valve Spring                        | 40    | 73202000 | 18% |
| 93131269 | Eicher Tractor Intermediate Deflector              | 890   | 84099990 | 28% |
| 93131361 | Eicher Tractor Air Inlet Hose                      | 469   | 40093100 | 18% |
| 93131490 | Eicher Tractor Rubber Hose (Dry A/C)               | 244   | 40093100 | 18% |
| 93131506 | Eicher Tractor Spl. Stud M8X44                     | 31    | 84129090 | 18% |
| 93131518 | Eicher Tractor Cyl. Head Sub Asly.                 | 4720  | 76169990 | 18% |
| 93131555 | Eicher Tractor Top Bracket                         | 183   | 84099941 | 28% |
| 93131609 | Eicher Tractor Blower Shaft-298                    | 1442  | 84091000 | 28% |
| 93131610 | Eicher Tractor Cooling Impeller Ø 28.2             | 473   | 84099941 | 28% |
| 93131622 | Eicher Tractor Blower Shaft Sub-Assy. -298         | 2548  | 84099941 | 28% |
| 93131774 | Eicher Tractor Crank Shaft Sub-Assy. -298          | 17871 | 84831092 | 18% |
| 93131798 | Eicher Tractor Gasket For Exhaust                  | 51    | 84841090 | 18% |
| 93131804 | Eicher Tractor Injector Assy. - 298Ei & 398Ed      | 6632  | 84099990 | 28% |
| 93131816 | Eicher Tractor Crank Pully 298Ei For 312P          | 1085  | 84835010 | 18% |
| 93131920 | Eicher Tractor Fuel Inj. Pipe Assly. Set-298Ei     | 988   | 84099941 | 28% |
| 93131932 | Eicher Tractor O-Ring (Push Rod Tube)              | 34    | 40169320 | 18% |
| 93131944 | Eicher Tractor Control Housing Mod. 298            | 2834  | 84099941 | 28% |
| 93131956 | Eicher Tractor Exhaust Valve                       | 375   | 84099111 | 28% |
| 93131968 | Eicher Tractor Piston Ring Set 100 Mm              | 823   | 84099913 | 28% |
| 93131993 | Eicher Tractor Inlet Valve( 298E)                  | 281   | 84099111 | 28% |
| 93132006 | Eicher Tractor Clamping Cone                       | 16    | 84099990 | 28% |
| 93132043 | Eicher Tractor Silencer Assy                       | 2023  | 87089200 | 18% |
| 93132109 | Eicher Tractor Stud M8X38                          | 28    | 73182100 | 18% |
| 93132122 | Eicher Tractor Alternator Assy (Vent Type)         | 7530  | 85115000 | 28% |
| 93132134 | Eicher Tractor Crank Pully M/Cd-322Esg             | 1249  | 84835010 | 18% |
| 93132146 | Eicher Tractor Blower Pulley                       | 474   | 84099941 | 28% |
| 93132158 | Eicher Tractor Timing Marking Bracket              | 35    | 84099941 | 28% |
| 93132213 | Eicher Tractor Crank Housing M/Cd 298Ei            | 34119 | 84831092 | 18% |
| 93132353 | Eicher Tractor Crank Pully M/Cd-322Esg (12")       | 2141  | 84099941 | 28% |
| 93132377 | Eicher Tractor Piston -98 Series(Trem-3A) \$       | 2103  | 84099112 | 28% |
| 93132389 | Eicher Tractor Fuel Inj. Pipe Set-298Ei(Trem-3A)   | 972   | 84099941 | 28% |
| 93132432 | Eicher Tractor Copper Washer (15X1.50X2)           | 15    | 74091100 | 18% |
| 93132470 | Eicher Tractor Crank Pulley 298Ei \$ (13")         | 1142  | 84835010 | 18% |
| 93132481 | Eicher Tractor Fip Lubricating Pipe Assy 298Ei \$  | 694   | 40094200 | 18% |
| 93132493 | Eicher Tractor Fuel Injection Pump-298Ei Trem -3A  | 26810 | 84133010 | 28% |
| 93132500 | Eicher Tractor Injector Assy 298Ei (Trem-3 A) \$   | 4995  | 84099990 | 28% |
| 93132523 | Eicher Tractor Gasket For Cylinder Liner           | 161   | 84099941 | 28% |
| 93132572 | Eicher Tractor Spring (Push Rod Tube)              | 25    | 73209090 | 18% |
| 93132584 | Eicher Tractor Fuel Pump Gear 298Ei                | 1272  | 87084000 | 18% |
| 93132696 | Eicher Tractor 00206002 = Conn.Rocker Shaft Oil Fe | 29    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93132869 | Eicher Tractor Inlet Manifold Rear                 | 496   | 84099941 | 28% |
| 93132912 | Eicher Tractor Fly Wheel Adopter Plate             | 2067  | 84099941 | 28% |
| 93133000 | Eicher Tractor Fuel Injection Pump(981)E-26        | 19873 | 84133010 | 28% |
| 93133059 | Eicher Tractor Drain Plug Assy                     | 83    | 84099941 | 28% |
| 93133060 | Eicher Tractor Drain Plug Assy                     | 75    | 84099941 | 28% |
| 93133140 | Eicher Tractor Dipstick Assy. 298Ei                | 63    | 84099941 | 28% |
| 93133151 | Eicher Tractor O.F.Head Cum Inspection Cover       | 854   | 84099941 | 28% |
| 93133175 | Eicher Tractor Injector Assy. For 323 Model-470    | 4156  | 84099990 | 28% |
| 93133333 | Eicher Tractor Crank Gear                          | 1142  | 87084000 | 18% |
| 93133345 | Eicher Tractor Fuel Pump Drive Gear                | 1124  | 87084000 | 18% |
| 93133369 | Eicher Tractor Control Hsg M/Cd                    | 3120  | 84099941 | 28% |
| 93133424 | Eicher Tractor Connecting Rod Sub Assy             | 2703  | 84099941 | 28% |
| 93133540 | Eicher Tractor Crank Pulley 298Ei                  | 1331  | 84835010 | 18% |
| 93133552 | Eicher Tractor Control Hsg M/Cd(298 I/L, 313 Auto) | 3649  | 84099941 | 28% |
| 93150150 | Eicher Tractor Dry Air Cleaner With Sensor         | 3983  | 84213920 | 18% |
| 93150264 | Eicher Tractor Speedo Cable 2016Mm (368 & 485)     | 312   | 85443000 | 18% |
| 93150288 | Eicher Tractor Alternator Cover                    | 168   | 87085000 | 18% |
| 93150290 | Eicher Tractor Mtg. Clamp                          | 43    | 87084000 | 18% |
| 93150306 | Eicher Tractor Fuel Injector Assy - 398Edd         | 7013  | 84133010 | 28% |
| 93150342 | Eicher Tractor Fuel Inj. Pump Assy - 398Edd        | 34048 | 84133010 | 28% |
| 93150355 | Eicher Tractor Fuel Inj. Pipe Front-398Edd         | 569   | 84099941 | 28% |
| 93150367 | Eicher Tractor Fuel Inj. Pipe Middle-398Edd        | 569   | 84099941 | 28% |
| 93150379 | Eicher Tractor Fuel Inj. Pipe Rear-398Edd          | 569   | 84099941 | 28% |
| 93150409 | Eicher Tractor Belt Guard W/C/333                  | 300   | 85122010 | 18% |
| 93150434 | Eicher Tractor Rubber Grommet                      | 12    | 40169320 | 18% |
| 93150460 | Eicher Tractor Cam Shaft(Chilled Cast-398)         | 5166  | 84831092 | 18% |
| 93150513 | Eicher Tractor Ring Gear                           | 1547  | 84835090 | 18% |
| 93150665 | Eicher Tractor O.F.Head Cum Inspection Cover       | 850   | 84099941 | 28% |
| 93150677 | Eicher Tractor Plastic Plug M10                    | 5     | 39021000 | 18% |
| 93150768 | Eicher Tractor Water Separator                     | 834   | 84212300 | 18% |
| 93150770 | Eicher Tractor Fuel Filter Bkt                     | 221   | 84219900 | 18% |
| 93150800 | Eicher Tractor Gasket(Inspection Cover Front)      | 34    | 68129922 | 18% |
| 93150847 | Eicher Tractor Bearing Hsg. Rear                   | 2096  | 84099941 | 28% |
| 93150859 | Eicher Tractor Thrust Washer                       | 105   | 73182100 | 18% |
| 93150884 | Eicher Tractor Crank Housing M/C-398               | 37947 | 84831092 | 18% |
| 93150914 | Eicher Tractor Blower Pulley-485                   | 429   | 84099941 | 28% |
| 93150963 | Eicher Tractor Blower Pulley-368                   | 636   | 84099941 | 28% |
| 93150987 | Eicher Tractor Baffle                              | 56    | 39089020 | 18% |
| 93150999 | Eicher Tractor Crank Pulley Bolt                   | 315   | 73181500 | 18% |
| 93151037 | Eicher Tractor Oil Gallery Tube Assy.-398          | 656   | 84099941 | 28% |
| 93151062 | Eicher Tractor Bush,Thin Wall (Cam Shaft Front)    | 179   | 84833000 | 18% |
| 93151074 | Eicher Tractor Thrust Washer (Cam Shaft Front)     | 345   | 73182100 | 18% |
| 93151086 | Eicher Tractor Cam Shaft M/C-313 (Chilled Cast)    | 4845  | 84831092 | 18% |
| 93151141 | Eicher Tractor Flywheel 398-Duel Clutch-12H        | 18675 | 84835010 | 18% |
| 93151177 | Eicher Tractor Sealing Cup Ø45                     | 22    | 84099941 | 28% |
| 93151189 | Eicher Tractor Special Stud M6X52                  | 18    | 84099941 | 28% |
| 93151207 | Eicher Tractor Crank Pulley-398Ex                  | 1283  | 84835010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93151270 | Eicher Tractor Gasket For Cont. Hsg.               | 98    | 68129922 | 18% |
| 93151281 | Eicher Tractor Fly Wheel-398 Single Cltch-6H       | 14860 | 84835010 | 18% |
| 93151300 | Eicher Tractor Flywheel Un-Balance-313(Ed/Edd-S/C) | 9387  | 84831099 | 18% |
| 93151311 | Eicher Tractor Crank Shaft Bal.-313                | 24051 | 84831092 | 18% |
| 93151359 | Eicher Tractor O.F.Head Cum Insp. Cover-398        | 1380  | 84099941 | 28% |
| 93151360 | Eicher Tractor Parallel Key 8X5X34                 | 35    | 73182990 | 18% |
| 93151372 | Eicher Tractor Gasket(Insp. Cover Front-398)       | 55    | 68129922 | 18% |
| 93151426 | Eicher Tractor Rigid Fuel Pipe (Fip-Filter)        | 773   | 40094200 | 18% |
| 93151591 | Eicher Tractor Banjo Bolt Front                    | 71    | 73181500 | 18% |
| 93151610 | Eicher Tractor Hour Meter Cover Plate              | 36    | 84099941 | 28% |
| 93151670 | Eicher Tractor Blower Shaft-398(Alt.)              | 2170  | 84091000 | 28% |
| 93151694 | Eicher Tractor Blower Shaft Sub Assly.-Alter.-398  | 3657  | 84099941 | 28% |
| 93151700 | Eicher Tractor Crank Gear                          | 1091  | 84099941 | 28% |
| 93151748 | Eicher Tractor Crank Shaft Sub-Assy.-398           | 26047 | 84831092 | 18% |
| 93151750 | Eicher Tractor Lubricating Pipe Assy.(Cam Shaft)   | 234   | 84099941 | 28% |
| 93151967 | Eicher Tractor Plug For Exh Manifold 298 And 398   | 13    | 39021000 | 18% |
| 93151992 | Eicher Tractor Piston-98 Series                    | 3219  | 84099112 | 28% |
| 93152108 | Eicher Tractor Dipstick Assy-398 Auto / 421Es & 4  | 55    | 84099941 | 28% |
| 93152170 | Eicher Tractor Crank Pulley-398Ed \$ (13")         | 1222  | 84099941 | 28% |
| 93152194 | Eicher Tractor Crank Case Machined -398            | 60345 | 84099941 | 28% |
| 93152285 | Eicher Tractor Fuel Injection Pump 398Edd Trem Iii | 27552 | 84133010 | 28% |
| 93152303 | Eicher Tractor Cyl. Head Sub Asly. Trem-3          | 7081  | 76169990 | 18% |
| 93152509 | Eicher Tractor Fuel Injection Pump 398Ed(909) Trem | 26744 | 84133010 | 28% |
| 93152510 | Eicher Tractor Crank Pulley-398Ed/Edd (14.30")     | 1537  | 84099941 | 28% |
| 93152698 | Eicher Tractor Crank Pulley (16 Deg)398E49 S/C, D/ | 1537  | 84099941 | 28% |
| 93152728 | Eicher Tractor Crank Housing - 3 Cyl. Auto         | 56615 | 84099941 | 28% |
| 93152819 | Eicher Tractor Dipstick Assy-398 Auto              | 70    | 84099941 | 28% |
| 93152870 | Eicher Tractor Fuel Pipe With Clamp Assy           | 1385  | 84099941 | 28% |
| 93152881 | Eicher Tractor Hex Screw M6X16                     | 13    | 73181500 | 18% |
| 93153162 | Eicher Tractor T-Joint-Injector Over Flow          | 19    | 84099941 | 28% |
| 93153289 | Eicher Tractor Crank Pulley-398Ed/Edd              | 1976  | 84099941 | 28% |
| 93153290 | Eicher Tractor Dust Shield Front Oil Seal (313 Mo  | 32    | 40169990 | 18% |
| 93153381 | Eicher Tractor Crank Pulley 398E49 S/C, D/C        | 1715  | 84099941 | 28% |
| 93153605 | Eicher Tractor Inspection Cover Rear               | 475   | 84099941 | 28% |
| 93153708 | Eicher Tractor Stud M8X1.25X36 (With Self Locking) | 23    | 73182100 | 18% |
| 93153710 | Eicher Tractor Flange - Hex Screw M8X25 (With Self | 18    | 73181500 | 18% |
| 93153721 | Eicher Tractor Stud M10X1.5X45 (With Nylon Blue)   | 30    | 73182100 | 18% |
| 93153733 | Eicher Tractor Hex Screw M8X16 (With Self Locking) | 15    | 73181500 | 18% |
| 93153745 | Eicher Tractor Gasket-Fuel Pump ( With Silicon Bea | 20    | 68129922 | 18% |
| 93153757 | Eicher Tractor Gasket - Cover Plate                | 15    | 68129090 | 18% |
| 93153769 | Eicher Tractor Gasket - Inspection Cover Front (39 | 46    | 68129922 | 18% |
| 93153770 | Eicher Tractor Gasket - Inspection Cover Front (29 | 36    | 68129090 | 18% |
| 93160221 | Eicher Tractor Fuel Gauge - 15 Kva Bsnl            | 4040  | 84099941 | 28% |
| 93160630 | Eicher Tractor V-Belt Cogged Avx13-1145            | 579   | 40101290 | 18% |
| 93161912 | Eicher Tractor Polybond Pad Pd3D                   | 1191  | 85369090 | 18% |
| 93162096 | Eicher Tractor Engine Cover 48" X 55"              | 196   | 39239020 | 18% |
| 93170019 | Eicher Tractor Wiring Harness                      | 445   | 85444220 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93170070 | Eicher Tractor Belt Guard Assly                    | 401   | 84091000 | 28% |
| 93170093 | Eicher Tractor Flywheel 321/421Es                  | 13105 | 84831099 | 18% |
| 93170100 | Eicher Tractor Flywheel-322/422Es                  | 24330 | 84835010 | 18% |
| 93170366 | Eicher Tractor Muffler Assly.                      | 1337  | 84099990 | 28% |
| 93170615 | Eicher Tractor Deflector Assy.Right-112            | 138   | 84099941 | 28% |
| 93170627 | Eicher Tractor Deflector Assy.Left-112             | 138   | 84099941 | 28% |
| 93170743 | Eicher Tractor Fly Wheel Casing-222Es-S/B Alt.     | 8386  | 84099941 | 28% |
| 93170755 | Eicher Tractor Fly Wheel-222Esg For Closed Coupled | 20578 | 84835010 | 18% |
| 93170871 | Eicher Tractor Fuel Injection Pump                 | 32910 | 84133010 | 28% |
| 93170962 | Eicher Tractor Engine Shutoff Solenoid Assy.       | 3029  | 85365090 | 18% |
| 93170974 | Eicher Tractor Mtg. Bracket For Solenoid           | 242   | 84099941 | 28% |
| 93170998 | Eicher Tractor Injector Assy.                      | 6723  | 84099990 | 28% |
| 93171024 | Eicher Tractor Crank Pulley 398 Stationary         | 1885  | 84835010 | 18% |
| 93171036 | Eicher Tractor F.I. Pipe Front                     | 597   | 84099941 | 28% |
| 93171048 | Eicher Tractor F.I. Pipe Middle                    | 597   | 84099941 | 28% |
| 93171050 | Eicher Tractor F.I. Pipe Rear                      | 597   | 84099941 | 28% |
| 93171073 | Eicher Tractor Pedastal Side                       | 263   | 84099941 | 28% |
| 93171115 | Eicher Tractor Link Rod For Solenoid               | 65    | 84099941 | 28% |
| 93171231 | Eicher Tractor Adapter (Oil Pr. Switch-Vdo)        | 55    | 85366190 | 18% |
| 93171280 | Eicher Tractor Cover Hyd. Pump Mtg.-422Esg         | 624   | 84099941 | 28% |
| 93171383 | Eicher Tractor Pedastal Front R.H.                 | 544   | 84099941 | 28% |
| 93171395 | Eicher Tractor Pedastal Front L.H.                 | 505   | 84099941 | 28% |
| 93171413 | Eicher Tractor Governor Spring Outer               | 94    | 73202000 | 18% |
| 93171425 | Eicher Tractor Actuating Pin-115E Genset           | 14    | 84129090 | 18% |
| 93171528 | Eicher Tractor Banjo Bolt Front M12X1.5/M10X1.5    | 62    | 73181500 | 18% |
| 93171530 | Eicher Tractor Plug M8 For O.F.Head                | 29    | 84099941 | 28% |
| 93171541 | Eicher Tractor Fuel Injection Pump For 322Es Gense | 15980 | 84133010 | 28% |
| 93171553 | Eicher Tractor Inlet Manifold-322Esg               | 706   | 84099941 | 28% |
| 93171607 | Eicher Tractor Core Plug Ø 42 (Din 443)            | 76    | 84099941 | 28% |
| 93171619 | Eicher Tractor Injector Assy.-322Esg               | 6744  | 84099990 | 28% |
| 93171668 | Eicher Tractor Control Panel-422Esg Rtu            | 810   | 84099941 | 28% |
| 93171670 | Eicher Tractor Banjo Bolt Front-422Esg             | 66    | 73181500 | 18% |
| 93171700 | Eicher Tractor Temperature Switch (M10X1)          | 811   | 84099941 | 28% |
| 93171711 | Eicher Tractor Fuel Inj. Pipe Front-322Esg         | 446   | 84099990 | 28% |
| 93171723 | Eicher Tractor Fuel Inj. Pipe Rear-322Esg          | 446   | 84099990 | 28% |
| 93171760 | Eicher Tractor Spacer Vent Alternator              | 37    | 73182100 | 18% |
| 93171784 | Eicher Tractor Alternator Assly Vent. Typ          | 7849  | 85115000 | 28% |
| 93171905 | Eicher Tractor Hose Over Flow (Inj-Ft)             | 679   | 40093100 | 18% |
| 93171917 | Eicher Tractor Adjusting Latch                     | 312   | 84091000 | 28% |
| 93171930 | Eicher Tractor Control Panel                       | 841   | 84099941 | 28% |
| 93172018 | Eicher Tractor Dipstick Assly.322Esg \$            | 50    | 84099941 | 28% |
| 93172054 | Eicher Tractor Fuel Filter Assly.(Single Bowl Filt | 986   | 84212900 | 18% |
| 93172120 | Eicher Tractor Rubber Hose (Ac To Manifold)        | 295   | 40093100 | 18% |
| 93172144 | Eicher Tractor Blower Shaft-398 S                  | 2095  | 84091000 | 28% |
| 93172200 | Eicher Tractor Ammeter 52 Dia Assy                 | 297   | 90303310 | 18% |
| 93172211 | Eicher Tractor Adapter For Oil Temperature         | 101   | 84099941 | 28% |
| 93172417 | Eicher Tractor Holding Plate                       | 290   | 84099941 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93172429 | Eicher Tractor Blower Shaft Sub Assembly-398 Stati  | 3578  | 84099941 | 28% |
| 93172430 | Eicher Tractor Decompression Lever Assy             | 265   | 84099941 | 28% |
| 93172510 | Eicher Tractor Decompression Lever                  | 239   | 84099941 | 28% |
| 93172740 | Eicher Tractor Inlet Manifold                       | 973   | 84099941 | 28% |
| 93172752 | Eicher Tractor Adjusting Latch                      | 164   | 84099941 | 28% |
| 93172776 | Eicher Tractor Belt Guard Assy                      | 351   | 84099941 | 28% |
| 93172806 | Eicher Tractor Adaptor For Pressure Switch          | 117   | 84099941 | 28% |
| 93172934 | Eicher Tractor Bracket For Idler Mtg.               | 195   | 84099941 | 28% |
| 93173185 | Eicher Tractor Bracket For Alternator               | 305   | 84099941 | 28% |
| 93173203 | Eicher Tractor Crank Pully For 222Es And 222Hs      | 1650  | 84835010 | 18% |
| 93173239 | Eicher Tractor Bracket Alternator Mtg               | 366   | 84099941 | 28% |
| 93173264 | Eicher Tractor Mtg. Bkt. For A/C Cum Contorl Pannel | 507   | 84099941 | 28% |
| 93173276 | Eicher Tractor Mounting Bracket For Solenoid        | 135   | 84099941 | 28% |
| 93173288 | Eicher Tractor Air Inlet Hose                       | 528   | 40093100 | 18% |
| 93173318 | Eicher Tractor Hydraulic Pump Cover Gasket          | 14    | 68129922 | 18% |
| 93173331 | Eicher Tractor Adaptor -Lower Side                  | 60    | 84099941 | 28% |
| 93173380 | Eicher Tractor Hydraulic Pump Cover-Front           | 275   | 84099941 | 28% |
| 93173410 | Eicher Tractor Padestal Front -R.H.                 | 832   | 84099941 | 28% |
| 93173422 | Eicher Tractor Padestal Front -L.H.                 | 843   | 84099941 | 28% |
| 93173446 | Eicher Tractor Rubber Pad                           | 130   | 40169390 | 18% |
| 93173471 | Eicher Tractor Water Inlet Hose - Radiator          | 753   | 40093100 | 18% |
| 93173483 | Eicher Tractor Water Out Let Hose                   | 430   | 40093100 | 18% |
| 93173549 | Eicher Tractor Radiator Mtg. Frame Right            | 492   | 84099941 | 28% |
| 93173550 | Eicher Tractor Radiator Mtg. Frame Left             | 492   | 84099941 | 28% |
| 93173593 | Eicher Tractor Gasket Between Exhaust Manifold & T  | 60    | 84841090 | 18% |
| 93173616 | Eicher Tractor Rubber Hose (Nylone)                 | 518   | 40093100 | 18% |
| 93173628 | Eicher Tractor Rubber Hose (Nylone)                 | 454   | 40093100 | 18% |
| 93173677 | Eicher Tractor Aluminium Pipe, Inlet Manifold To T  | 1053  | 83100090 | 18% |
| 93173689 | Eicher Tractor Exhaust Manifold                     | 8838  | 84099941 | 28% |
| 93173719 | Eicher Tractor Pressure Gauge (Electrical Operated  | 401   | 90262000 | 18% |
| 93173720 | Eicher Tractor Adaptor For Oil Pressure Pipe Mtg.   | 63    | 84099941 | 28% |
| 93173732 | Eicher Tractor Fan, Pusher 19"                      | 4431  | 84099941 | 28% |
| 93173793 | Eicher Tractor Hour Cum Rpm Gauge (Electronic)      | 2310  | 90292020 | 18% |
| 93173859 | Eicher Tractor Pedestal Front (R.H.)                | 510   | 84099941 | 28% |
| 93173860 | Eicher Tractor Pedestal Front (L.H.)                | 510   | 84099941 | 28% |
| 93173975 | Eicher Tractor Spacer For Adjusting Latch           | 33    | 73182100 | 18% |
| 93173987 | Eicher Tractor Fuel Line Assy-320Desg               | 193   | 40092200 | 18% |
| 93174165 | Eicher Tractor Wiring Harness For 222Es Agro        | 653   | 85444220 | 18% |
| 93174189 | Eicher Tractor Wiring Harness For 321Es/322Es       | 720   | 85443000 | 18% |
| 93174360 | Eicher Tractor Fuel Injection Pump-45Kva            | 35314 | 84133010 | 28% |
| 93174396 | Eicher Tractor Fuel Injection Pump For 30Kva        | 42312 | 84133010 | 28% |
| 93174451 | Eicher Tractor Feed Pump Hsg                        | 1319  | 84099941 | 28% |
| 93174463 | Eicher Tractor Cam Shaft For Feed Pump              | 922   | 84129090 | 18% |
| 93174475 | Eicher Tractor Bearing Flange                       | 290   | 84099941 | 28% |
| 93174487 | Eicher Tractor Gasket For Bearing Flange            | 15    | 68129922 | 18% |
| 93174724 | Eicher Tractor Alt. Mtg. Bracket                    | 305   | 84099941 | 28% |
| 93174736 | Eicher Tractor Bush                                 | 22    | 84099941 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93174852 | Eicher Tractor Hand Accelerator Assy 621Es/422Es    | 324   | 84099941 | 28% |
| 93174931 | Eicher Tractor Alternator Bracket                   | 325   | 84099941 | 28% |
| 93174967 | Eicher Tractor Cover Plate Rear For 461Es           | 301   | 84099941 | 28% |
| 93174979 | Eicher Tractor Fuel Duct Assy With Protection Tube  | 321   | 40092200 | 18% |
| 93175005 | Eicher Tractor Fuel Filter Bracket                  | 200   | 84219900 | 18% |
| 93175017 | Eicher Tractor Rubber Washer                        | 11    | 40169320 | 18% |
| 93175297 | Eicher Tractor Fuel Pipe Assy Ff To Feed Pump       | 146   | 84099941 | 28% |
| 93175303 | Eicher Tractor Fuel Pipe Assy Fuel Filter To Fuel   | 204   | 84219900 | 18% |
| 93175327 | Eicher Tractor Turbocharger (Hx 20 # Td 03 6T/6 -   | 29449 | 84148030 | 18% |
| 93175352 | Eicher Tractor Exhaust Extension                    | 647   | 84099941 | 28% |
| 93175364 | Eicher Tractor Adaptor - Turbo Inlet Lubrication    | 67    | 84099941 | 28% |
| 93175376 | Eicher Tractor Lub Inlet Pipe Assy                  | 469   | 84099941 | 28% |
| 93175406 | Eicher Tractor Hose (Turbo & Boost Pipe)            | 510   | 40093100 | 18% |
| 93175418 | Eicher Tractor Air Inlet Hose                       | 625   | 40093100 | 18% |
| 93175420 | Eicher Tractor Gasket - Oil Outlet Adaptor          | 10    | 68129922 | 18% |
| 93175479 | Eicher Tractor Air Cleaner Assy \$                  | 4759  | 84099990 | 28% |
| 93175522 | Eicher Tractor Oil Sump                             | 1827  | 84099941 | 28% |
| 93175534 | Eicher Tractor Exhaust Manifold                     | 2059  | 73182990 | 18% |
| 93175820 | Eicher Tractor Union-Oil Cooler Mtg. M24X1.5        | 371   | 84099941 | 28% |
| 93175832 | Eicher Tractor Nipple ( Inlet/Outlet ) \$           | 135   | 84099941 | 28% |
| 93175856 | Eicher Tractor Water Hose Elbow                     | 39    | 40093100 | 18% |
| 93175900 | Eicher Tractor Speedo Cable Assy. With Spring       | 286   | 90299000 | 18% |
| 93176009 | Eicher Tractor Temperature Switch 322/422Esg        | 516   | 90269000 | 18% |
| 93176034 | Eicher Tractor Engine Heater Plug                   | 9768  | 85114000 | 28% |
| 93176046 | Eicher Tractor Timer Relay For Heater Plug -12Vdc   | 5277  | 85118000 | 28% |
| 93176083 | Eicher Tractor Booster Pipe                         | 535   | 84099941 | 28% |
| 93176113 | Eicher Tractor Fuel Filter Bracket 222Esg           | 147   | 84219900 | 18% |
| 93176125 | Eicher Tractor Solenoid Assy. -322Esg               | 2941  | 85365090 | 18% |
| 93176137 | Eicher Tractor Pedestal Side                        | 309   | 84099941 | 28% |
| 93176204 | Eicher Tractor Dipstick Assly. -222Esg \$           | 50    | 84099941 | 28% |
| 93176319 | Eicher Tractor Alternator Assy Ventilator Type (D/  | 7896  | 85115000 | 28% |
| 93176320 | Eicher Tractor Wiring Harness Assy 421/422Es        | 456   | 85444220 | 18% |
| 93176344 | Eicher Tractor Adaptor For Llop Switch              | 72    | 84099941 | 28% |
| 93176393 | Eicher Tractor Hand Accelerator Assembly            | 297   | 84099941 | 28% |
| 93176411 | Eicher Tractor Llop Connecting Pipe                 | 96    | 84099941 | 28% |
| 93176435 | Eicher Tractor Fuel Pipe Assy.(Fuel Filter To Fip)  | 201   | 84219900 | 18% |
| 93176447 | Eicher Tractor Fuel Pipe Assy. ( Feed Pump To Fuel  | 410   | 40092200 | 18% |
| 93176976 | Eicher Tractor Oil Cooler Assy. - 12 Plates ( Poona | 6672  | 73182100 | 18% |
| 93177166 | Eicher Tractor Fuel Injection Pump-\$               | 65428 | 84133010 | 28% |
| 93177178 | Eicher Tractor Injector (Assy) 881Es \$             | 13490 | 84099990 | 28% |
| 93177269 | Eicher Tractor Gasket B/W Cylinder Head And E       | 115   | 84841090 | 18% |
| 93177270 | Eicher Tractor Gasket B/W Exht. Manifold And Turbo  | 50    | 73182200 | 18% |
| 93177289 | Eicher Tractor Gasket B/W Turbo And Extension (S.   | 58    | 73182200 | 18% |
| 93177290 | Eicher Tractor Gasket B/W Extension And Silencer \$ | 47    | 73182200 | 18% |
| 93177300 | Eicher Tractor Gasket B/W Turbo And Extension (S.   | 65    | 73182200 | 18% |
| 93177312 | Eicher Tractor Gasket - 45Kva ( Exhaust & Turbo )   | 62    | 73182200 | 18% |
| 93177324 | Eicher Tractor Gasket - 45Kva ( Between Turbo & Ex  | 94    | 73182200 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93177336 | Eicher Tractor Rubber Hose –Oil Cooler             | 88    | 40093100 | 18% |
| 93177350 | Eicher Tractor Exhaust Extension-Erw (62.5Kva)     | 763   | 84099941 | 28% |
| 93177361 | Eicher Tractor Padestal Rear                       | 184   | 84099941 | 28% |
| 93177403 | Eicher Tractor Solenoid Assy (222Es) Close Coupple | 2910  | 85365090 | 18% |
| 93177415 | Eicher Tractor Air Vent Union \$                   | 252   | 84099941 | 28% |
| 93177427 | Eicher Tractor Fuel Filter Mtg. Bracket 621Es/461  | 221   | 84099941 | 28% |
| 93177439 | Eicher Tractor Union (Dat Hose Connection)         | 282   | 40093100 | 18% |
| 93177440 | Eicher Tractor Dat To Water Pump Hose \$           | 477   | 40093100 | 18% |
| 93177490 | Eicher Tractor Dry A/C. (With Out Safety Ele       | 4373  | 84213920 | 18% |
| 93177518 | Eicher Tractor Turbo Drain Pipe Assembly           | 1673  | 40092200 | 18% |
| 93177609 | Eicher Tractor Lid 222Esg                          | 1273  | 84099941 | 28% |
| 93177634 | Eicher Tractor Pedestal Front M/Cd 222Esg          | 2313  | 84099941 | 28% |
| 93177671 | Eicher Tractor Air Inlet Manifold (Middle) 422Tc   | 4210  | 84099941 | 28% |
| 93177713 | Eicher Tractor Alternator Assy Ventilator Type (S/ | 6686  | 85115000 | 28% |
| 93177889 | Eicher Tractor Oil Pump Assy.(Oil Flow Increase    | 1996  | 84099941 | 28% |
| 93177919 | Eicher Tractor Inlet Valve Seat                    | 287   | 84099941 | 28% |
| 93177981 | Eicher Tractor Silicon Hose –Intak Side            | 374   | 40093100 | 18% |
| 93177993 | Eicher Tractor Alternator Bracket 322Es            | 340   | 84099941 | 28% |
| 93178006 | Eicher Tractor Flywheel 322Esg                     | 30305 | 84099941 | 28% |
| 93178018 | Eicher Tractor Flywheel Casing 322Esg/422Esg       | 9245  | 84099941 | 28% |
| 93178092 | Eicher Tractor Valve Guide – Semi Finish           | 73    | 84099111 | 28% |
| 93178109 | Eicher Tractor Fuel Injection Pump Assly 422Tc     | 32863 | 84133010 | 28% |
| 93178110 | Eicher Tractor Fuel Filter Bracket                 | 275   | 84219900 | 18% |
| 93178134 | Eicher Tractor Crank Housing Mcd 322Esg            | 32458 | 84099941 | 28% |
| 93178160 | Eicher Tractor Oil Gallery Tube Assly 322Esg       | 369   | 40092200 | 18% |
| 93178183 | Eicher Tractor V-Belt-1262 For 222Esg              | 491   | 40101290 | 18% |
| 93178195 | Eicher Tractor Cylinder Head Assy                  | 23190 | 76169990 | 18% |
| 93178444 | Eicher Tractor Fuel Pipe Assy Ff To Fip            | 586   | 84099941 | 28% |
| 93178456 | Eicher Tractor Fuel Pipe Assy Ff To Feed Pump To F | 554   | 84099941 | 28% |
| 93178560 | Eicher Tractor Adjusting Latch -222Esg             | 130   | 84099941 | 28% |
| 93178640 | Eicher Tractor Semi Rigid Fuel Pipe Assy Feed Pump | 552   | 40094200 | 18% |
| 93178651 | Eicher Tractor Rigid Fuel Pipe Assy With Clamp     | 1593  | 40094200 | 18% |
| 93178663 | Eicher Tractor Rigid Fuel Pipe Assy Fuel Filter To | 407   | 84099941 | 28% |
| 93178699 | Eicher Tractor Fuel Filter Bracket                 | 236   | 84099941 | 28% |
| 93178729 | Eicher Tractor Tc Oil Drain Pipe Assy. 422Tc       | 680   | 40092200 | 18% |
| 93178730 | Eicher Tractor Tc Oil Inlet Pipe For 422Tc         | 586   | 40092200 | 18% |
| 93178742 | Eicher Tractor Fly Wheel For 881Es                 | 17188 | 84835010 | 18% |
| 93178754 | Eicher Tractor Adaptor On Oil Gallery              | 62    | 84099990 | 28% |
| 93178857 | Eicher Tractor Pedestal - Rear \$                  | 263   | 84099941 | 28% |
| 93178869 | Eicher Tractor Flywheel Casing                     | 14562 | 73251000 | 18% |
| 93178870 | Eicher Tractor Crank Case Machined 322Esg          | 48299 | 84099941 | 28% |
| 93178894 | Eicher Tractor Special Hex Bolt                    | 23    | 73181500 | 18% |
| 93178936 | Eicher Tractor A/C.Mtg. Brkt Cum Lifting Hook-422T | 1277  | 84099941 | 28% |
| 93178948 | Eicher Tractor Steel Tube – 422Tc                  | 192   | 84099941 | 28% |
| 93178950 | Eicher Tractor Rubber Hose Inlet Manifold Side -42 | 269   | 40093100 | 18% |
| 93179175 | Eicher Tractor Bracket For Lever Mounting Assly.   | 47    | 84099941 | 28% |
| 93179321 | Eicher Tractor Oil Feed Pipe Assy. - For Cyl. Head | 1271  | 40094200 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93179359 | Eicher Tractor Gasket Between Turbo& Extension     | 45    | 73182200 | 18% |
| 93179369 | Eicher Tractor Oil Pressure Switch Cum Sensor      | 1885  | 90268090 | 18% |
| 93179394 | Eicher Tractor Hand Accelerator Assembly           | 276   | 84099941 | 28% |
| 93179448 | Eicher Tractor Hose (Steel Pipe To Tc Air Inlet)   | 179   | 40093100 | 18% |
| 93179473 | Eicher Tractor Holding Strip Right                 | 147   | 84099941 | 28% |
| 93179485 | Eicher Tractor Holding Strip Left                  | 153   | 84099941 | 28% |
| 93179564 | Eicher Tractor Balance Weight 322Es                | 853   | 84099941 | 28% |
| 93179631 | Eicher Tractor Air Inlet Hose A/C To Turbo -422Tc  | 730   | 40093100 | 18% |
| 93179643 | Eicher Tractor A/C Fixing Support \$               | 241   | 84099941 | 28% |
| 93179692 | Eicher Tractor Hose Clamp(Sltb-62) \$              | 139   | 73269099 | 18% |
| 93179710 | Eicher Tractor Bracket(A/C Mtg. Support) \$        | 347   | 84099941 | 28% |
| 93179734 | Eicher Tractor Water Inlet Hose                    | 1058  | 40093100 | 18% |
| 93179746 | Eicher Tractor Water Outlet Hose                   | 705   | 40093100 | 18% |
| 93179758 | Eicher Tractor Boost Pipe (Tc To Ic) \$            | 1125  | 84099941 | 28% |
| 93179760 | Eicher Tractor Boost Pipe (Ic To Intake) \$        | 918   | 84099941 | 28% |
| 93179771 | Eicher Tractor Silicon Hose-Tc Outlet              | 983   | 40093100 | 18% |
| 93179783 | Eicher Tractor Silicon Hose-Ic Intake              | 1010  | 40093100 | 18% |
| 93179795 | Eicher Tractor Silicon Hose-Ic Outlet              | 320   | 40093100 | 18% |
| 93179801 | Eicher Tractor Ric Assy.(Tata Toyo)                | 55023 | 84099941 | 28% |
| 93179850 | Eicher Tractor Boost Pipe Support(Tc To Ic Boost P | 215   | 84099941 | 28% |
| 93179862 | Eicher Tractor Boost Pipe Sup(Ic To Intake Boost P | 165   | 84099941 | 28% |
| 93179874 | Eicher Tractor Boost Pipe Holding Cap \$           | 136   | 84099941 | 28% |
| 93179886 | Eicher Tractor Boost Pipe Support Mtg. Bkt. Assy.  | 319   | 84099941 | 28% |
| 93179898 | Eicher Tractor Crank Shaft Sub-Assy. -322Es        | 21274 | 84831092 | 18% |
| 93180025 | Eicher Tractor Rigid Lub.Pipe Line                 | 156   | 84099990 | 28% |
| 93180104 | Eicher Tractor Oil Sump Load Bearing               | 22226 | 73251000 | 18% |
| 93180116 | Eicher Tractor Suction Pipe Assy                   | 427   | 84099941 | 28% |
| 93180128 | Eicher Tractor Gasket Oil Sump                     | 694   | 68129922 | 18% |
| 93180153 | Eicher Tractor Dry A/C Support Strip               | 162   | 40169390 | 18% |
| 93180165 | Eicher Tractor Clamp A/C Pipe 50Hp                 | 84    | 87089900 | 18% |
| 93180177 | Eicher Tractor Radiator Pad                        | 76    | 87087000 | 18% |
| 93180189 | Eicher Tractor Hose 50Hp (Engine Side)             | 176   | 40093100 | 18% |
| 93180220 | Eicher Tractor Exhaust Muffler                     | 3163  | 87089200 | 18% |
| 93180268 | Eicher Tractor Exhaust Manifold                    | 2435  | 84099941 | 28% |
| 93180305 | Eicher Tractor Fuel Pipe Assy (F.T.W.S.)           | 1235  | 84099941 | 28% |
| 93180372 | Eicher Tractor Dry Ac Mtg. Bkt                     | 590   | 84099941 | 28% |
| 93180414 | Eicher Tractor Radiator Assy                       | 17683 | 87087000 | 18% |
| 93180529 | Eicher Tractor Oil Filling Pipe Assly              | 536   | 84099941 | 28% |
| 93180554 | Eicher Tractor Piston                              | 3135  | 84099112 | 28% |
| 93180578 | Eicher Tractor Glow Plug                           | 2462  | 84099941 | 28% |
| 93180797 | Eicher Tractor Flywheel Casing M/C                 | 9673  | 84099941 | 28% |
| 93180803 | Eicher Tractor Flywheel 320Ded (S/C)               | 12147 | 84099941 | 28% |
| 93180839 | Eicher Tractor Injection Pipe Set Ø 1.8            | 914   | 84099941 | 28% |
| 93180875 | Eicher Tractor Injector Assly.                     | 7891  | 84099990 | 28% |
| 93180906 | Eicher Tractor Flywheel Assembly 320Ded (S/C)      | 21975 | 84835010 | 18% |
| 93180931 | Eicher Tractor Injection Pipe Set Ø 1.5            | 990   | 84099941 | 28% |
| 93180980 | Eicher Tractor Clamp For Injector                  | 213   | 84099941 | 28% |





|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93181005 | Eicher Tractor Rubber Ring                          | 13    | 40169320 | 18% |
| 93181066 | Eicher Tractor Inlet Manifold-5300                  | 2402  | 84099941 | 28% |
| 93181145 | Eicher Tractor V-Belt 1280 (50 Hp)                  | 462   | 40101290 | 18% |
| 93181182 | Eicher Tractor Timing Mark Bracket                  | 53    | 84099941 | 28% |
| 93181200 | Eicher Tractor Gasket For Starter Motor & Engine M  | 25    | 68129922 | 18% |
| 93181212 | Eicher Tractor Flywheel 320Ded (755 Tran.)          | 8067  | 84099941 | 28% |
| 93181224 | Eicher Tractor Flywheel Assy. 320Ded(755 Tran.)     | 10550 | 84835010 | 18% |
| 93181340 | Eicher Tractor Gear For Fuel Injection Pump         | 2450  | 87084000 | 18% |
| 93181352 | Eicher Tractor Drive Shaft For Hyd.Pump             | 1903  | 87084000 | 18% |
| 93181364 | Eicher Tractor Gear For Cam Shaft                   | 2153  | 87084000 | 18% |
| 93181388 | Eicher Tractor Gasket (Exhaust Manifold)            | 19    | 84841090 | 18% |
| 93181390 | Eicher Tractor Fuel Filter Bracket                  | 266   | 84219900 | 18% |
| 93181418 | Eicher Tractor Adjusting Latch                      | 207   | 84099941 | 28% |
| 93181443 | Eicher Tractor Crank Pulley 14 Deg Timing           | 1341  | 84099941 | 28% |
| 93181522 | Eicher Tractor Main Bearing Grooved 0.25 O/S        | 180   | 84821011 | 18% |
| 93181534 | Eicher Tractor Main Bearing Grooved 0.50 Mm O/S     | 166   | 84821011 | 18% |
| 93181546 | Eicher Tractor Main Bearing 0.25 Mm                 | 180   | 84821011 | 18% |
| 93181558 | Eicher Tractor Main Bearing 0.5 O/S                 | 183   | 84821011 | 18% |
| 93181560 | Eicher Tractor Big End Bearing 0.25 Mm Over Size    | 171   | 84099941 | 28% |
| 93181571 | Eicher Tractor Big End Bearing 0.50 Mm Over Size    | 171   | 84099941 | 28% |
| 93181704 | Eicher Tractor Air Vent Plug - M18X1.50             | 42    | 84099941 | 28% |
| 93181996 | Eicher Tractor Lifting Eye Valtra                   | 438   | 84099941 | 28% |
| 93182009 | Eicher Tractor Flange For Export                    | 235   | 84099941 | 28% |
| 93182058 | Eicher Tractor Pre Filter Connecting Pipe Assy (Va  | 140   | 84219900 | 18% |
| 93182107 | Eicher Tractor Nozzle Holder Assly                  | 4740  | 84099990 | 28% |
| 93182125 | Eicher Tractor Gasket B/W Ex.Maifold And Silencer   | 49    | 68129090 | 18% |
| 93182173 | Eicher Tractor Cross Member Assly                   | 300   | 84099941 | 28% |
| 93182198 | Eicher Tractor Radiator Pressure Cap                | 195   | 84099941 | 28% |
| 93182204 | Eicher Tractor Recovery Bottle                      | 643   | 84099941 | 28% |
| 93182216 | Eicher Tractor Exh. Manifold Assy With Ceramic Cla  | 4517  | 84099941 | 28% |
| 93182228 | Eicher Tractor Suted For Exhaust Manifold           | 153   | 73182990 | 18% |
| 93182265 | Eicher Tractor Hex Bolt M14X2X70 ,Is:1364-1967,B8.  | 63    | 73181500 | 18% |
| 93182289 | Eicher Tractor Air Inlet Hose(A/C To Tc) \$         | 430   | 40093100 | 18% |
| 93182502 | Eicher Tractor Air Cleaner Primary Element          | 1473  | 84219900 | 18% |
| 93182514 | Eicher Tractor Air Cleaner Choke Indicator          | 418   | 84099941 | 28% |
| 93182538 | Eicher Tractor Piston Ring Set                      | 965   | 84099941 | 28% |
| 93182575 | Eicher Tractor Valve Guide Reamed (Finished)        | 46    | 84099111 | 28% |
| 93182587 | Eicher Tractor Inlet Valve Seat (Finish)            | 160   | 84099941 | 28% |
| 93182599 | Eicher Tractor Exhaust Valve Seat (Finish)          | 161   | 84099941 | 28% |
| 93182629 | Eicher Tractor Gasket B/W Cylinder Head And Exht.M  | 43    | 73182200 | 18% |
| 93182678 | Eicher Tractor Cross Member Sim                     | 18    | 84099941 | 28% |
| 93182680 | Eicher Tractor Gasket B/W Extension And Silencer \$ | 147   | 84841090 | 18% |
| 93182824 | Eicher Tractor Water Inlet Hoses                    | 638   | 40093100 | 18% |
| 93182836 | Eicher Tractor Water Outlet Hoses                   | 475   | 40093100 | 18% |
| 93182885 | Eicher Tractor Tc Oil Inlet Pipe For 320Dr          | 491   | 40092200 | 18% |
| 93182988 | Eicher Tractor Bearing Housing                      | 669   | 84099941 | 28% |
| 93183117 | Eicher Tractor Exh. Extension Assy With Ceramic Cla | 1731  | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93183129 | Eicher Tractor Electrical Hour Cum Rpm Meter(881Es | 1871  | 90292020 | 18% |
| 93183130 | Eicher Tractor Boost Pipe Support (Tc To Ic Boost  | 203   | 84099941 | 28% |
| 93183350 | Eicher Tractor Dry Air Cleaner Assy.               | 4476  | 84099941 | 28% |
| 93183373 | Eicher Tractor Piston                              | 3263  | 84099112 | 28% |
| 93183427 | Eicher Tractor Recovery Bottle ( 621Es/461Es)      | 651   | 84099941 | 28% |
| 93183476 | Eicher Tractor Fuel Injection Pump 320Ded T3A(F867 | 26612 | 84133010 | 28% |
| 93183749 | Eicher Tractor Rigid Cum Flexible Fuel Pipe        | 1912  | 40094200 | 18% |
| 93183841 | Eicher Tractor Silicone Hose Ic Inlet              | 670   | 40093100 | 18% |
| 93183853 | Eicher Tractor Hose (I/C Outlet)                   | 918   | 40093100 | 18% |
| 93183877 | Eicher Tractor Silicon Hose( Ic Outlet)            | 340   | 40093100 | 18% |
| 93184006 | Eicher Tractor Intake Manifold(Valtra Stat)        | 2551  | 84099941 | 28% |
| 93184018 | Eicher Tractor Exhaust Manifold                    | 3238  | 84099941 | 28% |
| 93184160 | Eicher Tractor Link Rod For 45Kva/62.5Kva          | 484   | 84099941 | 28% |
| 93184171 | Eicher Tractor Tc Oil Drain Pipe Assy              | 719   | 40092200 | 18% |
| 93184304 | Eicher Tractor Flywheel Casing M/C Valtra(Industri | 8327  | 84099941 | 28% |
| 93184390 | Eicher Tractor Fan Dia.420-06 Blade Puller         | 3071  | 87089100 | 18% |
| 93184572 | Eicher Tractor Boost Pipe (Tc To Ic Inlet)62.5Kva( | 822   | 84099941 | 28% |
| 93184602 | Eicher Tractor Orifice Plate (Id 18 Mm)            | 109   | 84099990 | 28% |
| 93184663 | Eicher Tractor Identification Plate                | 19    | 87089400 | 18% |
| 93184699 | Eicher Tractor Flywheel For 12' Clutch             | 9319  | 87084000 | 18% |
| 93184729 | Eicher Tractor Support Plate                       | 147   | 84099941 | 28% |
| 93184821 | Eicher Tractor Turbo Charger Assly                 | 21929 | 84148030 | 18% |
| 93184870 | Eicher Tractor Oil Filling Pipe                    | 630   | 84099941 | 28% |
| 93184973 | Eicher Tractor Cap Plastic M8                      | 5     | 39021000 | 18% |
| 93184985 | Eicher Tractor Cap Plastic M14(Block Use 5 Nos)    | 6     | 39021000 | 18% |
| 93185059 | Eicher Tractor Exhaust Manifold M/Cd(320D49 S/C,D/ | 3381  | 84099941 | 28% |
| 93185102 | Eicher Tractor Stud Bolt M10X100 Din 939 8.8       | 49    | 73181500 | 18% |
| 93185114 | Eicher Tractor Stud For Exhaust Manifold M10X100   | 166   | 84099941 | 28% |
| 93185126 | Eicher Tractor Alternator Bracket                  | 320   | 84099941 | 28% |
| 93185138 | Eicher Tractor Bush For Alt Mtg Assy               | 29    | 73181500 | 18% |
| 93185199 | Eicher Tractor Fuel Injection Pump(F20)320D49S/C,D | 38266 | 84133010 | 28% |
| 93185321 | Eicher Tractor Stud M10X120 , Exhaust Manifold     | 171   | 73181500 | 18% |
| 93185333 | Eicher Tractor Bracket - Dual Filter Mtg.          | 432   | 87089900 | 18% |
| 93185345 | Eicher Tractor Cover Of Cylinder Head              | 494   | 84099941 | 28% |
| 93185357 | Eicher Tractor Lifting Eye Bracket For Cyl. Head   | 561   | 87089900 | 18% |
| 93185369 | Eicher Tractor Pr Filter Mounting Bracket          | 704   | 87089900 | 18% |
| 93185473 | Eicher Tractor Stud M8X92, Inlet Manifold          | 42    | 84099941 | 28% |
| 93185485 | Eicher Tractor Hex. Bolt M12X85                    | 45    | 73181500 | 18% |
| 93185564 | Eicher Tractor Fuel Inj. Pump Unit                 | 60217 | 84133010 | 28% |
| 93185576 | Eicher Tractor Gear - Fip                          | 1790  | 84834000 | 18% |
| 93185588 | Eicher Tractor Exhaust Manifold                    | 3152  | 84099941 | 28% |
| 93185620 | Eicher Tractor Injection Pipe Assy. Set Ø1.8       | 831   | 87089900 | 18% |
| 93185710 | Eicher Tractor Clamp For Injector                  | 357   | 84099990 | 28% |
| 93185850 | Eicher Tractor Angle Brackets Lh                   | 155   | 84099990 | 28% |
| 93185862 | Eicher Tractor Angle Bracket (Rh)                  | 155   | 84099990 | 28% |
| 93185874 | Eicher Tractor Turbocharger Tr45-2070 Dcb 6.12     | 21580 | 84148030 | 18% |
| 93185989 | Eicher Tractor Oil Dipstick                        | 119   | 84099941 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93186027 | Eicher Tractor Nozzle Holder Assembly (D-59) 5695   | 5174  | 84133010 | 28% |
| 93186040 | Eicher Tractor Fuel Injection Pump A4000 320D59 (5  | 47281 | 84133010 | 28% |
| 93186260 | Eicher Tractor Identification Plate                 | 19    | 87089400 | 18% |
| 93186520 | Eicher Tractor Intake Manifold Machined(D-59 & 60H  | 2787  | 84099941 | 28% |
| 93186556 | Eicher Tractor Exhaust Manifold Machined(D-59 & 60  | 3144  | 84099941 | 28% |
| 93186568 | Eicher Tractor Turbocharger                         | 34267 | 84148030 | 18% |
| 93186570 | Eicher Tractor Egr Controller-320D59                | 2537  | 85364900 | 18% |
| 93186581 | Eicher Tractor Exhaust Extension                    | 1170  | 84099941 | 28% |
| 93186593 | Eicher Tractor Wiring Harness (Field Retrofit) 82.  | 1501  | 85443000 | 18% |
| 93186611 | Eicher Tractor Pipe - Turbo Inlet Lub.              | 424   | 87089900 | 18% |
| 93186647 | Eicher Tractor Gasket Between Tc & Extension        | 81    | 68129922 | 18% |
| 93186714 | Eicher Tractor Exhaust Muffler Assy                 | 4553  | 87089200 | 18% |
| 93186738 | Eicher Tractor Pipe Egr - Cold End                  | 3742  | 84099941 | 28% |
| 93186740 | Eicher Tractor Pipe Egr - Hot End                   | 3372  | 84099941 | 28% |
| 93186751 | Eicher Tractor Boost Pipe                           | 1200  | 84099120 | 28% |
| 93186775 | Eicher Tractor Hose - (Tc To Boost Pipe)            | 704   | 84099120 | 28% |
| 93186787 | Eicher Tractor Clamp - Boost Pipe                   | 321   | 40169990 | 18% |
| 93186830 | Eicher Tractor Kit - Ccv (Filter+Check Valve)       | 2714  | 84099941 | 28% |
| 93186854 | Eicher Tractor Hose- Ccv Filter To Air Cleaner      | 603   | 84099941 | 28% |
| 93186866 | Eicher Tractor Hose - Ccv Filter To Check Valve     | 451   | 84099941 | 28% |
| 93186891 | Eicher Tractor P-Clamp (Ccv Oil Drain Hose)         | 27    | 84099120 | 28% |
| 93186945 | Eicher Tractor Hose- Rocker Cover To Ccv Filter     | 573   | 84099941 | 28% |
| 93186970 | Eicher Tractor Hose - Check Valve To Crankcase      | 102   | 84099941 | 28% |
| 93186994 | Eicher Tractor Cylinder Block M/Cd (D-59 Model)     | 63331 | 84099941 | 28% |
| 93187020 | Eicher Tractor Hose Clamp- Upper                    | 89    | 84099120 | 28% |
| 93187032 | Eicher Tractor Hose Clamp- Lower                    | 89    | 84099120 | 28% |
| 93187081 | Eicher Tractor Bracket - Boost Pipe Support         | 473   | 84099990 | 28% |
| 93187172 | Eicher Tractor Tc Oil Drain Pipe                    | 1307  | 84099120 | 28% |
| 93187214 | Eicher Tractor Connector - Tc Oil Drain             | 201   | 84099120 | 28% |
| 93187240 | Eicher Tractor Thermostat Housing                   | 1561  | 84099941 | 28% |
| 93187378 | Eicher Tractor Stud Din939-M10*30 With Self-Lockin  | 24    | 73182100 | 18% |
| 93190018 | Eicher Tractor 74S30120 = Setscrew Water Outlet Bo  | 20    | 73181500 | 18% |
| 93190020 | Eicher Tractor Hose Radiator To Inlet Manifold      | 211   | 40093100 | 18% |
| 93190031 | Eicher Tractor Intake Tube                          | 151   | 87089100 | 18% |
| 93190043 | Eicher Tractor Radiator Pad                         | 48    | 87087000 | 18% |
| 93190055 | Eicher Tractor Air Cleaner Mtg Bkt                  | 880   | 84099941 | 28% |
| 93190079 | Eicher Tractor Water Hose (Radiator Out Let To Eng  | 464   | 40093100 | 18% |
| 93190080 | Eicher Tractor Water Hose(Eng. Out Let To Radiator) | 207   | 40093100 | 18% |
| 93190104 | Eicher Tractor Gasket Exhaust Extension Stud        | 271   | 68129090 | 18% |
| 93190110 | Eicher Tractor Strip                                | 116   | 73011000 | 18% |
| 93190122 | Eicher Tractor Fuel Line (Water Separator To Feed   | 232   | 84219900 | 18% |
| 93190158 | Eicher Tractor Fuel Line(Fip Over Flow To F Tank)   | 472   | 84099941 | 28% |
| 93190161 | Eicher Tractor Radiator Assy                        | 11211 | 87087000 | 18% |
| 93190171 | Eicher Tractor Fuel Filter Bkt.                     | 114   | 84219900 | 18% |
| 93190201 | Eicher Tractor Air Inlet Hose (A/C Side)            | 509   | 40093100 | 18% |
| 93190237 | Eicher Tractor Fuel Pipe Injector (Over Flow To Ta  | 138   | 84099941 | 28% |
| 93190304 | Eicher Tractor 10S30535 = Bkt For Alternator        | 373   | 84099941 | 28% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93190330 | Eicher Tractor 2418M006 = Seal, Water Pump          | 337  | 84099941 | 28% |
| 93190341 | Eicher Tractor 31731515 = Tab Washer Bal.Wt. Setsc  | 7    | 73182100 | 18% |
| 93190353 | Eicher Tractor 92De0173 = Rubber Seal Cyl Head Cov  | 33   | 40169320 | 18% |
| 93190365 | Eicher Tractor 24S30119 = Cover,Cyl.Head Cover ( 4  | 1077 | 84099941 | 28% |
| 93190377 | Eicher Tractor 00032346 = Shaft, Water Pump(Int.Br  | 611  | 84835010 | 18% |
| 93190389 | Eicher Tractor 49S30127 = Gasket Cylinder Head      | 574  | 84841090 | 18% |
| 93190390 | Eicher Tractor 00050033 = Lever Rock. Lh Assy With  | 278  | 84099941 | 28% |
| 93190407 | Eicher Tractor 00050032 = Lever Rocker R.H.Assy Wi  | 278  | 84099941 | 28% |
| 93190420 | Eicher Tractor De005495 = Water Pump Kit Comprisin  | 544  | 84099941 | 28% |
| 93190432 | Eicher Tractor 00920053 = Washer Spring O.Seal Hsg  | 2    | 73182100 | 18% |
| 93190435 | Eicher Tractor Push Rod Tube-298E                   | 180  | 84129090 | 18% |
| 93190444 | Eicher Tractor 00095250 = Bolt Connecting Rod Cap   | 57   | 73181500 | 18% |
| 93190447 | Eicher Tractor O-Ring (Push Rod Tube)               | 24   | 40169320 | 18% |
| 93190456 | Eicher Tractor De005755 = Joint Kit Major (Item No  | 1880 | 84841090 | 18% |
| 93190468 | Eicher Tractor 00150008 = Cap Valve Spring          | 54   | 84099941 | 28% |
| 93190470 | Eicher Tractor 00170001 = Circlip Gudgeon Pin Reta  | 16   | 73182910 | 18% |
| 93190493 | Eicher Tractor 00180064 = Clip Cyl.Head Extn. Pipe  | 33   | 40093100 | 18% |
| 93190500 | Eicher Tractor 00180067 = Clip Hose                 | 36   | 40093100 | 18% |
| 93190511 | Eicher Tractor 00180066 = Clip Hose                 | 33   | 40093100 | 18% |
| 93190523 | Eicher Tractor 00180831 = Circlip Pump Idler Gr Re  | 6    | 73182910 | 18% |
| 93190535 | Eicher Tractor 00202016 = Hose Bypass Connection    | 109  | 40093100 | 18% |
| 93190559 | Eicher Tractor 00230001 = Cotter Valve Spring       | 11   | 84099941 | 28% |
| 93190560 | Eicher Tractor 00330505 = Distance Piece Rocker Le  | 10   | 84099941 | 28% |
| 93190584 | Eicher Tractor 00350005 = Dowel Idler Gear Hub Loc  | 8    | 84099941 | 28% |
| 93190596 | Eicher Tractor 00350015 = Dowel Cyl.Block To O.Sea  | 10   | 84099941 | 28% |
| 93190602 | Eicher Tractor 00350016 = Dowel Cyl. Block To Adop  | 13   | 84099941 | 28% |
| 93190638 | Eicher Tractor 00410236 = Starter Ring              | 1493 | 84099941 | 28% |
| 93190640 | Eicher Tractor 00410241 = Gear Camshaft Driving     | 1043 | 84099941 | 28% |
| 93190651 | Eicher Tractor 00490184 = Jt. Water Outlet Connecti | 12   | 84099941 | 28% |
| 93190675 | Eicher Tractor 00490482 = Jt.Cyl.Water Outlet Conn  | 19   | 84099941 | 28% |
| 93190687 | Eicher Tractor 00490484 = Joint Water Pump Back Pl  | 25   | 84099941 | 28% |
| 93190699 | Eicher Tractor 49S30128 = Jt.Cyl. Head Rear And Co  | 11   | 84099941 | 28% |
| 93190705 | Eicher Tractor 00490486 = Jt.Cyl. Blk Water Inlet   | 11   | 84099941 | 28% |
| 93190717 | Eicher Tractor 49S30123 = Joint Lub Oil Filter To   | 5    | 84219900 | 18% |
| 93190729 | Eicher Tractor 49S30122 = Jt. Fuel Pump To Timing   | 16   | 84099941 | 28% |
| 93190730 | Eicher Tractor 00560244 = Olive Lub. Oil Delivery   | 28   | 84099941 | 28% |
| 93190754 | Eicher Tractor 00571350 = Nut Fuel Pipe Damper Scr  | 5    | 73181500 | 18% |
| 93190780 | Eicher Tractor 15De0048 = Cap Lub Oil Filter        | 94   | 84219900 | 18% |
| 93190791 | Eicher Tractor 00650507 = Plug Rocker Shaft End     | 4    | 84099941 | 28% |
| 93190810 | Eicher Tractor 00650566 = Plug Cyl.Bl.Press.Rail F  | 12   | 84099941 | 28% |
| 93190821 | Eicher Tractor 00650586 = Plug                      | 12   | 84099941 | 28% |
| 93190833 | Eicher Tractor 00650586 = Plug Water Outlet Body    | 19   | 87084000 | 18% |
| 93190924 | Eicher Tractor 00920003 = Washer Plain F.Inj.Pump   | 4    | 73182100 | 18% |
| 93190936 | Eicher Tractor 00920004 = Washer Rockershaft Bkt R  | 4    | 73182100 | 18% |
| 93190948 | Eicher Tractor 00920052 = Wspring Frt Cvr To Timin  | 7    | 84099941 | 28% |
| 93190961 | Eicher Tractor 32S30036 = Dip Stick                 | 110  | 84099941 | 28% |
| 93190973 | Eicher Tractor 00920056 = W.Spring Lub.Oil Sump Bk  | 4    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93190985 | Eicher Tractor 00920058 = Washer Spring              | 9     | 73182100 | 18% |
| 93191000 | Eicher Tractor 92De0009 = Washer Banjo Bolt (Mico)   | 8     | 73182100 | 18% |
| 93191011 | Eicher Tractor 00920299 = Wshakeproof Timing Case    | 1     | 73182200 | 18% |
| 93191023 | Eicher Tractor 00920883 = Tab Wash. Idler Gear Hub   | 13    | 84099941 | 28% |
| 93191035 | Eicher Tractor 00940737 = Plate Cyl. Head Rear End   | 208   | 84099941 | 28% |
| 93191047 | Eicher Tractor 00940738 = Plate Idler Gear Retaini   | 48    | 84099941 | 28% |
| 93191059 | Eicher Tractor 00941183 = Back Pl. Water Pump Body   | 148   | 84099941 | 28% |
| 93191060 | Eicher Tractor 00995447 = Hub Idler Gear             | 486   | 84099941 | 28% |
| 93191072 | Eicher Tractor 02116078 = Dowel Drie Gear Locating   | 11    | 84099941 | 28% |
| 93191084 | Eicher Tractor 00690073 = Rivet Camshaft Thrust Sp   | 1     | 73182300 | 18% |
| 93191096 | Eicher Tractor 02182008 = Screw F. Injection Pipe    | 12    | 73181500 | 18% |
| 93191102 | Eicher Tractor 02185189 = Setscrew Balance Weight    | 37    | 73181500 | 18% |
| 93191114 | Eicher Tractor 65S30050 = Plug Oil Darin             | 171   | 84099941 | 28% |
| 93191138 | Eicher Tractor 73S30025 = O'Ring Dain Plug           | 17    | 84099941 | 28% |
| 93191140 | Eicher Tractor 83S30101 = Sump Lub Pil Castrine      | 20114 | 84099941 | 28% |
| 93191151 | Eicher Tractor 02415344 = Seal Timing Case Ft Cove   | 347   | 84099941 | 28% |
| 93191163 | Eicher Tractor 02415608 = 'O'Ring Rear Brg Cap Thi   | 24    | 84099941 | 28% |
| 93191175 | Eicher Tractor 99S31277 = Pipe Suction Assly         | 582   | 84099941 | 28% |
| 93191187 | Eicher Tractor 02431154 = Plug Cyl. Head             | 13    | 84099941 | 28% |
| 93191205 | Eicher Tractor 07De0018 = Belt Water Pump Pulley     | 226   | 40103290 | 18% |
| 93191217 | Eicher Tractor S4099177=Piston Assy With Pin & Cir   | 2270  | 84099114 | 28% |
| 93191229 | Eicher Tractor 32712715 = Plunger                    | 36    | 84099941 | 28% |
| 93191230 | Eicher Tractor 10S30289 = Bracket Rockershaft        | 123   | 84099941 | 28% |
| 93191254 | Eicher Tractor 20S30159 = Connection Cyl Head Wate   | 737   | 84099941 | 28% |
| 93191280 | Eicher Tractor 31131171 = Bearing, Cont Rod Big En   | 91    | 84099941 | 28% |
| 93191291 | Eicher Tractor 31131172 = Bearing Cont Rod Big End   | 100   | 84099941 | 28% |
| 93191308 | Eicher Tractor 31131173 = Bearing Cont Rod Big End   | 92    | 84821011 | 18% |
| 93191310 | Eicher Tractor 31131174 = Bearing Cont Rod Big End   | 92    | 84821011 | 18% |
| 93191333 | Eicher Tractor S4009933 = Washer Main Brg. Thrust T  | 190   | 73182100 | 18% |
| 93191370 | Eicher Tractor S4006717 = Pulley Crank Shaft (22")   | 1217  | 84835010 | 18% |
| 93191394 | Eicher Tractor 31164362 = Gear Idler                 | 2165  | 84099941 | 28% |
| 93191400 | Eicher Tractor 31164449 = Gear Fuel Pump Drive       | 1221  | 84099941 | 28% |
| 93191412 | Eicher Tractor 31328241 = Balance Wt. Crankshaft     | 1323  | 84099941 | 28% |
| 93191448 | Eicher Tractor 53De0005 = Liner Cyl. Block           | 807   | 84099941 | 28% |
| 93191450 | Eicher Tractor 37764251 = Head Lub. Oil Filter Asse  | 436   | 84219900 | 18% |
| 93191485 | Eicher Tractor 31431681 = Valve Inlet                | 242   | 84099941 | 28% |
| 93191497 | Eicher Tractor 31431011 = Valve Exhaust              | 371   | 84099941 | 28% |
| 93191503 | Eicher Tractor 31731516 = Tab Washer Bal. Setscrew   | 7     | 73182100 | 18% |
| 93191527 | Eicher Tractor 31754118 = Coil Spring Breath. Pipe   | 30    | 84099941 | 28% |
| 93191539 | Eicher Tractor 32S30026 = Dipstick Lub. Oil Sump A   | 90    | 84099941 | 28% |
| 93191540 | Eicher Tractor 32181458 = Bolt Cyl. Head Long        | 72    | 73181500 | 18% |
| 93191552 | Eicher Tractor 32181457 = Bolt Cyl. Head Short       | 59    | 73181500 | 18% |
| 93191606 | Eicher Tractor 33114118 = W. Timing Case To Cyl. Blk | 2     | 84099941 | 28% |
| 93191618 | Eicher Tractor 00921062 = W. Tab F. W To Crankshft S | 17    | 84099941 | 28% |
| 93191620 | Eicher Tractor 33125112 = W., Crankshaft Pulley Re   | 81    | 84099941 | 28% |
| 93191631 | Eicher Tractor 00870001 = Thimble Crankshaft Brg C   | 13    | 84099941 | 28% |
| 93191655 | Eicher Tractor 33176137 = Spacer Crankshaft Oil Th   | 19    | 84099941 | 28% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93191667 | Eicher Tractor 33221319 = Nut Cyl. Head Retn.       | 9    | 73181500 | 18% |
| 93191679 | Eicher Tractor 33221319 = Nut Conn. Rod To Cap Bol  | 8    | 73181600 | 18% |
| 93191680 | Eicher Tractor 33242407 = Tube Lub.Oil Sump Dipsti  | 31   | 84099941 | 28% |
| 93191692 | Eicher Tractor 33261723 = Guide Exhaust And Inlet   | 52   | 84099941 | 28% |
| 93191709 | Eicher Tractor 33177518 = Washer Spring Locating    | 17   | 73182100 | 18% |
| 93191734 | Eicher Tractor 33817114 = Dust Shield-Atomiser      | 20   | 84099941 | 28% |
| 93191758 | Eicher Tractor 49S30119 = Joint Rear End Hsg To Cy  | 59   | 84099941 | 28% |
| 93191760 | Eicher Tractor 33872531 = Pipe Breather Extension   | 76   | 84099941 | 28% |
| 93191771 | Eicher Tractor 34711129 = Pipe Lub.Oil Del.Pump To  | 120  | 84099941 | 28% |
| 93191783 | Eicher Tractor 34821422 = Hose Water Pump Outlet T  | 212  | 40093100 | 18% |
| 93191801 | Eicher Tractor 36271704 = Key Crankshaft            | 84   | 84099941 | 28% |
| 93191813 | Eicher Tractor 36511123 = Plate F.Inj.Pipe Vib.Dam  | 6    | 84099941 | 28% |
| 93191825 | Eicher Tractor 36561129 = Clip Breather Pipe Suppo  | 12   | 84099941 | 28% |
| 93191874 | Eicher Tractor 49S30126 = Joint Timing Case To Blo  | 180  | 84099941 | 28% |
| 93191898 | Eicher Tractor 36844116 = Damper F.Injec. Pipe Vib  | 11   | 84099941 | 28% |
| 93191916 | Eicher Tractor 36862143 = Jt.Exhaust Manifold To C  | 11   | 84099941 | 28% |
| 93191928 | Eicher Tractor 36862511 = Jt. Tachometer Drive Hsg  | 18   | 84099941 | 28% |
| 93191941 | Eicher Tractor 36867153 = Jt Induct.Manifold To Cy  | 72   | 84099941 | 28% |
| 93191953 | Eicher Tractor 36884112 = Joint Sump To Cylinder B  | 18   | 84099941 | 28% |
| 93191965 | Eicher Tractor 99S31183 = Cyl. Head Cover Assembly  | 331  | 84099941 | 28% |
| 93191977 | Eicher Tractor 24S30111 = Cover, Timing Case Botto  | 277  | 84099941 | 28% |
| 93191989 | Eicher Tractor 94De0019 = Plate Tachometer Drive B  | 62   | 84099941 | 28% |
| 93191990 | Eicher Tractor 37424611 = Housing Rear End Oil Sea  | 209  | 40169330 | 18% |
| 93192003 | Eicher Tractor 37447194 = Impeller                  | 206  | 84099941 | 28% |
| 93192027 | Eicher Tractor 37711332 = Body Water Ump            | 598  | 84099941 | 28% |
| 93192039 | Eicher Tractor 37736242 = Connection Cyl. Blk Water | 265  | 84099941 | 28% |
| 93192040 | Eicher Tractor 54S30045 = Manifold Induction        | 477  | 84099941 | 28% |
| 93192064 | Eicher Tractor 99S30540 = Lub.Oil Pump Idler Gear   | 616  | 84099941 | 28% |
| 93192076 | Eicher Tractor 99S31048 = Joint Lub.Oil Sump To Bl  | 124  | 84099941 | 28% |
| 93192090 | Eicher Tractor 44S30125 = Adaptor Plate Flywheel H  | 9353 | 84099941 | 28% |
| 93192106 | Eicher Tractor 49S30081 = Joint Lub Oil Sump Front  | 19   | 84099941 | 28% |
| 93192118 | Eicher Tractor 49S30113 = Joint Cylinder Head Cove  | 75   | 84099941 | 28% |
| 93192120 | Eicher Tractor 49S30133 = Joint Cylinder Head Cove  | 154  | 84099941 | 28% |
| 93192167 | Eicher Tractor S4005706 = Nut Cyl Head Top Cover R  | 8    | 73181500 | 18% |
| 93192180 | Eicher Tractor S4005710 = Nut Timing Case Front Co  | 3    | 73181500 | 18% |
| 93192192 | Eicher Tractor S4005711 = Gland Nut Lub.Oil Sump &  | 24   | 73181500 | 18% |
| 93192210 | Eicher Tractor S4006504 = Plug Sump Drain (Magneti  | 92   | 84099941 | 28% |
| 93192222 | Eicher Tractor S4006505 = Drain Plug Cylinder Bloc  | 72   | 84099941 | 28% |
| 93192337 | Eicher Tractor 00920443 = Metal Washer Cyl Head Co  | 7    | 73182990 | 18% |
| 93192349 | Eicher Tractor S4007423 = Setscrew Front Cover To   | 12   | 73181500 | 18% |
| 93192441 | Eicher Tractor S4008212 = Stud Water Outlet Connec  | 9    | 73182990 | 18% |
| 93192477 | Eicher Tractor S4008219 = Stud Cylhd To Rockershaf  | 21   | 73182990 | 18% |
| 93192507 | Eicher Tractor S4009202 = Washer Drain Plug Cyl Bl  | 2    | 73182100 | 18% |
| 93192568 | Eicher Tractor 57S30051 = Nut Lub Oil Sump Bkt To   | 11   | 73181500 | 18% |
| 93192593 | Eicher Tractor Piston Assy. (S325 Prtopped-63S3002  | 2236 | 84099114 | 28% |
| 93192600 | Eicher Tractor 67S30053 = Pully                     | 444  | 84835010 | 18% |
| 93192647 | Eicher Tractor 74S30118 = Stscrew Idler Gr.Hub To   | 33   | 73181500 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93192659 | Eicher Tractor 74S30127 = Setscrew                   | 27    | 73181500 | 18% |
| 93192672 | Eicher Tractor 74S30121 = Setscrew Timing Case To    | 9     | 73181500 | 18% |
| 93192684 | Eicher Tractor 74S30122 = S. Screw Frt. Axle Support | 96    | 73181500 | 18% |
| 93192702 | Eicher Tractor 82S30060 = Stud Cyl. Block To Sump    | 10    | 73182100 | 18% |
| 93192726 | Eicher Tractor 82S30063 = Stud Cyl Hd To Exh. Manif  | 18    | 73182100 | 18% |
| 93192738 | Eicher Tractor 82S30064 = Stud Timing Case Frnt Cv   | 5     | 73182100 | 18% |
| 93192740 | Eicher Tractor 82S30065 = Stud T. C Cover Ext. Pipe  | 86    | 73182100 | 18% |
| 93192763 | Eicher Tractor S4007426 = Setscrew Crankshaft Pull   | 119   | 73181110 | 18% |
| 93192775 | Eicher Tractor 00860012 = Tappet                     | 251   | 84099941 | 28% |
| 93192787 | Eicher Tractor 94S30155 = Plate Engine Lifting Rea   | 23    | 84099990 | 28% |
| 93192830 | Eicher Tractor 99S31084 = Pipe Fueloil Main Leak O   | 267   | 84099941 | 28% |
| 93192842 | Eicher Tractor 99S30964 = Pump Lub. Oil Assy         | 3393  | 84099941 | 28% |
| 93192933 | Eicher Tractor 65De0007 = Plug Fuel Filter2 911 27   | 18    | 84099941 | 28% |
| 93192957 | Eicher Tractor 92De0011 = Washer (1 413 453 025)     | 11    | 73182100 | 18% |
| 93193044 | Eicher Tractor 0068083A = Main Brg. 010 Undersize    | 822   | 84833000 | 18% |
| 93193056 | Eicher Tractor 0068083B = 020 Undersize              | 822   | 84833000 | 18% |
| 93193070 | Eicher Tractor 00780006 = Spring Exhaust And Inlet   | 69    | 84099941 | 28% |
| 93193093 | Eicher Tractor 09De0005 = Bolt Banjo (Mico9 411 03   | 22    | 73181900 | 18% |
| 93193123 | Eicher Tractor 20De0146 = Adaptor Lub Oil Pr. Gauge  | 51    | 84099941 | 28% |
| 93193135 | Eicher Tractor 2418F475 = Seal Crankshaft Rear End   | 1006  | 84099941 | 28% |
| 93193147 | Eicher Tractor 26S30011 = Crankshaft                 | 16489 | 84099941 | 28% |
| 93193202 | Eicher Tractor 74De0844 = Setscrew Driving Gr To C   | 11    | 73181500 | 18% |
| 93193226 | Eicher Tractor 99S31244 = Rocker Shaft Assly (W/Br   | 2038  | 84099941 | 28% |
| 93193263 | Eicher Tractor 92De0873 = Washer Spring              | 5     | 73182100 | 18% |
| 93193275 | Eicher Tractor 94De0053 = Adaptor Fuel Inject Pump   | 458   | 84099941 | 28% |
| 93193305 | Eicher Tractor 99De0203 = Pipe Fuel Injection Asy    | 300   | 84099941 | 28% |
| 93193317 | Eicher Tractor 99De0204 = Pipe Fuel Injection Asy    | 300   | 84099941 | 28% |
| 93193329 | Eicher Tractor 99De0205 = Pipe Fuel Injection Asy    | 300   | 84099941 | 28% |
| 93193330 | Eicher Tractor 99De0347 = Rockershaft Assy           | 2800  | 84099941 | 28% |
| 93193354 | Eicher Tractor 99S30799 = Water Pump Assy            | 3383  | 84099941 | 28% |
| 93193366 | Eicher Tractor 99S30480 = Cylinder Head Assy (Mino   | 15874 | 84099941 | 28% |
| 93193391 | Eicher Tractor 83S30092 = Sump Lub. Oil              | 13294 | 84099941 | 28% |
| 93193470 | Eicher Tractor 00032550 = Thermostat                 | 499   | 90321090 | 18% |
| 93193494 | Eicher Tractor De005755 = Joint Kit Major Item No    | 1716  | 84841090 | 18% |
| 93193500 | Eicher Tractor 10S30281 = Bracket Lub Oil Sump To    | 468   | 84099941 | 28% |
| 93193550 | Eicher Tractor 00068083 = Brg. Crankshaft Main Std   | 1081  | 84831092 | 18% |
| 93193603 | Eicher Tractor S4007404 = Bolt Timing Case Front C   | 11    | 73181500 | 18% |
| 93193639 | Eicher Tractor Sa063496 = Connecting Rod Assy Less   | 1569  | 84099941 | 28% |
| 93193706 | Eicher Tractor 02654408 = Canister Element           | 185   | 84212300 | 18% |
| 93193718 | Eicher Tractor 49S30135 = Joint Cylinder Head Cove   | 491   | 84099941 | 28% |
| 93193720 | Eicher Tractor 73De0016 = Seal Value Stem            | 73    | 84099941 | 28% |
| 93193779 | Eicher Tractor Cogged Belt -Alternator Driving-7S3   | 462   | 40103999 | 18% |
| 93193780 | Eicher Tractor Starter Motor (Mico)-De005339         | 14162 | 85114000 | 28% |
| 93193834 | Eicher Tractor 00920645 = Washer Tab Fan To Water    | 8     | 73182100 | 18% |
| 93193846 | Eicher Tractor 99S30644 = Pipe Fuel Pump Overflow    | 152   | 84099941 | 28% |
| 93193895 | Eicher Tractor De005756 = Joints Top Overhead Kit    | 13623 | 84841090 | 18% |
| 93193913 | Eicher Tractor 49S30105 = Joint Lub Oil Sump Reae    | 19    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93193925 | Eicher Tractor 00490016 = Joint Lub Oil Suction Pi | 6     | 84099941 | 28% |
| 93193937 | Eicher Tractor Fuel Pipe Assy (F.Pump To F.Filter) | 148   | 84099941 | 28% |
| 93193949 | Eicher Tractor Fuel Pipe Assy (F.Filter To F.Pump) | 130   | 84099941 | 28% |
| 93193974 | Eicher Tractor 99S31205 = F W Assy                 | 26627 | 84099941 | 28% |
| 93193986 | Eicher Tractor 36De0021 = Fan Assly 15" Pulley Typ | 271   | 84099941 | 28% |
| 93193998 | Eicher Tractor 10S30539 = Bracket Rocker Shaft     | 187   | 84099941 | 28% |
| 93194000 | Eicher Tractor Alternator With Pulley              | 6695  | 85115000 | 28% |
| 93211010 | Eicher Tractor Thrust Washer                       | 277   | 73182100 | 18% |
| 93225513 | Eicher Tractor H.D. Exhaust Fan -15 Inch Sweep     | 6052  | 84149040 | 18% |
| 93225525 | Eicher Tractor H.D. Exhaust Fan -18 Inch Sweep     | 8038  | 84149040 | 18% |
| 93226013 | Eicher Tractor Engine Safety Unit                  | 4485  | 85371000 | 18% |
| 93226025 | Eicher Tractor Genset Control Unit                 | 6030  | 85371000 | 18% |
| 93230030 | Eicher Tractor Cone Clamping                       | 15    | 84099990 | 28% |
| 93230077 | Eicher Tractor Fly Wheel Casing 222Es/Hs \$        | 4717  | 84099941 | 28% |
| 93230089 | Eicher Tractor A/C Mounting Clamp                  | 469   | 84099941 | 28% |
| 93230107 | Eicher Tractor Rubber Hose For Dry A/C             | 493   | 40093100 | 18% |
| 93230119 | Eicher Tractor Air Cleaner Assy With Clamp \$      | 3301  | 84213920 | 18% |
| 93230247 | Eicher Tractor Crank Pully For 222Es And 222Hs (20 | 1684  | 84099941 | 28% |
| 93230284 | Eicher Tractor Bracket Cum Lifting Hook 222Esg \$  | 739   | 84099941 | 28% |
| 93230764 | Eicher Tractor Fuel Pipe Assy(Ff To Fip)(F)        | 367   | 84099941 | 28% |
| 93231150 | Eicher Tractor Fly Wheel – 222Es Genset            | 34139 | 84099941 | 28% |
| 93231161 | Eicher Tractor Fly Wheel Casing M/Cd (222Esg)(Ndr) | 10829 | 84099941 | 28% |
| 93231227 | Eicher Tractor Timing Marking Bracket              | 32    | 84099941 | 28% |
| 93231239 | Eicher Tractor A/C Bracket Cum Lifting Hook 222Es  | 719   | 84091000 | 28% |
| 93231306 | Eicher Tractor Bracket For Alternator (222Es)      | 366   | 84099941 | 28% |
| 93231471 | Eicher Tractor Crank Shaft                         | 9591  | 84831092 | 18% |
| 93231481 | Eicher Tractor Crank Shaft Sub Assly.              | 13573 | 84831092 | 18% |
| 93231513 | Eicher Tractor Kit For Air Cleaner W/O Safety Ele  | 2132  | 84099941 | 28% |
| 93231677 | Eicher Tractor Crank Pulley                        | 1059  | 84835010 | 18% |
| 93231690 | Eicher Tractor Cam Shaft 115-Esg                   | 1644  | 84831099 | 18% |
| 93231707 | Eicher Tractor Rigid Fuel Pipe Ff To Fp            | 571   | 40094200 | 18% |
| 93232438 | Eicher Tractor Fly Wheel M/Cd                      | 32480 | 84835010 | 18% |
| 93232566 | Eicher Tractor Adjusting Latch -222Esg             | 165   | 84099941 | 28% |
| 93232645 | Eicher Tractor Split Adaptor                       | 261   | 84099941 | 28% |
| 93232657 | Eicher Tractor Fly Wheel Casing M/Cd               | 6488  | 84099941 | 28% |
| 93232797 | Eicher Tractor Upper Housing Assly 222Es/Hs (Vave  | 670   | 84099990 | 28% |
| 93232815 | Eicher Tractor Idler Pulley-322 /422Esg W/Out Alt. | 558   | 84099941 | 28% |
| 93232827 | Eicher Tractor Hand Accelator Lever                | 253   | 84099941 | 28% |
| 93232943 | Eicher Tractor Holding Plate-322 /422Esg W/Out Alt | 926   | 84099941 | 28% |
| 93232967 | Eicher Tractor V-Belt Avx 13 X 1235                | 450   | 40101290 | 18% |
| 93232979 | Eicher Tractor Stop Solenoid - 222Es (Rico)        | 2568  | 84099941 | 28% |
| 93232980 | Eicher Tractor Stop Solenoid -222Es (Mvd)          | 2594  | 84099941 | 28% |
| 93233080 | Eicher Tractor Breather Tube 222Esg                | 165   | 85462019 | 28% |
| 93233327 | Eicher Tractor Extension Tube                      | 462   | 84099941 | 28% |
| 93233479 | Eicher Tractor V-Belt Avx 13 X 1215                | 505   | 40101290 | 18% |
| 93233789 | Eicher Tractor Retro Kit Wc-10Kva-Rjio-Sedema To P | 12272 | 85030010 | 18% |
| 93233790 | Eicher Tractor Retro Kit Wc-10Kva-Rjio-Utopia To P | 13008 | 85030010 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93233807 | Eicher Tractor Retro Kit Wic-10Kva-Rjio-Utopia To  | 2537  | 85381010 | 18% |
| 93233819 | Eicher Tractor Procom Econ-Abt-Rel-10Kva           | 11800 | 85030010 | 18% |
| 93233844 | Eicher Tractor Retro Kit Wic-10Kva-Rjio-Sedema To  | 2537  | 85381010 | 18% |
| 93233856 | Eicher Tractor Retro Kit Wic-10Kva-Rjio-Utopia To  | 2537  | 85381010 | 18% |
| 93233893 | Eicher Tractor Retrofitment Kit (With Sedemac      | 12272 | 85030010 | 18% |
| 93233935 | Eicher Tractor Actuating Pin                       | 37    | 84129090 | 18% |
| 93233972 | Eicher Tractor Avr (5 To 125Kva)                   | 3264  | 85030010 | 18% |
| 93240060 | Eicher Tractor Kit For Rigid Fuel Pipe 322Esg      | 1884  | 84099941 | 28% |
| 93240095 | Eicher Tractor Instruction Plate                   | 34    | 84099941 | 28% |
| 93240125 | Eicher Tractor Fuel Pipe Assly (Wire Braded)       | 516   | 40092200 | 18% |
| 93240230 | Eicher Tractor Fuel Tank Assy 222Es/222Hs \$       | 6029  | 84099941 | 28% |
| 93240320 | Eicher Tractor Cyl. Head Sub Assy                  | 6817  | 84099941 | 28% |
| 93240356 | Eicher Tractor Oil Filter Element                  | 171   | 84219900 | 18% |
| 93240368 | Eicher Tractor Fuel Injection Pump-323(No.621)     | 24873 | 84133010 | 28% |
| 93240370 | Eicher Tractor Injector Assy. For 323 Model-289    | 4144  | 84099990 | 28% |
| 93240381 | Eicher Tractor Solenoid And Hand Accl. Mtg. Bracke | 494   | 85365090 | 18% |
| 93240423 | Eicher Tractor Pedestal Front M/Cd (Stat) 322Es/42 | 2172  | 84099941 | 28% |
| 93240435 | Eicher Tractor Pedestal Rear M/Cd (Stat) -322Es/42 | 2336  | 84099941 | 28% |
| 93240447 | Eicher Tractor Crank Pulley For 323 Esg (19")      | 1947  | 84835010 | 18% |
| 93240459 | Eicher Tractor Fuel Injection Pipe Assy Set-323Esg | 531   | 84099941 | 28% |
| 93240496 | Eicher Tractor Fuel Inj. Pump Unit                 | 41455 | 84133010 | 28% |
| 93240502 | Eicher Tractor Nozzle Holder Assly (75 & 85 Hp)(24 | 5027  | 84099990 | 28% |
| 93240605 | Eicher Tractor Fuel Pipe Assly (Fuel Filter To Fue | 875   | 84099941 | 28% |
| 93240617 | Eicher Tractor Fuel Pipe Assly (Feed Pump To Filte | 597   | 40094200 | 18% |
| 93240630 | Eicher Tractor Oil Filter Element Kit              | 181   | 84219900 | 18% |
| 93240654 | Eicher Tractor Solenoid And Hand Accl. Mtg. Bracke | 24    | 85365090 | 18% |
| 93240769 | Eicher Tractor Bearing Hsg. Rear                   | 2785  | 84099941 | 28% |
| 93241026 | Eicher Tractor Oil Filter Head Cum Inspection Cove | 1274  | 84219900 | 18% |
| 93241130 | Eicher Tractor Inlet Manifold Front                | 610   | 84099941 | 28% |
| 93241257 | Eicher Tractor Belt Guard Assembly(322 Esg/422Esg) | 657   | 84099941 | 28% |
| 93241300 | Eicher Tractor Inlet Manifold Rear (422Esg& Tci M  | 439   | 84099941 | 28% |
| 93241336 | Eicher Tractor Inlet Manifold (With Core Plug Feat | 596   | 84099941 | 28% |
| 93241350 | Eicher Tractor Adjusting Latch                     | 139   | 84099941 | 28% |
| 93241490 | Eicher Tractor Kit For Air Cleaner W/O Safety Ele  | 2111  | 84099941 | 28% |
| 93241520 | Eicher Tractor Injector Assy-464                   | 3640  | 84099990 | 28% |
| 93241531 | Eicher Tractor Cyl. Head Sub Assy                  | 6168  | 76169990 | 18% |
| 93241567 | Eicher Tractor Inlet Manifold                      | 1448  | 84099941 | 28% |
| 93241774 | Eicher Tractor Crank Pulley For 323 Esg (17")      | 2314  | 84099941 | 28% |
| 93241890 | Eicher Tractor Dipstick Assly 322Esg               | 63    | 84099941 | 28% |
| 93241907 | Eicher Tractor Dipstick Assly.(321/322 Es)         | 72    | 84099941 | 28% |
| 93241944 | Eicher Tractor Inspection Cover Rear (Sheet Metal) | 812   | 84099941 | 28% |
| 93242754 | Eicher Tractor Solenoid Rubber Below -Neoprene     | 96    | 85365090 | 18% |
| 93243217 | Eicher Tractor Blower Shaft Assly.                 | 7493  | 84099941 | 28% |
| 93243618 | Eicher Tractor Oil Pressure Switch                 | 197   | 84099941 | 28% |
| 93243620 | Eicher Tractor Oil Pressure Sensor (Llop)          | 953   | 90268090 | 18% |
| 93244106 | Eicher Tractor Gcu Gc 2111 - Rjil                  | 11800 | 85030010 | 18% |
| 93244258 | Eicher Tractor Sedemac Kit - Rjil - Universal      | 4800  | 85030010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93244404 | Eicher Tractor Sedemac Kit - Rjil - Phpl           | 2850  | 85030010 | 18% |
| 93245007 | Eicher Tractor Engine Wiring Harness - 422Tci (Dew | 1164  | 85444220 | 18% |
| 93245019 | Eicher Tractor Control Panel Wiring Harness - 422T | 1094  | 85444220 | 18% |
| 93245020 | Eicher Tractor Engine Wiring Harness - 422Es (Dewa | 1098  | 85444220 | 18% |
| 93245032 | Eicher Tractor Control Panel Wiring Harness - 422E | 1036  | 85444220 | 18% |
| 93250015 | Eicher Tractor Special Banjo Bolt M8X1X28)         | 54    | 73181500 | 18% |
| 93250063 | Eicher Tractor Blower Pulley-422Tc                 | 595   | 84099941 | 28% |
| 93250088 | Eicher Tractor Alternator Mtg Bracket 422 Tc       | 1169  | 84099941 | 28% |
| 93250090 | Eicher Tractor Inspection Cover Rear (398Auto/Stn. | 588   | 84099941 | 28% |
| 93250106 | Eicher Tractor Dipstick Assy 422 Esg \$            | 59    | 84099941 | 28% |
| 93250118 | Eicher Tractor Control Hsg M/Cd -422Tc             | 2762  | 84099941 | 28% |
| 93250155 | Eicher Tractor Gasket For Control Hsg (422 Tc)     | 93    | 84099941 | 28% |
| 93250179 | Eicher Tractor Main Bearing Middle- Upper(Std)     | 171   | 84099941 | 28% |
| 93250180 | Eicher Tractor Main Bearing Middle- Lower (Std)(42 | 169   | 84099941 | 28% |
| 93250192 | Eicher Tractor Big End Bearing 422Es(T.C)          | 148   | 84099941 | 28% |
| 93250209 | Eicher Tractor Main Bearing Bush                   | 400   | 84833000 | 18% |
| 93250271 | Eicher Tractor Turbocharger Assy.(Tata Holset)     | 29960 | 84148030 | 18% |
| 93250301 | Eicher Tractor Blower Shaft Assly.- 422Tc          | 8682  | 84099941 | 28% |
| 93250349 | Eicher Tractor Alternator Assy 422Tc( Vent Type)(  | 7240  | 85115000 | 28% |
| 93250374 | Eicher Tractor Solenoid Assly                      | 3507  | 85365090 | 18% |
| 93250398 | Eicher Tractor Exhaust Valve Seat                  | 328   | 84099941 | 28% |
| 93250477 | Eicher Tractor Inlet Hose (A.C To Intakle Manifold | 472   | 40093100 | 18% |
| 93250593 | Eicher Tractor Cylinder Liner -422Tc               | 5545  | 84099941 | 28% |
| 93250600 | Eicher Tractor Crank Case                          | 47205 | 84099941 | 28% |
| 93250684 | Eicher Tractor Crank Pulley -422Esg (16")          | 2154  | 84835010 | 18% |
| 93250696 | Eicher Tractor Blower Pulley -422Esg               | 476   | 84099941 | 28% |
| 93250740 | Eicher Tractor Cyl. Head Gasket (T=0.55) White     | 75    | 74152900 | 18% |
| 93250751 | Eicher Tractor Cyl. Head Gasket (T=0.65) Black     | 102   | 74152900 | 18% |
| 93250763 | Eicher Tractor Cyl. Head Gasket (T=0.75) Red       | 126   | 74152900 | 18% |
| 93250775 | Eicher Tractor Cyl. Head Gasket (T=0.85) Green     | 105   | 74152900 | 18% |
| 93250787 | Eicher Tractor Inlet Valve 422Tc                   | 301   | 84099111 | 28% |
| 93250921 | Eicher Tractor Exhaust Manifold Assy. With Ceramic | 4917  | 84099941 | 28% |
| 93250957 | Eicher Tractor Electronic Temp Gauge               | 446   | 90268010 | 18% |
| 93250969 | Eicher Tractor Temperature Sensor(422Tc/Ago.)      | 182   | 90269000 | 18% |
| 93250970 | Eicher Tractor Temperature Switch (422Tc (Esg)     | 453   | 84099941 | 28% |
| 93251020 | Eicher Tractor Control Pannel (422Tc)              | 977   | 84099941 | 28% |
| 93251032 | Eicher Tractor Turbo Exhaust Extension422Tc        | 764   | 84099941 | 28% |
| 93251056 | Eicher Tractor Wiring Harness Assy-422Tc           | 760   | 85444220 | 18% |
| 93251068 | Eicher Tractor Hour Cum Rpm Meter -422Tc           | 2895  | 90292090 | 18% |
| 93251081 | Eicher Tractor Heat Shield                         | 275   | 84841090 | 18% |
| 93251172 | Eicher Tractor Inlet Valve Seat 422Tc              | 393   | 84099941 | 28% |
| 93251184 | Eicher Tractor Cyl. Head Sub Asly.422Tc(Agro /Esg) | 7027  | 76169990 | 18% |
| 93251226 | Eicher Tractor Egr Gasket                          | 40    | 73182200 | 18% |
| 93251366 | Eicher Tractor Bracket Cum Lifting Hook 322/323 Es | 1218  | 84099990 | 28% |
| 93251410 | Eicher Tractor Inlet Manifold 422 Tc Esg           | 1154  | 84099941 | 28% |
| 93251421 | Eicher Tractor Exhaust Manifold(422Tc Gen.)        | 3766  | 84099941 | 28% |
| 93251548 | Eicher Tractor Gasket For Inspection Cover Front-1 | 26    | 68129922 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93251640 | Eicher Tractor Crank Pulley 422Tc                  | 5847  | 84835010 | 18% |
| 93251688 | Eicher Tractor Inlet Manifold                      | 1349  | 84099941 | 28% |
| 93251690 | Eicher Tractor Exhaust Mainfold                    | 2412  | 84099941 | 28% |
| 93251809 | Eicher Tractor Egr Valve Gasket                    | 39    | 73182200 | 18% |
| 93251822 | Eicher Tractor Orifice Plate (Id 14Mm)             | 109   | 84099990 | 28% |
| 93251834 | Eicher Tractor Thermocouple Assy                   | 1632  | 85364900 | 18% |
| 93251846 | Eicher Tractor Wiring Harness For Egr Valve        | 664   | 85443000 | 18% |
| 93251858 | Eicher Tractor Controller                          | 1966  | 85364900 | 18% |
| 93252097 | Eicher Tractor Egr Clamp Mtg. Bkt                  | 283   | 84099990 | 28% |
| 93252115 | Eicher Tractor Boost Pipe                          | 444   | 84099941 | 28% |
| 93252127 | Eicher Tractor Egr Pipe (Dia 20.4)                 | 2631  | 84099941 | 28% |
| 93252255 | Eicher Tractor Piston – 422Tc                      | 2270  | 84099912 | 28% |
| 93252280 | Eicher Tractor Piston Ring Set                     | 491   | 84099913 | 28% |
| 93252292 | Eicher Tractor Piston Pin                          | 262   | 84099941 | 28% |
| 93252360 | Eicher Tractor Adjusting Latch                     | 158   | 84099941 | 28% |
| 93252371 | Eicher Tractor T Oil Drain Pipe Assy. 422Tc        | 554   | 84099941 | 28% |
| 93252383 | Eicher Tractor Tc Oil Inlet Pipe Assy              | 746   | 40092200 | 18% |
| 93252396 | Eicher Tractor Hose (Turbo & Boost Pipe)           | 256   | 40093100 | 18% |
| 93252449 | Eicher Tractor Cyl. Head Gasket (T=0.95) Blue      | 159   | 74091100 | 18% |
| 93252450 | Eicher Tractor Cyl. Head Gasket (T=1.05) Brown     | 203   | 74091100 | 18% |
| 93252462 | Eicher Tractor Cyl. Head Gasket (T=1.15) Violet    | 235   | 74091100 | 18% |
| 93252528 | Eicher Tractor Control Hsg M/Cd                    | 3484  | 84099941 | 28% |
| 93252565 | Eicher Tractor Fuel Injection Pump -398E49 (001)   | 33887 | 84133010 | 28% |
| 93252747 | Eicher Tractor Bracket Cum Lifting Hook            | 851   | 84099990 | 28% |
| 93252760 | Eicher Tractor Exhaust Manifold(313E-49)(S.G.Iron) | 2982  | 84099941 | 28% |
| 93252851 | Eicher Tractor Turbocharger Tel 3. 12              | 22911 | 84148030 | 18% |
| 93252863 | Eicher Tractor Controller For 422Tc                | 2161  | 85364900 | 18% |
| 93252899 | Eicher Tractor Heat Shield - 422Es                 | 1906  | 84099941 | 28% |
| 93252905 | Eicher Tractor Heat Shield - 422Tc                 | 1995  | 84099941 | 28% |
| 93252991 | Eicher Tractor Orifice Plate (12 Mm)               | 119   | 84099990 | 28% |
| 93253004 | Eicher Tractor A/C Rubber Hose-422Tc               | 134   | 40093100 | 18% |
| 93253016 | Eicher Tractor Alternator Assly (7060)-422Esg      | 6822  | 85115000 | 28% |
| 93253041 | Eicher Tractor Support For Boost Pipe(422Tc)       | 193   | 84099941 | 28% |
| 93253090 | Eicher Tractor Intercooler - 422Tci                | 8055  | 84099941 | 28% |
| 93253119 | Eicher Tractor Fly Wheel Housing                   | 8019  | 84099941 | 28% |
| 93253120 | Eicher Tractor Blower Shaft - 422Tci               | 2162  | 84091000 | 28% |
| 93253132 | Eicher Tractor Blower Shaft Sub Assly. -422Tci     | 8399  | 84099941 | 28% |
| 93253170 | Eicher Tractor Blower Support Rear-422Tci          | 641   | 84099941 | 28% |
| 93253181 | Eicher Tractor Bottom Support- Ic                  | 85    | 84099941 | 28% |
| 93253200 | Eicher Tractor Bracket - Air Cleaner-422Tci        | 701   | 84099990 | 28% |
| 93253211 | Eicher Tractor Lifting Hook Assembly - 422Tci      | 474   | 84099941 | 28% |
| 93253247 | Eicher Tractor Heat Shield - 422Tci                | 2123  | 84841090 | 18% |
| 93253259 | Eicher Tractor Support - Egr Pipe-422Tci           | 48    | 84099941 | 28% |
| 93253260 | Eicher Tractor Impeller Housing Assy-422Tci        | 1571  | 84099990 | 28% |
| 93253272 | Eicher Tractor Boost Pipe- 422Tci                  | 877   | 84099941 | 28% |
| 93253296 | Eicher Tractor Impeller Assy 10 Blade-422Tci       | 634   | 84099941 | 28% |
| 93253314 | Eicher Tractor Holding Cap - Boost Pipe-422Tci     | 41    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93253326 | Eicher Tractor Hose Tc Outlet-422Tci               | 781   | 40093100 | 18% |
| 93253338 | Eicher Tractor Hose Ic Inlet-422Tci                | 518   | 40093100 | 18% |
| 93253340 | Eicher Tractor Hose - Ic Outlet-422Tci             | 1652  | 40093100 | 18% |
| 93253351 | Eicher Tractor Fuel Inj Pump - 422Tci-F03          | 30182 | 84099941 | 28% |
| 93253387 | Eicher Tractor Turbocharger - 3.12 - 422Tci        | 22569 | 84148030 | 18% |
| 93253405 | Eicher Tractor Crank Pulley 13"                    | 6119  | 84099941 | 28% |
| 93253442 | Eicher Tractor Top Support - Ic-422Tci             | 109   | 84099941 | 28% |
| 93253478 | Eicher Tractor Dipstick Assy 422 Esg               | 57    | 84099941 | 28% |
| 93253480 | Eicher Tractor Inspection Cover Rear (398Auto/Stn. | 698   | 84099941 | 28% |
| 93253545 | Eicher Tractor Exhaust Manifold-422Tci             | 3163  | 84099941 | 28% |
| 93253569 | Eicher Tractor Pipe Assy - Tc Oil Inlet-422Tci     | 1019  | 84099941 | 28% |
| 93253570 | Eicher Tractor Pipe Assy - Tc Oil Drain-422Tci     | 698   | 84099941 | 28% |
| 93253582 | Eicher Tractor Egr Pipe - 422Tci                   | 3106  | 84099941 | 28% |
| 93253594 | Eicher Tractor Crank Shaft-Fillet Haredning-422Tci | 29440 | 84831092 | 18% |
| 93253600 | Eicher Tractor Support- Boost Pipe-422Tci          | 129   | 84099941 | 28% |
| 93253661 | Eicher Tractor Air Cleaner Assy- 422Tci            | 2830  | 84213920 | 18% |
| 93253909 | Eicher Tractor Orifice Plate                       | 278   | 84099990 | 28% |
| 93254069 | Eicher Tractor Piston - Ring Carrier - 422Tci      | 3054  | 84099912 | 28% |
| 93254148 | Eicher Tractor Oil Pump Assy                       | 2440  | 84099941 | 28% |
| 93254173 | Eicher Tractor Circlip A16X1-422Tci                | 3     | 73182910 | 18% |
| 93254185 | Eicher Tractor Oil Feed Pipe Assy- 422Tci          | 1858  | 40094200 | 18% |
| 93254264 | Eicher Tractor Crank Pulley - 422Tci               | 5571  | 84099941 | 28% |
| 93254276 | Eicher Tractor Piston Ring Set-422Tci              | 887   | 84099913 | 28% |
| 93254288 | Eicher Tractor Controller 422Tci                   | 2176  | 85364900 | 18% |
| 93254318 | Eicher Tractor Steel Tube - 422Tci                 | 339   | 84099941 | 28% |
| 93254434 | Eicher Tractor Egr Gasket                          | 51    | 84841090 | 18% |
| 93254719 | Eicher Tractor Instruction Plate 422Tc (250 Hrs )  | 36    | 84099941 | 28% |
| 93254835 | Eicher Tractor Temperature Sensor 19.7 Mm          | 153   | 84099941 | 28% |
| 93255311 | Eicher Tractor Starter Motor Assy                  | 17305 | 85114000 | 28% |
| 93255335 | Eicher Tractor Crank Case 421,422&422Esg(New Cr Ca | 47909 | 84099941 | 28% |
| 93255347 | Eicher Tractor Crank Housing 422Tc / Tci           | 68263 | 84099941 | 28% |
| 93255484 | Eicher Tractor Turbocharger Tr50-1236-7.12(Bil)    | 22368 | 84148030 | 18% |
| 93255694 | Eicher Tractor Inlet Manifold For Cold Start       | 1188  | 84099941 | 28% |
| 93255955 | Eicher Tractor Egr Controller Inbuilt Egr Relay 42 | 2220  | 85364900 | 18% |
| 93255979 | Eicher Tractor Egr Controller With Inbuilt Egr 422 | 2220  | 87089900 | 18% |
| 93256194 | Eicher Tractor Tc Oil Inlet Pipe Assy              | 837   | 40092200 | 18% |
| 93256388 | Eicher Tractor Turbo Exhaust Extension             | 1191  | 84099941 | 28% |
| 93256480 | Eicher Tractor Industrial Control Panel Ff Engine  | 28514 | 85371000 | 18% |
| 93256509 | Eicher Tractor Control Panel Stand - Industrial    | 3060  | 84099941 | 28% |
| 93256583 | Eicher Tractor Rear - Pedestal                     | 5241  | 84099941 | 28% |
| 93260033 | Eicher Tractor Hose Clamp(Sltb - 44)\$             | 154   | 73269099 | 18% |
| 93260057 | Eicher Tractor Hose Dat To Air Vent Union \$       | 127   | 40093100 | 18% |
| 93260082 | Eicher Tractor Ric Assy Support Middle             | 276   | 84099941 | 28% |
| 93260100 | Eicher Tractor Injector Washer (2.5 Mm) \$         | 19    | 74091100 | 18% |
| 93260148 | Eicher Tractor A/C Holding Clamp \$                | 635   | 84099941 | 28% |
| 93260150 | Eicher Tractor Water Level Switch                  | 1673  | 84099941 | 28% |
| 93260161 | Eicher Tractor Hwt Switch For 881Es (30Kv/45Kv/62. | 531   | 90269000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93260203 | Eicher Tractor Timing Mark Bkt.                    | 49    | 84099941 | 28% |
| 93260215 | Eicher Tractor Cogged V-Belt-Av13X 1335 \$         | 509   | 40101290 | 18% |
| 93260227 | Eicher Tractor Piston With Ring Carrier \$         | 3657  | 84099912 | 28% |
| 93260239 | Eicher Tractor Piston Pin \$                       | 549   | 84099941 | 28% |
| 93260240 | Eicher Tractor Piston Ring(Top) \$                 | 625   | 84099913 | 28% |
| 93260252 | Eicher Tractor Piston Ring(Middle) \$              | 122   | 84099913 | 28% |
| 93260264 | Eicher Tractor Piston Ring(Oil) \$                 | 269   | 84099913 | 28% |
| 93260276 | Eicher Tractor Water Pump Assy.                    | 5129  | 84133020 | 28% |
| 93260288 | Eicher Tractor Al.Radiator Support                 | 609   | 84099941 | 28% |
| 93260290 | Eicher Tractor Hose Clamp(Sltb-52) \$              | 143   | 73269099 | 18% |
| 93260331 | Eicher Tractor Punched Washer For Lifting Eye      | 9     | 73182100 | 18% |
| 93260379 | Eicher Tractor Turbo Charger Unit (62.5Kva)        | 26273 | 84148030 | 18% |
| 93260768 | Eicher Tractor Calmp Assly                         | 46    | 84099941 | 28% |
| 93260823 | Eicher Tractor Engine Cum Radiaot Mounting Pedesta | 6990  | 85030090 | 18% |
| 93260847 | Eicher Tractor Water Temp. Gauge                   | 387   | 90268010 | 18% |
| 93260884 | Eicher Tractor Gasket Oil Cooler                   | 190   | 84099941 | 28% |
| 93260902 | Eicher Tractor Piston Ring Set                     | 1019  | 84099913 | 28% |
| 93260951 | Eicher Tractor V. Belt Guard Assy (461Es/621Es)    | 774   | 40101290 | 18% |
| 93261011 | Eicher Tractor Engine Cum Radiator Mtg Pedestal(L. | 6990  | 85030090 | 18% |
| 93261025 | Eicher Tractor Egr Pipe With Egr Clamp 422Es       | 2029  | 84099941 | 28% |
| 93261049 | Eicher Tractor Electrical Egr Valve,18Mm Dia       | 5913  | 84099941 | 28% |
| 93261086 | Eicher Tractor Reserve Tank Assly                  | 16532 | 84099941 | 28% |
| 93261098 | Eicher Tractor Intercooler                         | 22322 | 84099941 | 28% |
| 93261104 | Eicher Tractor Vent Pipe                           | 252   | 40169990 | 18% |
| 93261128 | Eicher Tractor Rad Assy                            | 20838 | 87089100 | 18% |
| 93261130 | Eicher Tractor Orifice Plate 10.5                  | 109   | 84099990 | 28% |
| 93261189 | Eicher Tractor Accelerator Lever Bracket           | 428   | 84099990 | 28% |
| 93261190 | Eicher Tractor Turbocharger - 3.12                 | 22911 | 84148030 | 18% |
| 93261207 | Eicher Tractor Pipe Egr Coolant Outlet             | 616   | 40093100 | 18% |
| 93261232 | Eicher Tractor Plate For Cylinder Head 881Es       | 212   | 84099941 | 28% |
| 93261256 | Eicher Tractor Pipe Egr Coolant Inlet              | 606   | 84099941 | 28% |
| 93261268 | Eicher Tractor Egr Pipe Outlet                     | 2130  | 84099941 | 28% |
| 93261270 | Eicher Tractor Egr Pipe Inlet                      | 1940  | 84099941 | 28% |
| 93261281 | Eicher Tractor Boost Pipe (Ic Outlet To Intake Man | 1354  | 84099941 | 28% |
| 93261323 | Eicher Tractor Radiator Mtg Strip Lh               | 156   | 84099941 | 28% |
| 93261335 | Eicher Tractor Radiator Mtg Strip R.H              | 156   | 84099941 | 28% |
| 93261359 | Eicher Tractor Breather Pipe 881Es                 | 977   | 40092200 | 18% |
| 93261384 | Eicher Tractor Solenoid Bracket                    | 272   | 84099941 | 28% |
| 93261396 | Eicher Tractor Retro Fitment Kit -Solenoid Bracket | 752   | 84099941 | 28% |
| 93261414 | Eicher Tractor Radiator Assy                       | 37249 | 84099941 | 28% |
| 93261463 | Eicher Tractor Air Cleaner Fixing Support Assy     | 158   | 84099941 | 28% |
| 93261505 | Eicher Tractor Fan Guard                           | 1684  | 85030090 | 18% |
| 93261530 | Eicher Tractor Air Inlet Hose (Air Cleaner To Turb | 356   | 40093100 | 18% |
| 93261852 | Eicher Tractor Egr Controller                      | 2161  | 85364900 | 18% |
| 93261864 | Eicher Tractor Boost Pipe (Tc To Ic Inlet)         | 489   | 84099941 | 28% |
| 93261876 | Eicher Tractor Radiator Outlet Water Pipe          | 552   | 84099941 | 28% |
| 93261888 | Eicher Tractor Radiator Inlet Water Hose           | 913   | 40093100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93261890 | Eicher Tractor Boost Pipe (Ic Outlet To Intake Man | 611   | 84099941 | 28% |
| 93261906 | Eicher Tractor Radiator Outlet Water Hose 1        | 532   | 40093100 | 18% |
| 93261918 | Eicher Tractor Radiator Outlet Water Hose 2        | 243   | 40093100 | 18% |
| 93261920 | Eicher Tractor Rubber Hose (Nylone) (Tc To Ic Pipe | 633   | 40093100 | 18% |
| 93261931 | Eicher Tractor Slit Hose                           | 41    | 40093100 | 18% |
| 93261943 | Eicher Tractor Mtg Frame (R.H)                     | 855   | 84099941 | 28% |
| 93261955 | Eicher Tractor Mtg Frame (L.H)                     | 797   | 84099941 | 28% |
| 93261967 | Eicher Tractor Controller - 621Es                  | 2161  | 85364900 | 18% |
| 93261979 | Eicher Tractor Heat Shield                         | 2074  | 84099941 | 28% |
| 93261980 | Eicher Tractor Radiator & Intercooler Assy         | 47074 | 84099199 | 28% |
| 93261992 | Eicher Tractor Radiator Outlet Pipe Bracket        | 39    | 84099941 | 28% |
| 93262005 | Eicher Tractor Boost Pipe Support Bkt. ( Tc To Ic  | 308   | 84099941 | 28% |
| 93262029 | Eicher Tractor Boost Pipe Support Assy. ( Tc To Ic | 306   | 84099941 | 28% |
| 93262042 | Eicher Tractor Radiator Holding Bracket            | 120   | 84099941 | 28% |
| 93262054 | Eicher Tractor Engine Pedestal Front Rh            | 1294  | 84099941 | 28% |
| 93262066 | Eicher Tractor Engine Pedestal Front Lh            | 1152  | 84099941 | 28% |
| 93262078 | Eicher Tractor Intermediate Pedestal Support       | 787   | 84099941 | 28% |
| 93262080 | Eicher Tractor Plate For Cylinder Head 621Es       | 247   | 84099941 | 28% |
| 93262110 | Eicher Tractor Reserve Tank                        | 4950  | 84099941 | 28% |
| 93262186 | Eicher Tractor Rubber Pad                          | 98    | 40169390 | 18% |
| 93262200 | Eicher Tractor Rubber Sleeve For Egr Cooler        | 68    | 40093100 | 18% |
| 93262212 | Eicher Tractor Bracket For Egr Cooler Lower        | 72    | 84099941 | 28% |
| 93262224 | Eicher Tractor Bracket For Egr Cooler Upper        | 68    | 84099941 | 28% |
| 93262273 | Eicher Tractor Relay, Egr                          | 358   | 85364900 | 18% |
| 93262339 | Eicher Tractor Radiator Pressure Cap – Tata Toyo   | 354   | 87081010 | 18% |
| 93262431 | Eicher Tractor Egr Coller Without Welded Bkt Count | 8447  | 84099941 | 28% |
| 93262560 | Eicher Tractor Heat Shield For Exhaust Extension   | 1180  | 84841090 | 18% |
| 93262698 | Eicher Tractor Pressure Cap                        | 176   | 84099941 | 28% |
| 93262741 | Eicher Tractor Oil Seal Rear                       | 1813  | 40169990 | 18% |
| 93262972 | Eicher Tractor Egr Controller Inbuilt Egr Relay 88 | 2220  | 87089900 | 18% |
| 93262984 | Eicher Tractor Egr Controller Inbuilt Egr Relay 62 | 2228  | 85364900 | 18% |
| 93270063 | Eicher Tractor Cylinder Liner M/C-125 Kva          | 3727  | 84099941 | 28% |
| 93270075 | Eicher Tractor Crank Shaft Machined-125 Kva        | 56467 | 84831092 | 18% |
| 93270087 | Eicher Tractor Con Rod Assly-125 Kva               | 4018  | 84099990 | 28% |
| 93270117 | Eicher Tractor Bush Con Rod Small End-125 Kva      | 232   | 84099941 | 28% |
| 93270129 | Eicher Tractor Connecting Rod Screw                | 61    | 73181500 | 18% |
| 93270142 | Eicher Tractor Piston Pin-125Kva                   | 718   | 84099941 | 28% |
| 93270166 | Eicher Tractor Piston Ring Oil Control Ring- 125 K | 673   | 84099913 | 28% |
| 93270178 | Eicher Tractor Piston Ring Top-125 Kva             | 1182  | 84099913 | 28% |
| 93270210 | Eicher Tractor Valve Seat-Intake-125 Kva           | 555   | 84099941 | 28% |
| 93270221 | Eicher Tractor Valve Seat-Exhaust-125 Kva          | 405   | 84099941 | 28% |
| 93270233 | Eicher Tractor Valve Guide-125Kva                  | 71    | 84099111 | 28% |
| 93270245 | Eicher Tractor Valve-Inlet                         | 258   | 40169330 | 18% |
| 93270257 | Eicher Tractor Valve-Exhaust                       | 333   | 40169330 | 18% |
| 93270269 | Eicher Tractor Gasket- Cylinder Head               | 1072  | 84841090 | 18% |
| 93270294 | Eicher Tractor Camshaft-Machined-125 Kva           | 6939  | 84831099 | 18% |
| 93270300 | Eicher Tractor Water Pump Assly-125Kva             | 17229 | 84133030 | 28% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93270361 | Eicher Tractor Gasket- Cover Thermostat            | 29     | 48239030 | 18% |
| 93270439 | Eicher Tractor Intake Manifold Machined-125Kva     | 6333   | 84099941 | 28% |
| 93270440 | Eicher Tractor Radiator & Intercooler Assy-125 Kva | 112753 | 84099199 | 28% |
| 93270452 | Eicher Tractor Exhaust Manifold Machined           | 5879   | 84099941 | 28% |
| 93270464 | Eicher Tractor Turbocharger Assembly (5.12)        | 29442  | 84148030 | 18% |
| 93270476 | Eicher Tractor Gasket Exhaust Manifold-125Kva      | 46     | 84841090 | 18% |
| 93270488 | Eicher Tractor Water Rail-125 Kva                  | 8129   | 84099941 | 28% |
| 93270490 | Eicher Tractor Egr Cooler Assembly-125 Kva         | 37072  | 87089900 | 18% |
| 93270506 | Eicher Tractor Fuel Injector-125Kva                | 25587  | 84139190 | 28% |
| 93270531 | Eicher Tractor Fuel Injection Pump-125 Kva         | 77581  | 84133010 | 28% |
| 93270543 | Eicher Tractor High Pressure Pipe Cr To Cyl1 - Ass | 1289   | 84099941 | 28% |
| 93270555 | Eicher Tractor High Pressure Pipe Cr To Cyl 2 - As | 1368   | 84099941 | 28% |
| 93270567 | Eicher Tractor High Pressure Pipe Cr To Cyl 3 - As | 1368   | 84099941 | 28% |
| 93270579 | Eicher Tractor High Pressure Pipe Cr To Cyl 4 - As | 1328   | 84099941 | 28% |
| 93270580 | Eicher Tractor High Pressure Pipe 1 - Fip To Cr -  | 1197   | 84099941 | 28% |
| 93270592 | Eicher Tractor High Pressure Pipe 2 - Fip To Cr -  | 1518   | 84099941 | 28% |
| 93270609 | Eicher Tractor Oil Pump Assembly-125 Kva           | 10227  | 84133020 | 28% |
| 93270762 | Eicher Tractor Rear Pedestal                       | 367    | 84099941 | 28% |
| 93270774 | Eicher Tractor Oil Delivery Pipe Assembly          | 1026   | 84099941 | 28% |
| 93270816 | Eicher Tractor Bolt M16 - Main Bearing Cap Mountin | 138    | 73181500 | 18% |
| 93270828 | Eicher Tractor Bearing- Main (Upper)-125Kva        | 261    | 84822011 | 18% |
| 93270830 | Eicher Tractor Bearing- Main (Lower)-125Kva        | 258    | 84822011 | 18% |
| 93270841 | Eicher Tractor Gear-Crank Shaft-125Kva             | 2354   | 84834000 | 18% |
| 93270865 | Eicher Tractor Flywheel Machined- 125 Kva          | 17456  | 84099941 | 28% |
| 93270907 | Eicher Tractor Connector-Blowby Oil Return         | 94     | 84099941 | 28% |
| 93270919 | Eicher Tractor Collet Assy- Valve-125 Kva          | 10     | 84099941 | 28% |
| 93270920 | Eicher Tractor Spring Retainer-Top-125Kva          | 66     | 73202000 | 18% |
| 93270968 | Eicher Tractor Valve Stem Oil Seal-125Kva          | 65     | 40169990 | 18% |
| 93270970 | Eicher Tractor Cylinder Head Bolt M12X1.5X174      | 125    | 73182990 | 18% |
| 93271043 | Eicher Tractor Cap-Cam Bore Shaft-125Kva           | 24     | 84099941 | 28% |
| 93271055 | Eicher Tractor Pushrod-125 Kva                     | 149    | 84099990 | 28% |
| 93271067 | Eicher Tractor Bearing-Cam Shaft-125Kva            | 194    | 84825011 | 18% |
| 93271080 | Eicher Tractor Valve Bridge-125 Kva                | 222    | 84099941 | 28% |
| 93271092 | Eicher Tractor Pesestal-Main-125 Kva               | 874    | 84099941 | 28% |
| 93271109 | Eicher Tractor Pedestal-Centre-125 Kva             | 983    | 84099941 | 28% |
| 93271122 | Eicher Tractor Pedestal-Side-125 Kva               | 834    | 84099941 | 28% |
| 93271146 | Eicher Tractor Spacer-Rocker Arm                   | 25     | 73182100 | 18% |
| 93271160 | Eicher Tractor Gear - Fuel Pump-125Kva             | 1603   | 84099941 | 28% |
| 93271201 | Eicher Tractor Gasket - Housing Thermostat         | 40     | 48239030 | 18% |
| 93271213 | Eicher Tractor Dogbone-Water Pump To Oil Cooler    | 467    | 84099941 | 28% |
| 93271225 | Eicher Tractor Gasket-Intake Manifold-125Kva       | 264    | 48239030 | 18% |
| 93271237 | Eicher Tractor Gasket-Grid Heater-125 Kva          | 27     | 84099941 | 28% |
| 93271249 | Eicher Tractor Pipe - Air Intake 125 Kva           | 1419   | 84219900 | 18% |
| 93271304 | Eicher Tractor Alternator With Vaccum Pump         | 11885  | 85118000 | 28% |
| 93271316 | Eicher Tractor Poly V Belt-125 Kva                 | 1122   | 40101290 | 18% |
| 93271377 | Eicher Tractor Tc Oil Drain Assembly-125Kva        | 694    | 40092200 | 18% |
| 93271432 | Eicher Tractor Fuel Pre Filter-125Kva              | 9607   | 84219900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93271456 | Eicher Tractor Injector Holding Clamp              | 1255  | 84099941 | 28% |
| 93271468 | Eicher Tractor Common Rail-125 Kva                 | 30581 | 84099990 | 28% |
| 93271470 | Eicher Tractor Main Fuel Filter-125Kva             | 6783  | 84219900 | 18% |
| 93271481 | Eicher Tractor Fuel Uniter Machined-125 Kva        | 715   | 84099941 | 28% |
| 93271500 | Eicher Tractor Pipe - Common Rail Overflow-125Kva  | 263   | 84099941 | 28% |
| 93271511 | Eicher Tractor Pipe - Main Filter To Pump - Assemb | 720   | 84219900 | 18% |
| 93271523 | Eicher Tractor Pipe - Prefilter To Pump - Assembly | 964   | 84219900 | 18% |
| 93271535 | Eicher Tractor Pipe - Pump Outlet To Uniter - Asse | 204   | 84099941 | 28% |
| 93271559 | Eicher Tractor Injector Overflow Pipe-125Kva       | 980   | 84099941 | 28% |
| 93271560 | Eicher Tractor Piston Cooling Jet Assembly-125Kva  | 273   | 84099941 | 28% |
| 93271584 | Eicher Tractor Dogbone - Oil Pump To Cooler        | 153   | 84099941 | 28% |
| 93271602 | Eicher Tractor Gasket - Oil Filter-125Kva          | 105   | 84219900 | 18% |
| 93271614 | Eicher Tractor Fip Lubrication Pipe Assembly-125Kv | 180   | 84099941 | 28% |
| 93271640 | Eicher Tractor Gasket-Oil Pan                      | 644   | 68129090 | 18% |
| 93271651 | Eicher Tractor Dipstick Tube Assembly-125Kva       | 408   | 84099941 | 28% |
| 93271663 | Eicher Tractor Injector Clamp Washer               | 10    | 84099941 | 28% |
| 93271687 | Eicher Tractor Hexagon Flange Bolt Iso 4162-M12X90 | 60    | 73181500 | 18% |
| 93271699 | Eicher Tractor Nipple-Alternator Oil-Drain-125Kva  | 44    | 84099941 | 28% |
| 93271705 | Eicher Tractor Fuel Connector M18X1.5 (Pre Fi      | 78    | 84099941 | 28% |
| 93271717 | Eicher Tractor Oil Pressure Sensor-125 Kva         | 5799  | 90328990 | 18% |
| 93271729 | Eicher Tractor Bearing Upper - Con Rod Big End     | 180   | 84825011 | 18% |
| 93271730 | Eicher Tractor Bearing Lower - Con Rod Big End-125 | 170   | 84822011 | 18% |
| 93271742 | Eicher Tractor Flywheel Bolt - M12X35-Din En 1665- | 54    | 73181500 | 18% |
| 93271791 | Eicher Tractor Injector Sleeve-125 Kva             | 521   | 84099941 | 28% |
| 93271821 | Eicher Tractor Screw - Adjusting-125 Kva           | 111   | 73181500 | 18% |
| 93271882 | Eicher Tractor Gear-Cam Shaft-125 Kva              | 1642  | 84834000 | 18% |
| 93271961 | Eicher Tractor Bracket- Alternator Mounting-125 Kv | 464   | 84099941 | 28% |
| 93271973 | Eicher Tractor Adjusting Latch - Alternator-125 Kv | 440   | 84099941 | 28% |
| 93272000 | Eicher Tractor Crank Pulley-125 Kva                | 2886  | 84835010 | 18% |
| 93272035 | Eicher Tractor Gasket-Egr Pipe-125Kva              | 32    | 84841090 | 18% |
| 93272047 | Eicher Tractor Boost Pressure Sensor-125 Kva       | 3621  | 90328990 | 18% |
| 93272072 | Eicher Tractor Washer – Crank Pulley-125Kva        | 179   | 73182100 | 18% |
| 93272084 | Eicher Tractor Flang Bolt M10 X 1.5 X 48- 125 Kva  | 24    | 73181500 | 18% |
| 93272102 | Eicher Tractor Spacer (Fuel Uniter)-125Kva         | 33    | 73182100 | 18% |
| 93272114 | Eicher Tractor Union-Fuel Uniter-125Kva            | 86    | 84099941 | 28% |
| 93272126 | Eicher Tractor Spacer - Fuel Pre Filter Mounting   | 31    | 84219900 | 18% |
| 93272229 | Eicher Tractor Bracket-Auto Tensioner Mtg-125 Kva  | 868   | 84099941 | 28% |
| 93272278 | Eicher Tractor Spring Retainer-Bottom-125 Kva      | 8     | 73202000 | 18% |
| 93272308 | Eicher Tractor Elephant Foot Assembly              | 651   | 84099941 | 28% |
| 93272345 | Eicher Tractor O-Ring For Sleeve-23.5 X 2.4- 125 K | 24    | 40169320 | 18% |
| 93272357 | Eicher Tractor Lifting Eye-125 Kva                 | 94    | 84099941 | 28% |
| 93272370 | Eicher Tractor Crankshaft Speed Sensor-125 Kva     | 3597  | 90328990 | 18% |
| 93272382 | Eicher Tractor Camshaft Speed Sensor-125 Kva       | 3276  | 90328990 | 18% |
| 93272424 | Eicher Tractor Alternator-Oil Inlet Pipe-125Kva    | 216   | 84099941 | 28% |
| 93272436 | Eicher Tractor Alternator Oil Drain Hose-125Kva    | 207   | 40093100 | 18% |
| 93272448 | Eicher Tractor Gear Housing-125 Kva                | 6675  | 84834000 | 18% |
| 93272461 | Eicher Tractor Sleeve – Exhaust Manifold-125Kva    | 39    | 84099941 | 28% |





|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93272473 | Eicher Tractor Gasket-Turbocharger-125Kva           | 37    | 84841090 | 18% |
| 93272540 | Eicher Tractor Gasket- Adaptor And Egr Valve-125Kv  | 34    | 84841090 | 18% |
| 93272552 | Eicher Tractor Egr Valve-125Kva                     | 6407  | 84099941 | 28% |
| 93272564 | Eicher Tractor Egr Pipe Assy. -125Kva               | 2630  | 84099941 | 28% |
| 93272576 | Eicher Tractor Bracket For Vacuum Modulator-125 Kv  | 36    | 84099941 | 28% |
| 93272588 | Eicher Tractor Vacuum Modulator                     | 2424  | 84099941 | 28% |
| 93272590 | Eicher Tractor Hose- Vaccum Modulator To Alternato  | 144   | 40093100 | 18% |
| 93272606 | Eicher Tractor Hose- Vaccum Modulator To Egr Valve  | 82    | 40093100 | 18% |
| 93272618 | Eicher Tractor Hose -Vaccum Modulator To Aircleaner | 246   | 40093100 | 18% |
| 93272620 | Eicher Tractor Gasket-Egr Cooler And Adaptor-125Kv  | 36    | 84841090 | 18% |
| 93272667 | Eicher Tractor Piston (Veriant 3) 82.5 Kva          | 11320 | 84099941 | 28% |
| 93272679 | Eicher Tractor Piston-125 Kva                       | 7722  | 84099941 | 28% |
| 93272850 | Eicher Tractor Circlip Piston Pin                   | 30    | 73182910 | 18% |
| 93272862 | Eicher Tractor Key-Crankshaft-125 Kva               | 24    | 73182990 | 18% |
| 93272874 | Eicher Tractor Gasket Main- Water Rail-125 Kva      | 75    | 84841090 | 18% |
| 93272886 | Eicher Tractor Gasket Side- Water Rail-125 Kva      | 47    | 84841090 | 18% |
| 93272898 | Eicher Tractor Hose For Water Rail-125Kva           | 132   | 40093100 | 18% |
| 93272904 | Eicher Tractor Connector-Water Rail-125Kva          | 100   | 84099941 | 28% |
| 93272990 | Eicher Tractor Cover-Oil Cooler                     | 3939  | 84099941 | 28% |
| 93273052 | Eicher Tractor Cover -Thermostat-125 Kva            | 720   | 84099941 | 28% |
| 93273064 | Eicher Tractor Housing - Thermostat-125 Kva         | 1920  | 84099941 | 28% |
| 93273076 | Eicher Tractor Dogbone-Water Rail-125Kva            | 350   | 84099941 | 28% |
| 93273118 | Eicher Tractor Core Plug Dia 12 With Hole           | 5     | 84099941 | 28% |
| 93273120 | Eicher Tractor Core Plug Dia 25-125 Kva             | 11    | 84099941 | 28% |
| 93273143 | Eicher Tractor Flange Grid Heater-125 Kva           | 373   | 84099941 | 28% |
| 93273155 | Eicher Tractor Spacer-Water Pump                    | 639   | 73182100 | 18% |
| 93273167 | Eicher Tractor Air Cleaner Assembly-125 Kva         | 7366  | 84213920 | 18% |
| 93273179 | Eicher Tractor Coolant Temp Sensor-125 Kva          | 2514  | 90328990 | 18% |
| 93273192 | Eicher Tractor Ecu(Edc 167 Cv54)                    | 30371 | 84099941 | 28% |
| 93273283 | Eicher Tractor Sealing-Oil Cooler-125 Kva           | 206   | 73182990 | 18% |
| 93273325 | Eicher Tractor Gasket-Oil Pump Delivery-125Kva      | 11    | 48239030 | 18% |
| 93273337 | Eicher Tractor O-Ring 31.5X3-125Kva                 | 65    | 40169320 | 18% |
| 93273349 | Eicher Tractor Cover Rear- 125 Kva                  | 488   | 84099941 | 28% |
| 93273362 | Eicher Tractor O-Ring 23.5X2.62-125Kva              | 56    | 40169320 | 18% |
| 93273386 | Eicher Tractor Gasket-Gear Housing-125 Kva          | 106   | 48239030 | 18% |
| 93273398 | Eicher Tractor Core Plug Dia 20-125Kva              | 9     | 84099941 | 28% |
| 93273404 | Eicher Tractor Core Plug Dia 12-125Kva              | 5     | 84099941 | 28% |
| 93273416 | Eicher Tractor Core Plug D28-125 Kva                | 13    | 84099941 | 28% |
| 93273428 | Eicher Tractor Core Plug Dia 21-125 Kva             | 10    | 84099941 | 28% |
| 93273430 | Eicher Tractor O-Ring 11.5X1.5- 125 Kva             | 19    | 40169320 | 18% |
| 93273441 | Eicher Tractor Auto Belt Tensioner                  | 4298  | 40103590 | 18% |
| 93273453 | Eicher Tractor O-Ring 40X3.53-125Kva                | 32    | 40169320 | 18% |
| 93273465 | Eicher Tractor O-Ring 53X3.53-125Kva                | 54    | 40169320 | 18% |
| 93273477 | Eicher Tractor Hose-Ric To Thermo Cover-125 Kva     | 1088  | 40093100 | 18% |
| 93273489 | Eicher Tractor Hose-Water Pump To Egr Cooler-125 K  | 290   | 40093100 | 18% |
| 93273490 | Eicher Tractor O-Ring 23X3-125Kva                   | 30    | 40169320 | 18% |
| 93273507 | Eicher Tractor Oil Suction Pipe Assembly            | 802   | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93273519 | Eicher Tractor Oil Cooler Assembly-125Kva          | 23219 | 84099941 | 28% |
| 93273520 | Eicher Tractor Cylinder Block With Core Plugs Assy | 54181 | 84099941 | 28% |
| 93273570 | Eicher Tractor Rocker Cover                        | 2908  | 84099941 | 28% |
| 93273600 | Eicher Tractor Hose -Dat To Water Pump Inlet Hose  | 530   | 40093100 | 18% |
| 93273611 | Eicher Tractor Hose Air Cleaner                    | 1855  | 40093100 | 18% |
| 93273659 | Eicher Tractor Rocker Shaft M/C Sub Assembly-125 K | 1340  | 84099941 | 28% |
| 93273684 | Eicher Tractor Connector For Turbocharger-125Kva   | 444   | 84099941 | 28% |
| 93273702 | Eicher Tractor Boost Pipe-Turbo To Ric             | 1057  | 84099941 | 28% |
| 93273714 | Eicher Tractor Ic Intake Hose-125Kva               | 902   | 40093100 | 18% |
| 93273726 | Eicher Tractor Ic Outlet Hose-125Kva               | 414   | 40093100 | 18% |
| 93273738 | Eicher Tractor Boost Pipe (Ic To Air Intake Pipe)- | 490   | 84099941 | 28% |
| 93273740 | Eicher Tractor Intake Manifold Hose-125Kva         | 647   | 40093100 | 18% |
| 93273751 | Eicher Tractor Ip Overflow Pipe 2 -Pump To Uniter  | 781   | 84099941 | 28% |
| 93273763 | Eicher Tractor Bracket- Air Filter                 | 2421  | 84099941 | 28% |
| 93273775 | Eicher Tractor Oil Pipe Tc Inlet-125Kva            | 226   | 84099941 | 28% |
| 93273805 | Eicher Tractor Gasket- Egr Valve-125 Kva           | 32    | 84841090 | 18% |
| 93273817 | Eicher Tractor Gasket- Turbo Exhuastextension      | 89    | 73182200 | 18% |
| 93273829 | Eicher Tractor Air Filter Element - Primary        | 3515  | 84219900 | 18% |
| 93273830 | Eicher Tractor Air Filter Element - Safety         | 1780  | 84219900 | 18% |
| 93273842 | Eicher Tractor Turbo Charger Extension             | 1675  | 84099941 | 28% |
| 93273866 | Eicher Tractor Bolt-Injector Clamp M7X45-125Kva    | 39    | 73181500 | 18% |
| 93273878 | Eicher Tractor Spacer Lifting Eye- 125 Kva         | 34    | 73182100 | 18% |
| 93273891 | Eicher Tractor Flywheel Casing- 125 Kva            | 10000 | 84099941 | 28% |
| 93273969 | Eicher Tractor Sealing Ring - Water Pump-125Kva    | 71    | 40169320 | 18% |
| 93273970 | Eicher Tractor Hose Breather-125Kva                | 1208  | 84099941 | 28% |
| 93274007 | Eicher Tractor V-Clamp For Turbo-125Kva            | 366   | 84099941 | 28% |
| 93274100 | Eicher Tractor Hex Bolt M10X85-125Kva              | 25    | 73181500 | 18% |
| 93274123 | Eicher Tractor Hex Bolt M8X120-125Kva              | 19    | 73181500 | 18% |
| 93274263 | Eicher Tractor Flange Screw M8X1.25X12-125Kva      | 5     | 73181500 | 18% |
| 93274275 | Eicher Tractor Flanged Bolt M6X16-125Kva           | 3     | 73181500 | 18% |
| 93274299 | Eicher Tractor Stud M8X28.5-125 Kva                | 55    | 73182100 | 18% |
| 93274329 | Eicher Tractor Hose Clip D25-125 Kva               | 27    | 40093100 | 18% |
| 93274354 | Eicher Tractor Valve Spring-125 Kva                | 90    | 73202000 | 18% |
| 93274366 | Eicher Tractor Banjo Bolt M18*1.5-125Kva           | 84    | 73181500 | 18% |
| 93274378 | Eicher Tractor Banjo Bolt M16*1.5-125Kva           | 68    | 73181500 | 18% |
| 93274380 | Eicher Tractor Banjo Bolt M10*1.5-125Kva           | 39    | 73181500 | 18% |
| 93274421 | Eicher Tractor Hose Clip Dia 120-125Kva            | 49    | 40093100 | 18% |
| 93274950 | Eicher Tractor Fan - Ric                           | 17143 | 84149040 | 18% |
| 93274962 | Eicher Tractor Hexagonal Head Bolt M8 X 100-125 Kv | 17    | 73181500 | 18% |
| 93275061 | Eicher Tractor Air Vent Union-125Kva               | 64    | 84099941 | 28% |
| 93275073 | Eicher Tractor Hose - Air Vent Union To Egr Cooler | 320   | 40093100 | 18% |
| 93275103 | Eicher Tractor Fuel Pipe Assy. ( Overflow To Fuel  | 1422  | 40092200 | 18% |
| 93275164 | Eicher Tractor Banjo Bolt M14*1.5 (Double Eye)-125 | 73    | 73181500 | 18% |
| 93275176 | Eicher Tractor Allen Screw M4X0.7Px10-125 Kva      | 14    | 73181500 | 18% |
| 93275220 | Eicher Tractor Spring - Compression                | 20    | 73209090 | 18% |
| 93275279 | Eicher Tractor Fuel Injection Pump                 | 92566 | 84133010 | 28% |
| 93275280 | Eicher Tractor Fuel Injector-82.5 Kva              | 6837  | 84139190 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93275292 | Eicher Tractor Injector Side Connector (Hpc)       | 1476  | 84099941 | 28% |
| 93275309 | Eicher Tractor Retaining Nut)-125Kva               | 200   | 73181500 | 18% |
| 93275310 | Eicher Tractor Primary Filter-82.5Kva              | 25540 | 84219900 | 18% |
| 93275322 | Eicher Tractor Secondary Fuel Filter               | 7052  | 84219900 | 18% |
| 93275346 | Eicher Tractor Spacer For Filter-125 Kva           | 1713  | 73182100 | 18% |
| 93275358 | Eicher Tractor Gear Housing - 82.5 & 100 Kva       | 4707  | 84834000 | 18% |
| 93275371 | Eicher Tractor Hpp - Fip To Cyl 01                 | 506   | 84099941 | 28% |
| 93275383 | Eicher Tractor Hpp - Fip To Cyl 02                 | 506   | 84099941 | 28% |
| 93275395 | Eicher Tractor High Pressure Pipe Cyl 3 - Assembly | 506   | 84099941 | 28% |
| 93275401 | Eicher Tractor High Pressure Pipe Cyl 4 - Assembly | 499   | 84099941 | 28% |
| 93275437 | Eicher Tractor Lpp - Primary Filter To Secondary F | 556   | 84219900 | 18% |
| 93275449 | Eicher Tractor Lpp - Secondary Filter To Fip Assy- | 199   | 84219900 | 18% |
| 93275474 | Eicher Tractor Adaptor - M14 To M12-125 Kva        | 154   | 84099990 | 28% |
| 93275498 | Eicher Tractor Core Plug - D32-125 Kva             | 18    | 84099941 | 28% |
| 93275531 | Eicher Tractor Rocker Arm Efa Assy - Inlet         | 1338  | 84099990 | 28% |
| 93275543 | Eicher Tractor Rocker Arm Efa Assy - Exhaust       | 981   | 84099990 | 28% |
| 93275590 | Eicher Tractor Stud M 10X65-125 Kva                | 27    | 73182100 | 18% |
| 93275656 | Eicher Tractor Donut Typ Oil Cooler - 14 Plate     | 8680  | 84099941 | 28% |
| 93275668 | Eicher Tractor Oil Filter Dia. 102                 | 624   | 84219900 | 18% |
| 93275670 | Eicher Tractor Oil Filter Dia 94                   | 571   | 84219900 | 18% |
| 93275681 | Eicher Tractor Nion Oil Cooler Mtg 100 Kva         | 288   | 84099941 | 28% |
| 93275693 | Eicher Tractor Gasket- Oil Cooler 100 Kva          | 122   | 84219900 | 18% |
| 93275700 | Eicher Tractor Oil Cooler Mtg. Plate 100 Kva       | 2704  | 73182100 | 18% |
| 93275723 | Eicher Tractor Bracket - Oil Filter Mounting Dia 1 | 4517  | 84099990 | 28% |
| 93275772 | Eicher Tractor Hex Bolt M10X1.25X90- 125 Kva       | 40    | 73181500 | 18% |
| 93275814 | Eicher Tractor Hose Water Inlet For Oil Cooler-125 | 97    | 40093100 | 18% |
| 93275875 | Eicher Tractor Adaptor-Oil Filter Dia. 102-125Kva  | 288   | 84219900 | 18% |
| 93275887 | Eicher Tractor Nipple For Water Inlet125 Kva       | 317   | 84099941 | 28% |
| 93275905 | Eicher Tractor Rotary Fuel Injection Pump - 82.5 K | 81356 | 84099990 | 28% |
| 93275917 | Eicher Tractor Flywheel Casing (82.5 & 100 Kva)    | 11040 | 84099941 | 28% |
| 93275930 | Eicher Tractor Flange Hex Screw M8X18-422Tci       | 8     | 73181500 | 18% |
| 93275942 | Eicher Tractor Allen Bolt M8 X 20 Ss 304           | 22    | 73181500 | 18% |
| 93275954 | Eicher Tractor Gasket – Egr Cooler Assy.-125Kva    | 71    | 73182200 | 18% |
| 93275966 | Eicher Tractor Gasket- Turbocharger Extension-125K | 82    | 73182200 | 18% |
| 93275978 | Eicher Tractor Sealing Washer Cu A16X20 Din7603-12 | 8     | 73182990 | 18% |
| 93275980 | Eicher Tractor Stud M10 X 85 Ss 304-125Kva         | 91    | 73182100 | 18% |
| 93276119 | Eicher Tractor Bracket - Support Turbo Extension   | 280   | 84099990 | 28% |
| 93276120 | Eicher Tractor Heat Shield-125 Kva                 | 1442  | 84841090 | 18% |
| 93276132 | Eicher Tractor Cap - Holding Turbo Extension( 125K | 182   | 84099941 | 28% |
| 93276168 | Eicher Tractor Dat- Ric Assy.                      | 9926  | 85030010 | 18% |
| 93276235 | Eicher Tractor Fuel Pipe Assy. ( Fuel Tank To Pref | 1098  | 84219900 | 18% |
| 93276247 | Eicher Tractor Wiring Harness Mtg. Clamp           | 30    | 84099941 | 28% |
| 93276326 | Eicher Tractor Heat Shield - Small 422Tci          | 1319  | 84841090 | 18% |
| 93276338 | Eicher Tractor Plug - Camshaft Sensor-125 Kva      | 202   | 84099941 | 28% |
| 93276340 | Eicher Tractor Plug Oil Pressure Sensor-125 Kva    | 225   | 84099941 | 28% |
| 93276351 | Eicher Tractor Pipe - Air Intake 82.5 Kva          | 1522  | 84219900 | 18% |
| 93276375 | Eicher Tractor Heat Shield - Turbo Ext 1751 Straig | 1345  | 84841090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93276399 | Eicher Tractor Lpp Fip To Main Fuel Filter-125 Kva | 1360  | 40092200 | 18% |
| 93276405 | Eicher Tractor Wiring Harness Assy.(125 Kva)1751   | 25108 | 85443000 | 18% |
| 93276417 | Eicher Tractor Fuel Connector M18X1.5              | 119   | 84099941 | 28% |
| 93276429 | Eicher Tractor Adaptor Main Fule Filter M18-125Kv  | 121   | 84219900 | 18% |
| 93276430 | Eicher Tractor Filter Insert- Main Fuel Filter     | 4624  | 84219900 | 18% |
| 93276442 | Eicher Tractor Filter Head Assy.- Main Fuel Filter | 4594  | 84219900 | 18% |
| 93276454 | Eicher Tractor Filter Insert- Fuel Pre Filter      | 4816  | 84219900 | 18% |
| 93276466 | Eicher Tractor Head Assy.- Fuel Pre Filter         | 14799 | 84219900 | 18% |
| 93276740 | Eicher Tractor Hose- Tc Outlet-125 Kva             | 3052  | 40093100 | 18% |
| 93276788 | Eicher Tractor Piston Ring(Middle)-125 Kva         | 300   | 84099913 | 28% |
| 93276820 | Eicher Tractor Plug M12 X 1.5-82.5 Kva             | 216   | 84099941 | 28% |
| 93276958 | Eicher Tractor Core Plug - D22-125 Kva             | 16    | 84099941 | 28% |
| 93276995 | Eicher Tractor Water Pump Assembly-82.5 Kva        | 19163 | 84133030 | 28% |
| 93277008 | Eicher Tractor Hose Air Cleaner                    | 1731  | 40093100 | 18% |
| 93277021 | Eicher Tractor Fip Fuel Over Flow Pipe (82.5 Kva)  | 548   | 84099941 | 28% |
| 93277392 | Eicher Tractor Clamp-125 Kva                       | 27    | 84099941 | 28% |
| 93277422 | Eicher Tractor Flange - Exhuast Manifold           | 394   | 84099941 | 28% |
| 93277434 | Eicher Tractor Flange - Pipe Air Intake            | 384   | 84099941 | 28% |
| 93277495 | Eicher Tractor Timing Mark Bkt-82.5 Kva            | 81    | 84099941 | 28% |
| 93277513 | Eicher Tractor Wiring Harness Assy.-82.5 Kva       | 2644  | 85443000 | 18% |
| 93277683 | Eicher Tractor Air Vent Plug                       | 1079  | 84099941 | 28% |
| 93277690 | Eicher Tractor 7 Pin Connector                     | 489   | 84099941 | 28% |
| 93277707 | Eicher Tractor 22 Pin Connector                    | 218   | 84099941 | 28% |
| 93277720 | Eicher Tractor Bearing Upper - Conrod Big End      | 214   | 84825011 | 18% |
| 93277732 | Eicher Tractor Bearing Lower - Conrod Big End      | 202   | 84825011 | 18% |
| 93277902 | Eicher Tractor Breather Assembly                   | 1567  | 84099941 | 28% |
| 93277940 | Eicher Tractor Lock Nut M24 X1.5                   | 152   | 87089900 | 18% |
| 93277951 | Eicher Tractor Rubber Washer (Breather)            | 74    | 87089900 | 18% |
| 93278013 | Eicher Tractor Connector - Turbo Charger 125Kva    | 670   | 84099941 | 28% |
| 93278025 | Eicher Tractor Crank Pulley (Dia 203.76) 125Kva    | 2966  | 84835010 | 18% |
| 93278098 | Eicher Tractor Element Assembly:                   | 4891  | 84212900 | 18% |
| 93278104 | Eicher Tractor Element Assembly:                   | 5334  | 84212900 | 18% |
| 93278130 | Eicher Tractor Gear-Fip                            | 1849  | 84834000 | 18% |
| 93278141 | Eicher Tractor Dipstick-125 Kva                    | 110   | 84099941 | 28% |
| 93278189 | Eicher Tractor Oil Pan - Flat Flange               | 5057  | 84099941 | 28% |
| 93278207 | Eicher Tractor Fuel Pipe Prim To Sec Filter-82.5 K | 345   | 84219900 | 18% |
| 93278220 | Eicher Tractor Dipstick-82.5 Kva                   | 136   | 84099941 | 28% |
| 93278232 | Eicher Tractor Heat Shield - Turbo Extension 1751E | 6443  | 84841090 | 18% |
| 93278335 | Eicher Tractor Water Collector Bowl Fuel Pre Filte | 449   | 84212300 | 18% |
| 93278347 | Eicher Tractor Water Sensor 12V Fuel Pre Filter    | 1543  | 84212300 | 18% |
| 93278359 | Eicher Tractor Head Casting - Fuel Pre Filter      | 6273  | 84212300 | 18% |
| 93278360 | Eicher Tractor Filter Element - Fuel Pre Filter    | 1931  | 84219900 | 18% |
| 93278384 | Eicher Tractor Hose Ric Outlet                     | 1923  | 40093100 | 18% |
| 93278396 | Eicher Tractor Hose Dat                            | 378   | 40093100 | 18% |
| 93278414 | Eicher Tractor Head Casting - Main Fuel Filter     | 5661  | 84212300 | 18% |
| 93278426 | Eicher Tractor Filter Element - Main Fuel Filter   | 877   | 84219900 | 18% |
| 93278438 | Eicher Tractor Poly V Belt (1420) 125Kva           | 1162  | 40101290 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93278608 | Eicher Tractor Fan Guard Assy – 125Kva              | 1975  | 85030090 | 18% |
| 93278610 | Eicher Tractor Pipe - Oil Cooler Outlet (82.5Kva)   | 679   | 84219900 | 18% |
| 93278669 | Eicher Tractor Hose - Coolant Outlet                | 169   | 40093100 | 18% |
| 93278670 | Eicher Tractor Rail-Water Outlet                    | 9634  | 84099941 | 28% |
| 93278682 | Eicher Tractor Clamp Egr Hose                       | 25    | 84099941 | 28% |
| 93278694 | Eicher Tractor Stud - Lifting Eye                   | 37    | 84099941 | 28% |
| 93278712 | Eicher Tractor Belt Guard Assy – 125Kva             | 822   | 84099941 | 28% |
| 93278748 | Eicher Tractor Hose- Water Rail Inlet               | 178   | 40093100 | 18% |
| 93278797 | Eicher Tractor Support Top – Belt Guard             | 158   | 84099941 | 28% |
| 93278803 | Eicher Tractor Support Bottom Belt Guard            | 133   | 84099941 | 28% |
| 93278839 | Eicher Tractor Gasket - Egr Cooler (Dia 16Mm)       | 35    | 84841090 | 18% |
| 93278840 | Eicher Tractor Egr Pipe Assy.                       | 2852  | 84099941 | 28% |
| 93278864 | Eicher Tractor Hose - Turbo Connector 125Kva        | 593   | 84099941 | 28% |
| 93278876 | Eicher Tractor Boost Pipe - Turbo To Ric            | 1707  | 84099941 | 28% |
| 93278890 | Eicher Tractor Coil Breather Hose125                | 58    | 40093100 | 18% |
| 93279157 | Eicher Tractor Front Pedestal Assly Lh              | 9132  | 84099941 | 28% |
| 93279169 | Eicher Tractor Front Pedestal Assly Rh              | 9132  | 84099941 | 28% |
| 93279194 | Eicher Tractor Alternator Assy.                     | 10530 | 85115000 | 28% |
| 93279285 | Eicher Tractor Water Bowl Assembly:                 | 4507  | 84212900 | 18% |
| 93279297 | Eicher Tractor Lock Ring Kit:                       | 2859  | 84212900 | 18% |
| 93279303 | Eicher Tractor Drain Valve Assembly                 | 1518  | 84212900 | 18% |
| 93279315 | Eicher Tractor Dust Seal                            | 645   | 84212900 | 18% |
| 93279418 | Eicher Tractor Starter Motor                        | 15320 | 85114000 | 28% |
| 93279479 | Eicher Tractor Timing Mark Bkt. 82Kva               | 41    | 84099941 | 28% |
| 93279510 | Eicher Tractor Hose Ac To Tc                        | 1788  | 40093100 | 18% |
| 93279522 | Eicher Tractor Bracket Air Cleaner Mtg.             | 1951  | 84099941 | 28% |
| 93279662 | Eicher Tractor Fuel Filter Assembly - 82.5 Kva      | 6785  | 84212300 | 18% |
| 93279741 | Eicher Tractor Bracket - Egr Cooler Mtg.            | 283   | 84099941 | 28% |
| 93279765 | Eicher Tractor Egr Pipe- Egr Cooler Outlet          | 2279  | 84099941 | 28% |
| 93279777 | Eicher Tractor Hose- Egr Cooler Inlet               | 561   | 40093100 | 18% |
| 93279781 | Eicher Tractor Hose-Egr Outlet                      | 411   | 40093100 | 18% |
| 93279819 | Eicher Tractor Fuel Injector                        | 6672  | 84099941 | 28% |
| 93279820 | Eicher Tractor Turbocharger Assembly                | 31233 | 84148030 | 18% |
| 93279844 | Eicher Tractor Turbo Charger Extension              | 1528  | 84099941 | 28% |
| 93279870 | Eicher Tractor Piston-1751                          | 5919  | 84099112 | 28% |
| 93279881 | Eicher Tractor Piston-82.5Kva(Federal Mughal)       | 5514  | 84099912 | 28% |
| 93279923 | Eicher Tractor Piston Pin - Fm                      | 759   | 84099941 | 28% |
| 93279935 | Eicher Tractor Piston Ring - Top(82.5/100/125Kva)   | 1017  | 84099941 | 28% |
| 93279947 | Eicher Tractor Piston Ring - Middle(82.5/100/125Kv  | 208   | 84099913 | 28% |
| 93279959 | Eicher Tractor Piston Ring-Oil Cont. 62.5/82.5/100/ | 429   | 84099941 | 28% |
| 93279960 | Eicher Tractor Circlip - Fm                         | 13    | 73182910 | 18% |
| 93290162 | Eicher Tractor Plug Temperature Gauge               | 88    | 84099941 | 28% |
| 93290598 | Eicher Tractor Pipe - Oil Cooler Outlet             | 1317  | 84099990 | 28% |
| 93290886 | Eicher Tractor Primary Fuel Filter                  | 3084  | 84219900 | 18% |
| 93291386 | Eicher Tractor Hose Clip - A 50                     | 33    | 73269099 | 18% |
| 93291437 | Eicher Tractor Hpp Clamp For 4 Pipe                 | 36    | 84099941 | 28% |
| 93291449 | Eicher Tractor Hpp Clamp For 3 Pipe                 | 32    | 84099941 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93291450 | Eicher Tractor Hpp Clamp For 2 Pipe                | 28    | 84099941 | 28% |
| 93291486 | Eicher Tractor Egr Pipe - Exhaust Mf To Egr Cooler | 2376  | 84099941 | 28% |
| 93291862 | Eicher Tractor Plug-Alternator Drain               | 80    | 84099941 | 28% |
| 93291925 | Eicher Tractor Pipe Assy- Tc Oil Inlet             | 641   | 40092200 | 18% |
| 93291937 | Eicher Tractor O-Ring For Sleeve 27.55X3.00-125Kva | 36    | 40169320 | 18% |
| 93291949 | Eicher Tractor Injector Sleeve                     | 735   | 84099941 | 28% |
| 93291962 | Eicher Tractor Cylinder Head Sub Assy (125Kva)     | 80324 | 84099941 | 28% |
| 93291974 | Eicher Tractor Cylinder Head Sub Assy (82.5 Kva)   | 75043 | 84099941 | 28% |
| 93292013 | Eicher Tractor Sealing Washer 16X22                | 29    | 73182990 | 18% |
| 93292025 | Eicher Tractor Sealing Washer 18X24                | 36    | 73182990 | 18% |
| 93292174 | Eicher Tractor Bracket - Egr Controller Mtg        | 236   | 87089900 | 18% |
| 93292186 | Eicher Tractor Heat Shield                         | 739   | 84841090 | 18% |
| 93292201 | Eicher Tractor Hose - Egr Cooler Inlet 125 Kva     | 1770  | 87089900 | 18% |
| 93292213 | Eicher Tractor Hose-Egr Cooler Outlet (125Kva)     | 877   | 40093100 | 18% |
| 93292301 | Eicher Tractor Tie Lock-Wiring Harness             | 4     | 85441920 | 18% |
| 93292313 | Eicher Tractor Name Plate                          | 31    | 76061190 | 18% |
| 93292349 | Eicher Tractor Back Plate - Water Rail             | 646   | 84099941 | 28% |
| 93292350 | Eicher Tractor Water Rail                          | 6297  | 87081010 | 18% |
| 93292513 | Eicher Tractor Wiring Harness Assy.(125 Kva)1751   | 16829 | 85444220 | 18% |
| 93292562 | Eicher Tractor Crank Pulley ( Dia 203.76 )         | 3114  | 73182100 | 18% |
| 93292813 | Eicher Tractor Fuel Connector Main Filter          | 130   | 84099941 | 28% |
| 93293450 | Eicher Tractor Exhaust Expansion Bellow            | 1850  | 83071000 | 18% |
| 93293486 | Eicher Tractor Bracket - Fuel Filter               | 328   | 87081010 | 18% |
| 93293498 | Eicher Tractor Lpp - Fuel Pump Outlet To Fuel Filt | 761   | 40092200 | 18% |
| 93293501 | Eicher Tractor Lpp - Uinter To Tank                | 987   | 40092200 | 18% |
| 93293513 | Eicher Tractor Relief Valve ( 1 Bar)               | 247   | 84818090 | 18% |
| 93293537 | Eicher Tractor Lpp –Uniter To Fip                  | 403   | 84099941 | 28% |
| 93293550 | Eicher Tractor Fuel Uniter                         | 320   | 84099941 | 28% |
| 93293650 | Eicher Tractor Lpp- Fuel Filter To Uniter          | 394   | 84219900 | 18% |
| 93293713 | Eicher Tractor Special Banjo Bolt M16X1.5          | 96    | 73181500 | 18% |
| 93293725 | Eicher Tractor Special Banjo Bolt M18X1.5          | 113   | 73181500 | 18% |
| 93293737 | Eicher Tractor Air Bleed Screw                     | 49    | 73181500 | 18% |
| 93293749 | Eicher Tractor Pump-Fuel In-Tank                   | 14608 | 84133020 | 28% |
| 93293762 | Eicher Tractor Special Banjo Bolt M14*1.5          | 78    | 73181500 | 18% |
| 93293774 | Eicher Tractor Sealing Washer 8 X 14 Is 3175 Cu    | 3     | 73182990 | 18% |
| 93294074 | Eicher Tractor Head Casting Assy                   | 3360  | 84212300 | 18% |
| 93294086 | Eicher Tractor Fuel Filter Element (Pre Filter)    | 884   | 84219900 | 18% |
| 93294098 | Eicher Tractor Fuel Filter Element (Main Filter)   | 1091  | 84219900 | 18% |
| 93294162 | Eicher Tractor Adaptor - Egr Pipe & Egr Valve      | 926   | 84099941 | 28% |
| 93294174 | Eicher Tractor Bracket - Egr & Modulator           | 403   | 87089900 | 18% |
| 93294198 | Eicher Tractor Cover Water Rail Front              | 543   | 84099941 | 28% |
| 93294225 | Eicher Tractor Egr Pipe - Exh. Mf To Egr Cooler    | 2424  | 84099990 | 28% |
| 93294462 | Eicher Tractor Hose – Air Vent                     | 309   | 40093100 | 18% |
| 93294713 | Eicher Tractor Lid-Fuel Tank Hatch Assy.           | 1180  | 45039090 | 18% |
| 93294737 | Eicher Tractor Rubber Washer - Water Separator     | 9     | 74091100 | 18% |
| 93294774 | Eicher Tractor Gasket - Lid Fuel Tank Hatch Assy.  | 239   | 85030010 | 18% |
| 93294837 | Eicher Tractor Air Bleed Arrangement-1751Es        | 1122  | 73182990 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93294901 | Eicher Tractor Pressure Cap- Ric Assy.             | 391   | 87089900 | 18% |
| 93310024 | Eicher Tractor Mudguard Assy.(Left)242/312/364/368 | 11918 | 87089900 | 18% |
| 93310036 | Eicher Tractor Mudguard Assy.(Right)242/312/364/36 | 11747 | 87089900 | 18% |
| 93310115 | Eicher Tractor Fuel Tank Assy. - 242 Superstar-Red | 9543  | 87089900 | 18% |
| 93310116 | Eicher Tractor Fuel Tank Assy. - 241 Superstar-Red | 6971  | 87089900 | 18% |
| 93310206 | Eicher Tractor Strainer Mtg. Plate                 | 66    | 84219900 | 18% |
| 93310231 | Eicher Tractor Cover Right                         | 228   | 87084000 | 18% |
| 93310255 | Eicher Tractor Graphic 241 Left                    | 266   | 39199090 | 18% |
| 93310267 | Eicher Tractor Graphic 241 Right                   | 266   | 39199090 | 18% |
| 93310553 | Eicher Tractor Brake Pedal Right                   | 876   | 87083000 | 18% |
| 93310565 | Eicher Tractor Foot Board Right                    | 911   | 87089900 | 18% |
| 93310590 | Eicher Tractor Grommet Acc.                        | 29    | 40169990 | 18% |
| 93310620 | Eicher Tractor Strip Graphics Lt (Red Bonnet)      | 77    | 39199090 | 18% |
| 93310632 | Eicher Tractor Strip Graphics Rt (Red Bonnet)      | 16    | 39199090 | 18% |
| 93310656 | Eicher Tractor Sticker Super Star-Left             | 344   | 39199090 | 18% |
| 93310668 | Eicher Tractor Sticker Super Star-Right            | 315   | 39199090 | 18% |
| 93310670 | Eicher Tractor 242 Sq. Graphics Lt. (Blue Bonnet)  | 601   | 39199090 | 18% |
| 93310899 | Eicher Tractor Foot Accelerator Pedal              | 237   | 87084000 | 18% |
| 93311065 | Eicher Tractor Torque Strut                        | 85    | 87089400 | 18% |
| 93311119 | Eicher Tractor Brake Pedal Left                    | 1206  | 87083000 | 18% |
| 93311260 | Eicher Tractor Pin For Pawl                        | 48    | 73182100 | 18% |
| 93311338 | Eicher Tractor Steering Gear Assy.(Zf)Modified     | 10691 | 87089400 | 18% |
| 93311648 | Eicher Tractor Front Axle Support-24Hp(Round)      | 22426 | 87089900 | 18% |
| 93311697 | Eicher Tractor Hand Acc Lever                      | 325   | 87089900 | 18% |
| 93311779 | Eicher Tractor Front Axle Support                  | 22782 | 87089900 | 18% |
| 93311788 | Eicher Tractor Bonnet Mtg. Bkt. Left               | 374   | 87089900 | 18% |
| 93311790 | Eicher Tractor Bonnet Mtg. Bkt. Right              | 363   | 87089900 | 18% |
| 93311946 | Eicher Tractor Bonnet Coughion                     | 25    | 87089900 | 18% |
| 93311995 | Eicher Tractor Lower Bracket                       | 3345  | 87089900 | 18% |
| 93312033 | Eicher Tractor Lock Mtg. Bkt. Lt.                  | 126   | 87089900 | 18% |
| 93312045 | Eicher Tractor Lock Mtg. Bkt. Rt.                  | 130   | 87089900 | 18% |
| 93312057 | Eicher Tractor Latch Mtg. Bkt. Lt.                 | 128   | 87089900 | 18% |
| 93312069 | Eicher Tractor Latch Mtg. Bkt. Rt.                 | 128   | 87089900 | 18% |
| 93312082 | Eicher Tractor Battery Cover 242                   | 515   | 85079090 | 28% |
| 93312112 | Eicher Tractor Fuel Tank 242Jbm                    | 6565  | 87089900 | 18% |
| 93312136 | Eicher Tractor Rod                                 | 75    | 87089900 | 18% |
| 93312185 | Eicher Tractor Bumper Assy                         | 5131  | 87081010 | 18% |
| 93312197 | Eicher Tractor Steering Lever Double               | 2649  | 87089400 | 18% |
| 93312227 | Eicher Tractor Dash Board - 24 Hp                  | 417   | 87089900 | 18% |
| 93312290 | Eicher Tractor Rubber Pad                          | 60    | 40169990 | 18% |
| 93312306 | Eicher Tractor Hinge Bracket -242Jbm               | 1017  | 87089900 | 18% |
| 93312320 | Eicher Tractor Starting Handle Assy                | 1191  | 84099941 | 28% |
| 93312355 | Eicher Tractor Bonnet Graphics Top Rt. 242Jbm      | 545   | 39199090 | 18% |
| 93312357 | Eicher Tractor Suction Elbow                       | 452   | 40093100 | 18% |
| 93312367 | Eicher Tractor Strip Graphics Premium              | 74    | 39199090 | 18% |
| 93312392 | Eicher Tractor Mudguard Red Sticker -241           | 81    | 39199090 | 18% |
| 93312409 | Eicher Tractor Mudguard Red Sticker -242           | 68    | 39199090 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93312410 | Eicher Tractor Mudguard Red Sticker -Eicher       | 91    | 39199090 | 18% |
| 93312446 | Eicher Tractor Sticker Fuel Tank Bottom Right     | 127   | 39199090 | 18% |
| 93312549 | Eicher Tractor Sticker X-Trac - 24Hp Rsm          | 88    | 39199090 | 18% |
| 93312604 | Eicher Tractor Rubber Beading                     | 48    | 40169320 | 18% |
| 93312616 | Eicher Tractor Cushion Pad 212J                   | 108   | 40169320 | 18% |
| 93312628 | Eicher Tractor Rubber Hd Light                    | 15    | 40169320 | 18% |
| 93312630 | Eicher Tractor Rubber Hd Light                    | 10    | 40169320 | 18% |
| 93312720 | Eicher Tractor Spline Shaft With Bush - 241 (Teet | 1711  | 87084000 | 18% |
| 93312768 | Eicher Tractor Special Washer 13X29X3 242Jbm      | 13    | 73182990 | 18% |
| 93312781 | Eicher Tractor Special Bolt                       | 40    | 73181500 | 18% |
| 93312823 | Eicher Tractor Back Rest Lt.                      | 915   | 87089900 | 18% |
| 93312884 | Eicher Tractor Grommet                            | 10    | 40169990 | 18% |
| 93313992 | Eicher Tractor Chain Mkt Bkt Rt                   | 922   | 87089900 | 18% |
| 93314005 | Eicher Tractor Chain Mkt Bkt Lt                   | 922   | 87089900 | 18% |
| 93314110 | Eicher Tractor Brake Pedal Right                  | 774   | 87083000 | 18% |
| 93314133 | Eicher Tractor Adjusting Latch                    | 281   | 87085000 | 18% |
| 93314285 | Eicher Tractor Fuel Tank Cap Assly                | 190   | 87089900 | 18% |
| 93314340 | Eicher Tractor Gasket For Guide Sleeve            | 31    | 68129090 | 18% |
| 93314390 | Eicher Tractor Lower Link                         | 2054  | 87089900 | 18% |
| 93314765 | Eicher Tractor Chain Assly                        | 1231  | 87089900 | 18% |
| 93314777 | Eicher Tractor Chain Assy                         | 1243  | 87089900 | 18% |
| 93314996 | Eicher Tractor Fuel Cock Assy.                    | 383   | 87089900 | 18% |
| 93315010 | Eicher Tractor Lower Link Assy.                   | 2723  | 87089900 | 18% |
| 93315071 | Eicher Tractor Front Axle Assy.                   | 19640 | 87085000 | 18% |
| 93315125 | Eicher Tractor Front Weight                       | 5405  | 87081010 | 18% |
| 93315356 | Eicher Tractor Starter Switch+Fuel Cap+Key Pair   | 699   | 84099941 | 28% |
| 93315423 | Eicher Tractor Front Logo (Big)                   | 272   | 39199090 | 18% |
| 93315472 | Eicher Tractor Brake Pedal Left                   | 1288  | 87083000 | 18% |
| 93315502 | Eicher Tractor Hand Brake Assy                    | 575   | 87083000 | 18% |
| 93315538 | Eicher Tractor Smv Emblem                         | 265   | 85122020 | 18% |
| 93315551 | Eicher Tractor D D Seat(Smv)-241/242/312/364      | 4665  | 94012000 | 18% |
| 93315575 | Eicher Tractor Rubber Flap - Small                | 67    | 40169320 | 18% |
| 93315605 | Eicher Tractor Rubber Flap - Big                  | 101   | 40169320 | 18% |
| 93315629 | Eicher Tractor Coupling Mouth                     | 3782  | 87089900 | 18% |
| 93315630 | Eicher Tractor Mounting Angle                     | 1034  | 87089900 | 18% |
| 93315642 | Eicher Tractor Pin                                | 413   | 73182100 | 18% |
| 93315654 | Eicher Tractor Front Weight 242 Jbm               | 3674  | 87081010 | 18% |
| 93315708 | Eicher Tractor Rear Wheel Weight                  | 7616  | 87087000 | 18% |
| 93315721 | Eicher Tractor Plate 242                          | 108   | 83100090 | 18% |
| 93315781 | Eicher Tractor Tool Box Assy (Plastic)            | 388   | 39235090 | 18% |
| 93315824 | Eicher Tractor Sticker For Air Cleaner            | 11    | 39199090 | 18% |
| 93315848 | Eicher Tractor Fuel Filter Bracket                | 278   | 84219900 | 18% |
| 93315903 | Eicher Tractor Gasket-Flywheel Housing            | 176   | 68129090 | 18% |
| 93315915 | Eicher Tractor Gasket For G1/Fw Hsg Joint         | 104   | 68129090 | 18% |
| 93316026 | Eicher Tractor On/Off Bracket                     | 33    | 87089900 | 18% |
| 93316087 | Eicher Tractor Label                              | 37    | 39199090 | 18% |
| 93316233 | Eicher Tractor Rear Axle- Db - 241                | 5337  | 87084000 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93316269 | Eicher Tractor Connecting Link Assly               | 456   | 87089900 | 18% |
| 93316270 | Eicher Tractor Foot Board Right                    | 1063  | 87089900 | 18% |
| 93316294 | Eicher Tractor Brake Mech 241 Db                   | 627   | 87083000 | 18% |
| 93316348 | Eicher Tractor Upper Link 2                        | 2705  | 87089900 | 18% |
| 93316350 | Eicher Tractor Chain Assy 242 Nf                   | 1327  | 87089900 | 18% |
| 93316403 | Eicher Tractor Sticker - Disc Brake                | 33    | 39199090 | 18% |
| 93316415 | Eicher Tractor Pedal Shaft                         | 1684  | 87084000 | 18% |
| 93316427 | Eicher Tractor Battery Mkt Bkt                     | 753   | 85079090 | 28% |
| 93316439 | Eicher Tractor Link Plate                          | 124   | 87089900 | 18% |
| 93316440 | Eicher Tractor Footboard-Lt                        | 1325  | 87089900 | 18% |
| 93316452 | Eicher Tractor Brake Link Assly                    | 374   | 87083000 | 18% |
| 93316476 | Eicher Tractor Rear Wheel W11X28 (Welded) Tsa-Whit | 11386 | 87087000 | 18% |
| 93316488 | Eicher Tractor Front Wheel Rim 4.5X16 Tsa -White   | 2444  | 87087000 | 18% |
| 93316490 | Eicher Tractor Fork And Guide Assembly             | 1761  | 87089900 | 18% |
| 93316506 | Eicher Tractor Brake Pedal Left                    | 1455  | 87083000 | 18% |
| 93316520 | Eicher Tractor Clutch Pedal 242 Nf                 | 1590  | 87089300 | 18% |
| 93316543 | Eicher Tractor Footboard-Rt                        | 1368  | 87089900 | 18% |
| 93316683 | Eicher Tractor Tool Kit Assy                       | 1295  | 82060090 | 18% |
| 93316695 | Eicher Tractor Tool Kit Assy                       | 1307  | 82060090 | 18% |
| 93316750 | Eicher Tractor Bottel Holder                       | 232   | 87089900 | 18% |
| 93316786 | Eicher Tractor Mounting Bracket                    | 263   | 87089900 | 18% |
| 93316798 | Eicher Tractor D D Seat(Smv)-241/242/312/364       | 6641  | 94012000 | 18% |
| 93316804 | Eicher Tractor Battery Box Assy 241                | 2024  | 85079090 | 28% |
| 93316830 | Eicher Tractor Link 241                            | 187   | 87089900 | 18% |
| 93316841 | Eicher Tractor Switch Mtg Bkt                      | 27    | 87089900 | 18% |
| 93316853 | Eicher Tractor Mounting Angle Lt                   | 1438  | 87089900 | 18% |
| 93316865 | Eicher Tractor Mounting Angle Rt                   | 1438  | 87089900 | 18% |
| 93316890 | Eicher Tractor Dd Seat (Fixed)                     | 3973  | 94012000 | 18% |
| 93316907 | Eicher Tractor Lever                               | 463   | 87089900 | 18% |
| 93316919 | Eicher Tractor Mounting Bracket                    | 53    | 87089900 | 18% |
| 93316920 | Eicher Tractor Sticker-Agristar                    | 54    | 39199090 | 18% |
| 93316932 | Eicher Tractor Sticker Xtrac Premiur               | 17    | 39199090 | 18% |
| 93316956 | Eicher Tractor Lift Arm 242 Hd                     | 2493  | 87089900 | 18% |
| 93317020 | Eicher Tractor Bottel Holder                       | 211   | 87089900 | 18% |
| 93317031 | Eicher Tractor Lower Link                          | 3211  | 87089900 | 18% |
| 93317043 | Eicher Tractor Indicator (Oil Pressure)            | 106   | 85311010 | 18% |
| 93317055 | Eicher Tractor Dashboard Indiacator (Oil Pressure) | 106   | 85311010 | 18% |
| 93317092 | Eicher Tractor C- Clamp                            | 24    | 87089900 | 18% |
| 93317146 | Eicher Tractor Brake Pedal Left                    | 982   | 87083000 | 18% |
| 93317158 | Eicher Tractor Brake Pedal Right                   | 741   | 87083000 | 18% |
| 93317160 | Eicher Tractor Saring Handle                       | 1104  | 87089900 | 18% |
| 93317183 | Eicher Tractor Foot Rest 241                       | 515   | 87089900 | 18% |
| 93317419 | Eicher Tractor Lifting Gear Mechanism              | 3269  | 87089900 | 18% |
| 93317560 | Eicher Tractor Sticker 242 Hyd. Lh                 | 97    | 39199090 | 18% |
| 93317572 | Eicher Tractor Sticker 242 Hyd. Rh                 | 97    | 39199090 | 18% |
| 93317602 | Eicher Tractor Fork & Guide Mechanism              | 1948  | 87089900 | 18% |
| 93317675 | Eicher Tractor Fuel Filter Bracket (241/242)       | 526   | 84219900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93317699 | Eicher Tractor Foot Rest 242                       | 464   | 87089900 | 18% |
| 93317705 | Eicher Tractor B P Rt 241                          | 1089  | 87083000 | 18% |
| 93317729 | Eicher Tractor Brake Pedal Right-242 Hyd.          | 906   | 87083000 | 18% |
| 93317808 | Eicher Tractor Rear Rim W11 S.Bolt Off Wht Knp 12  | 11964 | 73181500 | 18% |
| 93317810 | Eicher Tractor Rear Rim W11 Welded Off Wht Knp 12. | 14162 | 87087000 | 18% |
| 93318096 | Eicher Tractor Pedal Shaft                         | 1082  | 87084000 | 18% |
| 93318217 | Eicher Tractor Brake Pedal Left (242)              | 1180  | 87083000 | 18% |
| 93318229 | Eicher Tractor Brake Pedal Right (242)             | 929   | 87083000 | 18% |
| 93318254 | Eicher Tractor Grommet (Tail Lamp)                 | 14    | 40169990 | 18% |
| 93318266 | Eicher Tractor Fuse Box                            | 44    | 85369090 | 18% |
| 93318278 | Eicher Tractor Corrugated Pvc Tube                 | 11    | 85443000 | 18% |
| 93318345 | Eicher Tractor Battery Box 241                     | 2649  | 85079090 | 28% |
| 93318357 | Eicher Tractor Battery Box 242                     | 2238  | 85079090 | 28% |
| 93318369 | Eicher Tractor Dd Seat (Fixed)                     | 8146  | 94012000 | 18% |
| 93318370 | Eicher Tractor Dd Seat (Adjustable)                | 6406  | 94012000 | 18% |
| 93318382 | Eicher Tractor Battery Cover 242                   | 632   | 85079090 | 28% |
| 93318424 | Eicher Tractor Rim Front 2Wd 3.50Dx14 (Silver)     | 2449  | 87087000 | 18% |
| 93318436 | Eicher Tractor Rear Wheel Rim W6X18 (Silver)       | 6186  | 87087000 | 18% |
| 93318448 | Eicher Tractor Rim Front 4Wd 4.00Bx12 (Silver)     | 2491  | 87087000 | 18% |
| 93318485 | Eicher Tractor Dd Seat Assy                        | 6977  | 94012000 | 18% |
| 93318497 | Eicher Tractor Pad For Radiator                    | 37    | 87087000 | 18% |
| 93318680 | Eicher Tractor Axle                                | 193   | 87085000 | 18% |
| 93318692 | Eicher Tractor Flywheel Housing M/C 241.           | 33070 | 87084000 | 18% |
| 93318709 | Eicher Tractor Flywheel Housing M/C-242            | 31645 | 87084000 | 18% |
| 93318898 | Eicher Tractor Lifting Gear Mechanism              | 2916  | 87089900 | 18% |
| 93318928 | Eicher Tractor Lifting Gear Mechanism              | 3253  | 87089900 | 18% |
| 93318941 | Eicher Tractor Fork & Guide Assy                   | 2399  | 87089900 | 18% |
| 93318953 | Eicher Tractor Fork And Guide Mechanism            | 2189  | 87089900 | 18% |
| 93319064 | Eicher Tractor Front Axle Assy.                    | 20070 | 87085000 | 18% |
| 93319120 | Eicher Tractor Fork & Guide Mechanism              | 2388  | 87089900 | 18% |
| 93319179 | Eicher Tractor Lifting Gear Mechanism              | 2910  | 87089900 | 18% |
| 93319258 | Eicher Tractor Gasket (Inspection Window)-1.2Mm    | 42    | 68129090 | 18% |
| 93319271 | Eicher Tractor Mounting Bracket                    | 59    | 87089900 | 18% |
| 93319295 | Eicher Tractor Cover (Inspection Window)           | 104   | 87084000 | 18% |
| 93319301 | Eicher Tractor Rod (Accelerator)                   | 116   | 87084000 | 18% |
| 93319441 | Eicher Tractor Plastics Tool Box                   | 438   | 39021000 | 18% |
| 93319477 | Eicher Tractor Front Axle Support                  | 8599  | 87089900 | 18% |
| 93319489 | Eicher Tractor Center Pin                          | 583   | 73182400 | 18% |
| 93319490 | Eicher Tractor Sleeve (Center Pin)                 | 205   | 87089900 | 18% |
| 93319647 | Eicher Tractor Coupling Mouth                      | 4458  | 87089900 | 18% |
| 93319660 | Eicher Tractor Hose Bracket                        | 171   | 40093100 | 18% |
| 93319672 | Eicher Tractor Guard Plate                         | 83    | 87089900 | 18% |
| 93319751 | Eicher Tractor Steering Wheel Ps                   | 1670  | 87089400 | 18% |
| 93319775 | Eicher Tractor Front Grill (Bonnet)                | 704   | 87089900 | 18% |
| 93319891 | Eicher Tractor Dd Seat (Adjustable Dual Tone)      | 9680  | 94012000 | 18% |
| 93319994 | Eicher Tractor Super Plus Sticker                  | 77    | 39199090 | 18% |
| 93320042 | Eicher Tractor Trunnion Block                      | 83    | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93320054 | Eicher Tractor Relay Lever                         | 108   | 85364900 | 18% |
| 93320078 | Eicher Tractor Pin Tail Lug                        | 38    | 73182100 | 18% |
| 93320080 | Eicher Tractor Pin Small                           | 30    | 73182100 | 18% |
| 93320121 | Eicher Tractor Brake Pedal Right                   | 1062  | 87083000 | 18% |
| 93320170 | Eicher Tractor Brake Pedal Left-312P               | 1038  | 87083000 | 18% |
| 93320315 | Eicher Tractor Fas Assy-W/C                        | 57015 | 87089900 | 18% |
| 93320418 | Eicher Tractor Plate 312                           | 91    | 83100090 | 18% |
| 93320420 | Eicher Tractor Plate 364                           | 108   | 83100090 | 18% |
| 93320455 | Eicher Tractor Sticker Combi Torq                  | 48    | 39199090 | 18% |
| 93320467 | Eicher Tractor Sticker Super Di                    | 47    | 39199090 | 18% |
| 93320480 | Eicher Tractor Bracket (For Air Cleaner Mounting)  | 704   | 84099941 | 28% |
| 93320686 | Eicher Tractor Wheel Rim W11 (12.4X28 Tyre)        | 10464 | 87087000 | 18% |
| 93320861 | Eicher Tractor Front Axle Support-24Hp(Square)     | 10400 | 87089900 | 18% |
| 93320900 | Eicher Tractor Bonnet Mkt Bkt Lt                   | 413   | 87089900 | 18% |
| 93320911 | Eicher Tractor Bonnet Mkt Bkt Rt                   | 413   | 87089900 | 18% |
| 93320923 | Eicher Tractor Steering Lever Double               | 2451  | 87089400 | 18% |
| 93321034 | Eicher Tractor Foot Board Rightr                   | 1645  | 87089900 | 18% |
| 93321046 | Eicher Tractor Spacer                              | 21    | 73182100 | 18% |
| 93321058 | Eicher Tractor Foot Accelerator Shaft              | 166   | 73182100 | 18% |
| 93321060 | Eicher Tractor Foot Accelerator Shaft Guide        | 173   | 87084000 | 18% |
| 93321071 | Eicher Tractor Connecting Link Assy.(312 Hyd)      | 201   | 87089900 | 18% |
| 93321083 | Eicher Tractor Spacer (Acc.Mech)                   | 30    | 73182100 | 18% |
| 93321113 | Eicher Tractor Pedal Shaft 312 Nf                  | 1672  | 87084000 | 18% |
| 93321174 | Eicher Tractor Bumper Mtg. Bkt.(30 Hp Hyd.)        | 4714  | 87081010 | 18% |
| 93321198 | Eicher Tractor Fulcrum Pin(312 Hyd)                | 52    | 87089900 | 18% |
| 93321204 | Eicher Tractor Steering Rod Assy (30 Hp Hyd.)      | 1178  | 87089400 | 18% |
| 93321216 | Eicher Tractor Fork & Guide Assly                  | 1505  | 87089900 | 18% |
| 93321228 | Eicher Tractor Spindle & Guide Assly               | 2299  | 87089900 | 18% |
| 93321265 | Eicher Tractor Spacer (Stg. Gear Support)          | 1892  | 73182100 | 18% |
| 93321289 | Eicher Tractor Plate 278                           | 32    | 83100090 | 18% |
| 93321319 | Eicher Tractor Front Bumper Assly                  | 10744 | 87081010 | 18% |
| 93321344 | Eicher Tractor Hand Break Assy.                    | 675   | 87083000 | 18% |
| 93321356 | Eicher Tractor Dashboard (Jbm)                     | 317   | 87089900 | 18% |
| 93321370 | Eicher Tractor Sticker Parking Brake               | 4     | 39199090 | 18% |
| 93321381 | Eicher Tractor Sticker For Diff Lock               | 18    | 39199090 | 18% |
| 93321393 | Eicher Tractor Mudguard Red 278                    | 20    | 39199090 | 18% |
| 93321423 | Eicher Tractor Back Rest Rt.                       | 1193  | 87089900 | 18% |
| 93321435 | Eicher Tractor Wheel Nut M-16X1.5,6H,              | 37    | 73181500 | 18% |
| 93321460 | Eicher Tractor Lower Bkt 242                       | 3513  | 87089900 | 18% |
| 93321502 | Eicher Tractor Dash Board (Rsm)-241                | 668   | 87089900 | 18% |
| 93321540 | Eicher Tractor Chain Assy - 241                    | 1152  | 87089900 | 18% |
| 93321599 | Eicher Tractor Over Flow Pipe Assy. (Fip To 'T' As | 343   | 87089900 | 18% |
| 93321733 | Eicher Tractor Dash Board                          | 656   | 87089900 | 18% |
| 93321745 | Eicher Tractor Brake Pedal Right                   | 1150  | 87083000 | 18% |
| 93321782 | Eicher Tractor T- Hose Assly                       | 171   | 40093100 | 18% |
| 93321794 | Eicher Tractor Dash Board                          | 266   | 87089900 | 18% |
| 93321850 | Eicher Tractor Fuel Shut Off Lever (241/242 Rsm)   | 81    | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93321873 | Eicher Tractor Gasket For Silencer Mtg.            | 83    | 68129090 | 18% |
| 93321927 | Eicher Tractor Fork                                | 481   | 87084000 | 18% |
| 93321990 | Eicher Tractor Grommet- Fuel Tank                  | 42    | 87089900 | 18% |
| 93322003 | Eicher Tractor P Clamp                             | 11    | 87084000 | 18% |
| 93322014 | Eicher Tractor Cap - Tank Unit                     | 10    | 87089900 | 18% |
| 93322038 | Eicher Tractor Swivel Spacer Clip                  | 21    | 85118000 | 28% |
| 93322040 | Eicher Tractor Gasket-2Mm (Flywheel Housing)       | 481   | 68129090 | 18% |
| 93322051 | Eicher Tractor Gasket - 2Mm ( Engine - Fwh) - 5660 | 411   | 84099990 | 28% |
| 93322063 | Eicher Tractor Hssc Grub Screw M10                 | 31    | 73181500 | 18% |
| 93322099 | Eicher Tractor Harness Cover Assly                 | 212   | 85123010 | 18% |
| 93322117 | Eicher Tractor Swivel Clip - 10-14 Mm              | 16    | 73182910 | 18% |
| 93322130 | Eicher Tractor Foot Board Lt (Hydromatic)          | 1214  | 87089900 | 18% |
| 93322142 | Eicher Tractor Foot Board Rt                       | 1031  | 87089900 | 18% |
| 93322191 | Eicher Tractor Gasket (Engine-Flywheel)-1.0Mm,Grad | 473   | 84099941 | 28% |
| 93322282 | Eicher Tractor Support Bracket Lt                  | 495   | 87089900 | 18% |
| 93322294 | Eicher Tractor Support Bracket Rt                  | 495   | 87089900 | 18% |
| 93322336 | Eicher Tractor Wow Logo Sticker                    | 18    | 39199090 | 18% |
| 93322348 | Eicher Tractor Fuel Tank Cover Assly               | 4255  | 87089900 | 18% |
| 93322373 | Eicher Tractor Dual Clutch Sticker                 | 10    | 39199090 | 18% |
| 93322385 | Eicher Tractor Self Locking Beading                | 163   | 87089900 | 18% |
| 93322555 | Eicher Tractor Steering Cover                      | 738   | 87089900 | 18% |
| 93322592 | Eicher Tractor Cushioning Pad                      | 114   | 40169990 | 18% |
| 93322646 | Eicher Tractor Foam Bonnet Gap                     | 32    | 39219099 | 18% |
| 93322658 | Eicher Tractor Grommet-Fuel Tank                   | 46    | 87089900 | 18% |
| 93322660 | Eicher Tractor Steering Bellow - Small             | 73    | 40169320 | 18% |
| 93322671 | Eicher Tractor Steering Bellow - Big               | 85    | 40169320 | 18% |
| 93322683 | Eicher Tractor Hand Accelerator Grommet            | 23    | 40169990 | 18% |
| 93322695 | Eicher Tractor Tank Cover Support (Lt)             | 261   | 87089900 | 18% |
| 93322701 | Eicher Tractor Tank Cover Support Right            | 261   | 87089900 | 18% |
| 93322749 | Eicher Tractor Dashbaord (Rsm)                     | 494   | 87089900 | 18% |
| 93322762 | Eicher Tractor Battery Cover 242                   | 504   | 85079090 | 28% |
| 93322774 | Eicher Tractor Battery Box Assy 242                | 2001  | 85079090 | 28% |
| 93322786 | Eicher Tractor Cover                               | 139   | 87084000 | 18% |
| 93322798 | Eicher Tractor Foot Board Right 242                | 1018  | 87089900 | 18% |
| 93322816 | Eicher Tractor Silencer Assembly                   | 3409  | 87089200 | 18% |
| 93322828 | Eicher Tractor Cover- Front (Coupling Shaft)       | 2152  | 87084000 | 18% |
| 93322830 | Eicher Tractor Cover- Support (Coupling Shaft)     | 132   | 87089900 | 18% |
| 93322841 | Eicher Tractor Cover- Rear (Coupling Shaft)        | 1246  | 87084000 | 18% |
| 93322853 | Eicher Tractor Mtg Bkt-Rear Cover (Coupling Shaft) | 300   | 87089900 | 18% |
| 93322889 | Eicher Tractor Front Wheel Rim W8X24               | 12296 | 87087000 | 18% |
| 93322992 | Eicher Tractor Dry Air Cleaner Mtg. Brkt.-4Wd      | 2732  | 87089900 | 18% |
| 93323213 | Eicher Tractor Stud (Fas)                          | 144   | 73182100 | 18% |
| 93323225 | Eicher Tractor Stud (Fas)                          | 170   | 73182100 | 18% |
| 93323286 | Eicher Tractor Self Locking Push On Washer 5Mm Ara | 8     | 87089900 | 18% |
| 93323316 | Eicher Tractor Knob- Accelerator                   | 52    | 87084000 | 18% |
| 93323328 | Eicher Tractor Hand Brake Lever Assy               | 912   | 87083000 | 18% |
| 93323365 | Eicher Tractor Hand Brake Lever Assy               | 726   | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93323389 | Eicher Tractor Pto Lever Assy                      | 786   | 87084000 | 18% |
| 93323419 | Eicher Tractor Knob Hi/Low                         | 163   | 87084000 | 18% |
| 93323420 | Eicher Tractor Knob Main Gear                      | 163   | 87084000 | 18% |
| 93323444 | Eicher Tractor Knob- Main Gear                     | 90    | 87084000 | 18% |
| 93323456 | Eicher Tractor Knob- Hi/Low                        | 90    | 87084000 | 18% |
| 93323500 | Eicher Tractor Power Steering Gear Kit-Zf          | 35591 | 87089400 | 18% |
| 93323535 | Eicher Tractor Drag Link Assy.                     | 1681  | 87089400 | 18% |
| 93323547 | Eicher Tractor Steering Gear Support (Zf)          | 1908  | 87089400 | 18% |
| 93323584 | Eicher Tractor Front Grill Strip                   | 149   | 87089900 | 18% |
| 93323651 | Eicher Tractor Front Grill (Bonnet)                | 615   | 87089900 | 18% |
| 93323778 | Eicher Tractor Adopter Plate                       | 1260  | 87085000 | 18% |
| 93323780 | Eicher Tractor Battery Box Assy 241                | 2270  | 85079090 | 28% |
| 93323791 | Eicher Tractor Footboard Right 241                 | 1346  | 87089900 | 18% |
| 93323810 | Eicher Tractor Front Axle Support                  | 9736  | 87089900 | 18% |
| 93323821 | Eicher Tractor Sleeve                              | 257   | 87089900 | 18% |
| 93323833 | Eicher Tractor Center Pin                          | 672   | 73182400 | 18% |
| 93323845 | Eicher Tractor Wheel Rim W8X24 Top Coat Orange-Knp | 11729 | 87087000 | 18% |
| 93323857 | Eicher Tractor Grease Nipple                       | 13    | 87089900 | 18% |
| 93323882 | Eicher Tractor Wheel (Bolted) White                | 17668 | 73181500 | 18% |
| 93323894 | Eicher Tractor Welded (W11X28) Rim                 | 15123 | 87087000 | 18% |
| 93324000 | Eicher Tractor Tool Box Assy (Metal)               | 2565  | 87089900 | 18% |
| 93324023 | Eicher Tractor Fender Mtg Bkt Rt                   | 1150  | 87089900 | 18% |
| 93324035 | Eicher Tractor Fender Mtg Bkt Lt                   | 1150  | 87089900 | 18% |
| 93324126 | Eicher Tractor Driver Seat                         | 7509  | 94012000 | 18% |
| 93324187 | Eicher Tractor Shield For Fuel Tank (Lt.)          | 272   | 87089900 | 18% |
| 93324199 | Eicher Tractor Shield For Fuel Tank (Rt.)          | 328   | 87089900 | 18% |
| 93324205 | Eicher Tractor Shield For Fuel Tank (Centre)       | 372   | 87089900 | 18% |
| 93324217 | Eicher Tractor Mounting Bracket Hsrp-Front         | 39    | 87089900 | 18% |
| 93324242 | Eicher Tractor Bonnet Bumper                       | 6374  | 87081010 | 18% |
| 93324278 | Eicher Tractor Rubber Beading For Fuel Tank Shield | 28    | 40169320 | 18% |
| 93324357 | Eicher Tractor Rear Wheel Rim W11*28 (Welded)Tsa S | 19141 | 87087000 | 18% |
| 93324679 | Eicher Tractor Mounting Bracket Hsrp -Front (188)  | 39    | 87089900 | 18% |
| 93324886 | Eicher Tractor Grill Front (188)                   | 572   | 87089900 | 18% |
| 93324898 | Eicher Tractor Grill Front (Jbm)                   | 824   | 87089900 | 18% |
| 93324904 | Eicher Tractor Grill Front (557)                   | 696   | 87089900 | 18% |
| 93325155 | Eicher Tractor Mounting Bracket Hsrp - Front       | 55    | 87089900 | 18% |
| 93325167 | Eicher Tractor Relay Lever                         | 98    | 87089900 | 18% |
| 93325519 | Eicher Tractor Cable Tie 150Mm (Black)             | 2     | 87089900 | 18% |
| 93325570 | Eicher Tractor Hose (Clb)                          | 827   | 40093100 | 18% |
| 93325623 | Eicher Tractor Tool Kit Assy.(South)               | 1625  | 82060090 | 18% |
| 93325635 | Eicher Tractor Tool Kit Assy.(North)               | 1545  | 82060090 | 18% |
| 93325647 | Eicher Tractor Tool Kit Assy.(188)                 | 1457  | 82060090 | 18% |
| 93325763 | Eicher Tractor Front Axle Support                  | 12487 | 87089900 | 18% |
| 93325878 | Eicher Tractor Torsion Spring                      | 14    | 85123010 | 18% |
| 93325880 | Eicher Tractor Woodruff Key 8X11                   | 36    | 73182100 | 18% |
| 93325891 | Eicher Tractor Firewall Assy                       | 1690  | 87089900 | 18% |
| 93325910 | Eicher Tractor Mirror Assy                         | 1107  | 70091090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93326147 | Eicher Tractor Brake Pedal Left                    | 1442  | 87083000 | 18% |
| 93326159 | Eicher Tractor Brake Pedal Right                   | 1259  | 87083000 | 18% |
| 93326202 | Eicher Tractor Gasket (Inspection Cover)           | 54    | 68129090 | 18% |
| 93326214 | Eicher Tractor Clutch Pedal                        | 1605  | 87089300 | 18% |
| 93326330 | Eicher Tractor Silencer Assy With Guard (380)      | 5237  | 87089200 | 18% |
| 93326366 | Eicher Tractor Lower Link                          | 3272  | 87089900 | 18% |
| 93326378 | Eicher Tractor Lower Link Assy Left                | 4925  | 87089900 | 18% |
| 93326391 | Eicher Tractor Lower Link Assy Right               | 4925  | 87089900 | 18% |
| 93326410 | Eicher Tractor Lower Link Assly Rt.                | 3817  | 87089900 | 18% |
| 93326433 | Eicher Tractor Lower Link Assly Lt.                | 3817  | 87089900 | 18% |
| 93326457 | Eicher Tractor Lower Link Assy Left 368            | 4342  | 87089900 | 18% |
| 93326469 | Eicher Tractor Lower Link Assy Right 368           | 4342  | 87089900 | 18% |
| 93326470 | Eicher Tractor Lower Link Assly Lt.                | 4325  | 87089900 | 18% |
| 93326482 | Eicher Tractor Lower Link Assly Rt.                | 4294  | 87089900 | 18% |
| 93326494 | Eicher Tractor Lower Link Assy.                    | 3229  | 87089900 | 18% |
| 93326524 | Eicher Tractor Lower Link Assly Lt.                | 3870  | 87089900 | 18% |
| 93326639 | Eicher Tractor Gasket 24-Hp (Exhaust Tube Mtg.)    | 119   | 74152900 | 18% |
| 93326640 | Eicher Tractor Upper Link Assy                     | 2744  | 87089900 | 18% |
| 93326664 | Eicher Tractor Upper Link Assy                     | 3114  | 87089900 | 18% |
| 93326755 | Eicher Tractor Gasket - Brake Pedal Cover (2 Holes | 8     | 87083000 | 18% |
| 93326913 | Eicher Tractor Flywheel Housing                    | 26930 | 87084000 | 18% |
| 93326962 | Eicher Tractor Rod (Accelerator)                   | 179   | 87084000 | 18% |
| 93327140 | Eicher Tractor Connecting Link                     | 264   | 87089900 | 18% |
| 93327180 | Eicher Tractor Silencer Assy T4-650                | 6258  | 87089200 | 18% |
| 93327528 | Eicher Tractor Cover                               | 138   | 84129090 | 18% |
| 93327541 | Eicher Tractor Clutch Pedal                        | 988   | 87089300 | 18% |
| 93327589 | Eicher Tractor Steering Cylinder 380/480/333       | 14155 | 87089400 | 18% |
| 93327590 | Eicher Tractor Steering Cylinder 551/5660          | 14239 | 87089400 | 18% |
| 93328053 | Eicher Tractor Front Rim-4.5E X 16 Top Coat Silver | 4754  | 87087000 | 18% |
| 93328065 | Eicher Tractor Front Wheel Rim 4.5X16 Tsa -White   | 4511  | 87087000 | 18% |
| 93328259 | Eicher Tractor Exhaust Tube                        | 1971  | 87089900 | 18% |
| 93328508 | Eicher Tractor Back Rest Right Assy.               | 2082  | 87089900 | 18% |
| 93328510 | Eicher Tractor Back Rest Right Assy.               | 1944  | 87089900 | 18% |
| 93328594 | Eicher Tractor Pedal Shaft                         | 2210  | 87084000 | 18% |
| 93328600 | Eicher Tractor Pedal Shaft                         | 2971  | 87084000 | 18% |
| 93328612 | Eicher Tractor Coupling Mouth                      | 7220  | 87089900 | 18% |
| 93330230 | Eicher Tractor Bracket Assy Lower                  | 366   | 87089900 | 18% |
| 93330280 | Eicher Tractor Fuel Tank Sticker Lh                | 190   | 39199090 | 18% |
| 93330291 | Eicher Tractor Fuel Tank Sticker Rh                | 222   | 39199090 | 18% |
| 93330308 | Eicher Tractor Name Plate Eicher 312 Lh            | 883   | 39199090 | 18% |
| 93330310 | Eicher Tractor Name Plate Eicher 312 Rh            | 798   | 39199090 | 18% |
| 93330345 | Eicher Tractor Mudguard Graphics "312"             | 100   | 39199090 | 18% |
| 93330357 | Eicher Tractor Paddy Sticker                       | 140   | 39199090 | 18% |
| 93330436 | Eicher Tractor Steering Arm                        | 1495  | 87089400 | 18% |
| 93330588 | Eicher Tractor Tool Box Assy 241/242               | 400   | 87089900 | 18% |
| 93330760 | Eicher Tractor Tension Tie Assy                    | 176   | 87083000 | 18% |
| 93331104 | Eicher Tractor Bonnet Graphics Lt. Top (368 Red)   | 1443  | 39199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93331141 | Eicher Tractor Bonnet Graphics Top Lt. (Blue)      | 1301  | 39199090 | 18% |
| 93331383 | Eicher Tractor Coupling Shaft Assly                | 1101  | 87084000 | 18% |
| 93331568 | Eicher Tractor Fork & Guide Assembly               | 1580  | 87089900 | 18% |
| 93331573 | Eicher Tractor Spindle And Guide Assembly          | 1283  | 87089900 | 18% |
| 93331581 | Eicher Tractor Spindle And Guide Assembly          | 1375  | 87089900 | 18% |
| 93331593 | Eicher Tractor Fork And Guide Assembly             | 1391  | 87089900 | 18% |
| 93331635 | Eicher Tractor Battery Mounting Bracket            | 650   | 85079090 | 28% |
| 93332044 | Eicher Tractor Lower Link Bracket Lt.              | 1123  | 87084000 | 18% |
| 93332287 | Eicher Tractor Decal Bonnet Left - Red             | 658   | 39199090 | 18% |
| 93332299 | Eicher Tractor Decal Bonnet Right - Red            | 659   | 39199090 | 18% |
| 93332317 | Eicher Tractor Bonnet Graphics Top Right-Blue(Thin | 650   | 39199090 | 18% |
| 93332326 | Eicher Tractor Bonnet Graphics Bottom Lt. (Red)    | 424   | 39199090 | 18% |
| 93332378 | Eicher Tractor Bonnet Graphics Bottom Rt. (Red)    | 340   | 39199090 | 18% |
| 93332391 | Eicher Tractor Bonnet Graphics Bottom Rt. (Blue)   | 341   | 39199090 | 18% |
| 93332408 | Eicher Tractor Steering Gear Support               | 1451  | 87089400 | 18% |
| 93332410 | Eicher Tractor Front Axle Support                  | 10051 | 87089900 | 18% |
| 93332421 | Eicher Tractor Strut                               | 90    | 87089400 | 18% |
| 93332470 | Eicher Tractor Spacer                              | 259   | 73182100 | 18% |
| 93332500 | Eicher Tractor Flywheel Housing 333 M/C            | 28377 | 87084000 | 18% |
| 93332550 | Eicher Tractor Bonnet Graphics Lt.                 | 578   | 39199090 | 18% |
| 93332561 | Eicher Tractor Bonnet Graphics Rt.                 | 578   | 39199090 | 18% |
| 93332585 | Eicher Tractor Bonnet Graphics Bottom Lt. (Blue)-3 | 444   | 39199090 | 18% |
| 93332597 | Eicher Tractor Bonnet Graphics Bottom Rt. (Blue)-3 | 340   | 39199090 | 18% |
| 93332652 | Eicher Tractor Front Axle Assy                     | 10360 | 87085000 | 18% |
| 93332809 | Eicher Tractor Foot Board Right                    | 901   | 87089900 | 18% |
| 93332810 | Eicher Tractor Brake Pedal Rt                      | 849   | 87083000 | 18% |
| 93332834 | Eicher Tractor Foot Board Right                    | 865   | 87089900 | 18% |
| 93332858 | Eicher Tractor Mudguard Red Sticker -333           | 73    | 39199090 | 18% |
| 93332860 | Eicher Tractor Mudguard Red Sticker -312           | 62    | 39199090 | 18% |
| 93332871 | Eicher Tractor Mudguard Graphic - 364              | 50    | 39199090 | 18% |
| 93332974 | Eicher Tractor Link Brake                          | 69    | 87083000 | 18% |
| 93333190 | Eicher Tractor Spacer                              | 50    | 73182100 | 18% |
| 93333206 | Eicher Tractor Fulcrum Pin                         | 57    | 87089900 | 18% |
| 93333528 | Eicher Tractor Pin For Clutch                      | 58    | 87089300 | 18% |
| 93333541 | Eicher Tractor Clutch Pedal Assy                   | 1289  | 87089300 | 18% |
| 93333577 | Eicher Tractor Lower Link Assy Left                | 3230  | 87089900 | 18% |
| 93333589 | Eicher Tractor Lower Link Assy Right               | 3230  | 87089900 | 18% |
| 93333656 | Eicher Tractor Lower Link Assly Lt.                | 4019  | 87089900 | 18% |
| 93333668 | Eicher Tractor Lower Link Assly Rt.                | 4463  | 87089900 | 18% |
| 93333693 | Eicher Tractor Plate 333                           | 106   | 83100090 | 18% |
| 93333700 | Eicher Tractor Plate 368                           | 103   | 83100090 | 18% |
| 93333772 | Eicher Tractor Washer                              | 9     | 73182100 | 18% |
| 93333838 | Eicher Tractor Front Logo                          | 145   | 39199090 | 18% |
| 93333905 | Eicher Tractor Lower Link Bracket Lt.              | 1122  | 87089900 | 18% |
| 93333917 | Eicher Tractor Lower Link Bracket Rt.              | 1119  | 87089900 | 18% |
| 93334016 | Eicher Tractor D D Seat(Smv)-368/485/380/480       | 5242  | 94012000 | 18% |
| 93334041 | Eicher Tractor Sticker Hydromatic Nt               | 25    | 39199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93334156 | Eicher Tractor Air Cleaner Support Bracket         | 408   | 84099941 | 28% |
| 93334181 | Eicher Tractor Bracket (For Air Cleaner Mtg.)      | 1011  | 84099941 | 28% |
| 93334259 | Eicher Tractor Return Pipe Assy                    | 181   | 87089900 | 18% |
| 93334399 | Eicher Tractor Wheel W12 (13.6X28 Tyre)            | 10833 | 87087000 | 18% |
| 93334510 | Eicher Tractor Stub Axle -(South)                  | 3001  | 87085000 | 18% |
| 93334600 | Eicher Tractor Front Logo                          | 349   | 39199090 | 18% |
| 93334612 | Eicher Tractor Emblem 43Mm                         | 32    | 39199090 | 18% |
| 93334624 | Eicher Tractor Emblem 59Mm                         | 45    | 39199090 | 18% |
| 93334648 | Eicher Tractor Lever - Fuel Shut Off               | 82    | 84099941 | 28% |
| 93334650 | Eicher Tractor Knob -Fule Shut Off                 | 34    | 87084000 | 18% |
| 93334676 | Eicher Tractor Hub (South)                         | 2238  | 87085000 | 18% |
| 93334703 | Eicher Tractor Bush With Guard                     | 435   | 87089900 | 18% |
| 93334752 | Eicher Tractor Brake Link                          | 180   | 87083000 | 18% |
| 93334818 | Eicher Tractor Foot Acc Pedal Assy 5660 Ps         | 201   | 87089900 | 18% |
| 93334867 | Eicher Tractor Mudguard Support (Common )          | 479   | 87089900 | 18% |
| 93334879 | Eicher Tractor Battery Cover                       | 586   | 85079090 | 28% |
| 93334880 | Eicher Tractor Rubber Pad....                      | 65    | 40169990 | 18% |
| 93335124 | Eicher Tractor Lower Link Assy Left                | 3008  | 87089900 | 18% |
| 93335136 | Eicher Tractor Lower Link Assy Right               | 3008  | 87089900 | 18% |
| 93335161 | Eicher Tractor Woodruff Key 8X11                   | 25    | 73182100 | 18% |
| 93335203 | Eicher Tractor Steering Gear Assy.(Zf)Modified     | 11980 | 87089400 | 18% |
| 93335215 | Eicher Tractor Steering Assy (831)                 | 9440  | 87089400 | 18% |
| 93335227 | Eicher Tractor Steering Unit (Zf)                  | 12960 | 87089400 | 18% |
| 93335239 | Eicher Tractor Steering Arm-Zf                     | 1323  | 87089400 | 18% |
| 93335240 | Eicher Tractor Steering Drop Arm (834)             | 1344  | 87089400 | 18% |
| 93335252 | Eicher Tractor Steering Arm 364 (836)              | 1262  | 87089400 | 18% |
| 93335288 | Eicher Tractor Strut Stabliser Assy                | 2703  | 87089900 | 18% |
| 93335290 | Eicher Tractor Pin Assy                            | 137   | 73182100 | 18% |
| 93335392 | Eicher Tractor Rear Rim W12 Top Coat Off Wht Knp13 | 8678  | 87087000 | 18% |
| 93335409 | Eicher Tractor Rear Rim W12 Top Coat Silver Knp 13 | 12742 | 87087000 | 18% |
| 93335410 | Eicher Tractor Rear Rim W12 Top Coat Off Wht Knp14 | 12531 | 87087000 | 18% |
| 93335422 | Eicher Tractor Rear Rim W12 Top Coat Silver Knp 14 | 12731 | 87087000 | 18% |
| 93335458 | Eicher Tractor Rear Rim W12 Top Coat Off Wht Knp13 | 12465 | 87087000 | 18% |
| 93335460 | Eicher Tractor Rear Rim W12 Top Coat Silver Knp 13 | 12770 | 87087000 | 18% |
| 93335653 | Eicher Tractor Rear Wheel Rim W12 (14.9X28)        | 21459 | 87087000 | 18% |
| 93335665 | Eicher Tractor Rear Wheel W12 -Off White           | 17249 | 87087000 | 18% |
| 93335677 | Eicher Tractor Metal Fuel Tank                     | 7382  | 87089900 | 18% |
| 93335689 | Eicher Tractor Fuel Tank Mtg Bracket               | 1425  | 87089900 | 18% |
| 93335690 | Eicher Tractor Main Mounting Bracket               | 1409  | 87089900 | 18% |
| 93335707 | Eicher Tractor Rubber Pad                          | 20    | 40169990 | 18% |
| 93335720 | Eicher Tractor Clamping Bracket                    | 50    | 87089900 | 18% |
| 93335732 | Eicher Tractor P Clamp (Clamping Bracket)          | 21    | 87089900 | 18% |
| 93335756 | Eicher Tractor Rubber Flap                         | 87    | 40169320 | 18% |
| 93335770 | Eicher Tractor Front End Assy                      | 20488 | 87085000 | 18% |
| 93335781 | Eicher Tractor Front Axle Assy                     | 6810  | 87085000 | 18% |
| 93335793 | Eicher Tractor Center Pin Sleeve Bush (Ø22XØ26X35) | 124   | 72072030 | 18% |
| 93335800 | Eicher Tractor King Pin Bush (Ø25XØ29X48)          | 185   | 72072030 | 18% |





|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93335811 | Eicher Tractor Oil Seal 22X32X7                   | 66   | 40169330 | 18% |
| 93335823 | Eicher Tractor Felt Ring 22X32X5                  | 12   | 59113120 | 18% |
| 93335835 | Eicher Tractor Front Axle Support                 | 5232 | 87089900 | 18% |
| 93335847 | Eicher Tractor Thrust Washer                      | 69   | 73182100 | 18% |
| 93335859 | Eicher Tractor Shim (King Pin)                    | 4    | 73182100 | 18% |
| 93335860 | Eicher Tractor Shim 0.3Mm                         | 7    | 87089900 | 18% |
| 93335872 | Eicher Tractor Shim 0.2Mm                         | 6    | 87089900 | 18% |
| 93335884 | Eicher Tractor Sleeve (Center Pin)                | 110  | 87089900 | 18% |
| 93335896 | Eicher Tractor Centre Pin                         | 381  | 87085000 | 18% |
| 93335902 | Eicher Tractor Thrust Washer (King Pin)           | 211  | 73182100 | 18% |
| 93335914 | Eicher Tractor Oil Seals 36X56X8                  | 128  | 40169330 | 18% |
| 93335926 | Eicher Tractor Felt Ring 25X29X5                  | 19   | 59113120 | 18% |
| 93335938 | Eicher Tractor Stub Axle Lt                       | 2348 | 87085000 | 18% |
| 93335963 | Eicher Tractor Dust Shild (Front Wheel Hub)       | 109  | 40169990 | 18% |
| 93335975 | Eicher Tractor Stub Axle Rt                       | 2348 | 87085000 | 18% |
| 93335987 | Eicher Tractor V Ring V-36A                       | 37   | 40169990 | 18% |
| 93335999 | Eicher Tractor Oil Seals 32X56X10                 | 94   | 40169330 | 18% |
| 93336001 | Eicher Tractor Spacer Inner Bearing               | 73   | 84821020 | 18% |
| 93336013 | Eicher Tractor Taper Roller Brg (30205)           | 578  | 84822000 | 18% |
| 93336025 | Eicher Tractor Front Wheel Hub                    | 1351 | 87087000 | 18% |
| 93336037 | Eicher Tractor Taper Roller Brg (30204)           | 538  | 84822000 | 18% |
| 93336049 | Eicher Tractor Outer Bearing Retainer             | 73   | 84099941 | 28% |
| 93336050 | Eicher Tractor Slotted Nut M18X1.5                | 65   | 73181500 | 18% |
| 93336074 | Eicher Tractor Hub Cap                            | 180  | 87085000 | 18% |
| 93336086 | Eicher Tractor Steering Lever Double Left         | 2090 | 87089400 | 18% |
| 93336098 | Eicher Tractor Steering Lever Single Right        | 1627 | 87089400 | 18% |
| 93336104 | Eicher Tractor Woodruff Key 1/4' X 1'1/4'         | 41   | 73182990 | 18% |
| 93336128 | Eicher Tractor Tie Rod Assy                       | 1516 | 87089400 | 18% |
| 93336130 | Eicher Tractor Drag Link                          | 1587 | 87089400 | 18% |
| 93336141 | Eicher Tractor Lower Link Mounting Bracket (Left) | 1233 | 87089900 | 18% |
| 93336153 | Eicher Tractor Bkt (Coupling Mouth)               | 4421 | 87089900 | 18% |
| 93336165 | Eicher Tractor Lower Link Assy                    | 1960 | 87089900 | 18% |
| 93336177 | Eicher Tractor Chain Assy                         | 778  | 87089900 | 18% |
| 93336190 | Eicher Tractor Pin(Lift Arm)                      | 94   | 87089900 | 18% |
| 93336207 | Eicher Tractor Pin (Chain Assy)                   | 84   | 87089900 | 18% |
| 93336219 | Eicher Tractor Lift Arm Assy                      | 1241 | 87089900 | 18% |
| 93336223 | Eicher Tractor Fork And Guide Assy                | 1027 | 87089900 | 18% |
| 93336232 | Eicher Tractor Lifting Gear Assy                  | 1172 | 87089900 | 18% |
| 93336244 | Eicher Tractor Upper Fork                         | 610  | 87089900 | 18% |
| 93336268 | Eicher Tractor Lower Fork                         | 650  | 87089900 | 18% |
| 93336270 | Eicher Tractor Coupling Mouth                     | 2446 | 87089900 | 18% |
| 93336359 | Eicher Tractor Clutch Pedal Assy.                 | 523  | 87081010 | 18% |
| 93336440 | Eicher Tractor Back Cover                         | 126  | 87081010 | 18% |
| 93336451 | Eicher Tractor Side Stiffener (Bottom)            | 260  | 87089900 | 18% |
| 93336517 | Eicher Tractor Rubber Pad Front (Bonnet)          | 46   | 40169990 | 18% |
| 93336542 | Eicher Tractor Hinge Isolator                     | 28   | 87089900 | 18% |
| 93336554 | Eicher Tractor Bottom Rubber Pad (Fuel Tank)      | 272  | 40169990 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93336566 | Eicher Tractor Firewall Assy                   | 1667 | 87089900 | 18% |
| 93336578 | Eicher Tractor Cradle (Fuel Tank Mtg)          | 1389 | 87089900 | 18% |
| 93336580 | Eicher Tractor Fuel Tank Assy                  | 5561 | 87089900 | 18% |
| 93336645 | Eicher Tractor Brake Pedal Assy. Left          | 770  | 87081010 | 18% |
| 93336657 | Eicher Tractor Brake Pedal Assy. Right         | 769  | 87081010 | 18% |
| 93336670 | Eicher Tractor Parking Brake Assy              | 148  | 87089900 | 18% |
| 93336694 | Eicher Tractor Footboard Assy Lh               | 1816 | 87089900 | 18% |
| 93336700 | Eicher Tractor Footboard Assy Rh               | 1632 | 87089900 | 18% |
| 93336724 | Eicher Tractor Tool Box Assy (Metal)           | 834  | 87089900 | 18% |
| 93336736 | Eicher Tractor Tool Kit Assy                   | 1102 | 82060090 | 18% |
| 93336750 | Eicher Tractor Air Cleaner Mtg. Bkt.           | 273  | 87089900 | 18% |
| 93336761 | Eicher Tractor Air Cleaner Support Bkt.        | 508  | 87089900 | 18% |
| 93336876 | Eicher Tractor Air Inlet Hose                  | 350  | 40093100 | 18% |
| 93336888 | Eicher Tractor Rubber Stopper - Dd Seat        | 50   | 40169990 | 18% |
| 93336890 | Eicher Tractor Spring - Dd Seat                | 86   | 73202000 | 18% |
| 93336906 | Eicher Tractor Support Bracket Front (Fender)  | 204  | 87089900 | 18% |
| 93336943 | Eicher Tractor Aux. Valve Cover                | 1323 | 87089900 | 18% |
| 93336955 | Eicher Tractor Gasket For Silencer             | 53   | 68129090 | 18% |
| 93336979 | Eicher Tractor Center Pin                      | 705  | 73182400 | 18% |
| 93337005 | Eicher Tractor Tie Rod Assy.                   | 1754 | 87089400 | 18% |
| 93337017 | Eicher Tractor Draig Link Assy. (4Wd)          | 1988 | 87089900 | 18% |
| 93337078 | Eicher Tractor Draw Bar                        | 2118 | 87089900 | 18% |
| 93337091 | Eicher Tractor Top Link Assy                   | 2537 | 87089900 | 18% |
| 93337121 | Eicher Tractor Pin - Top Link Addc             | 238  | 87089900 | 18% |
| 93337157 | Eicher Tractor Pin - Lower Link                | 107  | 87089900 | 18% |
| 93337200 | Eicher Tractor Brake Pedal Shaft               | 967  | 87089900 | 18% |
| 93337248 | Eicher Tractor Firewall Support Bkt            | 63   | 87089900 | 18% |
| 93337250 | Eicher Tractor Clevis Pin                      | 40   | 87089900 | 18% |
| 93337261 | Eicher Tractor Lock Bkt. Parking Brake         | 220  | 87081010 | 18% |
| 93337315 | Eicher Tractor Fuel Tank Strap Assy            | 150  | 87089900 | 18% |
| 93337352 | Eicher Tractor Hand Accelerator Rod            | 204  | 87089900 | 18% |
| 93337364 | Eicher Tractor Hand Accelerator Lever          | 191  | 84099941 | 28% |
| 93337376 | Eicher Tractor Upper Link (Acc)                | 89   | 87089900 | 18% |
| 93337388 | Eicher Tractor Foot Acc Pedal Assy             | 191  | 87089900 | 18% |
| 93337390 | Eicher Tractor Accelerator Lever Left          | 56   | 87089900 | 18% |
| 93337406 | Eicher Tractor Accelerator Shaft               | 167  | 87089900 | 18% |
| 93337418 | Eicher Tractor Connecting Link (Fuel Pump)     | 79   | 87089900 | 18% |
| 93337420 | Eicher Tractor Eye Pin                         | 56   | 87089900 | 18% |
| 93337431 | Eicher Tractor Clamping Bracket                | 37   | 87089900 | 18% |
| 93337443 | Eicher Tractor Mounting Bracket (Hand Acc Rod) | 108  | 87089900 | 18% |
| 93337492 | Eicher Tractor Fuel Tank Strap Assy            | 221  | 87089900 | 18% |
| 93337522 | Eicher Tractor Fuel Pipe Assy                  | 509  | 84099941 | 28% |
| 93337558 | Eicher Tractor Upper Bracket Assly             | 254  | 87089900 | 18% |
| 93337625 | Eicher Tractor Tension Tie Assy                | 127  | 87089900 | 18% |
| 93337637 | Eicher Tractor Tension Tie Assy                | 145  | 87089900 | 18% |
| 93337674 | Eicher Tractor Cover (Wiring Harness)          | 99   | 87089900 | 18% |
| 93337704 | Eicher Tractor Steering Bracket (Ps)           | 1349 | 87089400 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93337716 | Eicher Tractor Bottom Rubber Pad (Big)             | 53    | 40169320 | 18% |
| 93337728 | Eicher Tractor Cassette Seal-45X72.2X12            | 507   | 40169330 | 18% |
| 93337730 | Eicher Tractor Stub Axle - South                   | 3648  | 87085000 | 18% |
| 93337856 | Eicher Tractor Fuel Shut Off Lever                 | 96    | 87089900 | 18% |
| 93337868 | Eicher Tractor Heat Shield                         | 73    | 87089900 | 18% |
| 93337870 | Eicher Tractor Bottom Rubber Pad (Small)           | 33    | 40169320 | 18% |
| 93337881 | Eicher Tractor Propeller Shaft Cover               | 475   | 87084000 | 18% |
| 93337893 | Eicher Tractor Uj Cover Upper Front                | 312   | 87084000 | 18% |
| 93337900 | Eicher Tractor Uj Cover Lower Front                | 312   | 87084000 | 18% |
| 93337911 | Eicher Tractor Uj Cover Rear                       | 297   | 87084000 | 18% |
| 93337923 | Eicher Tractor Rubber Bush (Cover)                 | 35    | 40169320 | 18% |
| 93338009 | Eicher Tractor Fuel Pipe Assy (Ft To Ws/Ffp)-380   | 481   | 84099941 | 28% |
| 93338010 | Eicher Tractor Fuel Shut Off Lever- 380            | 92    | 87089900 | 18% |
| 93338046 | Eicher Tractor Fuel Shut Off Lever - Ps            | 99    | 87089900 | 18% |
| 93338060 | Eicher Tractor Sediment Bowl(For Fuel Tank)        | 546   | 84099941 | 28% |
| 93338071 | Eicher Tractor Drain Plug (M12X1.5)                | 37    | 87084000 | 18% |
| 93338095 | Eicher Tractor Fuel Pipe Assy (Fuel Tank To Feed P | 280   | 87089900 | 18% |
| 93338101 | Eicher Tractor Fuel Pipe Assy (Feed Pump To Filter | 307   | 84219900 | 18% |
| 93338174 | Eicher Tractor Clamping Brkt For Fuel Tank         | 26    | 73182990 | 18% |
| 93338204 | Eicher Tractor Filter Mtg Brkt                     | 169   | 84219900 | 18% |
| 93338228 | Eicher Tractor Front Grill                         | 441   | 87089900 | 18% |
| 93338230 | Eicher Tractor Side Grill                          | 313   | 87089900 | 18% |
| 93338241 | Eicher Tractor Head Light Bazel                    | 767   | 85122010 | 18% |
| 93338253 | Eicher Tractor Side Stiffener (Bottom)             | 166   | 87089900 | 18% |
| 93338265 | Eicher Tractor Rubber Pad Bottom (Stiffener)       | 20    | 40169990 | 18% |
| 93338290 | Eicher Tractor Rubber Pad Right (Bonnet)           | 28    | 40169990 | 18% |
| 93338393 | Eicher Tractor Lower Link Assy. 50 Hp Hyd.         | 5462  | 87089900 | 18% |
| 93338526 | Eicher Tractor Lifting Gear Mechanism              | 4274  | 87089900 | 18% |
| 93338538 | Eicher Tractor Fork And Guide Assy                 | 2784  | 87089900 | 18% |
| 93338563 | Eicher Tractor Back Cover                          | 107   | 87089900 | 18% |
| 93338655 | Eicher Tractor Fork & Guide Mechanism              | 2694  | 87089900 | 18% |
| 93338658 | Eicher Tractor Bottom Pad-Stg Column               | 157   | 40169990 | 18% |
| 93338692 | Eicher Tractor Fuse Box Mtg Plate                  | 110   | 85369090 | 18% |
| 93338897 | Eicher Tractor Sticker Lt                          | 188   | 39199090 | 18% |
| 93338903 | Eicher Tractor Sticker Rt                          | 188   | 39199090 | 18% |
| 93338915 | Eicher Tractor Steering Cylinder (551)             | 13579 | 87089400 | 18% |
| 93338988 | Eicher Tractor Pedal Shaft                         | 1745  | 87084000 | 18% |
| 93338990 | Eicher Tractor Brake Pedal Assy Lt (Wdb)           | 1936  | 87083000 | 18% |
| 93339002 | Eicher Tractor Brake Pedal Right Hyd - Ddb         | 1318  | 87083000 | 18% |
| 93339014 | Eicher Tractor Brake Pedal Rt Hyd - Wdb            | 1619  | 87083000 | 18% |
| 93339026 | Eicher Tractor Cover                               | 186   | 84129090 | 18% |
| 93339105 | Eicher Tractor Bush                                | 220   | 84833000 | 18% |
| 93339117 | Eicher Tractor Clutch Pedal (Single Clutch)        | 1640  | 87089300 | 18% |
| 93339129 | Eicher Tractor Clutch Pedal (Double Clutch)        | 1652  | 87089300 | 18% |
| 93339130 | Eicher Tractor Spacer                              | 269   | 73182100 | 18% |
| 93339142 | Eicher Tractor V - Ring                            | 20    | 40169990 | 18% |
| 93339166 | Eicher Tractor Stub Axle - Lh - Ps                 | 3405  | 87085000 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93339178 | Eicher Tractor Stub Axle Right - Ps                | 3766 | 87085000 | 18% |
| 93339191 | Eicher Tractor Lower Link Mounting Bracket (Right) | 1233 | 87089900 | 18% |
| 93339282 | Eicher Tractor Lower Link Assy Lh 333/380          | 3995 | 87089900 | 18% |
| 93339294 | Eicher Tractor Lower Link Assy Rh 333/380          | 3995 | 87089900 | 18% |
| 93339300 | Eicher Tractor Lower Link Assy Left 368            | 4314 | 87089900 | 18% |
| 93339312 | Eicher Tractor Lower Link Assy Right 368           | 4334 | 87089900 | 18% |
| 93339324 | Eicher Tractor Lower Link Assy Left                | 3543 | 87089900 | 18% |
| 93339336 | Eicher Tractor Lower Link Assy Right               | 3543 | 87089900 | 18% |
| 93339348 | Eicher Tractor Pin                                 | 218  | 73182100 | 18% |
| 93339415 | Eicher Tractor Battery Tray Assy                   | 1086 | 87089900 | 18% |
| 93339427 | Eicher Tractor Calmping Latch                      | 104  | 87089900 | 18% |
| 93339439 | Eicher Tractor I-Bolt M8 (Battery)                 | 68   | 87089900 | 18% |
| 93339440 | Eicher Tractor Heat Shield (Silencer)              | 1001 | 87089900 | 18% |
| 93339452 | Eicher Tractor Silencer Support Bkt                | 153  | 87089900 | 18% |
| 93339488 | Eicher Tractor Fuel Filter                         | 823  | 84212900 | 18% |
| 93339506 | Eicher Tractor Filter Insert (Ff)                  | 254  | 84219900 | 18% |
| 93339518 | Eicher Tractor Fuel Pipe Assy (Fuel Filter To Fip) | 351  | 84219900 | 18% |
| 93339531 | Eicher Tractor Silencer Assy(With Guard)           | 4794 | 87089200 | 18% |
| 93339579 | Eicher Tractor Grommet Ø30X5Thk                    | 11   | 40169990 | 18% |
| 93339580 | Eicher Tractor Rubber Pad                          | 67   | 40169990 | 18% |
| 93339609 | Eicher Tractor Over Flow Pipe                      | 673  | 87089900 | 18% |
| 93339634 | Eicher Tractor Benjo Bolt Front-Adapter            | 66   | 73181500 | 18% |
| 93339646 | Eicher Tractor Over Flow Valve                     | 277  | 84099941 | 28% |
| 93339683 | Eicher Tractor Sticker Ft Cover Lt                 | 10   | 39199090 | 18% |
| 93339695 | Eicher Tractor Sticker Ft Cover Rt                 | 10   | 39199090 | 18% |
| 93339719 | Eicher Tractor Air Cleaner Assy                    | 2442 | 84213100 | 18% |
| 93339750 | Eicher Tractor Fuel Filter Support Bkt             | 88   | 84219900 | 18% |
| 93339828 | Eicher Tractor Brake Pedal Lt Hyd-Ddb              | 1663 | 87083000 | 18% |
| 93339919 | Eicher Tractor Mudguard Red Sticker - 330          | 51   | 39199090 | 18% |
| 93339920 | Eicher Tractor Plate 330                           | 85   | 87084000 | 18% |
| 93340041 | Eicher Tractor Wheel Cap                           | 39   | 87087000 | 18% |
| 93340077 | Eicher Tractor Head Light Panel Assy               | 1866 | 85122010 | 18% |
| 93340168 | Eicher Tractor Side Grill Left                     | 305  | 87089900 | 18% |
| 93340170 | Eicher Tractor Side Grill Right                    | 298  | 87089900 | 18% |
| 93340190 | Eicher Tractor Side Cover (Rt)                     | 29   | 87084000 | 18% |
| 93340200 | Eicher Tractor Front Grill                         | 723  | 87089900 | 18% |
| 93340340 | Eicher Tractor Main Mounting Bracket - Sdi         | 632  | 87089900 | 18% |
| 93340351 | Eicher Tractor Tank Top Support                    | 339  | 87089900 | 18% |
| 93340363 | Eicher Tractor Tank Bottom Support                 | 210  | 87089900 | 18% |
| 93340387 | Eicher Tractor Tank Cover Support Rt               | 195  | 87089900 | 18% |
| 93340466 | Eicher Tractor Hand Accelerating Rod               | 353  | 84099941 | 28% |
| 93340478 | Eicher Tractor Steering Unit (Zf)                  | 9440 | 87089400 | 18% |
| 93340533 | Eicher Tractor Hand Accelerating Lever             | 132  | 87089900 | 18% |
| 93340624 | Eicher Tractor Decal Bonnet Right                  | 574  | 39199090 | 18% |
| 93340636 | Eicher Tractor Decal Fuel Tank Lt.                 | 121  | 87089900 | 18% |
| 93340648 | Eicher Tractor Decal Fuel Tank Right               | 121  | 87089900 | 18% |
| 93340703 | Eicher Tractor Decal Bonnet Strip Right            | 394  | 39199090 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93340752 | Eicher Tractor Face Seal Cover              | 175   | 87089900 | 18% |
| 93340820 | Eicher Tractor Cap Nut                      | 85    | 73181500 | 18% |
| 93340909 | Eicher Tractor Lock Left                    | 228   | 83012000 | 18% |
| 93340910 | Eicher Tractor Lock Right                   | 203   | 83012000 | 18% |
| 93341689 | Eicher Tractor Pin                          | 468   | 73182100 | 18% |
| 93341707 | Eicher Tractor Chain Assy Left              | 697   | 87089900 | 18% |
| 93341719 | Eicher Tractor Chain Assy Right             | 649   | 87089900 | 18% |
| 93341770 | Eicher Tractor Top Link Assy                | 2562  | 87089900 | 18% |
| 93341800 | Eicher Tractor Lower Link Assy Right - Ve   | 1272  | 87089900 | 18% |
| 93341940 | Eicher Tractor Steering Gear Support        | 1619  | 87089400 | 18% |
| 93342025 | Eicher Tractor Main Mounting Bracket -Wc    | 602   | 87089900 | 18% |
| 93342130 | Eicher Tractor Foot Step                    | 707   | 87089900 | 18% |
| 93342141 | Eicher Tractor Mtg. Plate Left-Foot Step    | 198   | 87089900 | 18% |
| 93342359 | Eicher Tractor Chain Mounting Bracket Rt.   | 321   | 87089900 | 18% |
| 93342426 | Eicher Tractor Pin                          | 96    | 73182100 | 18% |
| 93342438 | Eicher Tractor Linch Pin 5 X 45             | 70    | 73182100 | 18% |
| 93342499 | Eicher Tractor Bracket For Weight           | 750   | 87089900 | 18% |
| 93342785 | Eicher Tractor Lower Link Assy Left         | 2130  | 87089900 | 18% |
| 93342827 | Eicher Tractor Link Upper                   | 152   | 87089900 | 18% |
| 93342852 | Eicher Tractor Lever-Fulcrum Pin            | 92    | 73182100 | 18% |
| 93342888 | Eicher Tractor Plate For Brake Mechanism    | 78    | 87083000 | 18% |
| 93342890 | Eicher Tractor Link For Brake Mechanism     | 29    | 87083000 | 18% |
| 93342918 | Eicher Tractor Bonnet Mtg. Bkt. Left        | 435   | 87089900 | 18% |
| 93342920 | Eicher Tractor Bonnet Mtg. Bkt. Right       | 435   | 87089900 | 18% |
| 93342943 | Eicher Tractor Foot Board Left              | 1093  | 87089900 | 18% |
| 93343030 | Eicher Tractor Steering Arm                 | 1667  | 87089400 | 18% |
| 93343042 | Eicher Tractor Flywheel Hsg. 380/480 Wc M/C | 26837 | 87084000 | 18% |
| 93343054 | Eicher Tractor Tie Rod End Left (86 Mm)     | 485   | 87089400 | 18% |
| 93343066 | Eicher Tractor Tie Rod End Right (86 Mm)    | 459   | 87089400 | 18% |
| 93343250 | Eicher Tractor Strut                        | 64    | 87089400 | 18% |
| 93343261 | Eicher Tractor Mtg. Plate Right-Foot Step   | 198   | 87089900 | 18% |
| 93343273 | Eicher Tractor Bracket For Air Cleaner Mtg. | 1787  | 84099941 | 28% |
| 93343297 | Eicher Tractor Bonnet Mtg Bkt Rt            | 334   | 87089900 | 18% |
| 93343303 | Eicher Tractor Bonnet Mounting Bkt Lt       | 334   | 87089900 | 18% |
| 93343315 | Eicher Tractor Rubber Pad                   | 723   | 40169990 | 18% |
| 93343339 | Eicher Tractor Rubber Pad Front             | 82    | 40169990 | 18% |
| 93343352 | Eicher Tractor Stud M20                     | 106   | 73182100 | 18% |
| 93343376 | Eicher Tractor Tie Rod Assy                 | 1181  | 87089400 | 18% |
| 93343480 | Eicher Tractor Front Axle Assy              | 9670  | 87085000 | 18% |
| 93343534 | Eicher Tractor Face Seal                    | 63    | 87089900 | 18% |
| 93343546 | Eicher Tractor Face Seal Cover              | 209   | 87089900 | 18% |
| 93343558 | Eicher Tractor Spacer                       | 132   | 73182100 | 18% |
| 93343674 | Eicher Tractor Pad Mounting Strip           | 27    | 40169320 | 18% |
| 93343686 | Eicher Tractor Pad Bkt+Bottom               | 52    | 40169320 | 18% |
| 93343716 | Eicher Tractor U-Bolt                       | 52    | 73181500 | 18% |
| 93343820 | Eicher Tractor Stud M14                     | 66    | 73182100 | 18% |
| 93343923 | Eicher Tractor Plate                        | 69    | 87089400 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93343935 | Eicher Tractor Pin (Coupling Mouth)                | 329   | 73182100 | 18% |
| 93343947 | Eicher Tractor Stay Bar Lt                         | 671   | 87089900 | 18% |
| 93344009 | Eicher Tractor Lower Link Lt                       | 4738  | 87089900 | 18% |
| 93344034 | Eicher Tractor 65.Plmg Bolt                        | 592   | 73181500 | 18% |
| 93344058 | Eicher Tractor Adopter                             | 2403  | 87089900 | 18% |
| 93344060 | Eicher Tractor Fork & Guide Assy                   | 2561  | 87089900 | 18% |
| 93344186 | Eicher Tractor Cover For Front Axle Support        | 40    | 87089900 | 18% |
| 93344241 | Eicher Tractor Bracket For Brake Switch            | 94    | 87083000 | 18% |
| 93344617 | Eicher Tractor Lower Link Assy Left                | 2899  | 87089900 | 18% |
| 93344630 | Eicher Tractor Lower Link Assly Right              | 2899  | 87089900 | 18% |
| 93344666 | Eicher Tractor Chain Assy Right                    | 926   | 87089900 | 18% |
| 93344691 | Eicher Tractor Fork And Guide Assy                 | 1996  | 87089900 | 18% |
| 93344769 | Eicher Tractor Brake Pedal Right                   | 578   | 87083000 | 18% |
| 93344903 | Eicher Tractor Bracket-Hand Brake                  | 417   | 87083000 | 18% |
| 93344915 | Eicher Tractor Bkt For Brake Switch                | 53    | 87083000 | 18% |
| 93345002 | Eicher Tractor Lifting Gear Assy                   | 3024  | 87089900 | 18% |
| 93345100 | Eicher Tractor Pin For Stay Bar                    | 343   | 73182100 | 18% |
| 93345130 | Eicher Tractor Eye Pin Stop Control                | 16    | 73182100 | 18% |
| 93345178 | Eicher Tractor Cover For Cylinder                  | 163   | 87089900 | 18% |
| 93345245 | Eicher Tractor Strut Mtg. Brkt. Lt.                | 812   | 87089400 | 18% |
| 93345269 | Eicher Tractor Cover                               | 100   | 87084000 | 18% |
| 93345294 | Eicher Tractor Distributor - Lubrication ( M 755 ) | 1111  | 87089900 | 18% |
| 93345336 | Eicher Tractor Bumper Assy - 485 Bent Axle         | 13829 | 87081010 | 18% |
| 93345348 | Eicher Tractor Tool Box Mtg. Bracket Export        | 263   | 87089900 | 18% |
| 93345350 | Eicher Tractor Spacer (12Mm)                       | 47    | 73182100 | 18% |
| 93345385 | Eicher Tractor Steering Lever Double               | 2347  | 87089400 | 18% |
| 93345403 | Eicher Tractor Hand Acc Bkt                        | 153   | 87089900 | 18% |
| 93345440 | Eicher Tractor Battery Pad Top                     | 25    | 85079090 | 28% |
| 93345490 | Eicher Tractor Sticker Diesel Saver - English      | 105   | 39199090 | 18% |
| 93345506 | Eicher Tractor Sticker Diesel Saver - Hindi        | 105   | 39199090 | 18% |
| 93345531 | Eicher Tractor Chain Mounting Bkt Rt               | 877   | 87089900 | 18% |
| 93345578 | Eicher Tractor Canopy-Green                        | 19472 | 87089900 | 18% |
| 93345660 | Eicher Tractor Chain Mounting Bkt Lt               | 878   | 87089900 | 18% |
| 93345880 | Eicher Tractor Grommet-Bonnet Lid                  | 10    | 40169990 | 18% |
| 93345932 | Eicher Tractor Foot Acc Pedal Assy                 | 182   | 87089900 | 18% |
| 93346018 | Eicher Tractor Decal Fuel Tank Left"485"           | 104   | 87089900 | 18% |
| 93346020 | Eicher Tractor Decal Fuel Tank Right"485"          | 104   | 87089900 | 18% |
| 93346146 | Eicher Tractor Chain Mtg. Bkt. Lt.                 | 803   | 87089900 | 18% |
| 93346158 | Eicher Tractor Chain Mtg. Bkt. Rt.                 | 803   | 87089900 | 18% |
| 93346377 | Eicher Tractor Bonnet Addon Lh                     | 1051  | 87089900 | 18% |
| 93346407 | Eicher Tractor Bonnet Addon Rh                     | 1369  | 87089900 | 18% |
| 93346419 | Eicher Tractor Tank Cover Addon Lh                 | 303   | 87089900 | 18% |
| 93346420 | Eicher Tractor Tank Cover Addon Rh                 | 287   | 87089900 | 18% |
| 93346432 | Eicher Tractor Head Lamp Cover                     | 1257  | 85122090 | 18% |
| 93346444 | Eicher Tractor Head Light Console                  | 510   | 85122010 | 18% |
| 93346500 | Eicher Tractor Adaptor                             | 602   | 87089900 | 18% |
| 93346754 | Eicher Tractor Bonnet Graphics Lt                  | 601   | 39199090 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93346766 | Eicher Tractor Bonnet Graphics Rt                  | 601  | 39199090 | 18% |
| 93347126 | Eicher Tractor Grill Element Rt                    | 85   | 87089900 | 18% |
| 93347266 | Eicher Tractor Decal Bonnet Lt Top                 | 244  | 39199090 | 18% |
| 93347280 | Eicher Tractor Decal Bonnet Rt Top                 | 244  | 39199090 | 18% |
| 93347291 | Eicher Tractor Decal Bonnet Strip Lt               | 336  | 39199090 | 18% |
| 93347450 | Eicher Tractor Decal Fuel Tank Lt.                 | 148  | 39199090 | 18% |
| 93347503 | Eicher Tractor Pin Assly.                          | 153  | 73182100 | 18% |
| 93347539 | Eicher Tractor Wire Rod Assy-865Mm(625Mm)          | 105  | 85122010 | 18% |
| 93347759 | Eicher Tractor Mirror Wc                           | 169  | 70060000 | 18% |
| 93347849 | Eicher Tractor Eye Pin                             | 28   | 73182100 | 18% |
| 93347850 | Eicher Tractor Connecting Link (Fuel Pump)         | 118  | 87089900 | 18% |
| 93347862 | Eicher Tractor Accelerator Lever Left              | 54   | 87084000 | 18% |
| 93347928 | Eicher Tractor Foot Board Lt                       | 2214 | 87089900 | 18% |
| 93347941 | Eicher Tractor Foot Board Rt                       | 2258 | 87089900 | 18% |
| 93348120 | Eicher Tractor Spacer                              | 95   | 73182100 | 18% |
| 93348143 | Eicher Tractor Lower Link Assy Right               | 2653 | 87089900 | 18% |
| 93348179 | Eicher Tractor S S Cover                           | 342  | 87084000 | 18% |
| 93348349 | Eicher Tractor Bonnet Mtg. Bkt. Lt.                | 301  | 87089900 | 18% |
| 93348350 | Eicher Tractor Bonnet Mtg. Bkt. Rt.                | 321  | 87089900 | 18% |
| 93348507 | Eicher Tractor Decal Fuel Tank Rt                  | 402  | 39199090 | 18% |
| 93348520 | Eicher Tractor Decal Bonnet Strip Rt               | 1706 | 39199090 | 18% |
| 93348556 | Eicher Tractor Cover                               | 118  | 87084000 | 18% |
| 93348611 | Eicher Tractor Latch Assembly                      | 329  | 84099941 | 28% |
| 93348623 | Eicher Tractor Lock Mtg. Bkt. Rt.                  | 207  | 87089900 | 18% |
| 93348751 | Eicher Tractor Bonnet Addon Lh - Small             | 133  | 87089900 | 18% |
| 93348933 | Eicher Tractor Tank Bottom Support (Sdi)           | 259  | 87089900 | 18% |
| 93348945 | Eicher Tractor Tank Top Support                    | 201  | 87089900 | 18% |
| 93348957 | Eicher Tractor Fuel Tank (Styling)                 | 8391 | 87089900 | 18% |
| 93348970 | Eicher Tractor Tank Bottom Support (Wc)            | 259  | 87089900 | 18% |
| 93349123 | Eicher Tractor Bonnet Graphics Lt. (380)           | 1521 | 39199090 | 18% |
| 93349135 | Eicher Tractor Bonnet Graphics Rt. (380)           | 1521 | 39199090 | 18% |
| 93349147 | Eicher Tractor Bonnet Strip Lt (380)               | 125  | 39199090 | 18% |
| 93349172 | Eicher Tractor Fuel Tank Graphics Rt. (380)        | 118  | 87089900 | 18% |
| 93349202 | Eicher Tractor Chain Mtg. Bkt. Lt.                 | 858  | 87089900 | 18% |
| 93349226 | Eicher Tractor Return Pipe Assy-Fuel Tank          | 147  | 84099941 | 28% |
| 93349391 | Eicher Tractor Pin - Chain Mtg. Bkt.               | 122  | 73182100 | 18% |
| 93349494 | Eicher Tractor Pin For Stay Bar                    | 375  | 73182100 | 18% |
| 93349603 | Eicher Tractor Grommet (Fuel Tank Cover Rt.)       | 12   | 87089900 | 18% |
| 93349640 | Eicher Tractor Worm Column Assy 93340478 Stg. Assl | 2691 | 87089400 | 18% |
| 93349652 | Eicher Tractor Gasket For Fly Wheel Housing        | 192  | 68129090 | 18% |
| 93349792 | Eicher Tractor Link Assy - Brake Linkage           | 276  | 87083000 | 18% |
| 93349834 | Eicher Tractor Washer                              | 53   | 73182100 | 18% |
| 93349844 | Eicher Tractor Mudguard Stiffner 6100 Lt.          | 269  | 87089900 | 18% |
| 93349854 | Eicher Tractor Mudguard Stiffner 6100 Rt           | 188  | 87089900 | 18% |
| 93349937 | Eicher Tractor Dash Board                          | 331  | 87089900 | 18% |
| 93349949 | Eicher Tractor Dash Board Cover                    | 430  | 87089900 | 18% |
| 93349950 | Eicher Tractor Stub Axle -Ap/South                 | 2829 | 87085000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93349986 | Eicher Tractor Pad - 50 Hp Without Canopy           | 279   | 40169320 | 18% |
| 93350034 | Eicher Tractor Bonnet Mtg Bkt Lt                    | 213   | 87089900 | 18% |
| 93350046 | Eicher Tractor Bonnet Mtg Bkt Rt                    | 192   | 87089900 | 18% |
| 93350125 | Eicher Tractor Steering Lever Single                | 1347  | 87089400 | 18% |
| 93350137 | Eicher Tractor Steering Lever Double                | 2212  | 87089400 | 18% |
| 93350150 | Eicher Tractor Front Axle Assembly                  | 13370 | 87085000 | 18% |
| 93350198 | Eicher Tractor Lock Bracket Rt                      | 131   | 87089900 | 18% |
| 93350204 | Eicher Tractor Lock Bracket Lt                      | 131   | 87089900 | 18% |
| 93350265 | Eicher Tractor Accelerator Lever Right              | 87    | 87084000 | 18% |
| 93350393 | Eicher Tractor Stablizer Mtg. Bkt. Left             | 1614  | 87089900 | 18% |
| 93350400 | Eicher Tractor Stablizer Mtg. Bkt. Right            | 1613  | 87089900 | 18% |
| 93350538 | Eicher Tractor Bonnet Graphics Top Lt. -50Hp Green  | 636   | 39199090 | 18% |
| 93350540 | Eicher Tractor Bonnet Graphics Top Rt. -50Hp Green  | 637   | 39199090 | 18% |
| 93350551 | Eicher Tractor Bonnet Graphics Bottom Lt -50Hp Gre  | 81    | 39199090 | 18% |
| 93350563 | Eicher Tractor Bonnet Graphics Bottom Rt -50Hp Gre  | 81    | 39199090 | 18% |
| 93350575 | Eicher Tractor Fuel Tank Graphics Left-50Hp Green   | 101   | 39199090 | 18% |
| 93350587 | Eicher Tractor Fuet Tank Graphics Right-50Hp Green  | 101   | 39199090 | 18% |
| 93350679 | Eicher Tractor Connecting Link-50Hp                 | 186   | 87089900 | 18% |
| 93350680 | Eicher Tractor Link Upper 50Hp                      | 111   | 87089900 | 18% |
| 93350721 | Eicher Tractor Alternator Cover                     | 300   | 87085000 | 18% |
| 93350812 | Eicher Tractor Pedal Shaft -5660 Ddb                | 1630  | 87084000 | 18% |
| 93350990 | Eicher Tractor Battery Mtg. Bkt.                    | 946   | 85079090 | 28% |
| 93351191 | Eicher Tractor Spacer                               | 48    | 73182100 | 18% |
| 93351270 | Eicher Tractor Side Plate Mtg. Lt                   | 2075  | 87089900 | 18% |
| 93351282 | Eicher Tractor Side Plate Mtg. Rt                   | 2075  | 87089900 | 18% |
| 93351440 | Eicher Tractor Cover Plate                          | 290   | 87084000 | 18% |
| 93351543 | Eicher Tractor Pin                                  | 28    | 73182100 | 18% |
| 93351713 | Eicher Tractor Mudguard Support                     | 401   | 87089900 | 18% |
| 93351798 | Eicher Tractor Fuel Tank Graphics Left-Red/Blue S.  | 181   | 39199090 | 18% |
| 93351804 | Eicher Tractor Fuel Tank Graphics Rt.-Red/Blue S.M  | 181   | 39199090 | 18% |
| 93351830 | Eicher Tractor 485 Plate                            | 134   | 83100090 | 18% |
| 93352020 | Eicher Tractor Fuel Pipe Assy (Ffp To Ff)           | 196   | 84099941 | 28% |
| 93352031 | Eicher Tractor Fuel Pipe Assy (Ff To Fip)           | 208   | 84099941 | 28% |
| 93352079 | Eicher Tractor Water Seperator Bracket              | 103   | 84099941 | 28% |
| 93352109 | Eicher Tractor Fuel Tank Graphics Left-Silver S.Me  | 205   | 39199090 | 18% |
| 93352110 | Eicher Tractor Fuel Tank Graphics Right-Silver S.M  | 203   | 39199090 | 18% |
| 93352171 | Eicher Tractor Aluminium Plate 480                  | 143   | 83100090 | 18% |
| 93352195 | Eicher Tractor Pedal Shaft - Wdb                    | 1988  | 87084000 | 18% |
| 93352225 | Eicher Tractor Foot Acc. Shaft - Wdb                | 131   | 87085000 | 18% |
| 93352237 | Eicher Tractor Fork Assy (Wdb)                      | 193   | 87084000 | 18% |
| 93352262 | Eicher Tractor Brake Pedal Right-Wdb                | 1606  | 87083000 | 18% |
| 93352274 | Eicher Tractor Strip For Radiator                   | 155   | 87087000 | 18% |
| 93352365 | Eicher Tractor Cover                                | 153   | 87084000 | 18% |
| 93352389 | Eicher Tractor Spacer                               | 893   | 73182100 | 18% |
| 93352651 | Eicher Tractor Bonnet Graphics Top Lt. -50Hp Silver | 639   | 39199090 | 18% |
| 93352675 | Eicher Tractor Bonnet Graphics Bottom Lt-50Hp Silv  | 81    | 39199090 | 18% |
| 93352687 | Eicher Tractor Bonnet Graphics Bottom Rt-50Hp Silv  | 81    | 39199090 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93352699 | Eicher Tractor Fuel Tank Graphics Lt-50Hp Silver | 112   | 87089900 | 18% |
| 93352705 | Eicher Tractor Fuel Tank Graphics Rt-50Hp Silver | 101   | 87089900 | 18% |
| 93352754 | Eicher Tractor Plate                             | 424   | 87089400 | 18% |
| 93352766 | Eicher Tractor Bonnet 50 Hp ( Wet A/C)           | 11975 | 87089900 | 18% |
| 93352778 | Eicher Tractor Back Rest Lt. With Canopy Plate   | 1495  | 87089900 | 18% |
| 93352869 | Eicher Tractor Steering Lever Left               | 1486  | 87089400 | 18% |
| 93352870 | Eicher Tractor Steering Lever Right              | 1486  | 87089400 | 18% |
| 93352882 | Eicher Tractor Flat Spring Washer M20            | 9     | 73182990 | 18% |
| 93352912 | Eicher Tractor Steering Cylinder                 | 17035 | 87089400 | 18% |
| 93352924 | Eicher Tractor Bkt For Steering                  | 916   | 87089400 | 18% |
| 93352985 | Eicher Tractor 5660 Graphic Plate                | 133   | 83100090 | 18% |
| 93353114 | Eicher Tractor Foot Acc Lever 50Hp               | 85    | 87085000 | 18% |
| 93353163 | Eicher Tractor Front Weight-Big                  | 8046  | 87081010 | 18% |
| 93353175 | Eicher Tractor Front Weight Small                | 3851  | 87081010 | 18% |
| 93353187 | Eicher Tractor Clutch Pedal Assly                | 1017  | 87089300 | 18% |
| 93353254 | Eicher Tractor Extension Spring                  | 81    | 73202000 | 18% |
| 93353345 | Eicher Tractor Mudguard Red Sticker -480         | 50    | 39199090 | 18% |
| 93353357 | Eicher Tractor Mudguard Sticker "485" - Red      | 62    | 39199090 | 18% |
| 93353382 | Eicher Tractor Plate 5150                        | 128   | 83100090 | 18% |
| 93353394 | Eicher Tractor Assy. Con Tie Rod                 | 2781  | 87089400 | 18% |
| 93353422 | Eicher Tractor Reflective Mudguard Sticker-5150  | 84    | 39199090 | 18% |
| 93353450 | Eicher Tractor Back Rest Rt. With Canopy Plate   | 1755  | 87089900 | 18% |
| 93353515 | Eicher Tractor Flywheel Housing                  | 23251 | 87084000 | 18% |
| 93353692 | Eicher Tractor Elbow Exhaust                     | 1044  | 87089200 | 18% |
| 93353825 | Eicher Tractor Tube Air Intake (Precleaner)      | 89    | 84099941 | 28% |
| 93353837 | Eicher Tractor A/C Hose (Engine Side)            | 190   | 40093100 | 18% |
| 93353850 | Eicher Tractor Air Intake Pipe                   | 571   | 40093100 | 18% |
| 93353862 | Eicher Tractor Exhaust Elbow-Ac                  | 1102  | 87089200 | 18% |
| 93354027 | Eicher Tractor Moulded Screw 6X14                | 13    | 73181500 | 18% |
| 93354040 | Eicher Tractor Brake Pedal Assy. Lt              | 993   | 87083000 | 18% |
| 93354064 | Eicher Tractor Steering Bkt.                     | 943   | 87089400 | 18% |
| 93354076 | Eicher Tractor Brake Pedal Assy. Rt-5660/South   | 1654  | 87083000 | 18% |
| 93354088 | Eicher Tractor On/Off Part Bracket               | 50    | 87089900 | 18% |
| 93354118 | Eicher Tractor Bonnet Mounting Bkt Lt.           | 258   | 87089900 | 18% |
| 93354120 | Eicher Tractor Bonnet Mtg Bkt Rt.                | 259   | 87089900 | 18% |
| 93354167 | Eicher Tractor Mirror Assly                      | 414   | 70091090 | 18% |
| 93354386 | Eicher Tractor Brake Pedal Rt -North             | 1541  | 87083000 | 18% |
| 93354570 | Eicher Tractor Fuse Mtg. Bracket                 | 83    | 87089400 | 18% |
| 93354593 | Eicher Tractor Bonnet Mtg. Bkt. Lt.              | 394   | 87089900 | 18% |
| 93354600 | Eicher Tractor Bonnet Mtg. Bkt. Rt.              | 385   | 87089900 | 18% |
| 93354805 | Eicher Tractor Eicher Front Logo                 | 220   | 39199090 | 18% |
| 93354817 | Eicher Tractor Water Seperator Bracket           | 61    | 87089900 | 18% |
| 93354829 | Eicher Tractor Fuel Pipe - ( Ws To Feed Pump)    | 245   | 84099941 | 28% |
| 93354921 | Eicher Tractor Tank Cover Support Lt             | 248   | 87089900 | 18% |
| 93354933 | Eicher Tractor Tank Cover Support Rt             | 248   | 87089900 | 18% |
| 93354970 | Eicher Tractor Linch Pin 6X45                    | 53    | 73182100 | 18% |
| 93354982 | Eicher Tractor Bonnet Mtg. Bkt. Left             | 354   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93354994 | Eicher Tractor Bonnet Mtg. Bkt. Right              | 354   | 87089900 | 18% |
| 93355123 | Eicher Tractor Brake Pedal Assy. Rt-5660/South     | 1850  | 87083000 | 18% |
| 93355196 | Eicher Tractor Foot Board Left                     | 1979  | 87089900 | 18% |
| 93355202 | Eicher Tractor Foot Board Right                    | 2352  | 87089900 | 18% |
| 93355226 | Eicher Tractor Lift Arm                            | 5124  | 87089900 | 18% |
| 93355251 | Eicher Tractor Pin                                 | 141   | 73182100 | 18% |
| 93355342 | Eicher Tractor Clutch Pedal Assly.                 | 1685  | 87089300 | 18% |
| 93355354 | Eicher Tractor Pin For Clutch                      | 58    | 87089300 | 18% |
| 93355380 | Eicher Tractor Fork And Guide Mechanism            | 2773  | 87089900 | 18% |
| 93355391 | Eicher Tractor Lifting Gear Mechanism              | 3978  | 87089900 | 18% |
| 93355434 | Eicher Tractor Rear Rim W11 Top Coat Off Wht Knp12 | 15746 | 87087000 | 18% |
| 93355446 | Eicher Tractor Rear Rim W11 Top Coat Silver Knp 12 | 16505 | 87087000 | 18% |
| 93355470 | Eicher Tractor Recovery Bottle Assly               | 480   | 87089100 | 18% |
| 93355512 | Eicher Tractor Lower Link Assly Left               | 2748  | 87089900 | 18% |
| 93355548 | Eicher Tractor On/Off Part Assy.                   | 567   | 87085000 | 18% |
| 93355688 | Eicher Tractor Front Bumper                        | 9090  | 87081010 | 18% |
| 93355755 | Eicher Tractor Brake Linkage Assy.                 | 561   | 87083000 | 18% |
| 93356000 | Eicher Tractor Adoptor                             | 206   | 73181500 | 18% |
| 93356012 | Eicher Tractor On/Off Part Assy.                   | 516   | 87089900 | 18% |
| 93356073 | Eicher Tractor Bracket                             | 148   | 87089900 | 18% |
| 93356164 | Eicher Tractor Air Inlet Hose                      | 614   | 40093100 | 18% |
| 93356176 | Eicher Tractor Battery Mtg. Bkt(14.9 Tyre)         | 684   | 85079090 | 28% |
| 93356206 | Eicher Tractor D D Seat                            | 6131  | 94012000 | 18% |
| 93356243 | Eicher Tractor Stub Axle Lt.                       | 7436  | 87085000 | 18% |
| 93356255 | Eicher Tractor Stub Axle Rt                        | 7522  | 87085000 | 18% |
| 93356267 | Eicher Tractor Stub Axle                           | 5863  | 87085000 | 18% |
| 93356292 | Eicher Tractor Bush                                | 157   | 87089900 | 18% |
| 93356309 | Eicher Tractor Bush                                | 157   | 87089900 | 18% |
| 93356360 | Eicher Tractor Battery Mtg. Bkt. 13.6              | 736   | 85079090 | 28% |
| 93356486 | Eicher Tractor Brake Linkage Assly                 | 469   | 87083000 | 18% |
| 93356565 | Eicher Tractor Tank Unit                           | 470   | 90261020 | 18% |
| 93356577 | Eicher Tractor T- Hose Assly                       | 254   | 40093100 | 18% |
| 93356589 | Eicher Tractor Pipe Assly                          | 257   | 87089900 | 18% |
| 93356607 | Eicher Tractor Overflow Pipe                       | 81    | 87089900 | 18% |
| 93356620 | Eicher Tractor Front Axle Support                  | 41120 | 87089900 | 18% |
| 93356656 | Eicher Tractor Steering Cylinder (63X36X190)       | 12894 | 87089400 | 18% |
| 93356670 | Eicher Tractor Connecting Rod Assy                 | 3826  | 87089900 | 18% |
| 93356747 | Eicher Tractor Fuel Tank - Plastic                 | 4919  | 87089900 | 18% |
| 93356759 | Eicher Tractor Fuel Pipe Assy                      | 384   | 84099941 | 28% |
| 93356760 | Eicher Tractor T- Hose Assly                       | 203   | 40093100 | 18% |
| 93356838 | Eicher Tractor Front Axle Assly                    | 17756 | 87085000 | 18% |
| 93356840 | Eicher Tractor Centre Pin                          | 1023  | 87085000 | 18% |
| 93356966 | Eicher Tractor On/Off Part Assy.                   | 456   | 87089900 | 18% |
| 93357170 | Eicher Tractor Pad For Mudguard                    | 602   | 87089900 | 18% |
| 93357181 | Eicher Tractor Front Axle Support                  | 15502 | 87089900 | 18% |
| 93357235 | Eicher Tractor Steering Rod                        | 2213  | 87089400 | 18% |
| 93357247 | Eicher Tractor Front Axle Support Assly. - 368 Hyd | 55956 | 87085000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93357302 | Eicher Tractor Fuel Pipe - ( Ws To Feed Pump)      | 188   | 84099941 | 28% |
| 93357314 | Eicher Tractor Spacer (5150 Ps)                    | 5562  | 73182100 | 18% |
| 93357326 | Eicher Tractor Bonnet Mtg. Bkt. Lt. (5151 Ps)      | 573   | 87089900 | 18% |
| 93357338 | Eicher Tractor Bonnet Mtg. Bkt. Rt. (5151 Ps)      | 573   | 87089900 | 18% |
| 93357340 | Eicher Tractor Connecting Link                     | 115   | 87089900 | 18% |
| 93357351 | Eicher Tractor Radiator Mkt Bkt                    | 4526  | 87087000 | 18% |
| 93357375 | Eicher Tractor Filter Mtg. Bkt                     | 275   | 84219900 | 18% |
| 93357399 | Eicher Tractor Front Axle Assy (5150 Ps)           | 16677 | 87085000 | 18% |
| 93357405 | Eicher Tractor Fuel Duct Assy (Ff To Fip)          | 298   | 84099941 | 28% |
| 93357417 | Eicher Tractor Fuel Duct Assy (Fip To Overflow)    | 273   | 84099941 | 28% |
| 93357430 | Eicher Tractor Fuel Duct Assy (Ff To On-Off)       | 206   | 84099941 | 28% |
| 93357454 | Eicher Tractor Battery Mounting Bracket 5660       | 612   | 85079090 | 28% |
| 93357466 | Eicher Tractor Battery Cover                       | 533   | 85079090 | 28% |
| 93357478 | Eicher Tractor Stub Axle Left                      | 4590  | 87085000 | 18% |
| 93357480 | Eicher Tractor Stub Axle Right                     | 4590  | 87085000 | 18% |
| 93357510 | Eicher Tractor Steering Cylinder (5150 Ps)         | 16276 | 87089400 | 18% |
| 93357740 | Eicher Tractor Strip For Radiator                  | 163   | 87087000 | 18% |
| 93357776 | Eicher Tractor Clamping Bkt                        | 29    | 87089900 | 18% |
| 93357788 | Eicher Tractor Accelerator Lever Left              | 47    | 87084000 | 18% |
| 93357790 | Eicher Tractor On/Off Part Assy.                   | 311   | 87089900 | 18% |
| 93357843 | Eicher Tractor Stopper Plate                       | 16    | 87084000 | 18% |
| 93357855 | Eicher Tractor Shim (0.2 Mm)                       | 11    | 73182100 | 18% |
| 93357879 | Eicher Tractor Sticker - Rotary                    | 33    | 39199090 | 18% |
| 93357880 | Eicher Tractor Sticker Power Steering Left         | 36    | 39199090 | 18% |
| 93357892 | Eicher Tractor Sticker Power Steering Right        | 36    | 39199090 | 18% |
| 93357946 | Eicher Tractor Bracket For Water Separator         | 82    | 87089900 | 18% |
| 93358057 | Eicher Tractor Starter Motor (1001) (380 Ps & 5150 | 9385  | 85114000 | 28% |
| 93358069 | Eicher Tractor Bottom Pad                          | 246   | 40169320 | 18% |
| 93358185 | Eicher Tractor Adjusting Screw                     | 34    | 73181500 | 18% |
| 93358422 | Eicher Tractor Bumper Assy - 5660                  | 11385 | 87081010 | 18% |
| 93358446 | Eicher Tractor Steel Strap                         | 118   | 87089900 | 18% |
| 93358550 | Eicher Tractor Recovery Bottle Mtg Bkt             | 94    | 87089100 | 18% |
| 93358598 | Eicher Tractor Tension Tie Assy                    | 348   | 87083000 | 18% |
| 93358616 | Eicher Tractor Alt. Mtg. Bracket                   | 221   | 87085000 | 18% |
| 93358628 | Eicher Tractor Air Inlet Hose                      | 531   | 40093100 | 18% |
| 93358630 | Eicher Tractor A/C Connecting Pipe                 | 822   | 84091000 | 28% |
| 93358693 | Eicher Tractor Hand Primer Mtg. Bkt(Ms)            | 273   | 87089900 | 18% |
| 93358744 | Eicher Tractor Fuel Filter Mtg. Bkt                | 214   | 84219900 | 18% |
| 93358835 | Eicher Tractor Brake Switch Bracket                | 111   | 87083000 | 18% |
| 93358872 | Eicher Tractor Lower Link Mtg. Bracket Lt          | 1153  | 87089900 | 18% |
| 93358884 | Eicher Tractor Lower Link Mtg. Bracket Rt          | 1153  | 87089900 | 18% |
| 93358896 | Eicher Tractor Strut Mtg Bkt Lt                    | 1570  | 87089900 | 18% |
| 93358902 | Eicher Tractor Strut Mtg Bkt Rt                    | 1570  | 87089900 | 18% |
| 93358914 | Eicher Tractor Spacer                              | 43    | 73182100 | 18% |
| 93358926 | Eicher Tractor Front Bumper                        | 11563 | 87081010 | 18% |
| 93358938 | Eicher Tractor Bumper Mtg Bkt. (5150 Ps)           | 2129  | 87081010 | 18% |
| 93358940 | Eicher Tractor Foot Board Left (Big)               | 3085  | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93358951 | Eicher Tractor Hub                                  | 3446  | 87085000 | 18% |
| 93358963 | Eicher Tractor Cap                                  | 307   | 87089900 | 18% |
| 93358987 | Eicher Tractor Steering Column                      | 3476  | 87089400 | 18% |
| 93358999 | Eicher Tractor Steering Bkt. P.S                    | 1001  | 87089400 | 18% |
| 93359049 | Eicher Tractor Hand Brake Assy                      | 836   | 87083000 | 18% |
| 93359050 | Eicher Tractor Gaskets For Axcle Tube               | 6     | 68129090 | 18% |
| 93359062 | Eicher Tractor Main Mounting Bracket                | 703   | 87089900 | 18% |
| 93359074 | Eicher Tractor Steel Strap                          | 116   | 87089900 | 18% |
| 93359086 | Eicher Tractor Lower Link Assly Left                | 6432  | 87089900 | 18% |
| 93359098 | Eicher Tractor Lower Link Assly Right               | 6432  | 87089900 | 18% |
| 93359128 | Eicher Tractor Accelerator Shaft                    | 156   | 87084000 | 18% |
| 93359190 | Eicher Tractor Stablizer Mtg. Bkt. Left             | 1275  | 87089900 | 18% |
| 93359207 | Eicher Tractor Stablizer Mtg. Bkt. Right            | 1187  | 87089900 | 18% |
| 93359219 | Eicher Tractor Pad For Fuel Tank                    | 574   | 87089900 | 18% |
| 93359220 | Eicher Tractor Connecting Link Assy.                | 143   | 87089900 | 18% |
| 93359232 | Eicher Tractor Adoptor                              | 173   | 87089900 | 18% |
| 93359244 | Eicher Tractor On/Off Assy                          | 181   | 87089900 | 18% |
| 93359256 | Eicher Tractor Nylon Pipe (On/Off To Sediment Bowl) | 165   | 87089900 | 18% |
| 93359268 | Eicher Tractor Nylon Pipe (Hand Primer To Feed Pu   | 212   | 87089900 | 18% |
| 93359270 | Eicher Tractor Nylon Pipe (Feed Pump To Filter)     | 232   | 84219900 | 18% |
| 93359281 | Eicher Tractor Rigid Pipe (Filter To Fip)           | 200   | 84219900 | 18% |
| 93359293 | Eicher Tractor Overflow Pipe Assy.                  | 557   | 87089900 | 18% |
| 93359440 | Eicher Tractor Bumper Assy Foldable                 | 10195 | 87081010 | 18% |
| 93359475 | Eicher Tractor Hand Brake Lever Assy                | 589   | 87083000 | 18% |
| 93359499 | Eicher Tractor Lower Link Assly Lt.                 | 3903  | 87089900 | 18% |
| 93359505 | Eicher Tractor Lower Link Assly Rt.                 | 3898  | 87089900 | 18% |
| 93359542 | Eicher Tractor Lower Link Assly Lt.                 | 4546  | 87089900 | 18% |
| 93359566 | Eicher Tractor Lower Link Assly Rt.                 | 4696  | 87089900 | 18% |
| 93359580 | Eicher Tractor Draw Bar                             | 2779  | 87089900 | 18% |
| 93359669 | Eicher Tractor Rear Rim W13 Top Coat Silver 14.9*2  | 19054 | 87087000 | 18% |
| 93359670 | Eicher Tractor Rear Rim W15 Silver Knp 16.9*28      | 21116 | 87087000 | 18% |
| 93359682 | Eicher Tractor Front Rim-5.5 X 16 Top Coat Silver   | 5680  | 87087000 | 18% |
| 93359694 | Eicher Tractor Front Weight                         | 9538  | 87081010 | 18% |
| 93359773 | Eicher Tractor Fuel Tank Strap Assy                 | 170   | 87089900 | 18% |
| 93359797 | Eicher Tractor Water Separator Assy                 | 758   | 84099941 | 28% |
| 93359840 | Eicher Tractor Taper Roller Bearing 32207           | 561   | 84822011 | 18% |
| 93359864 | Eicher Tractor Brake Pedal Assy Rt Wdb              | 1744  | 87083000 | 18% |
| 93359888 | Eicher Tractor Brake Pedal Asst Lt                  | 1381  | 87083000 | 18% |
| 93359890 | Eicher Tractor Clutch Pedal Assly                   | 1910  | 87089300 | 18% |
| 93359931 | Eicher Tractor Hand Accelerator Rod                 | 328   | 84099941 | 28% |
| 93359979 | Eicher Tractor Oil Seal- Ø72.2XØ45X11/15            | 120   | 40169330 | 18% |
| 93359980 | Eicher Tractor Stub Axle -North                     | 3730  | 87085000 | 18% |
| 93359992 | Eicher Tractor Hub                                  | 2023  | 87085000 | 18% |
| 93360076 | Eicher Tractor Mudguard Red Sticker -5660           | 57    | 39199090 | 18% |
| 93360258 | Eicher Tractor Bush                                 | 810   | 87089900 | 18% |
| 93360260 | Eicher Tractor Bush                                 | 417   | 87089900 | 18% |
| 93360271 | Eicher Tractor Battery Cover                        | 1558  | 85079090 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93360313 | Eicher Tractor Back Cover                          | 420   | 87089900 | 18% |
| 93360349 | Eicher Tractor Clamping Latch                      | 87    | 87089900 | 18% |
| 93360386 | Eicher Tractor Stud                                | 182   | 73182100 | 18% |
| 93360398 | Eicher Tractor Stud                                | 133   | 73182100 | 18% |
| 93360441 | Eicher Tractor Shuttle Link Lever                  | 118   | 87089900 | 18% |
| 93360453 | Eicher Tractor Shuttle Link Assy                   | 744   | 87089900 | 18% |
| 93360477 | Eicher Tractor Support Plate                       | 72    | 87089900 | 18% |
| 93360490 | Eicher Tractor Dowel Pin Ø20                       | 52    | 73182100 | 18% |
| 93360570 | Eicher Tractor Fulcrum Pin                         | 127   | 87089900 | 18% |
| 93360593 | Eicher Tractor Spacer                              | 47    | 73182100 | 18% |
| 93360611 | Eicher Tractor Spring (Clutch)                     | 28    | 73202000 | 18% |
| 93360623 | Eicher Tractor Clutch Tie Rod                      | 280   | 87089300 | 18% |
| 93360672 | Eicher Tractor Pin Small                           | 45    | 73182100 | 18% |
| 93360702 | Eicher Tractor Torsion Spring                      | 103   | 73202000 | 18% |
| 93360933 | Eicher Tractor Pin(Lower Link)                     | 228   | 73182100 | 18% |
| 93360945 | Eicher Tractor Pin(Lift Arm)                       | 247   | 73182100 | 18% |
| 93360957 | Eicher Tractor Lift Arm                            | 6172  | 87089900 | 18% |
| 93360970 | Eicher Tractor Link Pto (Push/Pull)                | 163   | 87084000 | 18% |
| 93360982 | Eicher Tractor Pto Knob                            | 99    | 87084000 | 18% |
| 93361020 | Eicher Tractor Plat Form Mtg. Bkt                  | 1206  | 87089900 | 18% |
| 93361032 | Eicher Tractor Plat Form Mtg.                      | 642   | 87089900 | 18% |
| 93361068 | Eicher Tractor Steering Column                     | 3507  | 87089400 | 18% |
| 93361070 | Eicher Tractor Clutch Lock Pin                     | 61    | 73182100 | 18% |
| 93361100 | Eicher Tractor Diff. Lock Pin                      | 178   | 73182100 | 18% |
| 93361111 | Eicher Tractor Diff. Lock Pivot                    | 126   | 73181500 | 18% |
| 93361123 | Eicher Tractor Diff. Lock Bkt                      | 118   | 87081010 | 18% |
| 93361135 | Eicher Tractor Diff. Lock Link Assy.               | 237   | 87089900 | 18% |
| 93361160 | Eicher Tractor Pto Clutch Pivot Pin                | 140   | 87084000 | 18% |
| 93361172 | Eicher Tractor Pto Clutch Pivot Lever              | 130   | 87089300 | 18% |
| 93361184 | Eicher Tractor Pto Clutch Link Assy                | 325   | 87089300 | 18% |
| 93361196 | Eicher Tractor Pto Engaging Lever Assy             | 996   | 87084000 | 18% |
| 93361214 | Eicher Tractor Clutch Lock Spring                  | 6     | 87089300 | 18% |
| 93361275 | Eicher Tractor Parking Brack Lever Assy            | 813   | 87089900 | 18% |
| 93361305 | Eicher Tractor Nylon Bush                          | 23    | 87089900 | 18% |
| 93361652 | Eicher Tractor Rubber Pad (Radiator)               | 134   | 87087000 | 18% |
| 93361718 | Eicher Tractor Oil Seal Stefa Ref. Bd 32X40X4      | 191   | 40169330 | 18% |
| 93361720 | Eicher Tractor Oil Seal Stefa Ref. Bd 45X55X4      | 334   | 40169330 | 18% |
| 93361731 | Eicher Tractor Oil Seal Stefa Ref. Bd 62X72X5      | 456   | 40169330 | 18% |
| 93361755 | Eicher Tractor Mounting Bolt M16                   | 364   | 73181500 | 18% |
| 93361767 | Eicher Tractor Bkt For Front Weight                | 7053  | 87089900 | 18% |
| 93362140 | Eicher Tractor Support Bkt Rt (Recovery Bottle Ass | 110   | 87089900 | 18% |
| 93362176 | Eicher Tractor Front Axle Assy                     | 17690 | 87085000 | 18% |
| 93362188 | Eicher Tractor Front Axle Support                  | 43193 | 87089900 | 18% |
| 93362218 | Eicher Tractor Alu Radiator Assy With Recovery (50 | 13458 | 87087000 | 18% |
| 93362231 | Eicher Tractor Base Mounting Bracket (A/C)         | 430   | 87085000 | 18% |
| 93362243 | Eicher Tractor Bottom Plate (Bonnet)               | 3124  | 87081010 | 18% |
| 93362255 | Eicher Tractor Bonnet Hinge Bracket                | 1937  | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93362267 | Eicher Tractor Pin (Bonnet Rotating)               | 100   | 87089900 | 18% |
| 93362279 | Eicher Tractor Pad Side (Bonnet)                   | 59    | 40169990 | 18% |
| 93362280 | Eicher Tractor Rubber Pad Front (Bonnet)           | 123   | 40169990 | 18% |
| 93362358 | Eicher Tractor Air Intake Hose                     | 960   | 40093100 | 18% |
| 93362360 | Eicher Tractor Air Intake Tube                     | 961   | 40093100 | 18% |
| 93362371 | Eicher Tractor Battery Tray Assy.                  | 2587  | 85079090 | 28% |
| 93362425 | Eicher Tractor Bonnet Stopper Rod                  | 65    | 87089900 | 18% |
| 93362437 | Eicher Tractor Calmping Lach                       | 87    | 87089900 | 18% |
| 93362553 | Eicher Tractor 5150 Bumper                         | 11344 | 87081010 | 18% |
| 93362590 | Eicher Tractor Shim                                | 23    | 73182100 | 18% |
| 93362607 | Eicher Tractor Shim                                | 14    | 73182100 | 18% |
| 93362619 | Eicher Tractor Sleeve (For Center Pin)             | 660   | 73182100 | 18% |
| 93362632 | Eicher Tractor Center Pin                          | 1808  | 87085000 | 18% |
| 93362644 | Eicher Tractor Stud M12X55,A10.9,Bp,               | 30    | 73182100 | 18% |
| 93362656 | Eicher Tractor Thrust Washer                       | 208   | 73182100 | 18% |
| 93362668 | Eicher Tractor Fly Wheel Housing                   | 33534 | 87084000 | 18% |
| 93362711 | Eicher Tractor Lock Pin                            | 111   | 73182100 | 18% |
| 93362759 | Eicher Tractor Clamping Braket                     | 40    | 87089900 | 18% |
| 93362875 | Eicher Tractor Lock Plate (Diff Lock)              | 61    | 87084000 | 18% |
| 93362887 | Eicher Tractor Taper Roller Brg.(Skf 603049)       | 1265  | 84822000 | 18% |
| 93362899 | Eicher Tractor Taper Roller Brg.(Skf 48548)        | 886   | 84822000 | 18% |
| 93362991 | Eicher Tractor Diff.Lock Pedal                     | 285   | 87085000 | 18% |
| 93363004 | Eicher Tractor Parking Brake Mtg.Plate             | 600   | 87089900 | 18% |
| 93363026 | Eicher Tractor Stub Axle Assy. Rt.                 | 4950  | 87085000 | 18% |
| 93363038 | Eicher Tractor Stub Axle Assy. Lt.                 | 4950  | 87085000 | 18% |
| 93363051 | Eicher Tractor Steering Lever Right                | 2043  | 87089400 | 18% |
| 93363063 | Eicher Tractor Steering Lever Left                 | 2043  | 87089400 | 18% |
| 93363247 | Eicher Tractor Water Separator Bracket             | 82    | 87089900 | 18% |
| 93363545 | Eicher Tractor Fan Daya – 450 (Bhopal Procurement) | 8751  | 87089100 | 18% |
| 93363570 | Eicher Tractor Hand Brake Lever Assy               | 693   | 87083000 | 18% |
| 93363582 | Eicher Tractor Front Axle Support                  | 16119 | 87089900 | 18% |
| 93363624 | Eicher Tractor Bumper Mtg. Bkt.                    | 2593  | 87081010 | 18% |
| 93363636 | Eicher Tractor Front Bumper Assly                  | 11835 | 87081010 | 18% |
| 93363818 | Eicher Tractor Strip For Radiator                  | 72    | 87087000 | 18% |
| 93363820 | Eicher Tractor Inlet Water Hose                    | 462   | 40093100 | 18% |
| 93363880 | Eicher Tractor Fuel Pipe Assy                      | 508   | 84099941 | 28% |
| 93363892 | Eicher Tractor Fuel Pipe (Ff To Fip)               | 154   | 84099941 | 28% |
| 93363909 | Eicher Tractor Fuel Pipe Assy (Ffp To Ff)          | 141   | 84099941 | 28% |
| 93363934 | Eicher Tractor Radiator With Ic Assy               | 28677 | 87087000 | 18% |
| 93364320 | Eicher Tractor Plastic Clamp                       | 15    | 39021000 | 18% |
| 93364343 | Eicher Tractor Battery Tray Assly                  | 2601  | 85079090 | 28% |
| 93364367 | Eicher Tractor Supporting Strip                    | 48    | 87084000 | 18% |
| 93364379 | Eicher Tractor Foot Board Right                    | 4199  | 87089900 | 18% |
| 93364380 | Eicher Tractor Support Strip (Foot Board)          | 102   | 87089900 | 18% |
| 93364409 | Eicher Tractor Flywheel Housing For Mspto          | 29061 | 87084000 | 18% |
| 93364434 | Eicher Tractor Mudguard Red Sticker -557           | 46    | 39199090 | 18% |
| 93364574 | Eicher Tractor Mudgaurd Support Plate              | 119   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93364586 | Eicher Tractor Top Cover Big (Platform)            | 1142  | 87084000 | 18% |
| 93364604 | Eicher Tractor Front Grill (Bonnet)                | 523   | 87089900 | 18% |
| 93364616 | Eicher Tractor Grill Mtg. Bkt.                     | 59    | 87089900 | 18% |
| 93364628 | Eicher Tractor Tension Tie Assy (Brake)            | 304   | 87083000 | 18% |
| 93364653 | Eicher Tractor Clutch Pedal                        | 1951  | 87089300 | 18% |
| 93364677 | Eicher Tractor Shield Bkt. Bottom (Radiator)       | 366   | 87087000 | 18% |
| 93364690 | Eicher Tractor Foam                                | 345   | 39219099 | 18% |
| 93364707 | Eicher Tractor Foam                                | 37    | 39219099 | 18% |
| 93364719 | Eicher Tractor Latch (Alternator)                  | 183   | 84099941 | 28% |
| 93364770 | Eicher Tractor Bracket Rec Bottle(Radiator Side)   | 85    | 87089900 | 18% |
| 93364793 | Eicher Tractor Silencer Assy                       | 4818  | 87089200 | 18% |
| 93364835 | Eicher Tractor Foam (Bonnet Top)                   | 355   | 39219099 | 18% |
| 93364859 | Eicher Tractor Draw Bar                            | 3613  | 87089900 | 18% |
| 93364860 | Eicher Tractor Steering Column Assy                | 3762  | 87089400 | 18% |
| 93364900 | Eicher Tractor Radiator Alu. Without Recovery      | 15841 | 87087000 | 18% |
| 93364950 | Eicher Tractor Rubber Boot                         | 111   | 40169320 | 18% |
| 93364973 | Eicher Tractor Silencer Assy                       | 5278  | 87089200 | 18% |
| 93365219 | Eicher Tractor Bonet Mtg Bracket Lt                | 389   | 87089900 | 18% |
| 93365220 | Eicher Tractor Bonet Mtg Bracket Rt                | 389   | 87089900 | 18% |
| 93365232 | Eicher Tractor Clamping Stud                       | 96    | 87089900 | 18% |
| 93365270 | Eicher Tractor Pad For Mudguard 14.9               | 550   | 40169320 | 18% |
| 93365281 | Eicher Tractor Pad For Mudguard 16.9               | 815   | 40169320 | 18% |
| 93365300 | Eicher Tractor Alu Radiator Assy With Recovery (50 | 14631 | 87087000 | 18% |
| 93365311 | Eicher Tractor Exhaust Muffler                     | 4596  | 87089200 | 18% |
| 93365359 | Eicher Tractor Front Axle Support                  | 35475 | 87089900 | 18% |
| 93365360 | Eicher Tractor Spacer Plate(4Wd)                   | 5894  | 73182100 | 18% |
| 93365372 | Eicher Tractor Spacer (4Wd)                        | 605   | 73182100 | 18% |
| 93365384 | Eicher Tractor Shield (Propeller Shaft)            | 6208  | 87089900 | 18% |
| 93365396 | Eicher Tractor Sheild Mtg. Bkt. (4Wd)              | 163   | 87089900 | 18% |
| 93365402 | Eicher Tractor Front Wheel Rim                     | 14671 | 87087000 | 18% |
| 93365414 | Eicher Tractor Rear Rim W15X30                     | 24676 | 87087000 | 18% |
| 93365438 | Eicher Tractor Stopper Block (4Wd)                 | 2815  | 87084000 | 18% |
| 93365499 | Eicher Tractor Lock Pin                            | 233   | 73182100 | 18% |
| 93365530 | Eicher Tractor Bonnet Lock                         | 488   | 87089900 | 18% |
| 93365542 | Eicher Tractor Gas Spring Mtg Bkt                  | 653   | 87089900 | 18% |
| 93365554 | Eicher Tractor Firewall Assy                       | 8301  | 87089900 | 18% |
| 93365578 | Eicher Tractor Bottom Plate (Bonnet)               | 3129  | 87081010 | 18% |
| 93365580 | Eicher Tractor Air Cleaner Support Bkt             | 725   | 87089900 | 18% |
| 93365591 | Eicher Tractor Hinge Pin (Bonnet)                  | 92    | 73182100 | 18% |
| 93365610 | Eicher Tractor Mtg Bkt Rear (Left) Engine Cover    | 54    | 87089900 | 18% |
| 93365621 | Eicher Tractor Mtg Bkt Rear Right (Engine Cover)   | 54    | 87089900 | 18% |
| 93365657 | Eicher Tractor Engine Cover Mtg Left (Engine Cover | 861   | 39239020 | 18% |
| 93365669 | Eicher Tractor Lower Mtg Bkt Left (Engine Cover)   | 345   | 87089900 | 18% |
| 93365670 | Eicher Tractor Lower Mtg Bkt Right (Engine Cover)  | 567   | 87089900 | 18% |
| 93365682 | Eicher Tractor Mounting Bkt Right (Engine Cover)   | 566   | 87089900 | 18% |
| 93365750 | Eicher Tractor Brake Pedal Assy. Rt                | 1671  | 87083000 | 18% |
| 93365761 | Eicher Tractor Brake Pedal Assy Lt                 | 1651  | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93365773 | Eicher Tractor Clutch Pedal Assy.              | 1645  | 87089300 | 18% |
| 93365785 | Eicher Tractor Pin (Snap Fit)                  | 57    | 73182100 | 18% |
| 93365797 | Eicher Tractor Bracket (Snap Fit)              | 15    | 87089900 | 18% |
| 93365827 | Eicher Tractor Lock Mounting Bkt               | 219   | 87089900 | 18% |
| 93365839 | Eicher Tractor Steering Cover Mtg Bkt (Lt)     | 899   | 87089900 | 18% |
| 93365840 | Eicher Tractor Steering Cover Mtg Bkt (Rt)     | 899   | 87089900 | 18% |
| 93365852 | Eicher Tractor Front Mtg Bkt - Fuel Tank       | 2467  | 87089900 | 18% |
| 93365864 | Eicher Tractor Rear Mtg Bkt - Fuel Tank        | 1651  | 87089900 | 18% |
| 93365888 | Eicher Tractor Rubber Strap Front              | 300   | 40169320 | 18% |
| 93365890 | Eicher Tractor Steel Strap Rear                | 372   | 87089900 | 18% |
| 93365906 | Eicher Tractor Bonnet Pin                      | 167   | 73182100 | 18% |
| 93365918 | Eicher Tractor Bonnet Lock Spring              | 9     | 73182100 | 18% |
| 93365920 | Eicher Tractor Rubber Strap Rear               | 281   | 40169320 | 18% |
| 93365931 | Eicher Tractor Steel Strap Front               | 373   | 87089900 | 18% |
| 93366029 | Eicher Tractor Cover Front (Fuel Tank)         | 837   | 87084000 | 18% |
| 93366030 | Eicher Tractor Cover Middle (Fuel Tank)        | 1524  | 87084000 | 18% |
| 93366078 | Eicher Tractor Gas Spring                      | 2320  | 87089900 | 18% |
| 93366080 | Eicher Tractor Shuttle Lever                   | 263   | 87089900 | 18% |
| 93366091 | Eicher Tractor Shuttle Link Rod                | 349   | 87089900 | 18% |
| 93366108 | Eicher Tractor Food Acc Pedal Assy             | 169   | 87083000 | 18% |
| 93366157 | Eicher Tractor Hand Accelerator Rod            | 329   | 84099941 | 28% |
| 93366169 | Eicher Tractor Grab Handle Right               | 1081  | 87084000 | 18% |
| 93366170 | Eicher Tractor Hand Accelerator Lever          | 146   | 87089900 | 18% |
| 93366182 | Eicher Tractor Bonnet Graphic Left             | 424   | 39199090 | 18% |
| 93366194 | Eicher Tractor Bonnet Graphic Right            | 495   | 39199090 | 18% |
| 93366236 | Eicher Tractor Rubber Bellow (For Acc. Lever)  | 81    | 40169320 | 18% |
| 93366248 | Eicher Tractor Grab Handle Left                | 1081  | 87084000 | 18% |
| 93366250 | Eicher Tractor Clamp Rubber                    | 16    | 40169320 | 18% |
| 93366261 | Eicher Tractor Glass Shield (Grab Handle)      | 665   | 87089900 | 18% |
| 93366303 | Eicher Tractor Pedal Support . Bkt             | 7234  | 87083000 | 18% |
| 93366315 | Eicher Tractor Foot Step                       | 4316  | 87089900 | 18% |
| 93366327 | Eicher Tractor Platform Left                   | 6550  | 87089900 | 18% |
| 93366339 | Eicher Tractor Platform Right                  | 6632  | 87089900 | 18% |
| 93366364 | Eicher Tractor Heat Shield Exhaust Elbow Front | 241   | 87089900 | 18% |
| 93366376 | Eicher Tractor Support Bracket Front Lh        | 511   | 87089900 | 18% |
| 93366388 | Eicher Tractor Support Bracket Front Rh        | 511   | 87089900 | 18% |
| 93366390 | Eicher Tractor Hood Assembly                   | 44088 | 84219900 | 18% |
| 93366480 | Eicher Tractor Front Grill Top                 | 991   | 87089900 | 18% |
| 93366492 | Eicher Tractor Front Grill Bottom              | 802   | 87089900 | 18% |
| 93366509 | Eicher Tractor Side Grill - Lt                 | 554   | 87089900 | 18% |
| 93366510 | Eicher Tractor Side Grill - Rt                 | 554   | 87089900 | 18% |
| 93366522 | Eicher Tractor Side Grill Small - Lt           | 257   | 87089900 | 18% |
| 93366534 | Eicher Tractor Side Grill Small - Rt           | 257   | 87089900 | 18% |
| 93366560 | Eicher Tractor Chrome Grille Front             | 2033  | 87089900 | 18% |
| 93366571 | Eicher Tractor Binnacle Console                | 2622  | 85122010 | 18% |
| 93366583 | Eicher Tractor Binnacle Back Cover             | 653   | 87089900 | 18% |
| 93366595 | Eicher Tractor Binnacle Side Cover Lt          | 4394  | 87084000 | 18% |





|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93366601 | Eicher Tractor Binnacle Side Cover Rt               | 4683  | 87084000 | 18% |
| 93366613 | Eicher Tractor Mounting Bkt (Binnacle Flange)       | 247   | 87089900 | 18% |
| 93366625 | Eicher Tractor Flange Middle Binnacle               | 94    | 87084000 | 18% |
| 93366649 | Eicher Tractor Engine Cover Rt                      | 1015  | 39239020 | 18% |
| 93366650 | Eicher Tractor Engine Cover Assembly Left           | 1127  | 39239020 | 18% |
| 93366662 | Eicher Tractor Adopter Plate (Silencer)             | 300   | 87085000 | 18% |
| 93366674 | Eicher Tractor Gasket For Silencer Mtg (Inlet Side) | 126   | 68129090 | 18% |
| 93366686 | Eicher Tractor Heat Shield Exhaust Elbow Rear       | 241   | 87089900 | 18% |
| 93366716 | Eicher Tractor Steering Cover Lt                    | 593   | 87089900 | 18% |
| 93366728 | Eicher Tractor Steering Cover Rt                    | 598   | 87089900 | 18% |
| 93366730 | Eicher Tractor Steering Cover Centre                | 772   | 87089900 | 18% |
| 93366741 | Eicher Tractor Fuel Tank                            | 15430 | 87089900 | 18% |
| 93366753 | Eicher Tractor Mud Flap                             | 922   | 87089900 | 18% |
| 93366832 | Eicher Tractor Fender Assy. Left                    | 52394 | 87089900 | 18% |
| 93366844 | Eicher Tractor Fender Assy. Right                   | 52394 | 87089900 | 18% |
| 93366868 | Eicher Tractor Rubber Packing Front                 | 184   | 40169320 | 18% |
| 93366893 | Eicher Tractor Shuttle Knob                         | 184   | 87084000 | 18% |
| 93366947 | Eicher Tractor Hose Guard                           | 670   | 40093100 | 18% |
| 93366960 | Eicher Tractor Sticker Red-560                      | 56    | 39199090 | 18% |
| 93366984 | Eicher Tractor Boost Pipe                           | 726   | 87089900 | 18% |
| 93366996 | Eicher Tractor Front Axle Support                   | 13038 | 87089900 | 18% |
| 93367009 | Eicher Tractor Air Cleaner Mtg. Bracket             | 2799  | 84099941 | 28% |
| 93367010 | Eicher Tractor Radiator Pad                         | 93    | 87087000 | 18% |
| 93367034 | Eicher Tractor Foot Rest Support                    | 242   | 87089900 | 18% |
| 93367060 | Eicher Tractor Fuel Shut Off Lever                  | 89    | 87089900 | 18% |
| 93367071 | Eicher Tractor Brake Pedal Assy Lt                  | 1454  | 87083000 | 18% |
| 93367083 | Eicher Tractor Brake Pedal Assy Rt                  | 1966  | 87083000 | 18% |
| 93367095 | Eicher Tractor Special Cup Washer                   | 6     | 73182990 | 18% |
| 93367101 | Eicher Tractor Platform Left                        | 3875  | 87089900 | 18% |
| 93367113 | Eicher Tractor Platform Right                       | 2498  | 87089900 | 18% |
| 93367125 | Eicher Tractor Support Bracket (Air Intake Tube)    | 95    | 84099941 | 28% |
| 93367137 | Eicher Tractor Shield Bkt. Top (Radiator)           | 405   | 87087000 | 18% |
| 93367150 | Eicher Tractor Rear Rim W15Lx28 Silver              | 23058 | 87087000 | 18% |
| 93367186 | Eicher Tractor Plastic Plug M20                     | 4     | 39021000 | 18% |
| 93367198 | Eicher Tractor Hose Clamp                           | 56    | 73269099 | 18% |
| 93367216 | Eicher Tractor Quadra Drive Sticker                 | 47    | 83100090 | 18% |
| 93367228 | Eicher Tractor Feature Sticker                      | 34    | 39199090 | 18% |
| 93367230 | Eicher Tractor Robust Epicyclic Reduction Sticker   | 62    | 39199090 | 18% |
| 93367241 | Eicher Tractor Robust Epicyclic Reduction Sticker   | 62    | 39199090 | 18% |
| 93367253 | Eicher Tractor Eicher 557 Graphic Sticker           | 217   | 39199090 | 18% |
| 93367265 | Eicher Tractor Spacer                               | 114   | 73182100 | 18% |
| 93367289 | Eicher Tractor Main Mounting Bracket                | 736   | 87089900 | 18% |
| 93367290 | Eicher Tractor Cassete Seal 57*85*12                | 558   | 40169330 | 18% |
| 93367332 | Eicher Tractor Bkt For Swinging Draw Bar            | 11396 | 87089900 | 18% |
| 93367344 | Eicher Tractor Swinging Draw Bar 557/548            | 4641  | 87089900 | 18% |
| 93367356 | Eicher Tractor Hinge Pin                            | 421   | 73182100 | 18% |
| 93367368 | Eicher Tractor Hitch Pin                            | 347   | 73182100 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93367370 | Eicher Tractor Sticker P-Line                 | 56   | 39199090 | 18% |
| 93367393 | Eicher Tractor Sticker - Features             | 33   | 39199090 | 18% |
| 93367447 | Eicher Tractor Bkt. For Swinging Draw Bar 548 | 9598 | 87089900 | 18% |
| 93367496 | Eicher Tractor Plastics Plug M8X1.25          | 2    | 39021000 | 18% |
| 93367502 | Eicher Tractor Plastics Plug M16X1.25         | 3    | 39021000 | 18% |
| 93367514 | Eicher Tractor Plastics Plug M18X2.5          | 4    | 39021000 | 18% |
| 93367538 | Eicher Tractor Strut Stabiliser Assy          | 3507 | 87089900 | 18% |
| 93367575 | Eicher Tractor Battery Mtg Bkt                | 710  | 85079090 | 28% |
| 93367587 | Eicher Tractor Front Weight Middle-Rt         | 6299 | 87081010 | 18% |
| 93367599 | Eicher Tractor Foot Acc Pedal Assy            | 141  | 87089900 | 18% |
| 93367605 | Eicher Tractor Front Weight Middle-Lt         | 6299 | 87081010 | 18% |
| 93367617 | Eicher Tractor Lifting Gear Mechanism         | 3359 | 87089900 | 18% |
| 93367629 | Eicher Tractor Fork And Guide Mechanism       | 2878 | 87089900 | 18% |
| 93367630 | Eicher Tractor Lower Link                     | 4107 | 87089900 | 18% |
| 93367642 | Eicher Tractor Lift Arm                       | 3587 | 87089900 | 18% |
| 93367678 | Eicher Tractor Suction Pipe (Tank Unit To Ws) | 344  | 87089900 | 18% |
| 93367691 | Eicher Tractor Strap Pin                      | 68   | 73182100 | 18% |
| 93367733 | Eicher Tractor Plastic Cap M8                 | 2    | 39021000 | 18% |
| 93367939 | Eicher Tractor Gasket B/W Ex.Maifold And      | 29   | 68129090 | 18% |
| 93367940 | Eicher Tractor Front Weight Left              | 4944 | 87081010 | 18% |
| 93367952 | Eicher Tractor Front Weight Right             | 4944 | 87081010 | 18% |
| 93367964 | Eicher Tractor Front Weight                   | 4894 | 87081010 | 18% |
| 93367976 | Eicher Tractor Pin Assy                       | 394  | 73182100 | 18% |
| 93367988 | Eicher Tractor Hex Bolt M20X250,B8.8,Zp       | 381  | 73181500 | 18% |
| 93367990 | Eicher Tractor Lever (Bottom)                 | 133  | 87089900 | 18% |
| 93368002 | Eicher Tractor Adaptor                        | 942  | 87089900 | 18% |
| 93368014 | Eicher Tractor Rubber Bellow                  | 82   | 40169320 | 18% |
| 93368075 | Eicher Tractor Stopper Plate                  | 44   | 87084000 | 18% |
| 93368245 | Eicher Tractor Clamping Latch                 | 115  | 87089900 | 18% |
| 93368282 | Eicher Tractor Rubber Packing Rear            | 156  | 40169320 | 18% |
| 93368300 | Eicher Tractor Washer (Back Rest)             | 59   | 73182100 | 18% |
| 93368312 | Eicher Tractor Lower Channel Lt               | 704  | 87089900 | 18% |
| 93368324 | Eicher Tractor Lower Channel Rt               | 704  | 87089900 | 18% |
| 93368336 | Eicher Tractor Mirror Assy                    | 450  | 70091090 | 18% |
| 93368385 | Eicher Tractor Washer (Mud Flap)              | 59   | 73182100 | 18% |
| 93368397 | Eicher Tractor Over Flow Pipe Assay           | 435  | 87089900 | 18% |
| 93368403 | Eicher Tractor Fuel Pipe (Fip To Ff)          | 326  | 84099941 | 28% |
| 93368415 | Eicher Tractor Fuel Pipe (Ff To Fip)          | 318  | 84099941 | 28% |
| 93368427 | Eicher Tractor Foot Acc Shaft                 | 132  | 87085000 | 18% |
| 93368439 | Eicher Tractor Accelerator Lever Left         | 37   | 87084000 | 18% |
| 93368440 | Eicher Tractor Accelerator Lever Rt           | 135  | 87084000 | 18% |
| 93368452 | Eicher Tractor Bottom Lever (Acc)             | 150  | 87089900 | 18% |
| 93368464 | Eicher Tractor Connecting Link (Fip)          | 125  | 87089900 | 18% |
| 93368476 | Eicher Tractor Upper Link (Acc)               | 84   | 87089900 | 18% |
| 93368488 | Eicher Tractor Brake Shaft                    | 1221 | 87083000 | 18% |
| 93368490 | Eicher Tractor Brake Lever                    | 609  | 87089900 | 18% |
| 93368506 | Eicher Tractor Brake Lever Rt                 | 710  | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93368518 | Eicher Tractor Brake Lever Lt                      | 563  | 87089900 | 18% |
| 93368520 | Eicher Tractor Tension Tie Brake                   | 185  | 87083000 | 18% |
| 93368531 | Eicher Tractor Brake Link Rear                     | 214  | 87083000 | 18% |
| 93368543 | Eicher Tractor Drain Plug (Fuel Tank)              | 176  | 87084000 | 18% |
| 93368580 | Eicher Tractor Top Cover Assy                      | 5132 | 87084000 | 18% |
| 93368592 | Eicher Tractor Cover (Aux. Valve)                  | 1047 | 87084000 | 18% |
| 93368610 | Eicher Tractor Top Cover Mtg Bkt                   | 409  | 87089900 | 18% |
| 93368622 | Eicher Tractor Upper Bracket Assy                  | 55   | 87089900 | 18% |
| 93368634 | Eicher Tractor Chain Assy (Acc)                    | 186  | 87089900 | 18% |
| 93368646 | Eicher Tractor D D Seat Mtg Bkt                    | 2396 | 87089900 | 18% |
| 93368658 | Eicher Tractor Back Rest Right                     | 1655 | 87089900 | 18% |
| 93368660 | Eicher Tractor Back Rest Left                      | 1327 | 87089900 | 18% |
| 93368671 | Eicher Tractor Mtg. Bkt (Binnacle Assy)            | 681  | 87089900 | 18% |
| 93368683 | Eicher Tractor Bonnet Cushion                      | 60   | 87089900 | 18% |
| 93368695 | Eicher Tractor Cover (Aux. Lever)                  | 288  | 87084000 | 18% |
| 93368713 | Eicher Tractor Stud M12X33, A10.9, Bp              | 33   | 73182100 | 18% |
| 93368750 | Eicher Tractor Battery Tray Assly                  | 2320 | 85079090 | 28% |
| 93368762 | Eicher Tractor Sticker Red-551                     | 51   | 39199090 | 18% |
| 93368786 | Eicher Tractor Pipe (Water Seperator To Sed Bowl)  | 235  | 87089900 | 18% |
| 93368804 | Eicher Tractor Bracket - Water Seperator Mtg       | 464  | 87089900 | 18% |
| 93368816 | Eicher Tractor Bkt Front Weight                    | 7816 | 87081010 | 18% |
| 93368841 | Eicher Tractor Air Intake Hose (Ac-Tc)             | 987  | 40093100 | 18% |
| 93368865 | Eicher Tractor Air Cleaner Mtg. Bracket            | 807  | 84099941 | 28% |
| 93368889 | Eicher Tractor Mudguard Red Sticker-650            | 52   | 39199090 | 18% |
| 93368944 | Eicher Tractor Gasket For Silencer Mtg (Outlet)    | 128  | 68129090 | 18% |
| 93368968 | Eicher Tractor Support Bkt Rt (Recovery Bottle)    | 149  | 87089900 | 18% |
| 93368970 | Eicher Tractor Support Bkt Lt (Recovery Bottle)    | 144  | 87089900 | 18% |
| 93368981 | Eicher Tractor Rubber Pad (A/C Support Bkt)        | 25   | 40169990 | 18% |
| 93369018 | Eicher Tractor Strip For Radiator (85 Hp)          | 67   | 87087000 | 18% |
| 93369020 | Eicher Tractor Dry A/C Support Strip               | 75   | 84099941 | 28% |
| 93369043 | Eicher Tractor Bottom Shield Bkt (Radiator)        | 292  | 87089900 | 18% |
| 93369055 | Eicher Tractor Support Rear (Steering Cover Mtg)   | 36   | 87089900 | 18% |
| 93369067 | Eicher Tractor Steering Cover Mtg Support          | 162  | 87089900 | 18% |
| 93369079 | Eicher Tractor Pivot Bkt (Fuel Shut Off)           | 121  | 73181500 | 18% |
| 93369080 | Eicher Tractor Link (Fuel Shut Off)                | 83   | 87089900 | 18% |
| 93369092 | Eicher Tractor Pivot Lever (Fuel Shut Off)         | 78   | 73181500 | 18% |
| 93369109 | Eicher Tractor Wire Sleeve Mtg Clamp (Fuel Shut Of | 40   | 87089900 | 18% |
| 93369110 | Eicher Tractor Wire Sleeve Guide (Fuel Shut Off)   | 52   | 84099941 | 28% |
| 93369122 | Eicher Tractor Wire Rod Assy                       | 112  | 85122010 | 18% |
| 93369134 | Eicher Tractor Link Guide (Fuel Shut Off)          | 8    | 87089900 | 18% |
| 93369146 | Eicher Tractor Pin Small (Fuel Shut Off)           | 34   | 84099941 | 28% |
| 93369158 | Eicher Tractor Mudguard Silver Sticker - Eicher    | 76   | 39199090 | 18% |
| 93369160 | Eicher Tractor Mudguard Silver Stiker - 548        | 20   | 39199090 | 18% |
| 93369183 | Eicher Tractor Platform Rt Small                   | 619  | 87089900 | 18% |
| 93369195 | Eicher Tractor Eicher 884 Sticker Lt               | 444  | 39199090 | 18% |
| 93369201 | Eicher Tractor Eicher 884 Sticker Rt               | 444  | 39199090 | 18% |
| 93369213 | Eicher Tractor Steering Column                     | 2781 | 87089400 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93369225 | Eicher Tractor Steering Cylinder                   | 13964 | 87089400 | 18% |
| 93369237 | Eicher Tractor Accelerator Knob                    | 184   | 87089900 | 18% |
| 93369249 | Eicher Tractor Dry Air Cleaner Assy                | 8188  | 84213920 | 18% |
| 93369262 | Eicher Tractor Firewall Support Plate              | 314   | 87089900 | 18% |
| 93369407 | Eicher Tractor Fuel Pipe (Ffp To Ff)               | 405   | 84099941 | 28% |
| 93369419 | Eicher Tractor Fuel Pipe (Ff To Fip)               | 260   | 84099941 | 28% |
| 93369626 | Eicher Tractor Swinging Draw Bar                   | 14917 | 87089900 | 18% |
| 93369651 | Eicher Tractor 557 Mudguard Sticker (Silver)       | 20    | 39199090 | 18% |
| 93369730 | Eicher Tractor Top Cover Small                     | 84    | 87084000 | 18% |
| 93369754 | Eicher Tractor Boarding Handle                     | 620   | 87084000 | 18% |
| 93369780 | Eicher Tractor Lower Link Assy                     | 7357  | 87089900 | 18% |
| 93369810 | Eicher Tractor Plastic Plug M10                    | 2     | 39021000 | 18% |
| 93369821 | Eicher Tractor Rubber Cap (Pto)                    | 18    | 40169320 | 18% |
| 93369833 | Eicher Tractor Eicher 551 Sticker                  | 218   | 39199090 | 18% |
| 93369845 | Eicher Tractor Front Rim 5.5X16 Top Coat Off White | 4770  | 87087000 | 18% |
| 93369857 | Eicher Tractor Shim 0.2 Mm                         | 11    | 73182100 | 18% |
| 93369882 | Eicher Tractor Front Axle Assy (85 Hp)             | 31346 | 87085000 | 18% |
| 93369894 | Eicher Tractor Rubber Bellow Stg. Column 548       | 66    | 40169320 | 18% |
| 93369912 | Eicher Tractor Flywheel Housing                    | 32372 | 87084000 | 18% |
| 93369950 | Eicher Tractor Fuel Pipe - (Ws To Feed Pump)       | 246   | 84099941 | 28% |
| 93369961 | Eicher Tractor Foot Board Right                    | 1626  | 87089900 | 18% |
| 93370999 | Eicher Tractor Hand Acc. Rod (650)                 | 341   | 84099941 | 28% |
| 93371001 | Eicher Tractor Hand Acc. Lever (650)               | 293   | 87089900 | 18% |
| 93371013 | Eicher Tractor Mounting Bkt (Acc-650)              | 264   | 87089900 | 18% |
| 93371049 | Eicher Tractor Steering Column (650)               | 2718  | 87089400 | 18% |
| 93371130 | Eicher Tractor Front Bumper                        | 11172 | 87081010 | 18% |
| 93371141 | Eicher Tractor Bumper Mtg Bracket                  | 3089  | 87081010 | 18% |
| 93371153 | Eicher Tractor Front Bumper                        | 13005 | 87081010 | 18% |
| 93371177 | Eicher Tractor Front Axle Assy (380)               | 15536 | 87085000 | 18% |
| 93371189 | Eicher Tractor Front Axle Assy (551)               | 17736 | 87085000 | 18% |
| 93371190 | Eicher Tractor Beading Harness Cover               | 21    | 85123010 | 18% |
| 93371232 | Eicher Tractor Bumper Mtg. Bracket                 | 3132  | 87081010 | 18% |
| 93371244 | Eicher Tractor Front Bumper 548 Ms                 | 11192 | 87081010 | 18% |
| 93371256 | Eicher Tractor Bumper Mtg. Bracket                 | 3431  | 87081010 | 18% |
| 93371268 | Eicher Tractor Bonnet Mtg. Bkt. Left               | 483   | 87089900 | 18% |
| 93371270 | Eicher Tractor Bonnet Mtg. Bkt. Right              | 483   | 87089900 | 18% |
| 93371300 | Eicher Tractor Front Axle Support                  | 14510 | 87089900 | 18% |
| 93371311 | Eicher Tractor Front Bumper                        | 14569 | 87081010 | 18% |
| 93371323 | Eicher Tractor Front Axle Support                  | 22471 | 87089900 | 18% |
| 93371335 | Eicher Tractor Front Axle Support Assy.            | 16501 | 87089900 | 18% |
| 93371347 | Eicher Tractor Bonnet Mtg Bkt Left                 | 217   | 87089900 | 18% |
| 93371359 | Eicher Tractor Bonnet Mounting Bkt Left            | 217   | 87089900 | 18% |
| 93371426 | Eicher Tractor Front Axle Assy (5660-Ps)           | 26575 | 87085000 | 18% |
| 93371438 | Eicher Tractor Front End Right.                    | 8396  | 87085000 | 18% |
| 93371451 | Eicher Tractor Front End Left                      | 8396  | 87085000 | 18% |
| 93371463 | Eicher Tractor Front Axle Assy (5660-Ms)           | 11283 | 87085000 | 18% |
| 93371487 | Eicher Tractor Front Axle Assy                     | 25899 | 87085000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93371499 | Eicher Tractor Bush Ø32XØ40X40                     | 480   | 84833000 | 18% |
| 93371505 | Eicher Tractor Thrust Washer                       | 183   | 73182100 | 18% |
| 93371517 | Eicher Tractor Felt Ring 32X40X5                   | 12    | 87084000 | 18% |
| 93371554 | Eicher Tractor Oil Seal 32X40X6                    | 72    | 40169330 | 18% |
| 93371580 | Eicher Tractor On Off Part Assy.                   | 453   | 87089900 | 18% |
| 93371670 | Eicher Tractor Silencer Assy (551)                 | 6661  | 87089200 | 18% |
| 93371682 | Eicher Tractor Elbow Exhaust 551                   | 1775  | 87089200 | 18% |
| 93371712 | Eicher Tractor Gasket For Silencer                 | 114   | 68129090 | 18% |
| 93371724 | Eicher Tractor Lifting Gear Mechanism              | 3926  | 87089900 | 18% |
| 93371736 | Eicher Tractor Upper Fork                          | 1214  | 87089900 | 18% |
| 93371748 | Eicher Tractor Lower Fork                          | 1507  | 87089900 | 18% |
| 93371761 | Eicher Tractor Front Axle                          | 21152 | 87085000 | 18% |
| 93371773 | Eicher Tractor Stub Axle Left                      | 5231  | 87085000 | 18% |
| 93371931 | Eicher Tractor Eicher 776 Sticker Lt               | 444   | 39199090 | 18% |
| 93371943 | Eicher Tractor Eicher 776 Sticker Rt               | 444   | 39199090 | 18% |
| 93372030 | Eicher Tractor Stub Axle Right                     | 5241  | 87085000 | 18% |
| 93372078 | Eicher Tractor Front Axle                          | 20830 | 87085000 | 18% |
| 93372248 | Eicher Tractor Front Wheel Hub                     | 2659  | 87087000 | 18% |
| 93372250 | Eicher Tractor Front Wheel Hub                     | 2378  | 87087000 | 18% |
| 93372352 | Eicher Tractor Silencer                            | 4609  | 87089200 | 18% |
| 93372364 | Eicher Tractor Exhaust Elbow                       | 1589  | 87089200 | 18% |
| 93372390 | Eicher Tractor Support Bracket (650)               | 89    | 87089900 | 18% |
| 93372406 | Eicher Tractor Spacer Gas Spring Mtg Bkt Support   | 187   | 87089900 | 18% |
| 93372420 | Eicher Tractor Hand Acc. Linkage Assy-650          | 572   | 87083000 | 18% |
| 93372480 | Eicher Tractor Guard Front Pipe-Silencer           | 773   | 87089900 | 18% |
| 93372534 | Eicher Tractor Rubber Beading Side Radiator- 480 M | 87    | 87087000 | 18% |
| 93372546 | Eicher Tractor Rubber Beading Top Radiator- 285 Mm | 51    | 87087000 | 18% |
| 93372558 | Eicher Tractor Top Link Assy                       | 3757  | 87089900 | 18% |
| 93372560 | Eicher Tractor Top Link Assy                       | 3528  | 87089900 | 18% |
| 93372595 | Eicher Tractor Fuel Duct Assy                      | 179   | 84099941 | 28% |
| 93372601 | Eicher Tractor Hand Acc. Rod                       | 318   | 84099941 | 28% |
| 93372637 | Eicher Tractor Upper Fork                          | 1214  | 87089900 | 18% |
| 93372649 | Eicher Tractor Lower Fork                          | 1507  | 87089900 | 18% |
| 93372716 | Eicher Tractor Fuel Tank Clamp                     | 331   | 73182100 | 18% |
| 93372777 | Eicher Tractor Case Transmission Front             | 50200 | 87089900 | 18% |
| 93372790 | Eicher Tractor Dry A/C Hose                        | 1149  | 40093100 | 18% |
| 93372807 | Eicher Tractor Rear Wheel W13X28                   | 19338 | 87087000 | 18% |
| 93372819 | Eicher Tractor Rear Wheel W15Lx28                  | 25607 | 87087000 | 18% |
| 93372820 | Eicher Tractor Front Rim 5.5X16 Top Coat Orange-Kn | 5143  | 87087000 | 18% |
| 93372832 | Eicher Tractor Rear Wheel W15X28 (Twin Lug)        | 24660 | 87087000 | 18% |
| 93372868 | Eicher Tractor Harness Cover Assy.(Non-Hyd.)       | 145   | 85123010 | 18% |
| 93372870 | Eicher Tractor Harness Cover Assy.(Hyd.)           | 175   | 85123010 | 18% |
| 93372881 | Eicher Tractor Fuel Cooler Assy                    | 3725  | 87087000 | 18% |
| 93372911 | Eicher Tractor Front Bumper                        | 16126 | 87081010 | 18% |
| 93372959 | Eicher Tractor Fuel Pipe - ( Ws To Sed Bowl)       | 410   | 84099941 | 28% |
| 93372960 | Eicher Tractor Inlet Hose (Of To Fuel Cooler)      | 371   | 40093100 | 18% |
| 93372972 | Eicher Tractor Outlet Hose Assy (Fc To Ft)         | 1112  | 40093100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93372984 | Eicher Tractor Resting Bkt                         | 214   | 87089900 | 18% |
| 93372996 | Eicher Tractor Pipe Cover                          | 675   | 87089900 | 18% |
| 93373009 | Eicher Tractor Pvc Clamp                           | 28    | 87084000 | 18% |
| 93373010 | Eicher Tractor Shield Bkt. Bottom (Radiator)       | 282   | 87087000 | 18% |
| 93373022 | Eicher Tractor Overflow Pipe                       | 198   | 87089900 | 18% |
| 93373034 | Eicher Tractor Corrugated Tube                     | 56    | 85443000 | 18% |
| 93373046 | Eicher Tractor Rubber Beading (650)                | 16    | 40169320 | 18% |
| 93373060 | Eicher Tractor Water Separator Bracket             | 197   | 87089900 | 18% |
| 93373071 | Eicher Tractor Bonnet Hinge Bracket                | 4801  | 87089900 | 18% |
| 93373083 | Eicher Tractor Main Mtg. Bracket                   | 1418  | 87089900 | 18% |
| 93373095 | Eicher Tractor Heat Shield Bkt Lt                  | 583   | 87089900 | 18% |
| 93373101 | Eicher Tractor Heat Shield Bkt Rt                  | 440   | 87089900 | 18% |
| 93373113 | Eicher Tractor Top Cover Big (Platform)            | 1401  | 87084000 | 18% |
| 93373149 | Eicher Tractor Shield Bkt. Top (Radiator)          | 396   | 87087000 | 18% |
| 93373162 | Eicher Tractor Bonnet Graphic Lt - 650             | 347   | 39199090 | 18% |
| 93373174 | Eicher Tractor Bonnet Graphic Rt - 650             | 347   | 39199090 | 18% |
| 93373186 | Eicher Tractor Quadra Drive Lt Sticker             | 97    | 39199090 | 18% |
| 93373198 | Eicher Tractor Quadra Drive Rt Sticker             | 97    | 39199090 | 18% |
| 93373204 | Eicher Tractor Front Axle Assy                     | 37008 | 87085000 | 18% |
| 93373228 | Eicher Tractor Connecting Rod Assy                 | 3568  | 87089900 | 18% |
| 93373230 | Eicher Tractor Flywheel Housing-557                | 37591 | 87084000 | 18% |
| 93373241 | Eicher Tractor Cover -Fas                          | 34    | 87084000 | 18% |
| 93373368 | Eicher Tractor Acce Linkage Sub Assy               | 1236  | 87083000 | 18% |
| 93373370 | Eicher Tractor Clamping Bracket                    | 84    | 87089900 | 18% |
| 93373484 | Eicher Tractor Hand Brake Lever Assy               | 1027  | 87083000 | 18% |
| 93373502 | Eicher Tractor Harness Cover Assy                  | 242   | 85123010 | 18% |
| 93373551 | Eicher Tractor Foot Accelerator Shaft Guide        | 141   | 87084000 | 18% |
| 93373563 | Eicher Tractor Foot Accelerator Shaft              | 165   | 87084000 | 18% |
| 93373575 | Eicher Tractor Foot Board Right                    | 859   | 87089900 | 18% |
| 93373587 | Eicher Tractor Air Cleaner Bkt                     | 1016  | 87089900 | 18% |
| 93373605 | Eicher Tractor Accelerator Linkage Sub Assy        | 1198  | 87083000 | 18% |
| 93373617 | Eicher Tractor Pedal Shaft                         | 1275  | 87084000 | 18% |
| 93373708 | Eicher Tractor Flywheel Housing 557                | 43772 | 87084000 | 18% |
| 93373710 | Eicher Tractor Rubber Beading Hood - 950 Mm        | 205   | 40169320 | 18% |
| 93373769 | Eicher Tractor Label Plate (For Export)            | 111   | 39199090 | 18% |
| 93373861 | Eicher Tractor Adj. Tie Rod End Rh                 | 1503  | 87089400 | 18% |
| 93374221 | Eicher Tractor Plastic Cover (Red)                 | 863   | 39021000 | 18% |
| 93374233 | Eicher Tractor Plastic Cover (Blue)                | 849   | 39021000 | 18% |
| 93374245 | Eicher Tractor Plastic Cover (Silver)              | 923   | 39021000 | 18% |
| 93374257 | Eicher Tractor Link Upper                          | 272   | 87089900 | 18% |
| 93374294 | Eicher Tractor Hose Pipe (Hose Bkt To Air Cleaner) | 289   | 40093100 | 18% |
| 93374300 | Eicher Tractor Support Bracket For Recovery        | 94    | 87089900 | 18% |
| 93374312 | Eicher Tractor Lower Bracket                       | 4251  | 87089900 | 18% |
| 93374348 | Eicher Tractor Hose Pipe (Engine To Hose Bkt)      | 612   | 40093100 | 18% |
| 93374350 | Eicher Tractor Plastic Cover (Green)               | 863   | 39021000 | 18% |
| 93374361 | Eicher Tractor Accelerator Linkage Sub Assy        | 1290  | 87083000 | 18% |
| 93374373 | Eicher Tractor Accelerator Linkage Sub Assy        | 1304  | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93374440 | Eicher Tractor Adaptor                             | 644   | 87089900 | 18% |
| 93374464 | Eicher Tractor Lifting Gear Assy.                  | 3768  | 87089900 | 18% |
| 93374476 | Eicher Tractor Fork & Guide Assy.                  | 2554  | 87089900 | 18% |
| 93374592 | Eicher Tractor Front Axle Support Hydromatic       | 17725 | 87089900 | 18% |
| 93374634 | Eicher Tractor Alternator Cover                    | 572   | 87085000 | 18% |
| 93374646 | Eicher Tractor Front Axle & Support Assy           | 30717 | 87089900 | 18% |
| 93374660 | Eicher Tractor Stablizer Mtg Bkt Lh                | 2598  | 87089900 | 18% |
| 93374671 | Eicher Tractor Stablizer Mtg Bkt Rh                | 2598  | 87089900 | 18% |
| 93374683 | Eicher Tractor Lower Bkt                           | 7068  | 87089900 | 18% |
| 93374701 | Eicher Tractor Fork & Guide Mech                   | 3134  | 87089900 | 18% |
| 93374713 | Eicher Tractor Lifting Gear Mech                   | 3717  | 87089900 | 18% |
| 93374725 | Eicher Tractor Lower Link Assy                     | 5931  | 87089900 | 18% |
| 93374737 | Eicher Tractor Front Axle & Support Assy. (Exp Hyd | 31386 | 87089900 | 18% |
| 93374798 | Eicher Tractor Front Bumper                        | 12711 | 87081010 | 18% |
| 93374804 | Eicher Tractor Back Rest Right                     | 1754  | 87089900 | 18% |
| 93374816 | Eicher Tractor Back Rest Left                      | 1243  | 87089900 | 18% |
| 93374828 | Eicher Tractor Bonnet Graphics Lt - 560            | 343   | 39199090 | 18% |
| 93374830 | Eicher Tractor Bonnet Graphics Rt - 560            | 343   | 39199090 | 18% |
| 93374889 | Eicher Tractor Bonnet Graphic Lt - 548             | 337   | 39199090 | 18% |
| 93374890 | Eicher Tractor Bonnet Graphic Rt - 548             | 337   | 39199090 | 18% |
| 93374907 | Eicher Tractor Bonnet Graphics Lt - 551            | 338   | 39199090 | 18% |
| 93374919 | Eicher Tractor Bonnet Graphics Rt - 551            | 338   | 39199090 | 18% |
| 93374920 | Eicher Tractor Bonnet Graphic Lt - 557             | 337   | 39199090 | 18% |
| 93374932 | Eicher Tractor Bonnet Graphic Rt - 557             | 337   | 39199090 | 18% |
| 93374944 | Eicher Tractor Adj. Tie Rod Assy                   | 4092  | 87089400 | 18% |
| 93374970 | Eicher Tractor 50 Hp Lift Arm                      | 2631  | 87089900 | 18% |
| 93374981 | Eicher Tractor Adj. Tie Rod End Lh                 | 986   | 87089400 | 18% |
| 93375006 | Eicher Tractor Pin (Lift Arm) Non Hydromatic       | 158   | 87089900 | 18% |
| 93375018 | Eicher Tractor Inlet Hose Assy                     | 381   | 40093100 | 18% |
| 93375043 | Eicher Tractor Eicher Sticker Lt                   | 306   | 39199090 | 18% |
| 93375055 | Eicher Tractor Eicher Sticker Rt                   | 306   | 39199090 | 18% |
| 93375067 | Eicher Tractor Fuel Tank Cover Sticker Lt          | 143   | 39199090 | 18% |
| 93375079 | Eicher Tractor Fuel Tank Cover Sticker Rt          | 143   | 39199090 | 18% |
| 93375109 | Eicher Tractor Spacer                              | 15    | 73182100 | 18% |
| 93375158 | Eicher Tractor Front Bumper Assy                   | 13513 | 87081010 | 18% |
| 93375250 | Eicher Tractor Foot Board Right                    | 2873  | 87089900 | 18% |
| 93375262 | Eicher Tractor Foot Board Left                     | 2946  | 87089900 | 18% |
| 93375328 | Eicher Tractor Foot Board Right                    | 2750  | 87089900 | 18% |
| 93375390 | Eicher Tractor End Rod Rh                          | 746   | 87084000 | 18% |
| 93375407 | Eicher Tractor End Rod Lh                          | 792   | 87084000 | 18% |
| 93375419 | Eicher Tractor Mudguard Cover Plate(14.9 Tyre)     | 143   | 87089900 | 18% |
| 93375432 | Eicher Tractor Battery Mtg. Bracket(14.9 Tyre)     | 915   | 85079090 | 28% |
| 93375444 | Eicher Tractor Battery Mtg. Bracket(13.6 Tyre)     | 878   | 85079090 | 28% |
| 93375456 | Eicher Tractor Battery Mtg Bracket                 | 768   | 85079090 | 28% |
| 93375470 | Eicher Tractor Front Bumper Assy                   | 13749 | 87081010 | 18% |
| 93375481 | Eicher Tractor Front Bumper Assy                   | 17402 | 87081010 | 18% |
| 93375493 | Eicher Tractor Front Bumper Assy                   | 16786 | 87081010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93375500 | Eicher Tractor Front Bumper Foldable               | 11862 | 87081010 | 18% |
| 93375511 | Eicher Tractor Hose Clamp (Sltb-44)                | 152   | 73269099 | 18% |
| 93375523 | Eicher Tractor Hose Clamp (Sltb-52)                | 157   | 73269099 | 18% |
| 93375547 | Eicher Tractor Front Bumper Assy                   | 15250 | 87081010 | 18% |
| 93375559 | Eicher Tractor Bumper Assy                         | 17383 | 87081010 | 18% |
| 93375560 | Eicher Tractor Front Bumper Assy                   | 13303 | 87081010 | 18% |
| 93375572 | Eicher Tractor Front Bumper Assy                   | 12170 | 87081010 | 18% |
| 93375602 | Eicher Tractor Break Linkage Rt                    | 600   | 87083000 | 18% |
| 93375640 | Eicher Tractor Break Linkage Lt                    | 600   | 87083000 | 18% |
| 93375857 | Eicher Tractor P_Line Sticker                      | 50    | 39199090 | 18% |
| 93375869 | Eicher Tractor 551 Silver Sticker Mudguard         | 51    | 39199090 | 18% |
| 93376102 | Eicher Tractor Chain Assy                          | 2409  | 87089900 | 18% |
| 93376643 | Eicher Tractor Battery Cover(Non- Face Lift)       | 1275  | 85079090 | 28% |
| 93376667 | Eicher Tractor Front Axle Support(Hydromatic)      | 16527 | 87089900 | 18% |
| 93376783 | Eicher Tractor Pressure Cap 1.0 Kg/cm <sup>2</sup> | 158   | 87087000 | 18% |
| 93376874 | Eicher Tractor Battery Cover- Face Lift            | 1298  | 85079090 | 28% |
| 93377027 | Eicher Tractor Battery Tray Assy-MS                | 2654  | 85079090 | 28% |
| 93377039 | Eicher Tractor Back Cover                          | 462   | 87089900 | 18% |
| 93377040 | Eicher Tractor Tie Rod End(Lever Side)             | 1594  | 87089400 | 18% |
| 93377350 | Eicher Tractor Cover Assy Front                    | 2141  | 87089300 | 18% |
| 93377374 | Eicher Tractor Cover Assy Rear                     | 2104  | 87089300 | 18% |
| 93377398 | Eicher Tractor Bonnet Mounting Bracket Rt.         | 388   | 87089900 | 18% |
| 93377404 | Eicher Tractor Bonnet Mounting Bracket Lt.         | 388   | 87089900 | 18% |
| 93377430 | Eicher Tractor Front Axle Support                  | 18755 | 87089900 | 18% |
| 93377544 | Eicher Tractor Bonnet Mounting Bracket Lt          | 421   | 87089900 | 18% |
| 93377556 | Eicher Tractor Bonnet Mounting Bracket Rt          | 421   | 87089900 | 18% |
| 93377568 | Eicher Tractor Bonnet Mounting Bracket Lt.         | 333   | 87089900 | 18% |
| 93377570 | Eicher Tractor Bonnet Mounting Bracket Rt.         | 333   | 87089900 | 18% |
| 93377581 | Eicher Tractor Bonnet Mounting Bracket Lt.         | 326   | 87089900 | 18% |
| 93377593 | Eicher Tractor Bonnet Mounting Bracket Rt.         | 326   | 87089900 | 18% |
| 93377600 | Eicher Tractor Bonnet Mounting Bracket Lt.         | 321   | 87089900 | 18% |
| 93377611 | Eicher Tractor Bonnet Mounting Bracket Rt.         | 287   | 87089900 | 18% |
| 93377623 | Eicher Tractor Front Wheel Hub                     | 3739  | 87085000 | 18% |
| 93377635 | Eicher Tractor Fuel Tank Mounting Bracket          | 1492  | 87089900 | 18% |
| 93377660 | Eicher Tractor Mudguard Assy. Rt (Big Top)         | 16859 | 87089900 | 18% |
| 93377672 | Eicher Tractor Mudguard Assy. Lt (Big Top)         | 16857 | 87089900 | 18% |
| 93377702 | Eicher Tractor Wheel Hub(6X16)                     | 2645  | 87087000 | 18% |
| 93377714 | Eicher Tractor Wheel Hub(7.5X16)                   | 2492  | 87087000 | 18% |
| 93377726 | Eicher Tractor Stub Axle Rt                        | 6892  | 87085000 | 18% |
| 93377738 | Eicher Tractor Stub Axle Lt.                       | 6886  | 87085000 | 18% |
| 93377740 | Eicher Tractor Stub Axle (MS)                      | 6402  | 87085000 | 18% |
| 93377751 | Eicher Tractor Guard Plate                         | 48    | 87089900 | 18% |
| 93377763 | Eicher Tractor Tube                                | 89    | 87089900 | 18% |
| 93377769 | Eicher Tractor Fuel Line Assy                      | 165   | 84219900 | 18% |
| 93377775 | Eicher Tractor Front Axle Support (Non Hyd.)       | 12325 | 87089900 | 18% |
| 93377787 | Eicher Tractor Clutch Pedal                        | 1916  | 87089300 | 18% |
| 93377799 | Eicher Tractor Tension Tie Assy                    | 382   | 87083000 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93377842 | Eicher Tractor Flywheel Hsg 557                    | 45234 | 87084000 | 18% |
| 93377854 | Eicher Tractor Front Axle Support-551-4Wd          | 41223 | 87089900 | 18% |
| 93377866 | Eicher Tractor Stud Fas                            | 344   | 73182100 | 18% |
| 93377880 | Eicher Tractor Base Bkt (Air Cleaner)              | 1054  | 87089900 | 18% |
| 93377891 | Eicher Tractor Mtg Bkt Lt (Radiator)               | 494   | 87089100 | 18% |
| 93377908 | Eicher Tractor Mtg Bkt Rt (Radiator)               | 494   | 87089100 | 18% |
| 93377910 | Eicher Tractor Alternator Cover                    | 676   | 87084000 | 18% |
| 93377921 | Eicher Tractor Bonnet Mtg Bkt Lt                   | 732   | 87089900 | 18% |
| 93377933 | Eicher Tractor Bonnet Mtg Bkt Rt                   | 732   | 87089900 | 18% |
| 93377945 | Eicher Tractor Brake Pedal Assy Rt                 | 1988  | 87083000 | 18% |
| 93377957 | Eicher Tractor Brake Pedal Assy Lt                 | 1766  | 87083000 | 18% |
| 93377969 | Eicher Tractor Pedal Shaft                         | 2490  | 87084000 | 18% |
| 93377970 | Eicher Tractor Brake Linkage Assy.                 | 762   | 87083000 | 18% |
| 93378007 | Eicher Tractor Clutch Pedal Assy                   | 2022  | 87089300 | 18% |
| 93378019 | Eicher Tractor Tension Tie Assy (Clutch)           | 523   | 87083000 | 18% |
| 93378032 | Eicher Tractor Foot Board Lt                       | 1558  | 87089900 | 18% |
| 93378044 | Eicher Tractor Foot Board Rt                       | 1195  | 87089900 | 18% |
| 93378056 | Eicher Tractor Cover Plate (Hyd)                   | 198   | 87084000 | 18% |
| 93378070 | Eicher Tractor Shield Cover Bottom (Radiator)      | 859   | 87089100 | 18% |
| 93378081 | Eicher Tractor Cover Front (Propeller Shaft)       | 2037  | 87084000 | 18% |
| 93378093 | Eicher Tractor Cover Rear (Propeller Shaft)        | 1622  | 87084000 | 18% |
| 93378100 | Eicher Tractor Cover Support                       | 882   | 87084000 | 18% |
| 93378123 | Eicher Tractor Guard (Rubber Boot)                 | 218   | 87089900 | 18% |
| 93378147 | Eicher Tractor Rim W7X20 Silver Color Outset-15    | 9240  | 87087000 | 18% |
| 93378159 | Eicher Tractor Front Axle Support                  | 40670 | 87089900 | 18% |
| 93378172 | Eicher Tractor Base Mtg Bkt-480/548                | 1908  | 87085000 | 18% |
| 93378184 | Eicher Tractor Outlet Hose (Radiator)              | 791   | 87089100 | 18% |
| 93378196 | Eicher Tractor Mounting Bkt (Radiator)             | 513   | 87089900 | 18% |
| 93378202 | Eicher Tractor Support Bkt - Alternator            | 121   | 85123010 | 18% |
| 93378214 | Eicher Tractor Strip For Radiator                  | 116   | 73011000 | 18% |
| 93378226 | Eicher Tractor Hand Brake Lever Assy               | 721   | 87083000 | 18% |
| 93378240 | Eicher Tractor Water Separator                     | 849   | 87089900 | 18% |
| 93378251 | Eicher Tractor Water Seperator Bracket             | 253   | 87089900 | 18% |
| 93378263 | Eicher Tractor Mounting Bkt (Water Separator & Pip | 547   | 87089900 | 18% |
| 93378615 | Eicher Tractor Top Link Assy.                      | 2326  | 87089900 | 18% |
| 93378664 | Eicher Tractor Front Bumper                        | 13801 | 87081010 | 18% |
| 93378676 | Eicher Tractor Rim W6X18 Silver Color Outset-45    | 8486  | 87087000 | 18% |
| 93378688 | Eicher Tractor Rim W7X20 Silver Color Outset-45    | 9240  | 87087000 | 18% |
| 93378690 | Eicher Tractor Shield Cover Bottom -480            | 716   | 87084000 | 18% |
| 93378706 | Eicher Tractor Radiator -480                       | 11606 | 87089100 | 18% |
| 93378718 | Eicher Tractor Mounting Bkt Lt -Bonnet             | 940   | 87089900 | 18% |
| 93378720 | Eicher Tractor Mounting Bkt Rt -Bonnet             | 940   | 87089900 | 18% |
| 93378743 | Eicher Tractor Cover Alternator                    | 1011  | 87085000 | 18% |
| 93378810 | Eicher Tractor Fuel Pipe (Ws To Fp)                | 429   | 40094200 | 18% |
| 93378822 | Eicher Tractor Fuel Pipe (Fp To Ff)                | 429   | 40094200 | 18% |
| 93378834 | Eicher Tractor Fuel Pipe (Ff To Fip)               | 429   | 40094200 | 18% |
| 93378846 | Eicher Tractor Tool Kit Assy. (South)              | 1958  | 82060090 | 18% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93378858 | Eicher Tractor Tool Kit Assy. (North)              | 1521   | 82060090 | 18% |
| 93378860 | Eicher Tractor Tool Kit Assy. (North) - 551/548 FI | 1748   | 82060090 | 18% |
| 93378871 | Eicher Tractor Tool Kit Assy. (South) - 557 FI2    | 2079   | 82060090 | 18% |
| 93378913 | Eicher Tractor Front Axle-4Wd                      | 265478 | 87089900 | 18% |
| 93378937 | Eicher Tractor Steering Gear Assy-Rane             | 12423  | 87089400 | 18% |
| 93378949 | Eicher Tractor Cover Front (Propeller Shaft)       | 2269   | 87084000 | 18% |
| 93378974 | Eicher Tractor Silencer Assy With Guard (551)      | 7631   | 87089200 | 18% |
| 93379000 | Eicher Tractor Steering Cover                      | 894    | 87089900 | 18% |
| 93379012 | Eicher Tractor Silencer Assy With Guard (548)      | 6777   | 87089200 | 18% |
| 93379309 | Eicher Tractor Bonnet Graphic Lt                   | 410    | 39199090 | 18% |
| 93379310 | Eicher Tractor Bonnet Graphic Rt                   | 410    | 39199090 | 18% |
| 93379322 | Eicher Tractor Eicher Graphics Lt                  | 232    | 39199090 | 18% |
| 93379334 | Eicher Tractor Eicher Graphics Rt                  | 201    | 39199090 | 18% |
| 93379346 | Eicher Tractor Sticker - Celebration               | 116    | 39199090 | 18% |
| 93379358 | Eicher Tractor Sticker - Quadra Drive              | 36     | 39199090 | 18% |
| 93379360 | Eicher Tractor Sticker - Star                      | 240    | 39199090 | 18% |
| 93379383 | Eicher Tractor Sticker Eicher Pu Dome              | 349    | 39199090 | 18% |
| 93379395 | Eicher Tractor Sticker 557 Pu Dome                 | 240    | 39199090 | 18% |
| 93379413 | Eicher Tractor Sticker 548 Pu Dome                 | 240    | 39199090 | 18% |
| 93379437 | Eicher Tractor Sticker 551 Pu Dome                 | 240    | 39199090 | 18% |
| 93379450 | Eicher Tractor Sticker 485 Pu Dome                 | 240    | 39199090 | 18% |
| 93379474 | Eicher Tractor Sticker 480 Pu Dome                 | 240    | 39199090 | 18% |
| 93379486 | Eicher Tractor Steering Wheel Logo Dome (Red)      | 71     | 39199090 | 18% |
| 93379590 | Eicher Tractor Silencer 551                        | 5506   | 87089200 | 18% |
| 93379607 | Eicher Tractor Silencer 485                        | 4776   | 87089200 | 18% |
| 93379656 | Eicher Tractor Drawbar                             | 5040   | 87089900 | 18% |
| 93379670 | Eicher Tractor Fuel Pipe – (Fp To Ff)              | 408    | 40092200 | 18% |
| 93379681 | Eicher Tractor Pre Filter Bracket                  | 271    | 84219900 | 18% |
| 93379693 | Eicher Tractor Fuel Pipe (Ft To Sb)                | 632    | 40094200 | 18% |
| 93379700 | Eicher Tractor Fuel Pipe (Ffp To Ff)               | 430    | 40094200 | 18% |
| 93379711 | Eicher Tractor Fuel Pipe (Ff To Pff)               | 376    | 40094200 | 18% |
| 93379723 | Eicher Tractor Fuel Pipe (Pff To Fip)              | 419    | 40094200 | 18% |
| 93379747 | Eicher Tractor Bracket - Fuel Filters Mtg          | 1060   | 84219900 | 18% |
| 93379759 | Eicher Tractor Fuel Pipe – (Ff To Pff)             | 421    | 40092200 | 18% |
| 93379760 | Eicher Tractor Mounting Bracket                    | 515    | 87089900 | 18% |
| 93379784 | Eicher Tractor Drain Plug With O Ring              | 62     | 87084000 | 18% |
| 93379796 | Eicher Tractor Footboard Right (Ddb)               | 1132   | 87089900 | 18% |
| 93379802 | Eicher Tractor Footboard Right (Wdb)               | 1086   | 87089900 | 18% |
| 93379826 | Eicher Tractor Mounting Bkt- Dual Filter           | 1129   | 87089900 | 18% |
| 93381810 | Eicher Tractor Stub Axle Lt. (M)                   | 5488   | 87085000 | 18% |
| 93381821 | Eicher Tractor Stub Axle Rt. (M)                   | 5500   | 87085000 | 18% |
| 93382011 | Eicher Tractor Lifting Gear                        | 4959   | 87089900 | 18% |
| 93382023 | Eicher Tractor Fork & Guide                        | 3830   | 87089900 | 18% |
| 93382035 | Eicher Tractor Stablizer Mtg. Bkt. Left            | 2556   | 87089900 | 18% |
| 93382047 | Eicher Tractor Stablizer Mtg. Bkt. Right           | 2556   | 87089900 | 18% |
| 93382059 | Eicher Tractor Lower Link Mutng Brkt Lh            | 1768   | 87089900 | 18% |
| 93382060 | Eicher Tractor Lower Link Mutng Brkt Rh            | 1768   | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93382092 | Eicher Tractor Adaptor (Coupling Mouth)           | 5995  | 87089900 | 18% |
| 93382102 | Eicher Tractor Coupling Mouth                     | 6128  | 87089900 | 18% |
| 93382114 | Eicher Tractor Pin(Adaptor)                       | 254   | 87089900 | 18% |
| 93382280 | Eicher Tractor Eicher 480 Sticker                 | 213   | 39199090 | 18% |
| 93382291 | Eicher Tractor Eicher 368 Sticker                 | 218   | 39199090 | 18% |
| 93382308 | Eicher Tractor 371 Eicher Sticker                 | 214   | 39199090 | 18% |
| 93382310 | Eicher Tractor Eicher 380 Sticker                 | 218   | 39199090 | 18% |
| 93382321 | Eicher Tractor Self Locking Beading - 80Mm        | 8     | 87089900 | 18% |
| 93382370 | Eicher Tractor Silencer 24Hp                      | 6137  | 87089200 | 18% |
| 93382400 | Eicher Tractor Silencer Mtg. Bracket              | 367   | 87089900 | 18% |
| 93382412 | Eicher Tractor Exhaust Elbow                      | 2140  | 87089200 | 18% |
| 93382424 | Eicher Tractor Silencer Pipe Assy                 | 1853  | 87089900 | 18% |
| 93382426 | Eicher Tractor Heat Shiled (For Silencer Pipe Lh) | 786   | 87089900 | 18% |
| 93382448 | Eicher Tractor Heat Shiled (For Silencer Pipe Rh) | 980   | 87089200 | 18% |
| 93383027 | Eicher Tractor Sticker Oib                        | 13    | 39199090 | 18% |
| 93383040 | Eicher Tractor Pedal Shaft – Wdb                  | 2051  | 87084000 | 18% |
| 93383052 | Eicher Tractor Stud M12X46X70                     | 44    | 73182100 | 18% |
| 93383258 | Eicher Tractor Pedal Shaft -5660 Ddb              | 1704  | 87084000 | 18% |
| 93383260 | Eicher Tractor Stud M8X30X48                      | 24    | 73182100 | 18% |
| 93383311 | Eicher Tractor Rops Bottom Assy Rt                | 28348 | 87089400 | 18% |
| 93383323 | Eicher Tractor Rops Bottom Assy Lt                | 28410 | 87089400 | 18% |
| 93383335 | Eicher Tractor Rops Top Assy.                     | 20452 | 87089900 | 18% |
| 93383349 | Eicher Tractor Stabliser Mtg Bkt Lt               | 4453  | 87089900 | 18% |
| 93383350 | Eicher Tractor Stabliser Mtg Bkt Rt               | 4453  | 87089900 | 18% |
| 93383362 | Eicher Tractor Top Cover Assy                     | 5838  | 87084000 | 18% |
| 93383477 | Eicher Tractor Hand Accelerator Linkage Assy.     | 883   | 87089900 | 18% |
| 93383570 | Eicher Tractor D D Seat Belt Adj. 85Hp            | 15199 | 94012000 | 18% |
| 93383660 | Eicher Tractor Front Weight Bottom                | 6535  | 87081010 | 18% |
| 93383672 | Eicher Tractor Front Weight Top                   | 10220 | 87081010 | 18% |
| 93383751 | Eicher Tractor Alternator Cover                   | 552   | 87085000 | 18% |
| 93383805 | Eicher Tractor Alternator Belt Guard (Air Cool)   | 274   | 85122010 | 18% |
| 93383982 | Eicher Tractor Top Cover Mtg. Bkt.                | 60    | 87089900 | 18% |
| 93383994 | Eicher Tractor Foot Board-Lt                      | 3267  | 87089900 | 18% |
| 93384007 | Eicher Tractor Foot Board-Rt                      | 3259  | 87089900 | 18% |
| 93384172 | Eicher Tractor Bush (Parking Brake)               | 195   | 87089400 | 18% |
| 93384317 | Eicher Tractor Heat Shield-Protection Cover       | 1346  | 87089900 | 18% |
| 93384329 | Eicher Tractor Protection Cover Assy              | 1169  | 87089900 | 18% |
| 93384354 | Eicher Tractor Decal Ser No. Plate (50 Hp)        | 6     | 39199090 | 18% |
| 93384809 | Eicher Tractor Top Cover Mtg.Bkt.                 | 846   | 87084000 | 18% |
| 93384810 | Eicher Tractor Protection Cover Assy. With        | 2893  | 87089900 | 18% |
| 93384871 | Eicher Tractor Fuel Lines Cover Assy              | 350   | 87089900 | 18% |
| 93384883 | Eicher Tractor Radiator Assy                      | 9214  | 87087000 | 18% |
| 93384913 | Eicher Tractor Knob                               | 47    | 87084000 | 18% |
| 93384925 | Eicher Tractor Radiator Cap                       | 264   | 87089100 | 18% |
| 93384937 | Eicher Tractor Thrash Guard                       | 1677  | 87089100 | 18% |
| 93384949 | Eicher Tractor Outlet Pipe                        | 350   | 84099941 | 28% |
| 93384986 | Eicher Tractor Radiator Shroud                    | 792   | 87087000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93385140 | Eicher Tractor Front Axle & Support Assy (T-Assy)   | 35166 | 87089900 | 18% |
| 93385176 | Eicher Tractor Plate Super Power                    | 55    | 83100090 | 18% |
| 93385322 | Eicher Tractor Exchange Filter Insert (1457434314)  | 2814  | 84219900 | 18% |
| 93385474 | Eicher Tractor Front Axle & Support Assy (T-Assy)   | 39873 | 87089900 | 18% |
| 93385565 | Eicher Tractor Upper Fork                           | 1214  | 87089900 | 18% |
| 93385607 | Eicher Tractor Bumper Mtg Bracket--551 4Wd          | 4778  | 87081010 | 18% |
| 93385620 | Eicher Tractor Front Bumper Assy-551 4Wd            | 14609 | 87081010 | 18% |
| 93385693 | Eicher Tractor Front Bumper Assy                    | 15194 | 87081010 | 18% |
| 93385772 | Eicher Tractor Sticker 380 Pu Dome                  | 249   | 39199090 | 18% |
| 93385784 | Eicher Tractor Shield Support Bkt Lt                | 66    | 87084000 | 18% |
| 93385796 | Eicher Tractor Shield Support Bkt Rt                | 66    | 87084000 | 18% |
| 93385802 | Eicher Tractor Shield Bkt Top                       | 699   | 87084000 | 18% |
| 93385814 | Eicher Tractor Foam (Radiator)                      | 57    | 39219099 | 18% |
| 93385826 | Eicher Tractor Grommet (Clb Hose)                   | 27    | 40169990 | 18% |
| 93385929 | Eicher Tractor Cover Flange (Propeller Shaft)       | 1099  | 87089900 | 18% |
| 93385930 | Eicher Tractor Gasket (Cover Flange)                | 46    | 68129922 | 18% |
| 93385942 | Eicher Tractor Felt Ring 75X85X5                    | 35    | 87084000 | 18% |
| 93385954 | Eicher Tractor Stopper Plate Front Grill            | 23    | 87084000 | 18% |
| 93386041 | Eicher Tractor Sticker 333 Pu Dome                  | 242   | 39199090 | 18% |
| 93386053 | Eicher Tractor Sticker 368 Pu Dome                  | 242   | 39199090 | 18% |
| 93386272 | Eicher Tractor Foot Board Right                     | 1144  | 87089900 | 18% |
| 93386284 | Eicher Tractor Foot Board Left                      | 1438  | 87089900 | 18% |
| 93386387 | Eicher Tractor Lower Link Assy                      | 10850 | 87089900 | 18% |
| 93386820 | Eicher Tractor Cover Front (Prop Shaft)( New)       | 4476  | 87084000 | 18% |
| 93386831 | Eicher Tractor Cover Rear ( Prop Shaft)( New)       | 1705  | 87084000 | 18% |
| 93386843 | Eicher Tractor Cover Support (Coupling Shaft)( New  | 548   | 87084000 | 18% |
| 93386855 | Eicher Tractor Mtg Bkt. - Rear Cover (Coupling Shaf | 566   | 87089900 | 18% |
| 93386867 | Eicher Tractor Bracket Cover Support( New)          | 943   | 87084000 | 18% |
| 93386892 | Eicher Tractor Cap Steering Wheel                   | 47    | 87087000 | 18% |
| 93386946 | Eicher Tractor Front Bumper Assy                    | 18079 | 87081010 | 18% |
| 93386958 | Eicher Tractor Front Bumper Assy                    | 16780 | 87081010 | 18% |
| 93386971 | Eicher Tractor Rubber Pad                           | 41    | 40169990 | 18% |
| 93387008 | Eicher Tractor Front Bumper Assy                    | 18224 | 87081010 | 18% |
| 93387112 | Eicher Tractor Muffler With Heat Shield Assy        | 6286  | 87089900 | 18% |
| 93387276 | Eicher Tractor Silencer 551                         | 5624  | 87089200 | 18% |
| 93387288 | Eicher Tractor Silencer 485/548                     | 5624  | 87089200 | 18% |
| 93387320 | Eicher Tractor Silencer 485/548 With Guard          | 6744  | 87089200 | 18% |
| 93387331 | Eicher Tractor Silencer 551 With Guard              | 7533  | 87089200 | 18% |
| 93387653 | Eicher Tractor Connecting Link (Fuel Pump)          | 301   | 87089900 | 18% |
| 93387665 | Eicher Tractor Fuel Pipe (Ft To Ws) - Eco           | 445   | 40094200 | 18% |
| 93387677 | Eicher Tractor Assy.Rr Hinge Firewall Side Rh       | 1013  | 87089900 | 18% |
| 93387689 | Eicher Tractor Assy.Rr Hinge Firewall Side Lh       | 1013  | 87089900 | 18% |
| 93387690 | Eicher Tractor Dry A/C Support Strip                | 137   | 40169390 | 18% |
| 93387720 | Eicher Tractor Wire Rod Assy-Eco                    | 423   | 85122010 | 18% |
| 93387732 | Eicher Tractor Platform Middle - Assy               | 1939  | 87089900 | 18% |
| 93387744 | Eicher Tractor A/C Mounting Bracket                 | 1173  | 87089900 | 18% |
| 93387756 | Eicher Tractor Foot Acc Pedal Assy                  | 266   | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93387768 | Eicher Tractor Wire Sleeve Guide             | 72    | 87089900 | 18% |
| 93387770 | Eicher Tractor Hand Brake Stopper Plate      | 49    | 87083000 | 18% |
| 93387823 | Eicher Tractor Fuel Tank Cover               | 3639  | 87089900 | 18% |
| 93388000 | Eicher Tractor Drain Cock                    | 39    | 87089900 | 18% |
| 93388219 | Eicher Tractor Bkt -Dual Fuel Filter         | 1046  | 84219900 | 18% |
| 93388220 | Eicher Tractor Fuel Pipe Assy (Ffp To Ff)    | 511   | 84099941 | 28% |
| 93388232 | Eicher Tractor Fuel Pipe Assy (Ff To Fip)    | 396   | 84099941 | 28% |
| 93388323 | Eicher Tractor Cover Front (Prop Shaft)      | 4503  | 87084000 | 18% |
| 93388368 | Eicher Tractor Pin                           | 123   | 73182100 | 18% |
| 93388414 | Eicher Tractor Battery Tray Assly            | 3373  | 85079090 | 28% |
| 93388876 | Eicher Tractor Bumper Assy                   | 17425 | 87081010 | 18% |
| 93388888 | Eicher Tractor Front Bumper Assy             | 11795 | 87081010 | 18% |
| 93388906 | Eicher Tractor Front Bumper Assy             | 13711 | 87081010 | 18% |
| 93388918 | Eicher Tractor Front Bumper Assy             | 13602 | 87081010 | 18% |
| 93388920 | Eicher Tractor Front Bumper Assy             | 17591 | 87081010 | 18% |
| 93388931 | Eicher Tractor Front Bumper Assy             | 12238 | 87081010 | 18% |
| 93390457 | Eicher Tractor Rear Wheel Rim Dw12X38 Silver | 41614 | 87087000 | 18% |
| 93390494 | Eicher Tractor Fuel Pipe (Ffp To Ff)         | 355   | 84099941 | 28% |
| 93390500 | Eicher Tractor Fuel Pipe - ( Ws To Sed Bowl) | 362   | 84099941 | 28% |
| 93390512 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 410   | 87089900 | 18% |
| 93390524 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 410   | 87089900 | 18% |
| 93390536 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 342   | 87089900 | 18% |
| 93390548 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 342   | 87089900 | 18% |
| 93390550 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 488   | 87089900 | 18% |
| 93390561 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 437   | 87089900 | 18% |
| 93390597 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 373   | 87089900 | 18% |
| 93390603 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 373   | 87089900 | 18% |
| 93390615 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 478   | 87089900 | 18% |
| 93390627 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 478   | 87089900 | 18% |
| 93390639 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 430   | 87089900 | 18% |
| 93390640 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 430   | 87089900 | 18% |
| 93390652 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 288   | 87089900 | 18% |
| 93390664 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 288   | 87089900 | 18% |
| 93390676 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 431   | 87089900 | 18% |
| 93390688 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 431   | 87089900 | 18% |
| 93390706 | Eicher Tractor Bonnet Mtg Bkt Lt.            | 299   | 87089900 | 18% |
| 93390718 | Eicher Tractor Bonnet Mtg Bkt Rt.            | 299   | 87089900 | 18% |
| 93390720 | Eicher Tractor Fuel Tank Cap (85-Hp)         | 500   | 87089900 | 18% |
| 93390743 | Eicher Tractor Tool Box Mtg Bkt              | 347   | 87089900 | 18% |
| 93390755 | Eicher Tractor Battery Tray Assy             | 3351  | 85079090 | 28% |
| 93390858 | Eicher Tractor Cover Add On Left- Bonnet     | 2469  | 87084000 | 18% |
| 93390860 | Eicher Tractor Cover Add On Right- Bonnet    | 2469  | 87084000 | 18% |
| 93390901 | Eicher Tractor Cover Add On Left - Ft Cover  | 840   | 87084000 | 18% |
| 93390913 | Eicher Tractor Cover Add On Right - Ft Cover | 840   | 87084000 | 18% |
| 93390925 | Eicher Tractor Cover Hinge Bracket           | 2883  | 87089900 | 18% |
| 93390949 | Eicher Tractor Head Light Panel Assy         | 2771  | 85122010 | 18% |
| 93390962 | Eicher Tractor Cover Head Light Console      | 1750  | 39269099 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93390974 | Eicher Tractor Steering Bracket (650)              | 1222  | 87089400 | 18% |
| 93390986 | Eicher Tractor Fuel Tank Mtg. Bracket              | 1592  | 87089900 | 18% |
| 93391061 | Eicher Tractor Front Axle Support                  | 42485 | 87089900 | 18% |
| 93391140 | Eicher Tractor Flywheel Housing                    | 40641 | 87084000 | 18% |
| 93391190 | Eicher Tractor Accelerator Lever Rt                | 109   | 87084000 | 18% |
| 93391218 | Eicher Tractor Lever Bottom (650)                  | 130   | 87089900 | 18% |
| 93391220 | Eicher Tractor Fuel Tank Bottom Pad (650)          | 137   | 40169990 | 18% |
| 93391231 | Eicher Tractor Steel Strap & Rabber Strap Assy     | 243   | 40169990 | 18% |
| 93391243 | Eicher Tractor Foam (Bonnet Top) (650)             | 435   | 39219099 | 18% |
| 93391279 | Eicher Tractor Foam (Bonnet Side) (650)            | 42    | 39219099 | 18% |
| 93391280 | Eicher Tractor Lock Bracket Assy Lt                | 161   | 87089900 | 18% |
| 93391292 | Eicher Tractor Lock Bracket Assy Rt                | 161   | 87089900 | 18% |
| 93391309 | Eicher Tractor Flange Nut (Front Wheel)-M18X1.5, Z | 183   | 87087000 | 18% |
| 93391322 | Eicher Tractor Tank Cover Support (650)            | 95    | 87089900 | 18% |
| 93391425 | Eicher Tractor Dry A/C Hose                        | 1255  | 40093100 | 18% |
| 93391437 | Eicher Tractor Air Cleaner Mtg. Bkt.               | 1104  | 87089900 | 18% |
| 93391590 | Eicher Tractor Front Axle Support                  | 44081 | 87089900 | 18% |
| 93391607 | Eicher Tractor Base Mtg Bkt (A/C)                  | 1177  | 87085000 | 18% |
| 93391619 | Eicher Tractor A/C Mtg Bkt                         | 904   | 87089900 | 18% |
| 93391693 | Eicher Tractor Front Rim 5.00Fx20 - Orange         | 6517  | 87087000 | 18% |
| 93391700 | Eicher Tractor Accelerator Linkage Sub Assly       | 1333  | 87083000 | 18% |
| 93391759 | Eicher Tractor Pin (Bonnet Rotating)               | 120   | 73182100 | 18% |
| 93391760 | Eicher Tractor Bonnet Hinge Bkt                    | 2392  | 87089900 | 18% |
| 93391772 | Eicher Tractor Bottom Plate                        | 2570  | 87089900 | 18% |
| 93391784 | Eicher Tractor Plastic Cover (Green Color)         | 767   | 39021000 | 18% |
| 93391840 | Eicher Tractor Cover Hinge (Green)                 | 2883  | 87089900 | 18% |
| 93391851 | Eicher Tractor Cover Hinge Red                     | 2883  | 87089900 | 18% |
| 93392752 | Eicher Tractor Lower Link Assy                     | 2441  | 87089900 | 18% |
| 93393203 | Eicher Tractor Pedal Support Bkt                   | 8107  | 87083000 | 18% |
| 93393215 | Eicher Tractor Brake Pedal Left                    | 1935  | 87083000 | 18% |
| 93393495 | Eicher Tractor Spacer (Dd Seat)                    | 1040  | 73182100 | 18% |
| 93393549 | Eicher Tractor Mudguard Red Sticker-884            | 57    | 39199090 | 18% |
| 93393628 | Eicher Tractor Sticker-4Wd                         | 10    | 39199090 | 18% |
| 93393689 | Eicher Tractor Lever Assy (Parking Brake)          | 380   | 87083000 | 18% |
| 93393690 | Eicher Tractor Spring(Parking Brake)               | 8     | 87083000 | 18% |
| 93393744 | Eicher Tractor Boarding Handle                     | 346   | 87084000 | 18% |
| 93393800 | Eicher Tractor Lock Pin                            | 564   | 73182100 | 18% |
| 93393811 | Eicher Tractor Swinging Draw Bar                   | 5173  | 87089900 | 18% |
| 93393847 | Eicher Tractor Mesh Guard                          | 1023  | 87089100 | 18% |
| 93393859 | Eicher Tractor Dry A/C Mtg Bkt                     | 1096  | 87089900 | 18% |
| 93393872 | Eicher Tractor Fuel Cooler Bkt                     | 141   | 87089900 | 18% |
| 93393884 | Eicher Tractor Shield Bkt. Bottom                  | 352   | 87087000 | 18% |
| 93393938 | Eicher Tractor Latch                               | 326   | 87085000 | 18% |
| 93393940 | Eicher Tractor Recovery Bottle Assy(Tube 600Mm)    | 698   | 87089100 | 18% |
| 93393951 | Eicher Tractor Bkt Recovery Bottle (Engine Side)   | 258   | 87089100 | 18% |
| 93393963 | Eicher Tractor Bkt Recovery Bottle (Radiator Side) | 232   | 87089900 | 18% |
| 93394025 | Eicher Tractor Base Mounting Bracket (A/C)         | 1516  | 87085000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93394050 | Eicher Tractor Steering Bracket (T4-650)           | 2387  | 87089400 | 18% |
| 93394074 | Eicher Tractor Ecu Cover                           | 419   | 87084000 | 18% |
| 93394104 | Eicher Tractor Foam (Bonnet Top)(T4-650)           | 356   | 39219099 | 18% |
| 93394128 | Eicher Tractor Silencer Elbow T4-650               | 2531  | 87089200 | 18% |
| 93394130 | Eicher Tractor Firewall Assy.                      | 3483  | 87089900 | 18% |
| 93394256 | Eicher Tractor Inlet Hose Overflow Fuel Cooler (T4 | 750   | 40093100 | 18% |
| 93394359 | Eicher Tractor Electronic Throttle Control Assy.   | 8493  | 85364900 | 18% |
| 93394396 | Eicher Tractor Mtg. Bkt. (Acc. Pedal)(T4-650)      | 126   | 87089900 | 18% |
| 93394402 | Eicher Tractor Wire Hand Acc.(T4-650)              | 463   | 73202000 | 18% |
| 93394414 | Eicher Tractor Foot Throttle Wire(T4-650)          | 366   | 87089900 | 18% |
| 93394426 | Eicher Tractor Hose Intercooler Side(T4-650)       | 587   | 40093100 | 18% |
| 93394440 | Eicher Tractor Tc Out Hose(T4-650)                 | 908   | 40093100 | 18% |
| 93394475 | Eicher Tractor Platform Right(T4-650)              | 3512  | 87089900 | 18% |
| 93394499 | Eicher Tractor Inter Cooler In Take Pipe(T4-650)   | 889   | 87089900 | 18% |
| 93394505 | Eicher Tractor Outlet Hose(T4-650)                 | 788   | 40093100 | 18% |
| 93394542 | Eicher Tractor Mtg. Bkt. (Fuel Tank)               | 1581  | 39199090 | 18% |
| 93394591 | Eicher Tractor Deflector Rh                        | 378   | 84099990 | 28% |
| 93394608 | Eicher Tractor Deflector Lh                        | 325   | 84099990 | 28% |
| 93394621 | Eicher Tractor Foam Radiator Bottom                | 50    | 87087000 | 18% |
| 93394633 | Eicher Tractor Foam Radiator Top                   | 54    | 87087000 | 18% |
| 93395005 | Eicher Tractor Dry Air Cleaner Assy(T4-650)        | 4165  | 84213920 | 18% |
| 93395030 | Eicher Tractor Radiator With Intercooler & Recover | 26020 | 87087000 | 18% |
| 93395121 | Eicher Tractor Dry A/C Hose(T4-650)                | 1539  | 40093100 | 18% |
| 93395133 | Eicher Tractor Shield Bkt. Radiator Top (T4-650)   | 282   | 87089900 | 18% |
| 93395273 | Eicher Tractor Gasket For Silencer                 | 106   | 68129090 | 18% |
| 93395388 | Eicher Tractor Lable Plate                         | 47    | 39199090 | 18% |
| 93395406 | Eicher Tractor Hose (Intake Manifold Side)         | 472   | 40093100 | 18% |
| 93395418 | Eicher Tractor Intercooler Out                     | 669   | 84099941 | 28% |
| 93395431 | Eicher Tractor Hose (Intercooler Side)             | 607   | 40093100 | 18% |
| 93395455 | Eicher Tractor Steel Strap & Rubber Assy           | 247   | 87089900 | 18% |
| 93395470 | Eicher Tractor Mounting Angle Right                | 1043  | 87089900 | 18% |
| 93395509 | Eicher Tractor Bottom Plate Bonnet                 | 2713  | 87089900 | 18% |
| 93395510 | Eicher Tractor Bonnet Hinge Bkt Assy.(T4 650)      | 3908  | 87089900 | 18% |
| 93395522 | Eicher Tractor Air Cleaner Pillar                  | 1675  | 87089900 | 18% |
| 93395558 | Eicher Tractor Front Axle Support                  | 57727 | 87089900 | 18% |
| 93395583 | Eicher Tractor Mudguard Red Sticker-776            | 57    | 39199090 | 18% |
| 93395595 | Eicher Tractor Air Cleaner Mtg Bkt(551/557)        | 1156  | 84099941 | 28% |
| 93395607 | Eicher Tractor Air Cleaner Mtg Bkt(548)            | 1010  | 84099941 | 28% |
| 93395820 | Eicher Tractor Lower Bracket Lh                    | 4861  | 87089900 | 18% |
| 93395832 | Eicher Tractor Lower Bracket Rh                    | 4861  | 87089900 | 18% |
| 93395923 | Eicher Tractor Lock Bkt Lt                         | 145   | 87081010 | 18% |
| 93395935 | Eicher Tractor Lock Bkt Rt                         | 145   | 87081010 | 18% |
| 93395959 | Eicher Tractor Metal Fuel Tank ( 58 Ltr)           | 9893  | 87089900 | 18% |
| 93395960 | Eicher Tractor Metal Fuel Tank (65 Ltr)            | 11774 | 87089900 | 18% |
| 93396117 | Eicher Tractor Brake Pedal Right                   | 1685  | 87083000 | 18% |
| 93396142 | Eicher Tractor Heat Shield Silencer Pipe - Left    | 1942  | 87089900 | 18% |
| 93396230 | Eicher Tractor Hex Bolt M18X60 Is:1364(P1)-2002    | 110   | 73181500 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93396241 | Eicher Tractor Spacer Plate                        | 296   | 73182100 | 18% |
| 93396319 | Eicher Tractor Silencer Pipe                       | 1914  | 87089900 | 18% |
| 93396400 | Eicher Tractor Brkt For Swinging Draw Bar          | 13386 | 87089900 | 18% |
| 93396411 | Eicher Tractor Support Plate (Sw. Db.) 2Wd         | 1103  | 87089900 | 18% |
| 93396423 | Eicher Tractor Support Plate (Sw. Db.) 4Wd         | 928   | 87089900 | 18% |
| 93396824 | Eicher Tractor Caution Sticker- 4Wd Lever          | 7     | 39199090 | 18% |
| 93396915 | Eicher Tractor Support Plate-2Wd (551,548)         | 1335  | 87089900 | 18% |
| 93396940 | Eicher Tractor Resting Bkt                         | 240   | 87089900 | 18% |
| 93396952 | Eicher Tractor Pipe Cover                          | 339   | 87089900 | 18% |
| 93396976 | Eicher Tractor Top Cover                           | 1188  | 87084000 | 18% |
| 93396988 | Eicher Tractor Fuel Tank T4 650                    | 15391 | 87089900 | 18% |
| 93396990 | Eicher Tractor Foot Accelerator Lever Assy. (T4-65 | 100   | 87089900 | 18% |
| 93397002 | Eicher Tractor Cable Strap                         | 26    | 87089900 | 18% |
| 93397014 | Eicher Tractor Wire Lock                           | 69    | 85122010 | 18% |
| 93397038 | Eicher Tractor Self Locking Beading                | 13    | 87089900 | 18% |
| 93397040 | Eicher Tractor Bkt. Mtg. (Hand Acc.)(T4-650)       | 256   | 87089900 | 18% |
| 93397087 | Eicher Tractor Master Shield Of Pto                | 2114  | 87084000 | 18% |
| 93397099 | Eicher Tractor Smv Emblem                          | 953   | 39199090 | 18% |
| 93397105 | Eicher Tractor Mounting Bracket (Smv Emblem)       | 247   | 87089900 | 18% |
| 93397130 | Eicher Tractor Rec. Reflex Reflector Assy.         | 113   | 85122010 | 18% |
| 93397154 | Eicher Tractor Guide Pin (Master Shield)           | 240   | 73182100 | 18% |
| 93397166 | Eicher Tractor Air Cleaner Mtg Bkt(650 4Wd)        | 2850  | 84099941 | 28% |
| 93397178 | Eicher Tractor Air Cleaner Mtg Bkt (557 4Wd)       | 1246  | 84099941 | 28% |
| 93397180 | Eicher Tractor Mounting Angle - Lt                 | 1437  | 87089900 | 18% |
| 93397191 | Eicher Tractor Mounting Angle - Rt                 | 1437  | 87089900 | 18% |
| 93397208 | Eicher Tractor Mounting Plate (Reflector) Rops     | 81    | 87089900 | 18% |
| 93397210 | Eicher Tractor Number Plate                        | 388   | 85122090 | 18% |
| 93397257 | Eicher Tractor Air Cleaner Mtg Bkt(650 2Wd)        | 1493  | 84099941 | 28% |
| 93397336 | Eicher Tractor Front Rim W7X20 Bolted Outset-45, S | 10951 | 87087000 | 18% |
| 93397348 | Eicher Tractor Front Rim W7X18 Bolted Outset-45,Sl | 8934  | 87087000 | 18% |
| 93397350 | Eicher Tractor Rear Rim W12X28 Bolted Inset – 43.5 | 18059 | 87087000 | 18% |
| 93397397 | Eicher Tractor Cover Flange                        | 1270  | 87084000 | 18% |
| 93397403 | Eicher Tractor Cover-Front (551-4Wd)               | 932   | 87084000 | 18% |
| 93397415 | Eicher Tractor Cover-Front (480-4Wd)               | 842   | 87084000 | 18% |
| 93397427 | Eicher Tractor Hose                                | 204   | 40093100 | 18% |
| 93397439 | Eicher Tractor Hose (Rear Cover)                   | 214   | 40093100 | 18% |
| 93397440 | Eicher Tractor Cover-Middle                        | 572   | 87084000 | 18% |
| 93397452 | Eicher Tractor Cover-Rear                          | 409   | 87084000 | 18% |
| 93397464 | Eicher Tractor Foot Step                           | 679   | 87089900 | 18% |
| 93397476 | Eicher Tractor Guard Tie Rod                       | 161   | 87084000 | 18% |
| 93397567 | Eicher Tractor Mtg Bkt Heat Guard Lh               | 1095  | 87089900 | 18% |
| 93397579 | Eicher Tractor Heat Guard Mtg Bkt Rh               | 1316  | 87089900 | 18% |
| 93397634 | Eicher Tractor Foot Step                           | 862   | 87089900 | 18% |
| 93397658 | Eicher Tractor Cover Front (Prop Shaft)            | 2376  | 87084000 | 18% |
| 93397737 | Eicher Tractor Wire Rod Assy.                      | 218   | 85122010 | 18% |
| 93397830 | Eicher Tractor 333 Sticker (Silver)                | 74    | 39199090 | 18% |
| 93397841 | Eicher Tractor Mudguard Silver Sticker-368         | 53    | 39199090 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93397853 | Eicher Tractor Sticker- Super Power                | 90    | 39199090 | 18% |
| 93397865 | Eicher Tractor Battery Mtg. Bkt.                   | 1004  | 85079090 | 28% |
| 93397889 | Eicher Tractor Heat Guard Assy. - Lh               | 3789  | 87089900 | 18% |
| 93397890 | Eicher Tractor Heat Guard Assy. - Rh               | 3789  | 87089900 | 18% |
| 93398640 | Eicher Tractor Radiator With Ic Assy.              | 34974 | 87087000 | 18% |
| 93398663 | Eicher Tractor Air Cleaner Support Bracket         | 1092  | 87089900 | 18% |
| 93398675 | Eicher Tractor Air Intake Hose (A/C Side)          | 2381  | 40093100 | 18% |
| 93398687 | Eicher Tractor Intake Hose (Intercooler)           | 2243  | 40093100 | 18% |
| 93398699 | Eicher Tractor Outlate Hose (Intercooler)          | 2243  | 40093100 | 18% |
| 93398717 | Eicher Tractor Rubber Pad (Radiator)               | 118   | 87087000 | 18% |
| 93398730 | Eicher Tractor Outlet Water Hose                   | 850   | 40093100 | 18% |
| 93398742 | Eicher Tractor Radiator Foam Lt                    | 390   | 87087000 | 18% |
| 93398754 | Eicher Tractor Radiator Foam Rt                    | 390   | 87087000 | 18% |
| 93398766 | Eicher Tractor Radiator Foam Top                   | 502   | 87087000 | 18% |
| 93398778 | Eicher Tractor Foam (Radiator Bottom)              | 66    | 87087000 | 18% |
| 93398780 | Eicher Tractor Foam (Radiator Top)                 | 174   | 87087000 | 18% |
| 93398791 | Eicher Tractor Bottom Shield Bkt. (Radiator)       | 423   | 87087000 | 18% |
| 93398808 | Eicher Tractor Top Shield Radiator                 | 375   | 87087000 | 18% |
| 93398810 | Eicher Tractor Silencer Muffler                    | 9713  | 87089200 | 18% |
| 93398821 | Eicher Tractor Stud M14                            | 305   | 73182100 | 18% |
| 93398845 | Eicher Tractor Heat Guard - Exhaust Pipe           | 983   | 87089900 | 18% |
| 93398857 | Eicher Tractor Platform Right                      | 3574  | 87089900 | 18% |
| 93398869 | Eicher Tractor Platform Left                       | 4783  | 87089900 | 18% |
| 93398882 | Eicher Tractor Foot Rest Support Bkt Lt            | 320   | 87089900 | 18% |
| 93398894 | Eicher Tractor Foot Rest Support Bkt Rt            | 320   | 87089900 | 18% |
| 93398900 | Eicher Tractor Foot Step                           | 1360  | 87089900 | 18% |
| 93398924 | Eicher Tractor Pawl Assy.                          | 498   | 87089900 | 18% |
| 93398936 | Eicher Tractor Assy Bracket-Parking Brake          | 281   | 87089900 | 18% |
| 93398948 | Eicher Tractor Pull Rod Assy.                      | 141   | 87089900 | 18% |
| 93398950 | Eicher Tractor Brake Pedal Left                    | 2326  | 87083000 | 18% |
| 93398961 | Eicher Tractor Brake Pedal Right                   | 2503  | 87083000 | 18% |
| 93398973 | Eicher Tractor Acc. Linkage Sub Assy.              | 1457  | 87083000 | 18% |
| 93398997 | Eicher Tractor Clutch Pedal                        | 2358  | 87089300 | 18% |
| 93399000 | Eicher Tractor Mudguard Support Plate Left         | 713   | 87089900 | 18% |
| 93399011 | Eicher Tractor Flywheel Housing                    | 61466 | 87084000 | 18% |
| 93399023 | Eicher Tractor Tension Tie Assy                    | 665   | 87089900 | 18% |
| 93399047 | Eicher Tractor Connecting Link Assy                | 258   | 87089900 | 18% |
| 93399084 | Eicher Tractor Spacer (Steering Bkt.)              | 1193  | 73182100 | 18% |
| 93399175 | Eicher Tractor Max Speed Sticker -2Wd              | 7     | 39199090 | 18% |
| 93399187 | Eicher Tractor Max Speed Sticker - 4Wd             | 7     | 39199090 | 18% |
| 93399199 | Eicher Tractor Mounting Plate (Reflector)          | 94    | 87089900 | 18% |
| 93399205 | Eicher Tractor Decal Plate                         | 17    | 39199090 | 18% |
| 93399217 | Eicher Tractor Support Bkt Top Cover               | 96    | 87084000 | 18% |
| 93399229 | Eicher Tractor Top Cover Small                     | 158   | 87089900 | 18% |
| 93399230 | Eicher Tractor Support Plate                       | 1388  | 87089900 | 18% |
| 93399242 | Eicher Tractor Mounting Bracket - Toolbox          | 1367  | 87089900 | 18% |
| 93399291 | Eicher Tractor Support Bkt Top (Fan Guard Lh 380 M | 249   | 85030090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93399394 | Eicher Tractor Top Cover Assy (Plateform)          | 3437  | 87084000 | 18% |
| 93399485 | Eicher Tractor Lifting Gear Assy                   | 1333  | 87089900 | 18% |
| 93399564 | Eicher Tractor Foot Board Right                    | 1282  | 87089900 | 18% |
| 93399606 | Eicher Tractor Lifting Gear Mechanism              | 4442  | 87084000 | 18% |
| 93399620 | Eicher Tractor Fork And Guide Mechanism            | 3234  | 87089900 | 18% |
| 93399643 | Eicher Tractor Battery Tray Assly                  | 3601  | 85079090 | 28% |
| 93399795 | Eicher Tractor Number Plate Mtg. Bkt.              | 866   | 85122090 | 18% |
| 93399813 | Eicher Tractor Propeller Shaft Cover Front         | 4161  | 87084000 | 18% |
| 93399825 | Eicher Tractor Propeller Shaft Cover Rear          | 2695  | 87084000 | 18% |
| 93399837 | Eicher Tractor Cover Front                         | 267   | 87089900 | 18% |
| 93399849 | Eicher Tractor Cover Rear                          | 291   | 87089900 | 18% |
| 93399862 | Eicher Tractor Rubber Beading - 350Lg              | 110   | 40169320 | 18% |
| 93399874 | Eicher Tractor Rubber Beading - 120Lg              | 41    | 40169320 | 18% |
| 93399886 | Eicher Tractor Rubber Beading - 80Lg               | 29    | 40169320 | 18% |
| 93399930 | Eicher Tractor Front Axle Support 551 4Wd          | 47025 | 87089900 | 18% |
| 93399941 | Eicher Tractor Assy Guard - Lh                     | 1582  | 87085000 | 18% |
| 93399953 | Eicher Tractor Assy Guard - Rh                     | 1582  | 87085000 | 18% |
| 93399965 | Eicher Tractor Strip Top -Lh                       | 499   | 39199090 | 18% |
| 93399977 | Eicher Tractor Strip Top -Rh                       | 499   | 39199090 | 18% |
| 93399989 | Eicher Tractor Washer 11X20X3.2                    | 33    | 73182100 | 18% |
| 93400104 | Eicher Tractor Head Lamp Lh (H4 Bulb)              | 3657  | 87089900 | 18% |
| 93400116 | Eicher Tractor Head Lamp Rh (H4 Bulb)              | 3657  | 87089900 | 18% |
| 93400165 | Eicher Tractor Hand Accc Lever Rod- Higher Hp      | 325   | 87084000 | 18% |
| 93400207 | Eicher Tractor Steering Column -380 Ps             | 2702  | 87089400 | 18% |
| 93400220 | Eicher Tractor Hand Acc Linkage Assy (Ms)- Ns      | 650   | 87089900 | 18% |
| 93400244 | Eicher Tractor Accelerator Linkage Sub Assy. 380/4 | 1274  | 87089900 | 18% |
| 93400256 | Eicher Tractor Accelerator Shaft - Ns              | 206   | 87084000 | 18% |
| 93400268 | Eicher Tractor Connecting Link Fip 380 - Ns        | 243   | 87089900 | 18% |
| 93400281 | Eicher Tractor Mounting Bkt - Ns (Hand Acc Assy-Ps | 273   | 87089900 | 18% |
| 93400293 | Eicher Tractor Chain Assly                         | 156   | 87089900 | 18% |
| 93400300 | Eicher Tractor Silencer Elbow                      | 1656  | 87089200 | 18% |
| 93400335 | Eicher Tractor Wet Air Cleaner Hose                | 1615  | 87089900 | 18% |
| 93400359 | Eicher Tractor Steering Gear Assy -Zf, Mech-380/   | 16081 | 87089400 | 18% |
| 93400360 | Eicher Tractor Air Cleaner Mtg Bkt                 | 1242  | 87089900 | 18% |
| 93400384 | Eicher Tractor Front Bonnet Bumper 650 (Cover Hing | 1172  | 87081010 | 18% |
| 93400529 | Eicher Tractor Bonnet Hinge Assembly (Rear Opening | 4848  | 87089900 | 18% |
| 93400542 | Eicher Tractor Rubber Stopper-Ns (Front Opening)   | 120   | 40169990 | 18% |
| 93400554 | Eicher Tractor Rubber Pad For Locator Pin          | 37    | 40169990 | 18% |
| 93400580 | Eicher Tractor Bonnet Pin(Rear Opening)            | 90    | 87089900 | 18% |
| 93400657 | Eicher Tractor Firewall (High Power) Front Opening | 6133  | 87089900 | 18% |
| 93400669 | Eicher Tractor Firewall 380 (Low Power) Front Open | 6091  | 87089900 | 18% |
| 93400785 | Eicher Tractor Scuttle Assembly (Front Opening)    | 10021 | 87084000 | 18% |
| 93400864 | Eicher Tractor Scuttle Leg Rh-Ns 380 Ms            | 698   | 87089900 | 18% |
| 93400876 | Eicher Tractor Scuttle Mounting Bkt Top (Front Ope | 329   | 87089900 | 18% |
| 93400918 | Eicher Tractor Switch Cover(Plastic)               | 1390  | 87083000 | 18% |
| 93400943 | Eicher Tractor Fuel Lid Latch Mtg Bkt              | 33    | 87089900 | 18% |
| 93401005 | Eicher Tractor Assembly Fuel Lid                   | 704   | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93401042 | Eicher Tractor Silencer Assy With Guard -380/480   | 5237 | 87089200 | 18% |
| 93401157 | Eicher Tractor Steering Bracket -557/650 Ps        | 2078 | 87089400 | 18% |
| 93401303 | Eicher Tractor Tank Unit 58 Ltr                    | 955  | 87089900 | 18% |
| 93401315 | Eicher Tractor Tank Unit 65 Ltr                    | 967  | 87089900 | 18% |
| 93401480 | Eicher Tractor Wet A/C Hose (551)                  | 1652 | 40093100 | 18% |
| 93401510 | Eicher Tractor Elbow Exhaust 551                   | 2045 | 87089200 | 18% |
| 93401595 | Eicher Tractor Mounting Upper Bkt. (Hand Acc Assy  | 120  | 87089900 | 18% |
| 93401601 | Eicher Tractor Mounting Bkt-Ns (Hand Acc Assy-Ms)  | 273  | 87089900 | 18% |
| 93401960 | Eicher Tractor Air Intake Hose / Air Intake Hose ( | 976  | 40093100 | 18% |
| 93402265 | Eicher Tractor Hand Acc Lever Rod- Lower Hp        | 297  | 87084000 | 18% |
| 93402277 | Eicher Tractor Hand Acc Linkage Assy- (Ps)- Ns     | 650  | 87089900 | 18% |
| 93402332 | Eicher Tractor Tube Assy 380                       | 519  | 87089900 | 18% |
| 93402861 | Eicher Tractor Console Top (Plastic)               | 1624 | 85122010 | 18% |
| 93402873 | Eicher Tractor Instrument Cover Top (Plastic)      | 884  | 85123010 | 18% |
| 93402976 | Eicher Tractor Fuel Tank Mtg. Bracket (For 65L Fue | 1716 | 87089900 | 18% |
| 93402988 | Eicher Tractor Fuel Tank Mtg Bkt (For 58L Fuel Tan | 1695 | 87089900 | 18% |
| 93402990 | Eicher Tractor Steering Bellow (For Sw- With Horn) | 253  | 87089400 | 18% |
| 93403002 | Eicher Tractor Assy. Front Hinge Moving Arm        | 2906 | 87089900 | 18% |
| 93403014 | Eicher Tractor Bonnet Front (Plastic Part) With Ch | 758  | 87089900 | 18% |
| 93403026 | Eicher Tractor Front Grill                         | 1082 | 87089900 | 18% |
| 93403038 | Eicher Tractor Side Grill Lwr Lh                   | 549  | 87089900 | 18% |
| 93403040 | Eicher Tractor Side Grill Lwr Rh                   | 549  | 87089900 | 18% |
| 93403051 | Eicher Tractor Over Flow Pipe Assy - 380 (Fip To   | 372  | 87089900 | 18% |
| 93403063 | Eicher Tractor Hose Fuel Tank                      | 258  | 39199090 | 18% |
| 93403075 | Eicher Tractor Self Locking Beading                | 171  | 87089900 | 18% |
| 93403087 | Eicher Tractor Assembly Striker Mtg - Front Openin | 263  | 87089900 | 18% |
| 93403105 | Eicher Tractor Assy Rear Opening Striker           | 116  | 87089900 | 18% |
| 93403117 | Eicher Tractor Latch Mtg Base Plate (Rear Opening) | 334  | 87084000 | 18% |
| 93403129 | Eicher Tractor Gas Spring                          | 1942 | 87089900 | 18% |
| 93403130 | Eicher Tractor Front Bonnet Lock Assy              | 1042 | 87089900 | 18% |
| 93403142 | Eicher Tractor Rear Bonnet Lock Assy (Lh)          | 408  | 87089900 | 18% |
| 93403166 | Eicher Tractor Asm Bonnet Locator Pin              | 97   | 73182100 | 18% |
| 93403178 | Eicher Tractor Fuel Pipe Assy -550 Lg ( Ft To Ws)  | 451  | 40092200 | 18% |
| 93403208 | Eicher Tractor Bonnet Sticker Eicher Rh (Low Hp)   | 591  | 39199090 | 18% |
| 93403210 | Eicher Tractor Bonnet Sticker Eicher Lh (Low Hp)   | 591  | 39199090 | 18% |
| 93403221 | Eicher Tractor Bonnet Lh Sticker 551               | 44   | 39199090 | 18% |
| 93403233 | Eicher Tractor Bonnet Rh Sticker 551               | 594  | 39199090 | 18% |
| 93403300 | Eicher Tractor Scuttle Sticker 480                 | 44   | 39199090 | 18% |
| 93403348 | Eicher Tractor Bonnet Lh Sticker 557 (Red)         | 829  | 39199090 | 18% |
| 93403350 | Eicher Tractor Bonnet Rh Sticker 557 (Red)         | 829  | 39199090 | 18% |
| 93403385 | Eicher Tractor Assy Bonnet Front Bottom            | 2865 | 87089900 | 18% |
| 93403440 | Eicher Tractor Bkt Radiator Top Mbr 557/(650-T3)   | 899  | 87087000 | 18% |
| 93403452 | Eicher Tractor Radiator Sealing Lh 557/(650-T3)    | 319  | 87087000 | 18% |
| 93403464 | Eicher Tractor Radiator Sealing Rh 557/(650-T3)    | 319  | 87087000 | 18% |
| 93403476 | Eicher Tractor Radiator Sealing Top 551/557/(650-T | 532  | 87087000 | 18% |
| 93403506 | Eicher Tractor Bkt Radiator Top Mbr 551            | 620  | 87087000 | 18% |
| 93403518 | Eicher Tractor Radiator Sealing Lh 551             | 317  | 87087000 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93403520 | Eicher Tractor Radiator Sealing Rh 551             | 317  | 87087000 | 18% |
| 93403610 | Eicher Tractor Overflow Pipe Assy- 551/557 (Fip To | 410  | 87089900 | 18% |
| 93403622 | Eicher Tractor Outlet Hose Fuel Cooler To Ft       | 1038 | 40093100 | 18% |
| 93403671 | Eicher Tractor Rubber Pad (Firewall Side)          | 24   | 40169990 | 18% |
| 93403683 | Eicher Tractor Scuttle Mtg Brkt Steering Side 650  | 442  | 87089400 | 18% |
| 93403695 | Eicher Tractor Scuttle Leg Lh-Ns 380               | 630  | 87089900 | 18% |
| 93403701 | Eicher Tractor Scuttle Leg Rh- 380 Ps              | 630  | 87089900 | 18% |
| 93403713 | Eicher Tractor Scuttle Leg Lh- Ns 557/650          | 742  | 87089900 | 18% |
| 93403725 | Eicher Tractor Scuttle Leg Rh-Ns 557/650           | 742  | 87089900 | 18% |
| 93403774 | Eicher Tractor U- Brackett (Stg. Column)           | 129  | 87084000 | 18% |
| 93403786 | Eicher Tractor Rubber Grommet (Stg. Column)        | 158  | 40169990 | 18% |
| 93403828 | Eicher Tractor Support Bkt- Ns (480 - 4Wd)         | 701  | 87089900 | 18% |
| 93403830 | Eicher Tractor Steering Bellow                     | 239  | 87089400 | 18% |
| 93403907 | Eicher Tractor Mirror Assembly Rh                  | 638  | 70091090 | 18% |
| 93403993 | Eicher Tractor Engine Mtg. Bkt Lh 380              | 433  | 87089900 | 18% |
| 93404006 | Eicher Tractor Engine Mtg. Bkt Rh 380              | 578  | 87089900 | 18% |
| 93404018 | Eicher Tractor Engine Mtg. Bkt Lh 551              | 538  | 87089900 | 18% |
| 93404020 | Eicher Tractor Engine Mtg. Bkt Rh 551              | 686  | 87089900 | 18% |
| 93404031 | Eicher Tractor Engine Mtg. Bkt Lh 557/650          | 644  | 87089900 | 18% |
| 93404043 | Eicher Tractor Engine Mtg. Bkt Rh 557/650          | 703  | 87089900 | 18% |
| 93404079 | Eicher Tractor Scuttle Mtg Bkt Top (Rear Opening)  | 205  | 87089900 | 18% |
| 93404171 | Eicher Tractor Firewall (Low Power) Rear Opening   | 5686 | 87089900 | 18% |
| 93404183 | Eicher Tractor Steering Wheel With Knob (Dia. 380) | 1592 | 87089400 | 18% |
| 93404195 | Eicher Tractor Steering Wheel Ø434                 | 1773 | 87089400 | 18% |
| 93404286 | Eicher Tractor Air Cleaner Assy New (557)          | 6223 | 87089900 | 18% |
| 93404353 | Eicher Tractor Air Cleaner Assy.                   | 6291 | 87089900 | 18% |
| 93404365 | Eicher Tractor Alternator Cover 380 Ms             | 845  | 87085000 | 18% |
| 93404390 | Eicher Tractor Air Cleaner Grommet                 | 209  | 87089900 | 18% |
| 93404456 | Eicher Tractor Steering Inlet Pipe Assy (380/480/3 | 664  | 40092200 | 18% |
| 93404468 | Eicher Tractor St. Return Pipe Assy 551            | 1819 | 87089400 | 18% |
| 93404470 | Eicher Tractor Steering Inlet Pipe Assy 551        | 832  | 87089400 | 18% |
| 93404481 | Eicher Tractor Pipe Steering Left 551              | 806  | 87089400 | 18% |
| 93404500 | Eicher Tractor Hose Pr. Line Filter 551            | 1127 | 40093100 | 18% |
| 93404511 | Eicher Tractor Steering Hose 551                   | 1036 | 87089400 | 18% |
| 93404523 | Eicher Tractor Suction Pipe Front 557/650          | 514  | 87089900 | 18% |
| 93404535 | Eicher Tractor Suction Pipe Rear 557/650           | 1256 | 87089900 | 18% |
| 93404547 | Eicher Tractor Hose Pressure Line Filter 557/650   | 1158 | 40093100 | 18% |
| 93404559 | Eicher Tractor Steering Inlet Pipe 557/650         | 815  | 87089400 | 18% |
| 93404560 | Eicher Tractor Pipe Steering Left 557/650          | 871  | 87089400 | 18% |
| 93404571 | Eicher Tractor Pipe Steering Right P1 557/650      | 826  | 87089400 | 18% |
| 93404626 | Eicher Tractor Accelerator Linkage Sub Assy. 551 H | 1416 | 87089900 | 18% |
| 93404717 | Eicher Tractor Assy Bump Stop Front Opening (650)  | 3379 | 87084000 | 18% |
| 93404730 | Eicher Tractor Grommet Hand Acc                    | 56   | 40169990 | 18% |
| 93404742 | Eicher Tractor Assy Scuttle Mtg Top Firewall Side  | 213  | 87089900 | 18% |
| 93404754 | Eicher Tractor Rubber Flap                         | 117  | 40169320 | 18% |
| 93404808 | Eicher Tractor Riblok                              | 7    | 87089900 | 18% |
| 93404810 | Eicher Tractor Metal U-Nut                         | 15   | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93404869 | Eicher Tractor Support Bkt- Ns (380/480 Ms)        | 702  | 87089900 | 18% |
| 93404948 | Eicher Tractor Wh Main 333/380/480 (Rear Opening)  | 5276 | 87089900 | 18% |
| 93404961 | Eicher Tractor Wh Main 551/551S+/5660 (Rear Openin | 5167 | 87089900 | 18% |
| 93405047 | Eicher Tractor Wh Front 333/380/480 (Rear Opening) | 1498 | 87089900 | 18% |
| 93405059 | Eicher Tractor Wh Front 551/551S+/5660 (Rear Openi | 1580 | 87089900 | 18% |
| 93405205 | Eicher Tractor Wh Headlamp (Front Opening)         | 753  | 87089900 | 18% |
| 93405321 | Eicher Tractor Air Cleaner Mtg. Bracket (551 Ps Hy | 3703 | 87089900 | 18% |
| 93405333 | Eicher Tractor Air Cleaner Mtg. Bracket (551 Ps No | 3638 | 87089900 | 18% |
| 93405382 | Eicher Tractor Front Hinge Support Bkt Lh (333/380 | 566  | 87089900 | 18% |
| 93405394 | Eicher Tractor Front Hinge Support Bkt Rh (333/380 | 566  | 87089900 | 18% |
| 93405400 | Eicher Tractor Radiator Mtg. Bkt. (333/380/480 Hyd | 2778 | 87087000 | 18% |
| 93405424 | Eicher Tractor Return Pipe Assy 557/650            | 1351 | 87089400 | 18% |
| 93405436 | Eicher Tractor Front Hinge Support Bkt Lh - Ns (48 | 840  | 87089900 | 18% |
| 93405448 | Eicher Tractor Front Hinge Support Bkt Rh - Ns (48 | 840  | 87089900 | 18% |
| 93405450 | Eicher Tractor Front Hinge Support Bkt Lh - Ns (54 | 773  | 87089900 | 18% |
| 93405461 | Eicher Tractor Front Hinge Support Bkt Rh - Ns (54 | 773  | 87089900 | 18% |
| 93405485 | Eicher Tractor Rr Opening Rubber Stopper           | 185  | 87089900 | 18% |
| 93405515 | Eicher Tractor Support Bkt- Ns (548/551 - 4Wd)     | 529  | 87089900 | 18% |
| 93405552 | Eicher Tractor Rear Bonnet Lock Assy (Rh)          | 408  | 87089900 | 18% |
| 93405564 | Eicher Tractor Sleeve -Ns (Low Hp Bumper)          | 129  | 87084000 | 18% |
| 93405590 | Eicher Tractor Weld Assy Scuttle Mtg               | 442  | 87089900 | 18% |
| 93405618 | Eicher Tractor Scuttle Mtg Lh Firewall Side        | 331  | 87089900 | 18% |
| 93405620 | Eicher Tractor Scuttle Mtg Rh Firewall Side        | 331  | 87089900 | 18% |
| 93405631 | Eicher Tractor Assy Scuttle Mtg Top                | 227  | 87089900 | 18% |
| 93405667 | Eicher Tractor Front Lock 551 Super Plus           | 1095 | 87089900 | 18% |
| 93405679 | Eicher Tractor Assy Striker Mtg 551                | 267  | 87089900 | 18% |
| 93405734 | Eicher Tractor Assy Bump Stop Front                | 3116 | 87084000 | 18% |
| 93405758 | Eicher Tractor Steering Eicher Logo                | 28   | 87089400 | 18% |
| 93405813 | Eicher Tractor Bonnet Hinge Asly Rear Opening 650  | 5064 | 87089900 | 18% |
| 93405825 | Eicher Tractor Latch Mtg Base Plate (Rear Opening) | 334  | 87084000 | 18% |
| 93405849 | Eicher Tractor Steering Bracket 380 Ps             | 2000 | 87089400 | 18% |
| 93405850 | Eicher Tractor Base Mounting Bracket (A/C) / Air C | 969  | 87089900 | 18% |
| 93406271 | Eicher Tractor Striker Pin                         | 80   | 87089900 | 18% |
| 93406283 | Eicher Tractor Bonnet Rubber Beading (Front Openin | 692  | 87089900 | 18% |
| 93406301 | Eicher Tractor Rubber Sealing Front Sealing        | 620  | 73182990 | 18% |
| 93406313 | Eicher Tractor Rubber Sealing 551 Super Plus(Front | 623  | 40169990 | 18% |
| 93406325 | Eicher Tractor Fuel Lid Striker Bkt                | 26   | 87089900 | 18% |
| 93406337 | Eicher Tractor Grommet (Araymond)                  | 8    | 40169990 | 18% |
| 93406349 | Eicher Tractor Latch (Push-Push) -ltw              | 2    | 87085000 | 18% |
| 93406374 | Eicher Tractor Front Bonnet Bumper 380 (Rear Openi | 1665 | 87081010 | 18% |
| 93406398 | Eicher Tractor Starter Switch + Key                | 701  | 85123010 | 18% |
| 93406416 | Eicher Tractor Steering Column 650-Ns (With Horn)  | 2991 | 87089400 | 18% |
| 93406428 | Eicher Tractor Steering Wheel With Horn(380 Dia)   | 2168 | 87089400 | 18% |
| 93406430 | Eicher Tractor Assy. Rr Hinge Bonnet Side          | 783  | 87089900 | 18% |
| 93406441 | Eicher Tractor Assy. Rr Hinge Firewall Side Lh     | 969  | 87089900 | 18% |
| 93406453 | Eicher Tractor Assy. Rr Hinge Firewall Side Rh     | 969  | 87089900 | 18% |
| 93406465 | Eicher Tractor Hinge Pin Bonnet (Front Opening)    | 98   | 73182100 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93406490 | Eicher Tractor Wh Main 557 (Front Opening)         | 6306 | 87089900 | 18% |
| 93406507 | Eicher Tractor Wh Front 557 (Front Opening)        | 1236 | 87089900 | 18% |
| 93406830 | Eicher Tractor Scc Middle Trim                     | 430  | 87089900 | 18% |
| 93406842 | Eicher Tractor Scc Lh Trim Assy Ns                 | 519  | 87089900 | 18% |
| 93406854 | Eicher Tractor Scc Rh Trim Assy Ns                 | 519  | 87089900 | 18% |
| 93406908 | Eicher Tractor Fuse Box Mtg Bkt (Middle Steering C | 158  | 85369090 | 18% |
| 93407780 | Eicher Tractor Piano Switch 1 (Hazard Switch)      | 688  | 85122020 | 18% |
| 93407792 | Eicher Tractor Piano Switch 2 (Go-Home Switch)     | 369  | 85122020 | 18% |
| 93408103 | Eicher Tractor Accelerator Linkage Sub Assly - 557 | 1398 | 87089900 | 18% |
| 93408115 | Eicher Tractor Connecting Link -Fip 557            | 258  | 87089900 | 18% |
| 93408139 | Eicher Tractor Acc Rod Assy                        | 301  | 87089900 | 18% |
| 93408140 | Eicher Tractor Accelerator Knob                    | 203  | 87084000 | 18% |
| 93408152 | Eicher Tractor Horn Pad With Horn                  | 688  | 85123010 | 18% |
| 93408164 | Eicher Tractor Horn Pad Without Horn               | 258  | 85123010 | 18% |
| 93408176 | Eicher Tractor Pu Knob With Cap                    | 206  | 87084000 | 18% |
| 93408188 | Eicher Tractor W/H Headlamp Support Bkt            | 74   | 87089900 | 18% |
| 93408206 | Eicher Tractor Instrument Cluster_551/551S+(1788)/ | 8270 | 85123010 | 18% |
| 93408218 | Eicher Tractor Instrument Cluster W/O Bezzel       | 4876 | 90292020 | 18% |
| 93408279 | Eicher Tractor Pressure Connection Flange 7/8      | 795  | 87089900 | 18% |
| 93408280 | Eicher Tractor Pipe Steering Right P2 557/650      | 611  | 87089400 | 18% |
| 93408322 | Eicher Tractor Instrument Cluster W/O Bezzel       | 4876 | 90292020 | 18% |
| 93408334 | Eicher Tractor Switch Cap (3.5Mm)                  | 62   | 87083000 | 18% |
| 93408371 | Eicher Tractor Brake Pedal Assy Lt Hyd (Wdb)       | 1972 | 87083000 | 18% |
| 93408395 | Eicher Tractor Brake Pedal Assy Rt Hyd (Wdb)       | 1672 | 87083000 | 18% |
| 93408413 | Eicher Tractor Brake Pedal Assy Rt                 | 2171 | 87083000 | 18% |
| 93408425 | Eicher Tractor Brake Pedal Asst Lt                 | 1561 | 87083000 | 18% |
| 93408437 | Eicher Tractor Brake Pedal Assy. Left              | 1555 | 87083000 | 18% |
| 93408449 | Eicher Tractor Brake Pedal Assy. Right             | 2191 | 87083000 | 18% |
| 93408528 | Eicher Tractor Pressure Pipe 551 Ms                | 1249 | 87089900 | 18% |
| 93408530 | Eicher Tractor Pressure Pipe Mid 557/650           | 899  | 87089900 | 18% |
| 93408553 | Eicher Tractor Steering Return Pipe 551 Hyd        | 1345 | 87089400 | 18% |
| 93408620 | Eicher Tractor Hose Pressure Line Filter 551 4Wd   | 1483 | 40093100 | 18% |
| 93408632 | Eicher Tractor Return Pipe Assy 551 4Wd            | 2097 | 40092200 | 18% |
| 93408656 | Eicher Tractor Steering Pipe Left 551 4Wd          | 884  | 87089400 | 18% |
| 93408681 | Eicher Tractor Steering Pipe Left 557 4Wd          | 812  | 87089400 | 18% |
| 93408711 | Eicher Tractor Steering Pipe Right 480/380 4Wd     | 786  | 87089400 | 18% |
| 93408723 | Eicher Tractor Steering Pipe Left 480/380 4Wd      | 827  | 87089400 | 18% |
| 93408772 | Eicher Tractor Wiring Harness Main                 | 7583 | 85123010 | 18% |
| 93408784 | Eicher Tractor Wiring Harness Front                | 907  | 85123010 | 18% |
| 93408796 | Eicher Tractor Instrument Cluster With Panel Assy. | 8286 | 85123010 | 18% |
| 93408802 | Eicher Tractor Instument Cluster_557               | 7866 | 85123010 | 18% |
| 93408814 | Eicher Tractor Wh Main 557/551S+ (Front Opening)   | 7671 | 87089900 | 18% |
| 93408863 | Eicher Tractor Wire Rod Assy-Es3                   | 504  | 85122010 | 18% |
| 93408875 | Eicher Tractor Wire Rod Mtg                        | 48   | 85122010 | 18% |
| 93408887 | Eicher Tractor Link Rod – 551/557                  | 76   | 84099941 | 28% |
| 93408899 | Eicher Tractor Link Rod -380/480                   | 66   | 84099941 | 28% |
| 93408917 | Eicher Tractor Fuel Pipe Assy (Ft-Ws) 380/480,2Wd  | 372  | 40092200 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93408942 | Eicher Tractor Suction Pipe Front 776/884 Es3      | 751   | 87089900 | 18% |
| 93408954 | Eicher Tractor Suction Pipe Rear 776/884 Es3       | 1269  | 87089900 | 18% |
| 93408980 | Eicher Tractor Hose Pressure Line Filter 776/884   | 1454  | 40093100 | 18% |
| 93409168 | Eicher Tractor Bkt Radiator Top Mbr 480            | 913   | 87087000 | 18% |
| 93409181 | Eicher Tractor Fanguard Bkt Rh (557)               | 562   | 85030090 | 18% |
| 93409193 | Eicher Tractor Assy Fan Guard Lh (380/551)         | 1050  | 85030090 | 18% |
| 93409211 | Eicher Tractor Fanguard Bkt Upper Lh 380           | 172   | 85030090 | 18% |
| 93409223 | Eicher Tractor Fanguard Bkt Rh (380-Ps)            | 653   | 85030090 | 18% |
| 93409284 | Eicher Tractor Fan Guard Assy. Rh 557              | 958   | 85030090 | 18% |
| 93409296 | Eicher Tractor Lower Bkt Assy Lh 557               | 120   | 87089900 | 18% |
| 93409302 | Eicher Tractor Lower Bkt Assy Rh 557               | 118   | 87089900 | 18% |
| 93409314 | Eicher Tractor Fanguard Bkt Upper Lh (557) Engine  | 137   | 85030090 | 18% |
| 93409326 | Eicher Tractor Engine Exhaust Bkt Rh 557           | 104   | 84099941 | 28% |
| 93409338 | Eicher Tractor Alternator Cover Assy.              | 555   | 87085000 | 18% |
| 93409363 | Eicher Tractor Fanguard Upper Bkt Rear Rh (551)    | 164   | 85030090 | 18% |
| 93409375 | Eicher Tractor Assy Fan Guard Rh (380/551)         | 977   | 85030090 | 18% |
| 93409387 | Eicher Tractor Fanguard Upper Bkt Lh (551)         | 210   | 85030090 | 18% |
| 93409399 | Eicher Tractor Alternator Cover 380 Ps             | 903   | 87085000 | 18% |
| 93409533 | Eicher Tractor Brake Pedal Assy. Lt (4Wd-Hyd)      | 2044  | 87083000 | 18% |
| 93409545 | Eicher Tractor Brake Pedal Assy. Rt (4Wd-Hyd)      | 2261  | 87083000 | 18% |
| 93409697 | Eicher Tractor Fan Guard Assy. Lh 557              | 970   | 85030090 | 18% |
| 93409788 | Eicher Tractor Fan Guard Bkt Rear Lh (551)         | 353   | 85030090 | 18% |
| 93409806 | Eicher Tractor Fanguard Bkt Lh (551)               | 171   | 85030090 | 18% |
| 93409831 | Eicher Tractor Fanguard Bkt Rh (551)               | 171   | 85030090 | 18% |
| 93409909 | Eicher Tractor Sticker 776 Kromex Badge Lh         | 599   | 39199090 | 18% |
| 93409922 | Eicher Tractor Sticker 884 Kromex Badge Rh         | 621   | 39199090 | 18% |
| 93409946 | Eicher Tractor Badge Sticker 557                   | 610   | 39199090 | 18% |
| 93409960 | Eicher Tractor Scuttle Sticker 380                 | 44    | 39199090 | 18% |
| 93410146 | Eicher Tractor Bonnet Graphics Right-Silver S.Meta | 1440  | 39199090 | 18% |
| 93410158 | Eicher Tractor Super Di Plate(Red)                 | 152   | 39199090 | 18% |
| 93410160 | Eicher Tractor Fuel Tank Graphics Left-Silver S.Me | 423   | 39199090 | 18% |
| 93410171 | Eicher Tractor Fuel Tank Graphics Right-Silver S.M | 436   | 39199090 | 18% |
| 93410250 | Eicher Tractor 485 Plate-Silver S.Metal            | 161   | 39199090 | 18% |
| 93410470 | Eicher Tractor Chain Assembly                      | 1136  | 87089900 | 18% |
| 93410481 | Eicher Tractor Lower Link Lt. Assy                 | 2735  | 87089900 | 18% |
| 93410500 | Eicher Tractor Lower Link Rt. Assy                 | 2735  | 87089900 | 18% |
| 93410559 | Eicher Tractor Bracket Left                        | 154   | 87089900 | 18% |
| 93410560 | Eicher Tractor Bracket Right                       | 154   | 87089900 | 18% |
| 93410705 | Eicher Tractor Bracket Assembly                    | 1315  | 87089900 | 18% |
| 93410730 | Eicher Tractor Stud M16                            | 94    | 73182100 | 18% |
| 93410766 | Eicher Tractor Disc Spring 31.05X16.3X2            | 94    | 87089900 | 18% |
| 93410792 | Eicher Tractor Plate                               | 783   | 87089400 | 18% |
| 93410924 | Eicher Tractor Bumper Assembly                     | 15592 | 87081010 | 18% |
| 93410948 | Eicher Tractor V Ring Guard                        | 38    | 87089900 | 18% |
| 93411217 | Eicher Tractor Front Axle Assy                     | 15564 | 87085000 | 18% |
| 93411345 | Eicher Tractor Bonnet Strip Left                   | 54    | 39199090 | 18% |
| 93411357 | Eicher Tractor Bonnet Strip Right                  | 54    | 39199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93411382 | Eicher Tractor 380 Plate                           | 116   | 83100090 | 18% |
| 93411837 | Eicher Tractor Threaded Bush Rt. For Top Link      | 276   | 87089900 | 18% |
| 93411886 | Eicher Tractor Bush With Guard                     | 461   | 87089900 | 18% |
| 93411898 | Eicher Tractor Hub                                 | 1779  | 87085000 | 18% |
| 93412180 | Eicher Tractor Smv Emblem Mounting Plate           | 249   | 87089900 | 18% |
| 93412209 | Eicher Tractor Foot Board Left                     | 987   | 87089900 | 18% |
| 93412234 | Eicher Tractor Clutch Pedal Dc                     | 1287  | 87089300 | 18% |
| 93412246 | Eicher Tractor Tension Tie Assy                    | 298   | 87083000 | 18% |
| 93412337 | Eicher Tractor Lift Arm                            | 3635  | 87089900 | 18% |
| 93412349 | Eicher Tractor Lower Link Bracket Lt.              | 1337  | 87089900 | 18% |
| 93412350 | Eicher Tractor Lower Link Bracket Rt.              | 1276  | 87089900 | 18% |
| 93412362 | Eicher Tractor Lift Arm                            | 3545  | 87089900 | 18% |
| 93412489 | Eicher Tractor Rubber Beading -Battery Cover Sdi   | 17    | 40169320 | 18% |
| 93412532 | Eicher Tractor Brake Pedal Rt.                     | 1015  | 87083000 | 18% |
| 93412544 | Eicher Tractor Foot Board Right 312P / 364P        | 974   | 87089900 | 18% |
| 93412647 | Eicher Tractor Wheel Rim W11 (12.4X28 Tyre)-152.4  | 10510 | 87087000 | 18% |
| 93412684 | Eicher Tractor Pedal Shaft                         | 1824  | 87084000 | 18% |
| 93412799 | Eicher Tractor Bonnet Bumper                       | 1081  | 87081010 | 18% |
| 93412830 | Eicher Tractor Bonnet Plate                        | 2657  | 87081010 | 18% |
| 93412891 | Eicher Tractor Tool Box - Plastic                  | 618   | 39021000 | 18% |
| 93412908 | Eicher Tractor Spacer                              | 78    | 73182100 | 18% |
| 93413032 | Eicher Tractor Cushioning Pad                      | 157   | 40169990 | 18% |
| 93413081 | Eicher Tractor Foot Acc Shaft Guide (Wdb)          | 147   | 87085000 | 18% |
| 93413093 | Eicher Tractor Lock Nut                            | 20    | 73181500 | 18% |
| 93413100 | Eicher Tractor Mounting Bracket Clamp              | 43    | 87089900 | 18% |
| 93413111 | Eicher Tractor Hand Accelerator Bracket            | 245   | 87089900 | 18% |
| 93413135 | Eicher Tractor Mounting Eye Assy                   | 167   | 87085000 | 18% |
| 93413214 | Eicher Tractor Cover Assy                          | 1695  | 87084000 | 18% |
| 93413226 | Eicher Tractor Cover Assy                          | 2319  | 87084000 | 18% |
| 93413251 | Eicher Tractor Front Axle Support                  | 12875 | 87089900 | 18% |
| 93413263 | Eicher Tractor Bush For Cover Assly                | 383   | 84833000 | 18% |
| 93413317 | Eicher Tractor Cogged Belt Avx 10/1070 Mm          | 292   | 40103999 | 18% |
| 93413755 | Eicher Tractor 364 Graphic Plate                   | 122   | 39199090 | 18% |
| 93413809 | Eicher Tractor Cover Assy                          | 2282  | 87084000 | 18% |
| 93414000 | Eicher Tractor Lift Arm Bigger Addc                | 4367  | 87089900 | 18% |
| 93414012 | Eicher Tractor Lower Link Assy Left                | 2602  | 87089900 | 18% |
| 93414061 | Eicher Tractor Hose (A/C Side)                     | 763   | 40093100 | 18% |
| 93414073 | Eicher Tractor Air Intake Tube                     | 192   | 40093100 | 18% |
| 93414097 | Eicher Tractor Strip                               | 126   | 73011000 | 18% |
| 93414103 | Eicher Tractor Hose Water (Eng.Out Let To Radiator | 279   | 40093100 | 18% |
| 93414127 | Eicher Tractor Lift Arm-Sw (Ph-2)                  | 2374  | 87089900 | 18% |
| 93414188 | Eicher Tractor Al. Radiator                        | 9217  | 87087000 | 18% |
| 93414218 | Eicher Tractor B P Lt ( 312/364 )                  | 1127  | 87083000 | 18% |
| 93414255 | Eicher Tractor Tank Unit Sdi/Wc/Int                | 369   | 87089900 | 18% |
| 93414310 | Eicher Tractor Lifting Gear Assy - 485             | 2563  | 87089900 | 18% |
| 93414322 | Eicher Tractor Hand Acc Link                       | 82    | 87089900 | 18% |
| 93414346 | Eicher Tractor Mudguard Red Sticker -368           | 55    | 39199090 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93414358 | Eicher Tractor Mudguard Red Sticker -380           | 76    | 39199090 | 18% |
| 93414395 | Eicher Tractor Bracket                             | 129   | 87089900 | 18% |
| 93414670 | Eicher Tractor Front Wheel Hub                     | 2022  | 87087000 | 18% |
| 93414772 | Eicher Tractor Spacer (Fuel Tank)                  | 293   | 73182100 | 18% |
| 93414796 | Eicher Tractor Steering Unit (Zf)                  | 10114 | 87089400 | 18% |
| 93414814 | Eicher Tractor Strut                               | 49    | 87089400 | 18% |
| 93414826 | Eicher Tractor Fuel Tank Bracket                   | 979   | 87089900 | 18% |
| 93414838 | Eicher Tractor Main Mtg. Bracket                   | 885   | 87089900 | 18% |
| 93414863 | Eicher Tractor Hand Accelerator Link               | 37    | 87089900 | 18% |
| 93414966 | Eicher Tractor Thrust Plate (Asp/Dsp) 2.9 Thick    | 218   | 87084000 | 18% |
| 93415090 | Eicher Tractor Water Separator Bkt                 | 161   | 87089900 | 18% |
| 93415156 | Eicher Tractor Flywheel Housing M/C                | 25135 | 87084000 | 18% |
| 93415200 | Eicher Tractor Clamping Bracket                    | 33    | 87089900 | 18% |
| 93415211 | Eicher Tractor Mounting Bracket                    | 97    | 87089900 | 18% |
| 93415235 | Eicher Tractor Spacer Small - Rhs                  | 61    | 73182100 | 18% |
| 93415259 | Eicher Tractor P T O Shaft With Bush               | 2652  | 87084000 | 18% |
| 93415272 | Eicher Tractor Hand Acc. Levfer                    | 175   | 84099941 | 28% |
| 93415284 | Eicher Tractor Hand Accelerator Lever (Lower)      | 108   | 87089900 | 18% |
| 93415296 | Eicher Tractor Hand Accl Rod (5150/5660            | 384   | 84099941 | 28% |
| 93415387 | Eicher Tractor Water Separator                     | 678   | 84212300 | 18% |
| 93415417 | Eicher Tractor Eicher Plate                        | 153   | 83100090 | 18% |
| 93415442 | Eicher Tractor Strip Graphics Lt.                  | 123   | 39199090 | 18% |
| 93415454 | Eicher Tractor Strip Graphics Rt.                  | 76    | 39199090 | 18% |
| 93415466 | Eicher Tractor Fuel Tank Graphics Lt               | 86    | 39199090 | 18% |
| 93415478 | Eicher Tractor Fuel Tank Graphics Rt               | 86    | 39199090 | 18% |
| 93415480 | Eicher Tractor Sticker Recardo Engine - English    | 64    | 39199090 | 18% |
| 93415600 | Eicher Tractor Sticker Recardo Engine -Hindi       | 51    | 39199090 | 18% |
| 93415697 | Eicher Tractor Plate '3'                           | 33    | 39199090 | 18% |
| 93415739 | Eicher Tractor Spacer Big - Lhs                    | 74    | 73182100 | 18% |
| 93415788 | Eicher Tractor Bonnet Graphics Lt                  | 403   | 39199090 | 18% |
| 93415790 | Eicher Tractor Bonnet Graphics Rt                  | 403   | 39199090 | 18% |
| 93415806 | Eicher Tractor Front Wheel Bolt 1/2" Unf X 41.5(8. | 34    | 73181500 | 18% |
| 93415922 | Eicher Tractor Shoulder Bush                       | 1072  | 87085000 | 18% |
| 93415946 | Eicher Tractor Ft Strip Top Lt                     | 35    | 39199090 | 18% |
| 93415958 | Eicher Tractor Ft Strip Bottom Lt                  | 28    | 39199090 | 18% |
| 93415960 | Eicher Tractor Ft Strip Top Rt                     | 35    | 39199090 | 18% |
| 93415971 | Eicher Tractor Ft Strip Bottom Rt                  | 28    | 39199090 | 18% |
| 93415983 | Eicher Tractor Rigid Fuel Pipe                     | 362   | 40094200 | 18% |
| 93416033 | Eicher Tractor Bumper Mtg. Bkt.                    | 2914  | 87081010 | 18% |
| 93416045 | Eicher Tractor Lower Link Bracket Lt.              | 1314  | 87089900 | 18% |
| 93416057 | Eicher Tractor Lower Link Bracket Rt.              | 1312  | 87089900 | 18% |
| 93416069 | Eicher Tractor Chain Mtg Bkt Lt                    | 1119  | 87089900 | 18% |
| 93416070 | Eicher Tractor Chain Mtg Bkt Rt                    | 1119  | 87089900 | 18% |
| 93416100 | Eicher Tractor Lower Link Assly Lt.                | 2448  | 87089900 | 18% |
| 93416112 | Eicher Tractor Lower Link Assly Rt.                | 2447  | 87089900 | 18% |
| 93416136 | Eicher Tractor Fork And Guide Assy                 | 1698  | 87089900 | 18% |
| 93416458 | Eicher Tractor Front Axle Support                  | 10984 | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93416550 | Eicher Tractor Drain Plug                     | 38    | 87084000 | 18% |
| 93416616 | Eicher Tractor Bracket For Brake Switch       | 79    | 87083000 | 18% |
| 93416859 | Eicher Tractor Refelector Mounting Plate      | 83    | 87089900 | 18% |
| 93417013 | Eicher Tractor Back Rest Rt.                  | 1160  | 87089900 | 18% |
| 93417128 | Eicher Tractor Drag Link                      | 2639  | 87089400 | 18% |
| 93417414 | Eicher Tractor Foot Acc. Shaft Guide          | 159   | 87085000 | 18% |
| 93417426 | Eicher Tractor Foot Accelerator Shaft         | 168   | 87084000 | 18% |
| 93417440 | Eicher Tractor Hand Accelerator Rod           | 277   | 84099941 | 28% |
| 93417463 | Eicher Tractor Nylon Bush                     | 38    | 87089900 | 18% |
| 93417487 | Eicher Tractor Fiber Washer                   | 16    | 87089900 | 18% |
| 93417499 | Eicher Tractor Lever (Bottom)                 | 135   | 87089900 | 18% |
| 93417505 | Eicher Tractor Link Bottom                    | 90    | 87089900 | 18% |
| 93417578 | Eicher Tractor Clutch Pedal Sc                | 1464  | 87089300 | 18% |
| 93417580 | Eicher Tractor Clutch Peadl Sw(Dc)            | 1470  | 87089300 | 18% |
| 93417621 | Eicher Tractor Front Wheel Weight             | 3484  | 73259910 | 18% |
| 93417669 | Eicher Tractor Bkt For Support Bottle         | 97    | 87089100 | 18% |
| 93417876 | Eicher Tractor Mudguard Support For Small Top | 302   | 87089900 | 18% |
| 93417888 | Eicher Tractor Mudguard Support For Big Top   | 556   | 87089900 | 18% |
| 93417906 | Eicher Tractor Water Seperator Bracket        | 138   | 87089900 | 18% |
| 93417992 | Eicher Tractor Foot Step                      | 528   | 87089900 | 18% |
| 93418005 | Eicher Tractor Brake Linkage Mechanism        | 409   | 87083000 | 18% |
| 93418042 | Eicher Tractor Hand Brake Lever Assy- 380 Sw  | 536   | 87083000 | 18% |
| 93418054 | Eicher Tractor Lifting Gear Mech 380 -Gt      | 3140  | 84834000 | 18% |
| 93418066 | Eicher Tractor Fork & Guide Mechanism         | 2226  | 87089900 | 18% |
| 93418078 | Eicher Tractor Hose (Radiator To Inlet Tube)  | 234   | 40093100 | 18% |
| 93418285 | Eicher Tractor Lower Link Assly Lt.           | 3240  | 87089900 | 18% |
| 93418297 | Eicher Tractor Lower Link Assly Rt.           | 3287  | 87089900 | 18% |
| 93418303 | Eicher Tractor Steering Wheel With Cap        | 1047  | 87089400 | 18% |
| 93418315 | Eicher Tractor Protection Plate               | 205   | 87089100 | 18% |
| 93418388 | Eicher Tractor Foot Accelerator Pedal         | 159   | 87084000 | 18% |
| 93418418 | Eicher Tractor Brake Pedal Assy Lt            | 1420  | 87083000 | 18% |
| 93418420 | Eicher Tractor Steering Gear Support          | 1813  | 87089400 | 18% |
| 93418431 | Eicher Tractor Steering Support Pad           | 635   | 87089400 | 18% |
| 93418510 | Eicher Tractor Cover Pressure Pipe            | 88    | 87089900 | 18% |
| 93418522 | Eicher Tractor Link Assly.                    | 47    | 87089900 | 18% |
| 93418601 | Eicher Tractor Lower Link Assly Lt.           | 2834  | 87089900 | 18% |
| 93418613 | Eicher Tractor Lower Link Assly Rt.           | 2629  | 87089900 | 18% |
| 93418959 | Eicher Tractor Chain Assy                     | 1319  | 87089900 | 18% |
| 93418960 | Eicher Tractor Chain Assy                     | 1637  | 87089900 | 18% |
| 93418984 | Eicher Tractor Air Cleaner Bracket            | 3059  | 84099941 | 28% |
| 93419022 | Eicher Tractor Recovery Bottle                | 279   | 87089100 | 18% |
| 93419071 | Eicher Tractor Accelerator Rod Guide Assly    | 151   | 87084000 | 18% |
| 93419083 | Eicher Tractor Upper Bracket Assly            | 213   | 87089900 | 18% |
| 93419149 | Eicher Tractor Battery Box                    | 2049  | 85079090 | 28% |
| 93419150 | Eicher Tractor Rigid Fuel Line Assly.         | 382   | 84099941 | 28% |
| 93419289 | Eicher Tractor Accelerator Lever Left         | 70    | 87084000 | 18% |
| 93419332 | Eicher Tractor Front Axle Assy                | 11033 | 87085000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93419368 | Eicher Tractor Assy. For Coupling Shaft             | 1962  | 87084000 | 18% |
| 93419459 | Eicher Tractor Gasket For Starter Motor             | 16    | 68129090 | 18% |
| 93419484 | Eicher Tractor Battery Pad Top                      | 15    | 85079090 | 28% |
| 93419502 | Eicher Tractor Steering Cover                       | 571   | 87089900 | 18% |
| 93419514 | Eicher Tractor Fuse Mtg. Bracket                    | 76    | 85122010 | 18% |
| 93419526 | Eicher Tractor Water Hose                           | 376   | 40093100 | 18% |
| 93419587 | Eicher Tractor Foot Board Left                      | 1008  | 87089900 | 18% |
| 93419599 | Eicher Tractor Battery Mounting Bkt                 | 987   | 85079090 | 28% |
| 93419605 | Eicher Tractor Hook                                 | 163   | 87089900 | 18% |
| 93419708 | Eicher Tractor Front Axle And Support Asst.         | 54258 | 87089900 | 18% |
| 93419745 | Eicher Tractor Fuel Line Assy. (Feed Pump To Filter | 245   | 84219900 | 18% |
| 93419757 | Eicher Tractor Front Axle Support                   | 15655 | 87089900 | 18% |
| 93419769 | Eicher Tractor Bonnet Mtg Bkt Lt                    | 432   | 87089900 | 18% |
| 93419770 | Eicher Tractor Bonnet Mounting Bkt Rt               | 432   | 87089900 | 18% |
| 93419812 | Eicher Tractor Spacer                               | 6508  | 73182100 | 18% |
| 93419824 | Eicher Tractor Front Wheel Hub                      | 3003  | 87087000 | 18% |
| 93419850 | Eicher Tractor Sleeve                               | 775   | 87089900 | 18% |
| 93419861 | Eicher Tractor Shim                                 | 17    | 73182100 | 18% |
| 93419990 | Eicher Tractor Wheel Cap (Hydromatic)               | 32    | 87087000 | 18% |
| 93421326 | Eicher Tractor Lower Link Assly Lt.                 | 2894  | 87089900 | 18% |
| 93421340 | Eicher Tractor Lower Link Assly Rt.                 | 2769  | 87089900 | 18% |
| 93421363 | Eicher Tractor Battery Cover                        | 1612  | 85079090 | 28% |
| 93421375 | Eicher Tractor Battery Tray Assy                    | 2576  | 85079090 | 28% |
| 93421405 | Eicher Tractor Brake Cover                          | 507   | 87083000 | 18% |
| 93421417 | Eicher Tractor Clamping Bolt                        | 36    | 73181500 | 18% |
| 93421424 | Eicher Tractor Supporting Strip                     | 55    | 87084000 | 18% |
| 93421430 | Eicher Tractor Spacer                               | 205   | 73182100 | 18% |
| 93421442 | Eicher Tractor Special Bolt                         | 56    | 73181500 | 18% |
| 93421459 | Eicher Tractor Cross Bar Assy                       | 1075  | 87089900 | 18% |
| 93421460 | Eicher Tractor Locking Pin Assy.                    | 698   | 73182100 | 18% |
| 93421472 | Eicher Tractor Hex Bolt M20X2.5X110, B10.9, Zp(Whi  | 215   | 73181500 | 18% |
| 93421582 | Eicher Tractor Front Axle Support                   | 10830 | 87089900 | 18% |
| 93421600 | Eicher Tractor Gasket (Fwh- Inspection Cover)       | 28    | 68129090 | 18% |
| 93421703 | Eicher Tractor Bumper Assembly                      | 12747 | 87081010 | 18% |
| 93421788 | Eicher Tractor Brake Pedal Assy. Rt                 | 1064  | 87083000 | 18% |
| 93421790 | Eicher Tractor Brake Linkage Assy. Left             | 518   | 87083000 | 18% |
| 93421806 | Eicher Tractor Brake Linkage Assy. Right            | 518   | 87083000 | 18% |
| 93421843 | Eicher Tractor Foot Board Rt                        | 799   | 87089900 | 18% |
| 93421855 | Eicher Tractor Guard Rubber But                     | 44    | 40169320 | 18% |
| 93421879 | Eicher Tractor Brake Pedal Assy Lt                  | 1414  | 87083000 | 18% |
| 93422148 | Eicher Tractor Steering Gear Assy-Rane              | 11934 | 87089400 | 18% |
| 93422161 | Eicher Tractor Steering Arm-Rane                    | 1927  | 87089400 | 18% |
| 93422276 | Eicher Tractor Ctr Top Cover                        | 4424  | 87084000 | 18% |
| 93422288 | Eicher Tractor Seat Mtg. Bracket                    | 2331  | 87089900 | 18% |
| 93422410 | Eicher Tractor Front Axle Assly                     | 10531 | 87085000 | 18% |
| 93422458 | Eicher Tractor Lower Link Assly Lt.                 | 3186  | 87089900 | 18% |
| 93422525 | Eicher Tractor Front Axle Support                   | 15350 | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93422537 | Eicher Tractor Bush                                | 286   | 84833000 | 18% |
| 93422549 | Eicher Tractor Tension Tie Assembly(Hydromatic)    | 517   | 87083000 | 18% |
| 93422598 | Eicher Tractor Adaptor                             | 553   | 87089900 | 18% |
| 93422604 | Eicher Tractor Lifting Gear Mechanism              | 3978  | 87089900 | 18% |
| 93422616 | Eicher Tractor Fork & Guide Mechanism              | 2712  | 87089900 | 18% |
| 93422630 | Eicher Tractor Mounting Bracket(Pipes And Ws)      | 467   | 87089900 | 18% |
| 93422641 | Eicher Tractor Steering Cylinder (30*50*185.5)     | 13915 | 87089400 | 18% |
| 93422653 | Eicher Tractor Assy.Connecting Tie Rod             | 1854  | 87089400 | 18% |
| 93422677 | Eicher Tractor Alternator Cover                    | 347   | 87085000 | 18% |
| 93422719 | Eicher Tractor Fas Adopter                         | 5745  | 87085000 | 18% |
| 93422793 | Eicher Tractor Stub Axle Left                      | 2887  | 87085000 | 18% |
| 93422800 | Eicher Tractor Stub Axle Right                     | 2887  | 87085000 | 18% |
| 93422914 | Eicher Tractor Mudguard Sticker 548                | 51    | 39199090 | 18% |
| 93422938 | Eicher Tractor Model Plate - 548                   | 70    | 39199090 | 18% |
| 93423232 | Eicher Tractor Brake Pedal Right                   | 1117  | 87083000 | 18% |
| 93423244 | Eicher Tractor Brake Pedal Rt                      | 1013  | 87083000 | 18% |
| 93423256 | Eicher Tractor Bonnet Bumper                       | 5099  | 87081010 | 18% |
| 93423268 | Eicher Tractor Front Axle Assy                     | 9910  | 87085000 | 18% |
| 93423281 | Eicher Tractor Brake Linkage Assy. Left            | 353   | 87083000 | 18% |
| 93423293 | Eicher Tractor Plate Left                          | 120   | 87083000 | 18% |
| 93423300 | Eicher Tractor Fork Assy (Brake Linkage) Wdb       | 143   | 87084000 | 18% |
| 93423311 | Eicher Tractor Brake Linkage Assy. Right           | 362   | 87083000 | 18% |
| 93423323 | Eicher Tractor Plate Right                         | 110   | 87089900 | 18% |
| 93423335 | Eicher Tractor Foot Board Rt                       | 1066  | 87089900 | 18% |
| 93423347 | Eicher Tractor Brake Pedal Assy Right              | 957   | 87083000 | 18% |
| 93423359 | Eicher Tractor Foot Board Lt                       | 1326  | 87089900 | 18% |
| 93423360 | Eicher Tractor Guard (Rubber Boot)                 | 82    | 40169320 | 18% |
| 93423372 | Eicher Tractor Brake Linkage Assy Left             | 522   | 87083000 | 18% |
| 93423384 | Eicher Tractor Brake Linkage Assy Left             | 530   | 87083000 | 18% |
| 93423396 | Eicher Tractor Plate Right                         | 212   | 87083000 | 18% |
| 93423402 | Eicher Tractor Plate Left                          | 212   | 87083000 | 18% |
| 93423426 | Eicher Tractor Link Upper                          | 137   | 87089900 | 18% |
| 93423438 | Eicher Tractor Pedal Shaft                         | 1413  | 87084000 | 18% |
| 93423463 | Eicher Tractor Assy. Coupling Shaft & Fork         | 1363  | 87084000 | 18% |
| 93423487 | Eicher Tractor Water Separator                     | 1008  | 84212300 | 18% |
| 93423499 | Eicher Tractor Rear Rim W11 Top Coat Off Wht Knp12 | 11952 | 87087000 | 18% |
| 93423505 | Eicher Tractor Rear Rim W11 Top Coat Silver Knp 12 | 12141 | 87087000 | 18% |
| 93423517 | Eicher Tractor Front Rim-4.5E X 16 Top Coat Silver | 3540  | 87087000 | 18% |
| 93423992 | Eicher Tractor Breather O-Ring 13.3X2.2 N90        | 65    | 87084000 | 18% |
| 93424005 | Eicher Tractor Top Cover O-Ring113.89X3.53 N70     | 358   | 40169990 | 18% |
| 93424029 | Eicher Tractor Reservoir Element (Filter)          | 238   | 84219900 | 18% |
| 93424066 | Eicher Tractor Fuel Shut Off Lever                 | 67    | 87089900 | 18% |
| 93424078 | Eicher Tractor Al. Radiator Assy                   | 7586  | 87087000 | 18% |
| 93424108 | Eicher Tractor Eicher 548 Sticker                  | 217   | 39199090 | 18% |
| 93424133 | Eicher Tractor Fuel Tank Strip Top Left            | 7     | 39199090 | 18% |
| 93424145 | Eicher Tractor Fuel Tank Strip Top Right           | 7     | 39199090 | 18% |
| 93424157 | Eicher Tractor Fuel Tank Strip Bottom Left         | 6     | 39199090 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93424169 | Eicher Tractor Fuel Tank Strip Bottom Right     | 6     | 39199090 | 18% |
| 93424170 | Eicher Tractor Flywheel Hsg                     | 23836 | 87084000 | 18% |
| 93424250 | Eicher Tractor Trunion Block                    | 79    | 87083000 | 18% |
| 93424315 | Eicher Tractor Sticker Dc                       | 7     | 39199090 | 18% |
| 93424339 | Eicher Tractor D D Seat (Adjustable)            | 9954  | 94012000 | 18% |
| 93424340 | Eicher Tractor Steering Wheel                   | 1440  | 87089400 | 18% |
| 93424390 | Eicher Tractor Mounting Angle                   | 2859  | 87089900 | 18% |
| 93424406 | Eicher Tractor Support Bracket Lt               | 378   | 87089900 | 18% |
| 93424418 | Eicher Tractor Support Bracket Rt               | 378   | 87089900 | 18% |
| 93424443 | Eicher Tractor Pin (Coupling Mouth)             | 149   | 73182100 | 18% |
| 93424467 | Eicher Tractor Lock Washer                      | 11    | 73182100 | 18% |
| 93424492 | Eicher Tractor Stg. Reservoir Assy.             | 3283  | 87089400 | 18% |
| 93424558 | Eicher Tractor Fwh Linkage 368/485/Sw           | 864   | 87083000 | 18% |
| 93424560 | Eicher Tractor Teflon Coated Mica Fiber Sheet   | 681   | 87089900 | 18% |
| 93424571 | Eicher Tractor Main Mtg. Bracket - Wc           | 1109  | 87089900 | 18% |
| 93424583 | Eicher Tractor Tank Cover Support Left          | 159   | 87089900 | 18% |
| 93424595 | Eicher Tractor Tank Cover Support Right         | 159   | 87089900 | 18% |
| 93424637 | Eicher Tractor Bonnet Graphics Left (G&O)       | 336   | 39199090 | 18% |
| 93424649 | Eicher Tractor Bonnet Graphics Right (G&O)      | 256   | 39199090 | 18% |
| 93424650 | Eicher Tractor Fuel Tank Graphics Left (G&O)    | 54    | 39199090 | 18% |
| 93424662 | Eicher Tractor Fuel Tank Graphics Right (G&O)   | 69    | 39199090 | 18% |
| 93424674 | Eicher Tractor Fuel Tank Strip Top Left (G&O)   | 18    | 39199090 | 18% |
| 93424686 | Eicher Tractor Fuel Tank Strip Top Right (G&O)  | 18    | 39199090 | 18% |
| 93424698 | Eicher Tractor Fuel Tank Strip Bottom Lt (G&O)  | 14    | 39199090 | 18% |
| 93424704 | Eicher Tractor Fuel Tank Strip Bottom Rt (G&O)  | 14    | 39199090 | 18% |
| 93424716 | Eicher Tractor A-Line Sticker                   | 56    | 83100090 | 18% |
| 93424728 | Eicher Tractor R-Line Sticker                   | 56    | 39199090 | 18% |
| 93424730 | Eicher Tractor Bonnet Graphic Left (R & Y)      | 256   | 39199090 | 18% |
| 93424741 | Eicher Tractor Bonnet Graphic Right (R & Y)     | 256   | 39199090 | 18% |
| 93424753 | Eicher Tractor Fuel Tank Graphics Left (R & Y)  | 69    | 39199090 | 18% |
| 93424765 | Eicher Tractor Fuel Tank Graphics Right (R & Y) | 54    | 39199090 | 18% |
| 93424777 | Eicher Tractor Fuel Tank Strip Top Left (R & Y) | 23    | 39199090 | 18% |
| 93424789 | Eicher Tractor Fuel Tank Strip Top Rt (R&Y)     | 23    | 39199090 | 18% |
| 93424790 | Eicher Tractor Fuel Tank Strip Bottom Lt (R&Y)  | 18    | 39199090 | 18% |
| 93424807 | Eicher Tractor Fuel Tank Strip Bottom Rt (R&Y)  | 18    | 39199090 | 18% |
| 93424819 | Eicher Tractor Super Plus Sticker               | 56    | 39199090 | 18% |
| 93424820 | Eicher Tractor Pad For Fuel Tank Small          | 17    | 87089900 | 18% |
| 93424832 | Eicher Tractor Pad For Fuel Tank Big            | 37    | 87089900 | 18% |
| 93424844 | Eicher Tractor Fuel Tank Bracket                | 2141  | 87089900 | 18% |
| 93424900 | Eicher Tractor Bush Steel                       | 735   | 87089900 | 18% |
| 93424911 | Eicher Tractor Rubber Bellow                    | 47    | 40169320 | 18% |
| 93424923 | Eicher Tractor Rubber Bellow                    | 60    | 40169320 | 18% |
| 93424935 | Eicher Tractor Felt Ring                        | 15    | 87084000 | 18% |
| 93424947 | Eicher Tractor Centre Pin                       | 777   | 87085000 | 18% |
| 93424959 | Eicher Tractor Front Axle Assly                 | 13690 | 87085000 | 18% |
| 93424972 | Eicher Tractor Label Plate                      | 37    | 39199090 | 18% |
| 93425010 | Eicher Tractor Lock Bracket Assy Lt             | 367   | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93425022 | Eicher Tractor Lock Bracket Assy Rt       | 367   | 87089900 | 18% |
| 93425046 | Eicher Tractor Fuel Tank Mtg. Bracket     | 1975  | 87089900 | 18% |
| 93425058 | Eicher Tractor Bottom Rubber Pad (Big)    | 375   | 40169320 | 18% |
| 93425060 | Eicher Tractor Fuel Tank Strap Assy       | 218   | 87089900 | 18% |
| 93425083 | Eicher Tractor Fuel Tank Assy             | 8558  | 87089900 | 18% |
| 93425101 | Eicher Tractor Front Pad                  | 36    | 40169990 | 18% |
| 93425199 | Eicher Tractor Fender Mtg Bkt Lt          | 816   | 87089900 | 18% |
| 93425241 | Eicher Tractor Front Axle Support         | 13085 | 87089900 | 18% |
| 93425253 | Eicher Tractor Front Axle Support         | 15679 | 87089900 | 18% |
| 93425265 | Eicher Tractor Front Axle Assy            | 15513 | 87085000 | 18% |
| 93425289 | Eicher Tractor Front Axle Support         | 16169 | 87089900 | 18% |
| 93425290 | Eicher Tractor Front Axle Assy            | 16759 | 87085000 | 18% |
| 93425307 | Eicher Tractor Front Axle Assy            | 10869 | 87085000 | 18% |
| 93425319 | Eicher Tractor Front Axle Assy            | 17518 | 87085000 | 18% |
| 93425381 | Eicher Tractor Shim 0.5Mm                 | 12    | 73182100 | 18% |
| 93425411 | Eicher Tractor Lift Arm - Hydromatic      | 2787  | 87089900 | 18% |
| 93425423 | Eicher Tractor Top Link Hook              | 124   | 87089900 | 18% |
| 93425435 | Eicher Tractor Battery Tray Assly         | 3595  | 85079090 | 28% |
| 93425447 | Eicher Tractor Bottom Pad                 | 142   | 40169990 | 18% |
| 93425496 | Eicher Tractor Brake Pedal Assy Lt        | 1178  | 87083000 | 18% |
| 93425540 | Eicher Tractor Radiator Cap               | 323   | 87087000 | 18% |
| 93425551 | Eicher Tractor Radiator Cowl              | 896   | 87087000 | 18% |
| 93425563 | Eicher Tractor Thresh Guard               | 686   | 87089100 | 18% |
| 93425575 | Eicher Tractor Aux Tank                   | 538   | 87089900 | 18% |
| 93425617 | Eicher Tractor Radiator Cap               | 323   | 87087000 | 18% |
| 93425629 | Eicher Tractor Radiator Cowl              | 587   | 87087000 | 18% |
| 93425630 | Eicher Tractor Thresh Guard               | 717   | 87089100 | 18% |
| 93425666 | Eicher Tractor I Line Sticker             | 55    | 39199090 | 18% |
| 93425678 | Eicher Tractor Belt Guard                 | 175   | 87089900 | 18% |
| 93425733 | Eicher Tractor Feature Sticker            | 33    | 39199090 | 18% |
| 93425745 | Eicher Tractor Pin For Lifting Gear       | 113   | 87089900 | 18% |
| 93425757 | Eicher Tractor Front Axle Support         | 16521 | 87089900 | 18% |
| 93425769 | Eicher Tractor Front Axle Support Non Hyd | 17552 | 87089900 | 18% |
| 93425770 | Eicher Tractor Battery Mtg Bracket        | 617   | 85079090 | 28% |
| 93425850 | Eicher Tractor Eicher 333                 | 223   | 39199090 | 18% |
| 93425885 | Eicher Tractor Mudguard Silver Sticker    | 46    | 39199090 | 18% |
| 93425903 | Eicher Tractor Tie Rod                    | 2496  | 87089400 | 18% |
| 93425915 | Eicher Tractor Steering Rod               | 2169  | 87089400 | 18% |
| 93426014 | Eicher Tractor Tool Kit North(White)      | 1349  | 82060090 | 18% |
| 93426026 | Eicher Tractor Tool Kit South             | 1415  | 82060090 | 18% |
| 93426038 | Eicher Tractor Bumper Mtg. Bkt.           | 2943  | 87081010 | 18% |
| 93426040 | Eicher Tractor Bumper Assy                | 14116 | 87081010 | 18% |
| 93426117 | Eicher Tractor Plastic Cover – Red        | 833   | 39021000 | 18% |
| 93426129 | Eicher Tractor Bonnet Graphics Lt- 485    | 383   | 39199090 | 18% |
| 93426130 | Eicher Tractor Bonnet Graphics Rt- 485    | 451   | 39199090 | 18% |
| 93426142 | Eicher Tractor Bonnet Graphics Lt- Eicher | 446   | 39199090 | 18% |
| 93426154 | Eicher Tractor Bonnet Graphics Rt- Eicher | 388   | 39199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93426180 | Eicher Tractor Fuel Tank Cover Graphics Lt         | 167   | 39199090 | 18% |
| 93426191 | Eicher Tractor Fuel Tank Cover Graphics Rt         | 167   | 39199090 | 18% |
| 93426208 | Eicher Tractor Blower Graphics Red                 | 73    | 39199090 | 18% |
| 93426210 | Eicher Tractor Battery Cover                       | 1509  | 85079090 | 28% |
| 93426233 | Eicher Tractor Head Light Panel Assy               | 1559  | 85122010 | 18% |
| 93426245 | Eicher Tractor Head Light Panel-Bezel              | 1051  | 85122090 | 18% |
| 93426257 | Eicher Tractor Snap Fit                            | 18    | 39269099 | 18% |
| 93426294 | Eicher Tractor Brake Linkage Assy Lh &Rh           | 348   | 87083000 | 18% |
| 93426300 | Eicher Tractor Plate                               | 99    | 39199090 | 18% |
| 93426312 | Eicher Tractor Foot Board Left                     | 1411  | 87089900 | 18% |
| 93426324 | Eicher Tractor Foot Board Right                    | 1175  | 87089900 | 18% |
| 93426336 | Eicher Tractor Blower Graphics Silver              | 73    | 39199090 | 18% |
| 93426348 | Eicher Tractor Plastic Cover – Silver              | 919   | 39021000 | 18% |
| 93426350 | Eicher Tractor Plastic Cover Blue                  | 821   | 39021000 | 18% |
| 93426397 | Eicher Tractor Hand Accelerator Linkage Assy       | 755   | 87089900 | 18% |
| 93426403 | Eicher Tractor Breather Cum Dipstick With O-Ring   | 490   | 87084000 | 18% |
| 93426415 | Eicher Tractor Reservoir Element(Filter)           | 1104  | 84219900 | 18% |
| 93426555 | Eicher Tractor Front Wheel Hub (7.5X16 Tyre)       | 1464  | 87087000 | 18% |
| 93426567 | Eicher Tractor Eicher 485 Sticker                  | 265   | 39199090 | 18% |
| 93426816 | Eicher Tractor Accelerator Linkage Sub Assy-5660   | 1157  | 87083000 | 18% |
| 93426865 | Eicher Tractor Acce Linkage Sub Assy-380 Non Hyd S | 1341  | 87089900 | 18% |
| 93426877 | Eicher Tractor Acce Linkage Sub Assy-485 Non Hyd S | 1397  | 87083000 | 18% |
| 93426890 | Eicher Tractor End (Lever Side)                    | 1038  | 87089400 | 18% |
| 93426907 | Eicher Tractor End (Cylinder Side)                 | 1233  | 87089400 | 18% |
| 93426981 | Eicher Tractor Lifting Gear Mechanism              | 3772  | 87089900 | 18% |
| 93426993 | Eicher Tractor Fork & Guide Mechanism              | 2761  | 87089900 | 18% |
| 93427055 | Eicher Tractor Accelerator Linkage Sub Assy-548 Hy | 1353  | 87083000 | 18% |
| 93427158 | Eicher Tractor Exhaust Extension                   | 669   | 87089200 | 18% |
| 93427171 | Eicher Tractor Steering Gear Support               | 1905  | 87089400 | 18% |
| 93427227 | Eicher Tractor Aux. Valve Cover Mtg Bkt            | 45    | 87089900 | 18% |
| 93427274 | Eicher Tractor 480 Sticker (Silver)                | 46    | 39199090 | 18% |
| 93427298 | Eicher Tractor Mudguard Sticker - Front Lt         | 114   | 39199090 | 18% |
| 93427304 | Eicher Tractor Bonnet Graphics Lt – 480            | 383   | 39199090 | 18% |
| 93427316 | Eicher Tractor Bonnet Graphics Rt – 480            | 362   | 39199090 | 18% |
| 93427365 | Eicher Tractor Chain Assy                          | 1059  | 87089900 | 18% |
| 93427390 | Eicher Tractor Mudguard Sticker - Front Rt         | 114   | 39199090 | 18% |
| 93427407 | Eicher Tractor Wow Logo Sticker                    | 22    | 39199090 | 18% |
| 93427419 | Eicher Tractor Dual Clutch Sticker                 | 24    | 39199090 | 18% |
| 93427420 | Eicher Tractor Sticker Power Steering Lt           | 38    | 39199090 | 18% |
| 93427432 | Eicher Tractor Sticker Power Steering Rt           | 38    | 39199090 | 18% |
| 93427444 | Eicher Tractor Sticker Hydromatic Nt               | 25    | 39199090 | 18% |
| 93427470 | Eicher Tractor Battery Mtg. Bracket (14.9)         | 741   | 85079090 | 28% |
| 93427481 | Eicher Tractor Battery Mtg Bracket (16.9)          | 774   | 85079090 | 28% |
| 93427547 | Eicher Tractor Rear Rim W11 Top Coat Silver Knp 12 | 12692 | 87087000 | 18% |
| 93427560 | Eicher Tractor Rear Rim W12 Top Coat Off Wht Knp13 | 13217 | 87087000 | 18% |
| 93427572 | Eicher Tractor Rear Rim W12 Top Coat Silver Knp 13 | 12019 | 87087000 | 18% |
| 93427596 | Eicher Tractor Rear Rim W12 Top Coat Off Wht Knp14 | 13217 | 87087000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93427602 | Eicher Tractor Rear Rim W12 Top Coat Silver Knp 14 | 13396 | 87087000 | 18% |
| 93427614 | Eicher Tractor Front Wheel Hub (7.6*16 Tyre)       | 2319  | 87087000 | 18% |
| 93427626 | Eicher Tractor Mudguard Silver Sticker -380        | 46    | 39199090 | 18% |
| 93427640 | Eicher Tractor Front Axle Support Assy             | 18372 | 87089900 | 18% |
| 93427754 | Eicher Tractor Hing Bkt (Dd Seat)                  | 421   | 87089900 | 18% |
| 93427766 | Eicher Tractor Clamping Latch                      | 94    | 87089900 | 18% |
| 93427791 | Eicher Tractor Front Axle Support(380,480Ps)       | 21205 | 87089900 | 18% |
| 93427808 | Eicher Tractor Front Axle Assy.(380,480Ps)         | 14606 | 87085000 | 18% |
| 93427810 | Eicher Tractor Adaptor Plate                       | 289   | 87085000 | 18% |
| 93427857 | Eicher Tractor Plate 485 Hd                        | 118   | 83100090 | 18% |
| 93427912 | Eicher Tractor Steering Lever Single               | 981   | 87089400 | 18% |
| 93427924 | Eicher Tractor Steering Lever Double               | 1876  | 87089400 | 18% |
| 93427973 | Eicher Tractor D D Seat Mtg Bkt                    | 1124  | 87089900 | 18% |
| 93428000 | Eicher Tractor Tail Light Assy Left - Amar Make    | 549   | 85122010 | 18% |
| 93428011 | Eicher Tractor Tail Light Assy Right - Amar Make   | 549   | 85122010 | 18% |
| 93428023 | Eicher Tractor Front Light Assy Left - Amar Make   | 392   | 85122010 | 18% |
| 93428035 | Eicher Tractor Front Light Assy Right - Amar Make  | 392   | 85122010 | 18% |
| 93428047 | Eicher Tractor Fender Support Bkt                  | 410   | 87089900 | 18% |
| 93428060 | Eicher Tractor Bottom Pad-Battery Box              | 55    | 40169990 | 18% |
| 93428084 | Eicher Tractor Bonnet Beading-188                  | 117   | 40169990 | 18% |
| 93428096 | Eicher Tractor Shim -Fas 0.5Mm                     | 6     | 87089900 | 18% |
| 93428102 | Eicher Tractor Shim -Fas 1Mm                       | 8     | 87089900 | 18% |
| 93428114 | Eicher Tractor Rubber Pad-Tail Light               | 39    | 40169990 | 18% |
| 93428126 | Eicher Tractor Rubber Pad-Front Light              | 42    | 40169990 | 18% |
| 93428140 | Eicher Tractor Front Axle Assy (551 Ps)            | 23064 | 87085000 | 18% |
| 93428151 | Eicher Tractor Front Axle Support (551 Ps)         | 21753 | 87089900 | 18% |
| 93428163 | Eicher Tractor Air Cleaner Mtg. Bracket            | 2887  | 84099941 | 28% |
| 93428187 | Eicher Tractor Fender Mtg Bkt Rt                   | 953   | 87089900 | 18% |
| 93428229 | Eicher Tractor Stub Axle                           | 3765  | 87085000 | 18% |
| 93428266 | Eicher Tractor Foam Pad (Boonet & Fuel Tank Cover) | 32    | 39219099 | 18% |
| 93428278 | Eicher Tractor Cushion Pad                         | 15    | 40169320 | 18% |
| 93428280 | Eicher Tractor Hinge Bkt Rt                        | 275   | 87089900 | 18% |
| 93428291 | Eicher Tractor Hinge Bkt Lt                        | 275   | 87089900 | 18% |
| 93428321 | Eicher Tractor Hinge Frame                         | 1509  | 87089900 | 18% |
| 93428369 | Eicher Tractor Drop Arm                            | 3411  | 87089400 | 18% |
| 93428370 | Eicher Tractor Steering Gear Assy                  | 12758 | 87089400 | 18% |
| 93428485 | Eicher Tractor Plastic Cap                         | 8     | 39021000 | 18% |
| 93428503 | Eicher Tractor Steering Wheel                      | 945   | 87089400 | 18% |
| 93428527 | Eicher Tractor Thrust Washer                       | 75    | 73182100 | 18% |
| 93428539 | Eicher Tractor Aux Valve Cover (4Wd)               | 1359  | 87089900 | 18% |
| 93428606 | Eicher Tractor Mounting Pin (D D Seat)             | 85    | 73182100 | 18% |
| 93428618 | Eicher Tractor Bonnet Latch Bkt                    | 59    | 87089900 | 18% |
| 93428620 | Eicher Tractor Radiator Mtg. Bkt.                  | 4535  | 87087000 | 18% |
| 93428655 | Eicher Tractor Shim 0.2Mm                          | 6     | 87089900 | 18% |
| 93428667 | Eicher Tractor Shim 0.3Mm                          | 8     | 87089900 | 18% |
| 93428692 | Eicher Tractor Front Axle Support Hyd              | 16521 | 87085000 | 18% |
| 93428709 | Eicher Tractor Front Axle Support Non Hyd          | 18614 | 87089900 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93428760 | Eicher Tractor Fork Assy                           | 129   | 87084000 | 18% |
| 93428771 | Eicher Tractor Driver Seat                         | 4505  | 94012000 | 18% |
| 93428783 | Eicher Tractor Stub Axle-North                     | 3877  | 87085000 | 18% |
| 93428795 | Eicher Tractor Stub Axle-South                     | 4286  | 87085000 | 18% |
| 93428825 | Eicher Tractor Steering Gear Support - Rane        | 1874  | 87089400 | 18% |
| 93428849 | Eicher Tractor Stud M12X47,A10.9,Bp                | 41    | 73182100 | 18% |
| 93428862 | Eicher Tractor Cover Assy (Engine Side)            | 2026  | 87084000 | 18% |
| 93428886 | Eicher Tractor Cover Assy (Bumper Side)            | 2205  | 87084000 | 18% |
| 93428898 | Eicher Tractor Shim 0.2Mm                          | 5     | 87089900 | 18% |
| 93428904 | Eicher Tractor Bonnet Graphics Left - 380          | 334   | 39199090 | 18% |
| 93428916 | Eicher Tractor Bonnet Graphics Right - 380         | 334   | 39199090 | 18% |
| 93428928 | Eicher Tractor Super Plus Sticker                  | 65    | 39199090 | 18% |
| 93428941 | Eicher Tractor Hexagon Head Bolt M12X1.5X45,B10.9, | 31    | 73181500 | 18% |
| 93428953 | Eicher Tractor Hexagon Nut M12X1.5,B10,Zp, (White) | 9     | 73181500 | 18% |
| 93429003 | Eicher Tractor Front Axle Assy (18 Hp)             | 7044  | 87085000 | 18% |
| 93429015 | Eicher Tractor Front End Assy.                     | 20603 | 87085000 | 18% |
| 93429039 | Eicher Tractor Tie Rod Assy                        | 1455  | 87089400 | 18% |
| 93429040 | Eicher Tractor Drag Link                           | 1506  | 87089400 | 18% |
| 93429052 | Eicher Tractor Front Axle Support                  | 10286 | 87089900 | 18% |
| 93429064 | Eicher Tractor Center Pin                          | 681   | 73182400 | 18% |
| 93429088 | Eicher Tractor Cover (Wiring Harness)              | 133   | 87089900 | 18% |
| 93429090 | Eicher Tractor Chain Assy                          | 1363  | 87089900 | 18% |
| 93429118 | Eicher Tractor Lifting Gear Mechanism              | 3641  | 87089900 | 18% |
| 93429120 | Eicher Tractor Fork And Guide Mechanism            | 2829  | 87089900 | 18% |
| 93429192 | Eicher Tractor Adaptor                             | 942   | 87089900 | 18% |
| 93429210 | Eicher Tractor Rear Wheel W11 Top Coat Wht Knp 12. | 19915 | 87087000 | 18% |
| 93429222 | Eicher Tractor Rear Wheel W11 Top Coat Sil. Knp 12 | 18193 | 87087000 | 18% |
| 93429246 | Eicher Tractor Rear Wheel W12 Top Coat Wht Knp 13. | 11718 | 87087000 | 18% |
| 93429258 | Eicher Tractor Rear Wheel W-12 Top Coat Sil.Knp 13 | 15014 | 87087000 | 18% |
| 93429271 | Eicher Tractor Rear Wheel W12 Top Coat Wht Knp 14. | 18802 | 87087000 | 18% |
| 93429283 | Eicher Tractor Rear Wheel W12 Top Coat Sil. Knp 14 | 19119 | 85122010 | 18% |
| 93429374 | Eicher Tractor Lower Link Assly Lt.                | 5045  | 87089900 | 18% |
| 93429386 | Eicher Tractor Lower Link Assly Rt.                | 5045  | 87089900 | 18% |
| 93429416 | Eicher Tractor Stub Axle Lh. Ps (South)            | 3973  | 87085000 | 18% |
| 93429428 | Eicher Tractor Stub Axle Rh. Ps (South)            | 4169  | 87085000 | 18% |
| 93429430 | Eicher Tractor Stub Axle Lh. Ps (North)            | 3691  | 87085000 | 18% |
| 93429453 | Eicher Tractor Stub Axle Rh. Ps (North)            | 3896  | 87085000 | 18% |
| 93429520 | Eicher Tractor M16 Special Bolt                    | 291   | 73181500 | 18% |
| 93429570 | Eicher Tractor Stabilizer Bracket Lt – (Rops)      | 3521  | 87089900 | 18% |
| 93429581 | Eicher Tractor Stabilizer Bracket Rt – (Rops)      | 3521  | 87089900 | 18% |
| 93429805 | Eicher Tractor Tube Assy.                          | 368   | 84099941 | 28% |
| 93429829 | Eicher Tractor Air Cleaner Assy.                   | 5653  | 84219900 | 18% |
| 93429842 | Eicher Tractor Front Bumper-188 (4Wd)              | 7362  | 87081010 | 18% |
| 93429994 | Eicher Tractor Rops Top Assy                       | 18064 | 87089900 | 18% |
| 93430029 | Eicher Tractor 53De0006 = Liner Cy. Block          | 907   | 84099941 | 28% |
| 93430030 | Eicher Tractor 99De1260 = Housing Tacho Drive Assl | 128   | 84099941 | 28% |
| 93430108 | Eicher Tractor 99S30779 = Piston Rings Assly       | 857   | 84099112 | 28% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93430376 | Eicher Tractor 44S30166 = Timing Case (Cast Iron)  | 5205  | 84099941 | 28% |
| 93430388 | Eicher Tractor 9S31445 = Cylinder Head Assy. (Majo | 30278 | 84099941 | 28% |
| 93430431 | Eicher Tractor Seal Kit Power Steering 5660        | 9480  | 87089400 | 18% |
| 93430443 | Eicher Tractor Worm Column Assy                    | 5012  | 87089400 | 18% |
| 93430558 | Eicher Tractor 44S30221 = Timing Csas 47Hp (Ps)    | 3419  | 84099941 | 28% |
| 93430560 | Eicher Tractor De006069 = Delphi Injector Assy     | 3265  | 84099120 | 28% |
| 93430601 | Eicher Tractor 67De0143 = Pulley Crankshaft        | 1981  | 84099941 | 28% |
| 93430613 | Eicher Tractor 10S30645 = Bracket Fip Support For  | 122   | 84099941 | 28% |
| 93430625 | Eicher Tractor De005959 = Delphi Fuel Filter With  | 2605  | 84219900 | 18% |
| 93430704 | Eicher Tractor De005507 = Rotary Fuel Filter (Delp | 377   | 84219900 | 18% |
| 93430765 | Eicher Tractor Thrash Guard                        | 932   | 87089100 | 18% |
| 93430777 | Eicher Tractor Radiator Cowl                       | 1069  | 87087000 | 18% |
| 93430922 | Eicher Tractor Pressure Cap                        | 409   | 84099941 | 28% |
| 93431484 | Eicher Tractor Locking Cup                         | 238   | 87089900 | 18% |
| 93440011 | Eicher Tractor Chain Assly 242/312                 | 703   | 87089900 | 18% |
| 93440140 | Eicher Tractor 10De0516 = Bracket (P Type) Injecto | 203   | 84099941 | 28% |
| 93440205 | Eicher Tractor 99S31073 = Fuel Pipe Injection Assy | 289   | 84099941 | 28% |
| 93440217 | Eicher Tractor 99S31074 = Fuel Pipe Injection Assy | 289   | 84099941 | 28% |
| 93440229 | Eicher Tractor 99S31075 = Fuel Pipe Injection Assy | 289   | 84099941 | 28% |
| 93440230 | Eicher Tractor 67Sg03002 = Pulley Crank Shaft(18") | 2100  | 84099941 | 28% |
| 93440242 | Eicher Tractor 67De0111 = Pulley Crank Shaft (17") | 1933  | 84099941 | 28% |
| 93440266 | Eicher Tractor 41S30047 = Gear F.I.P For Tiii Seri | 1171  | 84099941 | 28% |
| 93440291 | Eicher Tractor Brake Link Assly South / 5660       | 739   | 87083000 | 18% |
| 93440310 | Eicher Tractor 99S31445 = Cylinder Head Major-S-T. | 14998 | 84099941 | 28% |
| 93440321 | Eicher Tractor 99De1411 = Piston 63De0Tch          | 2137  | 84099112 | 28% |
| 93440436 | Eicher Tractor Seal Kit Power Steering 485         | 4849  | 87089400 | 18% |
| 93440564 | Eicher Tractor Seal Kit Power Steering 557         | 1541  | 87089400 | 18% |
| 93440576 | Eicher Tractor Seal Kit                            | 3567  | 87089900 | 18% |
| 93440588 | Eicher Tractor Seal Kit                            | 4636  | 87089900 | 18% |
| 93440620 | Eicher Tractor Oil Seal                            | 113   | 40169330 | 18% |
| 93440679 | Eicher Tractor Inner Column Sub Assyembly          | 5794  | 87084000 | 18% |
| 93440680 | Eicher Tractor Bearing,Top                         | 654   | 84821011 | 18% |
| 93440692 | Eicher Tractor Bearing, Bottom                     | 496   | 84821011 | 18% |
| 93440709 | Eicher Tractor Lock Nut                            | 52    | 73181500 | 18% |
| 93440710 | Eicher Tractor Outer Column Sub Assyembly          | 1091  | 87084000 | 18% |
| 93440722 | Eicher Tractor Rocker Shaft Sub Assyembly          | 3206  | 87089900 | 18% |
| 93440734 | Eicher Tractor Rocker Shaft Machined               | 2867  | 87089900 | 18% |
| 93440813 | Eicher Tractor Rubber Bush                         | 180   | 40169390 | 18% |
| 93440850 | Eicher Tractor Bush                                | 90    | 87085000 | 18% |
| 93440862 | Eicher Tractor Lock Nut                            | 73    | 73181500 | 18% |
| 93440886 | Eicher Tractor Steering Housing Sub Assembly (Hous | 7804  | 87089400 | 18% |
| 93440898 | Eicher Tractor Steering Housing Bush               | 183   | 87089400 | 18% |
| 93440904 | Eicher Tractor Steering Housing Oil Seal           | 120   | 87089400 | 18% |
| 93440916 | Eicher Tractor Inner Column Mainnutsub Assembly    | 7108  | 87089400 | 18% |
| 93440928 | Eicher Tractor Wood Ruff Key                       | 51    | 73182990 | 18% |
| 93440930 | Eicher Tractor Bearing, Outer Race                 | 526   | 84821011 | 18% |
| 93440941 | Eicher Tractor Bearing, Nylon Cage                 | 44    | 84821011 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93440953 | Eicher Tractor Bearing, Inner Race Top             | 175   | 84219900 | 18% |
| 93440965 | Eicher Tractor Bearing, Inner Race Bottom          | 240   | 84219900 | 18% |
| 93440977 | Eicher Tractor Bearing, Steel Ball                 | 14    | 84219900 | 18% |
| 93440989 | Eicher Tractor Steering Box, Outer Column Sub Asse | 3835  | 87089400 | 18% |
| 93440990 | Eicher Tractor Outer Column Bush                   | 180   | 87089900 | 18% |
| 93441003 | Eicher Tractor Shims_10"                           | 9     | 87089900 | 18% |
| 93441015 | Eicher Tractor Shims_5"                            | 9     | 87089900 | 18% |
| 93441027 | Eicher Tractor Shims_3"                            | 8     | 87089900 | 18% |
| 93441039 | Eicher Tractor Shims_2"                            | 9     | 73182100 | 18% |
| 93441040 | Eicher Tractor Endplate & Cover Plate Bolts_M8X1.2 | 18    | 73181500 | 18% |
| 93441052 | Eicher Tractor Spring Washers_M8                   | 4     | 73182990 | 18% |
| 93441064 | Eicher Tractor Rocker Shaft                        | 5277  | 87089900 | 18% |
| 93441076 | Eicher Tractor Spherical Roller                    | 505   | 84824000 | 18% |
| 93441088 | Eicher Tractor Spring Seat                         | 35    | 73209090 | 18% |
| 93441090 | Eicher Tractor Spring                              | 37    | 73209090 | 18% |
| 93441106 | Eicher Tractor Locator                             | 54    | 87089900 | 18% |
| 93441118 | Eicher Tractor Cover Plate Sub Assembly            | 1168  | 87084000 | 18% |
| 93441120 | Eicher Tractor Cover Plate Bush                    | 310   | 87084000 | 18% |
| 93441131 | Eicher Tractor Locknut (Adjuster)                  | 28    | 73181500 | 18% |
| 93441143 | Eicher Tractor Adjuster Screw                      | 80    | 73181500 | 18% |
| 93441155 | Eicher Tractor Rocker Shaft_Spring Washer          | 13    | 73182990 | 18% |
| 93441167 | Eicher Tractor Rocker Shaft_Locknut                | 120   | 73181500 | 18% |
| 93441179 | Eicher Tractor Dowel Pin                           | 11    | 73181500 | 18% |
| 93441180 | Eicher Tractor Oil Plug                            | 30    | 73181500 | 18% |
| 93441192 | Eicher Tractor Locknut Wheelend                    | 34    | 73181500 | 18% |
| 93441209 | Eicher Tractor Hub Assy Lt                         | 11985 | 87089900 | 18% |
| 93441210 | Eicher Tractor Hub Assy Rt                         | 11985 | 87089900 | 18% |
| 93441222 | Eicher Tractor Hub Assy Lt-Flt                     | 11985 | 87089900 | 18% |
| 93441234 | Eicher Tractor Hub Assy Rt-Flt                     | 11985 | 87089900 | 18% |
| 93441246 | Eicher Tractor Hub Assy-Ms                         | 11985 | 87089900 | 18% |
| 93441283 | Eicher Tractor Inner Column Mainnut Sub Assembly   | 6945  | 87084000 | 18% |
| 93441313 | Eicher Tractor Outer Column Bush                   | 320   | 87089400 | 18% |
| 93441325 | Eicher Tractor Outer Column Sub Assembly           | 5311  | 87084000 | 18% |
| 93441386 | Eicher Tractor End Right                           | 845   | 87089400 | 18% |
| 93441398 | Eicher Tractor End Left                            | 845   | 87089400 | 18% |
| 93441404 | Eicher Tractor End Right                           | 845   | 87089400 | 18% |
| 93441465 | Eicher Tractor Housing Assembly                    | 8541  | 87084000 | 18% |
| 93441477 | Eicher Tractor Sector Shaft Assembly               | 3979  | 87084000 | 18% |
| 93441489 | Eicher Tractor Housing Cover Assembly              | 2620  | 87084000 | 18% |
| 93441490 | Eicher Tractor Piston Assembly                     | 26166 | 84099112 | 28% |
| 93441507 | Eicher Tractor Complete Sealing Kit                | 2171  | 87089400 | 18% |
| 93441519 | Eicher Tractor Small Component Set                 | 1017  | 73181500 | 18% |
| 93441520 | Eicher Tractor Psg Box                             | 34630 | 84099112 | 28% |
| 93441532 | Eicher Tractor Stg. Col Assly                      | 2681  | 87089400 | 18% |
| 93441842 | Eicher Tractor Rear Support                        | 10537 | 87089900 | 18% |
| 93441854 | Eicher Tractor Bushing                             | 3048  | 87089900 | 18% |
| 93441866 | Eicher Tractor Seal                                | 1785  | 84314930 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93441878 | Eicher Tractor O. Ring                 | 36    | 40169320 | 18% |
| 93441880 | Eicher Tractor Bushing                 | 2622  | 87089900 | 18% |
| 93441891 | Eicher Tractor Thrust Washer           | 1651  | 73182990 | 18% |
| 93441908 | Eicher Tractor O. Ring                 | 23    | 40169320 | 18% |
| 93441910 | Eicher Tractor Axle Housing Bush Kit   | 22699 | 87084000 | 18% |
| 93441921 | Eicher Tractor Centering Bush          | 51    | 87089900 | 18% |
| 93441933 | Eicher Tractor Bolt M12X75             | 361   | 73181500 | 18% |
| 93441945 | Eicher Tractor Pin D. 12X30            | 36    | 73182100 | 18% |
| 93441957 | Eicher Tractor Axle Housing            | 29844 | 85311010 | 18% |
| 93441969 | Eicher Tractor Bolt M12X45             | 143   | 73181500 | 18% |
| 93441970 | Eicher Tractor Bushing                 | 2200  | 87089900 | 18% |
| 93441982 | Eicher Tractor Front Support           | 10538 | 87089900 | 18% |
| 93441994 | Eicher Tractor Oil Dipstick            | 495   | 87084000 | 18% |
| 93442007 | Eicher Tractor O. Ring                 | 93    | 40169320 | 18% |
| 93442020 | Eicher Tractor Steering Cylinder       | 43112 | 87089400 | 18% |
| 93442032 | Eicher Tractor Screw M14X40            | 122   | 73181500 | 18% |
| 93442044 | Eicher Tractor Nut                     | 12    | 87089900 | 18% |
| 93442056 | Eicher Tractor Screw M12X75            | 138   | 73181500 | 18% |
| 93442068 | Eicher Tractor Steering Arm Assy       | 5227  | 87089400 | 18% |
| 93442070 | Eicher Tractor Bevel Gear Washer Kit   | 25345 | 87084000 | 18% |
| 93442081 | Eicher Tractor Washer                  | 72    | 73182990 | 18% |
| 93442093 | Eicher Tractor Collapsible Spacer      | 817   | 73182100 | 18% |
| 93442100 | Eicher Tractor Washer                  | 65    | 73182990 | 18% |
| 93442111 | Eicher Tractor Lockwasher              | 203   | 73181500 | 18% |
| 93442123 | Eicher Tractor Ring Nut                | 1021  | 73181500 | 18% |
| 93442135 | Eicher Tractor Shims Kit 2.40-3.30Mm   | 2078  | 73182100 | 18% |
| 93442147 | Eicher Tractor Bearing                 | 1334  | 84822011 | 18% |
| 93442159 | Eicher Tractor Bearing                 | 1145  | 84822011 | 18% |
| 93442160 | Eicher Tractor Bushing                 | 785   | 87089900 | 18% |
| 93442172 | Eicher Tractor Oil Seal Ring           | 3012  | 87084000 | 18% |
| 93442184 | Eicher Tractor Snap Ring               | 19    | 73182910 | 18% |
| 93442196 | Eicher Tractor Splined Sleeve          | 1853  | 73182100 | 18% |
| 93442202 | Eicher Tractor Spacer                  | 173   | 73182100 | 18% |
| 93442226 | Eicher Tractor Differential Wahser Kit | 12091 | 87084000 | 18% |
| 93442238 | Eicher Tractor Thrust Washer           | 229   | 73182990 | 18% |
| 93442240 | Eicher Tractor Perno Shaft 63413       | 1117  | 73182100 | 18% |
| 93442251 | Eicher Tractor Spina Pin               | 27    | 73182100 | 18% |
| 93442263 | Eicher Tractor Clutch Pack             | 3004  | 87089900 | 18% |
| 93442275 | Eicher Tractor Locking Plate           | 124   | 73181500 | 18% |
| 93442287 | Eicher Tractor Ring Nut                | 1371  | 73181500 | 18% |
| 93442299 | Eicher Tractor Bearing                 | 847   | 84822011 | 18% |
| 93442305 | Eicher Tractor Diff Housing            | 5114  | 87084000 | 18% |
| 93442317 | Eicher Tractor Bolt M10X40             | 78    | 73181500 | 18% |
| 93442329 | Eicher Tractor Shaft                   | 4627  | 87089900 | 18% |
| 93442330 | Eicher Tractor Cover                   | 2235  | 87084000 | 18% |
| 93442354 | Eicher Tractor Snap Ring               | 450   | 73182910 | 18% |
| 93442366 | Eicher Tractor Shim Mm 0.50            | 110   | 73182100 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93442378 | Eicher Tractor Shim Mm 0.40             | 99    | 73182100 | 18% |
| 93442380 | Eicher Tractor Shim Mm 0.30             | 110   | 73182100 | 18% |
| 93442391 | Eicher Tractor Shim Mm 0.10             | 74    | 73182100 | 18% |
| 93442408 | Eicher Tractor Shim Mm 0.05             | 65    | 73182100 | 18% |
| 93442410 | Eicher Tractor Bearing                  | 2765  | 84821011 | 18% |
| 93442421 | Eicher Tractor Gears Kit                | 7919  | 87084000 | 18% |
| 93442433 | Eicher Tractor Screw M8X20              | 23    | 73181500 | 18% |
| 93442445 | Eicher Tractor Cover Top                | 2133  | 87084000 | 18% |
| 93442457 | Eicher Tractor O. Ring                  | 45    | 40169320 | 18% |
| 93442469 | Eicher Tractor Bearing                  | 829   | 84821011 | 18% |
| 93442470 | Eicher Tractor Rh King Pin Housing      | 10610 | 87084000 | 18% |
| 93442482 | Eicher Tractor Lh King Pin Housing      | 10610 | 87084000 | 18% |
| 93442494 | Eicher Tractor Rh Swivel Housing        | 24820 | 87084000 | 18% |
| 93442500 | Eicher Tractor Lh Swivel Housing        | 19365 | 87084000 | 18% |
| 93442512 | Eicher Tractor Roller Bearing           | 1078  | 84821011 | 18% |
| 93442524 | Eicher Tractor Seal                     | 4409  | 84314930 | 18% |
| 93442536 | Eicher Tractor Seal                     | 2454  | 84314930 | 18% |
| 93442548 | Eicher Tractor O. Ring                  | 333   | 40169320 | 18% |
| 93442550 | Eicher Tractor Bearing                  | 1797  | 84825011 | 18% |
| 93442561 | Eicher Tractor Bearing                  | 1450  | 84825011 | 18% |
| 93442573 | Eicher Tractor Washer                   | 224   | 73182990 | 18% |
| 93442585 | Eicher Tractor Ring Nut                 | 1043  | 73181500 | 18% |
| 93442597 | Eicher Tractor Shaft                    | 4807  | 87089900 | 18% |
| 93442603 | Eicher Tractor Straight Bevel Gear Z 12 | 2774  | 87084000 | 18% |
| 93442615 | Eicher Tractor Bearing                  | 2758  | 84825011 | 18% |
| 93442627 | Eicher Tractor Shim Mm 0.50             | 160   | 73182100 | 18% |
| 93442639 | Eicher Tractor Shim Mm 0.40             | 144   | 73182100 | 18% |
| 93442640 | Eicher Tractor Shim Mm 0.30             | 162   | 73182100 | 18% |
| 93442652 | Eicher Tractor Shim Mm 0.20             | 152   | 73182100 | 18% |
| 93442664 | Eicher Tractor Shim Mm 0.10             | 107   | 73182100 | 18% |
| 93442676 | Eicher Tractor Shim Mm 0.05             | 95    | 73182100 | 18% |
| 93442688 | Eicher Tractor O. Ring                  | 46    | 40169320 | 18% |
| 93442690 | Eicher Tractor Cover                    | 2128  | 84825011 | 18% |
| 93442706 | Eicher Tractor Wheel Shaft              | 13124 | 87084000 | 18% |
| 93442718 | Eicher Tractor Stud                     | 235   | 73181500 | 18% |
| 93442755 | Eicher Tractor Wheel Hub                | 7701  | 87087000 | 18% |
| 93442767 | Eicher Tractor Screw                    | 22    | 73181500 | 18% |
| 93442779 | Eicher Tractor Bearing                  | 1483  | 84822011 | 18% |
| 93442780 | Eicher Tractor Straight Bevel           | 16212 | 87084000 | 18% |
| 93442792 | Eicher Tractor O. Ring                  | 958   | 40169320 | 18% |
| 93442809 | Eicher Tractor Shim Mm 0.50             | 26    | 73182100 | 18% |
| 93442810 | Eicher Tractor Shim Mm 0.40             | 24    | 73182100 | 18% |
| 93442822 | Eicher Tractor Shim Mm 0.30             | 26    | 73182100 | 18% |
| 93442834 | Eicher Tractor Shim Mm 0.20             | 25    | 73182100 | 18% |
| 93442846 | Eicher Tractor Shim Mm 0.10             | 19    | 73182100 | 18% |
| 93442858 | Eicher Tractor Shim Mm 0.05             | 18    | 73182100 | 18% |
| 93442860 | Eicher Tractor Washer                   | 206   | 73182100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93442871 | Eicher Tractor Ring Nut                    | 660   | 73181500 | 18% |
| 93442895 | Eicher Tractor Washer,Sealing              | 183   | 84099990 | 28% |
| 93442901 | Eicher Tractor Bolt,Washer Assemble        | 34    | 84099990 | 28% |
| 93442913 | Eicher Tractor Gasket,Oil Pump Cove        | 134   | 84099990 | 28% |
| 93442925 | Eicher Tractor Plug,Tapered                | 46    | 84099990 | 28% |
| 93442937 | Eicher Tractor Gasket,Cylinder Head        | 4823  | 84099990 | 28% |
| 93442949 | Eicher Tractor Seal,Valve Stem             | 298   | 84099911 | 28% |
| 93442950 | Eicher Tractor Gasket,Rocker Cover         | 1210  | 84099990 | 28% |
| 93442962 | Eicher Tractor Key,Woodruff                | 73    | 84099990 | 28% |
| 93442974 | Eicher Tractor Seal,Side                   | 325   | 84099990 | 28% |
| 93442986 | Eicher Tractor Gasket,Oil Seal Case        | 234   | 84099990 | 28% |
| 93442998 | Eicher Tractor Bolt                        | 19    | 84099990 | 28% |
| 93443000 | Eicher Tractor Gasket,Front Plate          | 718   | 84099990 | 28% |
| 93443012 | Eicher Tractor Bolt                        | 31    | 84099990 | 28% |
| 93443024 | Eicher Tractor Bolt,Drive Plate            | 229   | 84099990 | 28% |
| 93443036 | Eicher Tractor Gasket,Inlet Cover          | 389   | 84099990 | 28% |
| 93443048 | Eicher Tractor Gasket,Exhaust              | 838   | 84099990 | 28% |
| 93443050 | Eicher Tractor Gasket                      | 38    | 84099990 | 28% |
| 93443061 | Eicher Tractor Gasket                      | 238   | 84099990 | 28% |
| 93443073 | Eicher Tractor Pipe,Breather               | 76    | 84099990 | 28% |
| 93443085 | Eicher Tractor Gasket,Water Pump           | 92    | 84099990 | 28% |
| 93443097 | Eicher Tractor Bolt,Flange                 | 42    | 84099990 | 28% |
| 93443103 | Eicher Tractor Gasket,Thermostat           | 468   | 84099990 | 28% |
| 93443115 | Eicher Tractor Gasket,Thermo Case          | 31    | 84099990 | 28% |
| 93443127 | Eicher Tractor Gasket,Holder               | 61    | 84099990 | 28% |
| 93443139 | Eicher Tractor Gasket,Fuel Return          | 61    | 84099990 | 28% |
| 93443140 | Eicher Tractor Gasket,Governor Case        | 85    | 84099990 | 28% |
| 93443152 | Eicher Tractor Pump Assy,Fuel Inj          | 95360 | 84099930 | 28% |
| 93443164 | Eicher Tractor Switch Water Temperature    | 819   | 85365090 | 18% |
| 93443176 | Eicher Tractor Plug,Drain                  | 336   | 84099990 | 28% |
| 93443188 | Eicher Tractor Switch Oil Pressure         | 1047  | 85365090 | 18% |
| 93443190 | Eicher Tractor Gasket                      | 91    | 84099990 | 28% |
| 93443206 | Eicher Tractor Gasket Housing              | 157   | 84099990 | 28% |
| 93443218 | Eicher Tractor Washer,Spring               | 11    | 84099990 | 28% |
| 93443220 | Eicher Tractor Bolt,Washer Assembled       | 31    | 84099990 | 28% |
| 93443231 | Eicher Tractor Bolt,Washer Assemble        | 50    | 84099990 | 28% |
| 93443243 | Eicher Tractor Electric Lift Pump Assembly | 3698  | 84099990 | 28% |
| 93443255 | Eicher Tractor Assy Fan                    | 4988  | 84099990 | 28% |
| 93443267 | Eicher Tractor Belt                        | 1047  | 84099990 | 28% |
| 93443279 | Eicher Tractor Filter Assy,Fuel            | 4275  | 84099990 | 28% |
| 93443280 | Eicher Tractor Fuel Filter                 | 1009  | 84212300 | 18% |
| 93443292 | Eicher Tractor Washer,Seal                 | 57    | 84099990 | 28% |
| 93443309 | Eicher Tractor Connector,Fuel Filte        | 1099  | 84099990 | 28% |
| 93443310 | Eicher Tractor Plug,Fuel Filter            | 606   | 84099990 | 28% |
| 93443322 | Eicher Tractor Filter,Fuel Pre             | 488   | 84099990 | 28% |
| 93443334 | Eicher Tractor Alternator Assy             | 34125 | 84099990 | 28% |
| 93443346 | Eicher Tractor Plate,Adjusting             | 416   | 84099990 | 28% |



|          |                                       |       |          |     |
|----------|---------------------------------------|-------|----------|-----|
| 93443358 | Eicher Tractor Washer                 | 42    | 84099990 | 28% |
| 93443360 | Eicher Tractor Nut                    | 12    | 84099990 | 28% |
| 93443371 | Eicher Tractor Washer, Spring         | 11    | 84099990 | 28% |
| 93443383 | Eicher Tractor Washer, Plain          | 23    | 84099990 | 28% |
| 93443395 | Eicher Tractor Bolt, Alternator       | 241   | 84099990 | 28% |
| 93443401 | Eicher Tractor Spacer, Alternator     | 577   | 84099990 | 28% |
| 93443413 | Eicher Tractor Bolt Washer A(6X55)    | 16    | 84099990 | 28% |
| 93443425 | Eicher Tractor Spacer, Fan(10)        | 195   | 84099990 | 28% |
| 93443437 | Eicher Tractor Spacer, Fan            | 1126  | 84099990 | 28% |
| 93443449 | Eicher Tractor Plug, Taper            | 76    | 84099990 | 28% |
| 93443450 | Eicher Tractor Bolt                   | 53    | 84099990 | 28% |
| 93443462 | Eicher Tractor Manifold, Exhaust      | 5785  | 84099990 | 28% |
| 93443474 | Eicher Tractor Stud                   | 38    | 84099990 | 28% |
| 93443486 | Eicher Tractor Bolt                   | 38    | 73181500 | 18% |
| 93443498 | Eicher Tractor Bolt                   | 65    | 84099990 | 28% |
| 93443504 | Eicher Tractor Cover Assy, Inlet      | 2684  | 84099990 | 28% |
| 93443516 | Eicher Tractor Pipe, Inlet            | 871   | 84099990 | 28% |
| 93443528 | Eicher Tractor Gasket, Inlet Pipe     | 95    | 84099990 | 28% |
| 93443530 | Eicher Tractor Bolt, Washer Assemble  | 38    | 84099990 | 28% |
| 93443541 | Eicher Tractor Flywheel Sub Assy      | 26267 | 84099990 | 28% |
| 93443553 | Eicher Tractor Gear, Ring             | 3346  | 84099990 | 28% |
| 93443565 | Eicher Tractor Adaptor, Bearing       | 1237  | 84099990 | 28% |
| 93443577 | Eicher Tractor Plate, Rear            | 14482 | 84099990 | 28% |
| 93443589 | Eicher Tractor Bolt                   | 80    | 84099990 | 28% |
| 93443590 | Eicher Tractor Washer, Spring         | 19    | 84099990 | 28% |
| 93443607 | Eicher Tractor Shaft, Fuel Inj Pump   | 8434  | 84099990 | 28% |
| 93443619 | Eicher Tractor Bearing, Ball          | 947   | 84099990 | 28% |
| 93443620 | Eicher Tractor Washer                 | 141   | 84099990 | 28% |
| 93443632 | Eicher Tractor Key, Sunk              | 61    | 84099990 | 28% |
| 93443644 | Eicher Tractor Nozzle And Holder Assy | 16288 | 84099920 | 28% |
| 93443656 | Eicher Tractor Nozzle Assy            | 5689  | 84099920 | 18% |
| 93443668 | Eicher Tractor Holder Assy            | 15273 | 84099990 | 28% |
| 93443670 | Eicher Tractor Washer                 | 397   | 84099990 | 28% |
| 93443681 | Eicher Tractor Washer                 | 397   | 84099990 | 28% |
| 93443693 | Eicher Tractor Washer                 | 397   | 84099990 | 28% |
| 93443700 | Eicher Tractor Washer                 | 397   | 84099990 | 28% |
| 93443711 | Eicher Tractor Washer                 | 397   | 84099990 | 28% |
| 93443723 | Eicher Tractor Washer                 | 298   | 84099990 | 28% |
| 93443735 | Eicher Tractor Washer                 | 256   | 84099990 | 28% |
| 93443747 | Eicher Tractor Washer                 | 256   | 84099990 | 28% |
| 93443759 | Eicher Tractor Washer                 | 256   | 84099990 | 28% |
| 93443760 | Eicher Tractor Washer                 | 256   | 84099990 | 28% |
| 93443772 | Eicher Tractor Pin, Pressure          | 249   | 84099990 | 28% |
| 93443784 | Eicher Tractor Piece, Distance        | 584   | 84099990 | 28% |
| 93443796 | Eicher Tractor Spring, Pressure       | 653   | 84099990 | 28% |
| 93443802 | Eicher Tractor Body Sub Assy          | 5479  | 84099990 | 28% |
| 93443814 | Eicher Tractor Nut, Nozzle Retaining  | 1481  | 73181600 | 18% |



|          |   |        |          |     |
|----------|---|--------|----------|-----|
| 93443826 | Eicher Tractor Nut                      | 20     | 84099990 | 28% |
| 93443838 | Eicher Tractor Pipe,Injection No.1      | 1044   | 84099990 | 28% |
| 93443840 | Eicher Tractor Pipe,Injection No.2      | 1044   | 84099990 | 28% |
| 93443851 | Eicher Tractor Pipe,Injection No.3      | 1044   | 84099990 | 28% |
| 93443863 | Eicher Tractor Clamp                    | 317    | 84099990 | 28% |
| 93443875 | Eicher Tractor Clamp                    | 118    | 84099990 | 28% |
| 93443887 | Eicher Tractor Clip Hose (9 4)          | 34     | 84099990 | 28% |
| 93443899 | Eicher Tractor Bolt,Washer Assemble     | 53     | 84099990 | 28% |
| 93443905 | Eicher Tractor Pipe,Fuel Leak Off       | 2666   | 84099990 | 28% |
| 93443917 | Eicher Tractor Hose Assy,Air Vent       | 2149   | 84099990 | 28% |
| 93443929 | Eicher Tractor Joint                    | 729    | 84099990 | 28% |
| 93443930 | Eicher Tractor Hose,Fuel                | 168    | 84099990 | 28% |
| 93443942 | Eicher Tractor Hose,Fuel                | 371    | 84099990 | 28% |
| 93443954 | Eicher Tractor Clip,Hose                | 34     | 84099990 | 28% |
| 93443966 | Eicher Tractor Plug Glow                | 1724   | 73182990 | 18% |
| 93443978 | Eicher Tractor Plate,Connector          | 56     | 84099990 | 28% |
| 93443980 | Eicher Tractor Solenoid And Nut Set     | 7514   | 84099990 | 28% |
| 93443991 | Eicher Tractor Hanger,Engine            | 130    | 84099990 | 28% |
| 93444004 | Eicher Tractor Bolt,Washer Assemble     | 42     | 84099990 | 28% |
| 93444016 | Eicher Tractor Gage,Oil Level           | 1893   | 84099990 | 28% |
| 93444028 | Eicher Tractor Oil Filter               | 547    | 84212300 | 18% |
| 93444030 | Eicher Tractor Strainer Assy, Oil       | 1409   | 84099990 | 28% |
| 93444041 | Eicher Tractor Nut,Jam                  | 44     | 84099990 | 28% |
| 93444053 | Eicher Tractor Valve Assy,Relief        | 3607   | 84099990 | 28% |
| 93444065 | Eicher Tractor Bearing Set,Main         | 8324   | 84099990 | 28% |
| 93444077 | Eicher Tractor Bearing Set,Main         | 8346   | 84099990 | 28% |
| 93444089 | Eicher Tractor Bearing Set,Main         | 8346   | 84099990 | 28% |
| 93444090 | Eicher Tractor Bearing Set,Main         | 15801  | 84099990 | 28% |
| 93444107 | Eicher Tractor Tool Set,Piston Pin      | 58651  | 84099990 | 28% |
| 93444168 | Eicher Tractor Piston (Std)             | 5704   | 84099912 | 28% |
| 93444170 | Eicher Tractor Pin,Piston               | 1070   | 84099990 | 28% |
| 93444181 | Eicher Tractor Ring Set,Piston (Std)    | 7319   | 84099913 | 28% |
| 93444193 | Eicher Tractor Ring Set,Piston (Os .25) | 7506   | 84099913 | 28% |
| 93444200 | Eicher Tractor Ring Set,Piston (Os .50) | 9758   | 84099913 | 28% |
| 93444211 | Eicher Tractor Piston (Os.25)           | 10957  | 84099912 | 28% |
| 93444223 | Eicher Tractor Ring Set,Piston (Os .50) | 10957  | 84099912 | 28% |
| 93444235 | Eicher Tractor Cover Assy,Rocker        | 2417   | 84099990 | 28% |
| 93444247 | Eicher Tractor Bolt,Washer Assemble     | 38     | 84099990 | 28% |
| 93444259 | Eicher Tractor Cap,Oil Filler           | 478    | 84099990 | 28% |
| 93444260 | Eicher Tractor Assy. Engine-S3L2        | 252498 | 84082020 | 18% |
| 93444272 | Eicher Tractor Starter Assy(12V-1.7     | 34550  | 84099990 | 28% |
| 93444296 | Eicher Tractor Gear,Crankshaft          | 2906   | 84099990 | 28% |
| 93444302 | Eicher Tractor Gear,Camshaft            | 6460   | 84099990 | 28% |
| 93444314 | Eicher Tractor Gear,Injection Pump      | 4502   | 84099990 | 28% |
| 93444326 | Eicher Tractor Gear Assy Idler          | 4639   | 84099990 | 28% |
| 93444338 | Eicher Tractor Gear,Press. Oil Pump     | 11269  | 84099990 | 28% |
| 93444340 | Eicher Tractor Bearing Rear             | 1558   | 84099990 | 28% |





|          |                                      |       |          |     |
|----------|--------------------------------------|-------|----------|-----|
| 93444351 | Eicher Tractor Pump Assy,Water       | 7686  | 84099990 | 28% |
| 93444387 | Eicher Tractor Gasket,Waterpump      | 145   | 84849000 | 18% |
| 93444399 | Eicher Tractor Bolt,Washer Assemble  | 34    | 84099990 | 28% |
| 93444405 | Eicher Tractor Bolt,Washer Assemble  | 42    | 84099990 | 28% |
| 93444417 | Eicher Tractor Bolt,Washer Assemble  | 46    | 84099990 | 28% |
| 93444429 | Eicher Tractor Washer,Plain          | 19    | 84099990 | 28% |
| 93444430 | Eicher Tractor Pulley,Water Pump     | 1460  | 84099990 | 28% |
| 93444442 | Eicher Tractor Assy. Muffler Exhaust | 3885  | 87089200 | 18% |
| 93444478 | Eicher Tractor Camshaft              | 14887 | 84099990 | 28% |
| 93444480 | Eicher Tractor Plate,Thrust          | 2612  | 84099990 | 28% |
| 93444491 | Eicher Tractor Tappet                | 638   | 84099990 | 28% |
| 93444508 | Eicher Tractor Rod,Push              | 233   | 84099990 | 28% |
| 93444510 | Eicher Tractor Rod Assy,Connecting   | 5019  | 84099949 | 28% |
| 93444522 | Eicher Tractor Nut,Connecting-Rod    | 218   | 73181600 | 18% |
| 93444534 | Eicher Tractor Bolt,Connecting-Rod   | 435   | 73181500 | 18% |
| 93444546 | Eicher Tractor Bearing Set,Con-Rod   | 3354  | 84099990 | 28% |
| 93444558 | Eicher Tractor Bearing Set,Con-Rod   | 5047  | 84099990 | 28% |
| 93444560 | Eicher Tractor Bearing Set,Con-Rod   | 5716  | 84099990 | 28% |
| 93444571 | Eicher Tractor Bearing Set,Con-Rod   | 5716  | 84099990 | 28% |
| 93444583 | Eicher Tractor Case Assy. Thermostat | 8713  | 84099990 | 28% |
| 93444595 | Eicher Tractor Cover,Thermostat      | 764   | 84099990 | 28% |
| 93444600 | Eicher Tractor Thermostate           | 3198  | 90321010 | 18% |
| 93444612 | Eicher Tractor Hose Assy             | 657   | 84099990 | 28% |
| 93444624 | Eicher Tractor Hose,By-Pass          | 630   | 84099990 | 28% |
| 93444636 | Eicher Tractor Clamp                 | 31    | 84099990 | 28% |
| 93444648 | Eicher Tractor Bolt,Washer Assemble  | 34    | 84099990 | 28% |
| 93444650 | Eicher Tractor Block Assy,Cylinder   | 76474 | 84099990 | 28% |
| 93444661 | Eicher Tractor Bolt,Bearingcap       | 386   | 73181500 | 18% |
| 93444673 | Eicher Tractor Bushing,Camshaft      | 1107  | 84099990 | 28% |
| 93444685 | Eicher Tractor Cap,Sealing           | 28    | 84099990 | 28% |
| 93444697 | Eicher Tractor Cap,Sealing           | 252   | 84099990 | 28% |
| 93444703 | Eicher Tractor Guide,Oil Level Gage  | 172   | 84099990 | 28% |
| 93444715 | Eicher Tractor Cap,Sealing           | 27    | 84099990 | 28% |
| 93444727 | Eicher Tractor Cap,Sealing           | 24    | 84099990 | 28% |
| 93444739 | Eicher Tractor Plug,Tapered          | 76    | 84099990 | 28% |
| 93444740 | Eicher Tractor Bushing,Knock         | 103   | 84099990 | 28% |
| 93444752 | Eicher Tractor Bushing,Knock         | 103   | 84099990 | 28% |
| 93444764 | Eicher Tractor Bushing,Knock         | 126   | 84099990 | 28% |
| 93444776 | Eicher Tractor Plug,Expansion        | 168   | 84099990 | 28% |
| 93444788 | Eicher Tractor Pin,Dowel             | 84    | 84099990 | 28% |
| 93444790 | Eicher Tractor Pin,Dowel             | 61    | 84099990 | 28% |
| 93444806 | Eicher Tractor Shaft Assy, Idler     | 718   | 84099990 | 28% |
| 93444818 | Eicher Tractor Ball,Steel Bearing    | 61    | 84099990 | 28% |
| 93444820 | Eicher Tractor Shaft,Oil Filter      | 122   | 84099990 | 28% |
| 93444831 | Eicher Tractor Pin,Dowel             | 69    | 84099990 | 28% |
| 93444843 | Eicher Tractor Plug,Tapered          | 248   | 84099990 | 28% |
| 93444855 | Eicher Tractor Case,Oil Seal         | 1315  | 84099990 | 28% |



|          |                                     |       |          |     |
|----------|-------------------------------------|-------|----------|-----|
| 93444867 | Eicher Tractor Seal,Oil, Crank Case | 1497  | 87085000 | 18% |
| 93444879 | Eicher Tractor Crankshaft           | 69680 | 84099990 | 28% |
| 93444880 | Eicher Tractor Washer,Plain         | 103   | 84099990 | 28% |
| 93444892 | Eicher Tractor Washer,Spring        | 34    | 84099990 | 28% |
| 93444909 | Eicher Tractor Nut                  | 72    | 84099990 | 28% |
| 93444910 | Eicher Tractor Pulley,Crankshaft    | 3402  | 84099990 | 28% |
| 93444922 | Eicher Tractor Head Assy.,Cylinder  | 76173 | 84099990 | 28% |
| 93444934 | Eicher Tractor Cap,Sealing          | 69    | 84099990 | 28% |
| 93444946 | Eicher Tractor Cap,Sealing          | 28    | 84099990 | 28% |
| 93444958 | Eicher Tractor Bolt,Cylinder Head 1 | 344   | 84099990 | 28% |
| 93444960 | Eicher Tractor Guide,Exhaust Valve  | 202   | 84099990 | 28% |
| 93444971 | Eicher Tractor Guide,Inlet Valve    | 202   | 84099990 | 28% |
| 93444983 | Eicher Tractor Jet,Combustion       | 3238  | 84099990 | 28% |
| 93445014 | Eicher Tractor Bolt,High Speed Set  | 27    | 84099990 | 28% |
| 93445026 | Eicher Tractor Nut,High Speed Set   | 183   | 84099990 | 28% |
| 93445038 | Eicher Tractor C-Ring               | 241   | 84099990 | 28% |
| 93445040 | Eicher Tractor C-Ring               | 218   | 84099990 | 28% |
| 93445051 | Eicher Tractor Spring,Tie Rod       | 535   | 84099990 | 28% |
| 93445063 | Eicher Tractor Cover,Governor Shaft | 69    | 84099990 | 28% |
| 93445075 | Eicher Tractor Shaft,Governor       | 7984  | 84099990 | 28% |
| 93445087 | Eicher Tractor Lever,Speed Control  | 305   | 84099990 | 28% |
| 93445099 | Eicher Tractor Spring,Start         | 351   | 84099990 | 28% |
| 93445100 | Eicher Tractor Spring Set,Torque    | 13765 | 84099990 | 28% |
| 93445173 | Eicher Tractor Bolt,Low Idle Set    | 34    | 84099990 | 28% |
| 93445185 | Eicher Tractor Pin,Grooved          | 42    | 84099990 | 28% |
| 93445197 | Eicher Tractor Case,Governor        | 4276  | 84099990 | 28% |
| 93445203 | Eicher Tractor Shim,Governor Shaft  | 34    | 84099990 | 28% |
| 93445215 | Eicher Tractor Tie-Rod              | 370   | 84099990 | 28% |
| 93445227 | Eicher Tractor Lever,Gov. Spring    | 1004  | 84099990 | 28% |
| 93445239 | Eicher Tractor Lever,Governor       | 2848  | 84099990 | 28% |
| 93445240 | Eicher Tractor Nut                  | 12    | 84099990 | 28% |
| 93445252 | Eicher Tractor Nut,Jam              | 12    | 84099990 | 28% |
| 93445264 | Eicher Tractor Pin,Spring           | 38    | 84099990 | 28% |
| 93445276 | Eicher Tractor C-Ring               | 103   | 84099990 | 28% |
| 93445288 | Eicher Tractor Spring,Governor      | 1180  | 84099990 | 28% |
| 93445290 | Eicher Tractor Shaft,Sliding Sleeve | 1985  | 84099990 | 28% |
| 93445306 | Eicher Tractor Sleeve,Sliding       | 2142  | 84099990 | 28% |
| 93445318 | Eicher Tractor Weight Assy,Governor | 5093  | 84099990 | 28% |
| 93445320 | Eicher Tractor Cover,High Speed Set | 229   | 84099990 | 28% |
| 93445331 | Eicher Tractor Cover,Torqueset      | 244   | 84099990 | 28% |
| 93445343 | Eicher Tractor Bolt,Governor Case   | 88    | 84099990 | 28% |
| 93445355 | Eicher Tractor Cover,Tie Rod        | 290   | 84099990 | 28% |
| 93445367 | Eicher Tractor Gasket,Tie Rod Cover | 100   | 84099990 | 28% |
| 93445379 | Eicher Tractor Bolt,Washer Assemble | 23    | 84099990 | 28% |
| 93445380 | Eicher Tractor Washer,Sealing       | 130   | 84099990 | 28% |
| 93445392 | Eicher Tractor Color,Union          | 1898  | 84099990 | 28% |
| 93445409 | Eicher Tractor Housing Sub Assy     | 26326 | 84099990 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93445410 | Eicher Tractor Element Sub Assy           | 8072  | 84099990 | 28% |
| 93445422 | Eicher Tractor Valve Sub Assy             | 3524  | 84099990 | 28% |
| 93445434 | Eicher Tractor Holder,Delivery            | 9889  | 84099990 | 28% |
| 93445446 | Eicher Tractor Spring,Delivery            | 431   | 84099990 | 28% |
| 93445458 | Eicher Tractor O-Ring                     | 409   | 84099990 | 28% |
| 93445460 | Eicher Tractor Sleeve,Control             | 2161  | 84099990 | 28% |
| 93445471 | Eicher Tractor Tappet Sub Assy            | 7056  | 84099990 | 28% |
| 93445483 | Eicher Tractor Pin,Tappet Guid            | 393   | 84099990 | 28% |
| 93445495 | Eicher Tractor Shim                       | 225   | 84099990 | 28% |
| 93445501 | Eicher Tractor Shim                       | 244   | 84099990 | 28% |
| 93445513 | Eicher Tractor Shim                       | 237   | 84099990 | 28% |
| 93445525 | Eicher Tractor Shim                       | 202   | 84099990 | 28% |
| 93445537 | Eicher Tractor Shim                       | 237   | 84099990 | 28% |
| 93445549 | Eicher Tractor Shim                       | 218   | 84099990 | 28% |
| 93445550 | Eicher Tractor Shim                       | 263   | 84099990 | 28% |
| 93445562 | Eicher Tractor Seat,Spring Lower          | 1856  | 84099990 | 28% |
| 93445574 | Eicher Tractor Spring,Plunger             | 756   | 84099990 | 28% |
| 93445586 | Eicher Tractor Washer,Pipe Union          | 50    | 84099990 | 28% |
| 93445598 | Eicher Tractor Seat,Spring Upper          | 218   | 84099990 | 28% |
| 93445604 | Eicher Tractor Screw,Air Bleeder          | 787   | 84099990 | 28% |
| 93445616 | Eicher Tractor Plate                      | 309   | 84099990 | 28% |
| 93445628 | Eicher Tractor Shim                       | 218   | 84099990 | 28% |
| 93445630 | Eicher Tractor Rack Assy,Control          | 5319  | 84099990 | 28% |
| 93445641 | Eicher Tractor Screw,Hollow               | 1581  | 84099990 | 28% |
| 93445653 | Eicher Tractor Shim                       | 218   | 84099990 | 28% |
| 93445665 | Eicher Tractor Shim                       | 401   | 84099990 | 28% |
| 93445677 | Eicher Tractor Gasket,Delivery            | 149   | 84099990 | 28% |
| 93445689 | Eicher Tractor Plate,Adjusting            | 1172  | 84099990 | 28% |
| 93445690 | Eicher Tractor Bolt,Washer Head           | 317   | 84099990 | 28% |
| 93445707 | Eicher Tractor Gasket Kit, Overhaul       | 25421 | 84841090 | 18% |
| 93445719 | Eicher Tractor Gasket,Tie Rod             | 130   | 84099990 | 28% |
| 93445720 | Eicher Tractor Gasket,Gear Case           | 1447  | 84099990 | 28% |
| 93445732 | Eicher Tractor Packing,Body               | 725   | 84099990 | 28% |
| 93445744 | Eicher Tractor Pan Assy.,                 | 10767 | 84099990 | 28% |
| 93445756 | Eicher Tractor Plug,Drain                 | 362   | 84099990 | 28% |
| 93445768 | Eicher Tractor Bolt,Flange L=25           | 61    | 84099990 | 28% |
| 93445770 | Eicher Tractor Bolt                       | 76    | 84099990 | 28% |
| 93445781 | Eicher Tractor Bolt (8X110 9T)            | 241   | 84099990 | 28% |
| 93445793 | Eicher Tractor Pump Assy,Oil              | 13833 | 84099990 | 28% |
| 93445800 | Eicher Tractor Packing,Body               | 421   | 40169990 | 18% |
| 93445811 | Eicher Tractor Bolt                       | 23    | 84099990 | 28% |
| 93445823 | Eicher Tractor Plate,Front                | 2780  | 84099990 | 28% |
| 93445835 | Eicher Tractor Case,Gear                  | 13849 | 84099990 | 28% |
| 93445847 | Eicher Tractor Gasket,Gear Case           | 1325  | 84099990 | 28% |
| 93445859 | Eicher Tractor Seal,Oil, Timing Gear Case | 422   | 87085000 | 18% |
| 93445860 | Eicher Tractor Housing,Gear Pump          | 2276  | 84099990 | 28% |
| 93445872 | Eicher Tractor Cover,Oil Pump Shaft       | 557   | 84099990 | 28% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93445884 | Eicher Tractor Cap,Filler                   | 1252  | 84099990 | 28% |
| 93445896 | Eicher Tractor Bolt,Washer Assemble         | 34    | 84099990 | 28% |
| 93445902 | Eicher Tractor Stud                         | 84    | 84099990 | 28% |
| 93445914 | Eicher Tractor Stud (8X22)                  | 107   | 84099990 | 28% |
| 93445926 | Eicher Tractor Nut                          | 12    | 84099990 | 28% |
| 93445938 | Eicher Tractor Bolt,Washer Assemble         | 53    | 84099990 | 28% |
| 93445940 | Eicher Tractor Bolt                         | 42    | 84099990 | 28% |
| 93445951 | Eicher Tractor Valve,Inlet                  | 2207  | 84099911 | 28% |
| 93445963 | Eicher Tractor Valve,Exhaust                | 1661  | 84099911 | 28% |
| 93445975 | Eicher Tractor Spring,Valve                 | 229   | 84099990 | 28% |
| 93445987 | Eicher Tractor Retainer,Valve Stem          | 328   | 84099911 | 28% |
| 93445999 | Eicher Tractor Valve Lock,Spring            | 19    | 84099990 | 28% |
| 93446001 | Eicher Tractor Cap,Valve Stem               | 305   | 84099911 | 28% |
| 93446013 | Eicher Tractor Rockerandshaft Assy          | 17522 | 84099990 | 28% |
| 93446025 | Eicher Tractor Bracket,Rocker Shaft         | 1058  | 84099990 | 28% |
| 93446037 | Eicher Tractor Spring,Rocker                | 930   | 84099990 | 28% |
| 93446049 | Eicher Tractor Bracket,Rocker Shaft         | 1149  | 84099990 | 28% |
| 93446050 | Eicher Tractor Shaft Assy,Rocker            | 10668 | 84099990 | 28% |
| 93446074 | Eicher Tractor Screw,Rocker                 | 229   | 84099990 | 28% |
| 93446086 | Eicher Tractor Bolt                         | 76    | 73181500 | 18% |
| 93446090 | Eicher Tractor Nut,Jam                      | 31    | 84099990 | 28% |
| 93446104 | Eicher Tractor Ring,Snap                    | 99    | 84099990 | 28% |
| 93446116 | Eicher Tractor Bolt,Rocker Bracket          | 61    | 84099990 | 28% |
| 93446128 | Eicher Tractor Assy. Radiator Complete      | 8521  | 87089100 | 18% |
| 93446130 | Eicher Tractor Hose, Cooling Water Up       | 561   | 40091100 | 18% |
| 93446141 | Eicher Tractor Hose, Cooling Water Lwr      | 610   | 40091100 | 18% |
| 93446177 | Eicher Tractor Sticker Radiator Cap         | 15    | 39199090 | 18% |
| 93446256 | Eicher Tractor Dust Cover Axial Ball Joint  | 67    | 87084000 | 18% |
| 93446268 | Eicher Tractor Dust Cover Radial Ball Joint | 63    | 87084000 | 18% |
| 93446293 | Eicher Tractor Intercooler Assy             | 13226 | 87084000 | 18% |
| 93446300 | Eicher Tractor Shroud                       | 839   | 87089900 | 18% |
| 93446311 | Eicher Tractor Drain Plug Assly             | 30    | 87084000 | 18% |
| 93446323 | Eicher Tractor Pressure Cap Assly           | 331   | 87089900 | 18% |
| 93446335 | Eicher Tractor No Loss Tank Assly           | 1143  | 84099941 | 28% |
| 93446360 | Eicher Tractor Seal                         | 1004  | 84314930 | 18% |
| 93446372 | Eicher Tractor Spring Buffer                | 85    | 94019000 | 18% |
| 93446384 | Eicher Tractor Unx Spring                   | 68    | 94019000 | 18% |
| 93446396 | Eicher Tractor Element Primary              | 777   | 84219900 | 18% |
| 93446402 | Eicher Tractor Safety Filter Assy           | 724   | 84219900 | 18% |
| 93446451 | Eicher Tractor Seal Kit                     | 13906 | 87089900 | 18% |
| 93446463 | Eicher Tractor Rod                          | 17825 | 87084000 | 18% |
| 93446475 | Eicher Tractor Snap Ring                    | 614   | 73182990 | 18% |
| 93446487 | Eicher Tractor Head                         | 6499  | 74152900 | 18% |
| 93446499 | Eicher Tractor Elastic Ring                 | 614   | 40169340 | 18% |
| 93446505 | Eicher Tractor Plug                         | 198   | 87084000 | 18% |
| 93446517 | Eicher Tractor Aux Valve Kit – 280          | 10861 | 87089900 | 18% |
| 93446529 | Eicher Tractor Tie Rod Assy Dia. - 40       | 2604  | 87089400 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93446530 | Eicher Tractor Self-Locking Nut Din                | 72    | 73181500 | 18% |
| 93446645 | Eicher Tractor Circlip                             | 49    | 73182910 | 18% |
| 93446657 | Eicher Tractor Bush                                | 552   | 87089900 | 18% |
| 93446700 | Eicher Tractor Filter,Fuel Pre                     | 455   | 84212300 | 18% |
| 93446712 | Eicher Tractor Seal Ring                           | 5036  | 84314930 | 18% |
| 93450041 | Eicher Tractor Ascending Disc Ø46                  | 57    | 87084000 | 18% |
| 93450053 | Eicher Tractor Steering Lever Double               | 2031  | 87089400 | 18% |
| 93450065 | Eicher Tractor Drag Link Assy.                     | 1681  | 87089400 | 18% |
| 93450077 | Eicher Tractor Stub Axle                           | 3399  | 87085000 | 18% |
| 93450120 | Eicher Tractor Gasket( For Gear Box Housing)       | 77    | 68129090 | 18% |
| 93450132 | Eicher Tractor Steering Gear Assy.                 | 14076 | 87089400 | 18% |
| 93450156 | Eicher Tractor Steering Arm Lh                     | 1823  | 87089400 | 18% |
| 93450168 | Eicher Tractor Steering Arm Rh                     | 1426  | 87089400 | 18% |
| 93450314 | Eicher Tractor I-Bolt M8(Battery)                  | 114   | 87089900 | 18% |
| 93450340 | Eicher Tractor Silencer Support Bkt                | 308   | 87089900 | 18% |
| 93450351 | Eicher Tractor Assy Bonnet                         | 8125  | 87089900 | 18% |
| 93450363 | Eicher Tractor Assy Fender-Rh                      | 6042  | 87089900 | 18% |
| 93450375 | Eicher Tractor Assy Fender-Lh                      | 6042  | 87089900 | 18% |
| 93450430 | Eicher Tractor Bush-Battery Tray Mtg               | 16    | 87089900 | 18% |
| 93450442 | Eicher Tractor Coller-Battery Tray Mtg             | 13    | 87089900 | 18% |
| 93450454 | Eicher Tractor Sleeve M10                          | 22    | 87084000 | 18% |
| 93450466 | Eicher Tractor Clamping Latch                      | 108   | 87089900 | 18% |
| 93450508 | Eicher Tractor Washer-Battery Tray Mtg             | 14    | 87089900 | 18% |
| 93452790 | Eicher Tractor Grease Gun                          | 506   | 84678990 | 18% |
| 93470829 | Eicher Tractor Leg Guard Mtg. Bkt. Lh              | 1265  | 87089900 | 18% |
| 93470830 | Eicher Tractor Leg Guard Mtg. Bkt. Rh              | 1265  | 87089900 | 18% |
| 93470842 | Eicher Tractor Steering Pipe Right 551 Super+ Es3  | 1285  | 87089400 | 18% |
| 93470854 | Eicher Tractor Suction Pipe Rear 551 Ps Hyd Es3    | 1612  | 87089900 | 18% |
| 93470878 | Eicher Tractor Fanguard Rear Bkt Lh (380Ms)        | 275   | 85030090 | 18% |
| 93470880 | Eicher Tractor Assy Leg Guard (High Power)         | 2285  | 87089900 | 18% |
| 93470908 | Eicher Tractor Fan Guard Mtg Bkt Lh (551S+)        | 335   | 85030090 | 18% |
| 93470910 | Eicher Tractor Fan Guard Mtg Bkt Rh                | 363   | 85030090 | 18% |
| 93470921 | Eicher Tractor Assy Alternator Cover 551-Sp        | 330   | 87085000 | 18% |
| 93470933 | Eicher Tractor Assy Alternator Cover 551-Ps        | 512   | 87085000 | 18% |
| 93470945 | Eicher Tractor Alternator Cover 551-Ms             | 495   | 87085000 | 18% |
| 93471044 | Eicher Tractor Assy Alternator Cover 551 4Wd       | 330   | 87085000 | 18% |
| 93471056 | Eicher Tractor Fuel Lid Bkt (Stryker Side)         | 72    | 87089900 | 18% |
| 93471100 | Eicher Tractor Fanguard Bkt Lh (551 4Wd)           | 282   | 85030090 | 18% |
| 93471147 | Eicher Tractor Alternator Cover 380 4Wd            | 854   | 87085000 | 18% |
| 93471238 | Eicher Tractor Sticker Star                        | 16    | 39199090 | 18% |
| 93471433 | Eicher Tractor Suction Pipe Front 551 Ps           | 269   | 87089900 | 18% |
| 93471445 | Eicher Tractor Suction Pipe Rear 551 Ps            | 1612  | 87089900 | 18% |
| 93471457 | Eicher Tractor St. Return Pipe Assy. 380/480/333 2 | 1677  | 40092200 | 18% |
| 93471469 | Eicher Tractor Steering Pipe Right 551 4Wd         | 1173  | 87089400 | 18% |
| 93471470 | Eicher Tractor Steering Pipe Right 551             | 1284  | 87089400 | 18% |
| 93471482 | Eicher Tractor Steering Pipe Right 557/650         | 1280  | 87089400 | 18% |
| 93471494 | Eicher Tractor Suction Pipe Rear 557/650           | 1490  | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93471690 | Eicher Tractor Stepped Bolt                        | 51    | 73181500 | 18% |
| 93472346 | Eicher Tractor Wh Headlamp (Front Opening)         | 811   | 87089900 | 18% |
| 93472383 | Eicher Tractor Assy Leg Guard (Low Power)          | 2338  | 87089900 | 18% |
| 93472395 | Eicher Tractor Alternator Mtg. Bkt Rh (380-MS)     | 325   | 87085000 | 18% |
| 93472413 | Eicher Tractor Fuel Lid Striker                    | 318   | 87089900 | 18% |
| 93472486 | Eicher Tractor L Pvc                               | 860   | 87084000 | 18% |
| 93472528 | Eicher Tractor Leg Guard Mtg Bkt Lh (551)          | 1402  | 87089900 | 18% |
| 93472530 | Eicher Tractor Leg Guard Mtg Bkt Rh (551)          | 1335  | 87089900 | 18% |
| 93472553 | Eicher Tractor Fanguard Upper Bkt Rh 380 Ps        | 129   | 85030090 | 18% |
| 93472565 | Eicher Tractor Fanguard Rear Bkt Lh (380)          | 510   | 85030090 | 18% |
| 93472577 | Eicher Tractor Fanguard Mtg Bkt Lh (380)           | 506   | 85030090 | 18% |
| 93472589 | Eicher Tractor Steering Pipe Right 557/650 - 4Wd   | 1183  | 87089400 | 18% |
| 93472590 | Eicher Tractor Engine Bkt Rh (Eco-V1)              | 127   | 87089900 | 18% |
| 93472632 | Eicher Tractor Engine Bkt Assy (All Valtra Models) | 109   | 87089900 | 18% |
| 93472670 | Eicher Tractor Wire Rod Assy -Lower Hp             | 483   | 85122010 | 18% |
| 93473028 | Eicher Tractor Suction Pipe Rear 551 4Wd           | 1587  | 87089900 | 18% |
| 93473107 | Eicher Tractor Radiator Sealing Top (380/480)      | 734   | 87087000 | 18% |
| 93473119 | Eicher Tractor Radiator Sealing Lh                 | 456   | 87087000 | 18% |
| 93473120 | Eicher Tractor Radiator Foam Rh 557-551            | 403   | 87087000 | 18% |
| 93473132 | Eicher Tractor Radiator Sealing Lh 380_480         | 443   | 87087000 | 18% |
| 93473144 | Eicher Tractor Radiator Sealing Rh 380_480         | 443   | 87087000 | 18% |
| 93473156 | Eicher Tractor Steering Pipe Right 776/884 V1 4Wd  | 1113  | 87084000 | 18% |
| 93473168 | Eicher Tractor Steering Inlet Pipe 776/884 V1      | 875   | 87084000 | 18% |
| 93473170 | Eicher Tractor Pressure Pipe 776/884 V1            | 1213  | 87089900 | 18% |
| 93473181 | Eicher Tractor Pressure Pipe Rear Aux              | 1170  | 87089900 | 18% |
| 93473193 | Eicher Tractor Pipe Steering Left 776/884 V1 2Wd   | 947   | 87084000 | 18% |
| 93473200 | Eicher Tractor St. Return Pipe Assy 776/884 V1     | 1643  | 87089900 | 18% |
| 93473211 | Eicher Tractor Radiator Foam Rh (551S+)            | 403   | 87087000 | 18% |
| 93473235 | Eicher Tractor Pipe Steering Left 551 Super +      | 971   | 87089400 | 18% |
| 93473259 | Eicher Tractor Combination Switch                  | 1063  | 87089900 | 18% |
| 93473260 | Eicher Tractor Tool Kit Assy. (557 Es-3)           | 1913  | 82060090 | 18% |
| 93473272 | Eicher Tractor Tool Kit Assy. (Es-3)               | 1824  | 82060090 | 18% |
| 93473284 | Eicher Tractor Wh Main 551/551S+(Rear Opening)     | 6966  | 87089900 | 18% |
| 93473296 | Eicher Tractor Wh Front 551/551S+(Rear Opening)    | 2101  | 87089900 | 18% |
| 93473302 | Eicher Tractor Wh Main 380/480(Rear Opening)       | 6916  | 87089900 | 18% |
| 93473314 | Eicher Tractor Wh Front 380/480(Rear Opening)      | 1915  | 87089900 | 18% |
| 93473388 | Eicher Tractor Lever Bottom - Acc - Eco            | 236   | 87089900 | 18% |
| 93473390 | Eicher Tractor Chain Assy-Eco                      | 147   | 87089900 | 18% |
| 93473405 | Eicher Tractor Pipe Steering Left 776/884 V1 4Wd E | 876   | 87084000 | 18% |
| 93473442 | Eicher Tractor Wire Rod Assy                       | 496   | 85122010 | 18% |
| 93473480 | Eicher Tractor Wh Front Supp Bkt                   | 32    | 87089900 | 18% |
| 93473508 | Eicher Tractor Alu Radiator Assy With Recovery Bot | 15992 | 87087000 | 18% |
| 93473703 | Eicher Tractor Crystal                             | 480   | 87089900 | 18% |
| 93473715 | Eicher Tractor Front Dial                          | 260   | 85122010 | 18% |
| 93473727 | Eicher Tractor Grommet Reset Knob                  | 61    | 40169990 | 18% |
| 93473739 | Eicher Tractor Grommet Programming Pin             | 70    | 40169990 | 18% |
| 93473752 | Eicher Tractor Sticker Super Plus                  | 35    | 39199090 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93473764 | Eicher Tractor Sticker Super Power               | 35   | 39199090 | 18% |
| 93473776 | Eicher Tractor Prima G3 Base Plate               | 33   | 87084000 | 18% |
| 93473788 | Eicher Tractor Badge Prima G3                    | 216  | 39199090 | 18% |
| 93474770 | Eicher Tractor Top Cover (Platform)              | 3133 | 87089900 | 18% |
| 93474896 | Eicher Tractor Fuel Lid Punger Locking           | 38   | 87089900 | 18% |
| 93474902 | Eicher Tractor Pin Latch Assembly (Stryker Side) | 1338 | 73182100 | 18% |
| 93474914 | Eicher Tractor Floating Receptacle               | 695  | 87083000 | 18% |
| 93474940 | Eicher Tractor Fuel Lid Bkt                      | 91   | 87089900 | 18% |
| 93475414 | Eicher Tractor Radiator Side Foam Rh             | 62   | 87087000 | 18% |
| 93475426 | Eicher Tractor Radiator Side Foam Lh             | 87   | 87087000 | 18% |
| 93476900 | Eicher Tractor Fuel Lead Bkt                     | 115  | 87089900 | 18% |
| 93476911 | Eicher Tractor Cap Fuel Lid                      | 15   | 87089900 | 18% |
| 93477320 | Eicher Tractor Fuel Lid Lock Assy                | 929  | 87089900 | 18% |
| 93477368 | Eicher Tractor Switch Cover (Plastic             | 1467 | 87083000 | 18% |
| 93477691 | Eicher Tractor Striker Pin                       | 82   | 87089900 | 18% |
| 93478040 | Eicher Tractor Shim                              | 3    | 73182200 | 18% |
| 93478052 | Eicher Tractor Shim                              | 13   | 73182200 | 18% |
| 93478064 | Eicher Tractor Cotter Pin                        | 2    | 73182400 | 18% |
| 93478076 | Eicher Tractor Spacer                            | 141  | 73072200 | 18% |
| 93478088 | Eicher Tractor Rubber Cap-Steering Column        | 21   | 87089900 | 18% |
| 93478090 | Eicher Tractor Collar                            | 38   | 73182200 | 18% |
| 93478105 | Eicher Tractor Rubber Plug                       | 4    | 87085000 | 18% |
| 93478117 | Eicher Tractor Cotter Pin                        | 2    | 73182400 | 18% |
| 93478129 | Eicher Tractor Plug                              | 8    | 40169360 | 18% |
| 93478142 | Eicher Tractor Friction Disc                     | 20   | 87089900 | 18% |
| 93478154 | Eicher Tractor Cable - Throttle Lever            | 437  | 87089900 | 18% |
| 93478166 | Eicher Tractor Pin, Split                        | 3    | 73182400 | 18% |
| 93478178 | Eicher Tractor Friction Spring                   | 12   | 87085000 | 18% |
| 93478180 | Eicher Tractor Spacer-Parking Brake              | 21   | 73182990 | 18% |
| 93478191 | Eicher Tractor Bolt Hex - (212082040-2500)       | 11   | 73181500 | 18% |
| 93478210 | Eicher Tractor Hsch Screw M8X30                  | 15   | 73181600 | 18% |
| 93478221 | Eicher Tractor Assy. Seal Radiator               | 82   | 87089100 | 18% |
| 93478233 | Eicher Tractor Plug-Inst. Panel                  | 28   | 40169360 | 18% |
| 93478245 | Eicher Tractor Grommet                           | 17   | 40169990 | 18% |
| 93478257 | Eicher Tractor Bolt Knob M6x12                   | 60   | 87089900 | 18% |
| 93478269 | Eicher Tractor Trim Moulding                     | 33   | 40091100 | 18% |
| 93478270 | Eicher Tractor Spacer                            | 23   | 73072200 | 18% |
| 93478294 | Eicher Tractor Bevel Gear, 11                    | 594  | 87085000 | 18% |
| 93478300 | Eicher Tractor Grease Nipple90 Deg               | 53   | 87085000 | 18% |
| 93478312 | Eicher Tractor Dipstick Front Axle               | 241  | 87089900 | 18% |
| 93478324 | Eicher Tractor Cotter Pin                        | 4    | 73182400 | 18% |
| 93478336 | Eicher Tractor Circlip                           | 13   | 73182990 | 18% |
| 93478348 | Eicher Tractor Knob Throttle Control Lever       | 84   | 87089900 | 18% |
| 93478350 | Eicher Tractor Pin,Connect                       | 1150 | 87089900 | 18% |
| 93478361 | Eicher Tractor Plug Magnetic Drain -(C/A)        | 102  | 87085000 | 18% |
| 93478373 | Eicher Tractor Rubber Washer(Pin Hitch)          | 30   | 40169350 | 18% |
| 93478385 | Eicher Tractor Bevel Gear, 16                    | 921  | 87085000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93478415 | Eicher Tractor Double End Socket(17 X 24)          | 421   | 82041210 | 18% |
| 93478427 | Eicher Tractor Handle Socket Spanner               | 165   | 84678990 | 18% |
| 93478439 | Eicher Tractor Abrasion Sticker (Exhaust System)   | 34    | 70199090 | 18% |
| 93478476 | Eicher Tractor Hexagon Socket Head Screw-M8        | 6     | 73181110 | 18% |
| 93478634 | Eicher Tractor Bracket Pc Lever                    | 4071  | 87089900 | 18% |
| 93478671 | Eicher Tractor 13/16-16Unf Lock Nut                | 59    | 73181600 | 18% |
| 93478683 | Eicher Tractor Integrated Qrc With Adaptor         | 848   | 84812000 | 18% |
| 93478830 | Eicher Tractor Hshc Screw M10X25                   | 17    | 73181500 | 18% |
| 93478841 | Eicher Tractor O-Ring - Suction Flange             | 15    | 40091100 | 18% |
| 93478865 | Eicher Tractor Bolt Hex - M10 - 40L                | 15    | 73181110 | 18% |
| 93478889 | Eicher Tractor Hex Head Bolt M6 X 1                | 8     | 73181110 | 18% |
| 93479018 | Eicher Tractor Knob - Fuel Cut Off                 | 52    | 87089900 | 18% |
| 93479020 | Eicher Tractor Shoulder Bolt                       | 11    | 73181500 | 18% |
| 93479031 | Eicher Tractor Cotter Pin                          | 1     | 73182400 | 18% |
| 93479055 | Eicher Tractor Flat Washer                         | 1     | 73182100 | 18% |
| 93479067 | Eicher Tractor Tension Tie Assy - Clutch           | 160   | 87089900 | 18% |
| 93479225 | Eicher Tractor Tube - Recovery Bottle              | 161   | 40091100 | 18% |
| 93479237 | Eicher Tractor Clamp Breather Mtg                  | 57    | 87089900 | 18% |
| 93479250 | Eicher Tractor Grommet                             | 30    | 87089100 | 18% |
| 93479328 | Eicher Tractor Trim Molding                        | 7     | 87089900 | 18% |
| 93479389 | Eicher Tractor Nut                                 | 40    | 73181600 | 18% |
| 93479390 | Eicher Tractor Stud                                | 115   | 73181500 | 18% |
| 93479407 | Eicher Tractor Hex Boltm10X1.5X65L                 | 25    | 73181110 | 18% |
| 93479419 | Eicher Tractor Grommet                             | 5     | 40169330 | 18% |
| 93479432 | Eicher Tractor Battery Cable -Ve - Mf 2605 / 2615  | 469   | 85443000 | 18% |
| 93479444 | Eicher Tractor Bolt Hex-M12X1.75-35L(102124035-250 | 20    | 73181500 | 18% |
| 93479456 | Eicher Tractor J Clip Round Type                   | 18    | 87089900 | 18% |
| 93479468 | Eicher Tractor Bolt Hex(202103055-2500)            | 18    | 73181500 | 18% |
| 93479470 | Eicher Tractor Nut - M10X1.5X8                     | 7     | 73181110 | 18% |
| 93479481 | Eicher Tractor P Clamp - Dia 23                    | 42    | 73079290 | 18% |
| 93479523 | Eicher Tractor Foam-Tank Support                   | 64    | 87089900 | 18% |
| 93479559 | Eicher Tractor Temperature Sensor                  | 314   | 90268010 | 18% |
| 93479560 | Eicher Tractor Pressure Switch                     | 267   | 85361010 | 18% |
| 93479584 | Eicher Tractor Screw Plug                          | 142   | 73181900 | 18% |
| 93479596 | Eicher Tractor O-Ring (Pump Pr. Port Adaptor)      | 15    | 87085000 | 18% |
| 93479602 | Eicher Tractor P Clip                              | 23    | 87089900 | 18% |
| 93479705 | Eicher Tractor Decal Hot Surface                   | 19    | 39199090 | 18% |
| 93479778 | Eicher Tractor Decal - Tlv                         | 7     | 39199090 | 18% |
| 93479827 | Eicher Tractor Comp Disk,Clutch                    | 3133  | 87089300 | 18% |
| 93480010 | Eicher Tractor Grip -Pto                           | 113   | 87089900 | 18% |
| 93480021 | Eicher Tractor Cover 1, Propeller Shaft            | 521   | 87089900 | 18% |
| 93480033 | Eicher Tractor Cover 3-Propeller-Shaft             | 329   | 87089900 | 18% |
| 93480045 | Eicher Tractor Coupling                            | 494   | 87085000 | 18% |
| 93480057 | Eicher Tractor Cover 2-Propeller Shaft             | 892   | 87089900 | 18% |
| 93480069 | Eicher Tractor Assy Power Steering Unit            | 15969 | 87089900 | 18% |
| 93480070 | Eicher Tractor Collar Steering Column Di-J And Eag | 28    | 87089400 | 18% |
| 93480082 | Eicher Tractor Cover Steering Column               | 13    | 87089900 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93480094 | Eicher Tractor Steering Column 284Mm               | 1661  | 87089900 | 18% |
| 93480100 | Eicher Tractor Assy Knob - Range                   | 371   | 87084000 | 18% |
| 93480124 | Eicher Tractor Plate - Engine Mount                | 809   | 73182910 | 18% |
| 93480136 | Eicher Tractor Sealent- Hyd. Pump Assy (Anabond 61 | 32    | 35069999 | 18% |
| 93480150 | Eicher Tractor Fork Clutch Release                 | 983   | 87089300 | 18% |
| 93480161 | Eicher Tractor Split_Pin                           | 1     | 73182400 | 18% |
| 93480173 | Eicher Tractor Assy. Tension Tie Rod-Clutch        | 424   | 87089900 | 18% |
| 93480185 | Eicher Tractor Join_Pin                            | 13    | 73182990 | 18% |
| 93480197 | Eicher Tractor Cover, Pedal                        | 126   | 87085000 | 18% |
| 93480203 | Eicher Tractor Spring                              | 35    | 73202000 | 18% |
| 93480215 | Eicher Tractor Arm High Low Connection             | 963   | 87089900 | 18% |
| 93480227 | Eicher Tractor Pin Clevis                          | 17    | 73182990 | 18% |
| 93480240 | Eicher Tractor Front Axle                          | 2733  | 87085000 | 18% |
| 93480252 | Eicher Tractor Seal, Oil                           | 192   | 87085000 | 18% |
| 93480264 | Eicher Tractor Tie Rod                             | 1995  | 87089900 | 18% |
| 93480276 | Eicher Tractor Steering Cylinder                   | 10047 | 87085000 | 18% |
| 93480290 | Eicher Tractor Assy. Radiator Support              | 1436  | 87089900 | 18% |
| 93480306 | Eicher Tractor Assy Battery Tray                   | 1811  | 87089900 | 18% |
| 93480318 | Eicher Tractor Beading-Firewall                    | 339   | 39269099 | 18% |
| 93480320 | Eicher Tractor Grommet                             | 22    | 40169390 | 18% |
| 93480343 | Eicher Tractor Assy Bracket-Radiator Mounting      | 241   | 87089900 | 18% |
| 93480355 | Eicher Tractor Plug                                | 36    | 87085000 | 18% |
| 93480367 | Eicher Tractor Plug                                | 33    | 87085000 | 18% |
| 93480379 | Eicher Tractor Lower Link-Assy                     | 2559  | 87089900 | 18% |
| 93480409 | Eicher Tractor Top-Link Assy                       | 2917  | 87089900 | 18% |
| 93480410 | Eicher Tractor Pin, Top Link                       | 185   | 73199000 | 18% |
| 93480422 | Eicher Tractor Adj. Lift Rod-Rh                    | 2147  | 87089900 | 18% |
| 93480434 | Eicher Tractor Pin-Lift Arm                        | 383   | 87089900 | 18% |
| 93480446 | Eicher Tractor Assy Chain Stabilizer               | 1065  | 87089900 | 18% |
| 93480458 | Eicher Tractor Linch Assy. 6X45                    | 61    | 87089900 | 18% |
| 93480460 | Eicher Tractor Pin - Lower Link                    | 110   | 73170099 | 18% |
| 93480471 | Eicher Tractor Drawbar                             | 2476  | 87089900 | 18% |
| 93480483 | Eicher Tractor Cotter Pin                          | 4     | 73182400 | 18% |
| 93480495 | Eicher Tractor Mounting Brkt Rh-Lowerlink          | 1280  | 87089900 | 18% |
| 93480501 | Eicher Tractor Mounting Brkt Lh-Lowerlink          | 2052  | 87089900 | 18% |
| 93480513 | Eicher Tractor Assy. Radiator                      | 8309  | 87089100 | 18% |
| 93480525 | Eicher Tractor Foam - Radiator Bottom              | 20    | 87089900 | 18% |
| 93480537 | Eicher Tractor Foam - Radiator Side Sealing        | 31    | 87089900 | 18% |
| 93480549 | Eicher Tractor Beading - Top Sealing Extended      | 45    | 40091100 | 18% |
| 93480550 | Eicher Tractor Hose -Radiator Outlet               | 454   | 40092100 | 18% |
| 93480562 | Eicher Tractor Hose - Radiator Inlet               | 351   | 40092100 | 18% |
| 93480574 | Eicher Tractor Beading-Radiator Top Sealing        | 209   | 39269099 | 18% |
| 93480616 | Eicher Tractor Assy Mtg- Recovery Tank             | 393   | 87089900 | 18% |
| 93480628 | Eicher Tractor Hose Clamp                          | 67    | 73269099 | 18% |
| 93480630 | Eicher Tractor Assy Surge - Tank                   | 554   | 87089900 | 18% |
| 93480641 | Eicher Tractor Ass. Brkt. Electric Feed Pump       | 634   | 87089900 | 18% |
| 93480653 | Eicher Tractor Tube-Radiator To Recovery Tank      | 48    | 40091100 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93480665 | Eicher Tractor Rubber Pad                      | 16   | 84099990 | 28% |
| 93480677 | Eicher Tractor Spring Band Hose Clamp          | 14   | 73269099 | 18% |
| 93480689 | Eicher Tractor Overflow Tube Recovery Bottle   | 69   | 87089900 | 18% |
| 93480719 | Eicher Tractor Assy. Brake Shaft               | 1661 | 87089900 | 18% |
| 93480720 | Eicher Tractor Collar                          | 126  | 40169360 | 18% |
| 93480732 | Eicher Tractor Assy. Brake Tension Rod         | 405  | 87089900 | 18% |
| 93480744 | Eicher Tractor Assy. Brake Tension Rod - Lh    | 499  | 87089900 | 18% |
| 93480756 | Eicher Tractor Assy Lever - Parking Brake      | 201  | 73182910 | 18% |
| 93480770 | Eicher Tractor Grip Parking Brake              | 35   | 87089900 | 18% |
| 93480781 | Eicher Tractor Bush-Parking Brake              | 161  | 87089900 | 18% |
| 93480793 | Eicher Tractor Cushion Step                    | 101  | 40169990 | 18% |
| 93480800 | Eicher Tractor Tension Spring (31)             | 12   | 87083000 | 18% |
| 93480811 | Eicher Tractor Spacer-17X30X8.3                | 224  | 87089900 | 18% |
| 93480823 | Eicher Tractor Slotted Spring Pin Dia 8X40     | 29   | 73209020 | 18% |
| 93480835 | Eicher Tractor Extension Spring - Clutch Pedal | 66   | 73181600 | 18% |
| 93480847 | Eicher Tractor Spacer-17X30X11                 | 196  | 87089900 | 18% |
| 93480859 | Eicher Tractor Pin Clevis                      | 30   | 73182990 | 18% |
| 93480860 | Eicher Tractor Split Pin                       | 1    | 73182400 | 18% |
| 93480872 | Eicher Tractor Circlip                         | 10   | 73209090 | 18% |
| 93480884 | Eicher Tractor Assy Mounting Brkt-Hood Lock Lh | 260  | 87089900 | 18% |
| 93480896 | Eicher Tractor Assy Mounting Brkt-Hood Lock Rh | 324  | 87089900 | 18% |
| 93480938 | Eicher Tractor Beading-Firewall                | 227  | 39269099 | 18% |
| 93480940 | Eicher Tractor Cap - Steering Wheel            | 47   | 87089400 | 18% |
| 93480975 | Eicher Tractor Assy Cover-Bulkhead             | 348  | 87089900 | 18% |
| 93480999 | Eicher Tractor Packing                         | 78   | 87089400 | 18% |
| 93481001 | Eicher Tractor Plate                           | 304  | 87089900 | 18% |
| 93481013 | Eicher Tractor Steering Wheel                  | 1192 | 87089400 | 18% |
| 93481025 | Eicher Tractor Rubber, Cushion                 | 105  | 87089400 | 18% |
| 93481037 | Eicher Tractor Heat Shield - Firewall          | 30   | 87089900 | 18% |
| 93481049 | Eicher Tractor Heat Shield Top - Binnacle      | 24   | 87089900 | 18% |
| 93481050 | Eicher Tractor Heat Shield Bottom - Binnacle   | 15   | 87089900 | 18% |
| 93481062 | Eicher Tractor Assy Hinge Brkt                 | 1583 | 87089900 | 18% |
| 93481074 | Eicher Tractor Assy. Bazel-Head Light          | 891  | 87089900 | 18% |
| 93481086 | Eicher Tractor Grill Front                     | 467  | 87089900 | 18% |
| 93481098 | Eicher Tractor Beading-Bonnet                  | 76   | 40169390 | 18% |
| 93481116 | Eicher Tractor Assy Hood Lock Lh               | 150  | 87089900 | 18% |
| 93481128 | Eicher Tractor Assy Hood Lock Rh               | 150  | 87089900 | 18% |
| 93481130 | Eicher Tractor Beading Side Sealing            | 212  | 39269099 | 18% |
| 93481153 | Eicher Tractor Side Grill                      | 246  | 87089900 | 18% |
| 93481165 | Eicher Tractor Pin -Bonnet Lock                | 81   | 73170099 | 18% |
| 93481177 | Eicher Tractor Lock Pin                        | 5    | 73170099 | 18% |
| 93481189 | Eicher Tractor Rubber Pad-Bonnet               | 20   | 40169390 | 18% |
| 93481190 | Eicher Tractor Handle Lock Assy                | 184  | 87089900 | 18% |
| 93481207 | Eicher Tractor Heat Shield - Bonnet            | 59   | 87089900 | 18% |
| 93481219 | Eicher Tractor Cushion Pad                     | 14   | 40169390 | 18% |
| 93481220 | Eicher Tractor Assy Guide Plate-Pc Lever       | 562  | 87089900 | 18% |
| 93481270 | Eicher Tractor Grip Fender                     | 1399 | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93481293 | Eicher Tractor Rubber Pad-Fender Mtg           | 136  | 40169390 | 18% |
| 93481300 | Eicher Tractor Assy. Front Lamp-Lh             | 470  | 87089900 | 18% |
| 93481311 | Eicher Tractor Assy. Front Lamp-Rh             | 470  | 87089900 | 18% |
| 93481323 | Eicher Tractor Assy. Rear Lamp-Lh              | 729  | 87089900 | 18% |
| 93481335 | Eicher Tractor Assy. Rear Lamp-Rh              | 729  | 87089900 | 18% |
| 93481347 | Eicher Tractor Assy. Worklamp                  | 801  | 85122010 | 18% |
| 93481360 | Eicher Tractor Clip                            | 13   | 73182100 | 18% |
| 93481372 | Eicher Tractor Rubber Pad- Tail Light          | 47   | 87089900 | 18% |
| 93481384 | Eicher Tractor Rubber Pad- Front Light         | 52   | 40169390 | 18% |
| 93481396 | Eicher Tractor Main Wiring Harness             | 9395 | 85443000 | 18% |
| 93481402 | Eicher Tractor Trailer Socket Harness          | 81   | 85443000 | 18% |
| 93481414 | Eicher Tractor Assy Brkt Starter Guard Mtg     | 133  | 87089900 | 18% |
| 93481426 | Eicher Tractor Starter Motor Guard             | 315  | 87089900 | 18% |
| 93481438 | Eicher Tractor Neutral Safety Switch           | 555  | 85365090 | 18% |
| 93481440 | Eicher Tractor Assy. Bracket                   | 187  | 87089900 | 18% |
| 93481451 | Eicher Tractor Preheater-Controller            | 2236 | 85364900 | 18% |
| 93481463 | Eicher Tractor Rubber, Cushion                 | 55   | 87089900 | 18% |
| 93481475 | Eicher Tractor Fuel Level Sensor               | 2462 | 90261020 | 18% |
| 93481487 | Eicher Tractor Trailer Socket 7 Pole           | 229  | 85365090 | 18% |
| 93481499 | Eicher Tractor Electronic Flasher              | 523  | 85369090 | 18% |
| 93481505 | Eicher Tractor Grommet Hand Throttle Lever     | 14   | 87089900 | 18% |
| 93481517 | Eicher Tractor Screw                           | 14   | 73181500 | 18% |
| 93481529 | Eicher Tractor Packing - Guide Lever           | 11   | 87085000 | 18% |
| 93481531 | Eicher Tractor Instrument Cluster              | 3645 | 90292020 | 18% |
| 93481543 | Eicher Tractor Hazard Warning Switch           | 331  | 85365090 | 18% |
| 93481555 | Eicher Tractor Starter Switch With Key Pair    | 683  | 85365090 | 18% |
| 93481567 | Eicher Tractor Assy. Rear View Mirror          | 695  | 70091090 | 18% |
| 93481579 | Eicher Tractor Assy. Combination Switch        | 782  | 87089900 | 18% |
| 93481580 | Eicher Tractor Assy. Platform Lh               | 4894 | 87089900 | 18% |
| 93481592 | Eicher Tractor Assy. Platform Rh               | 4961 | 87089900 | 18% |
| 93481608 | Eicher Tractor Cover Wind Lh                   | 323  | 87089900 | 18% |
| 93481610 | Eicher Tractor Cover, Wind-Rh                  | 298  | 87089900 | 18% |
| 93481633 | Eicher Tractor Assy. Support - Platformrh      | 963  | 87089900 | 18% |
| 93481645 | Eicher Tractor Assy. Rear Support -Platform Lh | 580  | 87089900 | 18% |
| 93481657 | Eicher Tractor Assy. Mtg. Brkt. - Platform     | 841  | 87089900 | 18% |
| 93481669 | Eicher Tractor Assy Platform Mtg - Lh          | 234  | 87089900 | 18% |
| 93481670 | Eicher Tractor Deck Assy                       | 2633 | 87084000 | 18% |
| 93481694 | Eicher Tractor Slide Plate - Tool Box          | 217  | 87089900 | 18% |
| 93481712 | Eicher Tractor Mtg. Brkt. - Bls Switch         | 149  | 87089900 | 18% |
| 93481724 | Eicher Tractor Deck Top Assy                   | 854  | 87089900 | 18% |
| 93481748 | Eicher Tractor Insulator                       | 186  | 39269051 | 18% |
| 93481750 | Eicher Tractor Beading-Deck Lh                 | 41   | 39269099 | 18% |
| 93481761 | Eicher Tractor Beading-Deck Rh                 | 68   | 39269099 | 18% |
| 93481796 | Eicher Tractor Rubber Pad-Fender               | 9    | 40169390 | 18% |
| 93481803 | Eicher Tractor Collar                          | 82   | 73199000 | 18% |
| 93481815 | Eicher Tractor Cap Sealing                     | 116  | 87089900 | 18% |
| 93481827 | Eicher Tractor Pin Split                       | 1    | 73182990 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93481839 | Eicher Tractor Rubber, Cushion                 | 35    | 87089900 | 18% |
| 93481840 | Eicher Tractor Pad-Fuel Tank Mtg               | 42    | 40169390 | 18% |
| 93481852 | Eicher Tractor Rubber, Cushion                 | 101   | 40169990 | 18% |
| 93481888 | Eicher Tractor Tail Pipe - Guard Rear          | 366   | 87089900 | 18% |
| 93481890 | Eicher Tractor Gasket Exhaust                  | 55    | 84841090 | 18% |
| 93481906 | Eicher Tractor Assy. Tail Pipe - Exhaust       | 3157  | 87089900 | 18% |
| 93481918 | Eicher Tractor Heat Sleeve                     | 1441  | 87089900 | 18% |
| 93481920 | Eicher Tractor Muffler Gasket                  | 63    | 87089200 | 18% |
| 93481931 | Eicher Tractor Battery (65Ah)                  | 10165 | 87089900 | 18% |
| 93481943 | Eicher Tractor Assy. Battery Retainer          | 229   | 87085000 | 18% |
| 93481955 | Eicher Tractor Battery Cable - Positive        | 1162  | 85443000 | 18% |
| 93481967 | Eicher Tractor Battery Cable - Negative        | 590   | 85443000 | 18% |
| 93481979 | Eicher Tractor Rod-Battery Retainer            | 46    | 73071900 | 18% |
| 93481980 | Eicher Tractor Assy Air Cleaner                | 3485  | 84212300 | 18% |
| 93481992 | Eicher Tractor Hose-Aircleaner Outlet          | 442   | 40091100 | 18% |
| 93482005 | Eicher Tractor Hose-Aircleaner To Engine       | 1225  | 40091100 | 18% |
| 93482017 | Eicher Tractor Holder, Aircleaner              | 508   | 87089900 | 18% |
| 93482042 | Eicher Tractor Ass. Fuel Tank With Cap         | 11338 | 87089900 | 18% |
| 93482054 | Eicher Tractor Pipe                            | 269   | 40094200 | 18% |
| 93482066 | Eicher Tractor Pipe                            | 782   | 87089900 | 18% |
| 93482078 | Eicher Tractor Tube 3, Fuel                    | 750   | 84099990 | 28% |
| 93482080 | Eicher Tractor Ass. Filter Mtg. Brkt           | 615   | 87089900 | 18% |
| 93482091 | Eicher Tractor Ass Strap                       | 487   | 87089900 | 18% |
| 93482108 | Eicher Tractor Pipe                            | 170   | 40094200 | 18% |
| 93482110 | Eicher Tractor Hose Clip                       | 26    | 73182990 | 18% |
| 93482133 | Eicher Tractor Cover Fuel Sensor               | 39    | 87083000 | 18% |
| 93482169 | Eicher Tractor Draw Bar                        | 3220  | 87089900 | 18% |
| 93482182 | Eicher Tractor Bracket                         | 2741  | 87089900 | 18% |
| 93482194 | Eicher Tractor Assy. Seat (With Spring)        | 7255  | 94012000 | 18% |
| 93482200 | Eicher Tractor Bracket, Towing Hook            | 2402  | 87089900 | 18% |
| 93482212 | Eicher Tractor Pin, Connect                    | 429   | 87089900 | 18% |
| 93482224 | Eicher Tractor Front Wheel - 4Jax12            | 1815  | 87087000 | 18% |
| 93482248 | Eicher Tractor Rear Wheel - W6X18              | 4373  | 87087000 | 18% |
| 93482250 | Eicher Tractor Ass. Slow Moving Vehicle Emblem | 295   | 94056010 | 18% |
| 93482261 | Eicher Tractor Stickerdiff. Lock Pedal         | 15    | 39199090 | 18% |
| 93482273 | Eicher Tractor Decal - Caution                 | 29    | 39199090 | 18% |
| 93482285 | Eicher Tractor Quality Approval Sticker - Sqgs | 3     | 39199090 | 18% |
| 93482297 | Eicher Tractor Label - Caution                 | 15    | 70199090 | 12% |
| 93482303 | Eicher Tractor Label, Warning                  | 15    | 70199090 | 12% |
| 93482315 | Eicher Tractor Label Radiator                  | 16    | 70199090 | 18% |
| 93482327 | Eicher Tractor Label Warning                   | 15    | 70199090 | 18% |
| 93482339 | Eicher Tractor Label, Speed Control            | 4     | 70199090 | 12% |
| 93482352 | Eicher Tractor Label - Position Control        | 17    | 70199090 | 12% |
| 93482364 | Eicher Tractor Label 4Wd                       | 7     | 70199090 | 12% |
| 93482376 | Eicher Tractor Decal Load Details Drawbar      | 10    | 87081010 | 18% |
| 93482388 | Eicher Tractor Label - Sub Speed Lever         | 8     | 70199090 | 18% |
| 93482390 | Eicher Tractor Label - Parking Brake           | 3     | 70199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93482406 | Eicher Tractor Decals Tractor Greasing Points      | 24    | 39199090 | 18% |
| 93482418 | Eicher Tractor Speed Chart-9X3(8.0X18)             | 22    | 49089000 | 12% |
| 93482420 | Eicher Tractor Emblem-Hood Lh                      | 215   | 49089000 | 18% |
| 93482431 | Eicher Tractor Emblem-Hood Rh                      | 215   | 49089000 | 18% |
| 93482443 | Eicher Tractor Emblem-Binnacle Lh                  | 63    | 49089000 | 18% |
| 93482455 | Eicher Tractor Emblem-Binnacle Rh                  | 63    | 49089000 | 18% |
| 93482509 | Eicher Tractor Sticker-Starter Switch              | 5     | 85365090 | 18% |
| 93482510 | Eicher Tractor Hood- Top Link                      | 63    | 73181110 | 18% |
| 93482522 | Eicher Tractor Pto Warning                         | 17    | 70199090 | 12% |
| 93482601 | Eicher Tractor Front Wheel 5Jax12                  | 2132  | 87087000 | 18% |
| 93482613 | Eicher Tractor Rear Rim W7X20                      | 6372  | 87087000 | 18% |
| 93482625 | Eicher Tractor Decal - High Lug Tyre Caution       | 13    | 84212300 | 18% |
| 93482650 | Eicher Tractor Trim Molding                        | 13    | 39269099 | 18% |
| 93482662 | Eicher Tractor Trim Molding                        | 18    | 73182100 | 18% |
| 93482674 | Eicher Tractor Suction Tube-Recovery Tank          | 28    | 39269099 | 18% |
| 93482686 | Eicher Tractor Assy. Sealing Foam - Fes            | 11    | 40169100 | 18% |
| 93482698 | Eicher Tractor Nut                                 | 7     | 87089900 | 18% |
| 93482704 | Eicher Tractor Clamp                               | 70    | 40091100 | 18% |
| 93482716 | Eicher Tractor Sticker Oil Dip Stick               | 4     | 39199090 | 18% |
| 93482741 | Eicher Tractor Decal - Battery Caution             | 20    | 49089000 | 12% |
| 93482753 | Eicher Tractor Tool Kit                            | 451   | 82060090 | 18% |
| 93482789 | Eicher Tractor Decal-Parking Brake                 | 9     | 39199090 | 18% |
| 93483484 | Eicher Tractor Shaft Pto Driving                   | 1487  | 87084000 | 18% |
| 93483509 | Eicher Tractor Gear Pto Driven                     | 5195  | 87084000 | 18% |
| 93484804 | Eicher Tractor Fuel Tank Cap                       | 3306  | 87089900 | 18% |
| 93610056 | Eicher Tractor Gear Housing Rear 241               | 20808 | 87084000 | 18% |
| 93610093 | Eicher Tractor Reverse Gear Assy - 241             | 890   | 87084000 | 18% |
| 93610100 | Eicher Tractor Sliding Gear 1St (Teeth-30)         | 1390  | 87084000 | 18% |
| 93610111 | Eicher Tractor Sliding Gear 2/3 - 241 (Teeth-23)   | 2247  | 87084000 | 18% |
| 93610123 | Eicher Tractor Sliding Gear 4/5-241 (New) (Teeth-  | 985   | 87084000 | 18% |
| 93610135 | Eicher Tractor Constant Mesh Gear - 241 (Teeth-54  | 1509  | 87084000 | 18% |
| 93610147 | Eicher Tractor Cpinion Main Shaft-241(New) (Teet   | 4381  | 87084000 | 18% |
| 93610159 | Eicher Tractor Primary Shaft - 241 (Teeth-17)      | 3985  | 87084000 | 18% |
| 93610240 | Eicher Tractor Gasket For Axle Tube                | 47    | 68129090 | 18% |
| 93610275 | Eicher Tractor Lever Hi/Low                        | 212   | 87084000 | 18% |
| 93610380 | Eicher Tractor Breather Pipe                       | 204   | 87084000 | 18% |
| 93610391 | Eicher Tractor Gear Box Housing Rear (V E)         | 41236 | 87084000 | 18% |
| 93610410 | Eicher Tractor Washer Lock                         | 16    | 73182100 | 18% |
| 93610457 | Eicher Tractor Thrust Plate 2.45 Thick(One Ho      | 220   | 87084000 | 18% |
| 93610469 | Eicher Tractor Thrust Plate 2.55 Thick(Two H       | 304   | 87084000 | 18% |
| 93610470 | Eicher Tractor Thrust Plate 2.65 Thick(Three       | 301   | 87084000 | 18% |
| 93610482 | Eicher Tractor Bearing Sleeve                      | 891   | 84822090 | 18% |
| 93610494 | Eicher Tractor Thrust Plate 2.35 Thick(W/O Hole)   | 231   | 87084000 | 18% |
| 93610550 | Eicher Tractor F D Pinion Assly 485 Z13 Ddb        | 4110  | 87084000 | 18% |
| 93610561 | Eicher Tractor F D Pinion Assly 755 Ddb Z14        | 5613  | 87084000 | 18% |
| 93610605 | Eicher Tractor Cylindrical Roller Bearing Nup 309  | 1249  | 84825011 | 18% |
| 93610615 | Eicher Tractor Pinion Shaft-241 New Model (Teeth-1 | 4382  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93610731 | Eicher Tractor Spur Pinion Ist - 242 Dr3644        | 1030  | 87084000 | 18% |
| 93610780 | Eicher Tractor Rubber Boot                         | 213   | 40169320 | 18% |
| 93610809 | Eicher Tractor Axle Tube Left                      | 10337 | 87084000 | 18% |
| 93610810 | Eicher Tractor Axle Tube Right                     | 10737 | 87084000 | 18% |
| 93610901 | Eicher Tractor Gear Housing Front - 50Hp           | 19714 | 87084000 | 18% |
| 93610998 | Eicher Tractor Pto Engaging Lever                  | 531   | 87084000 | 18% |
| 93611000 | Eicher Tractor Axial Star Pinion 242 Nf            | 1220  | 87084000 | 18% |
| 93611012 | Eicher Tractor Axial Diff. Star Pinion 242 Nf      | 1917  | 87084000 | 18% |
| 93611073 | Eicher Tractor Bearing Spacer                      | 308   | 84822090 | 18% |
| 93611085 | Eicher Tractor Conical Spring                      | 43    | 73202000 | 18% |
| 93611097 | Eicher Tractor Clutch Cover Assly.                 | 2621  | 87089300 | 18% |
| 93611243 | Eicher Tractor Breather Pipe Assy                  | 107   | 87084000 | 18% |
| 93611309 | Eicher Tractor Rear Shaft-242 Nf 17 Teeth          | 10878 | 87084000 | 18% |
| 93611310 | Eicher Tractor Gear Housing Front - 364 New        | 22342 | 87084000 | 18% |
| 93611358 | Eicher Tractor Gear Shift Lever                    | 455   | 87084000 | 18% |
| 93611360 | Eicher Tractor Gear Engaging Lever                 | 510   | 87084000 | 18% |
| 93611425 | Eicher Tractor Thrust Plate 2.25 Thick             | 257   | 87084000 | 18% |
| 93611450 | Eicher Tractor Needle Cage B18X25X22.2             | 89    | 84823000 | 18% |
| 93611462 | Eicher Tractor Reverse Gear Shaft                  | 572   | 87084000 | 18% |
| 93611486 | Eicher Tractor Shifter Fork 3/4                    | 884   | 87084000 | 18% |
| 93611530 | Eicher Tractor Reverse Gear Shaft                  | 311   | 87084000 | 18% |
| 93611565 | Eicher Tractor Rev Gear 241 (Rev Dr)               | 1901  | 87084000 | 18% |
| 93611589 | Eicher Tractor Locking Screw                       | 11    | 73181500 | 18% |
| 93611619 | Eicher Tractor Gear Housing Rear                   | 38249 | 87084000 | 18% |
| 93611620 | Eicher Tractor Shaft Diff Lock                     | 384   | 87084000 | 18% |
| 93611632 | Eicher Tractor Pivot Bolt                          | 86    | 73181500 | 18% |
| 93611644 | Eicher Tractor Lock Plate                          | 171   | 87084000 | 18% |
| 93611670 | Eicher Tractor Driven Disc 11"                     | 2355  | 87089300 | 18% |
| 93611681 | Eicher Tractor Driven Disc 11"                     | 3186  | 87089300 | 18% |
| 93611863 | Eicher Tractor Pin Dowel 10X21.5                   | 28    | 87089900 | 18% |
| 93611966 | Eicher Tractor Rev Gear Assly 241 Dia 30           | 2059  | 87084000 | 18% |
| 93611980 | Eicher Tractor Reverse Gear Shaft                  | 343   | 87084000 | 18% |
| 93611991 | Eicher Tractor Shifter Fork R.G                    | 738   | 87084000 | 18% |
| 93612004 | Eicher Tractor Gear Housing Front                  | 15142 | 87084000 | 18% |
| 93612235 | Eicher Tractor Rubber Boot (241 Oib)               | 230   | 40169320 | 18% |
| 93612314 | Eicher Tractor Diff Lock Pedal                     | 317   | 87085000 | 18% |
| 93612430 | Eicher Tractor Clutch Release Bearing Assly.       | 1770  | 87089300 | 18% |
| 93612442 | Eicher Tractor Sliding Gear 3/4 - 551 - Finishe    | 1757  | 87084000 | 18% |
| 93612454 | Eicher Tractor Spur Pinion 3Rd - 551 - Finished    | 1589  | 87084000 | 18% |
| 93612466 | Eicher Tractor C M Gear - 551 - Finished           | 1831  | 87084000 | 18% |
| 93612478 | Eicher Tractor Primary Shaft Sc - 551 - Finished   | 5251  | 87084000 | 18% |
| 93612480 | Eicher Tractor Primary Shaft - Dc - 551 - Finished | 5112  | 87084000 | 18% |
| 93612491 | Eicher Tractor Shifter Rod 1/2                     | 817   | 87084000 | 18% |
| 93612508 | Eicher Tractor Shifter Rod 3/4                     | 354   | 87084000 | 18% |
| 93612510 | Eicher Tractor Shifter Jaw 3/4                     | 470   | 87084000 | 18% |
| 93612521 | Eicher Tractor Shifter Jaw Rg                      | 439   | 87084000 | 18% |
| 93612533 | Eicher Tractor Gear Hsg Front - 551 - Finished     | 26889 | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93612545 | Eicher Tractor Oil Seal 41X62X11                   | 63    | 40169330 | 18% |
| 93612557 | Eicher Tractor Cm Gear H/L - 551 - Finished        | 2168  | 87084000 | 18% |
| 93612569 | Eicher Tractor Primary Shaft - Dc Dlx              | 3401  | 87084000 | 18% |
| 93612570 | Eicher Tractor Primary Shaft Sc - Dlx              | 5851  | 87084000 | 18% |
| 93612685 | Eicher Tractor Axle Tube Lt                        | 9915  | 87084000 | 18% |
| 93612697 | Eicher Tractor Axle Tube Rt                        | 9915  | 87084000 | 18% |
| 93612703 | Eicher Tractor Rear Axle- 241 Oib - 2703 - Finishe | 5144  | 87084000 | 18% |
| 93612727 | Eicher Tractor Cover Lt & Rt 3 Fd & 1ld (Oib)      | 2007  | 87084000 | 18% |
| 93612740 | Eicher Tractor Oil Dipstick                        | 138   | 87084000 | 18% |
| 93612818 | Eicher Tractor Brake Set 3 Fd & 1ld (Oib)          | 6084  | 87083000 | 18% |
| 93612879 | Eicher Tractor Pto Drive Shaft - Dlx               | 3809  | 87084000 | 18% |
| 93612880 | Eicher Tractor Axle Tube Left                      | 11066 | 87084000 | 18% |
| 93612892 | Eicher Tractor Axle Tube Right                     | 11077 | 87084000 | 18% |
| 93612909 | Eicher Tractor Rear Shaft 241                      | 6706  | 87084000 | 18% |
| 93612922 | Eicher Tractor Gasket For Engine To Fwh            | 204   | 84099941 | 28% |
| 93612934 | Eicher Tractor Flywheel Housing 18Hp (2Wd)         | 13518 | 87084000 | 18% |
| 93612946 | Eicher Tractor Clutch Cover Assembly 7-Inch        | 2327  | 87089300 | 18% |
| 93612958 | Eicher Tractor Clutch Driven Plate 7-Inch          | 1566  | 87089300 | 18% |
| 93612971 | Eicher Tractor Crb Assy (Bearing, Bush, Slide Slee | 1720  | 87089900 | 18% |
| 93612995 | Eicher Tractor Coupling Shaft Assembly             | 875   | 87084000 | 18% |
| 93613045 | Eicher Tractor 2Wd Cover - 18Hp                    | 2475  | 87084000 | 18% |
| 93613057 | Eicher Tractor Gasket 2Wd Cover To Gbh             | 62    | 68129090 | 18% |
| 93613070 | Eicher Tractor Gear Box Hsg (Front & Rear) - 18Hp  | 32100 | 87084000 | 18% |
| 93613094 | Eicher Tractor Gasket For Fwh To Gear Hsg.         | 64    | 68129922 | 18% |
| 93613100 | Eicher Tractor Main Shaft - 18Hp                   | 1613  | 87084000 | 18% |
| 93613112 | Eicher Tractor H/L Cl. Driving Gear (Z33, Z15) - 1 | 1412  | 87084000 | 18% |
| 93613124 | Eicher Tractor Gear 1St Driven (Z32) - 18Hp        | 2074  | 87084000 | 18% |
| 93613136 | Eicher Tractor Gear 2Nd And 3Rd Driven (Z27, Z17)  | 1941  | 87084000 | 18% |
| 93613148 | Eicher Tractor Gear 4Th Driven (Z15) - 18Hp        | 912   | 87084000 | 18% |
| 93613150 | Eicher Tractor Reverse Gear (Z16) - 18Hp           | 963   | 87084000 | 18% |
| 93613161 | Eicher Tractor Reverse Gear Shaft - 18Hp           | 268   | 87084000 | 18% |
| 93613173 | Eicher Tractor Spacer Rev. Gear                    | 50    | 87089900 | 18% |
| 93613185 | Eicher Tractor Spacer Needle Roller Cage           | 41    | 87089900 | 18% |
| 93613197 | Eicher Tractor Cp Shaft (Z-6)                      | 3284  | 87084000 | 18% |
| 93613215 | Eicher Tractor Spacer Cp Shaft                     | 229   | 87089900 | 18% |
| 93613239 | Eicher Tractor Low Gear Driven (Z34) - 18Hp        | 1177  | 87084000 | 18% |
| 93613240 | Eicher Tractor Hi Gear Driven (Z17) - 18Hp         | 752   | 87084000 | 18% |
| 93613252 | Eicher Tractor Gear 1St&2Nd Driving Cl. (Z18,Z23)- | 2499  | 87084000 | 18% |
| 93613264 | Eicher Tractor Gear 3Rd Driving (Z32) - 18Hp       | 1199  | 87084000 | 18% |
| 93613276 | Eicher Tractor Gear 4Th Driving (Z36) - 18Hp       | 898   | 87084000 | 18% |
| 93613288 | Eicher Tractor Spacer 4Th And Cm Driven Gear - 1   | 210   | 85123010 | 18% |
| 93613306 | Eicher Tractor Spacer Cluster - 18Hp               | 225   | 85123010 | 18% |
| 93613320 | Eicher Tractor Crimping Nut                        | 126   | 73181500 | 18% |
| 93613331 | Eicher Tractor Pto Shaft Front - 18Hp              | 1691  | 87084000 | 18% |
| 93613343 | Eicher Tractor Pto Cluster Gear (Z-26,Z-30)        | 1559  | 87084000 | 18% |
| 93613367 | Eicher Tractor Pto Sleeve 3367)-18Hp               | 784   | 87084000 | 18% |
| 93613380 | Eicher Tractor Pto Shaft Rear Cm Driving Gear (Z2  | 1512  | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93613409 | Eicher Tractor Pto Shaft Output 540                 | 1285  | 87084000 | 18% |
| 93613410 | Eicher Tractor Pto Driven Gear (Z-27)               | 1155  | 87084000 | 18% |
| 93613422 | Eicher Tractor Spacer-1 Pto Shaft 540               | 116   | 73182100 | 18% |
| 93613434 | Eicher Tractor Spacer-2 Pto Shaft 540               | 105   | 73182100 | 18% |
| 93613460 | Eicher Tractor Gasket Pto Cover                     | 26    | 68129090 | 18% |
| 93613483 | Eicher Tractor Differential Hsg.                    | 2837  | 87084000 | 18% |
| 93613501 | Eicher Tractor Axial Star Pinion (Asp)              | 963   | 87089900 | 18% |
| 93613525 | Eicher Tractor Thurst Washer (Asp)                  | 37    | 73182100 | 18% |
| 93613537 | Eicher Tractor Differential Shaft 2 Star            | 250   | 87089900 | 18% |
| 93613549 | Eicher Tractor Differential Star Pinion (Dsp)       | 603   | 87089900 | 18% |
| 93613562 | Eicher Tractor Lock Washer Cw                       | 9     | 87089900 | 18% |
| 93613574 | Eicher Tractor Shims For Crown Wheel 0.1 Mm         | 24    | 87089900 | 18% |
| 93613586 | Eicher Tractor Cover Diff. Housing Lh               | 1489  | 87084000 | 18% |
| 93613598 | Eicher Tractor Cover Diff. Housing Rh               | 1667  | 87084000 | 18% |
| 93613604 | Eicher Tractor Fd Pinion Left (Z-13)                | 2004  | 87084000 | 18% |
| 93613628 | Eicher Tractor Fd Pinion Right (Z-13)               | 1557  | 87084000 | 18% |
| 93613653 | Eicher Tractor Axle Housing Left - 18Hp             | 10464 | 87084000 | 18% |
| 93613665 | Eicher Tractor Axle Housing Right - 18Hp            | 10676 | 87084000 | 18% |
| 93613677 | Eicher Tractor Gasket Reduction Housing             | 167   | 68129090 | 18% |
| 93613689 | Eicher Tractor Brake Side Cover Lh/Rh               | 1580  | 87084000 | 18% |
| 93613690 | Eicher Tractor Gasket Brake Cover Lh & Rh           | 25    | 68129090 | 18% |
| 93613707 | Eicher Tractor Brake Set Rh/Lh                      | 3549  | 87083000 | 18% |
| 93613720 | Eicher Tractor Bull Gear (Z83) - 18Hp               | 4156  | 87084000 | 18% |
| 93613732 | Eicher Tractor Spacer Bull Gear                     | 128   | 87084000 | 18% |
| 93613768 | Eicher Tractor Gasket Top Cover                     | 55    | 68129090 | 18% |
| 93613781 | Eicher Tractor Shifter Rod 1St & Reverse            | 223   | 87089900 | 18% |
| 93613793 | Eicher Tractor Shifter Rod 2Nd & 3Rd                | 284   | 87089900 | 18% |
| 93613800 | Eicher Tractor Shifter Rod 4Th                      | 304   | 87089900 | 18% |
| 93613835 | Eicher Tractor Shifter Fork 1/Reverse               | 578   | 87084000 | 18% |
| 93613847 | Eicher Tractor Shifter Fork 2/3                     | 446   | 87084000 | 18% |
| 93613859 | Eicher Tractor Shifter Fork 4                       | 401   | 87084000 | 18% |
| 93613872 | Eicher Tractor Jaw 4Th                              | 437   | 87084000 | 18% |
| 93614116 | Eicher Tractor Sliding Piece                        | 165   | 87084000 | 18% |
| 93614141 | Eicher Tractor Pin For Coupling Fork                | 25    | 73269099 | 18% |
| 93614165 | Eicher Tractor Deep Groove Ball 6205Z-Nbc/Equi.     | 300   | 84822090 | 18% |
| 93614189 | Eicher Tractor Needle Roller & Cage Assy-K15X21X15  | 144   | 84824000 | 18% |
| 93614190 | Eicher Tractor Sapcer Nrb                           | 72    | 87089900 | 18% |
| 93614207 | Eicher Tractor Needle Roller & Cage Assy. - K18X24X | 99    | 84824000 | 18% |
| 93614219 | Eicher Tractor Taper Roller Brg 32006 Nbc/Equi.     | 682   | 84822090 | 18% |
| 93614220 | Eicher Tractor Circlip A-28 Light-3075.1.1986       | 11    | 73182910 | 18% |
| 93614232 | Eicher Tractor Thrust Spacer                        | 62    | 87089900 | 18% |
| 93614244 | Eicher Tractor Taper Roller Brg Tt25571 (Turbo)     | 643   | 84822090 | 18% |
| 93614256 | Eicher Tractor Needel Roller And Cage Assy- K-25X3  | 158   | 84824000 | 18% |
| 93614300 | Eicher Tractor Deep Groove Ball 6304-Nbc/Equi.      | 300   | 84822090 | 18% |
| 93614335 | Eicher Tractor Sealing Washer For Dipstick          | 9     | 76161000 | 18% |
| 93614359 | Eicher Tractor Pto Cover                            | 1909  | 87084000 | 18% |
| 93614360 | Eicher Tractor Deep Groove Ball Brg.6206Znr-Nbc/Eq  | 501   | 84822090 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93614372 | Eicher Tractor Conical Washer (Dsp)                | 36    | 73182100 | 18% |
| 93614396 | Eicher Tractor Deep Groove Ball Brg 6010           | 675   | 84822090 | 18% |
| 93614402 | Eicher Tractor Hex Bolt M10X105,B8.8,Zp,           | 32    | 73181500 | 18% |
| 93614438 | Eicher Tractor Deep Groove Ball Brg 63/28-Nbc/Equi | 758   | 84822090 | 18% |
| 93614440 | Eicher Tractor Circlip B-68 Light-3075.1.1986      | 37    | 73182910 | 18% |
| 93614451 | Eicher Tractor Sealing Cup Dia 15 Din443           | 6     | 87089900 | 18% |
| 93614700 | Eicher Tractor Shims For Crown Wheel 0.2 Mm        | 26    | 87089900 | 18% |
| 93614712 | Eicher Tractor Shims For Crown Wheel 0.3Mm         | 30    | 87089900 | 18% |
| 93614724 | Eicher Tractor Shims For Crown Wheel 0.5Mm         | 32    | 87089900 | 18% |
| 93614736 | Eicher Tractor Shims For Crown Wheel 1 Mm          | 58    | 87089900 | 18% |
| 93614773 | Eicher Tractor Clutch Cover Assy 11"               | 4405  | 87089300 | 18% |
| 93614797 | Eicher Tractor Diff. Hsg. Assy                     | 6665  | 87084000 | 18% |
| 93614803 | Eicher Tractor Flange Screw M12X1.75X35 (B-10.9)   | 28    | 73181500 | 18% |
| 93614815 | Eicher Tractor Shims 0.5 - Md Setting              | 8     | 87089900 | 18% |
| 93614827 | Eicher Tractor Shims 0.3 - Md Setting              | 11    | 87089900 | 18% |
| 93614839 | Eicher Tractor Shims 0.1 - Md Setting              | 6     | 87089900 | 18% |
| 93614852 | Eicher Tractor Shims 0.2 - Md Setting              | 6     | 87089900 | 18% |
| 93614943 | Eicher Tractor 4Wd Cover - 18Hp                    | 2219  | 87084000 | 18% |
| 93614967 | Eicher Tractor Pto Shaft Front-4Wd                 | 794   | 87084000 | 18% |
| 93614979 | Eicher Tractor 4Wd Pinion Z-15T                    | 943   | 87084000 | 18% |
| 93614980 | Eicher Tractor 4Wd Gear Z-32T                      | 1728  | 87084000 | 18% |
| 93615005 | Eicher Tractor Cp Shaft (Z-6)-4Wd                  | 4289  | 73182100 | 18% |
| 93615078 | Eicher Tractor Fork-4Wd Pinion                     | 993   | 87084000 | 18% |
| 93615091 | Eicher Tractor Felt Ring                           | 23    | 59113120 | 18% |
| 93615108 | Eicher Tractor L-Shape Link                        | 183   | 87084000 | 18% |
| 93615110 | Eicher Tractor Main Link                           | 119   | 87084000 | 18% |
| 93615121 | Eicher Tractor Pin Dia10X19                        | 102   | 73182100 | 18% |
| 93615133 | Eicher Tractor Support Bracket                     | 208   | 87089900 | 18% |
| 93615169 | Eicher Tractor Flywheel Housing 4Wd                | 16783 | 87084000 | 18% |
| 93615170 | Eicher Tractor Propeller Shaft                     | 943   | 87084000 | 18% |
| 93615182 | Eicher Tractor Universal Joint                     | 2492  | 85030010 | 18% |
| 93615248 | Eicher Tractor Oil Seal 52*72*10                   | 386   | 40169330 | 18% |
| 93615376 | Eicher Tractor Cp Shaft Front Axle 4Wd             | 1766  | 73182100 | 18% |
| 93615406 | Eicher Tractor Diff Shaft 3 Star                   | 927   | 87084000 | 18% |
| 93615546 | Eicher Tractor Rear Axle Shaft                     | 5954  | 87089900 | 18% |
| 93615728 | Eicher Tractor Actuator Assy                       | 3160  | 87083000 | 18% |
| 93615832 | Eicher Tractor Friction Disc                       | 1038  | 87083000 | 18% |
| 93615844 | Eicher Tractor Steel Plate                         | 453   | 87089900 | 18% |
| 93615947 | Eicher Tractor Rear Axle                           | 5851  | 87084000 | 18% |
| 93616046 | Eicher Tractor Friction Disc                       | 426   | 87083000 | 18% |
| 93616058 | Eicher Tractor Steel Disc                          | 212   | 87084000 | 18% |
| 93616300 | Eicher Tractor Pindle And Guide Assembly           | 2395  | 87089900 | 18% |
| 93616411 | Eicher Tractor G1 Top Cover                        | 6109  | 87084000 | 18% |
| 93616426 | Eicher Tractor Gasket Shifter Housing              | 15    | 68129090 | 18% |
| 93616435 | Eicher Tractor Cover Shifter Housing               | 87    | 87089900 | 18% |
| 93616447 | Eicher Tractor Pin Gs Lever                        | 21    | 87089900 | 18% |
| 93616459 | Eicher Tractor Stopper Gs Lever                    | 36    | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93616460 | Eicher Tractor Gate Selector                       | 1243  | 87089900 | 18% |
| 93616472 | Eicher Tractor Gs Selector Rod                     | 308   | 87089900 | 18% |
| 93616484 | Eicher Tractor Selector Lever                      | 1068  | 87084000 | 18% |
| 93616493 | Eicher Tractor Shifter Housing                     | 3827  | 87089900 | 18% |
| 93616502 | Eicher Tractor Dowel Bolt M8X25                    | 31    | 73181500 | 18% |
| 93616514 | Eicher Tractor Flange Screw M6X1X16                | 7     | 73181500 | 18% |
| 93616538 | Eicher Tractor Knob For Gs Lever                   | 120   | 87089900 | 18% |
| 93616617 | Eicher Tractor Hi-Low Actuator Assy.               | 334   | 87084000 | 18% |
| 93616630 | Eicher Tractor Pto Link                            | 229   | 87089900 | 18% |
| 93616642 | Eicher Tractor Pto Lever                           | 449   | 87089900 | 18% |
| 93616654 | Eicher Tractor Brake Linkage Assy.                 | 169   | 87089900 | 18% |
| 93616666 | Eicher Tractor Pto Knob                            | 109   | 87084000 | 18% |
| 93616678 | Eicher Tractor Pin Pto Link                        | 67    | 87089900 | 18% |
| 93616691 | Eicher Tractor Deep Groove Ball Bearing 62/28      | 619   | 84822090 | 18% |
| 93616708 | Eicher Tractor Spacer For Pto Cm Gear              | 142   | 73182100 | 18% |
| 93616710 | Eicher Tractor Wiper Oil Seal 35X47X7              | 648   | 40169330 | 18% |
| 93616721 | Eicher Tractor Actuator Assy. For Pto              | 271   | 87084000 | 18% |
| 93616733 | Eicher Tractor High Low Lever Assy.                | 552   | 87089900 | 18% |
| 93616745 | Eicher Tractor High Low Bush Assy.                 | 195   | 87089900 | 18% |
| 93616757 | Eicher Tractor Gear Housing Rear Machine           | 54424 | 87084000 | 18% |
| 93616794 | Eicher Tractor Pto Shaft Rear (6794)-18Hp          | 1150  | 87084000 | 18% |
| 93616800 | Eicher Tractor Primary Shaft Z16 (6800)-18Hp       | 3122  | 87084000 | 18% |
| 93616812 | Eicher Tractor C M Gear - Z30 - 18Hp               | 1995  | 87084000 | 18% |
| 93616824 | Eicher Tractor O-Ring 14X1.78 Nbr N70 -(Orar00015) | 35    | 40169320 | 18% |
| 93616873 | Eicher Tractor Lock Nut M35X1.5 (Km-7 Skf)         | 106   | 73181500 | 18% |
| 93616885 | Eicher Tractor Lock Washer                         | 20    | 87089900 | 18% |
| 93616903 | Eicher Tractor Spacer Cluster - 18Hp - 3.7 Mm      | 227   | 85123010 | 18% |
| 93616915 | Eicher Tractor Spacer Cluster - 18Hp - 3.9 Mm      | 227   | 85123010 | 18% |
| 93616927 | Eicher Tractor Spacer Cluster - 18Hp - 4.1 Mm      | 813   | 85123010 | 18% |
| 93616976 | Eicher Tractor Gasket G1 G2 (242)                  | 75    | 68129090 | 18% |
| 93616988 | Eicher Tractor Gasket For G1 Top Cover Ft.         | 74    | 68129090 | 18% |
| 93617014 | Eicher Tractor Housing Cover Front                 | 1994  | 87084000 | 18% |
| 93617026 | Eicher Tractor Gear Shift Lever                    | 536   | 87084000 | 18% |
| 93617076 | Eicher Tractor Gasket For Axle Tube                | 77    | 68129090 | 18% |
| 93617088 | Eicher Tractor Gear Housing Rear 241 - 708         | 21698 | 87084000 | 18% |
| 93617090 | Eicher Tractor Gear Housing Rear 242 -7090         | 21487 | 87084000 | 18% |
| 93617129 | Eicher Tractor Gasket G1 & G2                      | 114   | 68129090 | 18% |
| 93617130 | Eicher Tractor Gasket Front Cover                  | 61    | 68129090 | 18% |
| 93617142 | Eicher Tractor 4Wd Operating Lever - 4Wd           | 380   | 87089900 | 18% |
| 93617166 | Eicher Tractor Channel Support Bracket             | 647   | 87089900 | 18% |
| 93617178 | Eicher Tractor 4Wd Lever Fork - 4Wd                | 315   | 87084000 | 18% |
| 93617197 | Eicher Tractor Pin Dia10X27                        | 116   | 73182100 | 18% |
| 93617208 | Eicher Tractor Pto Lock Plate                      | 571   | 87089900 | 18% |
| 93617210 | Eicher Tractor Hi Low Lock Plate                   | 668   | 87089900 | 18% |
| 93617269 | Eicher Tractor Actuator Hi-Low                     | 669   | 87084000 | 18% |
| 93617270 | Eicher Tractor Shifter Fork Hi-Low                 | 412   | 87084000 | 18% |
| 93617282 | Eicher Tractor Actuator-Pto                        | 575   | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93617294 | Eicher Tractor Shifter Fork Pto                 | 342   | 87084000 | 18% |
| 93617300 | Eicher Tractor Nave Hi-Low                      | 427   | 87084000 | 18% |
| 93617312 | Eicher Tractor Nave Pto                         | 532   | 87084000 | 18% |
| 93617348 | Eicher Tractor Mud Cover                        | 45    | 87084000 | 18% |
| 93617373 | Eicher Tractor Transmission Housing Rear        | 45008 | 87084000 | 18% |
| 93617385 | Eicher Tractor Transmission Housing Rear (Exp)  | 41362 | 87084000 | 18% |
| 93617452 | Eicher Tractor Flange Screw M8X1.25X20          | 11    | 73181500 | 18% |
| 93617490 | Eicher Tractor Selector Fork Dowel (4Wd)        | 119   | 73182100 | 18% |
| 93617506 | Eicher Tractor Gear Housing Rear (241)-7506     | 21842 | 87084000 | 18% |
| 93617518 | Eicher Tractor Gear Housing Rear (241 Oib)-7518 | 20802 | 87084000 | 18% |
| 93617520 | Eicher Tractor Gasket For Engine To Fwh         | 1111  | 68129922 | 18% |
| 93617531 | Eicher Tractor Selector Cover-4Wd               | 1188  | 87084000 | 18% |
| 93617543 | Eicher Tractor O-Ring 8.9X1.8 Nbr Shore 70      | 43    | 40169990 | 18% |
| 93617567 | Eicher Tractor Selector Fork-4Wd                | 988   | 73259999 | 18% |
| 93617579 | Eicher Tractor Selector Lever-4Wd               | 660   | 73259999 | 18% |
| 93617634 | Eicher Tractor Gasket-Selector Cover (4Wd)      | 11    | 68129090 | 18% |
| 93617658 | Eicher Tractor Sticker -4Wd 188                 | 11    | 39199090 | 18% |
| 93617671 | Eicher Tractor Fork-4Wd Pinion (Ic) - 4Wd       | 1232  | 87084000 | 18% |
| 93617920 | Eicher Tractor Gear Housing Rear (242 Oib)      | 21487 | 87084000 | 18% |
| 93617956 | Eicher Tractor Gasket G1 G2                     | 120   | 68129090 | 18% |
| 93618158 | Eicher Tractor Rear Shaft                       | 5848  | 87084000 | 18% |
| 93618225 | Eicher Tractor Gear Housing Rear (Dlx)          | 58161 | 87084000 | 18% |
| 93618237 | Eicher Tractor Spacer Thk 2Mm                   | 279   | 73182100 | 18% |
| 93618365 | Eicher Tractor Clutch Cover Assy                | 5000  | 87089300 | 18% |
| 93618377 | Eicher Tractor Driven Disc Assy.                | 2247  | 87089300 | 18% |
| 93618481 | Eicher Tractor Taper Roller Bearing N1449Xa     | 725   | 84822011 | 18% |
| 93618523 | Eicher Tractor Deep Groove Ball Bearing 6207    | 532   | 84821011 | 18% |
| 93618535 | Eicher Tractor Deep Groove Ball Bearing 6209    | 676   | 84821011 | 18% |
| 93618572 | Eicher Tractor Stub Axle Housing                | 3359  | 87085000 | 18% |
| 93618584 | Eicher Tractor Pivot Housing                    | 2535  | 87084000 | 18% |
| 93618596 | Eicher Tractor Bottom Cover                     | 588   | 87084000 | 18% |
| 93618602 | Eicher Tractor Arm Holder                       | 766   | 87089400 | 18% |
| 93618614 | Eicher Tractor M8 × 20 Flang Bolt               | 13    | 73181500 | 18% |
| 93618626 | Eicher Tractor M8 × 20 Hex Bolt                 | 10    | 73181500 | 18% |
| 93618638 | Eicher Tractor M8 Spring Washer                 | 5     | 73182990 | 18% |
| 93618640 | Eicher Tractor Idler Shaft                      | 967   | 84099941 | 28% |
| 93618651 | Eicher Tractor 15T Gear                         | 1181  | 87084000 | 18% |
| 93618663 | Eicher Tractor 14T Gear                         | 1243  | 87084000 | 18% |
| 93618675 | Eicher Tractor Taper Roller Bearing             | 725   | 84822011 | 18% |
| 93618687 | Eicher Tractor Oil Seal                         | 217   | 40169330 | 18% |
| 93618699 | Eicher Tractor Gasket C/H                       | 52    | 68129090 | 18% |
| 93618705 | Eicher Tractor Wheel Hub                        | 3183  | 87087000 | 18% |
| 93618717 | Eicher Tractor Case Holder Bearing              | 1454  | 84821011 | 18% |
| 93618729 | Eicher Tractor Oil Seal                         | 88    | 40169330 | 18% |
| 93618730 | Eicher Tractor Ball Bearing                     | 906   | 84821012 | 18% |
| 93618742 | Eicher Tractor Ball Bearing                     | 409   | 84821012 | 18% |
| 93618754 | Eicher Tractor Spacer                           | 47    | 73182100 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93618766 | Eicher Tractor Circlip Dia 30                  | 41    | 73182910 | 18% |
| 93618778 | Eicher Tractor Circlip Dia 62                  | 88    | 73182910 | 18% |
| 93618780 | Eicher Tractor 29T Gear                        | 3869  | 87084000 | 18% |
| 93618791 | Eicher Tractor Gasket H/B                      | 62    | 68129090 | 18% |
| 93618808 | Eicher Tractor Oringdia 65                     | 21    | 40169320 | 18% |
| 93618870 | Eicher Tractor V-Ring Guard                    | 28    | 87089900 | 18% |
| 93618912 | Eicher Tractor Sintered Bush                   | 421   | 87089900 | 18% |
| 93618924 | Eicher Tractor Sub Transmission Shaft          | 1282  | 87089900 | 18% |
| 93618936 | Eicher Tractor Circlip Dia 25                  | 79    | 73182910 | 18% |
| 93618948 | Eicher Tractor Ball Bearing (Ds)               | 452   | 84821011 | 18% |
| 93619047 | Eicher Tractor Reduction Housing Left          | 11827 | 87084000 | 18% |
| 93619059 | Eicher Tractor Reduction Housing Right         | 12210 | 87084000 | 18% |
| 93619163 | Eicher Tractor Gasket For Top Cover            | 87    | 68129090 | 18% |
| 93619215 | Eicher Tractor Spacer Thickness 1.5            | 107   | 73182100 | 18% |
| 93619227 | Eicher Tractor Spacer Thickness 1.65           | 107   | 73182100 | 18% |
| 93619239 | Eicher Tractor Spacer Thickness 1.8            | 107   | 73182100 | 18% |
| 93619240 | Eicher Tractor Spacer Thickness 1.95           | 107   | 73182100 | 18% |
| 93619252 | Eicher Tractor Spacer Thickness 2.1            | 107   | 73182100 | 18% |
| 93619264 | Eicher Tractor Spacer Thickness 2.25           | 107   | 73182100 | 18% |
| 93619276 | Eicher Tractor Spacer Thickness 2.4            | 107   | 73182100 | 18% |
| 93619288 | Eicher Tractor Spacer Thickness 2.55           | 107   | 73182100 | 18% |
| 93619290 | Eicher Tractor Spacer Thickness 2.7            | 107   | 73182100 | 18% |
| 93619308 | Eicher Tractor Spacer Thickness 2.85           | 107   | 73182100 | 18% |
| 93619310 | Eicher Tractor Spacer Thickness 3.0            | 107   | 73182100 | 18% |
| 93619321 | Eicher Tractor Spacer Thickness 3.15           | 107   | 73182100 | 18% |
| 93619333 | Eicher Tractor Spacer Thickness 3.3            | 107   | 73182100 | 18% |
| 93619345 | Eicher Tractor Spacer Thickness 3.45           | 107   | 73182100 | 18% |
| 93619357 | Eicher Tractor Spacer Thickness 3.6            | 107   | 73182100 | 18% |
| 93619369 | Eicher Tractor Spacer Thickness 3.75           | 107   | 73182100 | 18% |
| 93619370 | Eicher Tractor Spacer Thickness 3.9            | 107   | 73182100 | 18% |
| 93619382 | Eicher Tractor Spacer Thickness 4.05           | 107   | 73182100 | 18% |
| 93619394 | Eicher Tractor Spacer Thickness 4.2            | 107   | 73182100 | 18% |
| 93619401 | Eicher Tractor Spacer Thickness 4.35           | 107   | 73182100 | 18% |
| 93619710 | Eicher Tractor Tension Spring                  | 22    | 73202000 | 18% |
| 93620013 | Eicher Tractor Axial Diff. Star Pinion         | 1461  | 87084000 | 18% |
| 93620020 | Eicher Tractor Reverse Gear Contant            | 2047  | 87084000 | 18% |
| 93620025 | Eicher Tractor Axial Star Pinion               | 1243  | 87084000 | 18% |
| 93620037 | Eicher Tractor Diff. Star Pinion               | 814   | 87084000 | 18% |
| 93620256 | Eicher Tractor Plate For Pto Redn. Unit        | 457   | 87084000 | 18% |
| 93620566 | Eicher Tractor Sliding Gear 1/2 (Teeth-35/36)  | 3392  | 87084000 | 18% |
| 93620578 | Eicher Tractor Spur Pinion I St (Teeth-23)     | 1143  | 87084000 | 18% |
| 93620785 | Eicher Tractor Window Cover                    | 194   | 87084000 | 18% |
| 93620815 | Eicher Tractor Oil Seal Hsg.                   | 870   | 40169330 | 18% |
| 93620827 | Eicher Tractor Gear Box Housing (V.E.)         | 37129 | 87084000 | 18% |
| 93620890 | Eicher Tractor Reverse Gear Sliding (Teeth-20) | 403   | 87084000 | 18% |
| 93620931 | Eicher Tractor Reverse Gear Sliding            | 1072  | 87084000 | 18% |
| 93620943 | Eicher Tractor Reverse Gear Fork               | 496   | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93620955 | Eicher Tractor Reverse Gear Shaft                 | 173   | 87084000 | 18% |
| 93620967 | Eicher Tractor Shifter Rod Reverse Gear           | 170   | 87084000 | 18% |
| 93621005 | Eicher Tractor Plastic Float                      | 651   | 39021000 | 18% |
| 93621108 | Eicher Tractor Spacer Nrb 25X30X20                | 43    | 73182100 | 18% |
| 93621121 | Eicher Tractor Knob Hi/Low                        | 108   | 87084000 | 18% |
| 93621133 | Eicher Tractor Knob Gs Lever                      | 124   | 87089900 | 18% |
| 93621169 | Eicher Tractor Pto Lever                          | 119   | 87084000 | 18% |
| 93621418 | Eicher Tractor Final Drive Gear (Z57)             | 11065 | 87084000 | 18% |
| 93621467 | Eicher Tractor Spur Pinion 1St                    | 1884  | 87084000 | 18% |
| 93621479 | Eicher Tractor Spur Pinion 2Nd                    | 2354  | 87084000 | 18% |
| 93621480 | Eicher Tractor C M Gear Hi/Lo                     | 3443  | 87084000 | 18% |
| 93621492 | Eicher Tractor Spur Gear 3Rd                      | 2684  | 87084000 | 18% |
| 93621510 | Eicher Tractor Cm Gear                            | 3299  | 87084000 | 18% |
| 93621522 | Eicher Tractor Primary Shaft                      | 14123 | 87084000 | 18% |
| 93621534 | Eicher Tractor Intermediate Shaft                 | 14743 | 87084000 | 18% |
| 93621546 | Eicher Tractor Lay Shaft Front- Nol Spline-24     | 2347  | 87084000 | 18% |
| 93621558 | Eicher Tractor Lay Shaft Rear - 50Hp Spline -24/2 | 3244  | 87084000 | 18% |
| 93621560 | Eicher Tractor C M Gear 1st                       | 4414  | 87084000 | 18% |
| 93621571 | Eicher Tractor C M Gear 2Nd                       | 2952  | 87084000 | 18% |
| 93621583 | Eicher Tractor Spur Pinion Hi/Lo                  | 2553  | 87084000 | 18% |
| 93621613 | Eicher Tractor C M Gear 3Rd                       | 2364  | 87084000 | 18% |
| 93621625 | Eicher Tractor Spur Gear Hi/Lo                    | 4252  | 87084000 | 18% |
| 93621730 | Eicher Tractor Reverse Gear 1St                   | 1966  | 87084000 | 18% |
| 93621741 | Eicher Tractor Reverse Gear 2Nd                   | 2253  | 87084000 | 18% |
| 93621789 | Eicher Tractor Pto Shaft Front - 50Hp Spline -10/ | 3609  | 87084000 | 18% |
| 93621820 | Eicher Tractor Slide Sleeve                       | 758   | 87084000 | 18% |
| 93621856 | Eicher Tractor Tension Spring                     | 18    | 73202000 | 18% |
| 93621870 | Eicher Tractor Pto Drive Shaft 755 Finished (Teet | 4463  | 87084000 | 18% |
| 93621911 | Eicher Tractor Double Clutch (A2 028P1300)        | 23584 | 87089300 | 18% |
| 93621960 | Eicher Tractor Bearing Sleeve - Md                | 549   | 84822090 | 18% |
| 93622010 | Eicher Tractor Spacer                             | 152   | 73182100 | 18% |
| 93622034 | Eicher Tractor Synchro Assy 1/2                   | 16468 | 87084000 | 18% |
| 93622046 | Eicher Tractor Synchro Assy 3/4                   | 11930 | 87084000 | 18% |
| 93622058 | Eicher Tractor Synchro Assy Hi/Lo                 | 8543  | 87084000 | 18% |
| 93622083 | Eicher Tractor Spacer Bush                        | 752   | 87089400 | 18% |
| 93622095 | Eicher Tractor Reverse Gear Sleeve -755 Finished  | 1831  | 87084000 | 18% |
| 93622137 | Eicher Tractor Spacer Cp Shaft (T-17.45)          | 272   | 73182100 | 18% |
| 93622174 | Eicher Tractor Spacer Cp Shaft (T-18.05)          | 256   | 73182100 | 18% |
| 93622198 | Eicher Tractor Spacer For Lay Shaft               | 202   | 73182100 | 18% |
| 93622216 | Eicher Tractor Spacer Spur Pinion Hi-Low          | 131   | 73182100 | 18% |
| 93622307 | Eicher Tractor Spacer Cp Shaft (T-18.65)          | 272   | 73182100 | 18% |
| 93622447 | Eicher Tractor Lower Cover                        | 166   | 87084000 | 18% |
| 93622460 | Eicher Tractor Nave Assy                          | 370   | 87084000 | 18% |
| 93622514 | Eicher Tractor Brake Housing Lt.                  | 3237  | 87083000 | 18% |
| 93622526 | Eicher Tractor Brake Cover Lt.                    | 2248  | 87083000 | 18% |
| 93622540 | Eicher Tractor F D Pinion Assy                    | 4387  | 87084000 | 18% |
| 93622575 | Eicher Tractor Brake Cover Rt                     | 2251  | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93622605 | Eicher Tractor Oil Seal 65X90X10 Type'A'(Int.W/116 | 120   | 40169990 | 18% |
| 93622836 | Eicher Tractor Support Hub                         | 824   | 87084000 | 18% |
| 93622861 | Eicher Tractor Assy. Lever Pto                     | 434   | 87084000 | 18% |
| 93622897 | Eicher Tractor Pin For Pto Lever                   | 9     | 73182100 | 18% |
| 93622915 | Eicher Tractor Crimping Nut                        | 156   | 73181500 | 18% |
| 93623002 | Eicher Tractor Threaded Plug                       | 17    | 87084000 | 18% |
| 93623051 | Eicher Tractor Spacer Rear                         | 245   | 73182100 | 18% |
| 93623075 | Eicher Tractor Shim For Primary Shaft T=2.8        | 114   | 73182100 | 18% |
| 93623208 | Eicher Tractor Spacer For G2 13.15 Thick           | 169   | 73182100 | 18% |
| 93623210 | Eicher Tractor Spacer For G2 13.30 Thick           | 146   | 73182100 | 18% |
| 93623221 | Eicher Tractor Spacer For G2 13.45 Thick           | 146   | 73182100 | 18% |
| 93623233 | Eicher Tractor Spacer For G2 13.60 Thick           | 154   | 73182100 | 18% |
| 93623348 | Eicher Tractor Pto Shaft Assembly                  | 2493  | 87084000 | 18% |
| 93623350 | Eicher Tractor Gear Housing Rear(Pto Strengthen)   | 40701 | 87084000 | 18% |
| 93623439 | Eicher Tractor Shifter Rod 1/2                     | 249   | 87084000 | 18% |
| 93623464 | Eicher Tractor Shifter Fork 1/2                    | 702   | 87084000 | 18% |
| 93623476 | Eicher Tractor Shifter Fork 3/4                    | 937   | 87084000 | 18% |
| 93623518 | Eicher Tractor Oil Seal Housing                    | 618   | 40169330 | 18% |
| 93623579 | Eicher Tractor 9 1/4" Driven Disc With Valeo Linin | 1673  | 87089300 | 18% |
| 93623592 | Eicher Tractor Shifter Fork Rg - Nol               | 1000  | 87084000 | 18% |
| 93623609 | Eicher Tractor Sliding Gear 1/2                    | 2806  | 87084000 | 18% |
| 93623830 | Eicher Tractor Gear Hsg Rear Sdi (With Bottom Hol  | 41786 | 87084000 | 18% |
| 93623853 | Eicher Tractor Felt Ring                           | 36    | 87084000 | 18% |
| 93623944 | Eicher Tractor Engaging Dog                        | 382   | 87084000 | 18% |
| 93623956 | Eicher Tractor Guide Bush                          | 868   | 87089400 | 18% |
| 93623968 | Eicher Tractor P T O Nave                          | 213   | 87084000 | 18% |
| 93624110 | Eicher Tractor Axial Star Pinion                   | 1366  | 87084000 | 18% |
| 93624122 | Eicher Tractor Axial Diff. Star Pinion             | 2180  | 87084000 | 18% |
| 93624160 | Eicher Tractor Thrust Plate (Asp/Dsp) 2.6 Thick    | 300   | 87084000 | 18% |
| 93624183 | Eicher Tractor C M Gear                            | 1585  | 87084000 | 18% |
| 93624195 | Eicher Tractor Lay Shaft Front - 50Hp (Teeth-22)   | 3293  | 87084000 | 18% |
| 93624201 | Eicher Tractor Spur Gear 2Nd - 50Hp (Teeth-32)     | 971   | 87084000 | 18% |
| 93624225 | Eicher Tractor Spur Pinion Hi-Lo - 50Hp (Teeth-27) | 1596  | 87084000 | 18% |
| 93624237 | Eicher Tractor C M Gear Hi-Low - 50Hp (Teeth-45)   | 1802  | 87084000 | 18% |
| 93624249 | Eicher Tractor Pull Rod                            | 270   | 87089900 | 18% |
| 93624250 | Eicher Tractor Lock Washer                         | 8     | 73182100 | 18% |
| 93624274 | Eicher Tractor Clamping Plate                      | 333   | 87089900 | 18% |
| 93624286 | Eicher Tractor Lock Plate                          | 130   | 87084000 | 18% |
| 93624328 | Eicher Tractor Axle Tube Left                      | 7090  | 87084000 | 18% |
| 93624330 | Eicher Tractor Axle Tube Right (South)             | 7233  | 87084000 | 18% |
| 93624341 | Eicher Tractor Rear Shaft                          | 7553  | 87084000 | 18% |
| 93624377 | Eicher Tractor Shifter Fork Pto                    | 385   | 87084000 | 18% |
| 93624389 | Eicher Tractor Shifter Rod Pto                     | 282   | 87084000 | 18% |
| 93624393 | Eicher Tractor Engaging Handle                     | 485   | 87084000 | 18% |
| 93624409 | Eicher Tractor Gear Housing Front - 50 Hp          | 24248 | 87084000 | 18% |
| 93624481 | Eicher Tractor Spacer For Lay Shaft                | 158   | 73182100 | 18% |
| 93624511 | Eicher Tractor 11" Single Clutch Cover Assy. (D Ty | 4651  | 87089300 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93624535 | Eicher Tractor Spacer Lay Shaft Rear               | 67    | 73182100 | 18% |
| 93624559 | Eicher Tractor Constant Mesh Gear- 485 Dlx (Teeth  | 1398  | 87084000 | 18% |
| 93624560 | Eicher Tractor Primary Shaft Sc 485 Dlx (Teeth-    | 5602  | 87084000 | 18% |
| 93624584 | Eicher Tractor Shifter Rod 3/4                     | 271   | 87084000 | 18% |
| 93624626 | Eicher Tractor Primary Shaft (Dc) -50Hp (Teeth-25) | 4709  | 87084000 | 18% |
| 93624638 | Eicher Tractor Primary Shaft (Sc) - 50Hp (Teeth-   | 5540  | 87084000 | 18% |
| 93624640 | Eicher Tractor Guide Sleeve                        | 852   | 87084000 | 18% |
| 93624821 | Eicher Tractor Spring Dowel Sleeve 6X16            | 12    | 73182100 | 18% |
| 93624857 | Eicher Tractor Reverse Gear Assembly (With Snap Ri | 1932  | 87084000 | 18% |
| 93624870 | Eicher Tractor Hex Nut M10X1.25                    | 14    | 73181500 | 18% |
| 93624961 | Eicher Tractor Brake Housing Lt.                   | 1550  | 87083000 | 18% |
| 93624973 | Eicher Tractor Brake Housing Rt                    | 1480  | 87083000 | 18% |
| 93624985 | Eicher Tractor Pto Shaft Front - 485 Dlx (Teeth    | 2551  | 87084000 | 18% |
| 93625011 | Eicher Tractor Coupling Sleeve                     | 531   | 87084000 | 18% |
| 93625035 | Eicher Tractor Sliding Piece                       | 30    | 87089900 | 18% |
| 93625047 | Eicher Tractor P T O Shaft With Bush 242 Spline    | 2239  | 87084000 | 18% |
| 93625060 | Eicher Tractor Spur Gear 3Rd                       | 1206  | 87084000 | 18% |
| 93625072 | Eicher Tractor Sld Pinion 3Rd/4Th - 485 Dlx (Teet  | 1428  | 87084000 | 18% |
| 93625096 | Eicher Tractor Pto Lever-Pull/Push                 | 157   | 87084000 | 18% |
| 93625102 | Eicher Tractor Pin For Fork                        | 28    | 87084000 | 18% |
| 93625266 | Eicher Tractor F D Gear Z-59 (Nol) -South Special  | 11571 | 87084000 | 18% |
| 93625370 | Eicher Tractor Dual Cluych Assly 11"X11"-2028P800  | 27593 | 87089300 | 18% |
| 93625400 | Eicher Tractor F D Pinion Z-12(Nol) 50Hp (Teeth-1  | 4604  | 87084000 | 18% |
| 93625412 | Eicher Tractor Gasket For Brake Housing            | 77    | 68129090 | 18% |
| 93625436 | Eicher Tractor Brake Housing Rt.                   | 1918  | 87083000 | 18% |
| 93625448 | Eicher Tractor Cover Lt                            | 2764  | 87084000 | 18% |
| 93625461 | Eicher Tractor Gasket Oil Seal Hsg.                | 15    | 40169990 | 18% |
| 93625590 | Eicher Tractor Assly Pto Shaft 540 - 485 Dlx       | 2811  | 87084000 | 18% |
| 93625606 | Eicher Tractor F D Pini Z13(Ol)50Hp-485Dlx (Teeth  | 3926  | 87084000 | 18% |
| 93625760 | Eicher Tractor Spacer Fd [1017871](No Po)          | 89    | 73182100 | 18% |
| 93625771 | Eicher Tractor Spacer                              | 121   | 73182100 | 18% |
| 93625825 | Eicher Tractor Washer (10.5X25X5)                  | 14    | 73182100 | 18% |
| 93625886 | Eicher Tractor Differential Hsg. 242               | 3727  | 87084000 | 18% |
| 93625898 | Eicher Tractor Support Hub                         | 929   | 87084000 | 18% |
| 93625904 | Eicher Tractor Axial Diff. Star Pinion             | 1888  | 87084000 | 18% |
| 93625928 | Eicher Tractor Actuating Unit With Pull Rod (50 Hp | 2065  | 87083000 | 18% |
| 93625930 | Eicher Tractor Lined Friction Disc (50 Hp)         | 804   | 87083000 | 18% |
| 93625941 | Eicher Tractor Rubber Boot (50 H.P.)               | 151   | 40169320 | 18% |
| 93625953 | Eicher Tractor Turning Block ( 2)                  | 107   | 87083000 | 18% |
| 93625965 | Eicher Tractor Adjuster Nut (4)                    | 26    | 73181500 | 18% |
| 93625977 | Eicher Tractor Lock Nut 50 Hp                      | 15    | 73181500 | 18% |
| 93626015 | Eicher Tractor Cover Left                          | 5118  | 87084000 | 18% |
| 93626027 | Eicher Tractor Cover Right                         | 5686  | 87084000 | 18% |
| 93626040 | Eicher Tractor Dowel Pin Od 14L 38Mm               | 62    | 73182100 | 18% |
| 93626076 | Eicher Tractor Wire Ring - Rear Shaft              | 14    | 87084000 | 18% |
| 93626088 | Eicher Tractor Shim For Oil Seal                   | 27    | 73182100 | 18% |
| 93626167 | Eicher Tractor Primary Shaft - Dc (Teeth-25)       | 4041  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93626489 | Eicher Tractor Diff.Hsg.Assly 368 F                | 5500  | 87084000 | 18% |
| 93626520 | Eicher Tractor Special Screw                       | 213   | 73181500 | 18% |
| 93626556 | Eicher Tractor Washer                              | 2     | 73182100 | 18% |
| 93626568 | Eicher Tractor Actuating Unit With Pull Rod        | 3060  | 87083000 | 18% |
| 93626593 | Eicher Tractor Oil Seal Housing                    | 1120  | 40169330 | 18% |
| 93626660 | Eicher Tractor Lever For Pto                       | 149   | 87084000 | 18% |
| 93626684 | Eicher Tractor Lock Washer                         | 16    | 73182100 | 18% |
| 93626738 | Eicher Tractor Chain Assy                          | 43    | 87089900 | 18% |
| 93626740 | Eicher Tractor Sticker Pto                         | 28    | 39199090 | 18% |
| 93626830 | Eicher Tractor Lock Washer                         | 26    | 73182100 | 18% |
| 93626854 | Eicher Tractor Cover G2 Top (C)                    | 5924  | 87084000 | 18% |
| 93626878 | Eicher Tractor Strip For Float                     | 67    | 87084000 | 18% |
| 93626969 | Eicher Tractor Assy Pto Shaft - 540                | 5012  | 87084000 | 18% |
| 93626982 | Eicher Tractor Driven Plate P T O                  | 5725  | 87089300 | 18% |
| 93627007 | Eicher Tractor Main Driven Plate                   | 9643  | 87089300 | 18% |
| 93627019 | Eicher Tractor Special Screw M10X22,Class 10.9     | 23    | 73181500 | 18% |
| 93627044 | Eicher Tractor Cover Right & Left                  | 2052  | 87084000 | 18% |
| 93627135 | Eicher Tractor Cover G1 Top                        | 4328  | 87084000 | 18% |
| 93627159 | Eicher Tractor Gear Shift Lever Assy               | 705   | 87084000 | 18% |
| 93627160 | Eicher Tractor Shifter Rod 1St & 2Nd               | 337   | 87084000 | 18% |
| 93627172 | Eicher Tractor Shifter Rod 3Rd & 4Th               | 326   | 87084000 | 18% |
| 93627184 | Eicher Tractor Shifter Rod Rev.Gear                | 330   | 87084000 | 18% |
| 93627196 | Eicher Tractor Jaw 1St & 2Nd                       | 298   | 87084000 | 18% |
| 93627202 | Eicher Tractor Jaw 3Rd & 4Th                       | 384   | 87084000 | 18% |
| 93627214 | Eicher Tractor Jaw Reverse                         | 346   | 87084000 | 18% |
| 93627226 | Eicher Tractor Shifter Fork Hi/Low                 | 837   | 87084000 | 18% |
| 93627238 | Eicher Tractor Bellow                              | 81    | 87084000 | 18% |
| 93627240 | Eicher Tractor Wire Ring For Side Shift            | 12    | 73202000 | 18% |
| 93627251 | Eicher Tractor Clip For Bellow                     | 28    | 73182100 | 18% |
| 93627263 | Eicher Tractor O-Ring For Side Shift               | 24    | 40169320 | 18% |
| 93627378 | Eicher Tractor Diaphragm Spring                    | 2841  | 87089300 | 18% |
| 93627391 | Eicher Tractor Fulcrum Ring                        | 60    | 87089900 | 18% |
| 93627445 | Eicher Tractor Shifter Fork Pto - 50 Hp            | 597   | 87084000 | 18% |
| 93627457 | Eicher Tractor Nave Assembly                       | 397   | 87084000 | 18% |
| 93627482 | Eicher Tractor Fork Pto                            | 125   | 87084000 | 18% |
| 93627500 | Eicher Tractor Pto Sleeve Front - 485 Dlx S-2      | 1255  | 87084000 | 18% |
| 93627615 | Eicher Tractor Shifter Fork 1St & 2Nd              | 758   | 87084000 | 18% |
| 93627627 | Eicher Tractor Shifter Fork 3Rd & 4Th              | 512   | 87084000 | 18% |
| 93627639 | Eicher Tractor Shifter Fork Rev.Gear               | 692   | 87084000 | 18% |
| 93627640 | Eicher Tractor Shifter Rod Hi/Low                  | 250   | 87084000 | 18% |
| 93627664 | Eicher Tractor Conical Spring                      | 123   | 73202000 | 18% |
| 93627720 | Eicher Tractor Wet Brake Set6.5"X4.3"(A29032216 E1 | 11068 | 87083000 | 18% |
| 93627731 | Eicher Tractor Spacer For Spring                   | 94    | 73182100 | 18% |
| 93627755 | Eicher Tractor Cable Tie Clip 250Mm (Black)        | 13    | 87084000 | 18% |
| 93627767 | Eicher Tractor Lubrication Pipe Assy Rt            | 356   | 87089900 | 18% |
| 93627779 | Eicher Tractor Lubrication Pipe                    | 313   | 87089900 | 18% |
| 93627780 | Eicher Tractor Special Precoated Screw             | 27    | 73181500 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93627809 | Eicher Tractor Spacer Thin Reverse Gear            | 111   | 73182100 | 18% |
| 93627834 | Eicher Tractor Wire Ring                           | 12    | 73202000 | 18% |
| 93627846 | Eicher Tractor Diff. Hsg. Assy                     | 8586  | 87084000 | 18% |
| 93627871 | Eicher Tractor Diff Shaft 3 Star                   | 1060  | 87084000 | 18% |
| 93627883 | Eicher Tractor Diff. Star Pinion                   | 673   | 87084000 | 18% |
| 93627895 | Eicher Tractor Thrust Washer                       | 121   | 73182100 | 18% |
| 93627925 | Eicher Tractor Oil Seal 25*35*7                    | 100   | 40169330 | 18% |
| 93627937 | Eicher Tractor Oil Seal 35*56*10                   | 92    | 40169330 | 18% |
| 93627949 | Eicher Tractor Oil Seal 42*62*8                    | 134   | 40169330 | 18% |
| 93627950 | Eicher Tractor Oil Seal 40*60*13                   | 130   | 40169330 | 18% |
| 93627962 | Eicher Tractor Oil Seal 45*62*8-368/485 Sdi        | 105   | 40169330 | 18% |
| 93627974 | Eicher Tractor Oil Seal 55*80*13                   | 196   | 40169330 | 18% |
| 93627986 | Eicher Tractor Oil Seal 70*90*10                   | 125   | 40169990 | 18% |
| 93628048 | Eicher Tractor Spacer For 3 Star                   | 46    | 73182100 | 18% |
| 93628206 | Eicher Tractor Support Spring                      | 18    | 87089900 | 18% |
| 93628280 | Eicher Tractor F.D.P Shaft Z13(OI)50Hp-Wdb (Teeth- | 4195  | 87084000 | 18% |
| 93628292 | Eicher Tractor F.D.P.Shaft Z14(OI)50Hp (Teeth-14)  | 4027  | 87084000 | 18% |
| 93628309 | Eicher Tractor G1 Top Cover                        | 3569  | 87084000 | 18% |
| 93628310 | Eicher Tractor Plate For Conical Spring            | 71    | 87089900 | 18% |
| 93628383 | Eicher Tractor Lever For Hi/Low                    | 323   | 87089900 | 18% |
| 93628528 | Eicher Tractor Sticker For Syncro                  | 62    | 39199090 | 18% |
| 93628565 | Eicher Tractor Bellow (Epdm)                       | 103   | 87084000 | 18% |
| 93628589 | Eicher Tractor Final Drive Gear Z-58 (OI) South    | 10410 | 87084000 | 18% |
| 93628632 | Eicher Tractor Pto Nave Adj.                       | 335   | 87084000 | 18% |
| 93628693 | Eicher Tractor Tube For Shifter Rod Rev Gear       | 32    | 87084000 | 18% |
| 93628700 | Eicher Tractor Tube For Shifter Rod 1/2            | 32    | 87089900 | 18% |
| 93628711 | Eicher Tractor Tube For Shifter Rod 3/4            | 47    | 87089900 | 18% |
| 93628735 | Eicher Tractor Locking Screw M10                   | 63    | 73181500 | 18% |
| 93628747 | Eicher Tractor Dowel Pin Od 12 L 22                | 34    | 73182100 | 18% |
| 93628840 | Eicher Tractor Diff. Hsg. Assy                     | 4965  | 87084000 | 18% |
| 93628851 | Eicher Tractor Conical Spring                      | 82    | 73202000 | 18% |
| 93628887 | Eicher Tractor Sticker Wdb                         | 18    | 39199090 | 18% |
| 93628905 | Eicher Tractor Gear Housing Front - 380            | 17691 | 87084000 | 18% |
| 93628954 | Eicher Tractor Spacer                              | 3     | 73182100 | 18% |
| 93628991 | Eicher Tractor 7" Friction Disc                    | 145   | 87083000 | 18% |
| 93629028 | Eicher Tractor Cover Lt.                           | 4737  | 87084000 | 18% |
| 93629030 | Eicher Tractor Cover Rt.                           | 5559  | 87084000 | 18% |
| 93629041 | Eicher Tractor Cover Left                          | 4892  | 87084000 | 18% |
| 93629053 | Eicher Tractor Cover Right                         | 6737  | 87084000 | 18% |
| 93629132 | Eicher Tractor Final Drive Gear                    | 8462  | 87084000 | 18% |
| 93629168 | Eicher Tractor Brake Housing Lt.                   | 2415  | 87083000 | 18% |
| 93629170 | Eicher Tractor Brake Housing Rt.                   | 2415  | 87083000 | 18% |
| 93629181 | Eicher Tractor Gasket For G2                       | 69    | 68129090 | 18% |
| 93629312 | Eicher Tractor Assy. Differential Housing          | 8780  | 87084000 | 18% |
| 93629351 | Eicher Tractor Fork For Pto                        | 639   | 87084000 | 18% |
| 93629375 | Eicher Tractor Spring For Pto Engaging Assy        | 3     | 73202000 | 18% |
| 93629557 | Eicher Tractor Cover Left                          | 3880  | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93629569 | Eicher Tractor Cover Right                    | 4378  | 87084000 | 18% |
| 93629582 | Eicher Tractor Shifter Fork 3Rd & 4Th         | 676   | 87084000 | 18% |
| 93629650 | Eicher Tractor F D Pinion Shaft Assly         | 4322  | 87084000 | 18% |
| 93629685 | Eicher Tractor Shim 0.15                      | 34    | 73182100 | 18% |
| 93629697 | Eicher Tractor Shim 0.2                       | 37    | 73182100 | 18% |
| 93629703 | Eicher Tractor Shim 0.5                       | 61    | 73182100 | 18% |
| 93629715 | Eicher Tractor Shim 1Mm                       | 75    | 73182100 | 18% |
| 93629831 | Eicher Tractor Slide Sleeve Dual Clutch       | 613   | 87089300 | 18% |
| 93629843 | Eicher Tractor Sliding Sleeve                 | 660   | 87084000 | 18% |
| 93629855 | Eicher Tractor Bearing Sleeve                 | 828   | 84822090 | 18% |
| 93629909 | Eicher Tractor Spacer For Cp Shaft            | 145   | 73182100 | 18% |
| 93629910 | Eicher Tractor Gear Housing Rear - 242 Common | 21486 | 87084000 | 18% |
| 93629946 | Eicher Tractor Spares Kit Reserve Shaft       | 2316  | 87084000 | 18% |
| 93630031 | Eicher Tractor Lever Hlr                      | 216   | 87089900 | 18% |
| 93630160 | Eicher Tractor Support                        | 174   | 87084000 | 18% |
| 93630171 | Eicher Tractor Plate                          | 118   | 87089400 | 18% |
| 93630183 | Eicher Tractor Gasket(Foam)                   | 70    | 40169990 | 18% |
| 93630195 | Eicher Tractor Plate                          | 118   | 87089400 | 18% |
| 93630213 | Eicher Tractor Wear Ring                      | 1306  | 87089900 | 18% |
| 93630468 | Eicher Tractor Clutch Shaft - Hollow          | 6480  | 87089300 | 18% |
| 93630684 | Eicher Tractor Oil Seal Housing               | 537   | 40169330 | 18% |
| 93630985 | Eicher Tractor Pto Coupler                    | 1277  | 87084000 | 18% |
| 93630997 | Eicher Tractor Pto Sleeve Inner               | 432   | 87084000 | 18% |
| 93631000 | Eicher Tractor Pto Sft Output -60-Hp          | 2510  | 87084000 | 18% |
| 93631760 | Eicher Tractor Engaging_Handle                | 529   | 87084000 | 18% |
| 93631886 | Eicher Tractor Cone Spring                    | 41    | 73209090 | 18% |
| 93631898 | Eicher Tractor Thrust Plate                   | 762   | 87084000 | 18% |
| 93631904 | Eicher Tractor Bush - Differential            | 265   | 87089900 | 18% |
| 93631977 | Eicher Tractor Guide Plate For Pto            | 585   | 87084000 | 18% |
| 93632027 | Eicher Tractor Nave For Pto                   | 591   | 87084000 | 18% |
| 93632040 | Eicher Tractor Shaft Diff. Lock Fork          | 957   | 87084000 | 18% |
| 93632192 | Eicher Tractor Spring For Diff. Lock          | 105   | 87089900 | 18% |
| 93632593 | Eicher Tractor Lay Shaft Front - 5660A        | 4195  | 87084000 | 18% |
| 93632635 | Eicher Tractor Ring Gear Z-69                 | 6409  | 87084000 | 18% |
| 93632647 | Eicher Tractor Gear Z26                       | 2292  | 87084000 | 18% |
| 93632659 | Eicher Tractor Planet Carrier                 | 3154  | 87084000 | 18% |
| 93632660 | Eicher Tractor Bearing Cage                   | 1412  | 87084000 | 18% |
| 93632672 | Eicher Tractor Circlip (Retaining Ring)       | 113   | 73182910 | 18% |
| 93632684 | Eicher Tractor Wire                           | 4     | 73202000 | 18% |
| 93632696 | Eicher Tractor Crown Wheel                    | 16640 | 87084000 | 18% |
| 93632702 | Eicher Tractor Axial Star Pinion              | 1757  | 87084000 | 18% |
| 93632714 | Eicher Tractor Axial Diff. Star Pinion        | 3147  | 87084000 | 18% |
| 93632726 | Eicher Tractor C M Gear 1St                   | 3852  | 87084000 | 18% |
| 93632738 | Eicher Tractor Intermediate Shaft             | 12853 | 87084000 | 18% |
| 93632740 | Eicher Tractor Primary Shaft                  | 12061 | 87084000 | 18% |
| 93632751 | Eicher Tractor Spur Pinion 1St                | 4516  | 87084000 | 18% |
| 93632763 | Eicher Tractor Shaft (Planet Pin)             | 476   | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93632787 | Eicher Tractor Rear Shaft               | 12382 | 87084000 | 18% |
| 93632799 | Eicher Tractor Sun Shaft,Left           | 3214  | 87084000 | 18% |
| 93632805 | Eicher Tractor Sun Shaft,Right          | 3554  | 87084000 | 18% |
| 93632817 | Eicher Tractor Adjusting Screw          | 964   | 73181500 | 18% |
| 93632829 | Eicher Tractor Oil Seal Hsg             | 579   | 40169330 | 18% |
| 93632878 | Eicher Tractor Washer,Rear Axle         | 375   | 73182100 | 18% |
| 93632880 | Eicher Tractor Intermediate Spacer      | 85    | 87084000 | 18% |
| 93632891 | Eicher Tractor Lock Washer              | 30    | 73182100 | 18% |
| 93632908 | Eicher Tractor Wear Plate               | 19    | 87084000 | 18% |
| 93632910 | Eicher Tractor Lock Washer              | 59    | 73182100 | 18% |
| 93632921 | Eicher Tractor Intermediate Shaft Rear  | 5315  | 87084000 | 18% |
| 93632933 | Eicher Tractor Nrb Retainer             | 33    | 84822090 | 18% |
| 93632945 | Eicher Tractor Splined Sleeve           | 660   | 87084000 | 18% |
| 93632970 | Eicher Tractor Crimping Nut             | 224   | 73181500 | 18% |
| 93632982 | Eicher Tractor Axle Tube Left           | 24995 | 87084000 | 18% |
| 93632994 | Eicher Tractor Axle Tube Right          | 24995 | 87084000 | 18% |
| 93633007 | Eicher Tractor Friction Plate           | 1770  | 87083000 | 18% |
| 93633019 | Eicher Tractor Steel Plate              | 1201  | 87089900 | 18% |
| 93633044 | Eicher Tractor Gasket, Brake Rack       | 15    | 68129090 | 18% |
| 93633093 | Eicher Tractor Bearing Retainer         | 47    | 84099941 | 28% |
| 93633100 | Eicher Tractor Gasket Oil Seal Hsg.     | 34    | 40169330 | 18% |
| 93633111 | Eicher Tractor Gasket, Axle Tube        | 107   | 68129090 | 18% |
| 93633172 | Eicher Tractor Pin Spring Locating      | 122   | 73202000 | 18% |
| 93633184 | Eicher Tractor Ball Cup                 | 127   | 87089400 | 18% |
| 93633214 | Eicher Tractor Dowel Pin Dia. 12X38     | 102   | 73182100 | 18% |
| 93633226 | Eicher Tractor Brake Set Rt             | 13918 | 87083000 | 18% |
| 93633238 | Eicher Tractor Brack Set Lt             | 13918 | 87083000 | 18% |
| 93633330 | Eicher Tractor High Low Lever           | 958   | 87084000 | 18% |
| 93633366 | Eicher Tractor Jaw 3Rd & 4Th            | 341   | 87084000 | 18% |
| 93633378 | Eicher Tractor Closing Screw            | 19    | 73181500 | 18% |
| 93633391 | Eicher Tractor Shaft Brake Lever        | 154   | 87083000 | 18% |
| 93633408 | Eicher Tractor Brake Ring Lt            | 3444  | 87083000 | 18% |
| 93633410 | Eicher Tractor Brake Ring Rt            | 3444  | 87083000 | 18% |
| 93633421 | Eicher Tractor Brake Rack Hsg           | 1519  | 87083000 | 18% |
| 93633433 | Eicher Tractor Brake Jaw                | 361   | 87083000 | 18% |
| 93633445 | Eicher Tractor Brake Lever              | 221   | 87083000 | 18% |
| 93633470 | Eicher Tractor Locking Screw M10        | 21    | 73181500 | 18% |
| 93633494 | Eicher Tractor Pto Actuating Lever      | 182   | 87084000 | 18% |
| 93633524 | Eicher Tractor Gear Housing Front       | 21929 | 87089900 | 18% |
| 93633962 | Eicher Tractor Axle Tube Left(South)    | 7971  | 87084000 | 18% |
| 93633974 | Eicher Tractor Axle Tube Right (South)  | 7969  | 87084000 | 18% |
| 93633986 | Eicher Tractor Brake Housing Rt.        | 3894  | 87083000 | 18% |
| 93633998 | Eicher Tractor Brake Housing Lt.        | 3893  | 87083000 | 18% |
| 93634000 | Eicher Tractor Cover Right              | 5369  | 87084000 | 18% |
| 93634012 | Eicher Tractor Cover Left               | 5369  | 87084000 | 18% |
| 93634050 | Eicher Tractor Main Pressure Plate-5600 | 4282  | 87089900 | 18% |
| 93634085 | Eicher Tractor Pto Pressure Plate       | 3045  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93634139 | Eicher Tractor Main Pressure Plate               | 4268  | 87089900 | 18% |
| 93634176 | Eicher Tractor Gear Housing Rear                 | 44796 | 87089900 | 18% |
| 93634188 | Eicher Tractor Gasket For G1 Fw Housing          | 121   | 68129090 | 18% |
| 93634190 | Eicher Tractor Gasket For G1 & G2                | 123   | 68129090 | 18% |
| 93634267 | Eicher Tractor Stud M16X80                       | 60    | 73182100 | 18% |
| 93634279 | Eicher Tractor Knob Hi/Low                       | 122   | 87084000 | 18% |
| 93634280 | Eicher Tractor Knob - Main                       | 122   | 87084000 | 18% |
| 93634309 | Eicher Tractor Pin Pto Actuator                  | 116   | 73182100 | 18% |
| 93634310 | Eicher Tractor Shifter Rod R.G                   | 307   | 87084000 | 18% |
| 93634346 | Eicher Tractor Assy. Drain Plug                  | 118   | 87084000 | 18% |
| 93634360 | Eicher Tractor Gasket Brake Housing              | 114   | 68129090 | 18% |
| 93634371 | Eicher Tractor Brake Lever Rt                    | 218   | 87083000 | 18% |
| 93634383 | Eicher Tractor Spur Pinion H/L (557) - Fin       | 2080  | 87084000 | 18% |
| 93634395 | Eicher Tractor Spur Gear H/L (557) - Fin         | 2611  | 87084000 | 18% |
| 93634401 | Eicher Tractor C.M.Gear H/L (557) - Fin          | 3000  | 87084000 | 18% |
| 93634413 | Eicher Tractor Intermediate Shaft Bearing Spacer | 146   | 84822090 | 18% |
| 93634425 | Eicher Tractor Reverse Gear 1St                  | 1912  | 87084000 | 18% |
| 93634437 | Eicher Tractor Reverse Gear Sleeve               | 1757  | 87084000 | 18% |
| 93634516 | Eicher Tractor Cover G1 Top                      | 3735  | 87084000 | 18% |
| 93634528 | Eicher Tractor Gasket G1 Top Cover               | 68    | 68129090 | 18% |
| 93634530 | Eicher Tractor Diff. Star Pinion                 | 1305  | 87084000 | 18% |
| 93634541 | Eicher Tractor Tube For Shifter Rod Rev Gear     | 21    | 87084000 | 18% |
| 93634577 | Eicher Tractor Primary Shaft Sc -557 - 4577      | 6812  | 87084000 | 18% |
| 93634632 | Eicher Tractor Brake Set                         | 7451  | 87083000 | 18% |
| 93634711 | Eicher Tractor Stud ,M14*42*70                   | 43    | 73182100 | 18% |
| 93634747 | Eicher Tractor Rubber Bellow (Side Shift)        | 77    | 40169320 | 18% |
| 93634759 | Eicher Tractor Pto Link Assy                     | 250   | 87084000 | 18% |
| 93634772 | Eicher Tractor Pto Actuator Assy                 | 405   | 87084000 | 18% |
| 93634784 | Eicher Tractor Engaging Handle                   | 574   | 87084000 | 18% |
| 93634802 | Eicher Tractor Pto Shaft Front - 50Hp (557)      | 2718  | 87084000 | 18% |
| 93634917 | Eicher Tractor Gear Shift Lever - Main           | 1332  | 87084000 | 18% |
| 93634929 | Eicher Tractor Rev Gear Jaw                      | 429   | 87084000 | 18% |
| 93634930 | Eicher Tractor 1/2 Jaw (Mod)                     | 408   | 87085000 | 18% |
| 93634942 | Eicher Tractor Jaw 3/4                           | 468   | 87084000 | 18% |
| 93635065 | Eicher Tractor Gear Shifter Lever                | 1133  | 87084000 | 18% |
| 93635296 | Eicher Tractor Knob Hi/Low                       | 144   | 87084000 | 18% |
| 93635302 | Eicher Tractor Main Gear Knob                    | 144   | 87084000 | 18% |
| 93635442 | Eicher Tractor Fork Diff Lock                    | 894   | 87084000 | 18% |
| 93635454 | Eicher Tractor Shaft Diff Lock                   | 566   | 87084000 | 18% |
| 93635466 | Eicher Tractor Foot Pedal Assy                   | 370   | 87089900 | 18% |
| 93635491 | Eicher Tractor Gear Box Hsg Rear                 | 42799 | 87084000 | 18% |
| 93635510 | Eicher Tractor Locking Screw                     | 57    | 73181500 | 18% |
| 93635635 | Eicher Tractor Reverse Shaft                     | 403   | 87084000 | 18% |
| 93635661 | Eicher Tractor Pin Dia 6X28                      | 17    | 73182100 | 18% |
| 93635696 | Eicher Tractor 4Wd Front Axle Assy               | 62061 | 87085000 | 18% |
| 93635703 | Eicher Tractor O-Ring 146.5X2.68, Shore-A75      | 45    | 40169320 | 18% |
| 93635805 | Eicher Tractor Pto Drive Shaft Dlx - Speed       | 4594  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93635819 | Eicher Tractor Pto C M Gear Dlx Speed              | 2290  | 87084000 | 18% |
| 93635842 | Eicher Tractor Axle Tube Left - S/W                | 11567 | 87084000 | 18% |
| 93635854 | Eicher Tractor Axle Tube Right - S/W               | 11678 | 87084000 | 18% |
| 93635866 | Eicher Tractor Axle Tube Left - Hyd                | 11541 | 87084000 | 18% |
| 93635878 | Eicher Tractor Axle Tube Right - Hyd               | 11651 | 87084000 | 18% |
| 93635899 | Eicher Tractor Pto Drive Shaft 755 - Speed         | 3602  | 87084000 | 18% |
| 93635909 | Eicher Tractor Oil Dipstick                        | 138   | 87089900 | 18% |
| 93635910 | Eicher Tractor Washer For Oil Dipstick             | 12    | 40169320 | 18% |
| 93635922 | Eicher Tractor Closing Screw                       | 55    | 87089900 | 18% |
| 93635934 | Eicher Tractor H/L Stopper Bush                    | 106   | 87089400 | 18% |
| 93635946 | Eicher Tractor H/L Stopper Bush (Hyd)              | 140   | 87089400 | 18% |
| 93635960 | Eicher Tractor Slide Sleeve Sc                     | 840   | 87084000 | 18% |
| 93636203 | Eicher Tractor Brake Set Right                     | 14614 | 87083000 | 18% |
| 93636215 | Eicher Tractor Brake Retainer Machining            | 6680  | 87089900 | 18% |
| 93636227 | Eicher Tractor Brake Set Left                      | 14614 | 87083000 | 18% |
| 93636240 | Eicher Tractor Brake Hsg Lt                        | 4109  | 87083000 | 18% |
| 93636252 | Eicher Tractor Brake Hsg Rt                        | 4108  | 87083000 | 18% |
| 93636264 | Eicher Tractor Cover Lt                            | 5253  | 87084000 | 18% |
| 93636276 | Eicher Tractor Cover Rt                            | 5108  | 87084000 | 18% |
| 93636288 | Eicher Tractor Brake Set Lh-Rh                     | 7272  | 87083000 | 18% |
| 93636290 | Eicher Tractor Actuating Unit                      | 3172  | 87083000 | 18% |
| 93636306 | Eicher Tractor Friction Disc                       | 887   | 87083000 | 18% |
| 93636318 | Eicher Tractor Intermediate Disc                   | 888   | 87083000 | 18% |
| 93636409 | Eicher Tractor Pto Shaft 540 (557R) 6409 - Induct  | 3918  | 87084000 | 18% |
| 93636422 | Eicher Tractor Pto Cover                           | 576   | 87084000 | 18% |
| 93636434 | Eicher Tractor Final Drive Gear (Z57)              | 11821 | 87084000 | 18% |
| 93636586 | Eicher Tractor Pto Actuating Assy                  | 572   | 87084000 | 18% |
| 93636598 | Eicher Tractor Engaging Handle                     | 607   | 87084000 | 18% |
| 93636604 | Eicher Tractor Nave For Pto                        | 676   | 87084000 | 18% |
| 93636616 | Eicher Tractor Pto Actuating Lever                 | 249   | 87084000 | 18% |
| 93636628 | Eicher Tractor Housing                             | 10783 | 87089300 | 18% |
| 93636630 | Eicher Tractor Driven Plate (Transmission Side)    | 6739  | 87089300 | 18% |
| 93636641 | Eicher Tractor Pressure Plate (Transmission Side)  | 4894  | 87089300 | 18% |
| 93636653 | Eicher Tractor Spring Pin                          | 2881  | 73209020 | 18% |
| 93636665 | Eicher Tractor Diaphragm Spring                    | 22    | 73182100 | 18% |
| 93636677 | Eicher Tractor Fulcrum Ring                        | 53    | 87089300 | 18% |
| 93636689 | Eicher Tractor Pressure Plate (Engine Side)        | 3872  | 87089300 | 18% |
| 93636690 | Eicher Tractor Driven Plate (Engine Side)          | 15006 | 87089300 | 18% |
| 93636707 | Eicher Tractor Finger Set Main                     | 4242  | 87089300 | 18% |
| 93636719 | Eicher Tractor Finger Set Pto                      | 3658  | 87089300 | 18% |
| 93636793 | Eicher Tractor Cluth Release Bearing Assy. (Dc)    | 2870  | 87089300 | 18% |
| 93636872 | Eicher Tractor Gear H/L Z44                        | 3886  | 87084000 | 18% |
| 93636884 | Eicher Tractor H/L Pinion Z-23                     | 1584  | 87084000 | 18% |
| 93636896 | Eicher Tractor Cm Gear 1St                         | 2817  | 87084000 | 18% |
| 93636902 | Eicher Tractor Spur Pinion 1St Z27                 | 1323  | 87084000 | 18% |
| 93636914 | Eicher Tractor Lock Washer                         | 11    | 73182100 | 18% |
| 93636940 | Eicher Tractor Assy Differential Housing (I.A. & 5 | 8918  | 87084000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93636987 | Eicher Tractor Diff. Star Pinion (557)        | 1198  | 87084000 | 18% |
| 93636999 | Eicher Tractor Axle Tube Left                 | 36257 | 87084000 | 18% |
| 93637001 | Eicher Tractor Axle Tube Right                | 36257 | 87084000 | 18% |
| 93637086 | Eicher Tractor Gasket G1 Fw Housing           | 121   | 68129090 | 18% |
| 93637175 | Eicher Tractor Diff. Star Pinion              | 1044  | 87084000 | 18% |
| 93637177 | Eicher Tractor Assembly Pto Shaft Rear        | 4190  | 87084000 | 18% |
| 93637189 | Eicher Tractor Actuating Unit Assembly        | 3513  | 87083000 | 18% |
| 93637207 | Eicher Tractor Final Drive Gear Z-59          | 14070 | 87084000 | 18% |
| 93637990 | Eicher Tractor Push Rod                       | 694   | 87089900 | 18% |
| 93638273 | Eicher Tractor Assy Pto Shaft Rear (5-Series) | 4450  | 87084000 | 18% |
| 93638790 | Eicher Tractor Gasket G1 Top Cover            | 57    | 68129090 | 18% |
| 93638900 | Eicher Tractor Clutch Plate Assembly Pto      | 5199  | 87089300 | 18% |
| 93639216 | Eicher Tractor Front Axle Assy 4Wd            | 67026 | 87085000 | 18% |
| 93639290 | Eicher Tractor Shifter Rod 3/4                | 415   | 87084000 | 18% |
| 93639307 | Eicher Tractor Brake Housing Left (3 Disc)    | 3845  | 87083000 | 18% |
| 93639319 | Eicher Tractor Brake Housing Right (3 Disc)   | 3845  | 87083000 | 18% |
| 93639320 | Eicher Tractor Crimping Nut M45X1.5           | 279   | 73181500 | 18% |
| 93639332 | Eicher Tractor Shim For Synchro 3/4 2.8 Thk.  | 110   | 73182100 | 18% |
| 93639836 | Eicher Tractor Axle Tube Left (Non Hyd)       | 12838 | 87084000 | 18% |
| 93639848 | Eicher Tractor Axle Tube Right (Non Hyd)      | 11357 | 87084000 | 18% |
| 93639885 | Eicher Tractor Planet Carrier                 | 4381  | 87084000 | 18% |
| 93639897 | Eicher Tractor Sun Shaft Left                 | 8940  | 87084000 | 18% |
| 93639903 | Eicher Tractor Sun Shaft Right                | 7904  | 87084000 | 18% |
| 93639915 | Eicher Tractor Planet Gear Z-24               | 8899  | 87084000 | 18% |
| 93639927 | Eicher Tractor Ring Gear Z-65                 | 7680  | 87084000 | 18% |
| 93639964 | Eicher Tractor Cover Left                     | 7417  | 87084000 | 18% |
| 93639976 | Eicher Tractor Cover Right                    | 4972  | 87084000 | 18% |
| 93639988 | Eicher Tractor Shifter Rod 3 & 4 (Ss)         | 435   | 87084000 | 18% |
| 93640012 | Eicher Tractor Diaghpram Spring               | 5090  | 87089300 | 18% |
| 93640024 | Eicher Tractor Travel Release Lever           | 418   | 87089900 | 18% |
| 93640036 | Eicher Tractor Driver Screw                   | 97    | 73181500 | 18% |
| 93640048 | Eicher Tractor Release Pin                    | 27    | 73182100 | 18% |
| 93640050 | Eicher Tractor Anti Rattle Spring             | 17    | 87089900 | 18% |
| 93640073 | Eicher Tractor Release Screw                  | 120   | 73181500 | 18% |
| 93640085 | Eicher Tractor Bush                           | 53    | 87089900 | 18% |
| 93640097 | Eicher Tractor Nylock Hexagon Nut             | 33    | 73181500 | 18% |
| 93640115 | Eicher Tractor Guide Pin                      | 31    | 73182100 | 18% |
| 93640140 | Eicher Tractor Diaphargm Spring               | 2958  | 87089300 | 18% |
| 93640164 | Eicher Tractor Cover Housing                  | 5336  | 87084000 | 18% |
| 93640294 | Eicher Tractor Pto Driven Plate               | 5476  | 87084000 | 18% |
| 93640309 | Eicher Tractor Pressure Plate For Pto Clutch  | 3390  | 87089300 | 18% |
| 93640310 | Eicher Tractor Pressure Plate For Main Clutch | 1679  | 87089300 | 18% |
| 93640322 | Eicher Tractor Repair Kit For Pto Clutch      | 2708  | 87089300 | 18% |
| 93640334 | Eicher Tractor Repair Kit For Main Clutch     | 2107  | 87089300 | 18% |
| 93640395 | Eicher Tractor Bracket                        | 289   | 87089900 | 18% |
| 93640401 | Eicher Tractor Split / Qtr Pin                | 3     | 73182100 | 18% |
| 93640413 | Eicher Tractor Pin                            | 25    | 73182100 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93640425 | Eicher Tractor Nosed Pad                          | 56    | 40169320 | 18% |
| 93640437 | Eicher Tractor Nylon Packing                      | 58    | 87084000 | 18% |
| 93640450 | Eicher Tractor Allen Screw                        | 25    | 73181500 | 18% |
| 93640498 | Eicher Tractor Pressure Plate                     | 1677  | 87089900 | 18% |
| 93640504 | Eicher Tractor Release Lever                      | 224   | 87089900 | 18% |
| 93640516 | Eicher Tractor R.L.Pin                            | 23    | 73182100 | 18% |
| 93640528 | Eicher Tractor R.L.Pin                            | 18    | 73182100 | 18% |
| 93640530 | Eicher Tractor A.R.Spring                         | 16    | 87089900 | 18% |
| 93640541 | Eicher Tractor Pressure Spring                    | 57    | 73202000 | 18% |
| 93640553 | Eicher Tractor Needle Roller                      | 2     | 84824000 | 18% |
| 93640565 | Eicher Tractor Lined Friction Disc                | 927   | 87083000 | 18% |
| 93640577 | Eicher Tractor Cottor Pin                         | 2     | 87089900 | 18% |
| 93640590 | Eicher Tractor Repair Kit Minor                   | 1445  | 87089300 | 18% |
| 93640619 | Eicher Tractor Sector Shaft Assly - Zf 7340105523 | 4296  | 87089400 | 18% |
| 93640620 | Eicher Tractor Bearing Kit - Zf 0770027800        | 1054  | 84822090 | 18% |
| 93640644 | Eicher Tractor Gasket -Zf -7340033109             | 40    | 87089400 | 18% |
| 93640668 | Eicher Tractor Friction Disc                      | 674   | 87083000 | 18% |
| 93640670 | Eicher Tractor Intermediate Plate                 | 499   | 87083000 | 18% |
| 93640681 | Eicher Tractor Intermediate Plate                 | 80    | 40169320 | 18% |
| 93640693 | Eicher Tractor Pull Rod                           | 542   | 87089900 | 18% |
| 93640838 | Eicher Tractor Spring For Friction Disc           | 35    | 87083000 | 18% |
| 93640840 | Eicher Tractor Ball                               | 73    | 87084000 | 18% |
| 93641007 | Eicher Tractor Clutch Finger Kit Pto              | 2696  | 87089300 | 18% |
| 93641065 | Eicher Tractor Clutch Cover Housing               | 7921  | 87089300 | 18% |
| 93641077 | Eicher Tractor Pressure Plate For Main Clutch     | 4511  | 87089300 | 18% |
| 93641089 | Eicher Tractor Pressure Plate For Pto Clutch      | 2668  | 87089300 | 18% |
| 93641090 | Eicher Tractor Clutch Finger Kit Main             | 2247  | 87089300 | 18% |
| 93641119 | Eicher Tractor Diaphargm Spring                   | 2684  | 87089300 | 18% |
| 93641144 | Eicher Tractor Dust Valve Clamp                   | 103   | 73181500 | 18% |
| 93641156 | Eicher Tractor Electrical Indicator (Oval)        | 766   | 85122010 | 18% |
| 93641181 | Eicher Tractor Cover Assembly                     | 929   | 87084000 | 18% |
| 93641193 | Eicher Tractor Element Safety                     | 1117  | 84219900 | 18% |
| 93641211 | Eicher Tractor Element Primary                    | 1693  | 84219900 | 18% |
| 93641223 | Eicher Tractor Pre Cleaner Assy                   | 1464  | 84099941 | 28% |
| 93641247 | Eicher Tractor Disc Mesh                          | 39    | 73141200 | 18% |
| 93641259 | Eicher Tractor Foam Disc                          | 219   | 39211310 | 18% |
| 93641260 | Eicher Tractor Secondary Insert Assy              | 335   | 84212300 | 18% |
| 93641272 | Eicher Tractor Sealing Ring                       | 79    | 40169390 | 18% |
| 93641284 | Eicher Tractor Flat Rubber Washer                 | 18    | 40169320 | 18% |
| 93641296 | Eicher Tractor Circlip                            | 13    | 73182910 | 18% |
| 93641302 | Eicher Tractor Primary Insert Assy                | 297   | 84212300 | 18% |
| 93641338 | Eicher Tractor Rubber Bush                        | 74    | 40169390 | 18% |
| 93641340 | Eicher Tractor Warm Drive Clamp                   | 115   | 87084000 | 18% |
| 93641351 | Eicher Tractor Top Dome With Knob                 | 395   | 84213100 | 18% |
| 93641363 | Eicher Tractor Dust Collector Bowl                | 298   | 84212300 | 18% |
| 93641375 | Eicher Tractor Base With Pre Cnr. Tube Assy       | 254   | 84212300 | 18% |
| 93641387 | Eicher Tractor Radiator Assy                      | 22811 | 87087000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93641399 | Eicher Tractor Drain Plug                       | 218   | 87084000 | 18% |
| 93641405 | Eicher Tractor Pressure Cap Assy.               | 377   | 87089900 | 18% |
| 93641417 | Eicher Tractor Inter-Cooler Assy.               | 15110 | 87089900 | 18% |
| 93641429 | Eicher Tractor Shroud                           | 1653  | 87089900 | 18% |
| 93641727 | Eicher Tractor Ctr Housing 4Wd                  | 62527 | 87084000 | 18% |
| 93641739 | Eicher Tractor Cover Plate Shifter              | 235   | 87084000 | 18% |
| 93641764 | Eicher Tractor Spacer Cp Shaft                  | 319   | 73182100 | 18% |
| 93641776 | Eicher Tractor Input Gear 4Wd V1 (Z39)          | 2531  | 87084000 | 18% |
| 93641788 | Eicher Tractor Spacer Layshaft 2 (4Wd)          | 232   | 73182100 | 18% |
| 93641806 | Eicher Tractor Layshaft Rear                    | 2374  | 87084000 | 18% |
| 93641818 | Eicher Tractor Idler Gear 1St                   | 1713  | 87084000 | 18% |
| 93641820 | Eicher Tractor Idler Gear 2Nd 4Wd               | 2027  | 87084000 | 18% |
| 93641831 | Eicher Tractor Shaft Idler 2Nd 4Wd              | 241   | 87084000 | 18% |
| 93641843 | Eicher Tractor Gasket Dropbox                   | 62    | 68129922 | 18% |
| 93641855 | Eicher Tractor Spacer Idler 2Nd                 | 275   | 73182100 | 18% |
| 93641867 | Eicher Tractor Dropbox Cover Rear               | 930   | 87084000 | 18% |
| 93641879 | Eicher Tractor Output Gear                      | 2343  | 87084000 | 18% |
| 93641880 | Eicher Tractor Dropbox Housing                  | 5670  | 87084000 | 18% |
| 93641892 | Eicher Tractor Sliding Sleeve                   | 1097  | 73182100 | 18% |
| 93641909 | Eicher Tractor Dropbox Cover Front              | 1027  | 87084000 | 18% |
| 93641922 | Eicher Tractor Output Shaft 4Wd                 | 2834  | 87084000 | 18% |
| 93641934 | Eicher Tractor Pto Shaft Front - (50Hp)         | 5169  | 87084000 | 18% |
| 93641946 | Eicher Tractor Bush Idler 1St                   | 515   | 87085000 | 18% |
| 93642045 | Eicher Tractor Gasket Dropbox Cover Front       | 42    | 68129922 | 18% |
| 93642057 | Eicher Tractor Plate For V Ring                 | 8     | 87084000 | 18% |
| 93642070 | Eicher Tractor Actuating Lever 4Wd              | 296   | 87089900 | 18% |
| 93642082 | Eicher Tractor Sliding Piece                    | 102   | 87089900 | 18% |
| 93642136 | Eicher Tractor Propeller Shaft 551              | 6747  | 87084000 | 18% |
| 93642148 | Eicher Tractor Engaging Lever 4Wd               | 527   | 87084000 | 18% |
| 93642173 | Eicher Tractor Nup 508019 Etn                   | 1158  | 84825011 | 18% |
| 93642185 | Eicher Tractor Bel Crank Lever 4Wd              | 337   | 87089900 | 18% |
| 93642197 | Eicher Tractor Intermediate Link 4Wd            | 387   | 87084000 | 18% |
| 93642203 | Eicher Tractor Shifter Lever 4Wd                | 233   | 87089900 | 18% |
| 93642215 | Eicher Tractor Spur Gear Hi-Low Z-41            | 1597  | 87084000 | 18% |
| 93642227 | Eicher Tractor Input Gear 4Wd V2 (Z38)          | 2627  | 87084000 | 18% |
| 93642239 | Eicher Tractor Guide Bracket For 4Wd            | 240   | 87089900 | 18% |
| 93642264 | Eicher Tractor Assembly Intermediate Shaft Pto  | 3311  | 87084000 | 18% |
| 93642422 | Eicher Tractor Primary Shaft-Dc Z-23 (551)-2422 | 7151  | 87084000 | 18% |
| 93642446 | Eicher Tractor Pto Drive Shaft Z-16 (551)-2446  | 4450  | 87084000 | 18% |
| 93642495 | Eicher Tractor Housing Front (Hf)               | 52158 | 87084000 | 18% |
| 93642604 | Eicher Tractor Ddb Cover Left                   | 5347  | 87089900 | 18% |
| 93642616 | Eicher Tractor Cover Right Ddb                  | 5347  | 87089900 | 18% |
| 93642630 | Eicher Tractor Shifter Rod 3Rd 4Th (Ss) Ve-551  | 519   | 87089900 | 18% |
| 93642665 | Eicher Tractor Shifter Rod 1St 2Nd (Ss) Ve-551  | 450   | 87089900 | 18% |
| 93642690 | Eicher Tractor Primary Shaft Dc (Z-23)          | 5932  | 87084000 | 18% |
| 93642835 | Eicher Tractor Shifter Jaw 1/2                  | 623   | 87084000 | 18% |
| 93642847 | Eicher Tractor Shifter Jaw Reverse              | 584   | 87084000 | 18% |





|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93642859 | Eicher Tractor Shifter Jaw 3/4           | 794    | 87084000 | 18% |
| 93642914 | Eicher Tractor Bearing Support Kit       | 3007   | 84825011 | 18% |
| 93642926 | Eicher Tractor Roller Pack 58.8X68.8X25  | 687    | 73181500 | 18% |
| 93642938 | Eicher Tractor Roller Pack 26.75X40.8X30 | 696    | 73181500 | 18% |
| 93642940 | Eicher Tractor Axle Housing              | 116371 | 87084000 | 18% |
| 93642951 | Eicher Tractor Breather M10X1            | 785    | 87084000 | 18% |
| 93642963 | Eicher Tractor Belleville Washer         | 310    | 73181500 | 18% |
| 93642975 | Eicher Tractor Bush                      | 1839   | 84833000 | 18% |
| 93642987 | Eicher Tractor Bush                      | 234    | 84833000 | 18% |
| 93642999 | Eicher Tractor Seal                      | 263    | 40169320 | 18% |
| 93643001 | Eicher Tractor Propeller Shaft 480 4Wd   | 6530   | 87084000 | 18% |
| 93643013 | Eicher Tractor Spherical Bearing         | 1694   | 84824000 | 18% |
| 93643025 | Eicher Tractor Belleville Washer         | 115    | 73182100 | 18% |
| 93643037 | Eicher Tractor Pin D15X35                | 131    | 73182100 | 18% |
| 93643049 | Eicher Tractor Differential Support      | 45404  | 87084000 | 18% |
| 93643050 | Eicher Tractor Bolt M14X75               | 251    | 73181500 | 18% |
| 93643062 | Eicher Tractor Centering Bush            | 57     | 84314930 | 18% |
| 93643074 | Eicher Tractor Greaser Nipple M10X1      | 33     | 87089900 | 18% |
| 93643086 | Eicher Tractor Plug M24X1.5              | 1215   | 40169320 | 18% |
| 93643098 | Eicher Tractor Bolt M12X33               | 105    | 73181500 | 18% |
| 93643104 | Eicher Tractor Bolt M12X75               | 211    | 73181500 | 18% |
| 93643116 | Eicher Tractor Washer                    | 1269   | 73182100 | 18% |
| 93643128 | Eicher Tractor Seal                      | 1460   | 40169320 | 18% |
| 93643130 | Eicher Tractor Bushing 105X115X44        | 3500   | 84314930 | 18% |
| 93643141 | Eicher Tractor Bushing 115X120X42        | 6006   | 84833000 | 18% |
| 93643153 | Eicher Tractor O. Ring                   | 63     | 40169320 | 18% |
| 93643165 | Eicher Tractor Rear Support              | 9222   | 87089900 | 18% |
| 93643177 | Eicher Tractor Bushing                   | 127    | 84833000 | 18% |
| 93643189 | Eicher Tractor Boccola105X115X44         | 2421   | 87089900 | 18% |
| 93643190 | Eicher Tractor Front Support             | 9982   | 87089900 | 18% |
| 93643207 | Eicher Tractor Greaser Nipple M6X1       | 21     | 87089900 | 18% |
| 93643220 | Eicher Tractor Bolt M12X30               | 59     | 73181500 | 18% |
| 93643232 | Eicher Tractor King Pin                  | 2498   | 87084000 | 18% |
| 93643244 | Eicher Tractor Plug                      | 13     | 39235090 | 18% |
| 93643256 | Eicher Tractor Lh Swivel Housing         | 26669  | 87084000 | 18% |
| 93643268 | Eicher Tractor Nut M18X1.5               | 154    | 73181500 | 18% |
| 93643270 | Eicher Tractor King Pin                  | 2064   | 87084000 | 18% |
| 93643281 | Eicher Tractor Steering Arm Assy Kit     | 9785   | 87089400 | 18% |
| 93643293 | Eicher Tractor Ball Joint                | 5572   | 87089400 | 18% |
| 93643300 | Eicher Tractor Nut M18X1.5               | 115    | 73181500 | 18% |
| 93643311 | Eicher Tractor Tie Rod                   | 9418   | 87084000 | 18% |
| 93643323 | Eicher Tractor Cover                     | 113    | 87089900 | 18% |
| 93643335 | Eicher Tractor Bolt M16X45               | 219    | 73181500 | 18% |
| 93643347 | Eicher Tractor Rh Swivel Housing         | 26665  | 87084000 | 18% |
| 93643359 | Eicher Tractor Nut M16                   | 24     | 73181500 | 18% |
| 93643360 | Eicher Tractor Bolt M16X100              | 235    | 73181500 | 18% |
| 93643372 | Eicher Tractor Bush                      | 1756   | 84833000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93643384 | Eicher Tractor Oil Seal Ring                | 3006  | 40169320 | 18% |
| 93643396 | Eicher Tractor Bearing                      | 867   | 84824000 | 18% |
| 93643402 | Eicher Tractor Steering Cylinder Kit        | 48348 | 87089400 | 18% |
| 93643414 | Eicher Tractor Cylinder Head                | 6727  | 87089900 | 18% |
| 93643426 | Eicher Tractor Oil Seal Kit                 | 11444 | 39269099 | 18% |
| 93643438 | Eicher Tractor Circlip                      | 986   | 73182910 | 18% |
| 93643440 | Eicher Tractor Rod                          | 14129 | 87084000 | 18% |
| 93643451 | Eicher Tractor Snap Ring                    | 99    | 73182990 | 18% |
| 93643463 | Eicher Tractor Bevel Gear/Pinion Z12/29 Kit | 83827 | 87084000 | 18% |
| 93643475 | Eicher Tractor Washer                       | 69    | 73182100 | 18% |
| 93643487 | Eicher Tractor Collapsible Spacer           | 478   | 84314930 | 18% |
| 93643499 | Eicher Tractor Lockwasher                   | 159   | 73182100 | 18% |
| 93643505 | Eicher Tractor Ring Nut M35X1.5             | 1065  | 73181500 | 18% |
| 93643517 | Eicher Tractor Bearing                      | 3173  | 84824000 | 18% |
| 93643529 | Eicher Tractor Seal                         | 3935  | 40169320 | 18% |
| 93643530 | Eicher Tractor Shim 2.50Mm                  | 834   | 73182100 | 18% |
| 93643542 | Eicher Tractor Shim 2.60Mm                  | 867   | 73182100 | 18% |
| 93643554 | Eicher Tractor Shim 2.70Mm                  | 867   | 73182100 | 18% |
| 93643566 | Eicher Tractor Shim 2.80Mm                  | 867   | 73182100 | 18% |
| 93643578 | Eicher Tractor Shim 2.90Mm                  | 867   | 73182100 | 18% |
| 93643580 | Eicher Tractor Shim 3.00Mm                  | 867   | 73182100 | 18% |
| 93643591 | Eicher Tractor Shim 3.10Mm                  | 866   | 73182100 | 18% |
| 93643608 | Eicher Tractor Shim 3.20Mm                  | 866   | 73182100 | 18% |
| 93643610 | Eicher Tractor Shim 3.30Mm                  | 2583  | 73182100 | 18% |
| 93643621 | Eicher Tractor Shim 3.40Mm                  | 866   | 73182100 | 18% |
| 93643633 | Eicher Tractor Differential Kit             | 13751 | 87084000 | 18% |
| 93643645 | Eicher Tractor Shaft                        | 2575  | 87084000 | 18% |
| 93643657 | Eicher Tractor Thrust Washer                | 335   | 73181500 | 18% |
| 93643669 | Eicher Tractor Clutch Pack                  | 4659  | 87089900 | 18% |
| 93643670 | Eicher Tractor Bearing                      | 1295  | 84824000 | 18% |
| 93643682 | Eicher Tractor Ring Nut M94X2               | 1028  | 73181500 | 18% |
| 93643694 | Eicher Tractor Bolt M6X10                   | 13    | 73181500 | 18% |
| 93643700 | Eicher Tractor Locking Plate                | 78    | 40169320 | 18% |
| 93643712 | Eicher Tractor Bolt M10X75                  | 86    | 73181500 | 18% |
| 93643724 | Eicher Tractor Differential Housing         | 9343  | 84314930 | 18% |
| 93643736 | Eicher Tractor Double U-Joint               | 50855 | 87089400 | 18% |
| 93643748 | Eicher Tractor Half-Shaft (Diff. Side) Kit  | 97528 | 87084000 | 18% |
| 93643750 | Eicher Tractor Central Body                 | 13912 | 87089900 | 18% |
| 93643761 | Eicher Tractor Spider                       | 11297 | 87089900 | 18% |
| 93643773 | Eicher Tractor Half-Shaft (Wheel Side)      | 37128 | 87084000 | 18% |
| 93643785 | Eicher Tractor Snap Ring                    | 95    | 73182990 | 18% |
| 93643797 | Eicher Tractor Seal Ring                    | 4862  | 84314930 | 18% |
| 93643803 | Eicher Tractor Bearing                      | 5841  | 84821011 | 18% |
| 93643815 | Eicher Tractor Wheel Hub Kit                | 31054 | 87087000 | 18% |
| 93643827 | Eicher Tractor Stud                         | 421   | 73181500 | 18% |
| 93643839 | Eicher Tractor O. Ring                      | 115   | 84314930 | 18% |
| 93643840 | Eicher Tractor Lockring                     | 138   | 73182990 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93643852 | Eicher Tractor Wheel Carrier                     | 7918  | 87089900 | 18% |
| 93643864 | Eicher Tractor Bolt M10X35                       | 49    | 73181500 | 18% |
| 93643876 | Eicher Tractor Crown Gear Z=60                   | 11647 | 87084000 | 18% |
| 93643888 | Eicher Tractor Planetary Carrier Assy Kit        | 31570 | 87084000 | 18% |
| 93643890 | Eicher Tractor Snap Ring D34                     | 34    | 73182990 | 18% |
| 93643906 | Eicher Tractor Thrust Washer                     | 536   | 73182100 | 18% |
| 93643918 | Eicher Tractor Gear Z=23                         | 2899  | 84835090 | 18% |
| 93643920 | Eicher Tractor Bearing Needles (By Tens)         | 70    | 84824000 | 18% |
| 93643931 | Eicher Tractor Thrust Washer                     | 71    | 73182100 | 18% |
| 93643943 | Eicher Tractor Bolt M8X20                        | 16    | 73181500 | 18% |
| 93643955 | Eicher Tractor Plug M30X2                        | 947   | 87084000 | 18% |
| 93643967 | Eicher Tractor Input Gear 4Wd Z-36               | 2537  | 87084000 | 18% |
| 93643980 | Eicher Tractor Output Gear Z-29                  | 2531  | 87084000 | 18% |
| 93643992 | Eicher Tractor Crown Pinion Shaft Z-10 (551-4Wd) | 3345  | 87084000 | 18% |
| 93644029 | Eicher Tractor Shifter Rod 3/4 Ss                | 307   | 87084000 | 18% |
| 93644054 | Eicher Tractor Pto Shaft Rear Assy (5 Series)    | 5242  | 87084000 | 18% |
| 93644066 | Eicher Tractor Cover Pto Shaft Rear              | 1494  | 87084000 | 18% |
| 93644078 | Eicher Tractor Sspacer Thrust Pto                | 147   | 73182100 | 18% |
| 93644091 | Eicher Tractor Assy Pto Shaft Rear (Dlx)         | 5368  | 87084000 | 18% |
| 93644108 | Eicher Tractor Mud Cover For Pto Shaft Rear      | 209   | 87084000 | 18% |
| 93644110 | Eicher Tractor Cr Graded Spacer G1&G2            | 190   | 87089400 | 18% |
| 93644121 | Eicher Tractor Cr Graded Spacer G1&G2            | 190   | 87089400 | 18% |
| 93644212 | Eicher Tractor Cr Cluster Gear Z35               | 2473  | 87084000 | 18% |
| 93644224 | Eicher Tractor Cr Dowel Bolt                     | 276   | 73181500 | 18% |
| 93644339 | Eicher Tractor Cr Sliding Sleeve Assembly        | 5227  | 87084000 | 18% |
| 93644340 | Eicher Tractor Cr Graded Spacer                  | 272   | 73182100 | 18% |
| 93644376 | Eicher Tractor Cr Graded Spacer                  | 272   | 73182100 | 18% |
| 93644406 | Eicher Tractor Cr Graded Spacer                  | 272   | 73182100 | 18% |
| 93644431 | Eicher Tractor Cr Graded Spacer                  | 272   | 73182100 | 18% |
| 93644479 | Eicher Tractor Cr Sliding Piece                  | 161   | 87084000 | 18% |
| 93645253 | Eicher Tractor Crimping Nut 38X1.5               | 231   | 73181500 | 18% |
| 93645289 | Eicher Tractor Primary Shaft Dc Z-25 Ve551       | 5349  | 87084000 | 18% |
| 93645423 | Eicher Tractor Reverse Gear Shaft                | 634   | 87084000 | 18% |
| 93645496 | Eicher Tractor Gear Shifter Lever                | 1117  | 87084000 | 18% |
| 93645540 | Eicher Tractor Input Pinion T4                   | 2830  | 87084000 | 18% |
| 93645551 | Eicher Tractor Gear Idler 1 T4                   | 2335  | 87084000 | 18% |
| 93645563 | Eicher Tractor Gear Idler 2 T4                   | 1717  | 87084000 | 18% |
| 93645575 | Eicher Tractor Output Gear T4                    | 1792  | 87084000 | 18% |
| 93645605 | Eicher Tractor Nave Assy (Non Hyd)               | 317   | 87084000 | 18% |
| 93645769 | Eicher Tractor Oil Dipstick (For Ps)             | 186   | 87084000 | 18% |
| 93645782 | Eicher Tractor Cover Pto Shaft Rear              | 1745  | 87084000 | 18% |
| 93645794 | Eicher Tractor Shifter Rod Hi-Low                | 326   | 87089900 | 18% |
| 93646373 | Eicher Tractor Propeller Shaft Front 551         | 5085  | 87084000 | 18% |
| 93646385 | Eicher Tractor Propeller Shaft Front 480         | 4855  | 87084000 | 18% |
| 93646397 | Eicher Tractor Mud Seal Cover                    | 488   | 87084000 | 18% |
| 93646403 | Eicher Tractor Propeller Shaft Rear              | 2114  | 87084000 | 18% |
| 93646415 | Eicher Tractor Dropbox Cover Front               | 772   | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93646427 | Eicher Tractor Gasket Mud Seal Cover               | 21    | 68129090 | 18% |
| 93646452 | Eicher Tractor Plate For V Ring                    | 24    | 87084000 | 18% |
| 93646737 | Eicher Tractor 4Wd Knob                            | 85    | 87084000 | 18% |
| 93646749 | Eicher Tractor Bearing Support Kit                 | 3144  | 87084000 | 18% |
| 93646970 | Eicher Tractor Shifter Rod 3 & 4                   | 435   | 87084000 | 18% |
| 93647602 | Eicher Tractor Spacer-1                            | 335   | 73182100 | 18% |
| 93647614 | Eicher Tractor Spacer-2                            | 460   | 73182100 | 18% |
| 93647950 | Eicher Tractor Clutch Release Bearing              | 4867  | 87083000 | 18% |
| 93648000 | Eicher Tractor Gasket (For Guide Sleeve)           | 45    | 84841090 | 18% |
| 93648072 | Eicher Tractor Gear Shift Lever - Main             | 1406  | 87084000 | 18% |
| 93648084 | Eicher Tractor Knob - Main                         | 333   | 87084000 | 18% |
| 93648096 | Eicher Tractor Knob Hi/Low                         | 333   | 87084000 | 18% |
| 93648157 | Eicher Tractor Clutch Release Bearing 557/650      | 3951  | 87083000 | 18% |
| 93648308 | Eicher Tractor Companion Flange - Axle Side        | 1427  | 87089900 | 18% |
| 93648692 | Eicher Tractor Cover G1 Top                        | 3855  | 87084000 | 18% |
| 93648709 | Eicher Tractor Cover G1 Top                        | 4581  | 87084000 | 18% |
| 93648710 | Eicher Tractor Rubber Bellow                       | 75    | 40169320 | 18% |
| 93648734 | Eicher Tractor Top Cover Rear                      | 2732  | 87084000 | 18% |
| 93649076 | Eicher Tractor Companion Flange Outer              | 1352  | 87089900 | 18% |
| 93649088 | Eicher Tractor Propeller Shaft 557                 | 5570  | 87084000 | 18% |
| 93649271 | Eicher Tractor Reverse Gear Assy (Z-17)            | 1703  | 87084000 | 18% |
| 93649295 | Eicher Tractor Reverse Gear Assy (Z-18)            | 2180  | 87084000 | 18% |
| 93650121 | Eicher Tractor Case Transmission Front             | 42045 | 87089900 | 18% |
| 93650145 | Eicher Tractor P Cover Front                       | 2094  | 87084000 | 18% |
| 93650170 | Eicher Tractor Axle Tube Right (Non Hydromatic)    | 7825  | 87084000 | 18% |
| 93650224 | Eicher Tractor Oil Seal Hsg.                       | 704   | 40169330 | 18% |
| 93650236 | Eicher Tractor Final Drive Gear Z58(OI)            | 10671 | 87084000 | 18% |
| 93650340 | Eicher Tractor Spur Pinion 2Nd - 380               | 946   | 87084000 | 18% |
| 93650479 | Eicher Tractor Spur Gear 3Rd 380 -485 Dlx (Teeth-3 | 1235  | 87084000 | 18% |
| 93650560 | Eicher Tractor Rev Gear Assy 380 -485 Dlx          | 1923  | 87084000 | 18% |
| 93650625 | Eicher Tractor Lay Shaft-2 - 368 Sw                | 1737  | 87084000 | 18% |
| 93650637 | Eicher Tractor Spacer For Lay Shaft 2              | 85    | 73182100 | 18% |
| 93650649 | Eicher Tractor Shifter Fork Hi-Low                 | 805   | 87084000 | 18% |
| 93650650 | Eicher Tractor Spacer For C.P. Shaft               | 58    | 73182100 | 18% |
| 93650662 | Eicher Tractor Spacer For Cp. Shaft2 28.5X26X4     | 58    | 73182100 | 18% |
| 93650674 | Eicher Tractor Lock Plate Common                   | 53    | 87084000 | 18% |
| 93650686 | Eicher Tractor Intermediate Shaft-368 Sw (Teeth-23 | 2841  | 87084000 | 18% |
| 93650698 | Eicher Tractor Sliding Rod Hi-Low                  | 406   | 87089900 | 18% |
| 93650704 | Eicher Tractor Shifting Rod Rev                    | 183   | 87084000 | 18% |
| 93650716 | Eicher Tractor Shifter Rod 1/2                     | 179   | 87084000 | 18% |
| 93650728 | Eicher Tractor Shifter Rod 3/4                     | 224   | 87084000 | 18% |
| 93650741 | Eicher Tractor Shifter Fork 1St & 2Nd              | 454   | 87084000 | 18% |
| 93650753 | Eicher Tractor Shifter Fork 3/4                    | 580   | 87084000 | 18% |
| 93650765 | Eicher Tractor Jaw Hi-Low                          | 356   | 87084000 | 18% |
| 93650789 | Eicher Tractor Pto C M Gear - 368 Sw (Teeth-54)    | 3395  | 87084000 | 18% |
| 93650790 | Eicher Tractor Reverse Gear Shaft                  | 490   | 87084000 | 18% |
| 93650807 | Eicher Tractor Pto Shaft Front                     | 2722  | 87084000 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93650819 | Eicher Tractor Guide Bush Pto                      | 985  | 87084000 | 18% |
| 93650820 | Eicher Tractor Nave For Pto                        | 328  | 87084000 | 18% |
| 93650856 | Eicher Tractor Pto Shaft Rear-540 Sw               | 2699 | 87084000 | 18% |
| 93651034 | Eicher Tractor Shifter Fork Rg - OI                | 785  | 87084000 | 18% |
| 93651046 | Eicher Tractor Reverse Gear Assembly (Teeth-20)    | 2136 | 87084000 | 18% |
| 93651095 | Eicher Tractor Pressure Springs (3Rd-4Th)          | 9    | 73202000 | 18% |
| 93651101 | Eicher Tractor Pressure Springs (R.G.-1&2)         | 9    | 73202000 | 18% |
| 93651113 | Eicher Tractor Pressure Springs (Hi-Lo)            | 8    | 73202000 | 18% |
| 93651174 | Eicher Tractor Shim Variable Thickness 0.2         | 13   | 73182100 | 18% |
| 93651186 | Eicher Tractor Shim Variable Thickness 0.3         | 14   | 73182100 | 18% |
| 93651198 | Eicher Tractor Shim Variable Thickness 0.5         | 15   | 73182100 | 18% |
| 93651204 | Eicher Tractor Crimping Nut                        | 165  | 73181500 | 18% |
| 93651241 | Eicher Tractor Pin Dowel Dia 14X30                 | 102  | 73182100 | 18% |
| 93651253 | Eicher Tractor Bearing Housin                      | 667  | 84099941 | 28% |
| 93651277 | Eicher Tractor Plastic Float                       | 676  | 39021000 | 18% |
| 93651289 | Eicher Tractor Strip For Float                     | 41   | 84099941 | 28% |
| 93651290 | Eicher Tractor Lever For Hi-Low                    | 390  | 87084000 | 18% |
| 93651319 | Eicher Tractor Axle Tube Left-368 M/C              | 8497 | 87084000 | 18% |
| 93651320 | Eicher Tractor Axle Tube Right -368 M/C (Hydromati | 8676 | 87084000 | 18% |
| 93651332 | Eicher Tractor Gasket-Top Cover Front              | 32   | 68129090 | 18% |
| 93651370 | Eicher Tractor Pin Dowel 8X20                      | 33   | 73182100 | 18% |
| 93651381 | Eicher Tractor Gasket For Guide Bush               | 14   | 68129090 | 18% |
| 93651393 | Eicher Tractor Gasket Top Cover                    | 25   | 68129090 | 18% |
| 93651411 | Eicher Tractor Axle Tube Left                      | 8309 | 87084000 | 18% |
| 93651423 | Eicher Tractor Axle Tube Right                     | 8245 | 87084000 | 18% |
| 93651514 | Eicher Tractor P T O Shaft With Bush - 242 Sw      | 3656 | 87084000 | 18% |
| 93651617 | Eicher Tractor Locking Plate                       | 46   | 87084000 | 18% |
| 93651624 | Eicher Tractor Clamping Plate                      | 297  | 87089900 | 18% |
| 93651630 | Eicher Tractor Gasket For Brake Hsg                | 29   | 68129090 | 18% |
| 93651666 | Eicher Tractor Pin Dowel                           | 38   | 73182100 | 18% |
| 93651745 | Eicher Tractor Shifting Rod Rg                     | 254  | 87084000 | 18% |
| 93651757 | Eicher Tractor Bearing Housing                     | 1422 | 84099941 | 28% |
| 93651769 | Eicher Tractor Bearing Housing                     | 1695 | 84099941 | 28% |
| 93651770 | Eicher Tractor Sliding Gear 1/2 Z36/Z31 (Teeth-35/ | 3015 | 87084000 | 18% |
| 93651782 | Eicher Tractor Spur Pinion 2Nd Z22 Gt380S (Teeth-2 | 1029 | 87084000 | 18% |
| 93651794 | Eicher Tractor Spur Pinion 1St Z17 Gt380S (Teeth-1 | 1029 | 87084000 | 18% |
| 93651812 | Eicher Tractor R/Gear Constant Mash Gt380S (Teeth- | 1452 | 87084000 | 18% |
| 93651824 | Eicher Tractor R/Gear Sld Assy Gt380S (Teeth-17)   | 1924 | 87084000 | 18% |
| 93651848 | Eicher Tractor Thrust Washer (Thin)                | 94   | 73182100 | 18% |
| 93651861 | Eicher Tractor Shifter Fork Rg                     | 769  | 87084000 | 18% |
| 93651897 | Eicher Tractor Crown Wheel                         | 8677 | 87084000 | 18% |
| 93651964 | Eicher Tractor Stud M14X38/66(1.5Pitch)            | 42   | 73182100 | 18% |
| 93651976 | Eicher Tractor Special Dowel Bolts                 | 41   | 73181500 | 18% |
| 93651988 | Eicher Tractor Special Bolt                        | 40   | 73181500 | 18% |
| 93652018 | Eicher Tractor F D Pinion Assly 755 Wdb (M) Z14    | 5629 | 87084000 | 18% |
| 93652020 | Eicher Tractor F D Pinion Assly Z13                | 5892 | 87084000 | 18% |
| 93652080 | Eicher Tractor Compound Dowel M14X20               | 31   | 73182100 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93652105 | Eicher Tractor Pto Shaft Front                    | 2167  | 87084000 | 18% |
| 93652129 | Eicher Tractor Pto Shaft Front - 485 Dlx (8620)   | 2136  | 87084000 | 18% |
| 93652191 | Eicher Tractor Reverse Gear Shaft                 | 610   | 87084000 | 18% |
| 93652203 | Eicher Tractor Thrust Washer                      | 146   | 73182100 | 18% |
| 93652215 | Eicher Tractor Bush For Non Hydro Rev Gear        | 182   | 87084000 | 18% |
| 93652227 | Eicher Tractor Reverse Gear C M Non Hydro         | 1669  | 87084000 | 18% |
| 93652232 | Eicher Tractor Vacuator Valve                     | 116   | 40169390 | 18% |
| 93652257 | Eicher Tractor Thrust Spacr Pto                   | 394   | 73182100 | 18% |
| 93652270 | Eicher Tractor Sliding Gear 3/4 - 5660A           | 1985  | 87084000 | 18% |
| 93652282 | Eicher Tractor Spur Pinion 3Rd (24S) - 5660A      | 1788  | 87084000 | 18% |
| 93652324 | Eicher Tractor Spur Pinion 2Nd 5660-A             | 1534  | 87084000 | 18% |
| 93652397 | Eicher Tractor Case Transmission Front (Boss With | 50354 | 87089900 | 18% |
| 93652579 | Eicher Tractor Rev Gear Assly Sliding             | 2121  | 87084000 | 18% |
| 93652580 | Eicher Tractor Reverse Gear Shaft                 | 850   | 87084000 | 18% |
| 93652592 | Eicher Tractor Conical Spring                     | 43    | 73202000 | 18% |
| 93652609 | Eicher Tractor Top Cover Rear                     | 1985  | 87084000 | 18% |
| 93652610 | Eicher Tractor Top Cover Front                    | 1321  | 87084000 | 18% |
| 93652622 | Eicher Tractor Shifter Jaw 1&2                    | 550   | 87084000 | 18% |
| 93652634 | Eicher Tractor Shifter Jaw 3&4                    | 634   | 87084000 | 18% |
| 93652646 | Eicher Tractor Shifter Jaw Reverse                | 506   | 87084000 | 18% |
| 93652658 | Eicher Tractor Shifter Jaw Hi-Lo                  | 520   | 87084000 | 18% |
| 93652660 | Eicher Tractor Shifter Rod 1/2                    | 311   | 87084000 | 18% |
| 93652671 | Eicher Tractor Shifter Rod 3Rd & 4Th              | 267   | 87084000 | 18% |
| 93652683 | Eicher Tractor Shifter Rod Reverse Gear           | 310   | 87084000 | 18% |
| 93652725 | Eicher Tractor Cylindrical Pin, Dia 6*22          | 18    | 87089900 | 18% |
| 93652737 | Eicher Tractor Conical Spring                     | 41    | 73202000 | 18% |
| 93652749 | Eicher Tractor Locking Pin For 3-4 Jaw            | 44    | 87084000 | 18% |
| 93652786 | Eicher Tractor Bracket Push Pull Lever            | 110   | 87089900 | 18% |
| 93652804 | Eicher Tractor Shifter Rod Hi/Low                 | 338   | 87084000 | 18% |
| 93652816 | Eicher Tractor Shifter Fork Hi-Low                | 603   | 87084000 | 18% |
| 93652828 | Eicher Tractor Pto Shaft Front (Hydro Gpto)       | 2673  | 87084000 | 18% |
| 93652830 | Eicher Tractor Lay Shaft-2 - (Ground Pto)         | 2989  | 87084000 | 18% |
| 93652841 | Eicher Tractor Nave Assembly-Gpto Hydro           | 350   | 87084000 | 18% |
| 93652889 | Eicher Tractor Shaft Diff Lock                    | 363   | 87084000 | 18% |
| 93652919 | Eicher Tractor Fork Diff Lock                     | 859   | 87084000 | 18% |
| 93652920 | Eicher Tractor Pedal Diff Lock                    | 746   | 87084000 | 18% |
| 93652932 | Eicher Tractor Pivot Bolt M10                     | 54    | 73181500 | 18% |
| 93652944 | Eicher Tractor Lock Plate                         | 52    | 87084000 | 18% |
| 93652970 | Eicher Tractor Sliding Gear 1/2 - 364             | 3643  | 87084000 | 18% |
| 93652993 | Eicher Tractor Spur Pinion 2Nd - 364              | 1371  | 87084000 | 18% |
| 93653031 | Eicher Tractor Shifter Fork Reverse Gear          | 738   | 87084000 | 18% |
| 93653043 | Eicher Tractor Shifter Rod R.G                    | 324   | 87089900 | 18% |
| 93653055 | Eicher Tractor Shifter Fork 1/2                   | 735   | 87084000 | 18% |
| 93653067 | Eicher Tractor Shifter Rod 1/2                    | 425   | 87084000 | 18% |
| 93653122 | Eicher Tractor Case Transmission Front Machined   | 42045 | 87089900 | 18% |
| 93653146 | Eicher Tractor Pto Shaft Rear 540 Sw (New)        | 3163  | 87084000 | 18% |
| 93653158 | Eicher Tractor Spacer Pto Shaft Rear              | 144   | 73182100 | 18% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93653183 | Eicher Tractor Pto Shaft 540 - 50Hp (Rel)          | 4173   | 87084000 | 18% |
| 93653201 | Eicher Tractor Pto Shaft 540-485 Dlx - Rel         | 4212   | 87084000 | 18% |
| 93653237 | Eicher Tractor Pto Shaft Front - Dlx (En-19)       | 2921   | 87084000 | 18% |
| 93653262 | Eicher Tractor Guide Sleeve Integral               | 2738   | 87084000 | 18% |
| 93653286 | Eicher Tractor High Low Lever                      | 1181   | 87084000 | 18% |
| 93653298 | Eicher Tractor Gear Shift Lever Assly              | 976    | 87084000 | 18% |
| 93653304 | Eicher Tractor Hi/Low Lever Assly                  | 742    | 87084000 | 18% |
| 93653353 | Eicher Tractor Shifter Rod 3/4                     | 253    | 87084000 | 18% |
| 93653390 | Eicher Tractor Shifter Fork Rg/5150Ind/548/485 Non | 755    | 87084000 | 18% |
| 93653421 | Eicher Tractor 557- G1 Assy                        | 143502 | 87084000 | 18% |
| 93653456 | Eicher Tractor Axle Tube Rh Assembly               | 119269 | 87084000 | 18% |
| 93653493 | Eicher Tractor Cover G1 Top                        | 3050   | 87084000 | 18% |
| 93653511 | Eicher Tractor Engaging Dog                        | 880    | 87084000 | 18% |
| 93653523 | Eicher Tractor Gear Housing Front Dlx - (5150 I-   | 18118  | 87084000 | 18% |
| 93653535 | Eicher Tractor Gear Housing Front Dlx Exp (5150-Ia | 19397  | 87084000 | 18% |
| 93653663 | Eicher Tractor Case Transmission Rear              | 39999  | 87089900 | 18% |
| 93653687 | Eicher Tractor Intermediate Shaft-(5150-1A) Rel    | 3035   | 87084000 | 18% |
| 93653699 | Eicher Tractor Spacer Cmg                          | 26     | 73182100 | 18% |
| 93653705 | Eicher Tractor Gasket Ctr - Ctf Joint              | 776    | 84841090 | 18% |
| 93653717 | Eicher Tractor Spacer For Lay Shaft                | 75     | 73182100 | 18% |
| 93653780 | Eicher Tractor Pto Shaft Front - Sw (Relb)         | 2699   | 87084000 | 18% |
| 93653791 | Eicher Tractor Shifter Rod 3/4                     | 291    | 87084000 | 18% |
| 93653821 | Eicher Tractor Housing For Bearing                 | 931    | 84099941 | 28% |
| 93653882 | Eicher Tractor Pto Shaft 540 S/W (Dia 40)          | 2744   | 87084000 | 18% |
| 93653894 | Eicher Tractor Spacer Pto Shaft Rear               | 99     | 73182100 | 18% |
| 93653948 | Eicher Tractor Ctr Machined (Side Shift With Diff. | 38499  | 87084000 | 18% |
| 93654096 | Eicher Tractor Gasket For Inspection               | 61     | 68129090 | 18% |
| 93654310 | Eicher Tractor Socket Head Pin M10                 | 52     | 82041110 | 18% |
| 93654321 | Eicher Tractor Roller Dia 205*3.2                  | 24     | 84824000 | 18% |
| 93654333 | Eicher Tractor Pto Shaft 540 - S/W (Dia 52)        | 5843   | 87084000 | 18% |
| 93654345 | Eicher Tractor Cover Pto Shaft Rear                | 2540   | 87084000 | 18% |
| 93654357 | Eicher Tractor Mud Cover For Pto Shaft Rear        | 508    | 87084000 | 18% |
| 93654369 | Eicher Tractor Lock Nut M65X1.5                    | 398    | 73181500 | 18% |
| 93654370 | Eicher Tractor Gasket For Pto Cover                | 13     | 68129090 | 18% |
| 93654382 | Eicher Tractor Case Transmission Rear (Side Shift) | 57150  | 87089900 | 18% |
| 93654394 | Eicher Tractor Protective Cap For Pto              | 51     | 87085000 | 18% |
| 93654400 | Eicher Tractor Cassette Seal 36X68X12              | 523    | 87089900 | 18% |
| 93654424 | Eicher Tractor Taper Roller Bearing JI69349/10     | 655    | 84822011 | 18% |
| 93654436 | Eicher Tractor Ctr Ø 80                            | 58278  | 87089900 | 18% |
| 93654497 | Eicher Tractor Oil Dipstic (Power Stg)             | 110    | 87089400 | 18% |
| 93654527 | Eicher Tractor Gear Housing Rear (5660)            | 54542  | 87084000 | 18% |
| 93654539 | Eicher Tractor Transmission Housing Rear (Dlx)     | 53943  | 87089900 | 18% |
| 93654540 | Eicher Tractor Pto Shaft 540- Assy 50Hp Dia 50 (5  | 5480   | 87084000 | 18% |
| 93654552 | Eicher Tractor Pto Shaft 540- Assy Dia 50 (5150)   | 4799   | 87084000 | 18% |
| 93654588 | Eicher Tractor Fd Gear                             | 11873  | 87084000 | 18% |
| 93654722 | Eicher Tractor Cassette Seal 35X56X12              | 831    | 87089900 | 18% |
| 93654734 | Eicher Tractor Sld Pin 3/4 380/50Hp Rel - Fin      | 598    | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93654746 | Eicher Tractor Spur Gear 3Rd 380 Rel Fin           | 1160  | 87084000 | 18% |
| 93654758 | Eicher Tractor Shifter Rod 3/4                     | 247   | 87084000 | 18% |
| 93654760 | Eicher Tractor Shifter Fork 3/4                    | 815   | 87084000 | 18% |
| 93654771 | Eicher Tractor Pto Shaft Rear 540 Sw (Dia-40-2)    | 2744  | 87084000 | 18% |
| 93654783 | Eicher Tractor Cover Pto                           | 395   | 87084000 | 18% |
| 93654795 | Eicher Tractor Mud Seal (Tss)                      | 286   | 87089900 | 18% |
| 93654801 | Eicher Tractor Gear Shifter Lever                  | 1223  | 87084000 | 18% |
| 93654813 | Eicher Tractor Pto Assy - 5660                     | 10090 | 87084000 | 18% |
| 93654825 | Eicher Tractor Pto Assy 380                        | 9555  | 87084000 | 18% |
| 93654837 | Eicher Tractor Pto Assy Nonhydromatic              | 8038  | 87084000 | 18% |
| 93654850 | Eicher Tractor Double Clutch                       | 27620 | 87089300 | 18% |
| 93654874 | Eicher Tractor Double Clutch                       | 27695 | 87089300 | 18% |
| 93654886 | Eicher Tractor Main Driven Plate                   | 5479  | 87089300 | 18% |
| 93654898 | Eicher Tractor Driven Plate Assy.                  | 5394  | 87089300 | 18% |
| 93654916 | Eicher Tractor Pto Shaft Front -557 (50Hp) - Fin   | 4107  | 87084000 | 18% |
| 93654989 | Eicher Tractor Shifter Rod Pto                     | 342   | 87084000 | 18% |
| 93655039 | Eicher Tractor Spring Retainer Pto                 | 14    | 73202000 | 18% |
| 93655064 | Eicher Tractor Shifter Fork Pto                    | 773   | 87084000 | 18% |
| 93655076 | Eicher Tractor Shifter Rod 3/4 (Ss)                | 329   | 87084000 | 18% |
| 93655088 | Eicher Tractor Top Cover Rear (Ss)                 | 1838  | 87084000 | 18% |
| 93655090 | Eicher Tractor Knob                                | 143   | 87084000 | 18% |
| 93655106 | Eicher Tractor Oil Dipistick                       | 143   | 87084000 | 18% |
| 93655131 | Eicher Tractor F D P Shaft Assly - 5131 Finished   | 5317  | 87084000 | 18% |
| 93655180 | Eicher Tractor Centre Housing Rear (Diff Lock)     | 44553 | 87084000 | 18% |
| 93655192 | Eicher Tractor Driven Plate Assy (Pto)             | 4720  | 87089300 | 18% |
| 93655560 | Eicher Tractor Fdp Shaft - Z13 - 5560 - Fin        | 6192  | 87084000 | 18% |
| 93655647 | Eicher Tractor Pedal Diff Lock                     | 770   | 87084000 | 18% |
| 93655660 | Eicher Tractor Assy. Pto Shaft 540 (Hydro) Sw      | 5267  | 87084000 | 18% |
| 93655672 | Eicher Tractor Pto Front Gpto - 5672               | 3933  | 87084000 | 18% |
| 93655684 | Eicher Tractor Pto Shaft Front (Hydro Non-Gpto)Sw  | 2867  | 87084000 | 18% |
| 93655715 | Eicher Tractor Pto Cover                           | 631   | 87084000 | 18% |
| 93655727 | Eicher Tractor Crimping Nut                        | 306   | 73181500 | 18% |
| 93655739 | Eicher Tractor Assy Pto Shaft Rear (R-Pto)         | 3539  | 87084000 | 18% |
| 93655751 | Eicher Tractor Final Drive Gear                    | 12596 | 87084000 | 18% |
| 93655785 | Eicher Tractor Spring Retainer (Hi-Lo)             | 7     | 73202000 | 18% |
| 93655799 | Eicher Tractor Assy Differential Housing           | 4383  | 87084000 | 18% |
| 93655921 | Eicher Tractor F D Pinion Shaft Left Z-13          | 5190  | 87084000 | 18% |
| 93655933 | Eicher Tractor Ascending Disc                      | 46    | 87084000 | 18% |
| 93656056 | Eicher Tractor Assembly Differential Housing       | 6452  | 87084000 | 18% |
| 93656068 | Eicher Tractor Pto Shaft 540 - 50Hp-6068 -Inductio | 5460  | 87084000 | 18% |
| 93656081 | Eicher Tractor Pto Shaft 540 - 485Dlx - 6081 Induc | 5020  | 87084000 | 18% |
| 93656100 | Eicher Tractor Case Transmission Front.            | 50490 | 87089900 | 18% |
| 93656263 | Eicher Tractor Case Transmission Front (Industrial | 52029 | 87089900 | 18% |
| 93656318 | Eicher Tractor Guide Sleeve                        | 1614  | 73182100 | 18% |
| 93656320 | Eicher Tractor Gasket For Guide Sleevef Fwh        | 12    | 68129922 | 18% |
| 93656355 | Eicher Tractor Spacer For Cm Gear                  | 200   | 73182100 | 18% |
| 93656367 | Eicher Tractor Hard Spacer For Cm Gear             | 226   | 73182100 | 18% |





|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93656379 | Eicher Tractor Primary Shaft - Dc (Z-25)           | 6053 | 87084000 | 18% |
| 93656380 | Eicher Tractor Pto Drive Shaft (Z-16)              | 3227 | 87084000 | 18% |
| 93656469 | Eicher Tractor Gasket Top Cover Front              | 49   | 68129922 | 18% |
| 93656524 | Eicher Tractor Gasket For Top Cover Rear           | 34   | 68129922 | 18% |
| 93656536 | Eicher Tractor Top Cover Front (Ss)                | 3282 | 87084000 | 18% |
| 93656550 | Eicher Tractor Shifter Rod Rev. Gear (Ss)          | 425  | 87089900 | 18% |
| 93656561 | Eicher Tractor Shifter Rod 1&2 Ss                  | 450  | 87089900 | 18% |
| 93656573 | Eicher Tractor Shifter Rod 3&4 (Ss)                | 519  | 87084000 | 18% |
| 93656585 | Eicher Tractor Shifter Rod H/L (Ss)                | 471  | 87089900 | 18% |
| 93656597 | Eicher Tractor Top Cover Rear (Ss)                 | 2558 | 87084000 | 18% |
| 93656615 | Eicher Tractor Engaging Handle (F)                 | 520  | 87084000 | 18% |
| 93656627 | Eicher Tractor Nave Assembly Gpto/Non Gpto Hyd     | 578  | 87084000 | 18% |
| 93656639 | Eicher Tractor Pto Actuator Assy                   | 749  | 87084000 | 18% |
| 93656640 | Eicher Tractor Nave For Pto                        | 517  | 87084000 | 18% |
| 93656652 | Eicher Tractor Pto Link Assy                       | 146  | 87084000 | 18% |
| 93656664 | Eicher Tractor Assy. Differential Housing (South)  | 8812 | 87084000 | 18% |
| 93656690 | Eicher Tractor Diff. Star Pinion                   | 1008 | 87084000 | 18% |
| 93656728 | Eicher Tractor Thrust Washer                       | 116  | 73182100 | 18% |
| 93656730 | Eicher Tractor Spacer For Nrb                      | 100  | 73182100 | 18% |
| 93656741 | Eicher Tractor Needle Roller 4X16.80               | 8    | 84824000 | 18% |
| 93656753 | Eicher Tractor Diff Shaft 3 Star                   | 1090 | 87084000 | 18% |
| 93656809 | Eicher Tractor Gasket Ctr - Ctf Joint              | 82   | 68129922 | 18% |
| 93656822 | Eicher Tractor Axle Tube-01                        | 9114 | 87084000 | 18% |
| 93656860 | Eicher Tractor Hex Flange Screw M12X1.25X27,12.9   | 34   | 73181500 | 18% |
| 93656871 | Eicher Tractor Hex Flange Screw M12X1.25X35,12.9   | 37   | 73181500 | 18% |
| 93656883 | Eicher Tractor Disc Assy (Complete)                | 731  | 87089300 | 18% |
| 93656895 | Eicher Tractor Thrust Washer (Bar Stock)           | 200  | 73182100 | 18% |
| 93656925 | Eicher Tractor Reverse Gear Shaft                  | 774  | 87084000 | 18% |
| 93656986 | Eicher Tractor Pto C M Gear (Z-53)                 | 4232 | 87084000 | 18% |
| 93656998 | Eicher Tractor Shifter Fork Rg                     | 826  | 87084000 | 18% |
| 93657034 | Eicher Tractor Sliding Rod Hi-Low                  | 677  | 87089900 | 18% |
| 93657103 | Eicher Tractor Nave Assy                           | 487  | 87084000 | 18% |
| 93657115 | Eicher Tractor M12 Special Bolt                    | 335  | 73181500 | 18% |
| 93657139 | Eicher Tractor Pto Link                            | 383  | 87089900 | 18% |
| 93657176 | Eicher Tractor Top Cover Rear Ss (H-Type)          | 3960 | 87084000 | 18% |
| 93657188 | Eicher Tractor Shifting Jaw Rev                    | 713  | 87084000 | 18% |
| 93657190 | Eicher Tractor Shifting Jaw 1St & 2Nd              | 855  | 87084000 | 18% |
| 93657206 | Eicher Tractor Shifting Jaw 3Rd/4Th                | 778  | 87084000 | 18% |
| 93657243 | Eicher Tractor Gasket For Side Cover               | 23   | 68129090 | 18% |
| 93657267 | Eicher Tractor Main Gear Knob (H-Type)             | 170  | 87084000 | 18% |
| 93657310 | Eicher Tractor Sliding Gear 1/2Nd Z39/45 (7310) -  | 3649 | 87084000 | 18% |
| 93657322 | Eicher Tractor Sliding Pinion 3/4Th Z33 (7322) - 3 | 3129 | 87084000 | 18% |
| 93657334 | Eicher Tractor Spur Pinion 1St Z21 (7334) - 30Hp   | 1211 | 87084000 | 18% |
| 93657346 | Eicher Tractor Spur Pinion 2Nd Z30 (7346) - 30Hp   | 1560 | 87084000 | 18% |
| 93657358 | Eicher Tractor Spur Gear 3Rd Z34 (7358) - 30Hp     | 1276 | 87084000 | 18% |
| 93657371 | Eicher Tractor Primary Shaft - New 30Hp (Teeth-26) | 3500 | 87084000 | 18% |
| 93657395 | Eicher Tractor Rear Axle Shaft Z14 (7395) - 30Hp   | 8306 | 87084000 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93657407 | Eicher Tractor Intermediate Shaft Z23 (7401) - 30H | 2904 | 87084000 | 18% |
| 93657413 | Eicher Tractor Final Drive Gear - High Speed       | 7965 | 87084000 | 18% |
| 93657528 | Eicher Tractor Sticker Implement & Pto Application | 51   | 39199090 | 18% |
| 93657530 | Eicher Tractor Gasket Top Cover Rear               | 52   | 68129090 | 18% |
| 93657541 | Eicher Tractor Gasket-Top Cover Front              | 67   | 68129090 | 18% |
| 93657553 | Eicher Tractor Dipstick Ps                         | 141  | 87084000 | 18% |
| 93657590 | Eicher Tractor Reverse Gear Cm Z23 (7590) - 30Hp   | 1484 | 87084000 | 18% |
| 93657607 | Eicher Tractor Assly Reverse Gear Sld Z21 (7607) - | 1713 | 87084000 | 18% |
| 93657619 | Eicher Tractor Spring For G.S. Lever               | 10   | 73202000 | 18% |
| 93657620 | Eicher Tractor Guide Plate                         | 105  | 87084000 | 18% |
| 93657644 | Eicher Tractor Gear Selector Rod Assly             | 2096 | 87084000 | 18% |
| 93657656 | Eicher Tractor Plug M10                            | 26   | 87084000 | 18% |
| 93657723 | Eicher Tractor Cover Reduction Housing             | 4073 | 87089900 | 18% |
| 93657735 | Eicher Tractor Gasket (Reduction Housing)          | 124  | 68129090 | 18% |
| 93657747 | Eicher Tractor Shifter Rod 1St & 2Nd               | 419  | 87084000 | 18% |
| 93657980 | Eicher Tractor Crb Nj 306                          | 1304 | 87089900 | 18% |
| 93658004 | Eicher Tractor Assy Differential Hsg-South         | 9288 | 87084000 | 18% |
| 93658090 | Eicher Tractor Nave Assy (Non Hyd)                 | 301  | 87084000 | 18% |
| 93658120 | Eicher Tractor Cover Pto Shaft Rear                | 2540 | 87084000 | 18% |
| 93658144 | Eicher Tractor Assembly Pto Shaft 540 (Hyd)        | 4897 | 87084000 | 18% |
| 93658156 | Eicher Tractor Spacer Thrust Pto                   | 172  | 73182100 | 18% |
| 93658170 | Eicher Tractor Oil Seal 18*30*7                    | 98   | 40169330 | 18% |
| 93658211 | Eicher Tractor Clutch Cover Assy 11" (North)       | 3877 | 87089300 | 18% |
| 93658223 | Eicher Tractor Clutch Release Bearing Assy.        | 3996 | 87083000 | 18% |
| 93658259 | Eicher Tractor Assly Pto Shaft 540-Dlx (58259)     | 4375 | 87084000 | 18% |
| 93658272 | Eicher Tractor Assembly Pto Shaft 540 (50 Hp)      | 4989 | 87084000 | 18% |
| 93658284 | Eicher Tractor Pto Lever                           | 1261 | 87084000 | 18% |
| 93658302 | Eicher Tractor Pto Knob Mspto                      | 114  | 87084000 | 18% |
| 93658326 | Eicher Tractor Spacer Pto Lever Brake Hsg          | 55   | 73182100 | 18% |
| 93658338 | Eicher Tractor Pto Link Ddb                        | 98   | 87084000 | 18% |
| 93658340 | Eicher Tractor Pto Link Wdb                        | 131  | 87089900 | 18% |
| 93658417 | Eicher Tractor M12X100 Special Bolt                | 293  | 73181500 | 18% |
| 93658429 | Eicher Tractor M12X92 Special Bolt                 | 322  | 73181500 | 18% |
| 93658466 | Eicher Tractor Pto Knob Single Pto                 | 114  | 87084000 | 18% |
| 93658545 | Eicher Tractor Pto Knob Big                        | 195  | 87084000 | 18% |
| 93658636 | Eicher Tractor Assembly Diff. Housing I.A          | 7243 | 87084000 | 18% |
| 93658650 | Eicher Tractor Differential Housing (South)        | 7738 | 87084000 | 18% |
| 93658661 | Eicher Tractor Assy. Differential Housing          | 7613 | 87084000 | 18% |
| 93658685 | Eicher Tractor Assy. Differential Housing          | 7130 | 87084000 | 18% |
| 93658697 | Eicher Tractor Guide Sleeve Integral               | 192  | 87084000 | 18% |
| 93658703 | Eicher Tractor Cover G1 Top                        | 3589 | 87084000 | 18% |
| 93658752 | Eicher Tractor F D Pinion Shaft Left Z-13          | 5340 | 87084000 | 18% |
| 93658764 | Eicher Tractor F D Pinion Shaft Left Z14           | 5301 | 87084000 | 18% |
| 93658806 | Eicher Tractor Diff Star Pinion                    | 642  | 87084000 | 18% |
| 93658818 | Eicher Tractor Diff.Star Pinion                    | 711  | 87084000 | 18% |
| 93658820 | Eicher Tractor Axial Star Pinion                   | 1265 | 87084000 | 18% |
| 93658910 | Eicher Tractor Pto Actuator Assy                   | 429  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93658922 | Eicher Tractor Cover G1 Top                    | 4371  | 87084000 | 18% |
| 93658983 | Eicher Tractor Shifter Fork Rg                 | 539   | 87084000 | 18% |
| 93658995 | Eicher Tractor Side Cover                      | 313   | 87084000 | 18% |
| 93659033 | Eicher Tractor Gasket - Top Cover Front        | 57    | 68129090 | 18% |
| 93659082 | Eicher Tractor Gasket G1 Top Cover             | 87    | 68129090 | 18% |
| 93659161 | Eicher Tractor Reverse Gear Assy (Z-17)        | 2158  | 87084000 | 18% |
| 93659469 | Eicher Tractor Cr Pto Shaft Front              | 3973  | 87084000 | 18% |
| 93659481 | Eicher Tractor Cr Intermediate Shaft Rear      | 6773  | 87084000 | 18% |
| 93659493 | Eicher Tractor Cr Shifter Rod Hi/Low           | 690   | 87084000 | 18% |
| 93659501 | Eicher Tractor Cr Guide Plate For Pto          | 521   | 87084000 | 18% |
| 93659513 | Eicher Tractor Cr Pto Shaft Assembly Rear      | 2954  | 87084000 | 18% |
| 93659525 | Eicher Tractor Cr Bearing Retainer             | 80    | 84821011 | 18% |
| 93659537 | Eicher Tractor Cr Spline Hub G1                | 1047  | 87084000 | 18% |
| 93659549 | Eicher Tractor Cr Pto Actuating Lever          | 333   | 87084000 | 18% |
| 93659550 | Eicher Tractor Cr Shifting Guide Rod           | 435   | 87084000 | 18% |
| 93659562 | Eicher Tractor Cr Special Bolt M10             | 86    | 73181500 | 18% |
| 93659574 | Eicher Tractor Cr Spline Hub G2                | 800   | 87084000 | 18% |
| 93659586 | Eicher Tractor Cr Retaining Spring             | 14    | 73202000 | 18% |
| 93659598 | Eicher Tractor Cr Engaging Dog                 | 1326  | 87084000 | 18% |
| 93659604 | Eicher Tractor Cr Circlip A 42 X 2.5 H Is:3075 | 27    | 73182910 | 18% |
| 93659641 | Eicher Tractor Cr Gear Hsg (Rear R - Pto 557)  | 71237 | 87084000 | 18% |
| 93659665 | Eicher Tractor Cr Bearing Housing              | 1384  | 84821011 | 18% |
| 93659677 | Eicher Tractor Cr Engaging Handle              | 1807  | 87084000 | 18% |
| 93659689 | Eicher Tractor Cr Supporting Block             | 2089  | 87089900 | 18% |
| 93659707 | Eicher Tractor Cr Spline Spacer 2Mm            | 126   | 87089400 | 18% |
| 93659719 | Eicher Tractor Cr Washer 2Mm                   | 156   | 73182100 | 18% |
| 93659720 | Eicher Tractor Cr 2Nd Gear Creeper Z-29        | 2841  | 87084000 | 18% |
| 93659732 | Eicher Tractor Cr Cluster Pinion Z18           | 2194  | 87084000 | 18% |
| 93659744 | Eicher Tractor Cr Cluster Shaft                | 2254  | 87084000 | 18% |
| 93659756 | Eicher Tractor Cr Housing Creeper Box          | 4233  | 87084000 | 18% |
| 93659767 | Eicher Tractor Cr Gasket Drop Box              | 65    | 68129090 | 18% |
| 93659779 | Eicher Tractor Cr Shifter Lever Assembly       | 996   | 87084000 | 18% |
| 93659780 | Eicher Tractor Cr Direct Hand Knob             | 186   | 87084000 | 18% |
| 93659792 | Eicher Tractor Cr Sticker Lever                | 71    | 39199090 | 18% |
| 93659800 | Eicher Tractor Cr Locking Pin Ball Assembly    | 909   | 87084000 | 18% |
| 93659811 | Eicher Tractor Cr Spur Pinion 1St              | 1885  | 87084000 | 18% |
| 93659823 | Eicher Tractor Cr H/L Pinion Z-23              | 1664  | 87084000 | 18% |
| 93659835 | Eicher Tractor Cr Spur Gear 1St                | 4270  | 87084000 | 18% |
| 93659847 | Eicher Tractor Cr 1St Pinion Creeper Assembly  | 1989  | 87084000 | 18% |
| 93659872 | Eicher Tractor Cr Shifter Fork                 | 1768  | 87084000 | 18% |
| 93659926 | Eicher Tractor Cr Bearing Nup 1013             | 1522  | 84821011 | 18% |
| 93659951 | Eicher Tractor Gear Housing Front              | 20963 | 87084000 | 18% |
| 93659975 | Eicher Tractor Gear Shift Lever                | 1147  | 87084000 | 18% |
| 93659999 | Eicher Tractor Cr Layshaft Rear Assembly       | 2952  | 87084000 | 18% |
| 93660138 | Eicher Tractor Pto Cover Upper                 | 449   | 87084000 | 18% |
| 93660163 | Eicher Tractor Ball Bearing 6016-2Rsr/C4       | 1613  | 84822090 | 18% |
| 93660217 | Eicher Tractor Coupling Fork Main              | 1609  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93660230 | Eicher Tractor Nrb (Nw31X46X27.2)                  | 581   | 84822090 | 18% |
| 93660242 | Eicher Tractor O Ring -267X3 Nbr Es 01 It31        | 240   | 40169340 | 18% |
| 93660254 | Eicher Tractor Rev Gear Input -60-Hp               | 1784  | 87084000 | 18% |
| 93660266 | Eicher Tractor Synchro Assy F-R                    | 18984 | 87084000 | 18% |
| 93660280 | Eicher Tractor Rev Gear Layshaft -60-Hp            | 1637  | 87084000 | 18% |
| 93660291 | Eicher Tractor Gear 1-Laysft Rev -60-Hp            | 1595  | 87084000 | 18% |
| 93660308 | Eicher Tractor Gear 2-Laysft Rev -60-Hp            | 1798  | 87084000 | 18% |
| 93660310 | Eicher Tractor Spacer Rev Lay Shaft                | 281   | 87084000 | 18% |
| 93660321 | Eicher Tractor Rev Idler Gear -60-Hp               | 1160  | 87084000 | 18% |
| 93660333 | Eicher Tractor Nrb B25X31X20                       | 146   | 84822090 | 18% |
| 93660345 | Eicher Tractor Shaft Reverse Idler                 | 1903  | 87084000 | 18% |
| 93660357 | Eicher Tractor Spacer Rev. Idler                   | 47    | 73182100 | 18% |
| 93660370 | Eicher Tractor Shifter Rod F-R                     | 407   | 87084000 | 18% |
| 93660382 | Eicher Tractor Shifter Fork F-R                    | 1016  | 87084000 | 18% |
| 93660394 | Eicher Tractor Operating Lever F-R                 | 338   | 87089900 | 18% |
| 93660424 | Eicher Tractor Gasket Cover F/W Housing            | 42    | 68129090 | 18% |
| 93660436 | Eicher Tractor Hub Medium & Pto                    | 858   | 87084000 | 18% |
| 93660448 | Eicher Tractor Ring Gear                           | 22696 | 87084000 | 18% |
| 93660450 | Eicher Tractor Gasket F/W Hsg To Mid Hsg           | 117   | 68129090 | 18% |
| 93660461 | Eicher Tractor Tractor Hsg. Tran Front Machining 8 | 45490 | 87083000 | 18% |
| 93660473 | Eicher Tractor Oil Seal 28X35X7 Is:5129-1979       | 105   | 40169330 | 18% |
| 93660485 | Eicher Tractor Pin Dowel 10X30                     | 26    | 73182100 | 18% |
| 93660497 | Eicher Tractor Cover Shifter                       | 2865  | 87089900 | 18% |
| 93660503 | Eicher Tractor Crown Wheel                         | 22882 | 87084000 | 18% |
| 93660515 | Eicher Tractor Differential Housing                | 3460  | 87084000 | 18% |
| 93660527 | Eicher Tractor Main Shaft                          | 2917  | 87084000 | 18% |
| 93660539 | Eicher Tractor Rev Gear Output -60-Hp              | 2084  | 87084000 | 18% |
| 93660540 | Eicher Tractor Spacer Coupling Shaft               | 40    | 87089900 | 18% |
| 93660552 | Eicher Tractor Stopper Pin                         | 42    | 73182100 | 18% |
| 93660588 | Eicher Tractor Gear 4Th                            | 2694  | 87084000 | 18% |
| 93660590 | Eicher Tractor Spacing Bush 1St                    | 1138  | 87089900 | 18% |
| 93660620 | Eicher Tractor Synchro Assy 1-2,3-4                | 23687 | 87084000 | 18% |
| 93660631 | Eicher Tractor Gear 3Rd -6                         | 2222  | 87084000 | 18% |
| 93660643 | Eicher Tractor Spacing Bush 2Nd                    | 1138  | 87089900 | 18% |
| 93660655 | Eicher Tractor Pinion 2Nd -6                       | 2366  | 87084000 | 18% |
| 93660667 | Eicher Tractor Spacing Bush 3Rd                    | 1138  | 87089900 | 18% |
| 93660680 | Eicher Tractor Pinion 1St -                        | 1888  | 87084000 | 18% |
| 93660692 | Eicher Tractor Spacing Bush 4Th                    | 1138  | 87089900 | 18% |
| 93660709 | Eicher Tractor Lay Shaft Speed -60-Hp              | 6062  | 87089900 | 18% |
| 93660710 | Eicher Tractor Cyl. Roller Bearing Nup2210         | 1632  | 84822090 | 18% |
| 93660722 | Eicher Tractor Planet Gear ( Z=26)                 | 2708  | 87084000 | 18% |
| 93660734 | Eicher Tractor Gear 1St                            | 2706  | 87084000 | 18% |
| 93660746 | Eicher Tractor Spacer Layshaft Speed               | 411   | 87084000 | 18% |
| 93660758 | Eicher Tractor Gear 2Nd 60 Hp                      | 2636  | 87084000 | 18% |
| 93660760 | Eicher Tractor Pinion 3Rd -6                       | 2368  | 87084000 | 18% |
| 93660771 | Eicher Tractor Pinion 4Th -6                       | 1619  | 87084000 | 18% |
| 93660813 | Eicher Tractor Layshaft Range                      | 7860  | 82060090 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93660825 | Eicher Tractor Gear Hi -60-Hp                       | 1369  | 87084000 | 18% |
| 93660837 | Eicher Tractor Pinion Med -60                       | 2878  | 87084000 | 18% |
| 93660904 | Eicher Tractor Shifter Coupling                     | 905   | 87089900 | 18% |
| 93660916 | Eicher Tractor Flange Differential                  | 2430  | 87084000 | 18% |
| 93660930 | Eicher Tractor Spacer Medium Pinion                 | 121   | 73182100 | 18% |
| 93660941 | Eicher Tractor Crown Pinion Shaft                   | 9240  | 87084000 | 18% |
| 93660953 | Eicher Tractor Spacer Pilot                         | 74    | 73182100 | 18% |
| 93660965 | Eicher Tractor Stopper Pin Small                    | 20    | 73182100 | 18% |
| 93660989 | Eicher Tractor Hub High-Low                         | 841   | 87085000 | 18% |
| 93660990 | Eicher Tractor Spacer Internal Low                  | 141   | 73182100 | 18% |
| 93661015 | Eicher Tractor Spacer Internal Low1                 | 121   | 73182100 | 18% |
| 93661039 | Eicher Tractor Gear Low -60                         | 5063  | 87084000 | 18% |
| 93661076 | Eicher Tractor Gear Med -6                          | 2396  | 87084000 | 18% |
| 93661088 | Eicher Tractor Buffer Ring 75.79X3.53               | 335   | 87089900 | 18% |
| 93661090 | Eicher Tractor Bearing Cage                         | 1882  | 87084000 | 18% |
| 93661106 | Eicher Tractor Gasket Mid Hsg. Rear Hsg.            | 124   | 68129090 | 18% |
| 93661118 | Eicher Tractor Shifter Rod 1/2                      | 777   | 87084000 | 18% |
| 93661120 | Eicher Tractor Shifter Rod 3/4                      | 715   | 87084000 | 18% |
| 93661143 | Eicher Tractor Shifter Rod H/L                      | 623   | 87084000 | 18% |
| 93661167 | Eicher Tractor Shifter Rod Medium                   | 744   | 87084000 | 18% |
| 93661179 | Eicher Tractor Shifter Fork 1/2                     | 1248  | 87084000 | 18% |
| 93661180 | Eicher Tractor Shifter Fork 3/4                     | 967   | 87084000 | 18% |
| 93661209 | Eicher Tractor Shifter Fork Hi-Low                  | 1711  | 87084000 | 18% |
| 93661210 | Eicher Tractor Shifter Fork Medium                  | 1068  | 87084000 | 18% |
| 93661234 | Eicher Tractor Shifter Block Med & 3/4              | 589   | 87084000 | 18% |
| 93661258 | Eicher Tractor Shifter Block 1/2                    | 541   | 87084000 | 18% |
| 93661325 | Eicher Tractor Lever Assy Range                     | 586   | 87089900 | 18% |
| 93661337 | Eicher Tractor Tractor Hsg. Tran Rear Machining 85H | 82678 | 87089900 | 18% |
| 93661349 | Eicher Tractor Spacer Rev Idler Rear                | 345   | 73182100 | 18% |
| 93661350 | Eicher Tractor Dipstick                             | 203   | 87084000 | 18% |
| 93661374 | Eicher Tractor Adjusting Screw                      | 1575  | 73181500 | 18% |
| 93661386 | Eicher Tractor Locking Bolt M16,Planetary Carrier   | 88    | 73181500 | 18% |
| 93661398 | Eicher Tractor Axle Tube                            | 18083 | 87084000 | 18% |
| 93661404 | Eicher Tractor Rear Shaft                           | 8179  | 87084000 | 18% |
| 93661430 | Eicher Tractor Gasket - Retainer Axle Tube          | 49    | 68129090 | 18% |
| 93661453 | Eicher Tractor Sun Shaft (Z-15)                     | 5703  | 87084000 | 18% |
| 93661465 | Eicher Tractor Lock Plate                           | 268   | 87084000 | 18% |
| 93661478 | Eicher Tractor Intermediate Plate                   | 2140  | 87083000 | 18% |
| 93661489 | Eicher Tractor Top Cover Front                      | 3320  | 68129090 | 18% |
| 93661519 | Eicher Tractor Selector Lever O/B                   | 387   | 87084000 | 18% |
| 93661544 | Eicher Tractor Fork Diff. Lock                      | 1624  | 87084000 | 18% |
| 93661556 | Eicher Tractor Planet Career Mach                   | 5136  | 87084000 | 18% |
| 93661611 | Eicher Tractor Selector Lever I/B                   | 485   | 87084000 | 18% |
| 93661623 | Eicher Tractor Selector Rod Range                   | 379   | 87084000 | 18% |
| 93661635 | Eicher Tractor Selector Rod Speed                   | 329   | 87084000 | 18% |
| 93661672 | Eicher Tractor Gasket For Axle Tube                 | 260   | 68129090 | 18% |
| 93661702 | Eicher Tractor Gasket Top Cover Front               | 74    | 68129090 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93661714 | Eicher Tractor Gasket Top Cover             | 96   | 68129090 | 18% |
| 93661726 | Eicher Tractor Gasket Pto Cover Upper       | 28   | 68129090 | 18% |
| 93661738 | Eicher Tractor Gasket Pto Cover Lower       | 29   | 68129090 | 18% |
| 93661740 | Eicher Tractor Gasket Shifter Housing       | 11   | 68129090 | 18% |
| 93661751 | Eicher Tractor Gasket Cover Shifter Housing | 37   | 68129090 | 18% |
| 93661763 | Eicher Tractor Shifter Hsg.                 | 3031 | 87084000 | 18% |
| 93661775 | Eicher Tractor Spacer Input Shaft           | 97   | 87084000 | 18% |
| 93661787 | Eicher Tractor Spacer Main Shaft            | 1991 | 87084000 | 18% |
| 93661799 | Eicher Tractor Spacing Tube Cp Shaft        | 392  | 73182100 | 18% |
| 93661805 | Eicher Tractor Spacing Tube Layshaft Speed  | 466  | 87084000 | 18% |
| 93661817 | Eicher Tractor Spacing Tube Main Shaft      | 1439 | 87084000 | 18% |
| 93661829 | Eicher Tractor Spacing Tube Range Lay Shaft | 648  | 73182100 | 18% |
| 93661842 | Eicher Tractor Spacer Rev Out Put           | 329  | 73182100 | 18% |
| 93661854 | Eicher Tractor Thrust Spacer                | 294  | 73182100 | 18% |
| 93661866 | Eicher Tractor Lock Washer Planetary        | 73   | 73182100 | 18% |
| 93661880 | Eicher Tractor Spacer 210                   | 569  | 73182100 | 18% |
| 93661891 | Eicher Tractor Thrust Spacer Pto            | 183  | 87089900 | 18% |
| 93661908 | Eicher Tractor Pto Cover Lower              | 652  | 87084000 | 18% |
| 93661921 | Eicher Tractor Pin For Brake                | 173  | 73182100 | 18% |
| 93661933 | Eicher Tractor Brake Link Outer (Rh)        | 1414 | 87083000 | 18% |
| 93661945 | Eicher Tractor Brake Link Small             | 175  | 87083000 | 18% |
| 93661969 | Eicher Tractor Brake Link Outer(Lh)         | 254  | 87083000 | 18% |
| 93661970 | Eicher Tractor Shifter Coupling             | 1120 | 87089900 | 18% |
| 93661982 | Eicher Tractor Main Lever F-R               | 265  | 87089900 | 18% |
| 93661994 | Eicher Tractor Spacer Coupling Shaft (Pto)  | 144  | 87084000 | 18% |
| 93662007 | Eicher Tractor Spacer Coupling Shaft (Main) | 175  | 87084000 | 18% |
| 93662020 | Eicher Tractor Pin Dowel                    | 102  | 73182100 | 18% |
| 93662068 | Eicher Tractor Shim 45/0.05                 | 5    | 73182100 | 18% |
| 93662070 | Eicher Tractor Shim 45/0.1                  | 5    | 73182100 | 18% |
| 93662081 | Eicher Tractor Shim 45/0.2                  | 6    | 73182100 | 18% |
| 93662093 | Eicher Tractor Shim 45/0.5                  | 7    | 73182100 | 18% |
| 93662100 | Eicher Tractor Shim 100/0.05                | 16   | 73182100 | 18% |
| 93662111 | Eicher Tractor Shim 0.15                    | 9    | 73182100 | 18% |
| 93662123 | Eicher Tractor Shim 100/0.2                 | 10   | 73182100 | 18% |
| 93662135 | Eicher Tractor Shim 100/0.5                 | 14   | 73182100 | 18% |
| 93662147 | Eicher Tractor Shim For Cp Shaft 0.1 Thk    | 13   | 73182100 | 18% |
| 93662159 | Eicher Tractor Shim For Cp Shaft 0.2 Thk    | 17   | 73182100 | 18% |
| 93662160 | Eicher Tractor Shim For Cp Shaft 0.3 Thk    | 20   | 73182100 | 18% |
| 93662172 | Eicher Tractor Shim For Cp Shaft 0.5 Thk    | 24   | 73182100 | 18% |
| 93662184 | Eicher Tractor Pto Actuating Lever          | 209  | 87084000 | 18% |
| 93662214 | Eicher Tractor Gasket Guide Sleeve          | 16   | 68129090 | 18% |
| 93662263 | Eicher Tractor Brake Link Inner Lh          | 374  | 87083000 | 18% |
| 93662275 | Eicher Tractor Differential Housing Casting | 3281 | 87084000 | 18% |
| 93662299 | Eicher Tractor Cover Flywheel Housing       | 992  | 87084000 | 18% |
| 93662354 | Eicher Tractor Top Cover                    | 7814 | 87084000 | 18% |
| 93662391 | Eicher Tractor Spacer Reverse Gear Input    | 95   | 73182100 | 18% |
| 93662408 | Eicher Tractor Spacer Pinion Medium         | 99   | 73182100 | 18% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93662469 | Eicher Tractor Brake Link Inner Rh                 | 374    | 87083000 | 18% |
| 93662470 | Eicher Tractor Pto Shaft Rear New - 60Hp           | 3170   | 87084000 | 18% |
| 93662482 | Eicher Tractor Gear Pto 540 New 60Hp               | 5998   | 87084000 | 18% |
| 93662494 | Eicher Tractor Pinion Pto Cluster New - 60Hp       | 2273   | 87084000 | 18% |
| 93662512 | Eicher Tractor Inter Locking Pin                   | 20     | 73182100 | 18% |
| 93662524 | Eicher Tractor Spacer Pto Shaft Rear               | 352    | 73182100 | 18% |
| 93662536 | Eicher Tractor Lock Plate                          | 232    | 87084000 | 18% |
| 93662548 | Eicher Tractor Nrb Rev. Gear Input(B60X68X25)      | 408    | 84822090 | 18% |
| 93662550 | Eicher Tractor Oil Seal 38X52X7 Is:5129 - 1979     | 218    | 40169330 | 18% |
| 93662573 | Eicher Tractor Brake Plate                         | 1860   | 87083000 | 18% |
| 93662640 | Eicher Tractor Oil Seal 85X110X12 Is:5129 - 1979   | 380    | 40169330 | 18% |
| 93662664 | Eicher Tractor Bearing Housing (12"Clutch)         | 9353   | 84099941 | 28% |
| 93662676 | Eicher Tractor Brake Set 7X5.25                    | 11961  | 87083000 | 18% |
| 93662860 | Eicher Tractor Flywheel Hsg. 12"Clutch Machining ( | 52861  | 87084000 | 18% |
| 93662871 | Eicher Tractor Coupling Fork Pto                   | 1634   | 87084000 | 18% |
| 93662883 | Eicher Tractor Input Shaft                         | 5783   | 87084000 | 18% |
| 93662895 | Eicher Tractor Thrust Sleeve Pto                   | 2841   | 87084000 | 18% |
| 93662901 | Eicher Tractor Sliding Sleeve -Pto                 | 2064   | 87084000 | 18% |
| 93662913 | Eicher Tractor Slide Sleeve M-D                    | 1834   | 87084000 | 18% |
| 93662925 | Eicher Tractor Guide Sleeve                        | 2347   | 87084000 | 18% |
| 93662937 | Eicher Tractor Thrust Sleeve M/D                   | 1191   | 87084000 | 18% |
| 93662949 | Eicher Tractor Double Clutch Assly                 | 45459  | 87089300 | 18% |
| 93662950 | Eicher Tractor Main Driven Plate Assly             | 13875  | 87089300 | 18% |
| 93662962 | Eicher Tractor Pto Driven Plate                    | 6131   | 87089300 | 18% |
| 93662974 | Eicher Tractor Pto Shaft Front                     | 5771   | 87084000 | 18% |
| 93662986 | Eicher Tractor Coupling Shaft Assly Main           | 2597   | 87084000 | 18% |
| 93662998 | Eicher Tractor Coupling Shaft Assly Pto            | 2215   | 87084000 | 18% |
| 93663000 | Eicher Tractor 4Wd Front Axle                      | 417278 | 87085000 | 18% |
| 93663036 | Eicher Tractor Drop Box Housing                    | 5422   | 87084000 | 18% |
| 93663048 | Eicher Tractor Gasket Drop Box                     | 76     | 68129922 | 18% |
| 93663050 | Eicher Tractor Gear 4Wd                            | 4191   | 87084000 | 18% |
| 93663061 | Eicher Tractor Pinion 4Wd                          | 2584   | 87089900 | 18% |
| 93663073 | Eicher Tractor Shaft 4Wd                           | 2226   | 87084000 | 18% |
| 93663085 | Eicher Tractor Clutch Sleeve 4Wd                   | 903    | 87089300 | 18% |
| 93663097 | Eicher Tractor Gasket 4Wd                          | 32     | 68129922 | 18% |
| 93663103 | Eicher Tractor Cover Plate 4Wd                     | 500    | 87084000 | 18% |
| 93663115 | Eicher Tractor Engaging Lever 4Wd                  | 433    | 87084000 | 18% |
| 93663127 | Eicher Tractor Guide Plate 4Wd                     | 581    | 87084000 | 18% |
| 93663139 | Eicher Tractor Sleeve 4Wd                          | 690    | 87084000 | 18% |
| 93663140 | Eicher Tractor Drive Shaft 4Wd                     | 9652   | 87084000 | 18% |
| 93663152 | Eicher Tractor Bearing Support                     | 1199   | 87084000 | 18% |
| 93663243 | Eicher Tractor 4Wd Pull Push Lever                 | 1341   | 87084000 | 18% |
| 93663255 | Eicher Tractor 4Wd Knob                            | 91     | 87084000 | 18% |
| 93663383 | Eicher Tractor Reverse Idler Screw-M10X1.5         | 43     | 73181500 | 18% |
| 93663395 | Eicher Tractor Interlocking Capsule                | 39     | 87084000 | 18% |
| 93663449 | Eicher Tractor Gear Shift Lever Assy               | 940    | 87089900 | 18% |
| 93663528 | Eicher Tractor Friction Disc                       | 1702   | 87083000 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93663530 | Eicher Tractor Steel Disc                         | 1130  | 87084000 | 18% |
| 93663541 | Eicher Tractor Actuator Assy                      | 7051  | 87084000 | 18% |
| 93663620 | Eicher Tractor O - Ring                           | 419   | 40169340 | 18% |
| 93663632 | Eicher Tractor Clutch Disc                        | 14166 | 87089300 | 18% |
| 93663644 | Eicher Tractor Cover                              | 748   | 87084000 | 18% |
| 93663668 | Eicher Tractor Dowel                              | 69    | 73182100 | 18% |
| 93663670 | Eicher Tractor Seal                               | 31591 | 40169990 | 18% |
| 93663681 | Eicher Tractor Bearing                            | 480   | 84821011 | 18% |
| 93663693 | Eicher Tractor Axle Case                          | 1743  | 73181500 | 18% |
| 93663700 | Eicher Tractor Seal                               | 45    | 40169990 | 18% |
| 93663711 | Eicher Tractor Ring                               | 3661  | 40169340 | 18% |
| 93663723 | Eicher Tractor O - Ring                           | 646   | 40169340 | 18% |
| 93663735 | Eicher Tractor Seal Kit                           | 319   | 87089900 | 18% |
| 93663747 | Eicher Tractor Rubber Boot & Locking Ring Kit     | 3840  | 40169320 | 18% |
| 93663759 | Eicher Tractor O - Ring                           | 1378  | 40169340 | 18% |
| 93663760 | Eicher Tractor O - Ring                           | 2645  | 40169340 | 18% |
| 93663772 | Eicher Tractor O - Ring                           | 3076  | 40169340 | 18% |
| 93663814 | Eicher Tractor Primary Shaft Z-23                 | 14926 | 87089900 | 18% |
| 93663826 | Eicher Tractor Intermediate Shaft Front Z-23      | 13686 | 87089900 | 18% |
| 93663838 | Eicher Tractor Intermediate Shaft Rear (Spline Z- | 7420  | 87089900 | 18% |
| 93663840 | Eicher Tractor Lay Shaft Front (Spline Z-24)      | 3116  | 87089900 | 18% |
| 93663863 | Eicher Tractor Pto Shaft Front (Spline Z-21/16)   | 5699  | 87084000 | 18% |
| 93663875 | Eicher Tractor Pto Drive Shaft Z-16               | 5567  | 87084000 | 18% |
| 93663887 | Eicher Tractor Cm Gear Z-44                       | 5630  | 87084000 | 18% |
| 93663899 | Eicher Tractor Driven Gear 1St Z-44               | 5840  | 87084000 | 18% |
| 93663905 | Eicher Tractor Driven Gear 2Nd Z-36               | 3776  | 87084000 | 18% |
| 93663917 | Eicher Tractor Driven Gear 3Rd Z-30               | 3190  | 87084000 | 18% |
| 93663929 | Eicher Tractor Drive Gear 1St Z-23                | 2127  | 87084000 | 18% |
| 93663930 | Eicher Tractor Drive Gear 2Nd Z-33                | 2898  | 87084000 | 18% |
| 93663942 | Eicher Tractor Drive Gear 3Rd Z-38                | 4350  | 87084000 | 18% |
| 93663954 | Eicher Tractor Reverse Idler Gear 1St Z-23        | 2468  | 87084000 | 18% |
| 93663966 | Eicher Tractor Reverse Idler Gear 2Nd Z-22        | 2505  | 87084000 | 18% |
| 93663978 | Eicher Tractor Synchro Assy 1/2 Dia 74            | 16798 | 87084000 | 18% |
| 93663980 | Eicher Tractor Cm Gear Hi-Low Z-45                | 3252  | 87084000 | 18% |
| 93663991 | Eicher Tractor Drive Gear Hi-Low Z-27             | 2258  | 87084000 | 18% |
| 93664004 | Eicher Tractor Driven Gear Hi-Low Z-41            | 4170  | 87084000 | 18% |
| 93664016 | Eicher Tractor Shifter Rod 1St & 2Nd              | 430   | 87084000 | 18% |
| 93664028 | Eicher Tractor Shifter Rod 3Rd/4Th                | 431   | 87084000 | 18% |
| 93664030 | Eicher Tractor Shifter Rod Hi/Low                 | 393   | 87084000 | 18% |
| 93664041 | Eicher Tractor Shifter Rod Reverse                | 407   | 87084000 | 18% |
| 93664065 | Eicher Tractor Shifter Fork Hi/Low                | 852   | 87084000 | 18% |
| 93664077 | Eicher Tractor Bush Int. Shaft -Driven Gear       | 708   | 87084000 | 18% |
| 93664089 | Eicher Tractor Spacer - Lay Shaft Front           | 213   | 73182100 | 18% |
| 93664090 | Eicher Tractor Spacer-1 Lay Shaft Rear            | 168   | 73182100 | 18% |
| 93664107 | Eicher Tractor Spacer -2 Lay Shaft Rear           | 150   | 73182100 | 18% |
| 93664119 | Eicher Tractor Shaft -Reverse Gear Idler          | 520   | 87084000 | 18% |
| 93664120 | Eicher Tractor Spacer Thin Reverse Gear           | 117   | 73182100 | 18% |





|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93664132 | Eicher Tractor Spacer-1 -Pto Shaft             | 159    | 73182100 | 18% |
| 93664144 | Eicher Tractor Spacer -2 -Pto Shaft            | 255    | 73182100 | 18% |
| 93664156 | Eicher Tractor Cylindrical Roller Brg. Nup 210 | 999    | 84825011 | 18% |
| 93664168 | Eicher Tractor Gasket G1 Top Cover             | 75     | 87089900 | 18% |
| 93664181 | Eicher Tractor Tube For Shifter Rod Rev Gear   | 74     | 87084000 | 18% |
| 93664193 | Eicher Tractor Tube For Shifter Rod 1/2        | 28     | 87084000 | 18% |
| 93664200 | Eicher Tractor Tube For Shifter Rod 3/4        | 89     | 87084000 | 18% |
| 93664296 | Eicher Tractor Plug                            | 2044   | 87084000 | 18% |
| 93664302 | Eicher Tractor Seal Washer                     | 1847   | 73182200 | 18% |
| 93664314 | Eicher Tractor Housing                         | 274610 | 87084000 | 18% |
| 93664338 | Eicher Tractor Ring Nut                        | 2589   | 73181500 | 18% |
| 93664351 | Eicher Tractor Spacer                          | 4783   | 73182100 | 18% |
| 93664363 | Eicher Tractor Seal                            | 8733   | 40169990 | 18% |
| 93664375 | Eicher Tractor Shim                            | 48     | 73182100 | 18% |
| 93664387 | Eicher Tractor Shim                            | 53     | 73182100 | 18% |
| 93664399 | Eicher Tractor Shim                            | 39     | 73182100 | 18% |
| 93664405 | Eicher Tractor Shim                            | 48     | 73182100 | 18% |
| 93664417 | Eicher Tractor Taper Roller Bearing            | 14003  | 84822011 | 18% |
| 93664429 | Eicher Tractor Shim                            | 244    | 73182100 | 18% |
| 93664430 | Eicher Tractor Shim                            | 219    | 73182100 | 18% |
| 93664442 | Eicher Tractor Shim                            | 2      | 73182100 | 18% |
| 93664454 | Eicher Tractor Bevel Gear Set                  | 96373  | 87084000 | 18% |
| 93664466 | Eicher Tractor Shim                            | 199    | 73182100 | 18% |
| 93664478 | Eicher Tractor Shim                            | 224    | 73182100 | 18% |
| 93664480 | Eicher Tractor Shim                            | 203    | 73182100 | 18% |
| 93664491 | Eicher Tractor Taper Roller Bearing            | 14901  | 84822011 | 18% |
| 93664508 | Eicher Tractor Hexagon Bolt                    | 360    | 73181500 | 18% |
| 93664510 | Eicher Tractor Cover                           | 44776  | 87084000 | 18% |
| 93664533 | Eicher Tractor Differential Shaft              | 5560   | 87084000 | 18% |
| 93664545 | Eicher Tractor Washer                          | 255    | 73182100 | 18% |
| 93664569 | Eicher Tractor Differential Carrier            | 83259  | 87084000 | 18% |
| 93664570 | Eicher Tractor Gear                            | 50056  | 87084000 | 18% |
| 93664582 | Eicher Tractor Differential Shaft              | 3312   | 87084000 | 18% |
| 93664594 | Eicher Tractor Shaft Retainer                  | 6612   | 87084000 | 18% |
| 93664600 | Eicher Tractor Axle Case                       | 177024 | 87085000 | 18% |
| 93664612 | Eicher Tractor Bolt                            | 461    | 73181500 | 18% |
| 93664624 | Eicher Tractor Thrust Bushing                  | 1337   | 84833000 | 18% |
| 93664648 | Eicher Tractor Joint                           | 215337 | 87089900 | 18% |
| 93664661 | Eicher Tractor Seal                            | 11752  | 40169990 | 18% |
| 93664673 | Eicher Tractor Circlip                         | 378    | 73182910 | 18% |
| 93664685 | Eicher Tractor Ball Bearing                    | 5206   | 84822011 | 18% |
| 93664697 | Eicher Tractor Washer                          | 1690   | 73182100 | 18% |
| 93664703 | Eicher Tractor Circlip                         | 358    | 73182910 | 18% |
| 93664715 | Eicher Tractor Taper Roller Bearing            | 9636   | 84822011 | 18% |
| 93664739 | Eicher Tractor Shim                            | 439    | 73182100 | 18% |
| 93664740 | Eicher Tractor Shim                            | 918    | 73182100 | 18% |
| 93664752 | Eicher Tractor Circlip                         | 345    | 73182910 | 18% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93664764 | Eicher Tractor Hexagon Bolt                      | 236    | 73181500 | 18% |
| 93664776 | Eicher Tractor Pivot Pin                         | 13037  | 87084000 | 18% |
| 93664788 | Eicher Tractor Plug                              | 1435   | 87084000 | 18% |
| 93664790 | Eicher Tractor Steering Case                     | 129308 | 87089400 | 18% |
| 93664806 | Eicher Tractor Steering Case                     | 129308 | 87089400 | 18% |
| 93664818 | Eicher Tractor Nut                               | 134    | 73181500 | 18% |
| 93664820 | Eicher Tractor Bolt                              | 837    | 73181500 | 18% |
| 93664855 | Eicher Tractor Wheel Stud                        | 2771   | 73182100 | 18% |
| 93664867 | Eicher Tractor Wheel Hub                         | 31818  | 87087000 | 18% |
| 93664880 | Eicher Tractor Circlip                           | 1540   | 73182910 | 18% |
| 93664892 | Eicher Tractor Ring Gear                         | 53612  | 87084000 | 18% |
| 93664909 | Eicher Tractor Ring Gear Support                 | 70155  | 87084000 | 18% |
| 93664910 | Eicher Tractor Hexagon Bolt                      | 179    | 73181500 | 18% |
| 93664922 | Eicher Tractor Planet Gear Carrier               | 70842  | 87084000 | 18% |
| 93664934 | Eicher Tractor Plug                              | 2111   | 87084000 | 18% |
| 93664946 | Eicher Tractor Seal Washer                       | 1847   | 73182200 | 18% |
| 93664958 | Eicher Tractor Bolt                              | 244    | 73181500 | 18% |
| 93664960 | Eicher Tractor Roller Bearing                    | 12853  | 84822011 | 18% |
| 93664971 | Eicher Tractor Differential Pinion               | 14934  | 87084000 | 18% |
| 93664983 | Eicher Tractor Half Shaft Differential Side      | 103330 | 87084000 | 18% |
| 93664995 | Eicher Tractor Joint Cross                       | 19835  | 87089900 | 18% |
| 93665008 | Eicher Tractor Joint Center Section              | 24264  | 87089900 | 18% |
| 93665010 | Eicher Tractor Half Shaft Hub Reduction Side     | 51209  | 87084000 | 18% |
| 93665021 | Eicher Tractor Cylinder                          | 1297   | 87089900 | 18% |
| 93665033 | Eicher Tractor Bar                               | 49666  | 87089900 | 18% |
| 93665045 | Eicher Tractor Cylinder Bolt                     | 772    | 73181500 | 18% |
| 93665057 | Eicher Tractor Shim                              | 6      | 73182100 | 18% |
| 93665069 | Eicher Tractor Shim                              | 7      | 73182100 | 18% |
| 93665082 | Eicher Tractor 90 Degree Joint                   | 39921  | 87089900 | 18% |
| 93665094 | Eicher Tractor Axial Joint                       | 55083  | 87089900 | 18% |
| 93665112 | Eicher Tractor Rubber Boot & Locking Ring Kit    | 46     | 40169320 | 18% |
| 93665124 | Eicher Tractor Support                           | 44737  | 87089400 | 18% |
| 93665148 | Eicher Tractor Bushing                           | 20619  | 87089900 | 18% |
| 93665150 | Eicher Tractor Shim                              | 2105   | 73182100 | 18% |
| 93665173 | Eicher Tractor Support                           | 40230  | 87089400 | 18% |
| 93665185 | Eicher Tractor Grease Fitting                    | 451    | 87089900 | 18% |
| 93665197 | Eicher Tractor Bushing                           | 4608   | 84833000 | 18% |
| 93665215 | Eicher Tractor Plug                              | 675    | 87084000 | 18% |
| 93665227 | Eicher Tractor Shim                              | 1837   | 73182100 | 18% |
| 93665239 | Eicher Tractor Thrust Bushing                    | 19161  | 73182100 | 18% |
| 93665264 | Eicher Tractor Rev. Gear Sleeve                  | 2101   | 87084000 | 18% |
| 93665276 | Eicher Tractor Spacer For G2 3.15 Thick          | 151    | 73182100 | 18% |
| 93665288 | Eicher Tractor Spacer For G2 3.15 Thick          | 151    | 73182100 | 18% |
| 93665653 | Eicher Tractor Lay Shaft Rear Assy               | 3858   | 87089900 | 18% |
| 93665665 | Eicher Tractor Guide Sleeve                      | 1137   | 84822090 | 18% |
| 93665914 | Eicher Tractor Cylindrical Roller Bearing Nj 209 | 854    | 84821011 | 18% |
| 93666055 | Eicher Tractor Gasket Fwh-Gear Housing Front     | 81     | 68129922 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93666232 | Eicher Tractor Dual Clutch 12"                     | 42059 | 87089300 | 18% |
| 93666256 | Eicher Tractor Bearing Retainer                    | 117   | 84821011 | 18% |
| 93666270 | Eicher Tractor Assembly Pto Shaft Rear (R-Pto Eco) | 4892  | 87084000 | 18% |
| 93666293 | Eicher Tractor Synchro Assy 3/4 Dia. 74            | 14513 | 87084000 | 18% |
| 93666300 | Eicher Tractor Shifter Fork Rev Gear               | 654   | 87084000 | 18% |
| 93666311 | Eicher Tractor Gasket For G1-Fw Hsg                | 105   | 68129090 | 18% |
| 93666523 | Eicher Tractor D.C. Assy 12" Without Md Plate      | 41374 | 87084000 | 18% |
| 93666535 | Eicher Tractor Driven Plate Assy. (Main)           | 16100 | 87089300 | 18% |
| 93666547 | Eicher Tractor Driven Plate (Pto)                  | 7028  | 87089300 | 18% |
| 93666584 | Eicher Tractor Propeller Shaft Eco                 | 4996  | 87084000 | 18% |
| 93666596 | Eicher Tractor Retaining Spring                    | 29    | 73202000 | 18% |
| 93666724 | Eicher Tractor Pto Lever                           | 1196  | 87084000 | 18% |
| 93666750 | Eicher Tractor Drop Box Housing                    | 5710  | 87084000 | 18% |
| 93666876 | Eicher Tractor Gear Selector Rod Assembly          | 2216  | 87084000 | 18% |
| 93667030 | Eicher Tractor Assy Pto Shaft 540 (Hyd)            | 6492  | 87084000 | 18% |
| 93667054 | Eicher Tractor Pto Seal 36X68X25 (Ericks)          | 13888 | 87089900 | 18% |
| 93667571 | Eicher Tractor Cover Pto Shaft Rear                | 2597  | 87084000 | 18% |
| 93667583 | Eicher Tractor Oil Seal Housing - 380 Exp.         | 1366  | 40169330 | 18% |
| 93667625 | Eicher Tractor Assy Pto Shaft 540(50Hp)            | 6573  | 87084000 | 18% |
| 93667674 | Eicher Tractor Gasket (Fwh-Gear Housing Front)     | 100   | 68129090 | 18% |
| 93667686 | Eicher Tractor Gasket-Top Cover Rear               | 328   | 68129090 | 18% |
| 93667698 | Eicher Tractor Gasket G1 Top Cover                 | 580   | 68129090 | 18% |
| 93669488 | Eicher Tractor Assrmbly Pto Shaft Rear(R-Pto Eco)  | 5420  | 87084000 | 18% |
| 93669531 | Eicher Tractor Assy Pto Shaft 540 (Hyd)            | 6999  | 87084000 | 18% |
| 93669567 | Eicher Tractor Assy Pto Shaft 540 (50Hp)           | 7367  | 87084000 | 18% |
| 93670041 | Eicher Tractor Rivet For Friction Disc- 24 Nos-936 | 33    | 73182100 | 18% |
| 93670054 | Eicher Tractor Flange For Flywheel.Housing         | 286   | 87084000 | 18% |
| 93670120 | Eicher Tractor Reverse Shaft                       | 363   | 87084000 | 18% |
| 93670132 | Eicher Tractor Spacer Rev Front                    | 144   | 73182100 | 18% |
| 93670363 | Eicher Tractor Top Cover Front                     | 846   | 87084000 | 18% |
| 93670387 | Eicher Tractor Hub (Sca)                           | 589   | 87085000 | 18% |
| 93670399 | Eicher Tractor Cylindrical Roller Bearing Nup 209  | 1340  | 84825011 | 18% |
| 93670429 | Eicher Tractor Stud M14X38/66                      | 47    | 73182100 | 18% |
| 93670430 | Eicher Tractor Stud M14X38/59                      | 44    | 73182100 | 18% |
| 93670521 | Eicher Tractor Pin 5*48                            | 35    | 73182100 | 18% |
| 93670569 | Eicher Tractor Gasket Cover G1 Top                 | 43    | 68129090 | 18% |
| 93670584 | Eicher Tractor Bolt Set                            | 54    | 73181500 | 18% |
| 93670612 | Eicher Tractor Synchro Assy Hi/Lo                  | 16822 | 87084000 | 18% |
| 93670648 | Eicher Tractor Clamping Plate                      | 257   | 87089900 | 18% |
| 93670922 | Eicher Tractor Gear Housing Rear                   | 45060 | 87084000 | 18% |
| 93670958 | Eicher Tractor Axle Tube Left                      | 10565 | 87084000 | 18% |
| 93670960 | Eicher Tractor Axle Tube Right                     | 10565 | 87084000 | 18% |
| 93671021 | Eicher Tractor Wet Brake Set6.5"X4.3"              | 7876  | 87083000 | 18% |
| 93671069 | Eicher Tractor Intermediate Shifter Fork           | 345   | 87084000 | 18% |
| 93671227 | Eicher Tractor Rev Gear Assy-380/485-Finished (Tee | 2107  | 87084000 | 18% |
| 93671264 | Eicher Tractor Gear Shifter Lever                  | 589   | 87084000 | 18% |
| 93671276 | Eicher Tractor Spur Pin 2Nd-380/485-Finished (Teet | 1314  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93671288 | Eicher Tractor S/Gear 1/2-380/485 -Finish (Teeth-4 | 2613  | 87084000 | 18% |
| 93671290 | Eicher Tractor 11" Clutch Disc                     | 3087  | 87089300 | 18% |
| 93671306 | Eicher Tractor 11" Clutch Cover Assy.              | 4383  | 87089300 | 18% |
| 93671318 | Eicher Tractor Brake Housing Rt.                   | 3089  | 87083000 | 18% |
| 93671320 | Eicher Tractor Brake Housing Lt.                   | 2842  | 87083000 | 18% |
| 93671331 | Eicher Tractor Brake Housing Rt.                   | 2973  | 87083000 | 18% |
| 93671343 | Eicher Tractor Brake Housing Lt.                   | 2900  | 87083000 | 18% |
| 93671355 | Eicher Tractor Actuating Unit With Pull Rod        | 3565  | 87083000 | 18% |
| 93671367 | Eicher Tractor Actuating Unit With Pull Rod        | 3558  | 87083000 | 18% |
| 93671379 | Eicher Tractor Lined Friction Disc                 | 1225  | 87083000 | 18% |
| 93671380 | Eicher Tractor Lined Friction Disc (Non Asbt)      | 632   | 87083000 | 18% |
| 93671392 | Eicher Tractor Breather Pipe Assy                  | 244   | 87084000 | 18% |
| 93671409 | Eicher Tractor Guide Sleeve Integral               | 1741  | 87084000 | 18% |
| 93671422 | Eicher Tractor Rear Shaft (Trb 32212/32211)        | 5394  | 87084000 | 18% |
| 93671434 | Eicher Tractor Rear Shaft                          | 9440  | 87084000 | 18% |
| 93671446 | Eicher Tractor Gear Housing Front - 242            | 22234 | 87084000 | 18% |
| 93671460 | Eicher Tractor Axle Tube Left                      | 9709  | 87084000 | 18% |
| 93671471 | Eicher Tractor Axle Tube Right                     | 9934  | 87084000 | 18% |
| 93671549 | Eicher Tractor Gasket For Ctf - Ctr                | 118   | 68129090 | 18% |
| 93671550 | Eicher Tractor Spacer For Lay Shaft 2              | 86    | 73182100 | 18% |
| 93671562 | Eicher Tractor Gear Housing Front - 755 Modify     | 20473 | 87084000 | 18% |
| 93671574 | Eicher Tractor Spacer Cm Gear                      | 73    | 73182100 | 18% |
| 93671598 | Eicher Tractor Shifter Rod 1/2                     | 252   | 87084000 | 18% |
| 93671604 | Eicher Tractor Shifter Fork 1/2                    | 775   | 87084000 | 18% |
| 93671630 | Eicher Tractor Lay Shaft Front- (Gt380 Hydro)      | 2214  | 87084000 | 18% |
| 93671689 | Eicher Tractor Differential Housing Assly          | 8434  | 87084000 | 18% |
| 93671719 | Eicher Tractor Cover Right                         | 4269  | 87084000 | 18% |
| 93671720 | Eicher Tractor Cover Lt                            | 4266  | 87084000 | 18% |
| 93671732 | Eicher Tractor Intermediate Plate Right            | 1585  | 87083000 | 18% |
| 93671744 | Eicher Tractor Intermediate Plate Left             | 1585  | 87083000 | 18% |
| 93671768 | Eicher Tractor F D Pinion Shaft Z-13 380 Sw        | 5201  | 87084000 | 18% |
| 93671823 | Eicher Tractor Brake Housing Lt.                   | 4221  | 87083000 | 18% |
| 93671835 | Eicher Tractor Brake Housing Rt.                   | 4221  | 87083000 | 18% |
| 93671847 | Eicher Tractor Cover Left                          | 4507  | 87084000 | 18% |
| 93671859 | Eicher Tractor Cover Right                         | 4507  | 87084000 | 18% |
| 93671872 | Eicher Tractor Locking Screw                       | 19    | 73181500 | 18% |
| 93671884 | Eicher Tractor Oil Seal 18X30X7                    | 27    | 40169330 | 18% |
| 93671896 | Eicher Tractor Spur Gear Hi/Lo - 5150              | 3201  | 87084000 | 18% |
| 93671987 | Eicher Tractor Shifting Rod Rev. Gear              | 291   | 87084000 | 18% |
| 93671999 | Eicher Tractor Shifter Rod 1St & 2Nd               | 516   | 87084000 | 18% |
| 93672013 | Eicher Tractor Jaw Reverse                         | 348   | 87084000 | 18% |
| 93672025 | Eicher Tractor Jaw 3Rd & 4Th                       | 389   | 87084000 | 18% |
| 93672086 | Eicher Tractor Gasket                              | 67    | 68129090 | 18% |
| 93672098 | Eicher Tractor Spacer For Fd Pinion                | 77    | 73182100 | 18% |
| 93672219 | Eicher Tractor Oil Seal (35X56X10)(Double Lip)     | 162   | 40169330 | 18% |
| 93672244 | Eicher Tractor Case Transmission Rear              | 51523 | 87089900 | 18% |
| 93672311 | Eicher Tractor F D Pinion Shaft Assly              | 4833  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93672372 | Eicher Tractor Knob                                | 75    | 39269099 | 18% |
| 93672384 | Eicher Tractor Knob                                | 72    | 39269099 | 18% |
| 93672396 | Eicher Tractor Knob                                | 80    | 39269099 | 18% |
| 93672402 | Eicher Tractor Knob Hi/Low                         | 65    | 39269099 | 18% |
| 93672414 | Eicher Tractor Knob Pto Engagine Lever             | 34    | 39269099 | 18% |
| 93672440 | Eicher Tractor Sliding Sleeve                      | 1143  | 87084000 | 18% |
| 93672487 | Eicher Tractor Sticker Pto                         | 14    | 39199090 | 18% |
| 93672499 | Eicher Tractor Sticker Pto                         | 5     | 39199090 | 18% |
| 93672517 | Eicher Tractor Pto Lever Assy (Push/Pull)          | 250   | 87084000 | 18% |
| 93672529 | Eicher Tractor Pto Lever Assy.(Push/Pull)          | 199   | 87084000 | 18% |
| 93672530 | Eicher Tractor Axial Diff. Star Pinion             | 1875  | 87084000 | 18% |
| 93672566 | Eicher Tractor Assemble Differential Housing-Fg    | 4873  | 87084000 | 18% |
| 93672580 | Eicher Tractor Assemble Differential Housing-Ia    | 7570  | 87084000 | 18% |
| 93672712 | Eicher Tractor Cover Left-Dr                       | 4187  | 87084000 | 18% |
| 93672724 | Eicher Tractor Cover Right- Dr                     | 4187  | 87084000 | 18% |
| 93672736 | Eicher Tractor Fd Gear                             | 9232  | 87084000 | 18% |
| 93672748 | Eicher Tractor Rear Axle - 364 Portal              | 6539  | 87084000 | 18% |
| 93673716 | Eicher Tractor Hex Flange Bolt M10X40L B10.9       | 19    | 73181500 | 18% |
| 93673753 | Eicher Tractor Oil Dipstick                        | 135   | 87084000 | 18% |
| 93674241 | Eicher Tractor Stopper Pin For Pto                 | 64    | 87084000 | 18% |
| 93674459 | Eicher Tractor Differential Bush                   | 168   | 87089900 | 18% |
| 93674460 | Eicher Tractor Main Shifting Lever Assembly        | 630   | 87089900 | 18% |
| 93674484 | Eicher Tractor Bearing Sleeve                      | 963   | 84822090 | 18% |
| 93674496 | Eicher Tractor Bearing Sleeve                      | 1116  | 84822090 | 18% |
| 93674502 | Eicher Tractor Flywheel Housing (548)              | 37399 | 87084000 | 18% |
| 93674514 | Eicher Tractor Lever Assy                          | 66    | 87089900 | 18% |
| 93674526 | Eicher Tractor Fly Wheel Housing                   | 33372 | 87084000 | 18% |
| 93674540 | Eicher Tractor Flywheel Hsg (Non Ind.) (485)       | 30712 | 87084000 | 18% |
| 93674563 | Eicher Tractor Flywheel Housing (5660)             | 29672 | 87084000 | 18% |
| 93674575 | Eicher Tractor Spring Dowel Sleeve 8X35 ,Din-1481  | 13    | 73182100 | 18% |
| 93674897 | Eicher Tractor Axle Tube Left                      | 9984  | 87084000 | 18% |
| 93674903 | Eicher Tractor Axle Tube Right                     | 9508  | 87084000 | 18% |
| 93674939 | Eicher Tractor Reduction Housing Cover             | 3676  | 87089900 | 18% |
| 93674940 | Eicher Tractor Reduction Gear Housing              | 7639  | 87084000 | 18% |
| 93674952 | Eicher Tractor Gasket For Reduction Hsg            | 83    | 68129090 | 18% |
| 93675257 | Eicher Tractor Gear Hsg (Rear R - Pto 557)         | 60266 | 87089900 | 18% |
| 93675269 | Eicher Tractor Gear Hsg (Rear R - Pto With Diffloc | 51517 | 87084000 | 18% |
| 93675270 | Eicher Tractor Hi-Low Coller Assy.                 | 4529  | 87084000 | 18% |
| 93675292 | Eicher Tractor Friction Disc                       | 1056  | 87083000 | 18% |
| 93675300 | Eicher Tractor Intermediate Plate                  | 498   | 87083000 | 18% |
| 93675350 | Eicher Tractor Assy. Differential Housing          | 9113  | 87084000 | 18% |
| 93675579 | Eicher Tractor Reverse Gear C M Non Hydro*         | 1826  | 87084000 | 18% |
| 93675580 | Eicher Tractor Spur Pinion 2Nd 22T - Hydro - Prosp | 1697  | 87084000 | 18% |
| 93675592 | Eicher Tractor Spur Pinion 1St (17T) - Hydro - Pro | 1382  | 87084000 | 18% |
| 93675609 | Eicher Tractor Spur Gear 2Nd                       | 1283  | 87084000 | 18% |
| 93675610 | Eicher Tractor Reverse Gear Assembly               | 1979  | 87084000 | 18% |
| 93675774 | Eicher Tractor Lay Shaft Front - 548 - Prospero    | 3564  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93675798 | Eicher Tractor Rev Gear Assly-17T-Hyd-Prospero     | 2046  | 87084000 | 18% |
| 93675865 | Eicher Tractor Driven Disc 11"                     | 3371  | 87089300 | 18% |
| 93675877 | Eicher Tractor Shim 0.1Mm                          | 42    | 73182100 | 18% |
| 93675889 | Eicher Tractor Shim 0.20Mm                         | 47    | 73182100 | 18% |
| 93675890 | Eicher Tractor Shim 0.30Mm                         | 54    | 73182100 | 18% |
| 93675907 | Eicher Tractor Shim 0.50Mm                         | 60    | 73182100 | 18% |
| 93675919 | Eicher Tractor Shim 1Mm                            | 87    | 73182100 | 18% |
| 93675920 | Eicher Tractor Gasket For Oil Seal Hsg             | 8     | 40169330 | 18% |
| 93675932 | Eicher Tractor Hex Flange Bolt M14X45 B8.8         | 45    | 73181500 | 18% |
| 93676150 | Eicher Tractor Cylindrical Pin 8*21                | 17    | 87089900 | 18% |
| 93676162 | Eicher Tractor Gear Shift Lever                    | 953   | 87084000 | 18% |
| 93676174 | Eicher Tractor High - Low Lever                    | 1138  | 87084000 | 18% |
| 93676186 | Eicher Tractor Top Cover Rear                      | 2621  | 87084000 | 18% |
| 93676298 | Eicher Tractor Pto Drive Shaft Z16-755 (6298)      | 4292  | 87084000 | 18% |
| 93676304 | Eicher Tractor Pto Cm Gear Z53 (6304)              | 2705  | 87084000 | 18% |
| 93676330 | Eicher Tractor Gasket G1 G2 (5660)                 | 70    | 68129090 | 18% |
| 93676456 | Eicher Tractor Shifting Guide Rod                  | 605   | 87084000 | 18% |
| 93676468 | Eicher Tractor Shifter Fork                        | 803   | 87084000 | 18% |
| 93676470 | Eicher Tractor Special Bolt M10                    | 94    | 73181500 | 18% |
| 93676481 | Eicher Tractor Sliding Sleeve                      | 923   | 87084000 | 18% |
| 93676493 | Eicher Tractor Drive Sleeve                        | 1645  | 87084000 | 18% |
| 93676500 | Eicher Tractor Idler Shaft                         | 403   | 84099941 | 28% |
| 93676511 | Eicher Tractor Bearing Cover                       | 643   | 84099941 | 28% |
| 93676523 | Eicher Tractor Support Sleeve                      | 5241  | 87084000 | 18% |
| 93676535 | Eicher Tractor Dropbox Housing                     | 4225  | 87084000 | 18% |
| 93676547 | Eicher Tractor Output Shaft                        | 2060  | 87084000 | 18% |
| 93676572 | Eicher Tractor Spacer For Idler                    | 154   | 73182100 | 18% |
| 93676602 | Eicher Tractor Crown Pinion Shaft                  | 13691 | 87084000 | 18% |
| 93676614 | Eicher Tractor Pry Shaft Sc Z23 (6614) - 515/560   | 6297  | 87084000 | 18% |
| 93676626 | Eicher Tractor Constant Mesh Gear Z44 (6626) - 515 | 2004  | 87084000 | 18% |
| 93676638 | Eicher Tractor Spur Pinion 1St Z18 (6638) - 515    | 1230  | 87084000 | 18% |
| 93676640 | Eicher Tractor Spur Pinion 2Nd Z22 (6640) - 515    | 1407  | 87084000 | 18% |
| 93676651 | Eicher Tractor Sliding Gear 1/2 Z30/34 (6651) - 51 | 4093  | 87084000 | 18% |
| 93676663 | Eicher Tractor Spur Pinion 3Rd Z26 (6663) - 515    | 1653  | 87084000 | 18% |
| 93676675 | Eicher Tractor Rev. Gear Sld Assy. Z18 (6675) - 51 | 2133  | 87084000 | 18% |
| 93676699 | Eicher Tractor Primary Shaft Dc                    | 5179  | 87084000 | 18% |
| 93676729 | Eicher Tractor Shifter Rod                         | 4838  | 87084000 | 18% |
| 93676730 | Eicher Tractor Shifter Fork 1/2                    | 1008  | 87084000 | 18% |
| 93676742 | Eicher Tractor Shifter Fork 3/4                    | 1048  | 87084000 | 18% |
| 93676754 | Eicher Tractor Shifter Rod 3/4                     | 613   | 87084000 | 18% |
| 93676766 | Eicher Tractor Shifter Rod 1/2                     | 665   | 87084000 | 18% |
| 93676778 | Eicher Tractor Pto Cm Gear Z-53 (6778) 515/560     | 3186  | 87084000 | 18% |
| 93676780 | Eicher Tractor Pto Drive Shaft Z16 (6780) - 515/56 | 4259  | 87084000 | 18% |
| 93676821 | Eicher Tractor Sliding Gear 3/4Th Z25 (6821) - 515 | 1746  | 87084000 | 18% |
| 93676833 | Eicher Tractor Rev. Gear Cm Z17 (6833) - 515       | 1689  | 87084000 | 18% |
| 93676845 | Eicher Tractor Uj Assembly                         | 5655  | 87084000 | 18% |
| 93676857 | Eicher Tractor Shifter Lever Assembly              | 691   | 87084000 | 18% |



|          |   |        |          |     |
|----------|---|--------|----------|-----|
| 93676869 | Eicher Tractor Propeller Shaft                    | 4671   | 87084000 | 18% |
| 93676870 | Eicher Tractor Gasket Dropbox Mounting            | 53     | 68129090 | 18% |
| 93676894 | Eicher Tractor Gasket For G1 & G2                 | 121    | 68129090 | 18% |
| 93676900 | Eicher Tractor Spacer Support Sleeve              | 605    | 73182100 | 18% |
| 93676912 | Eicher Tractor Retaining Spring                   | 35     | 73209090 | 18% |
| 93676924 | Eicher Tractor Gasket Bearing Cover               | 20     | 68129090 | 18% |
| 93676950 | Eicher Tractor Input Pinion                       | 2141   | 87084000 | 18% |
| 93676985 | Eicher Tractor Gear Housing Front                 | 20801  | 87089900 | 18% |
| 93676997 | Eicher Tractor Gear Hsg Rear                      | 55446  | 87089900 | 18% |
| 93677000 | Eicher Tractor Gear Idler 1                       | 2791   | 84099941 | 28% |
| 93677011 | Eicher Tractor Gear Idler 2                       | 1428   | 84099941 | 28% |
| 93677023 | Eicher Tractor Output Gear                        | 1748   | 87084000 | 18% |
| 93677035 | Eicher Tractor Engaging Dog                       | 1205   | 87084000 | 18% |
| 93677059 | Eicher Tractor Cm Gear                            | 1968   | 87084000 | 18% |
| 93677060 | Eicher Tractor Spur Pinion 2Nd                    | 1458   | 87084000 | 18% |
| 93677072 | Eicher Tractor Shifter Rod 1/2                    | 849    | 87084000 | 18% |
| 93677084 | Eicher Tractor Shifter Rod 3/4                    | 371    | 87084000 | 18% |
| 93677096 | Eicher Tractor Shifter Jaw 3/4                    | 645    | 87084000 | 18% |
| 93677102 | Eicher Tractor Shifter Jaw Rg                     | 645    | 87084000 | 18% |
| 93677114 | Eicher Tractor Lay Shaft Front                    | 3431   | 87084000 | 18% |
| 93677138 | Eicher Tractor Coupling Shaft Assy.               | 1113   | 87084000 | 18% |
| 93677163 | Eicher Tractor Hi Low Stopper Bush (Hyd)          | 129    | 87089400 | 18% |
| 93677199 | Eicher Tractor Differential Housing Assy          | 8432   | 87084000 | 18% |
| 93677242 | Eicher Tractor Sliding Fear 3Rd/4Th Z-26          | 2103   | 87084000 | 18% |
| 93677254 | Eicher Tractor Spur Pinion 3Rd Z-31               | 3112   | 87084000 | 18% |
| 93677278 | Eicher Tractor Gasket G1 Top Cover                | 109    | 68129090 | 18% |
| 93677400 | Eicher Tractor Uj Shaft                           | 2176   | 87084000 | 18% |
| 93677412 | Eicher Tractor Pto Cover                          | 3488   | 87084000 | 18% |
| 93677424 | Eicher Tractor Gasket Pto Cover                   | 73     | 68129090 | 18% |
| 93677436 | Eicher Tractor Pto Shaft Front                    | 3792   | 87084000 | 18% |
| 93677461 | Eicher Tractor Pto Shaft Output                   | 2899   | 87084000 | 18% |
| 93677473 | Eicher Tractor Pto Actuator Assy                  | 1296   | 87084000 | 18% |
| 93677485 | Eicher Tractor Companion Flange                   | 1128   | 87089900 | 18% |
| 93677497 | Eicher Tractor Gasket Engine Mounting Face        | 335    | 68129090 | 18% |
| 93677503 | Eicher Tractor Intermediate Shaft Rear            | 3190   | 87084000 | 18% |
| 93677527 | Eicher Tractor Pto Splined Sleeve                 | 898    | 87084000 | 18% |
| 93677540 | Eicher Tractor Lock Nut M75X1.5                   | 806    | 87087000 | 18% |
| 93677588 | Eicher Tractor G2 Assy 557 4Wd (Includes Drop Box | 185672 | 87084000 | 18% |
| 93677590 | Eicher Tractor Speed Gear Box Assy                | 156224 | 87084000 | 18% |
| 93677643 | Eicher Tractor Gs Lever                           | 1022   | 87084000 | 18% |
| 93678076 | Eicher Tractor Front Axle 4Wd                     | 411202 | 87085000 | 18% |
| 93678088 | Eicher Tractor Pto Shaft Assembly                 | 3082   | 87084000 | 18% |
| 93678090 | Eicher Tractor Pry Shaft Z23 Dc (78090)-Dlx       | 4261   | 87084000 | 18% |
| 93678106 | Eicher Tractor Pry Shaft Z23/16 Sc (78106)-Dlx    | 5445   | 87084000 | 18% |
| 93678118 | Eicher Tractor Pto Drive Shaft Z16 (78118)-Dlx    | 3043   | 87084000 | 18% |
| 93678120 | Eicher Tractor Shifter Knob                       | 190    | 87084000 | 18% |
| 93678143 | Eicher Tractor Pto Cm Gear Z53 - Dlx (78143)      | 2654   | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93678209 | Eicher Tractor Spur Pinion 3Rd                     | 1718  | 87084000 | 18% |
| 93678271 | Eicher Tractor Gasket G1 G2                        | 103   | 68129090 | 18% |
| 93679330 | Eicher Tractor Assy. Differential Housing          | 9162  | 87084000 | 18% |
| 93679433 | Eicher Tractor Roller Pack 25.5X35.5X30            | 541   | 73181500 | 18% |
| 93679445 | Eicher Tractor Roller Pack 59X69X30                | 718   | 73181500 | 18% |
| 93679457 | Eicher Tractor Dg Ball Bearing M16207              | 484   | 84821011 | 18% |
| 93679901 | Eicher Tractor Bearing Support Kit 557             | 2178  | 87084000 | 18% |
| 93679925 | Eicher Tractor Gasket For G1-Fw Hsg                | 137   | 68129090 | 18% |
| 93679937 | Eicher Tractor Mud Seal Cover                      | 488   | 87084000 | 18% |
| 93679949 | Eicher Tractor Gasket Mudseal Cover                | 7     | 68129922 | 18% |
| 93683199 | Eicher Tractor Guide Sleeve & Input Shaft Assy. 88 | 12182 | 87084000 | 18% |
| 93690027 | Eicher Tractor Shaft Pto Intermediate              | 800   | 87084000 | 18% |
| 93690039 | Eicher Tractor Spring - Slip Clutch                | 21    | 73209090 | 18% |
| 93690040 | Eicher Tractor Retaining Ring-Ext                  | 15    | 87089900 | 18% |
| 93690052 | Eicher Tractor Spacer                              | 12    | 87089900 | 18% |
| 93690064 | Eicher Tractor Shaft Range Driving                 | 3215  | 87084000 | 18% |
| 93690076 | Eicher Tractor Bush                                | 41    | 87085000 | 18% |
| 93690088 | Eicher Tractor Slip Clutch Pto                     | 537   | 87089900 | 18% |
| 93690090 | Eicher Tractor Case, Differential Bearing Rh       | 892   | 84822011 | 18% |
| 93690106 | Eicher Tractor Lock Plate                          | 61    | 87089900 | 18% |
| 93690118 | Eicher Tractor Plug Mangnet                        | 244   | 87085000 | 18% |
| 93690131 | Eicher Tractor Case Bearing Pinion                 | 727   | 84822011 | 18% |
| 93690143 | Eicher Tractor Ball_Bearing                        | 466   | 84828000 | 18% |
| 93690155 | Eicher Tractor Needle Bearing                      | 412   | 84824000 | 18% |
| 93690167 | Eicher Tractor Retaining Ring-Int                  | 59    | 87085000 | 18% |
| 93690179 | Eicher Tractor Gear 4Wd Driving                    | 1647  | 87084000 | 18% |
| 93690180 | Eicher Tractor Retaining Ring_Ext                  | 19    | 87085000 | 18% |
| 93690192 | Eicher Tractor Shim                                | 13    | 73182200 | 18% |
| 93690209 | Eicher Tractor Gear Range Driven                   | 3130  | 87084000 | 18% |
| 93690210 | Eicher Tractor Bevel Pinion 0T                     | 3051  | 87084000 | 18% |
| 93690222 | Eicher Tractor Spacer                              | 109   | 87089900 | 18% |
| 93690234 | Eicher Tractor Shim                                | 15    | 73182200 | 18% |
| 93690246 | Eicher Tractor Dowel Pin                           | 18    | 73182990 | 18% |
| 93690260 | Eicher Tractor Cover Case 4Wd                      | 740   | 87085000 | 18% |
| 93690271 | Eicher Tractor Shaft Idler 4Wd                     | 199   | 87084000 | 18% |
| 93690283 | Eicher Tractor Case 4Wd                            | 2364  | 87085000 | 18% |
| 93690295 | Eicher Tractor Plug                                | 17    | 73182990 | 18% |
| 93690301 | Eicher Tractor Oil Seal- Id25Xod42                 | 598   | 40169330 | 18% |
| 93690313 | Eicher Tractor Spring Detent 4Wd                   | 12    | 87089900 | 18% |
| 93690325 | Eicher Tractor Thrust Washer                       | 8     | 87089900 | 18% |
| 93690337 | Eicher Tractor Gear Driven 4Wd                     | 2051  | 87084000 | 18% |
| 93690349 | Eicher Tractor Shaft Driven 4Wd                    | 643   | 87084000 | 18% |
| 93690350 | Eicher Tractor Gear Idler 4Wd                      | 1695  | 87084000 | 18% |
| 93690362 | Eicher Tractor Steel Ball                          | 48    | 73182990 | 18% |
| 93690374 | Eicher Tractor Case Transmission                   | 16910 | 87089900 | 18% |
| 93690386 | Eicher Tractor Case, Differential Bearing Lh       | 864   | 84822011 | 18% |
| 93690404 | Eicher Tractor Differential Device Assy,Rr         | 2045  | 87084000 | 18% |





|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93690416 | Eicher Tractor Shaft, Differential Pinion  | 1843 | 87084000 | 18% |
| 93690428 | Eicher Tractor Pinion, Differential        | 649  | 87084000 | 18% |
| 93690430 | Eicher Tractor Pin Straight                | 16   | 73182990 | 18% |
| 93690441 | Eicher Tractor Pin Straight                | 16   | 73182990 | 18% |
| 93690453 | Eicher Tractor Gear, Diff Side             | 809  | 87084000 | 18% |
| 93690465 | Eicher Tractor Flange Screw                | 7    | 73181500 | 18% |
| 93690477 | Eicher Tractor Bevel Gear 41T              | 5593 | 87084000 | 18% |
| 93690490 | Eicher Tractor Shaft Pto Driver            | 1029 | 87084000 | 18% |
| 93690519 | Eicher Tractor Shaft Pto                   | 2477 | 87084000 | 18% |
| 93690520 | Eicher Tractor Gear Pto Driven 540         | 3428 | 87084000 | 18% |
| 93690532 | Eicher Tractor Cover Pto                   | 2094 | 87089900 | 18% |
| 93690544 | Eicher Tractor Plate Sealing               | 122  | 73182200 | 18% |
| 93690556 | Eicher Tractor Seal Radial                 | 81   | 87089900 | 18% |
| 93690570 | Eicher Tractor Case Axle Lh                | 6477 | 87089900 | 18% |
| 93690581 | Eicher Tractor Brake Assy Lh               | 4618 | 87083900 | 18% |
| 93690593 | Eicher Tractor Shaft Rear Axle             | 4491 | 87085000 | 18% |
| 93690600 | Eicher Tractor Dowel Pin-Hollow            | 29   | 87089900 | 18% |
| 93690611 | Eicher Tractor Spacer                      | 136  | 87089900 | 18% |
| 93690623 | Eicher Tractor Cover Brake                 | 645  | 87085000 | 18% |
| 93690635 | Eicher Tractor Retaining Ring-Int          | 64   | 87085000 | 18% |
| 93690647 | Eicher Tractor Gear, 72                    | 3399 | 87084000 | 18% |
| 93690659 | Eicher Tractor Mud Block Seal-Id60Xod90    | 2267 | 40169330 | 18% |
| 93690660 | Eicher Tractor Retaining Ring-Int          | 76   | 87085000 | 18% |
| 93690672 | Eicher Tractor Shaft Bull Pinion           | 1475 | 87089900 | 18% |
| 93690696 | Eicher Tractor Case Axle Rh                | 6477 | 87089900 | 18% |
| 93690702 | Eicher Tractor Brake Assy Rh               | 4618 | 87083900 | 18% |
| 93690714 | Eicher Tractor Stud                        | 51   | 73181900 | 18% |
| 93690726 | Eicher Tractor Coupling Difflock           | 464  | 87089900 | 18% |
| 93690738 | Eicher Tractor Shaft Difflock              | 448  | 87089900 | 18% |
| 93690740 | Eicher Tractor Assy. Difflock Pedal Andarm | 871  | 87089900 | 18% |
| 93690751 | Eicher Tractor Fork Difflock               | 1610 | 87089900 | 18% |
| 93690763 | Eicher Tractor Spring Difflock             | 22   | 73209090 | 18% |
| 93690775 | Eicher Tractor Linkage Diff Lock Assy      | 634  | 87089900 | 18% |
| 93690787 | Eicher Tractor Arm Diff Lock Assy          | 322  | 87089900 | 18% |
| 93690799 | Eicher Tractor Arm, Rock Spring            | 26   | 73209090 | 18% |
| 93690805 | Eicher Tractor Slotted Pin Spring          | 10   | 73209020 | 18% |
| 93690817 | Eicher Tractor Slotted Spring Pin          | 5    | 73209020 | 18% |
| 93690829 | Eicher Tractor Pin, Snap                   | 23   | 87089900 | 18% |
| 93690830 | Eicher Tractor Assy Linkage - Pto          | 553  | 87089900 | 18% |
| 93690842 | Eicher Tractor Shift Arm (Pto)             | 1465 | 87089900 | 18% |
| 93690854 | Eicher Tractor Pto Connecting Arm          | 251  | 87089900 | 18% |
| 93690866 | Eicher Tractor Lever                       | 1319 | 87089900 | 18% |
| 93690878 | Eicher Tractor Shift Fork (Pto)            | 1090 | 87089900 | 18% |
| 93690880 | Eicher Tractor Rail Pto                    | 272  | 87089900 | 18% |
| 93690891 | Eicher Tractor Head Pin                    | 19   | 73182990 | 18% |
| 93690908 | Eicher Tractor Spring                      | 6    | 73209090 | 18% |
| 93690910 | Eicher Tractor Stopper,2                   | 52   | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93690921 | Eicher Tractor Spring Pin                   | 3     | 73209020 | 18% |
| 93690945 | Eicher Tractor Cover Pto                    | 103   | 87089900 | 18% |
| 93690957 | Eicher Tractor Shaft Propeller 1            | 1335  | 87085000 | 18% |
| 93690969 | Eicher Tractor Shaft Propeller 2            | 1080  | 87085000 | 18% |
| 93690970 | Eicher Tractor Propeller Shaft Cover 2      | 895   | 87089900 | 18% |
| 93690982 | Eicher Tractor Retaining Ring-Int           | 29    | 87085000 | 18% |
| 93690994 | Eicher Tractor Case Bearing                 | 837   | 84822011 | 18% |
| 93691007 | Eicher Tractor Assy. Arm 4Wd                | 793   | 87089900 | 18% |
| 93691019 | Eicher Tractor Assy. Linkage                | 468   | 87089900 | 18% |
| 93691020 | Eicher Tractor Assy. 4Wd Lever              | 632   | 87089900 | 18% |
| 93691032 | Eicher Tractor Arm Shift 4Wd                | 1113  | 87089900 | 18% |
| 93691044 | Eicher Tractor Stopper                      | 12    | 73182200 | 18% |
| 93691056 | Eicher Tractor Holder 2                     | 33    | 87089900 | 18% |
| 93691068 | Eicher Tractor Pin                          | 177   | 73182990 | 18% |
| 93691070 | Eicher Tractor Shaft Counter                | 3056  | 87084000 | 18% |
| 93691081 | Eicher Tractor Coupler 1St-Rev              | 946   | 87089900 | 18% |
| 93691093 | Eicher Tractor Gear Driven 1St              | 1916  | 87084000 | 18% |
| 93691100 | Eicher Tractor Gear Driven 2Nd-3Rd          | 2148  | 87085000 | 18% |
| 93691111 | Eicher Tractor Gear Driven Rev              | 1264  | 87085000 | 18% |
| 93691123 | Eicher Tractor Spacer                       | 133   | 87089900 | 18% |
| 93691135 | Eicher Tractor Spacer                       | 177   | 87089900 | 18% |
| 93691147 | Eicher Tractor Hub 1St-Rev                  | 1177  | 87084000 | 18% |
| 93691159 | Eicher Tractor Retaining Ring-Ext           | 36    | 87085000 | 18% |
| 93691160 | Eicher Tractor Gear Reverse Idler           | 722   | 87084000 | 18% |
| 93691172 | Eicher Tractor Shaft Driving 1St-Rev        | 3220  | 87084000 | 18% |
| 93691184 | Eicher Tractor Cluster Gear Driving 2Nd-3Rd | 2983  | 87084000 | 18% |
| 93691196 | Eicher Tractor Case Bearing Mid             | 1554  | 87085000 | 18% |
| 93691202 | Eicher Tractor Plug,Oil Inlets              | 27    | 87089900 | 18% |
| 93691214 | Eicher Tractor Shaft Reverse Idler          | 270   | 87084000 | 18% |
| 93691226 | Eicher Tractor Plug Magnetic Drain -(C/A)   | 110   | 87085000 | 18% |
| 93691238 | Eicher Tractor Case Mid                     | 7010  | 87089900 | 18% |
| 93691240 | Eicher Tractor Dip Stick-24Hp               | 190   | 87089900 | 18% |
| 93691251 | Eicher Tractor Dowel Pin                    | 13    | 73182990 | 18% |
| 93691263 | Eicher Tractor Ass'Y, Clutch Cover          | 2446  | 87089300 | 18% |
| 93691275 | Eicher Tractor Comp Disk,Clutch             | 3133  | 87089300 | 18% |
| 93691287 | Eicher Tractor Dowel Pin                    | 15    | 73182990 | 18% |
| 93691299 | Eicher Tractor Shaft Main Drive             | 915   | 87084000 | 18% |
| 93691305 | Eicher Tractor Housing Clutch               | 15590 | 87084000 | 18% |
| 93691317 | Eicher Tractor Breather Rubber Hose         | 57    | 40092100 | 18% |
| 93691329 | Eicher Tractor Clip, Tube                   | 18    | 84099990 | 28% |
| 93691330 | Eicher Tractor Retaining Ring-Int           | 34    | 73209090 | 18% |
| 93691341 | Eicher Tractor Slotted Spring Pin           | 7     | 73209020 | 18% |
| 93691353 | Eicher Tractor Stud                         | 29    | 73181900 | 18% |
| 93691365 | Eicher Tractor Bush                         | 66    | 87089300 | 18% |
| 93691377 | Eicher Tractor Bush                         | 70    | 87089900 | 18% |
| 93691389 | Eicher Tractor Cover - Housing Clutch       | 1182  | 87084000 | 18% |
| 93691390 | Eicher Tractor Case, Differential Fr        | 953   | 84099941 | 28% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93691408 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691410 | Eicher Tractor Assy, Guard Front Supportframe - Co | 266  | 87089900 | 18% |
| 93691421 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691433 | Eicher Tractor Diff. Gear Shaft Rh -Narrow 1 -     | 483  | 87084000 | 18% |
| 93691445 | Eicher Tractor Thrust Collar                       | 23   | 73182200 | 18% |
| 93691457 | Eicher Tractor Cover-Front Diff Case               | 570  | 87089900 | 18% |
| 93691469 | Eicher Tractor Dx, Bush                            | 119  | 84833000 | 18% |
| 93691470 | Eicher Tractor Assy, Guard Front Supportframe - Co | 266  | 87089900 | 18% |
| 93691482 | Eicher Tractor Seal, Oil                           | 896  | 87085000 | 18% |
| 93691494 | Eicher Tractor Bevel Gear, 11                      | 958  | 87084000 | 18% |
| 93691512 | Eicher Tractor Collar, Fr Axle Shaft               | 41   | 73182200 | 18% |
| 93691524 | Eicher Tractor Snap_Ring                           | 51   | 87085000 | 18% |
| 93691536 | Eicher Tractor Spring Dowel Od 4.6 X28Mm           | 7    | 73209020 | 18% |
| 93691548 | Eicher Tractor Bracket,Rear                        | 1529 | 87089900 | 18% |
| 93691550 | Eicher Tractor Bevel Gear, 16                      | 1177 | 87084000 | 18% |
| 93691585 | Eicher Tractor Spiral Bevel Gear                   | 2833 | 87089900 | 18% |
| 93691597 | Eicher Tractor Bush                                | 218  | 84833000 | 18% |
| 93691603 | Eicher Tractor Gear-Diff Side                      | 749  | 87085000 | 18% |
| 93691615 | Eicher Tractor Diff. Gear Shaft Lh -Narrow 1 -     | 685  | 87084000 | 18% |
| 93691627 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691639 | Eicher Tractor Case, Bevel Gear                    | 1785 | 87089900 | 18% |
| 93691640 | Eicher Tractor Shaft , Bevel Gear                  | 654  | 87084000 | 18% |
| 93691652 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691664 | Eicher Tractor Dowel Pin                           | 17   | 73182990 | 18% |
| 93691676 | Eicher Tractor Collar Thrust                       | 49   | 73182200 | 18% |
| 93691688 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691690 | Eicher Tractor Wheel-End Housing - 4Wd             | 4001 | 87085000 | 18% |
| 93691706 | Eicher Tractor Bevel Gear, 9                       | 997  | 87084000 | 18% |
| 93691718 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691720 | Eicher Tractor Plin Semilunar Snap                 | 78   | 73182910 | 18% |
| 93691731 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691743 | Eicher Tractor Bevelpinion Shaft                   | 2518 | 87089900 | 18% |
| 93691755 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691779 | Eicher Tractor Plug                                | 236  | 87089900 | 18% |
| 93691780 | Eicher Tractor Shaft, Differential Pinion          | 358  | 87089900 | 18% |
| 93691792 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691809 | Eicher Tractor Seal, Oil                           | 385  | 87085000 | 18% |
| 93691810 | Eicher Tractor Pinion, Differential                | 385  | 87084000 | 18% |
| 93691822 | Eicher Tractor Dipstick Front Axle                 | 207  | 90178090 | 18% |
| 93691834 | Eicher Tractor Cover - Wheel End                   | 1600 | 87085000 | 18% |
| 93691846 | Eicher Tractor Bracket Front                       | 1643 | 87089900 | 18% |
| 93691858 | Eicher Tractor Bush, Dx                            | 263  | 84833000 | 18% |
| 93691860 | Eicher Tractor Collar, Adjust                      | 162  | 73199000 | 18% |
| 93691871 | Eicher Tractor Spacer                              | 168  | 73182990 | 18% |
| 93691883 | Eicher Tractor Cover Main Transmission             | 3385 | 87085000 | 18% |
| 93691895 | Eicher Tractor Main Shift Lever Assy               | 810  | 87089900 | 18% |
| 93691919 | Eicher Tractor Fork 1St-Rev                        | 970  | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93691920 | Eicher Tractor Fork 2Nd-3Rd                   | 952   | 87089900 | 18% |
| 93691932 | Eicher Tractor Rail 1St-Rev                   | 282   | 87089900 | 18% |
| 93691944 | Eicher Tractor Rail 2Nd-3Rd                   | 329   | 87089900 | 18% |
| 93691956 | Eicher Tractor Rod Main Shift                 | 484   | 87089900 | 18% |
| 93691968 | Eicher Tractor Pin Interlock                  | 60    | 73182990 | 18% |
| 93691970 | Eicher Tractor Return Spring                  | 43    | 73182200 | 18% |
| 93691981 | Eicher Tractor Join Pin                       | 15    | 73182990 | 18% |
| 93691993 | Eicher Tractor Pin, Main Transmissionassy     | 211   | 87085000 | 18% |
| 93692000 | Eicher Tractor Arm, Shift                     | 331   | 87089900 | 18% |
| 93692012 | Eicher Tractor Pin, Snap                      | 14    | 73182990 | 18% |
| 93692036 | Eicher Tractor Assy Knob Indicator Lever      | 357   | 87089900 | 18% |
| 93692048 | Eicher Tractor Oil_Seal                       | 152   | 87085000 | 18% |
| 93692050 | Eicher Tractor Spring Detent                  | 13    | 87089900 | 18% |
| 93692905 | Eicher Tractor Diff Lock Pedal Eco Es3        | 507   | 87085000 | 18% |
| 93693510 | Eicher Tractor Dual Clutch Assembly           | 27269 | 87089300 | 18% |
| 93694471 | Eicher Tractor Mud Seal Cover                 | 520   | 87084000 | 18% |
| 93704853 | Eicher Tractor Side Gear 16T (Mvbgp16340)     | 1336  | 87084000 | 18% |
| 93704865 | Eicher Tractor Pinion 10T (Mvbgp10140)        | 900   | 84834000 | 18% |
| 93704877 | Eicher Tractor Bearing 30205 Trb (Mvtrb30205) | 686   | 84828000 | 18% |
| 93704889 | Eicher Tractor Spring Dovel (Mvds0640)        | 11    | 73182100 | 18% |
| 93704890 | Eicher Tractor Conical Washer (Mvspw5000)     | 28    | 73182100 | 18% |
| 93704907 | Eicher Tractor Trust Washer ( Mvtw6000)       | 32    | 73182100 | 18% |
| 93704919 | Eicher Tractor Shaft Pinion (Mvcs1491)        | 248   | 84834000 | 18% |
| 93704920 | Eicher Tractor Gear Case B (Mvcg00002)        | 2427  | 84834000 | 18% |
| 93704932 | Eicher Tractor Case Cover A (Mvcg0000154)     | 7697  | 84841090 | 18% |
| 93704944 | Eicher Tractor Bush Axle Housing ( Mvcg02622) | 164   | 73181500 | 18% |
| 93710063 | Eicher Tractor Hydraulic Shaft                | 3710  | 87089900 | 18% |
| 93710154 | Eicher Tractor Draft Lever Assy               | 122   | 87089900 | 18% |
| 93710208 | Eicher Tractor Hydraulic Shaft                | 3909  | 87089900 | 18% |
| 93710257 | Eicher Tractor Gear For Hyd Pump              | 1071  | 87084000 | 18% |
| 93710269 | Eicher Tractor Strainer Hsg.                  | 1000  | 84219900 | 18% |
| 93710282 | Eicher Tractor Hyd.Gear Pump                  | 5226  | 84138190 | 18% |
| 93710312 | Eicher Tractor Strainer                       | 371   | 84219900 | 18% |
| 93710324 | Eicher Tractor Gasket-Strainer Hsg            | 35    | 68129090 | 18% |
| 93710336 | Eicher Tractor Plug                           | 100   | 87084000 | 18% |
| 93710348 | Eicher Tractor Hose Inlet                     | 195   | 40093100 | 18% |
| 93710350 | Eicher Tractor Cover Strainer Housing         | 278   | 87084000 | 18% |
| 93710385 | Eicher Tractor Suction Pipe Assy Pump End     | 370   | 87089900 | 18% |
| 93710427 | Eicher Tractor Mode Slector Value             | 210   | 87089900 | 18% |
| 93710762 | Eicher Tractor Plug M8X1,Din 906              | 74    | 87084000 | 18% |
| 93710865 | Eicher Tractor Cylindrical Pin, Dia 4         | 13    | 87089900 | 18% |
| 93710877 | Eicher Tractor Bead                           | 7     | 87089900 | 18% |
| 93711006 | Eicher Tractor Hydraulic Shaft                | 2688  | 87089900 | 18% |
| 93711018 | Eicher Tractor Shield Assy                    | 411   | 87089900 | 18% |
| 93711092 | Eicher Tractor Bracket                        | 241   | 87089900 | 18% |
| 93711422 | Eicher Tractor Spring Check Value             | 8     | 73209090 | 18% |
| 93711511 | Eicher Tractor Suction Pipe Rear              | 213   | 87089900 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 93711547 | Eicher Tractor Hydraulic Shaft                | 6070 | 87089900 | 18% |
| 93711559 | Eicher Tractor Crank                          | 4196 | 87089900 | 18% |
| 93711560 | Eicher Tractor Connecting Rod                 | 1061 | 87089900 | 18% |
| 93711572 | Eicher Tractor End Cover Lt.                  | 392  | 87084000 | 18% |
| 93711584 | Eicher Tractor End Cover Rt.                  | 392  | 87084000 | 18% |
| 93711614 | Eicher Tractor Special Bolt                   | 165  | 73181500 | 18% |
| 93711626 | Eicher Tractor Special Bolt                   | 148  | 73181500 | 18% |
| 93711640 | Eicher Tractor Cylinder Assy 100 Dia          | 3599 | 87089900 | 18% |
| 93711754 | Eicher Tractor Bracket (Mixed Mode - 368)     | 1261 | 87089900 | 18% |
| 93711894 | Eicher Tractor Pin Assembly                   | 306  | 87089900 | 18% |
| 93711948 | Eicher Tractor Coupling Suction               | 218  | 87084000 | 18% |
| 93712230 | Eicher Tractor Cam                            | 746  | 87089900 | 18% |
| 93712242 | Eicher Tractor Hydraulic Shaft                | 3990 | 87089900 | 18% |
| 93712424 | Eicher Tractor Sensing Pin                    | 362  | 73182100 | 18% |
| 93712450 | Eicher Tractor Addc Hsg. Top Cover            | 2149 | 87089900 | 18% |
| 93712461 | Eicher Tractor Feed Back Rod                  | 117  | 87089900 | 18% |
| 93712497 | Eicher Tractor Draft Input Assy               | 583  | 87089900 | 18% |
| 93712527 | Eicher Tractor Spring Linkage                 | 25   | 73209090 | 18% |
| 93712564 | Eicher Tractor Spring Tripper                 | 19   | 73182100 | 18% |
| 93712588 | Eicher Tractor Spacer Tube                    | 27   | 73182100 | 18% |
| 93712618 | Eicher Tractor Pin Assy-Addc End              | 336  | 87089900 | 18% |
| 93712643 | Eicher Tractor Linkage Assy                   | 2170 | 87083000 | 18% |
| 93712758 | Eicher Tractor Addc Top Cover (Fabricated)    | 2626 | 87089900 | 18% |
| 93713040 | Eicher Tractor Suction Pipe Rear-Sdi/368B     | 277  | 87089900 | 18% |
| 93713064 | Eicher Tractor Suction Pipe Front-Super Style | 274  | 87089900 | 18% |
| 93713179 | Eicher Tractor Tripper Rod Assembly           | 94   | 87089900 | 18% |
| 93713180 | Eicher Tractor Extension Rod                  | 153  | 87089900 | 18% |
| 93713192 | Eicher Tractor Cam                            | 967  | 87089900 | 18% |
| 93713209 | Eicher Tractor Feed Back Rod                  | 154  | 87089900 | 18% |
| 93713210 | Eicher Tractor Hydraulic Pump Assy            | 6839 | 84138190 | 18% |
| 93713258 | Eicher Tractor Bush                           | 84   | 87089900 | 18% |
| 93713295 | Eicher Tractor Bush                           | 59   | 87089900 | 18% |
| 93713313 | Eicher Tractor Draft Assy                     | 124  | 87089900 | 18% |
| 93713374 | Eicher Tractor H Link Assy                    | 294  | 87089900 | 18% |
| 93713441 | Eicher Tractor Bush 65*60*47 Du               | 569  | 87089900 | 18% |
| 93713453 | Eicher Tractor Bush 60*55*47 Du (B&S)         | 526  | 87089900 | 18% |
| 93713477 | Eicher Tractor Gasket Addc Top                | 173  | 40169990 | 18% |
| 93713520 | Eicher Tractor O Ring (15.3X2.4) Shore A70    | 17   | 40169320 | 18% |
| 93713581 | Eicher Tractor Suction Pipe Rear              | 170  | 87089900 | 18% |
| 93713702 | Eicher Tractor Position Lever Assy.           | 149  | 87089900 | 18% |
| 93713738 | Eicher Tractor Rod Assembly                   | 177  | 87089900 | 18% |
| 93713751 | Eicher Tractor Draft Input Rod                | 57   | 87089900 | 18% |
| 93713854 | Eicher Tractor Turn Rod                       | 145  | 87089900 | 18% |
| 93713878 | Eicher Tractor Crank                          | 1413 | 87089900 | 18% |
| 93713880 | Eicher Tractor Piston (Dia 100)               | 1332 | 87089900 | 18% |
| 93713891 | Eicher Tractor Cylinder Assembly              | 3168 | 87089900 | 18% |
| 93713921 | Eicher Tractor Suction Pipe Front             | 244  | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93713945 | Eicher Tractor Pressure Pipe 312P/369    | 1379 | 87089900 | 18% |
| 93713969 | Eicher Tractor Connecting Rod            | 691  | 87089900 | 18% |
| 93713972 | Eicher Tractor Suction Pipe Front        | 401  | 87089900 | 18% |
| 93713982 | Eicher Tractor Special Screw             | 381  | 73181500 | 18% |
| 93713994 | Eicher Tractor Spacer                    | 132  | 73182100 | 18% |
| 93714007 | Eicher Tractor Roto Glydring Dia 55(B+S) | 250  | 39269099 | 18% |
| 93714019 | Eicher Tractor Roto Glydring Dia 60(B+S) | 281  | 39269099 | 18% |
| 93714354 | Eicher Tractor Guide Block               | 43   | 87089900 | 18% |
| 93714410 | Eicher Tractor Hydraulic Shaft (241)     | 2670 | 87089900 | 18% |
| 93714603 | Eicher Tractor Clamp Hyd. Pipe           | 26   | 87089900 | 18% |
| 93714822 | Eicher Tractor Hydraulic Shaft (368F)    | 3659 | 87089900 | 18% |
| 93714860 | Eicher Tractor Hydrulic Shaft (242/312)  | 3217 | 87089900 | 18% |
| 93715061 | Eicher Tractor Suction Pipe Front 241    | 459  | 87089900 | 18% |
| 93715085 | Eicher Tractor Suction Pipe 241 Rear     | 248  | 87089900 | 18% |
| 93715139 | Eicher Tractor Bracket                   | 3188 | 87089900 | 18% |
| 93715140 | Eicher Tractor Wynseal Dia 100           | 494  | 39269099 | 18% |
| 93715152 | Eicher Tractor Wynseal Dia 90            | 533  | 39269099 | 18% |
| 93715164 | Eicher Tractor Wynseal Dia 80            | 519  | 39269099 | 18% |
| 93715206 | Eicher Tractor Strainer Mtg Plate        | 246  | 84219900 | 18% |
| 93715243 | Eicher Tractor Hyd. Gear Pump            | 5256 | 84138190 | 18% |
| 93715255 | Eicher Tractor Hyd. Gear Pump            | 4160 | 84138190 | 18% |
| 93715267 | Eicher Tractor Cylinder Assy Dia 90      | 1963 | 87089900 | 18% |
| 93715279 | Eicher Tractor Piston Dia 90             | 925  | 87089900 | 18% |
| 93715413 | Eicher Tractor Shim 45.5X63X0.5          | 13   | 73182100 | 18% |
| 93715449 | Eicher Tractor Breather Assy.            | 35   | 87089900 | 18% |
| 93715516 | Eicher Tractor Hydraulic Shaft- Sdi      | 4283 | 87089900 | 18% |
| 93715541 | Eicher Tractor Suction Cover             | 98   | 87084000 | 18% |
| 93715577 | Eicher Tractor Roto Glydring Dia 50      | 199  | 39269099 | 18% |
| 93715589 | Eicher Tractor Roto Glydring Dia 45      | 163  | 39269099 | 18% |
| 93715632 | Eicher Tractor Breather Pipe             | 230  | 87084000 | 18% |
| 93715656 | Eicher Tractor Clamp Hyd. Pipe           | 28   | 87089900 | 18% |
| 93715668 | Eicher Tractor Grommet                   | 26   | 40169990 | 18% |
| 93715681 | Eicher Tractor Crank                     | 335  | 87089900 | 18% |
| 93715693 | Eicher Tractor Roller Position           | 62   | 84824000 | 18% |
| 93715700 | Eicher Tractor Pin Sliding               | 61   | 87084000 | 18% |
| 93715711 | Eicher Tractor Position Cam              | 566  | 87089900 | 18% |
| 93715759 | Eicher Tractor Spring Tripper            | 22   | 73202000 | 18% |
| 93715760 | Eicher Tractor Arbor Spring              | 86   | 73202000 | 18% |
| 93715772 | Eicher Tractor Connection Pin            | 102  | 87089900 | 18% |
| 93715784 | Eicher Tractor Transmission Lever        | 278  | 87085000 | 18% |
| 93715826 | Eicher Tractor Feedback Link             | 62   | 87089900 | 18% |
| 93715840 | Eicher Tractor Coupler Rod               | 158  | 87089900 | 18% |
| 93715887 | Eicher Tractor Roller Draft              | 75   | 84824000 | 18% |
| 93715905 | Eicher Tractor Lever Draft               | 296  | 87089900 | 18% |
| 93715929 | Eicher Tractor Auto Trip Support         | 79   | 87089900 | 18% |
| 93715942 | Eicher Tractor Special Screw             | 211  | 73181500 | 18% |
| 93716120 | Eicher Tractor Rod                       | 197  | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93716181 | Eicher Tractor Distributor Assy                 | 8671  | 87089900 | 18% |
| 93716247 | Eicher Tractor Lowering Spool                   | 189   | 87089900 | 18% |
| 93716259 | Eicher Tractor Spring Cap                       | 35    | 73209090 | 18% |
| 93716260 | Eicher Tractor Valve Lifter                     | 207   | 87089900 | 18% |
| 93716272 | Eicher Tractor Cover Plate                      | 30    | 87084000 | 18% |
| 93716284 | Eicher Tractor Back Plate                       | 112   | 87089900 | 18% |
| 93716314 | Eicher Tractor Hinge Pin                        | 335   | 73181500 | 18% |
| 93716326 | Eicher Tractor Hydraulic Shaft-368F             | 3272  | 87089900 | 18% |
| 93716338 | Eicher Tractor Seat Unloading Valve             | 44    | 87089900 | 18% |
| 93716340 | Eicher Tractor Unloading Valve                  | 168   | 87089900 | 18% |
| 93716351 | Eicher Tractor Reainer Unlodging Valve          | 64    | 87089900 | 18% |
| 93716363 | Eicher Tractor Retainer Damping Valve           | 36    | 87089900 | 18% |
| 93716375 | Eicher Tractor Reainer Check Valve              | 93    | 87089900 | 18% |
| 93716387 | Eicher Tractor Check Nut                        | 40    | 73181500 | 18% |
| 93716399 | Eicher Tractor Retainer-Spool Spring            | 82    | 87089900 | 18% |
| 93716405 | Eicher Tractor Seat-Safety Valve                | 148   | 87089900 | 18% |
| 93716417 | Eicher Tractor Guide Safety Valve               | 18    | 87089900 | 18% |
| 93716429 | Eicher Tractor Spacer                           | 15    | 73182100 | 18% |
| 93716430 | Eicher Tractor Drop Rate Adjuster               | 126   | 87089900 | 18% |
| 93716442 | Eicher Tractor Stopper Screw                    | 69    | 73181500 | 18% |
| 93716454 | Eicher Tractor Mode Selector Valve              | 173   | 87089900 | 18% |
| 93716466 | Eicher Tractor Wire Lock                        | 4     | 73202000 | 18% |
| 93716480 | Eicher Tractor Damping Valve                    | 62    | 87089900 | 18% |
| 93716508 | Eicher Tractor Sensing Rod                      | 154   | 87089900 | 18% |
| 93716521 | Eicher Tractor Sensing Lever                    | 161   | 87089900 | 18% |
| 93716557 | Eicher Tractor Shaft (H-Link)                   | 113   | 87084000 | 18% |
| 93716569 | Eicher Tractor H-Link Assy                      | 115   | 87089900 | 18% |
| 93716648 | Eicher Tractor Power Lift Hsg ( Ps )            | 15711 | 87089900 | 18% |
| 93716673 | Eicher Tractor Hydraulic Shaft                  | 3741  | 87089900 | 18% |
| 93716697 | Eicher Tractor End Cover Lt                     | 332   | 87084000 | 18% |
| 93716703 | Eicher Tractor End Cover Rt                     | 339   | 87084000 | 18% |
| 93716764 | Eicher Tractor Shield Assy.                     | 448   | 87089900 | 18% |
| 93716776 | Eicher Tractor Position Lever Assy.             | 159   | 87089900 | 18% |
| 93716806 | Eicher Tractor Hydraulic Shaft                  | 3400  | 87089900 | 18% |
| 93716831 | Eicher Tractor Adjusting Screw M8               | 36    | 73181500 | 18% |
| 93716843 | Eicher Tractor Spring Main Spool                | 5     | 73202000 | 18% |
| 93716855 | Eicher Tractor Spring Lowering Valve            | 5     | 73202000 | 18% |
| 93716960 | Eicher Tractor Pressure Pipe Assy Front-5660    | 926   | 87089900 | 18% |
| 93716971 | Eicher Tractor Pressure Pipe Rear (5660/485Int) | 691   | 87089900 | 18% |
| 93716983 | Eicher Tractor Union 7/8 Unf                    | 133   | 87089900 | 18% |
| 93716995 | Eicher Tractor Male Connector                   | 117   | 85443000 | 18% |
| 93717161 | Eicher Tractor Hose Pr. Line Filter             | 786   | 40093100 | 18% |
| 93717173 | Eicher Tractor Pressure Pipe                    | 950   | 87089900 | 18% |
| 93717185 | Eicher Tractor Suction Pipe Front               | 470   | 87089900 | 18% |
| 93717197 | Eicher Tractor Suction Pipe Rear Assy           | 434   | 87089900 | 18% |
| 93717203 | Eicher Tractor Suction Adaptor                  | 197   | 87089900 | 18% |
| 93717215 | Eicher Tractor Adapter Return                   | 253   | 87089900 | 18% |



|          |  |        |          |     |
|----------|--|--------|----------|-----|
| 93717239 | Eicher Tractor Suction Pipe Rear                   | 387    | 87089900 | 18% |
| 93717276 | Eicher Tractor Top Link Bkt M/C                    | 2167   | 87089900 | 18% |
| 93717288 | Eicher Tractor Flange                              | 263    | 87089900 | 18% |
| 93717290 | Eicher Tractor Draft Spring                        | 202    | 73202000 | 18% |
| 93717306 | Eicher Tractor Special Bolt                        | 81     | 73181500 | 18% |
| 93717320 | Eicher Tractor Addc Housing Mix Mode - 241         | 14004  | 87089900 | 18% |
| 93717343 | Eicher Tractor Power Lift Assy-333/380 Hydr        | 355054 | 87089900 | 18% |
| 93717471 | Eicher Tractor Pressure Pipe 380                   | 1234   | 87089900 | 18% |
| 93717690 | Eicher Tractor Pressure Pipe                       | 617    | 87089900 | 18% |
| 93717707 | Eicher Tractor Spacer                              | 287    | 73182100 | 18% |
| 93717719 | Eicher Tractor Clamping Plate                      | 340    | 87089900 | 18% |
| 93717793 | Eicher Tractor Addc Top Cover                      | 3304   | 87089900 | 18% |
| 93717811 | Eicher Tractor Pr. Pipe Assy Front(485 With 5660 A | 1075   | 87089900 | 18% |
| 93717823 | Eicher Tractor Pressure Pipe                       | 663    | 87089900 | 18% |
| 93717835 | Eicher Tractor Suction Pipe Rear                   | 331    | 87089900 | 18% |
| 93718074 | Eicher Tractor Counter Spring                      | 1691   | 73202000 | 18% |
| 93718086 | Eicher Tractor Bracket Stoper                      | 739    | 87089900 | 18% |
| 93718098 | Eicher Tractor Shim 0.5Mm                          | 15     | 73182100 | 18% |
| 93718104 | Eicher Tractor Shim (0.50Mm)                       | 13     | 73182100 | 18% |
| 93718116 | Eicher Tractor Addc Housing                        | 26684  | 87089900 | 18% |
| 93718128 | Eicher Tractor Guide Spacer                        | 37     | 87089900 | 18% |
| 93718130 | Eicher Tractor Gasket-Addc Hsg                     | 209    | 68129090 | 18% |
| 93718153 | Eicher Tractor Shim                                | 6      | 73182100 | 18% |
| 93718165 | Eicher Tractor Extension Rod                       | 257    | 87089900 | 18% |
| 93718177 | Eicher Tractor Shim                                | 15     | 73182100 | 18% |
| 93718220 | Eicher Tractor Stud Addc Mtg.                      | 26     | 73182100 | 18% |
| 93718426 | Eicher Tractor Lowering Sleeve (S/F)               | 347    | 87089900 | 18% |
| 93718440 | Eicher Tractor Distributor Hsg (S/F)               | 2644   | 87089900 | 18% |
| 93718487 | Eicher Tractor Delivery Elbow 3/4 Unf              | 426    | 87089900 | 18% |
| 93718499 | Eicher Tractor Union 3/4 Unf                       | 137    | 87089900 | 18% |
| 93718529 | Eicher Tractor Strainer Assly.                     | 641    | 84219900 | 18% |
| 93718542 | Eicher Tractor T.T.Plug                            | 37     | 87084000 | 18% |
| 93718554 | Eicher Tractor Lock Plate                          | 12     | 87084000 | 18% |
| 93718578 | Eicher Tractor Suction Pipe Assy Front             | 347    | 87089900 | 18% |
| 93718580 | Eicher Tractor Suction Pipe Assy Rear              | 868    | 87089900 | 18% |
| 93718591 | Eicher Tractor Sector Mounting Flange              | 474    | 87089900 | 18% |
| 93718621 | Eicher Tractor Shim ( 0.5 Mm )                     | 8      | 73182100 | 18% |
| 93718633 | Eicher Tractor Ptfе Washer                         | 18     | 73182100 | 18% |
| 93718645 | Eicher Tractor Presure Pipe Front                  | 328    | 87089900 | 18% |
| 93718657 | Eicher Tractor Presure Pipe Rear                   | 232    | 87089900 | 18% |
| 93718669 | Eicher Tractor Roto Glydng Dia 48                  | 266    | 39269099 | 18% |
| 93718712 | Eicher Tractor Pressure Pipe-333/380-480           | 619    | 87089900 | 18% |
| 93718724 | Eicher Tractor Pressure Pipe-368/485               | 1191   | 87089900 | 18% |
| 93718736 | Eicher Tractor Suction Pipe Rear-368/485           | 263    | 87089900 | 18% |
| 93718827 | Eicher Tractor Hydraulic Shaft                     | 4357   | 87089900 | 18% |
| 93718918 | Eicher Tractor Cylinder Assy ( Hsd Dia 90)         | 3422   | 87089900 | 18% |
| 93718955 | Eicher Tractor Spool Sleeve Assy                   | 1047   | 87089900 | 18% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93718967 | Eicher Tractor Main Spool                      | 242   | 87089900 | 18% |
| 93718980 | Eicher Tractor Main Sleeve (S/F)               | 673   | 87084000 | 18% |
| 93718992 | Eicher Tractor Cylinder Assy Dia 100           | 3756  | 87089900 | 18% |
| 93719029 | Eicher Tractor Pin (Crank)                     | 85    | 87084000 | 18% |
| 93719030 | Eicher Tractor Auto Trip Lever                 | 176   | 87089900 | 18% |
| 93719054 | Eicher Tractor Crank                           | 2142  | 87089900 | 18% |
| 93719066 | Eicher Tractor Con Rod                         | 680   | 87089900 | 18% |
| 93719078 | Eicher Tractor Addc Hsg                        | 20572 | 87089900 | 18% |
| 93719080 | Eicher Tractor Push Rod                        | 56    | 87089900 | 18% |
| 93719091 | Eicher Tractor Du Bush 48X53X40                | 406   | 87089900 | 18% |
| 93719108 | Eicher Tractor Du Bush 55X60X40                | 454   | 87089900 | 18% |
| 93719112 | Eicher Tractor Grommet                         | 25    | 40169990 | 18% |
| 93719121 | Eicher Tractor Clamp                           | 29    | 87089900 | 18% |
| 93719133 | Eicher Tractor Piston (Hds Dia 90)             | 1026  | 87089900 | 18% |
| 93719157 | Eicher Tractor Stopper                         | 38    | 87084000 | 18% |
| 93719169 | Eicher Tractor Etainer Damping Valve           | 34    | 87089900 | 18% |
| 93719170 | Eicher Tractor Spring Return                   | 12    | 73202000 | 18% |
| 93719194 | Eicher Tractor Cup Spring                      | 409   | 73202000 | 18% |
| 93719224 | Eicher Tractor Lever Main                      | 764   | 87089900 | 18% |
| 93719236 | Eicher Tractor Special Bolt                    | 190   | 73181500 | 18% |
| 93719248 | Eicher Tractor Holder Spring                   | 201   | 73202000 | 18% |
| 93719250 | Eicher Tractor Sliding Link                    | 41    | 87089900 | 18% |
| 93719261 | Eicher Tractor Cam Shaft Assy.                 | 396   | 87089900 | 18% |
| 93719339 | Eicher Tractor Sticker ( Mixed-Mode )          | 54    | 39199090 | 18% |
| 93719376 | Eicher Tractor Linkage Assy-50Hp               | 3319  | 87083000 | 18% |
| 93719406 | Eicher Tractor Oil Filter Assly                | 178   | 84219900 | 18% |
| 93719418 | Eicher Tractor Steering Hose Left 5660 Ps      | 997   | 40093100 | 18% |
| 93719420 | Eicher Tractor Steering Hose Left 5660 Ps      | 1341  | 40093100 | 18% |
| 93719443 | Eicher Tractor Pipe Steering Right             | 1266  | 87089400 | 18% |
| 93719455 | Eicher Tractor Steering Hose Right             | 932   | 40093100 | 18% |
| 93719467 | Eicher Tractor Pipe Pump Steering              | 876   | 87089400 | 18% |
| 93719510 | Eicher Tractor Lock Nut 3/4-16Unf              | 30    | 73181500 | 18% |
| 93719522 | Eicher Tractor Bulkhead Union 3/4 -16 Unf      | 139   | 87089900 | 18% |
| 93719534 | Eicher Tractor Clamp Fornt Steering            | 106   | 87089400 | 18% |
| 93719558 | Eicher Tractor Clamp Upper Strg.               | 72    | 87089400 | 18% |
| 93719560 | Eicher Tractor Clamp Lower Strg.               | 73    | 87089400 | 18% |
| 93719601 | Eicher Tractor Shield Assy - 241               | 445   | 87089900 | 18% |
| 93719625 | Eicher Tractor Shield Assly                    | 396   | 87089900 | 18% |
| 93719650 | Eicher Tractor Power Lift Housing - 9651 (Fin) | 17864 | 87089900 | 18% |
| 93719662 | Eicher Tractor Suction Pipe Assy Front         | 518   | 87089900 | 18% |
| 93719674 | Eicher Tractor Suction Pipe Assy Rear          | 487   | 87089900 | 18% |
| 93719686 | Eicher Tractor Pressure Pipe Assly Front       | 395   | 87089900 | 18% |
| 93719698 | Eicher Tractor Presure Pipe Assly Rear         | 494   | 87089900 | 18% |
| 93719730 | Eicher Tractor Filter Mtg. Bracket             | 770   | 87089900 | 18% |
| 93719790 | Eicher Tractor Steering Hose Right (485 Ps)    | 1054  | 40093100 | 18% |
| 93719807 | Eicher Tractor Steering Hose Left (485 Ps)     | 1105  | 40093100 | 18% |
| 93719819 | Eicher Tractor Pipe Steering Left (485 Ps)     | 1108  | 87089400 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93719820 | Eicher Tractor Pipe Steering Right (485 Ps)       | 1117  | 87089400 | 18% |
| 93719832 | Eicher Tractor Pipe Pump Steering (485 Ps)        | 463   | 87089400 | 18% |
| 93719844 | Eicher Tractor Pipe Return Steering (485 Ps)      | 893   | 87089400 | 18% |
| 93719856 | Eicher Tractor Steering Pl Filter (485 Ps)        | 518   | 87089400 | 18% |
| 93719868 | Eicher Tractor Pressure Pipe (485 Ps)             | 494   | 87089900 | 18% |
| 93719870 | Eicher Tractor Suction Pipe Front (485 Ps)        | 655   | 87089900 | 18% |
| 93719881 | Eicher Tractor Suction Pipe Rear (485 Ps)         | 337   | 87089900 | 18% |
| 93719893 | Eicher Tractor Tandem Pump Assly (485Ps)          | 8504  | 84138190 | 18% |
| 93719900 | Eicher Tractor Striner Hsg. (485 Ps)              | 1014  | 87084000 | 18% |
| 93719911 | Eicher Tractor Strainer Cover (485Ps)             | 329   | 84219900 | 18% |
| 93719935 | Eicher Tractor Delivery Elbow 7/8 Unf             | 429   | 87089900 | 18% |
| 93719947 | Eicher Tractor Casing                             | 2353  | 87089900 | 18% |
| 93719959 | Eicher Tractor Draft Spring                       | 2282  | 73202000 | 18% |
| 93719960 | Eicher Tractor Special Bolt                       | 288   | 73181500 | 18% |
| 93719972 | Eicher Tractor Flange                             | 7390  | 87089900 | 18% |
| 93722107 | Eicher Tractor Pin (Crank)                        | 86    | 73182990 | 18% |
| 93722119 | Eicher Tractor Coupler Rod                        | 228   | 87089900 | 18% |
| 93722120 | Eicher Tractor Lever Autotrip                     | 193   | 87089900 | 18% |
| 93722144 | Eicher Tractor Feedback Link                      | 48    | 87089900 | 18% |
| 93722156 | Eicher Tractor Hydraulic Shaft                    | 8857  | 87089900 | 18% |
| 93722168 | Eicher Tractor Crank                              | 5442  | 84831092 | 18% |
| 93722170 | Eicher Tractor Con Rod                            | 1590  | 87089900 | 18% |
| 93722181 | Eicher Tractor Ram Cylinder                       | 4494  | 87089900 | 18% |
| 93722211 | Eicher Tractor Piston                             | 2408  | 87089900 | 18% |
| 93722223 | Eicher Tractor End Cover Lt.                      | 520   | 87084000 | 18% |
| 93722235 | Eicher Tractor End Cover Rt.                      | 430   | 87084000 | 18% |
| 93722247 | Eicher Tractor Du Bush 70 X 75 X 70               | 1583  | 87089400 | 18% |
| 93722259 | Eicher Tractor Du Bush 65 X 70 X 70               | 1369  | 87089400 | 18% |
| 93722272 | Eicher Tractor Addc Housing                       | 21382 | 87089900 | 18% |
| 93722284 | Eicher Tractor Top Link Bkt                       | 2300  | 87089900 | 18% |
| 93722302 | Eicher Tractor Stopper                            | 650   | 87084000 | 18% |
| 93722314 | Eicher Tractor Shim Flange (0.25)                 | 20    | 73182100 | 18% |
| 93722326 | Eicher Tractor Shim Flange (0.5)                  | 20    | 73182100 | 18% |
| 93722340 | Eicher Tractor Sensing Pin                        | 1242  | 73182100 | 18% |
| 93722351 | Eicher Tractor Gasket For Addc                    | 170   | 68129090 | 18% |
| 93722375 | Eicher Tractor Position Lever Assly.              | 1422  | 87089900 | 18% |
| 93722387 | Eicher Tractor Draft Lever Assly                  | 1422  | 87084000 | 18% |
| 93722399 | Eicher Tractor Coupler                            | 1117  | 87089900 | 18% |
| 93722417 | Eicher Tractor Position Rod                       | 834   | 87089900 | 18% |
| 93722430 | Eicher Tractor Lever Assly Dl                     | 922   | 87084000 | 18% |
| 93722442 | Eicher Tractor Ptfе Washer                        | 23    | 73182100 | 18% |
| 93722454 | Eicher Tractor Shim Hyd Shaft                     | 14    | 73182100 | 18% |
| 93722521 | Eicher Tractor Quick Coupler-Female               | 1776  | 87089900 | 18% |
| 93722558 | Eicher Tractor Cam & Shaft Assly                  | 383   | 87089900 | 18% |
| 93722571 | Eicher Tractor Wynseal Dia 110                    | 761   | 87089900 | 18% |
| 93722583 | Eicher Tractor O Ring 91.44X53.. N70 Nrb Es 01 It | 40    | 40169320 | 18% |
| 93722595 | Eicher Tractor Slydring Dia 110                   | 284   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93722600 | Eicher Tractor Rotoglydring Dia65                  | 328   | 87089900 | 18% |
| 93722624 | Eicher Tractor Rotoglydring Dia70                  | 383   | 87089900 | 18% |
| 93722648 | Eicher Tractor Clamp Upper                         | 39    | 87089900 | 18% |
| 93722650 | Eicher Tractor Clamping Lower                      | 39    | 87089900 | 18% |
| 93722673 | Eicher Tractor Lever Assly Pl                      | 577   | 87084000 | 18% |
| 93722715 | Eicher Tractor Shim Special Bolt                   | 7     | 73182100 | 18% |
| 93722727 | Eicher Tractor Clamp Pressure Pipe                 | 29    | 87089900 | 18% |
| 93722740 | Eicher Tractor Clamp Return Pipe                   | 31    | 87089900 | 18% |
| 93722752 | Eicher Tractor Rod End Dia 8                       | 2560  | 87089400 | 18% |
| 93722806 | Eicher Tractor Support Plate Assly                 | 8066  | 87089900 | 18% |
| 93722831 | Eicher Tractor Aux Pipe A2                         | 608   | 87089900 | 18% |
| 93722843 | Eicher Tractor Aux Pipe B2                         | 619   | 87089900 | 18% |
| 93722855 | Eicher Tractor Aux Pipe A3                         | 346   | 87089900 | 18% |
| 93722867 | Eicher Tractor Aux Pipe B3                         | 346   | 87089900 | 18% |
| 93722879 | Eicher Tractor Aux Valve Lever 1                   | 322   | 87089900 | 18% |
| 93722971 | Eicher Tractor Elbow 7/8 Unf, M18X1.5              | 552   | 87089900 | 18% |
| 93722983 | Eicher Tractor Manifold                            | 1984  | 84099941 | 28% |
| 93722995 | Eicher Tractor Spring Retainer                     | 153   | 73202000 | 18% |
| 93723008 | Eicher Tractor Sp Pipe Union Bolt M14X1.5          | 156   | 73181500 | 18% |
| 93723010 | Eicher Tractor Reducing Adaptor                    | 107   | 87084000 | 18% |
| 93723021 | Eicher Tractor Plug P Port                         | 51    | 87084000 | 18% |
| 93723033 | Eicher Tractor Distributor Assy-85 Hp              | 8466  | 87089900 | 18% |
| 93723045 | Eicher Tractor Distributor Hsg                     | 2615  | 87089900 | 18% |
| 93723057 | Eicher Tractor Lamp Pressure Pipe                  | 36    | 87089900 | 18% |
| 93723184 | Eicher Tractor Rubber Gasket                       | 33    | 40169320 | 18% |
| 93723215 | Eicher Tractor Aux. Valve Sd6/1                    | 18891 | 87089900 | 18% |
| 93723227 | Eicher Tractor Aux Valvesd 6/2                     | 25902 | 87089900 | 18% |
| 93723269 | Eicher Tractor Gasket Gear Pump (5150Ps)           | 23    | 68129090 | 18% |
| 93723318 | Eicher Tractor Pressure Pipe Assy                  | 497   | 87089900 | 18% |
| 93723331 | Eicher Tractor Suction Pipe Assy Front Dia 22, Erw | 509   | 87089900 | 18% |
| 93723343 | Eicher Tractor Suction Pipe Assy Rear Dia 22, Erw  | 848   | 87089900 | 18% |
| 93723355 | Eicher Tractor Clamp Suction Pipe                  | 372   | 87089900 | 18% |
| 93723367 | Eicher Tractor Cylinder Assy-242 Nf                | 2488  | 87089900 | 18% |
| 93723380 | Eicher Tractor Steering Valve                      | 18897 | 87089400 | 18% |
| 93723410 | Eicher Tractor Crank (380)                         | 1920  | 87089900 | 18% |
| 93723422 | Eicher Tractor Tripple Clam Upper                  | 34    | 87089900 | 18% |
| 93723434 | Eicher Tractor Tripple Clam Lower                  | 44    | 87089900 | 18% |
| 93723458 | Eicher Tractor Pressure Pipe (5150 Ps)             | 541   | 87089900 | 18% |
| 93723483 | Eicher Tractor Section Pipe Rear (5150 Ps)         | 215   | 87089900 | 18% |
| 93723574 | Eicher Tractor Clamp Upper                         | 26    | 87089900 | 18% |
| 93723586 | Eicher Tractor Clamp Lower                         | 44    | 87089900 | 18% |
| 93723598 | Eicher Tractor Clamp Upper                         | 106   | 87084000 | 18% |
| 93723604 | Eicher Tractor Clamp Lower Dia-38                  | 284   | 87084000 | 18% |
| 93723641 | Eicher Tractor Suction Elbow (55Hp)                | 813   | 40093100 | 18% |
| 93723665 | Eicher Tractor Steering Hose                       | 944   | 40093100 | 18% |
| 93723744 | Eicher Tractor Shim H - Link                       | 3     | 73182100 | 18% |
| 93723756 | Eicher Tractor Clamp Hydro South                   | 53    | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93723800 | Eicher Tractor Tandem Pump (5150 Ps)                | 13414 | 84138190 | 18% |
| 93723811 | Eicher Tractor Pipe Pump Filter (5150 Ps)           | 1016  | 84219900 | 18% |
| 93723823 | Eicher Tractor Hose Filter - Orbitrol (5150 Ps)     | 625   | 40093100 | 18% |
| 93723835 | Eicher Tractor Pipe Orbitrol - Steering Right (515  | 1154  | 87089900 | 18% |
| 93723847 | Eicher Tractor Pipe Orbitrol - Steering Lt. (5150 P | 1367  | 87089400 | 18% |
| 93723859 | Eicher Tractor Pipe Mtg. Bkt (5150 Ps)              | 187   | 87089900 | 18% |
| 93723860 | Eicher Tractor Steering Hose Right (5150 Ps)        | 827   | 40093100 | 18% |
| 93723872 | Eicher Tractor Steering Hose L/T (5150 Ps)          | 485   | 40093100 | 18% |
| 93723884 | Eicher Tractor Filter Mkt Bkt                       | 840   | 84219900 | 18% |
| 93723896 | Eicher Tractor Suction Pipe Assy Front (5150Ps)     | 338   | 87089900 | 18% |
| 93724050 | Eicher Tractor Sticker Aux Port 1-2                 | 5     | 39199090 | 18% |
| 93724116 | Eicher Tractor Steering Hose Clamp Lower            | 46    | 73269099 | 18% |
| 93724128 | Eicher Tractor Gromet Dia 12                        | 15    | 40169990 | 18% |
| 93724130 | Eicher Tractor Tandem Pump Assly (485 Hyd. Ps)      | 16520 | 84138190 | 18% |
| 93724141 | Eicher Tractor Pressure Pipe (485 Hyd. Ps)          | 669   | 87089900 | 18% |
| 93724153 | Eicher Tractor Suction Pipe Assy Front (485 Hyd. P  | 894   | 87089900 | 18% |
| 93724165 | Eicher Tractor Suction Pipe Rear (485 Hyd. Ps)      | 994   | 87089900 | 18% |
| 93724189 | Eicher Tractor Clamp Suction Pipe                   | 31    | 87089900 | 18% |
| 93724190 | Eicher Tractor Clamp Suction Pipe                   | 110   | 87089900 | 18% |
| 93724268 | Eicher Tractor Pipe Pump Steering (485 Hyd Ps)      | 828   | 87089400 | 18% |
| 93724270 | Eicher Tractor Clamp Upper                          | 32    | 87089900 | 18% |
| 93724281 | Eicher Tractor Clamp Lower                          | 35    | 87089900 | 18% |
| 93724293 | Eicher Tractor Adaptor PI Filter (485 Hyd. Ps)      | 210   | 84219900 | 18% |
| 93724305 | Eicher Tractor Aux Valve Lever 2                    | 360   | 87089900 | 18% |
| 93724384 | Eicher Tractor Presure Conecting Flange (5150 Ps)   | 480   | 87089900 | 18% |
| 93724402 | Eicher Tractor Clamp Lower Press Pipe               | 74    | 87089900 | 18% |
| 93724414 | Eicher Tractor Clamp Upper Press. Pipe              | 28    | 87089900 | 18% |
| 93724529 | Eicher Tractor Steering Pile Right (485 Hyd Ps)     | 1333  | 87089400 | 18% |
| 93724530 | Eicher Tractor Steering Pipe Left (485 Hyd. Ps)     | 1524  | 87089400 | 18% |
| 93724535 | Eicher Tractor Suction Hose Dia - 19                | 92    | 40093100 | 18% |
| 93724670 | Eicher Tractor Distributor Oib (Hyd.)               | 723   | 87089900 | 18% |
| 93724682 | Eicher Tractor Lubrication Pipe Assly Lt            | 377   | 87089900 | 18% |
| 93724694 | Eicher Tractor Lubrication Pipe Assly Rt            | 272   | 87089900 | 18% |
| 93724724 | Eicher Tractor Adapter Distributor (Hyd.)           | 287   | 87089900 | 18% |
| 93724736 | Eicher Tractor Addc Hsg. (Hyd)                      | 18878 | 87089900 | 18% |
| 93724827 | Eicher Tractor Lowering Valve Sleeve (S/F)          | 381   | 87089900 | 18% |
| 93724906 | Eicher Tractor Lowering Spool Assly                 | 230   | 87089900 | 18% |
| 93724920 | Eicher Tractor Pipe Assy For Tt-Hds                 | 432   | 87089900 | 18% |
| 93724967 | Eicher Tractor Spring Cap                           | 37    | 73209090 | 18% |
| 93724979 | Eicher Tractor Spring Lowering Valve                | 2     | 73202000 | 18% |
| 93725157 | Eicher Tractor Strainer Assly.                      | 819   | 84219900 | 18% |
| 93725170 | Eicher Tractor Force Lubrication Pipe               | 398   | 87089900 | 18% |
| 93725248 | Eicher Tractor Pressure Pipe Front (312)            | 558   | 87089900 | 18% |
| 93725250 | Eicher Tractor Pressure Pipe Rear (312)             | 619   | 87089900 | 18% |
| 93725261 | Eicher Tractor Suction Pipe Front                   | 580   | 87089900 | 18% |
| 93725273 | Eicher Tractor Suction Pipe Rear                    | 835   | 87089900 | 18% |
| 93725390 | Eicher Tractor Floating Link                        | 89    | 87083000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93725406 | Eicher Tractor Lock Nut Qrc                  | 28    | 73181500 | 18% |
| 93725443 | Eicher Tractor Spacer Rear Dsa               | 80    | 73182100 | 18% |
| 93725455 | Eicher Tractor Washer Cl Assy                | 78    | 73182100 | 18% |
| 93725480 | Eicher Tractor Elbow 3/4 Unf To M18*1.5      | 475   | 87089900 | 18% |
| 93725509 | Eicher Tractor Tandem Pump Assly             | 17871 | 84138190 | 18% |
| 93725534 | Eicher Tractor Distributor Oib (Hyd.)        | 683   | 87089900 | 18% |
| 93725558 | Eicher Tractor Hex Lock Nut M14X1.5-Lh       | 10    | 73181500 | 18% |
| 93725583 | Eicher Tractor Pipe Steering Cyllynder Left  | 365   | 87089400 | 18% |
| 93725595 | Eicher Tractor Pipe Steering Cyllynder Right | 355   | 87089400 | 18% |
| 93725601 | Eicher Tractor Steering Hose (380 Ps)        | 1000  | 40093100 | 18% |
| 93725637 | Eicher Tractor Suction Pipe Addc             | 432   | 87089900 | 18% |
| 93725649 | Eicher Tractor Pressure Pipe Addc Front      | 349   | 87089900 | 18% |
| 93725662 | Eicher Tractor Adaptor                       | 89    | 87089900 | 18% |
| 93725698 | Eicher Tractor Stcker Aux Valve              | 4     | 87089900 | 18% |
| 93725704 | Eicher Tractor Strip Draft Lever             | 17    | 87089900 | 18% |
| 93725716 | Eicher Tractor Strip Position Lever          | 17    | 87089900 | 18% |
| 93725730 | Eicher Tractor Stcker Aux Port               | 4     | 39199090 | 18% |
| 93725741 | Eicher Tractor Back Plate                    | 366   | 87089900 | 18% |
| 93725754 | Eicher Tractor Cover Plate                   | 163   | 87084000 | 18% |
| 93725765 | Eicher Tractor Check Valve Seat              | 199   | 87089900 | 18% |
| 93725777 | Eicher Tractor Retainer Check Valve          | 935   | 87089900 | 18% |
| 93725790 | Eicher Tractor Mode Selector Valve           | 201   | 87089900 | 18% |
| 93725807 | Eicher Tractor Plug M10                      | 95    | 87084000 | 18% |
| 93725819 | Eicher Tractor Spring Check Value            | 4     | 73209090 | 18% |
| 93725868 | Eicher Tractor Connecting Hose Dia 38        | 254   | 40093100 | 18% |
| 93725881 | Eicher Tractor Inlet Elbow                   | 623   | 40169320 | 18% |
| 93725893 | Eicher Tractor Pump Delivery Connector       | 1785  | 73072200 | 18% |
| 93725947 | Eicher Tractor Guide Spacer                  | 74    | 87089900 | 18% |
| 93726058 | Eicher Tractor Male Stud Coupling 7/8        | 148   | 73181500 | 18% |
| 93726083 | Eicher Tractor Lowering Valve Spool          | 236   | 87089900 | 18% |
| 93726204 | Eicher Tractor Position Lever Assy.          | 195   | 87089900 | 18% |
| 93726216 | Eicher Tractor Draft Lever Assy              | 142   | 87089900 | 18% |
| 93726228 | Eicher Tractor Finger Tip Assy               | 106   | 87089900 | 18% |
| 93726230 | Eicher Tractor Position Lever Assy.          | 207   | 87089900 | 18% |
| 93726253 | Eicher Tractor Draft Input Assy.             | 816   | 87089900 | 18% |
| 93726277 | Eicher Tractor Position Lever Assy.          | 236   | 87089900 | 18% |
| 93726289 | Eicher Tractor Draft Input Assy.             | 687   | 87089900 | 18% |
| 93726307 | Eicher Tractor Position Lever Assy 5150 Ind  | 190   | 87089900 | 18% |
| 93726319 | Eicher Tractor Draft Input Assy              | 757   | 87089900 | 18% |
| 93726332 | Eicher Tractor Finger Tip Assembly           | 78    | 87089900 | 18% |
| 93726344 | Eicher Tractor Position Lever Assy           | 194   | 87089900 | 18% |
| 93726356 | Eicher Tractor Draft Input Assy              | 659   | 87089900 | 18% |
| 93726435 | Eicher Tractor Pressure Pipe                 | 724   | 87089900 | 18% |
| 93726459 | Eicher Tractor Pipe Steering Right           | 1250  | 87089400 | 18% |
| 93726460 | Eicher Tractor Pipe Steering Left            | 502   | 87089400 | 18% |
| 93726472 | Eicher Tractor Bulkhead Union 7/8 Unf        | 164   | 87089900 | 18% |
| 93726484 | Eicher Tractor Clamp Bulkhead                | 152   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93726496 | Eicher Tractor Pipe Clamp Upper              | 34    | 87089900 | 18% |
| 93726502 | Eicher Tractor Pipe Clamp Lower              | 30    | 87089900 | 18% |
| 93726514 | Eicher Tractor Suction Pipe Rear             | 667   | 87089900 | 18% |
| 93726538 | Eicher Tractor Steering Hose                 | 1482  | 40093100 | 18% |
| 93726769 | Eicher Tractor Steering Hose Clamp Upper     | 45    | 73269099 | 18% |
| 93726770 | Eicher Tractor Counter Spring                | 3237  | 73202000 | 18% |
| 93726782 | Eicher Tractor Spacer                        | 254   | 73182100 | 18% |
| 93726794 | Eicher Tractor Bracket Stopper               | 815   | 87089900 | 18% |
| 93726812 | Eicher Tractor Pressure Pipe Front (47Hp-Ac) | 707   | 87089900 | 18% |
| 93726824 | Eicher Tractor Pressure Pipe Rear (47Hp-Ac)  | 746   | 87089900 | 18% |
| 93726915 | Eicher Tractor Steering Unit Vsp 80Cc        | 15307 | 87089400 | 18% |
| 93726927 | Eicher Tractor Steering Unit - Vsp 100Cc     | 18905 | 87089400 | 18% |
| 93727180 | Eicher Tractor Quick Coupler Male            | 480   | 87089900 | 18% |
| 93727208 | Eicher Tractor Connecting Hose Dia 34        | 174   | 40093100 | 18% |
| 93727555 | Eicher Tractor Pluf 7/8 Unf                  | 48    | 87089900 | 18% |
| 93727579 | Eicher Tractor Aux Pipe Big Addc             | 660   | 87089900 | 18% |
| 93727580 | Eicher Tractor Aux Pipe Smaller Addc         | 505   | 87089900 | 18% |
| 93727592 | Eicher Tractor Clamp Upper Aux Pipe          | 40    | 87089900 | 18% |
| 93727609 | Eicher Tractor Clamp Lower Aux Pipe          | 75    | 87089900 | 18% |
| 93727610 | Eicher Tractor Sticker Tbv                   | 6     | 39199090 | 18% |
| 93727622 | Eicher Tractor Shim Clamping (1 Mm)          | 12    | 73182100 | 18% |
| 93727671 | Eicher Tractor Suction Pipe Front            | 689   | 87089900 | 18% |
| 93727725 | Eicher Tractor Suction Pipe Rear             | 412   | 87089900 | 18% |
| 93727737 | Eicher Tractor Pressure Pipe Rear            | 270   | 87089900 | 18% |
| 93727749 | Eicher Tractor Cover Pressure Pipe           | 69    | 87089900 | 18% |
| 93727750 | Eicher Tractor Pressure Pipe Assly Rear      | 520   | 87089900 | 18% |
| 93727919 | Eicher Tractor Tandem Pump                   | 15729 | 84138190 | 18% |
| 93727920 | Eicher Tractor Suction Pipe Front            | 436   | 87089900 | 18% |
| 93727993 | Eicher Tractor Pressure Pipe Rear (5660 Ps)  | 1179  | 87089900 | 18% |
| 93728031 | Eicher Tractor Pipe Pump Steering            | 851   | 87089400 | 18% |
| 93728080 | Eicher Tractor Pressure Pipe Orbitrol        | 613   | 87089900 | 18% |
| 93728109 | Eicher Tractor Bracket Qrc                   | 138   | 87089900 | 18% |
| 93728146 | Eicher Tractor Hydraulic Shaft               | 4617  | 87089900 | 18% |
| 93728250 | Eicher Tractor Clamp Suction Pipe            | 26    | 87089900 | 18% |
| 93728274 | Eicher Tractor Aux Pipe-1                    | 380   | 87089900 | 18% |
| 93728286 | Eicher Tractor Aux Pipe-2                    | 362   | 87089900 | 18% |
| 93728353 | Eicher Tractor Suction Pipe Assy Rear        | 573   | 87089900 | 18% |
| 93728377 | Eicher Tractor Special Bolt                  | 221   | 73181500 | 18% |
| 93728419 | Eicher Tractor Cam & Shaft Assy              | 340   | 87089900 | 18% |
| 93728420 | Eicher Tractor H-Link Assy                   | 90    | 87089900 | 18% |
| 93728640 | Eicher Tractor Arbor Spring                  | 129   | 73202000 | 18% |
| 93728651 | Eicher Tractor Connecting Pin                | 116   | 73182100 | 18% |
| 93728833 | Eicher Tractor Clamp Presure Pipe            | 29    | 87089900 | 18% |
| 93728845 | Eicher Tractor Tandem Pump                   | 12383 | 84138190 | 18% |
| 93728857 | Eicher Tractor Pressure Pipe Front           | 429   | 87089900 | 18% |
| 93728869 | Eicher Tractor Pressure Pipe Rear            | 718   | 87089900 | 18% |
| 93728870 | Eicher Tractor Clamp Bulk Head               | 67    | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93728882 | Eicher Tractor Banjo Bolt M18X1.5                | 104   | 73181500 | 18% |
| 93728894 | Eicher Tractor Aux Valve                         | 12552 | 87089900 | 18% |
| 93728912 | Eicher Tractor Aux Lever                         | 390   | 87089900 | 18% |
| 93728936 | Eicher Tractor Manifold Assly (Aux Valve)        | 4110  | 87089900 | 18% |
| 93728948 | Eicher Tractor Addc Hsg                          | 16729 | 87089900 | 18% |
| 93728985 | Eicher Tractor Spacer (Nylon)                    | 11    | 73182100 | 18% |
| 93728997 | Eicher Tractor Plastic Plug M14X1.5              | 4     | 39021000 | 18% |
| 93729000 | Eicher Tractor Cover                             | 653   | 87084000 | 18% |
| 93729023 | Eicher Tractor Adapter Asy. 7/8" Unf-1/2"Bsp     | 216   | 87089900 | 18% |
| 93729035 | Eicher Tractor Bracket Front Pipe                | 127   | 87089900 | 18% |
| 93729047 | Eicher Tractor Bracket Rear Pipe                 | 80    | 87089900 | 18% |
| 93729072 | Eicher Tractor Spacer Nylon                      | 12    | 73182100 | 18% |
| 93729096 | Eicher Tractor Pressure Hose Rear                | 1213  | 40093100 | 18% |
| 93729175 | Eicher Tractor Pressure Connection Flange        | 394   | 87089900 | 18% |
| 93729187 | Eicher Tractor Aux Pipe Sub Assy (Smaller Addc)  | 742   | 87089900 | 18% |
| 93729205 | Eicher Tractor Aux Pipe Sub Assy (Big Addc)      | 723   | 87089900 | 18% |
| 93729229 | Eicher Tractor Aux Pipe Sub Assy (Hyd)           | 718   | 87089900 | 18% |
| 93729357 | Eicher Tractor Aux Pipe (Hyd)                    | 670   | 87089900 | 18% |
| 93729369 | Eicher Tractor Pressure Pipe (485Hyd. Ps) Export | 1094  | 87089400 | 18% |
| 93729436 | Eicher Tractor Pressure Pipe Ps (551)            | 917   | 87089900 | 18% |
| 93729448 | Eicher Tractor Strainer Hsg (551)                | 1459  | 87089400 | 18% |
| 93729450 | Eicher Tractor Pressure Pipe Ms                  | 1529  | 87089900 | 18% |
| 93729461 | Eicher Tractor Suction Pipe Front                | 490   | 87089900 | 18% |
| 93729473 | Eicher Tractor Suction Pipe Rear                 | 336   | 87089900 | 18% |
| 93729564 | Eicher Tractor Rane Steering Unit-80Cc           | 13816 | 87089400 | 18% |
| 93729588 | Eicher Tractor Steering Pipe Right               | 744   | 87089400 | 18% |
| 93729590 | Eicher Tractor Steering Inlet Pipe               | 422   | 87089400 | 18% |
| 93729606 | Eicher Tractor Steering Return Pipe              | 414   | 87089400 | 18% |
| 93729618 | Eicher Tractor Pressure Pipe Rear Dia -16        | 1117  | 87089900 | 18% |
| 93729620 | Eicher Tractor Suction Pipe Rear Dia-38          | 529   | 87089900 | 18% |
| 93729631 | Eicher Tractor Suction Pipe Front Dia-38         | 707   | 87089900 | 18% |
| 93729643 | Eicher Tractor Pressure Hose                     | 1256  | 40093100 | 18% |
| 93729655 | Eicher Tractor Knob Position Lever (PI)          | 120   | 87084000 | 18% |
| 93729667 | Eicher Tractor Knob Draft Lever (DI)             | 120   | 87084000 | 18% |
| 93729679 | Eicher Tractor Knob Aux Valve (Aux)              | 115   | 87089900 | 18% |
| 93729680 | Eicher Tractor Elbow 7/8 Unf To M27              | 947   | 87089200 | 18% |
| 93729692 | Eicher Tractor Spacer                            | 20    | 73182100 | 18% |
| 93729710 | Eicher Tractor Suction Pipe Rear Assy            | 434   | 87089900 | 18% |
| 93729722 | Eicher Tractor Du Bush 12X14X20                  | 44    | 87089900 | 18% |
| 93729734 | Eicher Tractor Hardened Washer M16               | 75    | 73182100 | 18% |
| 93729746 | Eicher Tractor Shield Mtg Flange                 | 740   | 87089900 | 18% |
| 93729758 | Eicher Tractor Inlet Block Assy                  | 7010  | 39011010 | 18% |
| 93729771 | Eicher Tractor Plug Qrc Male                     | 930   | 87084000 | 18% |
| 93729801 | Eicher Tractor Breather Pipe Assy                | 234   | 87084000 | 18% |
| 93729813 | Eicher Tractor Qrc Bracket                       | 988   | 87084000 | 18% |
| 93729825 | Eicher Tractor Pressure Connection Flange 85 Hp  | 1131  | 87089900 | 18% |
| 93729837 | Eicher Tractor Return Pipe Ps                    | 388   | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93729849 | Eicher Tractor Suction Pipe Ps            | 238   | 87089900 | 18% |
| 93729874 | Eicher Tractor Sticker Aux Valve Float    | 6     | 39199090 | 18% |
| 93729898 | Eicher Tractor Aux. Pipe Assy (Hyd)       | 706   | 87089900 | 18% |
| 93729941 | Eicher Tractor Pivot Screw                | 31    | 73181500 | 18% |
| 93729953 | Eicher Tractor Aux Lever Lock             | 35    | 87089900 | 18% |
| 93729990 | Eicher Tractor Cap Qrc Male               | 156   | 87089900 | 18% |
| 93730116 | Eicher Tractor Clamp Steering             | 36    | 87089900 | 18% |
| 93730128 | Eicher Tractor Bracket                    | 468   | 84099941 | 28% |
| 93730347 | Eicher Tractor Hose Service Line          | 816   | 40093100 | 18% |
| 93730578 | Eicher Tractor Stud Aux Valve Assy        | 732   | 87089900 | 18% |
| 93730761 | Eicher Tractor Top Link Bkt. 50 Hp Hyd.   | 1379  | 87089900 | 18% |
| 93730773 | Eicher Tractor Casing Spring 50 Hp Hyd.   | 1347  | 73202000 | 18% |
| 93730785 | Eicher Tractor Push Cup                   | 734   | 87089900 | 18% |
| 93730797 | Eicher Tractor Draft Spring               | 258   | 73202000 | 18% |
| 93730803 | Eicher Tractor Holder Spring              | 763   | 73202000 | 18% |
| 93730815 | Eicher Tractor Special Bolt               | 372   | 73181500 | 18% |
| 93730827 | Eicher Tractor Sensing Pin                | 199   | 87089900 | 18% |
| 93730839 | Eicher Tractor Spacer                     | 64    | 73182100 | 18% |
| 93730840 | Eicher Tractor Bellow                     | 179   | 87084000 | 18% |
| 93730852 | Eicher Tractor Gasket                     | 33    | 68129090 | 18% |
| 93730876 | Eicher Tractor Powerlift Hsg 50 Hp Hyd    | 27198 | 87089900 | 18% |
| 93730888 | Eicher Tractor Hydraulic Shaft 50 Hp Hyd. | 5559  | 87089900 | 18% |
| 93730890 | Eicher Tractor Distributor Hsg.(S/F)      | 3084  | 87089900 | 18% |
| 93730906 | Eicher Tractor Cyl. Assy Dia.100          | 3347  | 87089900 | 18% |
| 93730931 | Eicher Tractor Crank                      | 3495  | 87089900 | 18% |
| 93730943 | Eicher Tractor Connecting Rod 50 Hp Hyd.  | 1078  | 87089900 | 18% |
| 93730955 | Eicher Tractor Shim Hyd Shaft             | 9     | 87089900 | 18% |
| 93730980 | Eicher Tractor Clamp Upper-Aux Pipe       | 81    | 87089900 | 18% |
| 93730992 | Eicher Tractor Du Bush 14X16X30           | 60    | 87089900 | 18% |
| 93731005 | Eicher Tractor Floating Link              | 73    | 87083000 | 18% |
| 93731029 | Eicher Tractor Lever Autotrip             | 165   | 87089900 | 18% |
| 93731030 | Eicher Tractor Shield Mtg Flange          | 752   | 87089900 | 18% |
| 93731078 | Eicher Tractor Ptfе Washer                | 22    | 73182100 | 18% |
| 93731080 | Eicher Tractor Spring Control Lever       | 7     | 73202000 | 18% |
| 93731123 | Eicher Tractor Shield Assembly            | 644   | 87089900 | 18% |
| 93731135 | Eicher Tractor Draft Input Assy           | 715   | 87089900 | 18% |
| 93731147 | Eicher Tractor Stopper                    | 13    | 87084000 | 18% |
| 93731159 | Eicher Tractor Stopper Bolt               | 51    | 73181500 | 18% |
| 93731160 | Eicher Tractor Special Bolt               | 55    | 73181500 | 18% |
| 93731184 | Eicher Tractor Manifold (Ddb)             | 341   | 87089900 | 18% |
| 93731212 | Eicher Tractor Support Pin                | 181   | 73182100 | 18% |
| 93731248 | Eicher Tractor Extension Lever Pl         | 221   | 87089900 | 18% |
| 93731303 | Eicher Tractor Coupler Assy               | 100   | 87089900 | 18% |
| 93731327 | Eicher Tractor Spacer Plate               | 26    | 73182100 | 18% |
| 93731339 | Eicher Tractor Metal Washer               | 11    | 73182100 | 18% |
| 93731352 | Eicher Tractor Position Rod               | 219   | 87089900 | 18% |
| 93731364 | Eicher Tractor Power Lift Assy            | 53002 | 87089900 | 18% |





|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93731418 | Eicher Tractor Distributor Assy - New Addc        | 6069  | 87089900 | 18% |
| 93731455 | Eicher Tractor Aux Pipe Sub Assy                  | 774   | 87089900 | 18% |
| 93731479 | Eicher Tractor Pressure Hose Rear                 | 709   | 40093100 | 18% |
| 93731492 | Eicher Tractor Manifold (Lub.)                    | 573   | 87089900 | 18% |
| 93731509 | Eicher Tractor Cover Manifold                     | 53    | 87084000 | 18% |
| 93731510 | Eicher Tractor Lubrication Pipe Assy Right        | 639   | 87089900 | 18% |
| 93731534 | Eicher Tractor Lubrication Pipe Assy Lt + Synchro | 1092  | 87089900 | 18% |
| 93731625 | Eicher Tractor Gasket Gear Pump                   | 22    | 68129090 | 18% |
| 93731637 | Eicher Tractor Shield Assy                        | 124   | 87089900 | 18% |
| 93731649 | Eicher Tractor Position Input Assy.               | 128   | 87089900 | 18% |
| 93731650 | Eicher Tractor Position Lever Assy                | 262   | 87089900 | 18% |
| 93731662 | Eicher Tractor Draft Input Assy.                  | 390   | 87089900 | 18% |
| 93731698 | Eicher Tractor Draft Lever Assy                   | 189   | 87089900 | 18% |
| 93731704 | Eicher Tractor Position Rod                       | 134   | 87089900 | 18% |
| 93731753 | Eicher Tractor Stopper Assy                       | 57    | 87089900 | 18% |
| 93731765 | Eicher Tractor Power Lift Hsg (Addc) - 18Hp       | 11452 | 87089900 | 18% |
| 93731777 | Eicher Tractor Hydraulic Shaft                    | 1541  | 87089900 | 18% |
| 93731789 | Eicher Tractor Cyl. Assy. Dia. 63                 | 1297  | 87089900 | 18% |
| 93731790 | Eicher Tractor Crank                              | 992   | 87089900 | 18% |
| 93731807 | Eicher Tractor Piston Dia 63                      | 533   | 87089900 | 18% |
| 93731844 | Eicher Tractor Con Rod                            | 404   | 87089900 | 18% |
| 93731870 | Eicher Tractor Spacer Seal Left                   | 52    | 73182100 | 18% |
| 93731881 | Eicher Tractor Spacer Seal Right                  | 52    | 73182100 | 18% |
| 93731893 | Eicher Tractor Gasket For Addc                    | 73    | 68129922 | 18% |
| 93731900 | Eicher Tractor Transmission Lever                 | 268   | 87085000 | 18% |
| 93731923 | Eicher Tractor Pin Trans Lever                    | 35    | 87089900 | 18% |
| 93731935 | Eicher Tractor Feedback Link                      | 29    | 87089900 | 18% |
| 93731947 | Eicher Tractor Position Cam Assy                  | 472   | 87089900 | 18% |
| 93731972 | Eicher Tractor Special Bolt                       | 164   | 87089900 | 18% |
| 93731984 | Eicher Tractor Cam & Shaft Assy.                  | 292   | 87089900 | 18% |
| 93732009 | Eicher Tractor Special Screw                      | 149   | 87089900 | 18% |
| 93732010 | Eicher Tractor Pin Crank                          | 72    | 87089900 | 18% |
| 93732022 | Eicher Tractor Lever Autotrip                     | 150   | 87089900 | 18% |
| 93732034 | Eicher Tractor Top Link Bkt.                      | 1181  | 87089900 | 18% |
| 93732046 | Eicher Tractor Flange                             | 99    | 87089900 | 18% |
| 93732058 | Eicher Tractor Hinge Pin                          | 118   | 87089900 | 18% |
| 93732060 | Eicher Tractor Extension Rod                      | 133   | 87089900 | 18% |
| 93732071 | Eicher Tractor Sensing Lever                      | 78    | 87089900 | 18% |
| 93732083 | Eicher Tractor Sensing Rod                        | 104   | 87089900 | 18% |
| 93732095 | Eicher Tractor Strainer Assy                      | 448   | 84219900 | 18% |
| 93732113 | Eicher Tractor Gasket Strainer Cover              | 7     | 68129090 | 18% |
| 93732149 | Eicher Tractor Hydraulic Gear Pump                | 5330  | 84138190 | 18% |
| 93732150 | Eicher Tractor Pressure Pipe Assy Front           | 896   | 87089900 | 18% |
| 93732162 | Eicher Tractor Pressure Pipe Assy Rear            | 642   | 87089900 | 18% |
| 93732174 | Eicher Tractor Suction Pipe Assy                  | 800   | 87089900 | 18% |
| 93732198 | Eicher Tractor Clamp Lower                        | 32    | 87089900 | 18% |
| 93732204 | Eicher Tractor Clamp Upper Suction Pipe           | 10    | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93732216 | Eicher Tractor Valve Lifter Assy               | 207   | 87089900 | 18% |
| 93732241 | Eicher Tractor Aux Pipe Assy                   | 456   | 87081010 | 18% |
| 93732265 | Eicher Tractor Spacer Hyd Shaft                | 78    | 87089900 | 18% |
| 93732318 | Eicher Tractor Sector Assy                     | 590   | 87089900 | 18% |
| 93732331 | Eicher Tractor Sticker Sector                  | 24    | 39199090 | 18% |
| 93732423 | Eicher Tractor Clamp Lower Aux Pipe            | 23    | 87089900 | 18% |
| 93732435 | Eicher Tractor Shim Hyd Shaft                  | 8     | 87089900 | 18% |
| 93732472 | Eicher Tractor Grommet Suction Pipe            | 22    | 40169990 | 18% |
| 93732481 | Eicher Tractor Grommet                         | 19    | 40169990 | 18% |
| 93732493 | Eicher Tractor Male Connector 3/4" Unf,M14X1.5 | 127   | 87089900 | 18% |
| 93732514 | Eicher Tractor Distributor Assy                | 6200  | 87089900 | 18% |
| 93732540 | Eicher Tractor Clamp Upper Aux Pipe            | 12    | 87089900 | 18% |
| 93732599 | Eicher Tractor Special Screw                   | 135   | 73181500 | 18% |
| 93732629 | Eicher Tractor Piston Seal Assy Dia 63         | 323   | 87089900 | 18% |
| 93732630 | Eicher Tractor Wear Ring Dia 63                | 95    | 87089900 | 18% |
| 93732642 | Eicher Tractor Gasket (Ddb Manifold)           | 7     | 84841090 | 18% |
| 93732654 | Eicher Tractor Aux Pipe- 1                     | 607   | 87089900 | 18% |
| 93732668 | Eicher Tractor Aux Pipe - 2                    | 557   | 87089900 | 18% |
| 93732670 | Eicher Tractor Clamp Qrc                       | 165   | 87089900 | 18% |
| 93732681 | Eicher Tractor Aux Lever - 50Hp                | 201   | 87089900 | 18% |
| 93732691 | Eicher Tractor Manifold Assy Aux Valve         | 9355  | 87089900 | 18% |
| 93732733 | Eicher Tractor Pressure Pipe Rear              | 522   | 87089900 | 18% |
| 93732745 | Eicher Tractor Quick Coupler- Female           | 1141  | 87089900 | 18% |
| 93732800 | Eicher Tractor Filter Manifold Wdb             | 1234  | 87089900 | 18% |
| 93732812 | Eicher Tractor Filter Manifold Ddb             | 1161  | 87089900 | 18% |
| 93732824 | Eicher Tractor Gasket Filter Manifold          | 13    | 68129922 | 18% |
| 93732873 | Eicher Tractor Cyl. Assy Dia 90 (50Hp Hyd)     | 3143  | 87089900 | 18% |
| 93732903 | Eicher Tractor Lever Autotrip                  | 197   | 87089900 | 18% |
| 93732927 | Eicher Tractor Plug M14X1.5 Din 906            | 43    | 73079990 | 18% |
| 93732952 | Eicher Tractor Pipe Steering                   | 2260  | 87089400 | 18% |
| 93732964 | Eicher Tractor Pipe Steering Left              | 1547  | 87089400 | 18% |
| 93732976 | Eicher Tractor Pipe Pump                       | 1232  | 87089900 | 18% |
| 93732990 | Eicher Tractor Bush 12X14X25                   | 35    | 87089900 | 18% |
| 93733014 | Eicher Tractor Lever Assy                      | 565   | 87089900 | 18% |
| 93733105 | Eicher Tractor Feedback Rod                    | 291   | 87089900 | 18% |
| 93733117 | Eicher Tractor Sensing Lever                   | 131   | 87089900 | 18% |
| 93733166 | Eicher Tractor Knob Position Lever             | 119   | 87089900 | 18% |
| 93733178 | Eicher Tractor Knob Draft Lever                | 132   | 87089900 | 18% |
| 93733208 | Eicher Tractor Power Lift Assy (Hds)           | 54801 | 87089900 | 18% |
| 93733300 | Eicher Tractor Sealing Cup                     | 15    | 87089900 | 18% |
| 93733312 | Eicher Tractor Cover Pump Mounting             | 593   | 87084000 | 18% |
| 93733324 | Eicher Tractor Guard Plate                     | 190   | 87089900 | 18% |
| 93733336 | Eicher Tractor Position Input Assy             | 279   | 87089900 | 18% |
| 93733373 | Eicher Tractor Draft Input Sub Assy            | 631   | 87089900 | 18% |
| 93733385 | Eicher Tractor Lever Sub Assy                  | 621   | 87089900 | 18% |
| 93733488 | Eicher Tractor Suction Pipe Front              | 431   | 87089900 | 18% |
| 93733506 | Eicher Tractor Suction Pipe Rear 551 Ps        | 636   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93733567 | Eicher Tractor Clamp Lower                         | 27    | 87089900 | 18% |
| 93733579 | Eicher Tractor Hose Pr. Line Filter                | 1139  | 40093100 | 18% |
| 93733609 | Eicher Tractor Hydraulic Shaft                     | 5621  | 87089900 | 18% |
| 93733634 | Eicher Tractor Du Bush 40X44X25                    | 119   | 87089900 | 18% |
| 93733646 | Eicher Tractor Du Bush 35X39X25                    | 110   | 87089900 | 18% |
| 93733660 | Eicher Tractor Distributor Hsg.(S/F)               | 2543  | 87089900 | 18% |
| 93733671 | Eicher Tractor Special Bolt                        | 76    | 73181500 | 18% |
| 93733695 | Eicher Tractor Top Link Bkt                        | 2031  | 87089900 | 18% |
| 93733725 | Eicher Tractor Holder Spring                       | 204   | 73202000 | 18% |
| 93733750 | Eicher Tractor Hyd.Pump 548                        | 5966  | 84138190 | 18% |
| 93733762 | Eicher Tractor Hyd Pump 5660/551                   | 6381  | 84138190 | 18% |
| 93733841 | Eicher Tractor Pressure Pipe Assy Rear             | 564   | 87089900 | 18% |
| 93733853 | Eicher Tractor Auxiliary Valve Assy                | 17632 | 87089900 | 18% |
| 93733865 | Eicher Tractor Plug M18X1.5                        | 70    | 87084000 | 18% |
| 93733890 | Eicher Tractor Pressure Pipe Rear (333/371/380/480 | 336   | 87089900 | 18% |
| 93733907 | Eicher Tractor Pressure Pipe Front (333/371/380/48 | 720   | 87089900 | 18% |
| 93733919 | Eicher Tractor Pressure Pipe Rear (380/480 Exp)    | 450   | 87089900 | 18% |
| 93733920 | Eicher Tractor Pressure Pipe Front (386/485 Hyd)   | 664   | 87089900 | 18% |
| 93733932 | Eicher Tractor Pressure Pipe Rear (368/485 Hyd)    | 782   | 87089900 | 18% |
| 93733944 | Eicher Tractor Pressure Pipe Rear (485 Hyd Exp)    | 709   | 87089900 | 18% |
| 93733968 | Eicher Tractor Distributor                         | 1079  | 87089900 | 18% |
| 93733970 | Eicher Tractor Lubrication Pipe Left               | 668   | 87089900 | 18% |
| 93733981 | Eicher Tractor Lubrication Pipe Left               | 356   | 87089900 | 18% |
| 93733993 | Eicher Tractor Pressure Pipe Front 380/480 Hds     | 1151  | 87089900 | 18% |
| 93734006 | Eicher Tractor Pressure Pipe Rear 380/480 Hds      | 611   | 87089900 | 18% |
| 93734110 | Eicher Tractor Addc Top Cover                      | 3425  | 87089900 | 18% |
| 93734122 | Eicher Tractor Gasket For Cover                    | 68    | 68129090 | 18% |
| 93734171 | Eicher Tractor Sensing Pin 50 Hp                   | 410   | 87089900 | 18% |
| 93734183 | Eicher Tractor Breather Pipe Assy                  | 233   | 87084000 | 18% |
| 93734249 | Eicher Tractor Suction Pipe Front                  | 504   | 87089900 | 18% |
| 93734250 | Eicher Tractor Suction Pipe Rear                   | 1035  | 87089900 | 18% |
| 93734262 | Eicher Tractor Steering Inlet Pipe                 | 1183  | 87089900 | 18% |
| 93734274 | Eicher Tractor Pressure Pipe Mid                   | 521   | 87089900 | 18% |
| 93734286 | Eicher Tractor Pressure Pipe Front                 | 335   | 87089900 | 18% |
| 93734328 | Eicher Tractor Pipe Steering Left                  | 1754  | 87089400 | 18% |
| 93734330 | Eicher Tractor Pipe Pump Steering                  | 645   | 87089400 | 18% |
| 93734341 | Eicher Tractor Pipe Steering Right                 | 2426  | 87089400 | 18% |
| 93734353 | Eicher Tractor Tandem Pump                         | 16753 | 84138190 | 18% |
| 93734365 | Eicher Tractor Filter Mtg. Bracket                 | 1213  | 87089900 | 18% |
| 93734420 | Eicher Tractor Reducing Adaptor M27 To 14X1.5      | 127   | 87084000 | 18% |
| 93734511 | Eicher Tractor Suction Pipe Assyfront              | 431   | 87089900 | 18% |
| 93734523 | Eicher Tractor Suction Pipe Assyrear               | 387   | 87089900 | 18% |
| 93734614 | Eicher Tractor Cup Spring                          | 331   | 73202000 | 18% |
| 93734626 | Eicher Tractor Top Link Bkt.                       | 2344  | 87089900 | 18% |
| 93734638 | Eicher Tractor Extension Rod                       | 238   | 87089900 | 18% |
| 93734640 | Eicher Tractor Feedback Rod                        | 148   | 87089900 | 18% |
| 93734651 | Eicher Tractor Guide Flange                        | 1179  | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93734663 | Eicher Tractor Bush                                | 129   | 87085000 | 18% |
| 93734705 | Eicher Tractor Suction Pipe Assyfront              | 569   | 87089900 | 18% |
| 93734717 | Eicher Tractor Suction Pipe Assyrear               | 567   | 87089900 | 18% |
| 93734729 | Eicher Tractor Main Spool                          | 256   | 87089900 | 18% |
| 93734730 | Eicher Tractor Spool Sleeve Assy.                  | 1138  | 87089900 | 18% |
| 93734754 | Eicher Tractor Pressure Pipe Assy Front            | 842   | 87089900 | 18% |
| 93734766 | Eicher Tractor Pressure Pipe Ps                    | 786   | 87089900 | 18% |
| 93734778 | Eicher Tractor Suction Pipe Rear Assy              | 1548  | 87089900 | 18% |
| 93734780 | Eicher Tractor Steering Hose                       | 1106  | 40093100 | 18% |
| 93734821 | Eicher Tractor Transmission Lever                  | 357   | 87085000 | 18% |
| 93734845 | Eicher Tractor Sticker Ps Oil-Caution              | 22    | 39199090 | 18% |
| 93734857 | Eicher Tractor Pressure Connecting Flange          | 519   | 87089900 | 18% |
| 93734870 | Eicher Tractor Power Lift Assembly                 | 72380 | 87089900 | 18% |
| 93734900 | Eicher Tractor Suction Pipe 241 Rear               | 416   | 87089900 | 18% |
| 93734912 | Eicher Tractor Pressure Pipe Assy                  | 1670  | 87089900 | 18% |
| 93734936 | Eicher Tractor Suction Pipe Rear                   | 581   | 87089900 | 18% |
| 93735011 | Eicher Tractor Return Pipe Assy                    | 1524  | 87089400 | 18% |
| 93735023 | Eicher Tractor Pressure Pipe 557 4Wd               | 1041  | 87089400 | 18% |
| 93735035 | Eicher Tractor Pipe Steering Left-557 4Wd          | 662   | 87089400 | 18% |
| 93735047 | Eicher Tractor Pipe Steering Right - 557 4Wd       | 1050  | 87089400 | 18% |
| 93735059 | Eicher Tractor Steering Hose - 557 4Wd             | 1024  | 40093100 | 18% |
| 93735060 | Eicher Tractor Filter Mtg Bkt                      | 1975  | 87089900 | 18% |
| 93735096 | Eicher Tractor Reducing Adapter                    | 146   | 87089900 | 18% |
| 93735102 | Eicher Tractor Aux. Valve                          | 7017  | 87089900 | 18% |
| 93735114 | Eicher Tractor Quick Coupler Female 1/2" With 3/4" | 1059  | 87089900 | 18% |
| 93735140 | Eicher Tractor 50 Hp New Sensing Kit               | 6219  | 87089900 | 18% |
| 93735205 | Eicher Tractor Steering Pipe Left (485 Hyd. Ps)    | 1638  | 87089400 | 18% |
| 93735217 | Eicher Tractor Steering Pipe Right (485 Hyd Ps)    | 1581  | 87089400 | 18% |
| 93735254 | Eicher Tractor Pipe Steering Cylinder Left         | 535   | 87089400 | 18% |
| 93735266 | Eicher Tractor Pipe Steering Cylinder Right        | 525   | 87089400 | 18% |
| 93735278 | Eicher Tractor Pipe Steering Right 5660 Ps         | 1227  | 87089400 | 18% |
| 93735280 | Eicher Tractor Pipe Steering Left 5660 Ps          | 1217  | 40093100 | 18% |
| 93735308 | Eicher Tractor Pipe Steering Left 557              | 768   | 87089400 | 18% |
| 93735310 | Eicher Tractor Pipe Pump Steering 557              | 1080  | 87089400 | 18% |
| 93735321 | Eicher Tractor Pipe Steering Right 557             | 1558  | 87089400 | 18% |
| 93735333 | Eicher Tractor Hose Pr Line Filter                 | 931   | 40093100 | 18% |
| 93735345 | Eicher Tractor Steering Inlet Pipe                 | 1183  | 87089900 | 18% |
| 93735357 | Eicher Tractor Filter Mtg. Bracket                 | 1620  | 87089900 | 18% |
| 93735369 | Eicher Tractor Suction Pipe Rear 551 Ps            | 1140  | 87089900 | 18% |
| 93735382 | Eicher Tractor Suction Pie Rear 551 Ms             | 1360  | 87089900 | 18% |
| 93735394 | Eicher Tractor Suction Pipe Rear 548/485 Ms        | 1024  | 87089900 | 18% |
| 93735400 | Eicher Tractor Suction Pipe Rear 548 Ps            | 1040  | 87089900 | 18% |
| 93735412 | Eicher Tractor Suction Pipe Rear 380 Ms            | 1323  | 87089900 | 18% |
| 93735576 | Eicher Tractor Tandem Pump Assy 241/242            | 15401 | 84138190 | 18% |
| 93735667 | Eicher Tractor Banjo Bolt M16X1.5                  | 91    | 73181500 | 18% |
| 93735709 | Eicher Tractor Suction Adaptor                     | 397   | 87089900 | 18% |
| 93735710 | Eicher Tractor Suction Pipe Rear Ps                | 1171  | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93735758 | Eicher Tractor Banjo Bolt M14X1.5                  | 79   | 73181500 | 18% |
| 93735771 | Eicher Tractor Adapter Distributor (Hyd)           | 315  | 87089900 | 18% |
| 93735783 | Eicher Tractor Pressure Pipe Front                 | 1604 | 87089900 | 18% |
| 93735953 | Eicher Tractor Return Pipe (Pump)                  | 476  | 87089400 | 18% |
| 93736046 | Eicher Tractor Pipe Steering Right                 | 2526 | 87089400 | 18% |
| 93736118 | Eicher Tractor Streering Return Pipe               | 1099 | 87089400 | 18% |
| 93736192 | Eicher Tractor Steering Inlet Pipe                 | 1764 | 87089900 | 18% |
| 93736209 | Eicher Tractor Suction Pipe Front                  | 725  | 87089900 | 18% |
| 93736362 | Eicher Tractor Stud B M8X25 P8.8                   | 20   | 73182100 | 18% |
| 93736441 | Eicher Tractor Suction Pipe Front                  | 428  | 87089900 | 18% |
| 93736620 | Eicher Tractor Auxiliary Pipe                      | 815  | 87089900 | 18% |
| 93736655 | Eicher Tractor Distributor Assy                    | 7754 | 87089900 | 18% |
| 93736771 | Eicher Tractor Steering Return Pipe                | 1489 | 87089400 | 18% |
| 93736805 | Eicher Tractor Fcv Assy -242                       | 3492 | 84138190 | 18% |
| 93736817 | Eicher Tractor Steering Return Pipe Assy 242 Hmps  | 1422 | 87089400 | 18% |
| 93737160 | Eicher Tractor Clamp                               | 350  | 84099941 | 28% |
| 93737482 | Eicher Tractor Aux Pipe 1 Assy.                    | 510  | 87089900 | 18% |
| 93737494 | Eicher Tractor Aux Pipe 2 Assy.                    | 700  | 87089900 | 18% |
| 93737500 | Eicher Tractor Carryover Pipe Assy.                | 608  | 40092200 | 18% |
| 93737512 | Eicher Tractor Return Pipe Assy.                   | 1374 | 87089900 | 18% |
| 93737524 | Eicher Tractor Inlet Pipe Assy                     | 1063 | 87089900 | 18% |
| 93737536 | Eicher Tractor Pressure Pipe                       | 720  | 87089900 | 18% |
| 93737548 | Eicher Tractor Hinge Pin & Qrc Bkt. Assy.          | 872  | 73181500 | 18% |
| 93737550 | Eicher Tractor Aux. Valve Mtg. Bracket             | 874  | 87089900 | 18% |
| 93737573 | Eicher Tractor Suction Cover                       | 144  | 87084000 | 18% |
| 93737585 | Eicher Tractor Pipe Steering Left-551 4Wd          | 743  | 87089400 | 18% |
| 93737597 | Eicher Tractor Pipe Steering Right-551 4Wd         | 1237 | 87089400 | 18% |
| 93737627 | Eicher Tractor Aux Lever                           | 244  | 87089900 | 18% |
| 93737664 | Eicher Tractor Gasket-Suction Cover                | 22   | 87084000 | 18% |
| 93737792 | Eicher Tractor Return Pipe Assy.                   | 1799 | 87089400 | 18% |
| 93737834 | Eicher Tractor Clamp Upper                         | 17   | 87089900 | 18% |
| 93737858 | Eicher Tractor Pressure Pipe Mid                   | 509  | 87089900 | 18% |
| 93738061 | Eicher Tractor Lubrication Pipe Left               | 370  | 87089900 | 18% |
| 93738073 | Eicher Tractor Suction Pipe Rear 548 Ps            | 1583 | 87089900 | 18% |
| 93738085 | Eicher Tractor Suction Pipe Rear 548/485 Ms        | 1387 | 87089900 | 18% |
| 93738097 | Eicher Tractor Pressure Pipe Rear Aux              | 1111 | 87089400 | 18% |
| 93738188 | Eicher Tractor Hose Guard                          | 1212 | 40093100 | 18% |
| 93738190 | Eicher Tractor Filter Mtg Bkt 480 - 4Wd            | 2546 | 87085000 | 18% |
| 93738206 | Eicher Tractor Pipe Steering Left - 480 4Wd        | 689  | 87089900 | 18% |
| 93738218 | Eicher Tractor Pipe Steering Right - 480 4Wd       | 664  | 87089900 | 18% |
| 93738220 | Eicher Tractor Pipe Cylinder End Left - 480 4Wd    | 978  | 87089900 | 18% |
| 93738231 | Eicher Tractor Pipe CyLinder End Right - 480 4Wd   | 1058 | 87089900 | 18% |
| 93738279 | Eicher Tractor Pressure Pipe Assy - 480 4Wd        | 968  | 87089900 | 18% |
| 93738826 | Eicher Tractor Suction Pie Rear 5660 Ms            | 1455 | 87089900 | 18% |
| 93738905 | Eicher Tractor Lubrication Pipe Left (Wdb+Synchro) | 840  | 87089900 | 18% |
| 93739089 | Eicher Tractor Lubrication Pipe Wdb                | 516  | 87089900 | 18% |
| 93739120 | Eicher Tractor Filter Mtg Bkt                      | 1740 | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93739144 | Eicher Tractor Pressure Pipe Front 776/884 4Wd     | 1171  | 87089900 | 18% |
| 93739442 | Eicher Tractor Steering Return Pipe 551 4Wd        | 1721  | 87089400 | 18% |
| 93739454 | Eicher Tractor Pressure Pipe Assy 551 4Wd          | 858   | 87089900 | 18% |
| 93739466 | Eicher Tractor Pipe Steering Cylinder-551 4Wd      | 928   | 87089400 | 18% |
| 93739480 | Eicher Tractor Steering Clamp Upper 551 4Wd        | 65    | 87089400 | 18% |
| 93739491 | Eicher Tractor Floating Link Assy                  | 95    | 87083000 | 18% |
| 93739510 | Eicher Tractor Pipe Pressure Line 551 4Wd          | 1139  | 87089900 | 18% |
| 93739521 | Eicher Tractor Pipe Clamp Upper                    | 40    | 87089900 | 18% |
| 93739533 | Eicher Tractor Pipe Clamp Lower                    | 49    | 87089900 | 18% |
| 93739612 | Eicher Tractor Pipe Steering Cylinder End Right 48 | 1941  | 87089400 | 18% |
| 93740031 | Eicher Tractor Distributor Assy                    | 7571  | 87089900 | 18% |
| 93750012 | Eicher Tractor Hydraulic Arm Assy                  | 1657  | 87089900 | 18% |
| 93750024 | Eicher Tractor Assy Push Rod                       | 161   | 87089900 | 18% |
| 93750036 | Eicher Tractor Arm Assy                            | 1711  | 87089900 | 18% |
| 93750048 | Eicher Tractor U- Connect                          | 55    | 87089900 | 18% |
| 93750050 | Eicher Tractor Tube, Breather Assy                 | 185   | 87089900 | 18% |
| 93750061 | Eicher Tractor Assy.Pump Actuator                  | 695   | 87089900 | 18% |
| 93750073 | Eicher Tractor Assy.Dc Actuator                    | 1091  | 87089900 | 18% |
| 93750085 | Eicher Tractor Holder Lever Assy                   | 1525  | 87089900 | 18% |
| 93750097 | Eicher Tractor Assy. Pc Rod                        | 515   | 87089900 | 18% |
| 93750103 | Eicher Tractor Bush                                | 186   | 87089900 | 18% |
| 93750115 | Eicher Tractor Cover                               | 1512  | 87089900 | 18% |
| 93750127 | Eicher Tractor Shaft Hydraulic Arm                 | 1653  | 87089900 | 18% |
| 93750139 | Eicher Tractor Rod, Hydraulic                      | 551   | 87089900 | 18% |
| 93750140 | Eicher Tractor Piston                              | 621   | 87085000 | 18% |
| 93750152 | Eicher Tractor Cylinder                            | 1810  | 87089900 | 18% |
| 93750164 | Eicher Tractor Screw, Holder                       | 66    | 73182990 | 18% |
| 93750176 | Eicher Tractor Roller                              | 43    | 87089900 | 18% |
| 93750188 | Eicher Tractor Seat, Spring                        | 198   | 73182990 | 18% |
| 93750190 | Eicher Tractor Lever                               | 123   | 87089900 | 18% |
| 93750206 | Eicher Tractor Lever                               | 1174  | 87089900 | 18% |
| 93750218 | Eicher Tractor Link - 3                            | 44    | 87089900 | 18% |
| 93750220 | Eicher Tractor Roller-2                            | 54    | 73182990 | 18% |
| 93750231 | Eicher Tractor Spring                              | 9     | 73209090 | 18% |
| 93750243 | Eicher Tractor Pin                                 | 11    | 73182990 | 18% |
| 93750255 | Eicher Tractor Support Pin                         | 199   | 87089900 | 18% |
| 93750267 | Eicher Tractor Pin                                 | 199   | 73182990 | 18% |
| 93750279 | Eicher Tractor Grommet                             | 83    | 87089400 | 18% |
| 93750280 | Eicher Tractor Grip                                | 60    | 87089900 | 18% |
| 93750292 | Eicher Tractor Bush                                | 199   | 87089900 | 18% |
| 93750309 | Eicher Tractor Shaft                               | 553   | 87089900 | 18% |
| 93750310 | Eicher Tractor Pin - Dc Link                       | 163   | 73170099 | 18% |
| 93750322 | Eicher Tractor Hydraulic Lift Cover                | 10102 | 87089900 | 18% |
| 93750334 | Eicher Tractor Back Up Ring                        | 92    | 40169320 | 18% |
| 93750346 | Eicher Tractor Assy Pin And Ring - (C/A)           | 39    | 87089900 | 18% |
| 93750358 | Eicher Tractor Pin Top Link                        | 217   | 73182990 | 18% |
| 93750360 | Eicher Tractor Grip Transport Lock                 | 115   | 87089900 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93750371 | Eicher Tractor Spring                             | 32    | 73209090 | 18% |
| 93750383 | Eicher Tractor Control Valve Type MIs             | 12315 | 87089900 | 18% |
| 93750395 | Eicher Tractor Assy. Compact Rear Hitch           | 5868  | 87089900 | 18% |
| 93750437 | Eicher Tractor Rod Extension - Tlv                | 152   | 87089900 | 18% |
| 93750449 | Eicher Tractor Cotter Pin                         | 2     | 73182400 | 18% |
| 93750450 | Eicher Tractor Packing                            | 16    | 74152100 | 18% |
| 93750462 | Eicher Tractor Plug                               | 52    | 87089900 | 18% |
| 93750474 | Eicher Tractor Split Pin                          | 2     | 73182400 | 18% |
| 93750486 | Eicher Tractor Spacer                             | 53    | 73072200 | 18% |
| 93750498 | Eicher Tractor Assy. Lift Arm                     | 1726  | 87089900 | 18% |
| 93750504 | Eicher Tractor Oil_Seal                           | 114   | 87089900 | 18% |
| 93750516 | Eicher Tractor Spring Dish                        | 6     | 73209090 | 18% |
| 93750528 | Eicher Tractor Slotted Spring Pin1                | 8     | 73209020 | 18% |
| 93750530 | Eicher Tractor Slotted Spring Pin                 | 4     | 73209020 | 18% |
| 93750541 | Eicher Tractor Packing                            | 20    | 87089900 | 18% |
| 93750553 | Eicher Tractor Flange - Oil Pipe Filler           | 167   | 87089900 | 18% |
| 93750565 | Eicher Tractor Assy. Pipe - Hose To Hyd. Pump     | 422   | 87089900 | 18% |
| 93750577 | Eicher Tractor Gear Pump - Steering(7 Cc)         | 10482 | 87084000 | 18% |
| 93750589 | Eicher Tractor Gear Pump - Hydraulic(10Cc)        | 14030 | 87084000 | 18% |
| 93750590 | Eicher Tractor Connector                          | 196   | 73072200 | 18% |
| 93750607 | Eicher Tractor Suction Hose                       | 203   | 40092100 | 18% |
| 93750619 | Eicher Tractor Filter,Oil                         | 2045  | 84212300 | 18% |
| 93750620 | Eicher Tractor Tube 1, Input                      | 1463  | 87089200 | 18% |
| 93750632 | Eicher Tractor Assy. Pipe - Hose To Stg. Pump     | 1293  | 87089200 | 18% |
| 93750644 | Eicher Tractor Assy Pump To Filter Rear Line      | 1022  | 87089900 | 18% |
| 93750656 | Eicher Tractor Assy. Tube 4,Suction               | 1616  | 87089200 | 18% |
| 93750668 | Eicher Tractor Assy. Pipe-Hyd. Pump To Tc Rear    | 1815  | 87089200 | 18% |
| 93750670 | Eicher Tractor Assy. Filter Bracket               | 2857  | 87089900 | 18% |
| 93750681 | Eicher Tractor Hose - Stg. Pump To Hyd. Pump      | 304   | 87089200 | 18% |
| 93750693 | Eicher Tractor Assy Relief Valve Divertor         | 5575  | 84812000 | 18% |
| 93750700 | Eicher Tractor Assy. Pipe Return                  | 249   | 87089900 | 18% |
| 93750711 | Eicher Tractor Assy. Bracket-Reliefvalvemtg       | 1311  | 87089900 | 18% |
| 93750723 | Eicher Tractor Hose-Relief Valve To Pressure Line | 142   | 40092200 | 18% |
| 93750735 | Eicher Tractor Rubber Pad                         | 26    | 87089400 | 18% |
| 93750747 | Eicher Tractor Cover Clamp Pipe                   | 17    | 87089400 | 18% |
| 93750759 | Eicher Tractor Plate Clamp Pipe                   | 19    | 87083000 | 18% |
| 93750760 | Eicher Tractor Strap Clamp                        | 7     | 87083000 | 18% |
| 93750772 | Eicher Tractor Guard - Relief Valve               | 1864  | 87089900 | 18% |
| 93750784 | Eicher Tractor Assy Pipe Stg Pump To Hose Return  | 1134  | 73062919 | 18% |
| 93750796 | Eicher Tractor Hose R, Steering                   | 2339  | 40094200 | 18% |
| 93750802 | Eicher Tractor Hose P, Steering                   | 1211  | 40094200 | 18% |
| 93750814 | Eicher Tractor Hose L, Steering                   | 2351  | 40094200 | 18% |
| 93750826 | Eicher Tractor Steering Hose                      | 875   | 40092200 | 18% |
| 93750838 | Eicher Tractor Connector                          | 100   | 73072200 | 18% |
| 93750840 | Eicher Tractor Tube Connector                     | 98    | 73072200 | 18% |
| 93750851 | Eicher Tractor Collar Assy                        | 448   | 87089900 | 18% |
| 93750863 | Eicher Tractor Arm Shift Range                    | 1168  | 87089900 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93750875 | Eicher Tractor Assy. Linkage                       | 607  | 87089900 | 18% |
| 93750887 | Eicher Tractor Assy Lever - Range                  | 1714 | 87089900 | 18% |
| 93750899 | Eicher Tractor Fork Range                          | 1072 | 87089900 | 18% |
| 93750905 | Eicher Tractor Rail Range                          | 322  | 87089900 | 18% |
| 93750917 | Eicher Tractor Assy.Throttle Mtg.Brkt              | 336  | 84099990 | 28% |
| 93750929 | Eicher Tractor Spring                              | 55   | 73209090 | 18% |
| 93750930 | Eicher Tractor Assy.Throttle Cable Mtg.            | 110  | 87089900 | 18% |
| 93750942 | Eicher Tractor Cable, Throttl Lever                | 385  | 87089900 | 18% |
| 93750954 | Eicher Tractor Pedal,Accel                         | 274  | 87089900 | 18% |
| 93750966 | Eicher Tractor Assy.Throttle Lever - Bottom        | 367  | 87089900 | 18% |
| 93750978 | Eicher Tractor Bracket Throttle Mtg.               | 772  | 82041110 | 18% |
| 93750980 | Eicher Tractor Disc Friction                       | 29   | 87089900 | 18% |
| 93750991 | Eicher Tractor Cap Assembly Throttle               | 62   | 87089900 | 18% |
| 93751004 | Eicher Tractor Cover - Throttle Pad                | 54   | 87089900 | 18% |
| 93751016 | Eicher Tractor Split Pin                           | 1    | 73182400 | 18% |
| 93751077 | Eicher Tractor Bracket – Return Pipe               | 121  | 87089900 | 18% |
| 93751089 | Eicher Tractor Lever Kit Lbh/S5                    | 2574 | 87089900 | 18% |
| 93751600 | Eicher Tractor Connection 90°-1"-14 Orfsx M18 Orb  | 134  | 73181500 | 18% |
| 93751788 | Eicher Tractor Filter Mtg Bkt                      | 1749 | 87089900 | 18% |
| 93751790 | Eicher Tractor Pipe Cylinder End Right 551 4Wd     | 1684 | 87089900 | 18% |
| 93751806 | Eicher Tractor Pipe Cylinder End Left 551 4Wd      | 1714 | 87089900 | 18% |
| 93751818 | Eicher Tractor Pressure Pipe Front 551 4Wd         | 1419 | 87089900 | 18% |
| 93751820 | Eicher Tractor Steering Pipe Left 551 4Wd          | 899  | 87089400 | 18% |
| 93751831 | Eicher Tractor Steering Pipe Right 551 4Wd         | 1566 | 87089400 | 18% |
| 93751843 | Eicher Tractor Pressure Pipe Assy 551 4Wd          | 958  | 87089900 | 18% |
| 93751995 | Eicher Tractor Clamp Pressure Pipe 485 Ps Hyd      | 101  | 87089900 | 18% |
| 93752008 | Eicher Tractor Pressure Pipe 485 Ps Hyd            | 1030 | 87089900 | 18% |
| 93810124 | Eicher Tractor Assy Rpm Meter With Dial And Pointe | 504  | 85123010 | 18% |
| 93810136 | Eicher Tractor Assy Elec.Temp.Guage With Dial & Po | 329  | 85123010 | 18% |
| 93810148 | Eicher Tractor Assy Oil Pr.Guage With Dial & Point | 357  | 85123010 | 18% |
| 93810150 | Eicher Tractor Assy Voltmeter With Dial And Pointe | 374  | 85123010 | 18% |
| 93810161 | Eicher Tractor H28-Awedge Base T10,1.7W            | 48   | 85122010 | 18% |
| 93810185 | Eicher Tractor Assy Fuel Gauge With Dial & Pointer | 359  | 85123010 | 18% |
| 93810197 | Eicher Tractor Glass                               | 131  | 70060000 | 18% |
| 93810203 | Eicher Tractor Assy Wiring Harness                 | 600  | 85123010 | 18% |
| 93810215 | Eicher Tractor Sealing Ring(Inner)                 | 143  | 87089900 | 18% |
| 93810227 | Eicher Tractor Sealing Ring(Outer)                 | 334  | 87089900 | 18% |
| 93810288 | Eicher Tractor Dual Gauge ( Int W/ 2129681 )       | 963  | 90292020 | 18% |
| 93810290 | Eicher Tractor Tank Unit-312/364/368               | 484  | 90292020 | 18% |
| 93810320 | Eicher Tractor Elect.Temp. Gauge                   | 575  | 90268010 | 18% |
| 93810367 | Eicher Tractor Lead Assy (+Ve)                     | 1688 | 85123010 | 18% |
| 93810502 | Eicher Tractor Visor                               | 255  | 87089900 | 18% |
| 93810513 | Eicher Tractor Assy Hour Counter                   | 255  | 85123010 | 18% |
| 93810525 | Eicher Tractor Assy Rpm Pcb                        | 2026 | 85123010 | 18% |
| 93810549 | Eicher Tractor Case                                | 147  | 87089900 | 18% |
| 93810550 | Eicher Tractor Front Dial                          | 190  | 85122010 | 18% |
| 93810586 | Eicher Tractor Fitment Kit                         | 76   | 90292020 | 18% |





|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93810604 | Eicher Tractor Front Light Assy Left               | 602  | 85122010 | 18% |
| 93810616 | Eicher Tractor Front Light Assy Right              | 487  | 85122010 | 18% |
| 93810628 | Eicher Tractor Front Light Assy Left               | 739  | 85122010 | 18% |
| 93810630 | Eicher Tractor Front Light Right                   | 763  | 85122010 | 18% |
| 93810902 | Eicher Tractor Instrument Cluster-368/485          | 5104 | 85123010 | 18% |
| 93810987 | Eicher Tractor Wiring Harnes Front-312/364         | 439  | 85441920 | 18% |
| 93811262 | Eicher Tractor Trailer Connector                   | 411  | 85441920 | 18% |
| 93811300 | Eicher Tractor Main Wiring Harness-242Sq           | 1112 | 85123010 | 18% |
| 93811384 | Eicher Tractor Front Wiring Harness                | 570  | 85443000 | 18% |
| 93811396 | Eicher Tractor Hour Cum Rpm Meter-333              | 699  | 85441920 | 18% |
| 93811438 | Eicher Tractor Ventilated Alternator With Pulley   | 6477 | 85122010 | 18% |
| 93811463 | Eicher Tractor Dual Gauge                          | 1143 | 85118000 | 28% |
| 93811475 | Eicher Tractor Speedo Meter Cable                  | 142  | 85441920 | 18% |
| 93811530 | Eicher Tractor Alternator Bracket                  | 493  | 87085000 | 18% |
| 93811578 | Eicher Tractor Tail Light Assy Right               | 779  | 85122010 | 18% |
| 93811580 | Eicher Tractor Tail Light Assy Left                | 776  | 85122010 | 18% |
| 93811608 | Eicher Tractor Tail Light Assy Right               | 458  | 85123010 | 18% |
| 93811610 | Eicher Tractor Tail Light Assy Left.               | 447  | 85123010 | 18% |
| 93811645 | Eicher Tractor Lense For Rear Light                | 150  | 85123010 | 18% |
| 93811682 | Eicher Tractor Instrument Cluster - 5150           | 4697 | 85123010 | 18% |
| 93811748 | Eicher Tractor Head Beam Indicator                 | 107  | 85311010 | 18% |
| 93811750 | Eicher Tractor Main Beam Indicator                 | 105  | 85311010 | 18% |
| 93811920 | Eicher Tractor Adaptor Plate                       | 34   | 87085000 | 18% |
| 93811931 | Eicher Tractor Starter Switch+ Fuel Cap+ Key Pair  | 590  | 83012000 | 18% |
| 93811980 | Eicher Tractor Main Wiring Harness                 | 1195 | 85123010 | 18% |
| 93812017 | Eicher Tractor Front Wiring Harness                | 629  | 85443000 | 18% |
| 93812029 | Eicher Tractor Instrument Cluster-312/364          | 5121 | 85123010 | 18% |
| 93812041 | Eicher Tractor Alternator 312                      | 8297 | 85115000 | 28% |
| 93812110 | Eicher Tractor Main Wiring Harness 380             | 1921 | 85443000 | 18% |
| 93812133 | Eicher Tractor Pressure Switch Wire                | 61   | 85443000 | 18% |
| 93812157 | Eicher Tractor Front Wiring Harness                | 578  | 85123010 | 18% |
| 93812182 | Eicher Tractor Alternator Wire                     | 45   | 85443000 | 18% |
| 93812212 | Eicher Tractor Front Wiring Harness                | 555  | 85443000 | 18% |
| 93812236 | Eicher Tractor Alternator With Pully               | 5651 | 85123010 | 18% |
| 93812285 | Eicher Tractor Vantilated Alternator With Pulley   | 6769 | 85122010 | 18% |
| 93812303 | Eicher Tractor Alternator Cover                    | 428  | 87085000 | 18% |
| 93812339 | Eicher Tractor Latch/Adopter Plate                 | 52   | 87085000 | 18% |
| 93812340 | Eicher Tractor Lead Assy (+Ve)                     | 662  | 85444999 | 18% |
| 93812364 | Eicher Tractor Main Wiring Harness                 | 2470 | 85123010 | 18% |
| 93812388 | Eicher Tractor Alternatert With Pully (5150 Ps)    | 6557 | 85123010 | 18% |
| 93812406 | Eicher Tractor Main Wiring Harness                 | 2584 | 85123010 | 18% |
| 93812418 | Eicher Tractor Main Wiring Harness 368/485         | 2100 | 85123010 | 18% |
| 93812420 | Eicher Tractor Pig Tail - Tank Unit                | 35   | 85443000 | 18% |
| 93812443 | Eicher Tractor Relay                               | 230  | 85364900 | 18% |
| 93812455 | Eicher Tractor Fuse Mtg. Bracket                   | 89   | 87089900 | 18% |
| 93812480 | Eicher Tractor Mobile Socket - 12V                 | 241  | 85366900 | 18% |
| 93812492 | Eicher Tractor Trailer Socket Wiring Harness Assly | 411  | 85123010 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93812521 | Eicher Tractor Main Wiring Harness              | 2541  | 85443000 | 18% |
| 93812560 | Eicher Tractor Main Wiring Harness 485          | 2498  | 85123010 | 18% |
| 93812595 | Eicher Tractor Safe Start Switch                | 227   | 85123010 | 18% |
| 93812601 | Eicher Tractor Mobile Pouch                     | 95    | 87089900 | 18% |
| 93812637 | Eicher Tractor Starter Motor Assly (12V/2.5Kw)  | 12317 | 85114000 | 28% |
| 93812650 | Eicher Tractor Main Wiring Harness-Jbm          | 1638  | 85123010 | 18% |
| 93812704 | Eicher Tractor Main Wiring Harness W.C          | 2306  | 85123010 | 18% |
| 93812730 | Eicher Tractor Sns Mounting Bracket             | 50    | 87089900 | 18% |
| 93812789 | Eicher Tractor Tank Unit                        | 410   | 87089900 | 18% |
| 93812790 | Eicher Tractor Hazard Switch (Toggle)           | 117   | 85123010 | 18% |
| 93812807 | Eicher Tractor Hazard Switch                    | 404   | 85123010 | 18% |
| 93812819 | Eicher Tractor Main Wiring Harness              | 1494  | 85123010 | 18% |
| 93812832 | Eicher Tractor Dual Gauge                       | 1011  | 85123010 | 18% |
| 93812844 | Eicher Tractor Rotary Main Switch               | 378   | 85369090 | 18% |
| 93812856 | Eicher Tractor Instrument Cluster               | 3872  | 85123010 | 18% |
| 93812868 | Eicher Tractor Instrument Cluster               | 3877  | 85123010 | 18% |
| 93812870 | Eicher Tractor Instrument Cluster               | 3872  | 90268090 | 18% |
| 93812881 | Eicher Tractor Instrument Cluster-5660          | 4263  | 85123010 | 18% |
| 93812900 | Eicher Tractor Wireing Harness - 242J           | 230   | 85123010 | 18% |
| 93812911 | Eicher Tractor Main Wiring Harness 312/364/485  | 1611  | 85123010 | 18% |
| 93812923 | Eicher Tractor Main Wiring Harness 333/380/5660 | 1636  | 85123010 | 18% |
| 93812935 | Eicher Tractor Main Wiring Harness (5150 Ps)    | 2640  | 85443000 | 18% |
| 93812947 | Eicher Tractor Fuel Gauge                       | 572   | 85123010 | 18% |
| 93812959 | Eicher Tractor Indicating Unit                  | 561   | 85123010 | 18% |
| 93812960 | Eicher Tractor Indicator Turning                | 92    | 85311010 | 18% |
| 93812972 | Eicher Tractor Indicators (Turn)                | 95    | 85311010 | 18% |
| 93812984 | Eicher Tractor Horn Push Button Assy            | 109   | 85123010 | 18% |
| 93813034 | Eicher Tractor Starter Motor Assy A/C           | 10385 | 85114000 | 28% |
| 93813046 | Eicher Tractor Sticker-Starter Switch           | 2     | 39199090 | 18% |
| 93813058 | Eicher Tractor Starter Motor Assy 12V/2.5Kw     | 10062 | 85114000 | 28% |
| 93813071 | Eicher Tractor Main Wiring Harness (5150 Ms)    | 2588  | 85123010 | 18% |
| 93813137 | Eicher Tractor Front Light                      | 628   | 85122010 | 18% |
| 93813149 | Eicher Tractor Front Light                      | 647   | 85122010 | 18% |
| 93813198 | Eicher Tractor Starter Switch - Rsm             | 556   | 85123010 | 18% |
| 93813204 | Eicher Tractor Starter Switch - Jbm             | 812   | 85123010 | 18% |
| 93813216 | Eicher Tractor Main Wiring Harness Jbm          | 1539  | 85123010 | 18% |
| 93813228 | Eicher Tractor Main Wiring Harness Assy.        | 1811  | 85443000 | 18% |
| 93813241 | Eicher Tractor Alternator Cover                 | 663   | 87085000 | 18% |
| 93813253 | Eicher Tractor Main Wiring Harness              | 1904  | 85443000 | 18% |
| 93813277 | Eicher Tractor Main Wiring Harness (557         | 2180  | 85123010 | 18% |
| 93813356 | Eicher Tractor Alternator With Pulley           | 5996  | 85123010 | 18% |
| 93813368 | Eicher Tractor Alternator With Pulley           | 5503  | 85123010 | 18% |
| 93813370 | Eicher Tractor Alternator With Pulley           | 6035  | 85123010 | 18% |
| 93813381 | Eicher Tractor Instrument Cluster               | 4049  | 85123010 | 18% |
| 93813400 | Eicher Tractor Plough Light Assy                | 543   | 85122010 | 18% |
| 93813423 | Eicher Tractor Blade Fuse - 10 Amp              | 16    | 85123010 | 18% |
| 93813435 | Eicher Tractor Blade Fuse 15 Amp                | 16    | 85123010 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 93813447 | Eicher Tractor Blade Fuse 30 Amp                   | 16   | 85123010 | 18% |
| 93813459 | Eicher Tractor Main Wiring Harness                 | 2884 | 85443000 | 18% |
| 93813460 | Eicher Tractor Main Wiring Harness                 | 2497 | 85443000 | 18% |
| 93813496 | Eicher Tractor Main Wiring Harness                 | 2112 | 85123010 | 18% |
| 93813502 | Eicher Tractor Gasket (Starter Motor) 333 380 480  | 44   | 68129090 | 18% |
| 93813514 | Eicher Tractor Gasket (Starter Motor) 380 5150 P.S | 39   | 68129090 | 18% |
| 93813526 | Eicher Tractor Gasket (Starter Motor 5660 557)     | 40   | 68129090 | 18% |
| 93813538 | Eicher Tractor Gasket (Starter Motor) 312 364 485  | 39   | 68129090 | 18% |
| 93813575 | Eicher Tractor Fusible Link                        | 90   | 85123010 | 18% |
| 93813587 | Eicher Tractor Pig Tail - Music Player             | 169  | 85443000 | 18% |
| 93813642 | Eicher Tractor Trailer Socket Wiring Harness Assy  | 343  | 82041110 | 18% |
| 93813666 | Eicher Tractor Front Cover                         | 221  | 40169330 | 18% |
| 93813678 | Eicher Tractor Crystal                             | 97   | 87089900 | 18% |
| 93813680 | Eicher Tractor Sealing Ring Inner                  | 165  | 40169320 | 18% |
| 93813710 | Eicher Tractor Fuel Gauge Assy.                    | 359  | 85123010 | 18% |
| 93813721 | Eicher Tractor Temp. Gauge Assy.                   | 272  | 85123010 | 18% |
| 93813733 | Eicher Tractor Oil Pressure Gauge Assy.            | 357  | 85123010 | 18% |
| 93813745 | Eicher Tractor Battery Gauge Assy.                 | 301  | 85079090 | 28% |
| 93813757 | Eicher Tractor Rpm Meter Assy.                     | 2794 | 90292090 | 18% |
| 93813769 | Eicher Tractor Assy. Wiring Harness                | 1495 | 85123010 | 18% |
| 93813861 | Eicher Tractor Lead Assy                           | 462  | 85123010 | 18% |
| 93813873 | Eicher Tractor Temp. Sw. Wire                      | 69   | 85443000 | 18% |
| 93813885 | Eicher Tractor Assy Temp Gauge                     | 249  | 85123010 | 18% |
| 93813897 | Eicher Tractor Front Light - Left                  | 757  | 85122010 | 18% |
| 93813903 | Eicher Tractor Front Light Assy Rt.                | 786  | 85122010 | 18% |
| 93814063 | Eicher Tractor Front Wiring Harness                | 459  | 85443000 | 18% |
| 93814191 | Eicher Tractor Instrument Cluster                  | 3081 | 90292020 | 18% |
| 93814208 | Eicher Tractor Head Light Assy.                    | 539  | 85122010 | 18% |
| 93814257 | Eicher Tractor Fuel Tank Unit                      | 323  | 87089900 | 18% |
| 93814269 | Eicher Tractor Main Wiring Harness-Chottu          | 1782 | 85123010 | 18% |
| 93814270 | Eicher Tractor Front Wiring Harness                | 754  | 85123010 | 18% |
| 93814282 | Eicher Tractor Lead Assy +Ve                       | 534  | 85444999 | 18% |
| 93814294 | Eicher Tractor Trailer Socket With Wiring Harness  | 385  | 85444220 | 18% |
| 93814306 | Eicher Tractor Adjusting Latch                     | 152  | 87089900 | 18% |
| 93814312 | Eicher Tractor Belt Xv 13X1010                     | 305  | 40101290 | 18% |
| 93814427 | Eicher Tractor Temperature Gauge Assy.             | 329  | 90268090 | 18% |
| 93814439 | Eicher Tractor Fuel Gauge Assy.                    | 356  | 90261020 | 18% |
| 93814446 | Eicher Tractor Electrical Hr./ Rpm Meter Assy.     | 3186 | 90292090 | 18% |
| 93814452 | Eicher Tractor Main Wiring Harness (380)           | 3025 | 85443000 | 18% |
| 93814464 | Eicher Tractor Trailer Socket Wiring Harness Assy  | 464  | 85443000 | 18% |
| 93814476 | Eicher Tractor Main Wiring Harness (485)           | 3836 | 85443000 | 18% |
| 93814488 | Eicher Tractor Main Wiring Harness (557)           | 2969 | 85123010 | 18% |
| 93814520 | Eicher Tractor Instrument Cluster With Push Botton | 4987 | 85123010 | 18% |
| 93814531 | Eicher Tractor Push Button Assy.                   | 211  | 87089900 | 18% |
| 93814580 | Eicher Tractor Lead Assy Positive                  | 1294 | 85123010 | 18% |
| 93814592 | Eicher Tractor Lead Assy Negative                  | 502  | 85123010 | 18% |
| 93814683 | Eicher Tractor Tail Light Assy Right               | 797  | 85122010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93814695 | Eicher Tractor Tail Lamp Assy Lh                   | 590   | 85122010 | 18% |
| 93814701 | Eicher Tractor Tail Light Assy Right               | 958   | 85122010 | 18% |
| 93814713 | Eicher Tractor Tail Lamp Assy Lh                   | 979   | 85122010 | 18% |
| 93814749 | Eicher Tractor Head Light Bulb 12-35/35W           | 183   | 85122020 | 18% |
| 93814786 | Eicher Tractor Instrument Cluster (548E)-Export    | 4050  | 90268090 | 18% |
| 93814798 | Eicher Tractor Instrument Cluster 557              | 5613  | 85123010 | 18% |
| 93814816 | Eicher Tractor Switch (Black) – Piano Type         | 32    | 87083000 | 18% |
| 93814932 | Eicher Tractor Bulb 12V/21W                        | 43    | 85122010 | 18% |
| 93814944 | Eicher Tractor Bulb 12V/5W Cap Less                | 22    | 85122010 | 18% |
| 93815031 | Eicher Tractor Rpm Meter Assy.                     | 2794  | 90292090 | 18% |
| 93815055 | Eicher Tractor Instrument Cluster With Push Botton | 4018  | 85123010 | 18% |
| 93815067 | Eicher Tractor Temp. Gauge Assy.                   | 315   | 85123010 | 18% |
| 93815079 | Eicher Tractor Lead Assy Negative                  | 558   | 85123010 | 18% |
| 93815080 | Eicher Tractor Instrument Cluster (With Push Butto | 4714  | 90268090 | 18% |
| 93815237 | Eicher Tractor Tail Light Assy Rh                  | 762   | 85122010 | 18% |
| 93815249 | Eicher Tractor Tail Light Assy Lh                  | 748   | 85123010 | 18% |
| 93815328 | Eicher Tractor Starter Motor (485)                 | 11689 | 85114000 | 28% |
| 93815330 | Eicher Tractor Starter Motor (380)                 | 10894 | 85114000 | 28% |
| 93815341 | Eicher Tractor Starter Motor (241/242)             | 8909  | 85114000 | 28% |
| 93815389 | Eicher Tractor Instrument Cluster                  | 3749  | 90268090 | 18% |
| 93815390 | Eicher Tractor Main Wiring Harness                 | 1776  | 85444220 | 18% |
| 93815444 | Eicher Tractor Front Wiring Harness                | 858   | 85444220 | 18% |
| 93815456 | Eicher Tractor Lead Assy +Ve                       | 533   | 85444999 | 18% |
| 93815468 | Eicher Tractor Starter Motor                       | 12030 | 85114000 | 28% |
| 93815523 | Eicher Tractor Front Lamp Assy (Lt)                | 823   | 85122010 | 18% |
| 93815535 | Eicher Tractor Front Lamp Assy (Rt)                | 809   | 85122010 | 18% |
| 93815547 | Eicher Tractor Front Lamp Assy (Lt)                | 1109  | 85122010 | 18% |
| 93815559 | Eicher Tractor Front Lamp Assy (Rt)                | 1146  | 85122010 | 18% |
| 93815560 | Eicher Tractor Front Lamp Assy (Lt)                | 1013  | 85122010 | 18% |
| 93815572 | Eicher Tractor Front Lamp Assy (Rt)                | 1024  | 85122010 | 18% |
| 93815584 | Eicher Tractor Front Lamp Assy (Lt)                | 827   | 85122010 | 18% |
| 93815596 | Eicher Tractor Front Lamp Assy (Rt)                | 828   | 85122010 | 18% |
| 93815602 | Eicher Tractor Front Lamp Assy (Lt)                | 666   | 85122010 | 18% |
| 93815640 | Eicher Tractor Main Wiring Harness                 | 4544  | 85123010 | 18% |
| 93815641 | Eicher Tractor Front Lamp Assy (Rt)                | 698   | 85122010 | 18% |
| 93815651 | Eicher Tractor Front Wiring Harness                | 1646  | 85443000 | 18% |
| 93815699 | Eicher Tractor Lead Assy +Ve-312/364/368F          | 1726  | 85444999 | 18% |
| 93815705 | Eicher Tractor Lead Assy Positive                  | 1764  | 85444999 | 18% |
| 93815717 | Eicher Tractor Lead Assy I (350 Mm)                | 640   | 85441920 | 18% |
| 93815730 | Eicher Tractor Lead Assy Positive                  | 608   | 85444999 | 18% |
| 93815742 | Eicher Tractor Lead Assy Positive                  | 798   | 85444999 | 18% |
| 93815754 | Eicher Tractor Lead Assy Negative                  | 469   | 85443000 | 18% |
| 93815766 | Eicher Tractor Lead Assembly -Ve                   | 683   | 85443000 | 18% |
| 93815778 | Eicher Tractor Temp. Gauge Assy.                   | 364   | 85123010 | 18% |
| 93815780 | Eicher Tractor Rpm Meter Assy.                     | 3687  | 90292090 | 18% |
| 93816084 | Eicher Tractor Main Wiring Harness (380/480)       | 3791  | 85443000 | 18% |
| 93816229 | Eicher Tractor Main Wiring Harness (241/242R)      | 1718  | 85443000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93816230 | Eicher Tractor Main Wiring Harness (242 J)         | 1694  | 85123010 | 18% |
| 93816242 | Eicher Tractor Main Wiring Harness (551/557)       | 4073  | 85123010 | 18% |
| 93816254 | Eicher Tractor Main Wiring Harness (380Nh)         | 3119  | 85443000 | 18% |
| 93816266 | Eicher Tractor Front Wiring Harness (380/480)      | 517   | 85443000 | 18% |
| 93816280 | Eicher Tractor Front Wiring Harness (551/557)      | 600   | 85443000 | 18% |
| 93816653 | Eicher Tractor Instrument Cluster- 364/312         | 3872  | 85123010 | 18% |
| 93816665 | Eicher Tractor Instrument Cluster-368/485          | 3877  | 85123010 | 18% |
| 93816677 | Eicher Tractor Instrument Cluster - 380/480        | 5310  | 90268090 | 18% |
| 93816689 | Eicher Tractor Instrument Cluster-333/380/480      | 3872  | 85123010 | 18% |
| 93816734 | Eicher Tractor Plough Lamp Switch                  | 54    | 85123010 | 18% |
| 93816813 | Eicher Tractor Instrument Cluster                  | 4712  | 85123010 | 18% |
| 93816953 | Eicher Tractor Temp. Gauge Assy.                   | 281   | 85123010 | 18% |
| 93816965 | Eicher Tractor Rpm Meter Assy.                     | 2794  | 90292090 | 18% |
| 93816989 | Eicher Tractor Main Wiring Harness                 | 4412  | 85123010 | 18% |
| 93816990 | Eicher Tractor Front Wiring Harness                | 1925  | 85443000 | 18% |
| 93817003 | Eicher Tractor Instrument Cluster With Push Button | 4262  | 85123010 | 18% |
| 93817015 | Eicher Tractor Rpm Meter Assy.                     | 2817  | 90292020 | 18% |
| 93817027 | Eicher Tractor Temp. Gauge Assy.                   | 275   | 90268010 | 18% |
| 93817039 | Eicher Tractor Assy. Elec. Hr / Rpm Meter          | 3742  | 90292020 | 18% |
| 93817040 | Eicher Tractor Assy. Elec. Hr / Rpm Meter          | 3729  | 90292020 | 18% |
| 93817052 | Eicher Tractor Assy. Temp. Gauge                   | 373   | 90268010 | 18% |
| 93817301 | Eicher Tractor Instrument Cluster                  | 4636  | 85123010 | 18% |
| 93817313 | Eicher Tractor Lead Assy. +Ve                      | 805   | 85444999 | 18% |
| 93817325 | Eicher Tractor Main Wiring Harness                 | 6053  | 85444220 | 18% |
| 93817337 | Eicher Tractor Front Wiring Harness                | 1048  | 85444220 | 18% |
| 93817404 | Eicher Tractor Horn 90 Dia                         | 312   | 85122010 | 18% |
| 93817416 | Eicher Tractor Trailer Socket Wiring Harness Assy. | 403   | 85443000 | 18% |
| 93817428 | Eicher Tractor Ecu Bkt Earth Pigtail               | 117   | 87089900 | 18% |
| 93817489 | Eicher Tractor Main Wiring Harness (241/242R)      | 1934  | 85123010 | 18% |
| 93817490 | Eicher Tractor Front Wiring Harness (242R)         | 671   | 85123010 | 18% |
| 93817507 | Eicher Tractor Main Wiring Harness (551/557/5660)  | 3771  | 85443000 | 18% |
| 93817532 | Eicher Tractor Main Wiring Harness (548Fl)         | 3830  | 85123010 | 18% |
| 93817544 | Eicher Tractor Main Wiring Harness (380/480)       | 3689  | 85123010 | 18% |
| 93817570 | Eicher Tractor Assy. Fuel Gauge                    | 394   | 85123010 | 18% |
| 93817581 | Eicher Tractor Assy. Oil Pressure Gauge            | 370   | 85123010 | 18% |
| 93817593 | Eicher Tractor Assy. Volt Meter                    | 370   | 85123010 | 18% |
| 93817600 | Eicher Tractor Assy. Hr./Rpm Meter                 | 3687  | 90292020 | 18% |
| 93817611 | Eicher Tractor Assy. Hr./Rpm Meter                 | 3687  | 90292020 | 18% |
| 93817623 | Eicher Tractor Assy. Hr./Rpm Meter                 | 3687  | 90292020 | 18% |
| 93817635 | Eicher Tractor Assy. Hr./Rpm Meter                 | 3687  | 90292020 | 18% |
| 93817647 | Eicher Tractor Assy. Temperature Gauge             | 364   | 90268090 | 18% |
| 93817659 | Eicher Tractor Assy. Temperature Gauge             | 364   | 90268090 | 18% |
| 93817817 | Eicher Tractor Solenoid Swtich                     | 1975  | 85369020 | 18% |
| 93817866 | Eicher Tractor Starter Motor Direct Drive (Lucas)  | 13950 | 85114000 | 28% |
| 93817880 | Eicher Tractor Wiring Harness Main (551/557)       | 4561  | 85441920 | 18% |
| 93817891 | Eicher Tractor Wiring Harness Main (548/485)       | 4688  | 85441920 | 18% |
| 93817908 | Eicher Tractor Wiring Harness Front(551/557)       | 1583  | 85441920 | 18% |



|          |   |       |          |     |
|----------|---|-------|----------|-----|
| 93817910 | Eicher Tractor Wiring Harness Front(548)          | 1201  | 85441920 | 18% |
| 93817933 | Eicher Tractor Wiring Harness Main (551/557 F13)  | 4698  | 85441920 | 18% |
| 93817945 | Eicher Tractor Wiring Harness Main (548/485 F13)  | 4796  | 85441920 | 18% |
| 93817969 | Eicher Tractor Solenoid Assy. (Lucas)             | 3478  | 85365090 | 18% |
| 93817970 | Eicher Tractor Pig Tail- Mcb F13 To Wh F12        | 81    | 87089900 | 18% |
| 93817982 | Eicher Tractor Pig Tail- Mcb F12 To Wh F13        | 92    | 87089900 | 18% |
| 93818070 | Eicher Tractor Solenoid Assy. (Lucas)             | 4349  | 85365090 | 18% |
| 93818081 | Eicher Tractor Shroud                             | 564   | 87089900 | 18% |
| 93818093 | Eicher Tractor Plunger Assembly                   | 747   | 85119000 | 28% |
| 93818100 | Eicher Tractor Solenoid Switch Assembly           | 4262  | 85119000 | 28% |
| 93818111 | Eicher Tractor Moving Contact Assembly            | 409   | 87089900 | 18% |
| 93818123 | Eicher Tractor Terminal Base Assembly             | 718   | 87089900 | 18% |
| 93818135 | Eicher Tractor Fixing Bracket Assembly            | 4562  | 87089900 | 18% |
| 93818147 | Eicher Tractor Drive Assembly                     | 2676  | 85119000 | 28% |
| 93818159 | Eicher Tractor Engaging Lever Assembly            | 95    | 87084000 | 18% |
| 93818160 | Eicher Tractor Intermediate Bracket               | 955   | 87089900 | 18% |
| 93818172 | Eicher Tractor Armature Assembly                  | 5970  | 85119000 | 28% |
| 93818184 | Eicher Tractor Field Coil Assembly                | 4695  | 85119000 | 28% |
| 93818196 | Eicher Tractor Brush Gear Assembly                | 1494  | 85119000 | 28% |
| 93818202 | Eicher Tractor Ce Bracket Assembly                | 1063  | 87089900 | 18% |
| 93818214 | Eicher Tractor Armature Assembly Kit              | 329   | 85119000 | 28% |
| 93818226 | Eicher Tractor Fasteners & Sundries Parts Kit     | 260   | 73181500 | 18% |
| 93818238 | Eicher Tractor Brush Assembling Kit               | 38    | 87089900 | 18% |
| 93818240 | Eicher Tractor Fasteners Assembling Kit           | 416   | 87089900 | 18% |
| 93818251 | Eicher Tractor Sealing Assembling Kit             | 133   | 73182990 | 18% |
| 93818342 | Eicher Tractor Starter Motor Lucas Grs -          | 12336 | 85114000 | 28% |
| 93818378 | Eicher Tractor Wiring Harness Main (650 Trem-3A)  | 5617  | 85441920 | 18% |
| 93818380 | Eicher Tractor Wiring Harness Front (650 Trem-3A) | 2486  | 85441920 | 18% |
| 93818391 | Eicher Tractor Solenoid Assy. (Lucas)             | 4221  | 85365090 | 18% |
| 93818469 | Eicher Tractor Solenoid                           | 3140  | 85365090 | 18% |
| 93818512 | Eicher Tractor Solenoid                           | 2706  | 85365090 | 18% |
| 93819061 | Eicher Tractor Led Plough Lamp                    | 2430  | 85122010 | 18% |
| 93820336 | Eicher Tractor Battery Lead +Ve                   | 689   | 85079090 | 28% |
| 93820348 | Eicher Tractor Alternator With Pully              | 6707  | 85123010 | 18% |
| 93820350 | Eicher Tractor Latch                              | 232   | 87085000 | 18% |
| 93820427 | Eicher Tractor Wiring Harness Main                | 3442  | 85123010 | 18% |
| 93820440 | Eicher Tractor Battery Cable                      | 506   | 85443000 | 18% |
| 93820476 | Eicher Tractor Adopter Plate                      | 17    | 87085000 | 18% |
| 93820506 | Eicher Tractor Starter Motor 12V/2.8Kw            | 9286  | 85114000 | 28% |
| 93820579 | Eicher Tractor Air Pressure Wire                  | 72    | 73202000 | 18% |
| 93820580 | Eicher Tractor Front W/H                          | 586   | 85443000 | 18% |
| 93820592 | Eicher Tractor Combination Switch                 | 811   | 85369090 | 18% |
| 93820609 | Eicher Tractor Number Plate Light                 | 209   | 85122090 | 18% |
| 93820646 | Eicher Tractor Alternator Cover                   | 140   | 87085000 | 18% |
| 93820671 | Eicher Tractor Alternator Cover                   | 222   | 87085000 | 18% |
| 93820737 | Eicher Tractor Battery Lead +Ve                   | 946   | 85079090 | 28% |
| 93820750 | Eicher Tractor Flasher                            | 1411  | 85122010 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 93820786 | Eicher Tractor Main Wiring Harness                 | 4560  | 85123010 | 18% |
| 93820798 | Eicher Tractor Front Wiring Harness                | 524   | 85123010 | 18% |
| 93820804 | Eicher Tractor On/Off Switch                       | 191   | 85122020 | 18% |
| 93820853 | Eicher Tractor Lead Assy (-Ve)                     | 350   | 85123010 | 18% |
| 93820865 | Eicher Tractor Inst. Cluster                       | 26668 | 90268090 | 18% |
| 93820877 | Eicher Tractor Tank Unit                           | 1434  | 87089900 | 18% |
| 93820920 | Eicher Tractor Trailer Socket                      | 621   | 85443000 | 18% |
| 93820956 | Eicher Tractor Front Cover                         | 1145  | 40169330 | 18% |
| 93820968 | Eicher Tractor Crystal                             | 813   | 87089900 | 18% |
| 93820970 | Eicher Tractor Cap                                 | 31    | 87085000 | 18% |
| 93820993 | Eicher Tractor Sealing Ring (Outer)                | 853   | 40169320 | 18% |
| 93821006 | Eicher Tractor Alternator Cover Assy               | 494   | 87085000 | 18% |
| 93821092 | Eicher Tractor Head Light Assy - Left              | 5846  | 85122010 | 18% |
| 93821109 | Eicher Tractor Head Light Assy - Right             | 5846  | 85122010 | 18% |
| 93821110 | Eicher Tractor Tail Light Assy- Left               | 3427  | 85122010 | 18% |
| 93821122 | Eicher Tractor Tail Light Assy- Right              | 3427  | 85122010 | 18% |
| 93821134 | Eicher Tractor Front Light -Left                   | 2338  | 85122010 | 18% |
| 93821146 | Eicher Tractor Front Light -Right                  | 2338  | 85122010 | 18% |
| 93821158 | Eicher Tractor Instrument Cluster                  | 4018  | 85123010 | 18% |
| 93821201 | Eicher Tractor Alternator Cover                    | 226   | 87085000 | 18% |
| 93821225 | Eicher Tractor Alternatert With Pully              | 6544  | 85115000 | 28% |
| 93821432 | Eicher Tractor Head Lamp Assy                      | 648   | 85122010 | 18% |
| 93821456 | Eicher Tractor Starter Motor (5660)                | 12464 | 85114000 | 28% |
| 93821468 | Eicher Tractor Starter Motor (380Ps/5150Ps)        | 10541 | 85114000 | 28% |
| 93821500 | Eicher Tractor Hazard Switch                       | 323   | 85365090 | 18% |
| 93821535 | Eicher Tractor Instrument Cluster-650              | 4820  | 85123010 | 18% |
| 93821584 | Eicher Tractor Instrument Cluster (560-1530)       | 4696  | 90268090 | 18% |
| 93821717 | Eicher Tractor Main Wiring Harness (548FI)         | 3758  | 85443000 | 18% |
| 93821730 | Eicher Tractor Main Wiring Harness (551/557/5660)  | 3687  | 85443000 | 18% |
| 93821742 | Eicher Tractor Instrument Cluster-485/548          | 6169  | 85123010 | 18% |
| 93821778 | Eicher Tractor Instrument Cluster -557/551/5660    | 5355  | 85123010 | 18% |
| 93822072 | Eicher Tractor Mobile Charger Box                  | 1354  | 39021000 | 18% |
| 93822100 | Eicher Tractor Go Home Controller                  | 1280  | 85364900 | 18% |
| 93822140 | Eicher Tractor Mobile Charger Box (With Indigenous | 1189  | 39021000 | 18% |
| 93822217 | Eicher Tractor Egr Branch Support Bkt              | 28    | 87089900 | 18% |
| 93822229 | Eicher Tractor Ecu Branch Supp Bkt                 | 78    | 87089900 | 18% |
| 93822230 | Eicher Tractor U-Bolt M8X30                        | 76    | 73181500 | 18% |
| 93822266 | Eicher Tractor Go Home Switch (Push Button)        | 130   | 83100090 | 18% |
| 93822278 | Eicher Tractor Instrument Cluster - T4 650         | 6095  | 90292020 | 18% |
| 93822436 | Eicher Tractor Instrument Cluster (650)            | 5669  | 85123010 | 18% |
| 94040958 | Eicher Tractor Plastic Cap(Air Intake Tube)        | 5     | 39021000 | 18% |
| 94041106 | Eicher Tractor Speedo Cable Assy                   | 283   | 85443000 | 18% |
| 94041367 | Eicher Tractor Pulley Water Pump-5300              | 1584  | 84099941 | 28% |
| 94041392 | Eicher Tractor Dry A/C Support Bkt. 50Hp           | 394   | 87089900 | 18% |
| 94041616 | Eicher Tractor Cyl. Head With Groove               | 3774  | 84099941 | 28% |
| 94042270 | Eicher Tractor V-Belt Avx13-1160                   | 454   | 40101290 | 18% |
| 94042323 | Eicher Tractor Cap Forging                         | 483   | 73261990 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 94042335 | Eicher Tractor Con Rod Forging                     | 1231  | 73261990 | 18% |
| 94042890 | Eicher Tractor Plug For Inlet Manifold             | 15    | 39021000 | 18% |
| 94043900 | Eicher Tractor Blower Support                      | 1474  | 84091000 | 28% |
| 94066110 | Eicher Tractor Chain Mounting Bracket Left         | 528   | 87089900 | 18% |
| 94066121 | Eicher Tractor Chain Mounting Bracket Right        | 528   | 87089900 | 18% |
| 94081808 | Eicher Tractor D.C. Assembly                       | 31872 | 87089300 | 18% |
| 94081810 | Eicher Tractor Driven Plate Assembly               | 11853 | 87089300 | 18% |
| 94100013 | Eicher Tractor Lead Assy +Ve-241/242               | 1101  | 85123010 | 18% |
| 95010068 | Eicher Tractor Piston & Pin Set-115E               | 3589  | 84099112 | 28% |
| 95010070 | Eicher Tractor Ring Set-115E                       | 695   | 84099913 | 28% |
| 95020050 | Eicher Tractor Cylinder Block Semi M/C             | 64515 | 84099941 | 28% |
| 95020141 | Eicher Tractor Cylinder Head Semi Machined         | 23013 | 84841090 | 18% |
| 95020293 | Eicher Tractor Main Bearing Cap S/F                | 1027  | 84822090 | 18% |
| 95020300 | Eicher Tractor Guide Bearing Cap Central S/F       | 984   | 84822090 | 18% |
| 96110022 | Eicher Tractor V Ring                              | 112   | 87089900 | 18% |
| 96130185 | Eicher Tractor Sealing Cup Dia 17                  | 12    | 87089900 | 18% |
| 96130227 | Eicher Tractor Hex Screw M12*100                   | 78    | 73181500 | 18% |
| 96130275 | Eicher Tractor Oil Seal                            | 124   | 40169330 | 18% |
| 96130279 | Eicher Tractor Spring Washer 'Square'-8 Zpw        | 2     | 73182990 | 18% |
| 96130288 | Eicher Tractor Hex Bolt M18X85,B8.8,Zp             | 109   | 73181500 | 18% |
| 96130380 | Eicher Tractor Cross Recessed Pan Hd.Screw M5X35-B | 5     | 73181500 | 18% |
| 96130409 | Eicher Tractor Spring Washer A-18,'Flat',Zp,       | 12    | 73182990 | 18% |
| 96130463 | Eicher Tractor Special Bolt M12X1.25 X 35 B10.9    | 16    | 73181500 | 18% |
| 96130483 | Eicher Tractor Plain Washer 6.4 (Od 18Mm)          | 5     | 73182100 | 18% |
| 96130525 | Eicher Tractor Hex Bolt M14X2X80,B8.8,Zp,          | 40    | 73181500 | 18% |
| 96130616 | Eicher Tractor Cogged Belt Avx 10/1085 Mm          | 239   | 40103999 | 18% |
| 96130689 | Eicher Tractor Hex Bolt M16X1.5X75,B8.8,Zp         | 66    | 73181500 | 18% |
| 96130690 | Eicher Tractor Circlip A-25 Heavy                  | 26    | 73182910 | 18% |
| 96130719 | Eicher Tractor Punched Washer B5.5 B.P.            | 3     | 73182100 | 18% |
| 96130744 | Eicher Tractor Hex Screw M24X1.5X55                | 187   | 73181500 | 18% |
| 96130781 | Eicher Tractor Nylock Nut M14X1.5                  | 27    | 73181500 | 18% |
| 96130800 | Eicher Tractor Cross Recessed Pan Hd.Screw M4X10-Z | 3     | 73181500 | 18% |
| 96130823 | Eicher Tractor Cross Recessed C'Sk Screw M6X15-Bp  | 4     | 73181500 | 18% |
| 96130835 | Eicher Tractor Cross Recessed C'Sk Screw M8X30-Zn  | 10    | 73181500 | 18% |
| 96130847 | Eicher Tractor Circlip A18 Heavy Duty              | 13    | 73182910 | 18% |
| 96130859 | Eicher Tractor Needle Bearing Nb 35*45*20          | 507   | 84824000 | 18% |
| 96130872 | Eicher Tractor Hex Bolt M8X6                       | 8     | 73181500 | 18% |
| 96130926 | Eicher Tractor Plain Washer 5.3 (Od 15)-Zn         | 3     | 73182100 | 18% |
| 96130940 | Eicher Tractor Hex Screw M12X70,B8.8-Zn            | 52    | 73181500 | 18% |
| 96131040 | Eicher Tractor Cross Recessed Pan Hd.Screw M5X20-Z | 4     | 73181500 | 18% |
| 96131051 | Eicher Tractor Flange Hex Screw M8X25              | 8     | 73181500 | 18% |
| 96131075 | Eicher Tractor Hexthin Nut 20*2.5                  | 26    | 73181500 | 18% |
| 96131104 | Eicher Tractor Bush 18*16*36 Du(B+S)               | 133   | 87089900 | 18% |
| 96131116 | Eicher Tractor Circlip 55X3H                       | 44    | 73182910 | 18% |
| 96131130 | Eicher Tractor Spring Dowel 8X80                   | 29    | 73182100 | 18% |
| 96131141 | Eicher Tractor Hex Skt.Grub Screw M10X35,Type-G    | 58    | 73181500 | 18% |
| 96131153 | Eicher Tractor Needle Bearing - Nb 304030          | 579   | 84822090 | 18% |





|          |  |     |          |     |
|----------|--|-----|----------|-----|
| 96131177 | Eicher Tractor Hex Bolt M12*60 Grade 10.9          | 28  | 73181500 | 18% |
| 96131189 | Eicher Tractor Machined Washer 19-Zn               | 13  | 73182100 | 18% |
| 96131190 | Eicher Tractor Hex Bolt M20*2.5*50                 | 118 | 73181500 | 18% |
| 96131281 | Eicher Tractor O Ring 6X2 Shore A 70 Nbr           | 10  | 40169320 | 18% |
| 96131293 | Eicher Tractor Back Up Ring 6.7X10X1.4 Ptfе        | 41  | 39269099 | 18% |
| 96131396 | Eicher Tractor Plastic Plug Dia 14                 | 4   | 39021000 | 18% |
| 96131402 | Eicher Tractor Plastic Plug M12                    | 4   | 39021000 | 18% |
| 96131440 | Eicher Tractor Plastic Plug Dia 32                 | 10  | 39021000 | 18% |
| 96131463 | Eicher Tractor Plastic Plug Dia 13                 | 4   | 39021000 | 18% |
| 96131505 | Eicher Tractor Circlip 28X1.5N                     | 16  | 73182910 | 18% |
| 96131542 | Eicher Tractor Hex Bolt M12X80,B8.8,Zp,            | 62  | 73181500 | 18% |
| 96131566 | Eicher Tractor Hex Bolt M14X115,B8.8,Zp,           | 109 | 73181500 | 18% |
| 96131580 | Eicher Tractor D G Ball Bearing 6308 Zr            | 802 | 84821011 | 18% |
| 96131591 | Eicher Tractor D G Ball Bearing 6209 Zr            | 576 | 84821011 | 18% |
| 96131608 | Eicher Tractor D G Ball Bearing 6211N Zr           | 864 | 84821012 | 18% |
| 96131694 | Eicher Tractor Circlip B40 Light                   | 13  | 73182910 | 18% |
| 96131876 | Eicher Tractor Key Shifting                        | 267 | 84818090 | 18% |
| 96131888 | Eicher Tractor Spring Shifting Key                 | 322 | 73209090 | 18% |
| 96131955 | Eicher Tractor Hex Screw M20X2.5X160,B8.8,Zp,      | 317 | 73181500 | 18% |
| 96132091 | Eicher Tractor Circlip C-10 External Is:3075       | 7   | 73182910 | 18% |
| 96132194 | Eicher Tractor Hex Socket Head Grub Screw E M8X30  | 40  | 73181500 | 18% |
| 96132200 | Eicher Tractor Hex Socket Grub Screw A M8X25 Is:60 | 33  | 73181500 | 18% |
| 96132212 | Eicher Tractor O Ring 17X1.5 Shore A 70 Nbr        | 14  | 40169320 | 18% |
| 96132224 | Eicher Tractor O Ring 19.3X2.4 Shore A 70 Nbr      | 19  | 40169320 | 18% |
| 96132236 | Eicher Tractor O Ring 21.3X2.4 Shore A 70 Nbr      | 26  | 40169320 | 18% |
| 96132250 | Eicher Tractor Back Up Ring 18.4X22X1.4Ptfе        | 51  | 39269099 | 18% |
| 96132261 | Eicher Tractor Back Up Ring 20.4X24X1.4Ptfе        | 58  | 39269099 | 18% |
| 96132268 | Eicher Tractor Cross Recessed C'Sk St Steel Screw  | 24  | 73181500 | 18% |
| 96132297 | Eicher Tractor O Ring 9.25X1.78 Shore A 70 Nbr     | 13  | 40169320 | 18% |
| 96132303 | Eicher Tractor Back Up Ring 10.1X212.7X1.4Ptfе     | 38  | 39269099 | 18% |
| 96132339 | Eicher Tractor Oil Seal 55X80X10                   | 192 | 40169330 | 18% |
| 96132352 | Eicher Tractor Hex Bolt M12X140,B8.8,Zn            | 82  | 73181500 | 18% |
| 96132376 | Eicher Tractor Spring Dowel Sleeve Heavy 4X30Is:5  | 11  | 73182100 | 18% |
| 96132390 | Eicher Tractor Stud M 10X55, Type A,B10.9,Bp       | 30  | 73182100 | 18% |
| 96132406 | Eicher Tractor Hex Bolt M12X115,B8.8,Zp            | 56  | 73181500 | 18% |
| 96132431 | Eicher Tractor Stud Bm10X30                        | 17  | 73182100 | 18% |
| 96132467 | Eicher Tractor O-Ring 20X2.5 Nbr Es01 It31:0       | 14  | 40169320 | 18% |
| 96132480 | Eicher Tractor Hex S'Kt Set Screw M8X12Tp          | 12  | 73181500 | 18% |
| 96132492 | Eicher Tractor Circlip Heavy A 48X2.5 Is:3075      | 32  | 73182910 | 18% |
| 96132510 | Eicher Tractor Spring Dowel Light 6X25             | 15  | 73182100 | 18% |
| 96132534 | Eicher Tractor Cogged Belt Avx13 - 1280            | 457 | 40101290 | 18% |
| 96132546 | Eicher Tractor Nrb 25X30X13                        | 94  | 84824000 | 18% |
| 96132558 | Eicher Tractor Hshc Bolt M 14X70, B12.90           | 86  | 73181500 | 18% |
| 96132595 | Eicher Tractor Hex. Bolt M8X90,Is:1364-1967,B8.8   | 16  | 73181500 | 18% |
| 96132741 | Eicher Tractor Hshc Bolt M 18X90, B12.9            | 180 | 73181500 | 18% |
| 96132753 | Eicher Tractor Stud M14 X 65 - Type B              | 58  | 73182100 | 18% |
| 96132777 | Eicher Tractor O-Ring 64*3-Nbr Shore 70            | 32  | 40169320 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 96132790 | Eicher Tractor Hex Bolt M16X150                    | 103  | 73181500 | 18% |
| 96132807 | Eicher Tractor Hex Bolt M6X1X55, B8.8              | 11   | 73181500 | 18% |
| 96132819 | Eicher Tractor Spring Dowel Sleeve Heavy 4X14Is:5  | 7    | 73182100 | 18% |
| 96132832 | Eicher Tractor Hex Soc Screw M10 * 30 Sfs 2219     | 49   | 73181500 | 18% |
| 96132856 | Eicher Tractor M12 Prevailing Torque Allmetal Nut- | 82   | 73181500 | 18% |
| 96132900 | Eicher Tractor Hshc Screw M12X25,B12.9             | 28   | 73181500 | 18% |
| 96132923 | Eicher Tractor Hex.Screw M14X2X35 (B-10.9)         | 29   | 73181500 | 18% |
| 96132931 | Eicher Tractor Cogged Belt Avx-13-1115             | 414  | 40101290 | 18% |
| 96132960 | Eicher Tractor Bonded Seal M26                     | 141  | 73072100 | 18% |
| 96132996 | Eicher Tractor Elbow 3/4 Union M 14X1.5            | 501  | 73072100 | 18% |
| 96133010 | Eicher Tractor Circlip C-12 Is:3075-1986           | 5    | 73182910 | 18% |
| 96133046 | Eicher Tractor Banjo Bolt 14X1.5 With 2 Holes(222E | 40   | 73181500 | 18% |
| 96133060 | Eicher Tractor Hex Screw 16X1.5X40                 | 46   | 73181500 | 18% |
| 96133101 | Eicher Tractor Hshc Screw M8 X 30, B10.9-Zp        | 13   | 73181500 | 18% |
| 96133113 | Eicher Tractor O Ring 18 X 2                       | 29   | 40169340 | 18% |
| 96133125 | Eicher Tractor O Ring 26 X 5                       | 92   | 40169340 | 18% |
| 96133277 | Eicher Tractor O Ring 25X2.5                       | 18   | 40169320 | 18% |
| 96133332 | Eicher Tractor Hshc Screw M10X35,B10.9-Zpw         | 17   | 73181500 | 18% |
| 96133344 | Eicher Tractor Sealing Washer 30X36,Al             | 10   | 73182990 | 18% |
| 96133368 | Eicher Tractor Hose Clamp Dia 16                   | 15   | 73269099 | 18% |
| 96133370 | Eicher Tractor Hex Screw M14X25                    | 19   | 73181500 | 18% |
| 96133448 | Eicher Tractor Dg Ball Bearing 6013 2Rsr C4 L140   | 573  | 84821012 | 18% |
| 96133450 | Eicher Tractor Dg Ball Bearing 6011.2Rsr. C4.140 F | 697  | 84821012 | 18% |
| 96133460 | Eicher Tractor Hex Nut M10 \$                      | 20   | 73181500 | 18% |
| 96133472 | Eicher Tractor Hex Screw M8X80 \$                  | 18   | 73181500 | 18% |
| 96133484 | Eicher Tractor Hex Nut M8 \$                       | 12   | 73181600 | 18% |
| 96133538 | Eicher Tractor O-Ring 32X2.5 Nbr                   | 14   | 40169320 | 18% |
| 96133540 | Eicher Tractor Hex Bolt M12X1.50X35 Is ;1364-2002  | 19   | 73181500 | 18% |
| 96133575 | Eicher Tractor Cyll. Roller Brg Nj209              | 896  | 84822090 | 18% |
| 96133599 | Eicher Tractor Brg 6306                            | 396  | 84822090 | 18% |
| 96133605 | Eicher Tractor Trb 32013                           | 1958 | 84822000 | 18% |
| 96133617 | Eicher Tractor Crb W/O 35X58.5X33                  | 832  | 84822090 | 18% |
| 96133629 | Eicher Tractor Thrust Brg. 51109 (45X65X14)        | 413  | 84821051 | 18% |
| 96133642 | Eicher Tractor Hex Screw M16X1.5X70 (B 10.9 Bp)    | 62   | 73181500 | 18% |
| 96133666 | Eicher Tractor Ball Bearing 6212 Zr-Nbr            | 654  | 84822090 | 18% |
| 96133680 | Eicher Tractor Nrb (B45X53X28)                     | 238  | 84822090 | 18% |
| 96133691 | Eicher Tractor Nrb (Bb 50X57X36)                   | 255  | 84822090 | 18% |
| 96133710 | Eicher Tractor Circlip Heavy A45 Is-3075           | 21   | 73182910 | 18% |
| 96133721 | Eicher Tractor Circlip Heavy A50 Is-3075           | 29   | 73182910 | 18% |
| 96133745 | Eicher Tractor Snap Ring Sp 45 Din5417             | 20   | 73182990 | 18% |
| 96133757 | Eicher Tractor Circlip A35 Light Is-3075           | 12   | 73182910 | 18% |
| 96133769 | Eicher Tractor Circlip Heavy A65 Is: 3075          | 68   | 73182910 | 18% |
| 96133770 | Eicher Tractor Flange Bolt M16 X60 B10.9,Din-6921  | 54   | 73181500 | 18% |
| 96133782 | Eicher Tractor Flange Bolt M14X50 B10.9 Din-6921   | 38   | 73181500 | 18% |
| 96133794 | Eicher Tractor Flange Bolt M12X110 ,B 10.9,Din-692 | 51   | 73181500 | 18% |
| 96133812 | Eicher Tractor O Ring 50.47X2.62                   | 48   | 40169340 | 18% |
| 96133824 | Eicher Tractor O Ring 24X4                         | 38   | 40169340 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 96133836 | Eicher Tractor Hex Nut M14X1.5 ,B-10               | 22   | 73181500 | 18% |
| 96133861 | Eicher Tractor M8 X 12 Countersunk Head Screw, Is: | 7    | 73181500 | 18% |
| 96133873 | Eicher Tractor Hshc ,M 8*20                        | 8    | 73181500 | 18% |
| 96133897 | Eicher Tractor Circlip Heavy A 40                  | 27   | 73182910 | 18% |
| 96133940 | Eicher Tractor Trb Rear Shaft 30215X               | 5272 | 84822090 | 18% |
| 96133952 | Eicher Tractor Linch Pin 8X42                      | 42   | 73182100 | 18% |
| 96133964 | Eicher Tractor Punched Washer A20Is2016            | 9    | 73182100 | 18% |
| 96133976 | Eicher Tractor Sealing Cup Din443                  | 21   | 87089900 | 18% |
| 96134002 | Eicher Tractor Hex Bolt M10X60,B10.9,Zp, Es 01 It1 | 19   | 73181500 | 18% |
| 96134026 | Eicher Tractor O-Ring 42X4 Shore A 70 Nbr Es01 It  | 41   | 40169340 | 18% |
| 96134075 | Eicher Tractor Hex Screw M8X85, B8.8Zp             | 18   | 73181500 | 18% |
| 96134099 | Eicher Tractor Nyloc Nut M16X1.5 -Din985-8G        | 90   | 73181500 | 18% |
| 96134117 | Eicher Tractor Circlip A 45 Heavy                  | 41   | 73182910 | 18% |
| 96134129 | Eicher Tractor Punch Washer B22-Zp                 | 11   | 73182100 | 18% |
| 96134180 | Eicher Tractor Circlip Heavy B-30                  | 12   | 73182910 | 18% |
| 96134208 | Eicher Tractor O Ring 44.12*2.62                   | 15   | 40169320 | 18% |
| 96134233 | Eicher Tractor Du Bush 18*20*20Du                  | 124  | 87089900 | 18% |
| 96134245 | Eicher Tractor Hex Screw M8X55,B8.8,Zp, Es 01 It19 | 11   | 73181500 | 18% |
| 96134270 | Eicher Tractor Needle Cage Nw 264026               | 576  | 84824000 | 18% |
| 96134282 | Eicher Tractor Taper Roller Bearing 32014X         | 3040 | 84822090 | 18% |
| 96134294 | Eicher Tractor Hex Screw M16X1.5X50                | 41   | 73181500 | 18% |
| 96134300 | Eicher Tractor Ball Dia 20 Din 5401                | 104  | 84829119 | 18% |
| 96134324 | Eicher Tractor Hex Nut M12,B10,Zp,(Is 1364-1982)   | 8    | 73181500 | 18% |
| 96134336 | Eicher Tractor Sealing Cup Ø30 - Din443            | 25   | 87089900 | 18% |
| 96134361 | Eicher Tractor Snap Ring Sp 55X1.7,Din-5417        | 23   | 73182990 | 18% |
| 96134373 | Eicher Tractor Snap Ring Br21 Din5417              | 12   | 73182990 | 18% |
| 96134397 | Eicher Tractor Hshc Screw M14X40, B12.9            | 53   | 73181500 | 18% |
| 96134415 | Eicher Tractor Spring Dowel Light Ø3.5X50 Din-1481 | 8    | 73182100 | 18% |
| 96134452 | Eicher Tractor Punched Washer A3.4,Zp              | 34   | 73182100 | 18% |
| 96134464 | Eicher Tractor Hex Screw M20X2.5X65                | 97   | 73181500 | 18% |
| 96134476 | Eicher Tractor Machined Washer 21                  | 10   | 73182100 | 18% |
| 96134488 | Eicher Tractor Hex Nut M8 Lh B12.9 Bp Is:2269      | 8    | 73181500 | 18% |
| 96134506 | Eicher Tractor Hex Screw M12X55,B10.9,Bp,          | 24   | 73181500 | 18% |
| 96134567 | Eicher Tractor Hshc Screw M12X35, B12.9 Zn,        | 32   | 73181500 | 18% |
| 96134579 | Eicher Tractor Hshc Screw M12X55,B12.9 Zn,         | 44   | 73181500 | 18% |
| 96134592 | Eicher Tractor Hex Screw M20X40, B8.8 Zp           | 76   | 73181500 | 18% |
| 96134737 | Eicher Tractor M12 X 70 Hexbolt,Is:1364-1967       | 27   | 73181500 | 18% |
| 96134749 | Eicher Tractor Circlip Light B85                   | 46   | 73182910 | 18% |
| 96134774 | Eicher Tractor Bearing 6009                        | 693  | 84822090 | 18% |
| 96134786 | Eicher Tractor Circlip Heavy B75                   | 93   | 73182910 | 18% |
| 96134798 | Eicher Tractor Circlip                             | 13   | 73182910 | 18% |
| 96134816 | Eicher Tractor Hshc Screw M12 X 20 B8.8            | 21   | 73181500 | 18% |
| 96134841 | Eicher Tractor Hshc Screw M20X45, B12.9 Zn         | 119  | 73181500 | 18% |
| 96134853 | Eicher Tractor Hex Bolt M20X80,B8.8,Zn             | 153  | 73181500 | 18% |
| 96134889 | Eicher Tractor Nut-Front Whhel                     | 128  | 87087000 | 18% |
| 96134920 | Eicher Tractor Circlip B41*1.75 Din - 472 (Mod)    | 13   | 73182910 | 18% |
| 96134932 | Eicher Tractor Hex Bolt M14X1.5X85 (B 10.9 Bp)     | 66   | 73181500 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 96134956 | Eicher Tractor Flanged Hex Screw M16X1.5X35,       | 65   | 73181500 | 18% |
| 96135171 | Eicher Tractor Flange Hex Screw M8X1.25X25         | 10   | 73181500 | 18% |
| 96135208 | Eicher Tractor O-Ring 21.95*1.78                   | 87   | 40169320 | 18% |
| 96135237 | Eicher Tractor Hex Flange Bolt M6X12,B8.8,Bp(Is:15 | 4    | 73181500 | 18% |
| 96135249 | Eicher Tractor Circlip A-17 Heavy 1.5              | 7    | 73182910 | 18% |
| 96135262 | Eicher Tractor Hsch Screw M6X20                    | 5    | 73181500 | 18% |
| 96135274 | Eicher Tractor Hex Screw M16X2X60,B8.8,Zp          | 54   | 73181500 | 18% |
| 96135286 | Eicher Tractor O-Ring 15.3 X 2.2 Nbr Shore A70     | 32   | 40169320 | 18% |
| 96135304 | Eicher Tractor O-Ring 14 X 1.78 Nbr Shore A70      | 65   | 40169320 | 18% |
| 96135341 | Eicher Tractor Hshc Screw M16X50, B10.9, Zp, Is:22 | 229  | 73181500 | 18% |
| 96135353 | Eicher Tractor Nyloc Nut M16X1.5 -Din985-8-Zp      | 126  | 73181500 | 18% |
| 96135365 | Eicher Tractor Sealing Washer 18X24:3175,Al        | 6    | 73182990 | 18% |
| 96135419 | Eicher Tractor Solenoid Switch                     | 2493 | 84099941 | 28% |
| 96135420 | Eicher Tractor Solenoid Switch                     | 2493 | 84099941 | 28% |
| 96135432 | Eicher Tractor Cross Recessed Pan Hd.Screw M6X12   | 3    | 73181500 | 18% |
| 96135444 | Eicher Tractor Jacket Brg Bush                     | 182  | 87089400 | 18% |
| 96135450 | Eicher Tractor Hex Flange Bolt M12X35 8.8 Zn Is155 | 22   | 73181500 | 18% |
| 96135493 | Eicher Tractor Flange Screw M8X20                  | 8    | 73181500 | 18% |
| 96135584 | Eicher Tractor Hex Flange Bolt M12X30 8.8 Zn Is155 | 18   | 73181500 | 18% |
| 96135602 | Eicher Tractor Split Pin 2.5X36                    | 3    | 73182100 | 18% |
| 96135614 | Eicher Tractor Hex Bolt M12X65,B10.9 Bp,           | 59   | 73181500 | 18% |
| 96135626 | Eicher Tractor Hex Screw M14X2X60 (B-10.9), Zn     | 45   | 73181500 | 18% |
| 96135640 | Eicher Tractor Hex Flange Nut M12, A8, Zp Is:1558  | 12   | 73181500 | 18% |
| 96135651 | Eicher Tractor Hex Flange Nut M10, A8, Zp Is:1558  | 8    | 73181500 | 18% |
| 96135663 | Eicher Tractor O Ring 47.5X5.33 Nbr Shore A70 Es01 | 38   | 40169320 | 18% |
| 96135675 | Eicher Tractor Hex Socket Head Grub Screw Fdp M8X2 | 26   | 87089900 | 18% |
| 96135699 | Eicher Tractor Hex Bolt M10X16,B8.8,Zp,            | 9    | 73181500 | 18% |
| 96135717 | Eicher Tractor Hex Screw M12X1.25X25 B10.9 (White) | 24   | 73181500 | 18% |
| 96135729 | Eicher Tractor Hex Screw M14X1.5X25 B10.9 Zpw      | 28   | 73181500 | 18% |
| 96135766 | Eicher Tractor Circlip B-58 Light                  | 25   | 73182910 | 18% |
| 96135778 | Eicher Tractor Circlip B-85 Heavy                  | 87   | 73182910 | 18% |
| 96135808 | Eicher Tractor Sealing Washer 24X29                | 6    | 73182990 | 18% |
| 96135821 | Eicher Tractor Circlip 15 Type E For Shaft-3075.1. | 12   | 73182910 | 18% |
| 96135826 | Eicher Tractor O-Ring 15.3X2.2 Nbr , Shore A 70 ,  | 39   | 40169320 | 18% |
| 96135869 | Eicher Tractor O-Ring 11.8X1.8 Nbr Shore 70        | 15   | 40169320 | 18% |
| 96135870 | Eicher Tractor Hex Thin Nut M18X1.5,6H, B8 Zp      | 27   | 73181500 | 18% |
| 96135900 | Eicher Tractor Spring Dowel Sleeve Heavy 8X65 Is:5 | 29   | 73182100 | 18% |
| 96135924 | Eicher Tractor Oil Seal 50X80X10                   | 111  | 40169330 | 18% |
| 96135948 | Eicher Tractor Hexagon Flange Screw M14X2X35,B10.9 | 35   | 73181500 | 18% |
| 96136114 | Eicher Tractor Hex Flange Bolt M10X1.5X20          | 14   | 73181500 | 18% |
| 96136138 | Eicher Tractor Hshc Screw M6X12,B12.9,Bp Is:2269-1 | 4    | 73181500 | 18% |
| 96136140 | Eicher Tractor Hex Flange Screw M10X25 (Is 15582)  | 11   | 73181500 | 18% |
| 96136151 | Eicher Tractor Hex Flange Screw M12X25,B10.9 Zpw   | 24   | 73181500 | 18% |
| 96136163 | Eicher Tractor Circlip A-20 Heahy                  | 14   | 73182910 | 18% |
| 96136175 | Eicher Tractor Circlip A-28 Heavy                  | 20   | 73182990 | 18% |
| 96136187 | Eicher Tractor Circlip A-12 Light (K15X21X15)      | 3    | 73182990 | 18% |
| 96136199 | Eicher Tractor Circlip B-55 Heavy                  | 36   | 73182910 | 18% |



|          |  |     |          |     |
|----------|--|-----|----------|-----|
| 96136205 | Eicher Tractor Circlip B-52 Heahy                  | 28  | 73182990 | 18% |
| 96136291 | Eicher Tractor Spring Dowel Sleeve Heavy 6X28 Is:5 | 23  | 73182100 | 18% |
| 96136310 | Eicher Tractor Bulb, Bay 15D, 12V, 21/5W (Optima M | 53  | 85122010 | 18% |
| 96136321 | Eicher Tractor Bulb, Bay 15S 12V, 21W (Optima Mak  | 43  | 85122010 | 18% |
| 96136394 | Eicher Tractor Oil Seal 38X25X7 (4Wd)              | 259 | 40169330 | 18% |
| 96136424 | Eicher Tractor Hex Screw M12X1.5X25-B 8.8          | 14  | 73181500 | 18% |
| 96136461 | Eicher Tractor Hose Clamps A65 Width 8Mm           | 21  | 73269099 | 18% |
| 96136473 | Eicher Tractor Punched Washer A16 Is:2016          | 6   | 73182100 | 18% |
| 96136515 | Eicher Tractor Conical Hd. Grease Nipple Am6X1     | 10  | 87089900 | 18% |
| 96136540 | Eicher Tractor Worm Drive Hose Clamp 25            | 21  | 73269099 | 18% |
| 96136564 | Eicher Tractor Circlip Heavy A-58                  | 242 | 73182910 | 18% |
| 96136692 | Eicher Tractor Bonded Seal M16                     | 79  | 87089900 | 18% |
| 96136722 | Eicher Tractor Hshc Screw M6X55 12.9 Bp Is: 2269-2 | 12  | 73181500 | 18% |
| 96136734 | Eicher Tractor Hex Bolt M18X70-10.9-Zpw            | 127 | 73181500 | 18% |
| 96136746 | Eicher Tractor Hshc Bolt M10X50- 10.9-Zpw          | 25  | 73181500 | 18% |
| 96136760 | Eicher Tractor Pressure Spring                     | 51  | 73202000 | 18% |
| 96136795 | Eicher Tractor Slot Cheese Head Screw M4X20        | 4   | 73181500 | 18% |
| 96136813 | Eicher Tractor Hex Nut M4. Is:1364(P3)-1992-Zn     | 2   | 73181600 | 18% |
| 96136825 | Eicher Tractor Flange Bolt M10X35                  | 19  | 73181500 | 18% |
| 96136862 | Eicher Tractor Hsch Screw M10X1.5X20               | 14  | 87089900 | 18% |
| 96137780 | Eicher Tractor Hshc Screw M20X60,B12.9 Zn,         | 163 | 73181500 | 18% |
| 96138305 | Eicher Tractor Hex Bolt M20X70-B10.9-Bp            | 192 | 73181500 | 18% |
| 96138317 | Eicher Tractor Hex Bolt M10X90,B8.8,Zpw            | 31  | 73181500 | 18% |
| 96138500 | Eicher Tractor Hex Bolt M16X2X50                   | 64  | 73181500 | 18% |
| 96138524 | Eicher Tractor Hose Clamp F16, Ss3-Sae J1508       | 37  | 73269099 | 18% |
| 96138536 | Eicher Tractor Hose Clamp F25, Ss3-Sae J1508       | 44  | 73269099 | 18% |
| 96138548 | Eicher Tractor Hose Clamp F55, Ss3-Sae J1508       | 44  | 73269099 | 18% |
| 96138550 | Eicher Tractor Hose Clamp F60, Ss3-Sae J1508       | 48  | 73269099 | 18% |
| 96138561 | Eicher Tractor Hose Clamp F70,Ss3-Sae J1508        | 51  | 73269099 | 18% |
| 96138573 | Eicher Tractor Hose Clamp F80, Ss3-Sae J1508       | 53  | 73269099 | 18% |
| 96138585 | Eicher Tractor Hose Clamp F35, Ss3-Sae J1508       | 44  | 73269099 | 18% |
| 96138597 | Eicher Tractor Hose Clamp F45, Ss3-Sae J1508       | 52  | 73269099 | 18% |
| 96138652 | Eicher Tractor Hshc Screw M20X2.5X65               | 186 | 73181500 | 18% |
| 96138663 | Eicher Tractor Screw St-4.2X16                     | 2   | 73181500 | 18% |
| 96138687 | Eicher Tractor Hshc Screw Is:2269-1981 M8X70-12.9- | 23  | 73181500 | 18% |
| 96138720 | Eicher Tractor Nylock Nut M12                      | 29  | 73181500 | 18% |
| 96138731 | Eicher Tractor Socket Button Head Screw M8X20 1.25 | 14  | 73181500 | 18% |
| 96138743 | Eicher Tractor St Screw 4.2 X 9.5                  | 3   | 73181500 | 18% |
| 96138925 | Eicher Tractor Pop Up Rivet 2 X 6                  | 2   | 73182100 | 18% |
| 96150100 | Eicher Tractor Disc Brake Lining(4) Wth Rivets(24) | 303 | 87083900 | 18% |
| 96150111 | Eicher Tractor Fric Lining F11"Clutch(2) Wth Rivet | 380 | 87089300 | 18% |
| 96150283 | Eicher Tractor Cogged Belt Avx-10 (1100Mm)         | 248 | 40169990 | 18% |
| 96150354 | Eicher Tractor Oil Seal 70*90*10 With Dust Lip     | 166 | 40169330 | 18% |
| 96150391 | Eicher Tractor Belt Xv 13X1135                     | 401 | 40101290 | 18% |
| 96150445 | Eicher Tractor Hose Clip A100                      | 48  | 40093100 | 18% |
| 96150470 | Eicher Tractor O Ring 87X2 Nbr                     | 122 | 40169320 | 18% |
| 96150585 | Eicher Tractor Oil Seal 25X33X4 Is:5129 - 1979     | 116 | 40169330 | 18% |



|          |  |     |          |     |
|----------|--|-----|----------|-----|
| 96150597 | Eicher Tractor Oil Seal 65X90X10                   | 424 | 40169330 | 18% |
| 96150615 | Eicher Tractor Bonded Seal                         | 197 | 40169390 | 18% |
| 96150640 | Eicher Tractor Bonded Seal M12                     | 198 | 40169320 | 18% |
| 96150652 | Eicher Tractor Bonded Seal M14                     | 89  | 40169390 | 18% |
| 96150664 | Eicher Tractor Oil Seal 55X70X8 Is:5129 - 1979     | 269 | 40169330 | 18% |
| 96150688 | Eicher Tractor Hex Bolt M12X105                    | 48  | 73181500 | 18% |
| 96150690 | Eicher Tractor O Ring                              | 16  | 40169340 | 18% |
| 96150730 | Eicher Tractor Ball Bearing 6309Rs1                | 780 | 84822090 | 18% |
| 96150767 | Eicher Tractor Sealing Cup Dia 20 X 6              | 12  | 87089900 | 18% |
| 96150779 | Eicher Tractor O Ring 30*2.5                       | 19  | 40169320 | 18% |
| 96150780 | Eicher Tractor Circlip A30 Heavy                   | 21  | 73182910 | 18% |
| 96150834 | Eicher Tractor Oil Seal 80X110X10-Trallborg        | 570 | 40169330 | 18% |
| 96150871 | Eicher Tractor O Ring 23.6*2.9                     | 17  | 40169320 | 18% |
| 96150901 | Eicher Tractor O Ring 7.59X2.62                    | 24  | 40169320 | 18% |
| 96150913 | Eicher Tractor Back Up Ring                        | 189 | 40169990 | 18% |
| 96150925 | Eicher Tractor O Ring 12.42X1.78 N90 Nbr           | 16  | 40169320 | 18% |
| 96150949 | Eicher Tractor O-Ring 36.09X3.53 Shore A 70 Nbr E  | 52  | 40169340 | 18% |
| 96150950 | Eicher Tractor Steel Ball Dia 12, Grade 20 Is:2898 | 8   | 84829119 | 18% |
| 96151206 | Eicher Tractor O'Ring 34.59X2.62                   | 27  | 40169320 | 18% |
| 96151243 | Eicher Tractor O Ring 40.87X3.53 N70               | 49  | 40169320 | 18% |
| 96151280 | Eicher Tractor Oring 12.37*2.62 Nrb-70 Es01 It 31: | 9   | 40169320 | 18% |
| 96151292 | Eicher Tractor O Ring 12X2 Fkm Sh 70 Green Es01 It | 102 | 40169320 | 18% |
| 96151309 | Eicher Tractor O Ring 14X1.78 Shore A70 Nbr Es01It | 56  | 40169320 | 18% |
| 96151310 | Eicher Tractor Backup Ring 14X17.5X1.4             | 236 | 40169990 | 18% |
| 96151322 | Eicher Tractor Hose Clip A-25                      | 128 | 40093100 | 18% |
| 96151336 | Eicher Tractor Conical Grease Nipple Am6X1         | 21  | 87089900 | 18% |
| 96151350 | Eicher Tractor Bonded Seal M8                      | 43  | 87089900 | 18% |
| 96151383 | Eicher Tractor Glassy Front Light - Rt             | 75  | 85122010 | 18% |
| 96151395 | Eicher Tractor Glassy Tail Light - Rt              | 171 | 85123010 | 18% |
| 96151450 | Eicher Tractor Rubber Bellow                       | 64  | 40169320 | 18% |
| 96151474 | Eicher Tractor Glassy Tail Light - Lt              | 171 | 85123010 | 18% |
| 96151530 | Eicher Tractor V—Ring, Type A , Shaft Diameter - 3 | 232 | 87084000 | 18% |
| 96151553 | Eicher Tractor Circlip E 15 Is 3075 (Part 3)       | 14  | 73182910 | 18% |
| 96151607 | Eicher Tractor Snap_Ring                           | 13  | 73182990 | 18% |
| 96151619 | Eicher Tractor Ball_Bearing                        | 240 | 84828000 | 18% |
| 96151620 | Eicher Tractor Ring Nut                            | 355 | 73181600 | 18% |
| 96151632 | Eicher Tractor Dummy Plug-Pto                      | 101 | 73182990 | 18% |
| 96151644 | Eicher Tractor Bolt                                | 15  | 73181500 | 18% |
| 96151656 | Eicher Tractor O Ring                              | 18  | 87089900 | 18% |
| 96151668 | Eicher Tractor Snap Ring-External                  | 19  | 73182910 | 18% |
| 96151670 | Eicher Tractor Stud                                | 21  | 73181900 | 18% |
| 96151681 | Eicher Tractor Spring Washer Ixdod 10.5 X 18 - (C/ | 3   | 73182200 | 18% |
| 96151693 | Eicher Tractor Thrust Washer                       | 8   | 87089900 | 18% |
| 96151700 | Eicher Tractor Nut                                 | 8   | 87085000 | 18% |
| 96151711 | Eicher Tractor O Ring                              | 56  | 40169320 | 18% |
| 96151723 | Eicher Tractor O Ring                              | 57  | 40169320 | 18% |
| 96151735 | Eicher Tractor Ball_Bearing                        | 95  | 84828000 | 18% |



|          |  |      |          |     |
|----------|--|------|----------|-----|
| 96151747 | Eicher Tractor Needle Roller Bearing     | 132  | 87084000 | 18% |
| 96151759 | Eicher Tractor Seal_Washer               | 39   | 87085000 | 18% |
| 96151760 | Eicher Tractor O_Ring                    | 35   | 87084000 | 18% |
| 96151772 | Eicher Tractor Bolt                      | 75   | 73181500 | 18% |
| 96151784 | Eicher Tractor Ball_Bearing              | 110  | 84828000 | 18% |
| 96151796 | Eicher Tractor Flange Bolt               | 6    | 73181500 | 18% |
| 96151802 | Eicher Tractor Bolt                      | 19   | 73181500 | 18% |
| 96151814 | Eicher Tractor Bolt With Washer          | 77   | 73181500 | 18% |
| 96151826 | Eicher Tractor Ball_Bearing              | 441  | 84828000 | 18% |
| 96151838 | Eicher Tractor Shim                      | 19   | 73182200 | 18% |
| 96151840 | Eicher Tractor Shim                      | 22   | 73182200 | 18% |
| 96151851 | Eicher Tractor Ball_Bearing              | 625  | 84828000 | 18% |
| 96151863 | Eicher Tractor Washer,Diff Pinion        | 25   | 73182200 | 18% |
| 96151875 | Eicher Tractor Shim                      | 17   | 73182200 | 18% |
| 96151887 | Eicher Tractor Shim                      | 15   | 73182200 | 18% |
| 96151899 | Eicher Tractor Nut                       | 6    | 73181600 | 18% |
| 96151905 | Eicher Tractor Washer, Seal              | 72   | 87085000 | 18% |
| 96151917 | Eicher Tractor Shim                      | 20   | 73182200 | 18% |
| 96151929 | Eicher Tractor Stud                      | 25   | 49119990 | 18% |
| 96151930 | Eicher Tractor Shim                      | 12   | 73182200 | 18% |
| 96151942 | Eicher Tractor Washer Idxod - 12.5X22    | 3    | 73182200 | 18% |
| 96151954 | Eicher Tractor Ball_Bearing              | 190  | 84828000 | 18% |
| 96151966 | Eicher Tractor Ball_Bearing              | 345  | 84828000 | 18% |
| 96151978 | Eicher Tractor Flange Bolt MOX.5X25      | 11   | 73181500 | 18% |
| 96151980 | Eicher Tractor Hexagon Head Bolt-M6      | 4    | 73181500 | 18% |
| 96151991 | Eicher Tractor Spring Washer Idxod 6.5X2 | 2    | 73182200 | 18% |
| 96152004 | Eicher Tractor Ball_Bearing              | 564  | 84828000 | 18% |
| 96152016 | Eicher Tractor Spring Washer             | 2    | 73182200 | 18% |
| 96152028 | Eicher Tractor Retaining Ring External   | 16   | 73182910 | 18% |
| 96152030 | Eicher Tractor Ball Bearing-6405         | 1112 | 87089400 | 18% |
| 96152041 | Eicher Tractor Lock Nut                  | 174  | 73181600 | 18% |
| 96152053 | Eicher Tractor M8X30 Bolt                | 5    | 73181500 | 18% |
| 96152065 | Eicher Tractor Bolt                      | 68   | 73181500 | 18% |
| 96152077 | Eicher Tractor O_Ring                    | 34   | 87089900 | 18% |
| 96152089 | Eicher Tractor O_Ring                    | 35   | 87089900 | 18% |
| 96152090 | Eicher Tractor O_Ring                    | 81   | 87089900 | 18% |
| 96152107 | Eicher Tractor Bolt, Hexagen             | 21   | 73181500 | 18% |
| 96152119 | Eicher Tractor O_Ring                    | 16   | 87089900 | 18% |
| 96152120 | Eicher Tractor Bolt, Joint               | 248  | 73181500 | 18% |
| 96152132 | Eicher Tractor Flange Nut                | 27   | 73181600 | 18% |
| 96152144 | Eicher Tractor Snap Ring                 | 3    | 73182910 | 18% |
| 96152156 | Eicher Tractor Socket Head Screw         | 4    | 73181500 | 18% |
| 96152168 | Eicher Tractor Socket Head Screw         | 8    | 73181500 | 18% |
| 96152170 | Eicher Tractor Washer Lock               | 22   | 73182990 | 18% |
| 96152181 | Eicher Tractor O_Ring                    | 19   | 87089900 | 18% |
| 96152193 | Eicher Tractor Lock Washer               | 51   | 87089900 | 18% |
| 96152200 | Eicher Tractor Bolt Spl - M10            | 167  | 73181110 | 18% |



|          |  |     |          |     |
|----------|--|-----|----------|-----|
| 96152211 | Eicher Tractor Nut Hex                             | 7   | 73181600 | 18% |
| 96152223 | Eicher Tractor Flat Washer-M16-17.5X30X3.2T Zn     | 17  | 73182990 | 18% |
| 96152235 | Eicher Tractor Hex Nut - M10X1.5                   | 6   | 87089900 | 18% |
| 96152247 | Eicher Tractor Bolt                                | 80  | 73181500 | 18% |
| 96152259 | Eicher Tractor Nut                                 | 16  | 73181110 | 18% |
| 96152260 | Eicher Tractor Flat Washer                         | 6   | 73182100 | 18% |
| 96152272 | Eicher Tractor Hex Bolt - M8X1.25 -35L             | 10  | 73181500 | 18% |
| 96152284 | Eicher Tractor Bolt Hex(112082025-2500)            | 10  | 73181500 | 18% |
| 96152296 | Eicher Tractor Bolt (69040808)                     | 20  | 73181110 | 18% |
| 96152302 | Eicher Tractor Snap_Ring                           | 19  | 73182990 | 18% |
| 96152314 | Eicher Tractor Shim-Diff Pinion                    | 3   | 73182200 | 18% |
| 96152326 | Eicher Tractor U Nut                               | 24  | 73181500 | 18% |
| 96152338 | Eicher Tractor O_Ring                              | 20  | 87089900 | 18% |
| 96152340 | Eicher Tractor Snap Ring                           | 5   | 73182910 | 18% |
| 96152351 | Eicher Tractor Bolt                                | 33  | 73181500 | 18% |
| 96152363 | Eicher Tractor Bolt Stud                           | 27  | 73181190 | 18% |
| 96152375 | Eicher Tractor Washer                              | 1   | 73182100 | 18% |
| 96152387 | Eicher Tractor Snap Ring                           | 6   | 73182990 | 18% |
| 96152399 | Eicher Tractor Spring Lock Washer Ixdod14.2X24.1 - | 3   | 73182100 | 18% |
| 96152405 | Eicher Tractor Plain Machined Washer R-M 8         | 2   | 73182100 | 18% |
| 96152417 | Eicher Tractor Snap Ring                           | 4   | 73182910 | 18% |
| 96152429 | Eicher Tractor Bolt                                | 28  | 73181500 | 18% |
| 96152430 | Eicher Tractor Bolt-M10X1.25X30                    | 18  | 73181500 | 18% |
| 96152442 | Eicher Tractor Washer Lock                         | 2   | 73182990 | 18% |
| 96152454 | Eicher Tractor Nut Hex                             | 3   | 73181600 | 18% |
| 96152466 | Eicher Tractor Bolt Hex                            | 3   | 73181500 | 18% |
| 96152478 | Eicher Tractor Bolt-M10X1.25X18                    | 13  | 73181500 | 18% |
| 96152480 | Eicher Tractor Bolt, Joint                         | 202 | 73181500 | 18% |
| 96152491 | Eicher Tractor Bolt-M10X1.25X20                    | 14  | 73181500 | 18% |
| 96152508 | Eicher Tractor O-Ring                              | 20  | 87085000 | 18% |
| 96152510 | Eicher Tractor O_Ring                              | 29  | 84138190 | 18% |
| 96152521 | Eicher Tractor Hose Clamp                          | 56  | 73269099 | 18% |
| 96152533 | Eicher Tractor M8 Hex Bolt Length 20(112082020-250 | 5   | 73181190 | 18% |
| 96152545 | Eicher Tractor Bolt Hex                            | 4   | 73181500 | 18% |
| 96152557 | Eicher Tractor Hose Clip                           | 49  | 73079290 | 18% |
| 96152569 | Eicher Tractor O' Ring -I. D 15.6 X178             | 12  | 87089400 | 18% |
| 96152570 | Eicher Tractor Bolt - Pivot                        | 161 | 73181110 | 18% |
| 96152582 | Eicher Tractor O_Ring                              | 19  | 87085000 | 18% |
| 96152594 | Eicher Tractor Grease Nipple90 Deg                 | 16  | 87085000 | 18% |
| 96152600 | Eicher Tractor Pilot Bolt                          | 608 | 73181110 | 18% |
| 96152612 | Eicher Tractor O_Ring                              | 20  | 87089300 | 18% |
| 96152624 | Eicher Tractor Thin Nut                            | 7   | 73181600 | 18% |
| 96152636 | Eicher Tractor Bolt Hex                            | 4   | 73181500 | 18% |
| 96152648 | Eicher Tractor Bolt                                | 163 | 73181500 | 18% |
| 96152650 | Eicher Tractor Flat Washer                         | 9   | 73181500 | 18% |
| 96152661 | Eicher Tractor Nut Hex                             | 9   | 73181600 | 18% |
| 96152673 | Eicher Tractor Bolt                                | 13  | 73181500 | 18% |





|          |  |      |          |     |
|----------|--|------|----------|-----|
| 96152685 | Eicher Tractor O_Ring                              | 35   | 87085000 | 18% |
| 96152697 | Eicher Tractor Ball Bearing-6204 2Rs               | 203  | 87089400 | 18% |
| 96152703 | Eicher Tractor O Ring                              | 58   | 40169320 | 18% |
| 96152715 | Eicher Tractor O_Ring                              | 19   | 87085000 | 18% |
| 96152727 | Eicher Tractor Needle_Bearing                      | 448  | 84828000 | 18% |
| 96152739 | Eicher Tractor Ball_Bearing                        | 227  | 84828000 | 18% |
| 96152740 | Eicher Tractor Needle Cage Bearing K 35X40X22(B601 | 185  | 84824000 | 18% |
| 96152752 | Eicher Tractor Needle Bearing                      | 525  | 84828000 | 18% |
| 96152764 | Eicher Tractor Thrust Washer                       | 11   | 87089900 | 18% |
| 96152776 | Eicher Tractor Sealing Washer                      | 65   | 87085000 | 18% |
| 96152788 | Eicher Tractor O Ring                              | 57   | 40169320 | 18% |
| 96152790 | Eicher Tractor Flange Bolt - M10X1.5X30            | 13   | 73181500 | 18% |
| 96152806 | Eicher Tractor Clamp                               | 131  | 87085000 | 18% |
| 96152818 | Eicher Tractor Bolt Hex                            | 3    | 73181500 | 18% |
| 96152820 | Eicher Tractor Flat Washer                         | 2    | 73182100 | 18% |
| 96152831 | Eicher Tractor Felt Washer                         | 18   | 59119090 | 12% |
| 96152843 | Eicher Tractor Hose Clamp                          | 19   | 87089400 | 18% |
| 96152855 | Eicher Tractor Bolt                                | 17   | 73181500 | 18% |
| 96152867 | Eicher Tractor Ball Bearing                        | 70   | 84828000 | 18% |
| 96152879 | Eicher Tractor Hex Bolt                            | 17   | 73181500 | 18% |
| 96152880 | Eicher Tractor Clutch Release Bearing              | 1085 | 87089400 | 18% |
| 96152892 | Eicher Tractor Adoptor With Hex Nut                | 103  | 73181500 | 18% |
| 96152909 | Eicher Tractor Bolt                                | 124  | 73181500 | 18% |
| 96152910 | Eicher Tractor Ball Bearing - (C/A)                | 164  | 84828000 | 18% |
| 96152922 | Eicher Tractor Bolt                                | 79   | 73181500 | 18% |
| 96152934 | Eicher Tractor Plug                                | 31   | 40169990 | 18% |
| 96152946 | Eicher Tractor Shim                                | 9    | 73182200 | 18% |
| 96152958 | Eicher Tractor Ball Bearing - (C/A)                | 356  | 84828000 | 18% |
| 96152960 | Eicher Tractor Shim (Comp)                         | 10   | 73182200 | 18% |
| 96152971 | Eicher Tractor Bearing, Taper Roller               | 385  | 84822011 | 18% |
| 96152983 | Eicher Tractor Washer                              | 18   | 73182200 | 18% |
| 96152995 | Eicher Tractor Bever Gear, 40                      | 4745 | 87084000 | 18% |
| 96153008 | Eicher Tractor Shim (Comp)                         | 7    | 73182200 | 18% |
| 96153010 | Eicher Tractor O_Ring                              | 35   | 87085000 | 18% |
| 96153021 | Eicher Tractor Snap_Ring                           | 28   | 73182990 | 18% |
| 96153033 | Eicher Tractor Adjusting Bolt                      | 33   | 73181500 | 18% |
| 96153045 | Eicher Tractor Shim (Comp)                         | 10   | 73182200 | 18% |
| 96153057 | Eicher Tractor Shim                                | 12   | 73182200 | 18% |
| 96153069 | Eicher Tractor Shim                                | 11   | 73182200 | 18% |
| 96153070 | Eicher Tractor Ball_Bearing                        | 211  | 84828000 | 18% |
| 96153082 | Eicher Tractor O_Ring                              | 35   | 87085000 | 18% |
| 96153094 | Eicher Tractor Snap_Ring                           | 25   | 73182990 | 18% |
| 96153100 | Eicher Tractor Shim-Diff Pinion                    | 3    | 73182200 | 18% |
| 96153112 | Eicher Tractor Bolt                                | 49   | 73181500 | 18% |
| 96153124 | Eicher Tractor Nut                                 | 45   | 73181500 | 18% |
| 96153136 | Eicher Tractor O_Ring                              | 78   | 87085000 | 18% |
| 96153148 | Eicher Tractor Grease Nipple                       | 28   | 87089900 | 18% |



|          |  |     |          |     |
|----------|--|-----|----------|-----|
| 96153150 | Eicher Tractor Bolt                        | 99  | 73181500 | 18% |
| 96153161 | Eicher Tractor Ball_Bearing                | 430 | 84828000 | 18% |
| 96153173 | Eicher Tractor Shim                        | 7   | 73182200 | 18% |
| 96153185 | Eicher Tractor Shim-Diff-Side Gear         | 8   | 73182200 | 18% |
| 96153197 | Eicher Tractor Shim                        | 6   | 73182200 | 18% |
| 96153203 | Eicher Tractor Seal Washer                 | 82  | 73182200 | 18% |
| 96153215 | Eicher Tractor Shim                        | 14  | 73182200 | 18% |
| 96153227 | Eicher Tractor Shim-Diff-Side Gear         | 7   | 73182200 | 18% |
| 96153239 | Eicher Tractor Bolt-Stopper                | 82  | 73181500 | 18% |
| 96153240 | Eicher Tractor Ball_Bearing                | 178 | 84828000 | 18% |
| 96153264 | Eicher Tractor Shim-Diff-Side Gear         | 8   | 73182200 | 18% |
| 96153276 | Eicher Tractor Nut                         | 13  | 73181600 | 18% |
| 96153288 | Eicher Tractor Shim (Comp)                 | 8   | 73182200 | 18% |
| 96153291 | Eicher Tractor Ubs Bolt                    | 23  | 73181500 | 18% |
| 96153306 | Eicher Tractor O Ring                      | 296 | 87085000 | 18% |
| 96153318 | Eicher Tractor Hex Bolt - M12 X 1.75-110l  | 48  | 73181500 | 18% |
| 96153320 | Eicher Tractor Bearing, Tape Roller        | 477 | 84822011 | 18% |
| 96153331 | Eicher Tractor Shim-Diff Pinion            | 3   | 73182200 | 18% |
| 96153343 | Eicher Tractor O_Ring                      | 77  | 87085000 | 18% |
| 96153355 | Eicher Tractor Shim                        | 11  | 73182200 | 18% |
| 96153367 | Eicher Tractor Shim                        | 12  | 73182200 | 18% |
| 96153379 | Eicher Tractor Shim                        | 6   | 73182200 | 18% |
| 96153380 | Eicher Tractor Nut                         | 148 | 73181500 | 18% |
| 96153392 | Eicher Tractor Washer - Special            | 8   | 73182200 | 18% |
| 96153409 | Eicher Tractor Plain Washer M12            | 2   | 73182100 | 18% |
| 96153410 | Eicher Tractor Belleville Washer           | 15  | 73182200 | 18% |
| 96153422 | Eicher Tractor Nut Hex Nyloc               | 16  | 73181600 | 18% |
| 96153446 | Eicher Tractor Hex Nut - M8X1.25           | 3   | 73181600 | 18% |
| 96153458 | Eicher Tractor Washer                      | 5   | 73182100 | 18% |
| 96153460 | Eicher Tractor Flange Bolt - M10X1.5-20L   | 19  | 73181500 | 18% |
| 96153471 | Eicher Tractor Bolt                        | 21  | 73181500 | 18% |
| 96153483 | Eicher Tractor Nut                         | 14  | 73181500 | 18% |
| 96153495 | Eicher Tractor Lock Washer-M16 - (C/A)     | 5   | 73182200 | 18% |
| 96153501 | Eicher Tractor Hexagon Head Bolt           | 15  | 73181110 | 18% |
| 96153513 | Eicher Tractor Grease_Nipple               | 17  | 87089900 | 18% |
| 96153525 | Eicher Tractor Bolt Fr                     | 133 | 73181500 | 18% |
| 96153537 | Eicher Tractor Bearing-Mcm                 | 91  | 84822012 | 18% |
| 96153549 | Eicher Tractor Thin Nuts Class 4,Is : 1367 | 24  | 73181600 | 18% |
| 96153550 | Eicher Tractor Washer                      | 3   | 73182100 | 18% |
| 96153562 | Eicher Tractor Stud                        | 18  | 73181500 | 18% |
| 96153574 | Eicher Tractor Screw                       | 12  | 73181500 | 18% |
| 96153586 | Eicher Tractor Flat Washer                 | 3   | 73182100 | 18% |
| 96153598 | Eicher Tractor Washer Flat                 | 4   | 73182100 | 18% |
| 96153604 | Eicher Tractor Lock Nut Nylock             | 2   | 73182100 | 18% |
| 96153616 | Eicher Tractor Screw [M6 X 1]              | 5   | 73181110 | 18% |
| 96153628 | Eicher Tractor Washer                      | 4   | 40169350 | 18% |
| 96153630 | Eicher Tractor Hsch Screw M8X20            | 9   | 73181500 | 18% |



|          |   |      |          |     |
|----------|---|------|----------|-----|
| 96153641 | Eicher Tractor Bolt, Flange                         | 31   | 73181500 | 18% |
| 96153653 | Eicher Tractor Hex. Bolt-M10X1.5-20L Zn             | 30   | 87089900 | 18% |
| 96153665 | Eicher Tractor Washer - Rubber                      | 23   | 40091100 | 18% |
| 96153677 | Eicher Tractor Hex Head Bolt (M12)                  | 20   | 73181110 | 18% |
| 96153689 | Eicher Tractor Hex. Bolt-M12X1.75-50L Zn            | 46   | 73181500 | 18% |
| 96153690 | Eicher Tractor Washer                               | 4    | 73181500 | 18% |
| 96153719 | Eicher Tractor Flange Screw                         | 4    | 73181500 | 18% |
| 96153720 | Eicher Tractor Bolt                                 | 3    | 73181500 | 18% |
| 96153732 | Eicher Tractor Nut Hex                              | 2    | 73181600 | 18% |
| 96153744 | Eicher Tractor Pan Head Screw                       | 2    | 73181110 | 18% |
| 96153756 | Eicher Tractor Bolt-M5                              | 2    | 73181110 | 18% |
| 96153768 | Eicher Tractor Washer                               | 1    | 73182100 | 18% |
| 96153770 | Eicher Tractor Flat Washer                          | 1    | 73182100 | 18% |
| 96153781 | Eicher Tractor Crch Screw M5X35,St. Steel           | 17   | 73181500 | 18% |
| 96153793 | Eicher Tractor Bolt Hex(212163080-2500)             | 70   | 73181500 | 18% |
| 96153800 | Eicher Tractor Hexagon Head Bolt M16X2.0 And M16X1  | 38   | 73181110 | 18% |
| 96153811 | Eicher Tractor Screw Hex (1035/245)(102103025-2500) | 15   | 73181500 | 18% |
| 96153823 | Eicher Tractor Bolt M10 X1.5 - 30L(102103030-2500)  | 11   | 73181500 | 18% |
| 96153847 | Eicher Tractor Asher, Plain                         | 23   | 73182100 | 18% |
| 96153859 | Eicher Tractor Bolt Resin                           | 90   | 87089900 | 18% |
| 96153860 | Eicher Tractor Washer, Plain                        | 3    | 40169390 | 18% |
| 96153871 | Eicher Tractor Plain Washer M10                     | 4    | 87089900 | 18% |
| 96153895 | Eicher Tractor Bolt, Adjusting                      | 89   | 73181500 | 18% |
| 96153914 | Eicher Tractor Bolt Hex-M10X1.5-35L(102103035-2500) | 11   | 73181500 | 18% |
| 96153926 | Eicher Tractor Hex Nut                              | 4    | 73181600 | 18% |
| 96153938 | Eicher Tractor Flange Bolt                          | 3    | 73181500 | 18% |
| 96153940 | Eicher Tractor Clamp Breather Mtg                   | 20   | 87089900 | 18% |
| 96153951 | Eicher Tractor Hose Clamp                           | 66   | 84099900 | 28% |
| 96153963 | Eicher Tractor Screw                                | 5    | 73181110 | 18% |
| 96153975 | Eicher Tractor Bolt                                 | 74   | 87085000 | 18% |
| 96153987 | Eicher Tractor Bolt Hex                             | 3    | 73181500 | 18% |
| 96154001 | Eicher Tractor Rubber Washer(Pin Hitch)             | 26   | 87089900 | 18% |
| 96154013 | Eicher Tractor Pin, Connect                         | 710  | 87089900 | 18% |
| 96154025 | Eicher Tractor Joint Pin                            | 31   | 73182990 | 18% |
| 96154037 | Eicher Tractor Pin, Snap                            | 20   | 73182990 | 18% |
| 96154050 | Eicher Tractor Nut                                  | 23   | 73181600 | 18% |
| 96154062 | Eicher Tractor Bolt                                 | 139  | 73181500 | 18% |
| 96154074 | Eicher Tractor Spring Washer                        | 7    | 73181600 | 18% |
| 96154116 | Eicher Tractor Bolt, Washer                         | 60   | 73181500 | 18% |
| 96154141 | Eicher Tractor Bolt                                 | 128  | 73181500 | 18% |
| 96154220 | Eicher Tractor Plain Machined Washer                | 19   | 73182990 | 18% |
| 96154293 | Eicher Tractor B8 Spring Washer- Znco               | 3    | 73182200 | 18% |
| 96154300 | Eicher Tractor Hex Hd Screw M8X16                   | 8    | 73181500 | 18% |
| 96154311 | Eicher Tractor Hex Hd Screw M8X25-Plated- Znco      | 11   | 73181500 | 18% |
| 96154402 | Eicher Tractor Diaphragm Spring                     | 2722 | 73182100 | 18% |
| 96154414 | Eicher Tractor Spring Pin                           | 20   | 73182100 | 18% |
| 96160761 | Eicher Tractor Coolant Castrol Heavy Duty)          | 691  | 27101980 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 96220230 | Eicher Tractor Male Coupler (Housing) Et01-1W      | 4     | 85118000 | 28% |
| 96220289 | Eicher Tractor Solenoid Switch                     | 4033  | 84099941 | 28% |
| 96220290 | Eicher Tractor Solenoid Switch                     | 2493  | 84099941 | 28% |
| 96220307 | Eicher Tractor Solenoid Switch                     | 2493  | 84099941 | 28% |
| 96230143 | Eicher Tractor Loctite 680                         | 11824 | 35069999 | 18% |
| 97020028 | Eicher Tractor Oil Sump (C)                        | 13651 | 73251000 | 18% |
| 97020259 | Eicher Tractor Cylinder Block Casting-125 Kva      | 46052 | 84099941 | 28% |
| 97020363 | Eicher Tractor Gear Housing ( Casting)-125 Kva     | 3262  | 84099941 | 28% |
| 97020405 | Eicher Tractor Rocker Arm Exhaust Casting          | 166   | 84099941 | 28% |
| 97200004 | Eicher Tractor Spt-028=Mandrel Valve Stem Seal Pre | 613   | 82060090 | 18% |
| 97200005 | Eicher Tractor Spt-029=Mandrel Valve Stem Seal Pre | 613   | 82060090 | 18% |
| 97200006 | Eicher Tractor 312 Nc O/H Kit                      | 15002 | 84099941 | 28% |
| 97200007 | Eicher Tractor 312 Ricardo O/H Kit                 | 16686 | 84099941 | 28% |
| 97200008 | Eicher Tractor Switch And Key Assly                | 332   | 85123010 | 18% |
| 97200019 | Eicher Tractor Brake Lining-Small(4) With Rivits ( | 216   | 87083000 | 18% |
| 97200020 | Eicher Tractor Brake Lining(Big) With Rivets       | 353   | 87083000 | 18% |
| 97200021 | Eicher Tractor Friction Lining-2(Big) With Rivets- | 409   | 87083000 | 18% |
| 97200022 | Eicher Tractor Fric Lining- 9-1/4" Clut With Rivet | 357   | 87083000 | 18% |
| 97200031 | Eicher Tractor Sptws001-Valve Spring Comop W Adopt | 2504  | 82060090 | 18% |
| 97200032 | Eicher Tractor Sptws002-Piston Hght & Valve Depth  | 569   | 82060090 | 18% |
| 97200033 | Eicher Tractor Sptws003-C Shaft Rear End Oil Sel R | 3923  | 82060090 | 18% |
| 97200044 | Eicher Tractor Liner / Ring(L) W Eicher Pistons    | 6002  | 84099941 | 28% |
| 97200045 | Eicher Tractor Liner / Ring(Conf) W Eicher Pistons | 5669  | 84099941 | 28% |
| 97200047 | Eicher Tractor Piston (Eicher)                     | 2942  | 84099941 | 28% |
| 97200051 | Eicher Tractor Clutch Finger Kit - 24Hp            | 193   | 87089300 | 18% |
| 97200052 | Eicher Tractor Clutch Finger Kit - 35Hp            | 177   | 87089300 | 18% |
| 97200054 | Eicher Tractor Starter Switch With Keys -2361712   | 515   | 85123010 | 18% |
| 97200060 | Eicher Tractor Mudguard Left - 485 Sdi (White)-Big | 11420 | 87089900 | 18% |
| 97200063 | Eicher Tractor Cover Assy(F.Tank)Red 368/480/485Sd | 6816  | 87089900 | 18% |
| 97200064 | Eicher Tractor Cover Assy(F.Tank)Blue368/480/485Sd | 9414  | 87089900 | 18% |
| 97200114 | Eicher Tractor Cover                               | 195   | 87084000 | 18% |
| 97200119 | Eicher Tractor Bush                                | 1114  | 87089900 | 18% |
| 97200121 | Eicher Tractor Steering Cly. R. H.                 | 3343  | 87089400 | 18% |
| 97200122 | Eicher Tractor Steering Cly. L. H.                 | 3343  | 87089400 | 18% |
| 97200124 | Eicher Tractor Screw                               | 70    | 73181500 | 18% |
| 97200130 | Eicher Tractor Frame                               | 6686  | 87089900 | 18% |
| 97200143 | Eicher Tractor Crown+Pinion Kit -Dlx (1961056-1964 | 11304 | 87084000 | 18% |
| 97200148 | Eicher Tractor Bonnet Assly -368 Sdi(Decortaed) Re | 12640 | 87089900 | 18% |
| 97200153 | Eicher Tractor Counter Sunk Set (Mico - 2003421018 | 26    | 84099941 | 28% |
| 97200154 | Eicher Tractor Carbon Brush Set (Mico-F002G20089)  | 1120  | 84099941 | 28% |
| 97200164 | Eicher Tractor Bonnet Assly -380-Wc-Blue (Decorate | 15959 | 87089900 | 18% |
| 97200165 | Eicher Tractor Bonnet Assly -480-Wc-Blue (Decorate | 20029 | 87089900 | 18% |
| 97200166 | Eicher Tractor Int. Lp(M) Nc Set With Ring(Conf)   | 9874  | 84099941 | 28% |
| 97200175 | Eicher Tractor Bonnet Assly -368 Sdi(Decortaed) Bl | 18715 | 87089900 | 18% |
| 97200180 | Eicher Tractor Front Wheel Rim 4.5X16(White-Alt-30 | 4298  | 87087000 | 18% |
| 97200183 | Eicher Tractor Bonnet Assly -485 Sdi-Int Dec (Blue | 16760 | 87089900 | 18% |
| 97200197 | Eicher Tractor Fuel Tank (Red) - Dholki            | 9015  | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200198 | Eicher Tractor Tool Box (White) 241/242/485Sdi-Int | 1437  | 87089900 | 18% |
| 97200203 | Eicher Tractor Tool Box (Blue) 312/364/380/480/368 | 1421  | 87089900 | 18% |
| 97200216 | Eicher Tractor Repair Kit (Main Clutch) Valtra     | 2627  | 87089300 | 18% |
| 97200219 | Eicher Tractor Pto Driven Plate (Valtra)           | 7373  | 87084000 | 18% |
| 97200220 | Eicher Tractor Pressure Plate F Pto Cutch Valtra   | 1656  | 87084000 | 18% |
| 97200221 | Eicher Tractor Pressure Plate F Main Clutch Valtra | 2377  | 87089300 | 18% |
| 97200223 | Eicher Tractor Fulcrum Ring Valtra(216511501       | 280   | 87089900 | 18% |
| 97200228 | Eicher Tractor Bonnet Assly-242(Sq)- Red-(Modif) D | 15247 | 87089900 | 18% |
| 97200229 | Eicher Tractor Bonnet Assly -380-Wc-Dark Blue (Dec | 17213 | 87089900 | 18% |
| 97200230 | Eicher Tractor Cov Assy( F Tank)380/312/364 Jbm Dk | 6597  | 87089900 | 18% |
| 97200231 | Eicher Tractor Fuel Tank (Dark Blue)-Dholki        | 11398 | 87089900 | 18% |
| 97200233 | Eicher Tractor Mudguard Right - 485 Int (Silver)   | 14947 | 87089900 | 18% |
| 97200234 | Eicher Tractor Mudguard Left - 485 Int (Sliver)    | 13926 | 87089900 | 18% |
| 97200235 | Eicher Tractor Fuel Tank (Black)-Dholki            | 11933 | 87089900 | 18% |
| 97200238 | Eicher Tractor Cover Assy(F.Tank) - Red -485Sdi-In | 7274  | 87084000 | 18% |
| 97200240 | Eicher Tractor Cover Assy(F.Tank) -Silver-485Sdi-I | 9678  | 87089900 | 18% |
| 97200242 | Eicher Tractor Tool Box (Silver) - 485Sdi-Interim  | 1506  | 87089900 | 18% |
| 97200248 | Eicher Tractor O-Ring Kit - Addc (Hydromatic)      | 591   | 40169320 | 18% |
| 97200252 | Eicher Tractor 298 Recardo Engine O/H Kit          | 17757 | 84099941 | 28% |
| 97200253 | Eicher Tractor 298 Recardo O/H Kit W/O Valves(9720 | 16707 | 84099941 | 28% |
| 97200254 | Eicher Tractor 364Nc Eng O/H Kit W/O Valves(197471 | 14776 | 84099941 | 28% |
| 97200255 | Eicher Tractor 312 Nc O/H Kit W/O Valves(97200006) | 13393 | 84099941 | 28% |
| 97200256 | Eicher Tractor 115Nc Eng O/H Kit W/O Valves(138838 | 11685 | 84099941 | 28% |
| 97200257 | Eicher Tractor 115Nc Eng O/H Kit W/O Valves(129369 | 6679  | 84099941 | 28% |
| 97200258 | Eicher Tractor Bonnet Assly-5660 - Green - (Deco)  | 16410 | 87089900 | 18% |
| 97200260 | Eicher Tractor Mudguard Left - 368 (White)         | 14794 | 87089900 | 18% |
| 97200263 | Eicher Tractor Cover Assy(F.Tank) -Silver-380/5660 | 7723  | 87089900 | 18% |
| 97200264 | Eicher Tractor Bonnet Assly -380-Wc-Silver- (Deco) | 17044 | 87089900 | 18% |
| 97200268 | Eicher Tractor Eicher Gear Oil Ep80(20Ltr)         | 7310  | 27101980 | 18% |
| 97200269 | Eicher Tractor Eicher Gear Oil Ep80 (10 Ltr)       | 3660  | 27101980 | 18% |
| 97200271 | Eicher Tractor Eicher Gear Oil Ep80 (5Ltr)         | 1830  | 27101980 | 18% |
| 97200272 | Eicher Tractor Eicher Gear Oil Ep80 (1 Ltr)        | 370   | 27101980 | 18% |
| 97200280 | Eicher Tractor Clutch Repair Kit 9,1/4" 1 Set      | 576   | 87089300 | 18% |
| 97200281 | Eicher Tractor Clutch Repair Kit 10" 1 Set         | 530   | 87089300 | 18% |
| 97200282 | Eicher Tractor Clutch Repair Kit 11" 1 Set         | 1462  | 87089300 | 18% |
| 97200290 | Eicher Tractor Cover Assy Fuel Tank 5150-5660- Sil | 6730  | 87089900 | 18% |
| 97200291 | Eicher Tractor Cov Asy F Tank 5150-5660-380 Hyd Nt | 8539  | 87089900 | 18% |
| 97200292 | Eicher Tractor Cov Asy F Tank 5150-5660-380 Hyd Gr | 6944  | 87089900 | 18% |
| 97200293 | Eicher Tractor Cov Asy F Tank 5150-5660-380 Hyd Nt | 7250  | 87089900 | 18% |
| 97200294 | Eicher Tractor Lowering Valve Assy                 | 823   | 87089900 | 18% |
| 97200295 | Eicher Tractor 4 *Dif O/H Kit93620037/93672530/936 | 6172  | 87084000 | 18% |
| 97200296 | Eicher Tractor 3 *Diffo/H Kit93627883/93672530/936 | 4997  | 87085000 | 18% |
| 97200299 | Eicher Tractor Crown+Pinion Kit -Sw (93650844+196  | 9440  | 87084000 | 18% |
| 97200301 | Eicher Tractor Bevel Gear+Pinion (2020038+2021249  | 4596  | 87084000 | 18% |
| 97200302 | Eicher Tractor Bonnet Assy 368Sdi New Grahics Jbm( | 14902 | 87089900 | 18% |
| 97200337 | Eicher Tractor Bonnet Assly -312 -Dark Blue -Jbm-D | 10995 | 87089900 | 18% |
| 97200351 | Eicher Tractor Mudguard Right -5660-Green          | 14260 | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200352 | Eicher Tractor Mudguard Left-5660 -Green           | 14237 | 87089900 | 18% |
| 97200355 | Eicher Tractor Cover Assy (F.Tank) -Green-5660     | 6053  | 87089900 | 18% |
| 97200359 | Eicher Tractor Front Wheel Rim- 5.50X16-5600- (Sil | 5685  | 87087000 | 18% |
| 97200360 | Eicher Tractor Front Wheel Rim- 5.50X16-5600- (Ora | 4942  | 87087000 | 18% |
| 97200361 | Eicher Tractor Bonnet Assly -X-Trac-Red-Deco -241/ | 14410 | 87089900 | 18% |
| 97200366 | Eicher Tractor Rear Wheel Rim -5660-Orange -(W-15/ | 20284 | 87087000 | 18% |
| 97200367 | Eicher Tractor Rear Wheel Rim -W15X28-5660-White   | 17430 | 87087000 | 18% |
| 97200369 | Eicher Tractor Bonnet Assly-5660 - Silver (Decora  | 18950 | 87089900 | 18% |
| 97200370 | Eicher Tractor Rear Wheel Rim-Silver-W12-14.9      | 12698 | 87087000 | 18% |
| 97200371 | Eicher Tractor Crown+Pinion Kit -312P (93628670+19 | 11892 | 87084000 | 18% |
| 97200379 | Eicher Tractor Bonnet Decorated 485 Sdi Red        | 16592 | 87089900 | 18% |
| 97200402 | Eicher Tractor Bonnet Assly -242-Premium-Red (Jbm) | 17598 | 87089900 | 18% |
| 97200403 | Eicher Tractor Fuel Tank Assy 242-Premium-Red (Jbm | 12786 | 87089900 | 18% |
| 97200429 | Eicher Tractor Nozzle                              | 2948  | 84099941 | 28% |
| 97200430 | Eicher Tractor Element                             | 2575  | 84099941 | 28% |
| 97200431 | Eicher Tractor Delevery Valve                      | 570   | 84099941 | 28% |
| 97200432 | Eicher Tractor Element                             | 2221  | 84099941 | 28% |
| 97200433 | Eicher Tractor Delevery Valve                      | 570   | 84099941 | 28% |
| 97200436 | Eicher Tractor Bonnet Assy - 312P Red - Deco-New G | 17996 | 87089900 | 18% |
| 97200437 | Eicher Tractor Bonnet Assy - 364P -Red-Deco-New Gr | 17522 | 87089900 | 18% |
| 97200438 | Eicher Tractor Cover Assy - Fuel Tank-Red          | 6810  | 87089900 | 18% |
| 97200439 | Eicher Tractor Bonnet Assy - 312P-Dark Blue - Jbm  | 12940 | 87089900 | 18% |
| 97200440 | Eicher Tractor Bonnet Assy - 364P- Jbm -Dark Blue  | 14977 | 87089900 | 18% |
| 97200441 | Eicher Tractor Fuel Tank (Black-Pu - Dholki        | 12428 | 87089900 | 18% |
| 97200446 | Eicher Tractor Wheel Rim W12-13.6*28 Tyre152.4 Pcd | 11556 | 87087000 | 18% |
| 97200447 | Eicher Tractor Wheelrim W11-12.4*28 Pcd 152.4 Whit | 11744 | 87087000 | 18% |
| 97200451 | Eicher Tractor Rear Wheel Rim-W12-14.9 , 152.4 , W | 12030 | 87087000 | 18% |
| 97200452 | Eicher Tractor Front Wheel Rim -4.5*16-Silver - Ta | 1938  | 87087000 | 18% |
| 97200453 | Eicher Tractor Rear Wheel Rim 5660 (Orange W13)    | 17473 | 87087000 | 18% |
| 97200455 | Eicher Tractor 7" Friction Disc (4) W / Rivets(24) | 843   | 87083000 | 18% |
| 97200457 | Eicher Tractor Bonnet Assly - 5660 -Wet A/C - Gree | 20358 | 87089900 | 18% |
| 97200459 | Eicher Tractor Front Axle Bush & Oring Kit         | 4893  | 84099941 | 28% |
| 97200463 | Eicher Tractor 115 E Ricardo Engine O/H Kit Minor  | 1576  | 84099941 | 28% |
| 97200464 | Eicher Tractor 298 E Ricardo Engine O/H Kit Minor  | 3146  | 84099941 | 28% |
| 97200465 | Eicher Tractor 298 Ricardo Engine O/H Kit Minor (I | 3116  | 84099941 | 28% |
| 97200466 | Eicher Tractor 398 E Ricardo Engine O/H Kit Minor  | 4762  | 84099941 | 28% |
| 97200467 | Eicher Tractor Bonnet Decorated 5150 Dark Blue     | 13264 | 87089900 | 18% |
| 97200468 | Eicher Tractor Bonnet Decorated 5150 Antique Silve | 18425 | 87089900 | 18% |
| 97200469 | Eicher Tractor Bonnet Decorated 485 Sdi Silver     | 16194 | 87089900 | 18% |
| 97200471 | Eicher Tractor Bonnet Assy Decorated Dark Blue -3  | 18054 | 87089900 | 18% |
| 97200472 | Eicher Tractor Bonnet Assy Decorated Silver-       | 16316 | 87089900 | 18% |
| 97200473 | Eicher Tractor Bonnet Assy Decorated Silver-480    | 15572 | 87089900 | 18% |
| 97200476 | Eicher Tractor Mudguard Right - 380 Sw (White)     | 12878 | 87089900 | 18% |
| 97200477 | Eicher Tractor Steering Wheel Cover - Premium      | 157   | 87089400 | 18% |
| 97200478 | Eicher Tractor Steering Wheel Cover - Deluxe       | 224   | 87089400 | 18% |
| 97200479 | Eicher Tractor Roof Canopy                         | 4744  | 87089900 | 18% |
| 97200480 | Eicher Tractor Mudguard Seat                       | 1861  | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200481 | Eicher Tractor Horn - Cleartone H/L                | 771   | 85123010 | 18% |
| 97200482 | Eicher Tractor Horn - Smartone H/L                 | 545   | 85123010 | 18% |
| 97200483 | Eicher Tractor Horn - Vibromini H/L                | 889   | 85123010 | 18% |
| 97200484 | Eicher Tractor Crown+Pinion Kit- 241 (1011406+9361 | 9113  | 87084000 | 18% |
| 97200486 | Eicher Tractor Mudguard Right Big Top Silver 485I  | 15249 | 87089900 | 18% |
| 97200488 | Eicher Tractor Big Pin Of 3 Stage Coupling Mouth   | 706   | 87089900 | 18% |
| 97200489 | Eicher Tractor Small Pin Of 3 Stage Coupling Mouth | 157   | 87089900 | 18% |
| 97200490 | Eicher Tractor Bonnet Assy 368 Sdi New Grahics Jbm | 15980 | 87089900 | 18% |
| 97200492 | Eicher Tractor Mudguard Right - 380 Sw (Silver)    | 10466 | 87089900 | 18% |
| 97200493 | Eicher Tractor Mudguard Left - 380 Sw (White)      | 11536 | 87089900 | 18% |
| 97200494 | Eicher Tractor Mudguard Left - 380 Sw (Silver)     | 10009 | 87089900 | 18% |
| 97200496 | Eicher Tractor Mudguard Right - 380 Big Top (Silve | 11806 | 87089900 | 18% |
| 97200498 | Eicher Tractor Mudguard Left - 380 Big Top (Silver | 10780 | 87089900 | 18% |
| 97200504 | Eicher Tractor Mudgud Left Big Top 368/485/380/480 | 13790 | 87089900 | 18% |
| 97200511 | Eicher Tractor O'Ring Kit For Single Spool Prv 24  | 460   | 40169320 | 18% |
| 97200512 | Eicher Tractor 115 Nce Liner With Ring - Xtrac     | 10126 | 84099941 | 28% |
| 97200513 | Eicher Tractor 115 Nce Liner / Ring With Piston Xt | 13536 | 84099941 | 28% |
| 97200514 | Eicher Tractor 398 Ed Liner With Ring - 485        | 12030 | 84099941 | 28% |
| 97200515 | Eicher Tractor 398 Ed Liner / Ring With Piston - 4 | 23783 | 84099941 | 28% |
| 97200518 | Eicher Tractor 4 Star Differential O/H Kit         | 6345  | 87084000 | 18% |
| 97200519 | Eicher Tractor 3 Star Differential O/H Kit         | 5170  | 87085000 | 18% |
| 97200520 | Eicher Tractor 485 Engine Gasket Kit               | 703   | 84099941 | 28% |
| 97200544 | Eicher Tractor 115 Nce Cyl Liner With Ring Kit- Xt | 3176  | 84099941 | 28% |
| 97200545 | Eicher Tractor 115 Nce Cyl Liner/Ring/Piston Kit X | 5851  | 84099941 | 28% |
| 97200546 | Eicher Tractor Inlet Exh Valve Kit (1715707+171571 | 805   | 84099941 | 28% |
| 97200547 | Eicher Tractor Inlet Exh Valve Kit (1123751+112376 | 437   | 84099941 | 28% |
| 97200548 | Eicher Tractor Inlet Exh Valve Kit (1384211+138422 | 731   | 84099941 | 28% |
| 97200549 | Eicher Tractor Inlet Exh Valve Kit (1387959+138796 | 554   | 84099941 | 28% |
| 97200550 | Eicher Tractor Inlet Exh Valve Kit (1670700+167071 | 727   | 84099941 | 28% |
| 97200551 | Eicher Tractor Inlet Exh Valve Kit (1972730+931319 | 347   | 84099111 | 28% |
| 97200552 | Eicher Tractor Inlet Exh Valve Kit (93131956+      | 623   | 84099941 | 28% |
| 97200553 | Eicher Tractor Thin Walled Brg Kit (1127676+112883 | 334   | 84099941 | 28% |
| 97200554 | Eicher Tractor Brg Kit (1381787+1381829 )          | 202   | 84822090 | 18% |
| 97200555 | Eicher Tractor Brg Kit (1381799+1381830 )          | 213   | 84099941 | 28% |
| 97200556 | Eicher Tractor Be Brg Kit U/S .75 Mm (1381805+1381 | 213   | 84099941 | 28% |
| 97200557 | Eicher Tractor Be Brg Kit U/S 1.0 Mm (1381817+1381 | 199   | 84099941 | 28% |
| 97200558 | Eicher Tractor Main Brg Kit (1670086+1670098 )     | 349   | 84833000 | 18% |
| 97200559 | Eicher Tractor Mainbrg Kit O/S.25 Mm(93181522+9318 | 342   | 84099941 | 28% |
| 97200560 | Eicher Tractor Mainbrg Kit O/S.50 Mm(93181534+9318 | 332   | 84099941 | 28% |
| 97200561 | Eicher Tractor Kit Mb Middle U/S.25 Mm(1974464+197 | 207   | 84099941 | 28% |
| 97200562 | Eicher Tractor Kit Mb Middle U/S .5 Mm(1974476+197 | 207   | 84099941 | 28% |
| 97200563 | Eicher Tractor Kit M B Middle (1971955+1971967 )   | 296   | 84099941 | 28% |
| 97200564 | Eicher Tractor Eicher Rakshak Touch Up Paint Red   | 490   | 32082090 | 18% |
| 97200565 | Eicher Tractor Eicher Rakshak Touch Up Paint Blue  | 490   | 32082090 | 18% |
| 97200566 | Eicher Tractor Eicher Rakshak Touch Up Paint Silve | 438   | 32082090 | 18% |
| 97200567 | Eicher Tractor Eicher Rakshak Touch Up Paint Off W | 490   | 32082090 | 18% |
| 97200568 | Eicher Tractor Eicher Rakshak Touch Up Paint Dark  | 490   | 32082090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200569 | Eicher Tractor Eicher Rakshak Touch Up Paint Thinn | 420   | 38140010 | 18% |
| 97200570 | Eicher Tractor Engine O/H Kit For 485 Trem- Iii    | 20717 | 84099941 | 28% |
| 97200571 | Eicher Tractor Engine O/H Kit For 485 Trem- Iii W/ | 19141 | 84099941 | 28% |
| 97200572 | Eicher Tractor Crown Wheel Pinion Kit 1011406+9361 | 10777 | 87084000 | 18% |
| 97200574 | Eicher Tractor Clutch Brg Sleeve Assy Single Clutc | 1730  | 87089300 | 18% |
| 97200575 | Eicher Tractor Roller Tappet Kit                   | 282   | 84824000 | 18% |
| 97200576 | Eicher Tractor O Ring And Gasket Kit For 115 Cyl H | 182   | 84099941 | 28% |
| 97200577 | Eicher Tractor Engine Oring Kit (398 Eng)          | 986   | 84099941 | 28% |
| 97200578 | Eicher Tractor Engine Oring Kit (298 Eng Old)      | 855   | 84099941 | 28% |
| 97200579 | Eicher Tractor Engine Gasket Kit Minor (115 Eng)   | 276   | 84099941 | 28% |
| 97200580 | Eicher Tractor Bush Insert Kit (Old)               | 416   | 84099941 | 28% |
| 97200581 | Eicher Tractor Fan Bush Kit (115)                  | 347   | 84099941 | 28% |
| 97200582 | Eicher Tractor Engine O Ring & Oilseal Kit (298Ei  | 1496  | 84099941 | 28% |
| 97200583 | Eicher Tractor Engine O Ring & Oilseal Kit (398 En | 1885  | 84099941 | 28% |
| 97200584 | Eicher Tractor Engine Gasket Kit (298Ei Eng)       | 602   | 84099941 | 28% |
| 97200585 | Eicher Tractor Engine Gasket Kit (398 Eng)         | 703   | 84099941 | 28% |
| 97200586 | Eicher Tractor Cyl Head Assy Complete 115 Nc       | 12161 | 84099941 | 28% |
| 97200588 | Eicher Tractor Tie Rod End Set (81 Mm) (Cp2535129/ | 1121  | 87089400 | 18% |
| 97200589 | Eicher Tractor Tie Rod End Set (86 Mm)             | 725   | 87089400 | 18% |
| 97200590 | Eicher Tractor Tie Rod End Set (Bsw)               | 1079  | 87089400 | 18% |
| 97200591 | Eicher Tractor O-Ring Kit - Distributor (Hydromati | 1285  | 40169320 | 18% |
| 97200592 | Eicher Tractor Decal Kit For 241                   | 1986  | 39199090 | 18% |
| 97200593 | Eicher Tractor Decal Kit For 242                   | 1696  | 39199090 | 18% |
| 97200595 | Eicher Tractor Decal Kit For 333                   | 1816  | 39199090 | 18% |
| 97200597 | Eicher Tractor Decal Kit For 368                   | 1799  | 39199090 | 18% |
| 97200598 | Eicher Tractor Decal Kit For 380                   | 1747  | 39199090 | 18% |
| 97200599 | Eicher Tractor Decal Kit For 480                   | 1994  | 39199090 | 18% |
| 97200602 | Eicher Tractor Decal Kit For 5600                  | 509   | 39199090 | 18% |
| 97200603 | Eicher Tractor Engine Gasket Kit (5660)            | 3243  | 84099941 | 28% |
| 97200604 | Eicher Tractor Engine Gasket Kit (241 / 242)       | 409   | 84099941 | 28% |
| 97200605 | Eicher Tractor Crown Wheel Pinion Kit 5660 Syncro  | 13631 | 87084000 | 18% |
| 97200606 | Eicher Tractor Crown Wheel Pinion Kit 5660 Non Syn | 9777  | 87084000 | 18% |
| 97200613 | Eicher Tractor Kit Hose Pump Steering 93717148     | 2505  | 40093100 | 18% |
| 97200614 | Eicher Tractor Kit Steering Hose Left 93717124     | 2638  | 40093100 | 18% |
| 97200615 | Eicher Tractor Kit Front Axel Support 93352602     | 14835 | 87085000 | 18% |
| 97200618 | Eicher Tractor Kit Steering Hose Right 9371713     | 2474  | 40093100 | 18% |
| 97200621 | Eicher Tractor Engine Repair Kit -Euro Power 6100  | 30156 | 84099941 | 28% |
| 97200622 | Eicher Tractor In/Exh Valve Kit(93113528+93113541) | 501   | 84099941 | 28% |
| 97200623 | Eicher Tractor In/Exh Valve Kit(93250581+93250787) | 748   | 84099941 | 28% |
| 97200624 | Eicher Tractor In/Exh Valve Kit (93113310+93113323 | 492   | 84099111 | 28% |
| 97200625 | Eicher Tractor Bonnet Assly -380-Wc- Red(Decot)    | 17217 | 87089900 | 18% |
| 97200627 | Eicher Tractor Kit(Assy Rpm93810124 & Assy Rpm9381 | 2404  | 85122010 | 18% |
| 97200631 | Eicher Tractor 320 Ed Engine O/H Kit - 5660        | 30651 | 84099941 | 28% |
| 97200632 | Eicher Tractor 320 Ed Liner With Ring (Tufric Coat | 12936 | 84099941 | 28% |
| 97200633 | Eicher Tractor 320Edliner/Ring (Tufric Coatd) W/ P | 21871 | 84099941 | 28% |
| 97200634 | Eicher Tractor Mudgud Rt 380 93334776 Big Top Whi  | 12228 | 87089900 | 18% |
| 97200636 | Eicher Tractor Kit M B Middle (93250179+93250180 ) | 323   | 84099941 | 28% |





|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200637 | Eicher Tractor Eicher Rakshak Ready To Use Coolant | 180   | 38249022 | 18% |
| 97200638 | Eicher Tractor Brake Lining 1St Oversize           | 52    | 87083000 | 18% |
| 97200640 | Eicher Tractor Disc Brake Lining(4) W/Rivets(24)1S | 524   | 87083000 | 18% |
| 97200641 | Eicher Tractor Brake Lining(Big) W Rivets Drum 1St | 376   | 87083000 | 18% |
| 97200642 | Eicher Tractor 7" Fric Disc(4)W/ Rivets(36)5660 1S | 932   | 87083000 | 18% |
| 97200643 | Eicher Tractor Tt Kit For 5660/ 5150 (Big Addc)    | 1340  | 87089900 | 18% |
| 97200644 | Eicher Tractor Tt Kit For 242/ 364 Exp (Small Add  | 1496  | 87089900 | 18% |
| 97200646 | Eicher Tractor Rakshak Silicon Gasket Sealant (50G | 281   | 32141000 | 18% |
| 97200647 | Eicher Tractor Rakshak Silicon Gasket Sealant (25G | 147   | 32141000 | 18% |
| 97200648 | Eicher Tractor Eicher Rakshak Wet Disc Brake Oil(1 | 3760  | 27101980 | 18% |
| 97200649 | Eicher Tractor Eicher Rakshak Wet Disc Brake Oil(2 | 7450  | 27101980 | 18% |
| 97200652 | Eicher Tractor Mudgud Lt 380 93422975Big Top White | 17509 | 87089900 | 18% |
| 97200653 | Eicher Tractor Mudgud Rt 380 93422987Big Top White | 17725 | 87089900 | 18% |
| 97200654 | Eicher Tractor In/Exh Valve Kit(93131956+93250787) | 642   | 84099941 | 28% |
| 97200655 | Eicher Tractor Mudguard Right -5660-Green          | 16004 | 87089900 | 18% |
| 97200656 | Eicher Tractor Mudguard Left-5660 -Green           | 19312 | 87089900 | 18% |
| 97200657 | Eicher Tractor Eicher Rakshak Wet Disc Brake Oil(5 | 1900  | 27101980 | 18% |
| 97200658 | Eicher Tractor Mudgud Lt 380 93422975 Big Top Silv | 17399 | 87089900 | 18% |
| 97200659 | Eicher Tractor Mudgud Rt 380 93422987Big Top Silve | 20528 | 87089900 | 18% |
| 97200660 | Eicher Tractor Rakshak Touch Up Paint Coral Orange | 620   | 32082090 | 18% |
| 97200670 | Eicher Tractor Lockable Fuel Tank Cap+Key Pair     | 252   | 87089900 | 18% |
| 97200671 | Eicher Tractor Starter Switch+Key Pair             | 438   | 85123010 | 18% |
| 97200672 | Eicher Tractor Starter Switch+Key Pair             | 388   | 85123010 | 18% |
| 97200674 | Eicher Tractor Bolt & Nut Set For Bolted Rim (9333 | 84    | 73181500 | 18% |
| 97200676 | Eicher Tractor Engine O/H Kit For 485 Trem- Iii Ne | 20796 | 84099941 | 28% |
| 97200677 | Eicher Tractor Bracket For Alternator (222Es) Kit  | 403   | 84099941 | 28% |
| 97200678 | Eicher Tractor Inspection Cover Rear (398Auto/Stn. | 734   | 84099941 | 28% |
| 97200679 | Eicher Tractor Mudgmudguard Left-5660 Silver       | 19694 | 87089900 | 18% |
| 97200680 | Eicher Tractor Mudguard Right-5660 -Silver         | 13598 | 87089900 | 18% |
| 97200681 | Eicher Tractor Top Overhauling Kit - 322 Es (Toh)  | 24311 | 84099941 | 28% |
| 97200682 | Eicher Tractor Major Overhauling Kit - 322 Es (Moh | 31320 | 84099941 | 28% |
| 97200683 | Eicher Tractor Top Overhauling Kit - 422 Es (Toh)  | 28875 | 84099941 | 28% |
| 97200684 | Eicher Tractor Major Overhauling Kit - 422 Es (Moh | 30341 | 84099941 | 28% |
| 97200685 | Eicher Tractor Engine O/H Kit 485 Trem - 3 New     | 26290 | 84099941 | 28% |
| 97200686 | Eicher Tractor Engine O/H Kit 485 Trem- 3 W/O Valv | 24714 | 84099941 | 28% |
| 97200687 | Eicher Tractor Seal Kit 100 Dia (93715140-2562807- | 927   | 87089900 | 18% |
| 97200688 | Eicher Tractor Seal Kit 90 Dia-93715152+1939866+25 | 657   | 87089900 | 18% |
| 97200689 | Eicher Tractor Seal Kit 80 Dia(93715164-1939592-25 | 875   | 87089900 | 18% |
| 97200690 | Eicher Tractor O Ring Kit (1932731-1932743)        | 125   | 40169340 | 18% |
| 97200691 | Eicher Tractor Kit Plastic Bush(2568329-2568330)   | 181   | 39021000 | 18% |
| 97200692 | Eicher Tractor Mudguard Right -333 Hyd Silver(Smal | 12312 | 87089900 | 18% |
| 97200693 | Eicher Tractor Mudguard Left -333 Hyd Silver(Small | 12315 | 87089900 | 18% |
| 97200694 | Eicher Tractor Eicher Rakshak Touch Up Paint Green | 490   | 32082090 | 18% |
| 97200695 | Eicher Tractor Pto Shaft Assy(93653183+93653158)   | 4101  | 87084000 | 18% |
| 97200696 | Eicher Tractor Assly Pto Shaft 540-485 Dlx(8620)   | 4160  | 87084000 | 18% |
| 97200698 | Eicher Tractor Pto Shaft Front (93652105)          | 2600  | 87084000 | 18% |
| 97200700 | Eicher Tractor Pto Shaft Rear-540 Sw               | 3164  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200701 | Eicher Tractor Battery Box Assy Kit                | 4417  | 87089900 | 18% |
| 97200709 | Eicher Tractor Rakshak Engine Oil 15W 40 - 6.5 Ltr | 2190  | 27101980 | 18% |
| 97200710 | Eicher Tractor Rakshak Engine Oil 15W 40 - 8 Ltr   | 2670  | 27101980 | 18% |
| 97200711 | Eicher Tractor Rakshak Engine Oil 15W 40 - 10 Ltr  | 3340  | 27101980 | 18% |
| 97200712 | Eicher Tractor Rakshak Engine Oil 15W 40 - 20 Ltr  | 6670  | 27101980 | 18% |
| 97200713 | Eicher Tractor Filter Kit B-Check 15 / 20 / 25 Kva | 530   | 84219900 | 18% |
| 97200714 | Eicher Tractor Filter Kit C-Check 15 / 20 / 25 Kva | 1303  | 84219900 | 18% |
| 97200715 | Eicher Tractor Mudgud Rt 380 93422987Big Top Silve | 17505 | 87089900 | 18% |
| 97200716 | Eicher Tractor Hydraulic Linkage Assy (Hydromatic) | 2597  | 87089900 | 18% |
| 97200717 | Eicher Tractor Crown+Pinion Kit- Ss (93651897+9367 | 9271  | 87084000 | 18% |
| 97200718 | Eicher Tractor Decal Kit For 557                   | 1965  | 39199090 | 18% |
| 97200719 | Eicher Tractor Decal Kit For 548                   | 1471  | 39199090 | 18% |
| 97200720 | Eicher Tractor Rakshak Engine Oil 15W40 1 Ltr      | 340   | 27101980 | 18% |
| 97200721 | Eicher Tractor Rakshak Engine Oil 15W40 5 Ltr      | 1670  | 27101980 | 18% |
| 97200722 | Eicher Tractor Top Overhauling Kit - 322 Es        | 24562 | 84099941 | 28% |
| 97200723 | Eicher Tractor Major Overhauling Kit - 322 Es      | 32646 | 84099941 | 28% |
| 97200724 | Eicher Tractor Top Overhauling Kit - 422 Es        | 32615 | 84099941 | 28% |
| 97200725 | Eicher Tractor Major Overhauling Kit - 422 Es      | 42411 | 84099941 | 28% |
| 97200726 | Eicher Tractor Bracket For Alternator Kit (222Es)  | 142   | 84099941 | 28% |
| 97200727 | Eicher Tractor Bonnet Assy 548 Sdi New Grahics Jbm | 15284 | 87089900 | 18% |
| 97200728 | Eicher Tractor Rakshak Genset Oil (Ci4) - 1Ltr     | 320   | 27101980 | 18% |
| 97200729 | Eicher Tractor Rakshak Genset Oil (Ci4) - 5Ltr     | 1590  | 27101980 | 18% |
| 97200730 | Eicher Tractor Rakshak Genset Oil (Ci4) - 7.5Ltr   | 2390  | 27101980 | 18% |
| 97200731 | Eicher Tractor Rakshak Genset Oil (Ci4) - 8Ltr     | 2550  | 27101980 | 18% |
| 97200732 | Eicher Tractor Rakshak Genset Oil (Ci4) - 9.5Ltr   | 3030  | 27101980 | 18% |
| 97200735 | Eicher Tractor Rakshak Engine Oil Ci4 Grade 209 Lt | 57870 | 27101980 | 18% |
| 97200736 | Eicher Tractor Bonnet Assy 548 Sdi New Grahics (Si | 16393 | 87089900 | 18% |
| 97200738 | Eicher Tractor Bonnet Assy 557 Sdi New Grahics (Si | 15491 | 87089900 | 18% |
| 97200739 | Eicher Tractor Bonnet Assy 557 Sdi New Grahics (Gr | 16948 | 87089900 | 18% |
| 97200740 | Eicher Tractor Crown+Pinion Kit- Ss (93632775+9363 | 23487 | 87084000 | 18% |
| 97200741 | Eicher Tractor Pedstal Kit (93240423+93240435)     | 4283  | 84099941 | 28% |
| 97200748 | Eicher Tractor Kit For Altr Brkt(93185126+93185138 | 332   | 84099941 | 28% |
| 97200749 | Eicher Tractor Eicher Rakshak Touch Up Paint Hr Bl | 670   | 32082090 | 18% |
| 97200750 | Eicher Tractor Cf4 20W40 Rakshak Eng Oil-1 Ltr     | 310   | 27101980 | 18% |
| 97200751 | Eicher Tractor Cf4 20W40 Rakshak Eng Oil-5 Ltr     | 1570  | 27101980 | 18% |
| 97200752 | Eicher Tractor Cf4 20W40 Rakshak Eng Oil-6.5 Ltr   | 2050  | 27101980 | 18% |
| 97200753 | Eicher Tractor Cf4 20W40 Rakshak Eng Oil-8 Ltr     | 2510  | 27101980 | 18% |
| 97200754 | Eicher Tractor Cf4 20W40 Rakshak Eng Oil-10 Ltr    | 3140  | 27101980 | 18% |
| 97200755 | Eicher Tractor Rakshak Rotavator Oil- 6.5 Ltr      | 2700  | 27101980 | 18% |
| 97200757 | Eicher Tractor 398 Ed Liner / Ring With Piston - 4 | 23210 | 84099941 | 28% |
| 97200758 | Eicher Tractor Engine O/H Kit For 485 Trem- Iii W/ | 25567 | 84099941 | 28% |
| 97200759 | Eicher Tractor Engine Gasket Kit Minor (115 Eng) N | 295   | 84099941 | 28% |
| 97200760 | Eicher Tractor Bonnet Assy 278 Red                 | 10818 | 87089900 | 18% |
| 97200762 | Eicher Tractor Case Transmisson Rear Kit - Export  | 10429 | 87085000 | 18% |
| 97200763 | Eicher Tractor Engine Overhauling Kit For 548      | 24230 | 84099941 | 28% |
| 97200764 | Eicher Tractor V Ring Kit For Front Axle           | 239   | 87089900 | 18% |
| 97200765 | Eicher Tractor Bonnet Lock Kit                     | 987   | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200766 | Eicher Tractor Gasket Kit 242 Reduction Hsg. Model | 638   | 68129090 | 18% |
| 97200767 | Eicher Tractor Gasket Kit 485 Non Hydromatic       | 836   | 68129090 | 18% |
| 97200768 | Eicher Tractor Gasket Kit 241 Model                | 449   | 68129090 | 18% |
| 97200769 | Eicher Tractor Fr Axle Assy Kit - 548 / 485 Ps - ( | 13945 | 87085000 | 18% |
| 97200770 | Eicher Tractor Decal Kit For 312 New               | 2219  | 39199090 | 18% |
| 97200771 | Eicher Tractor Decal Kit For 364 New               | 2280  | 39199090 | 18% |
| 97200772 | Eicher Tractor Decal Kit For 485 New               | 1690  | 39199090 | 18% |
| 97200773 | Eicher Tractor Mudguard Left-5660 / 557 Silver 16X | 19197 | 87089900 | 18% |
| 97200774 | Eicher Tractor Mudguard Right-5660 / 557 Silver 16 | 19197 | 87089900 | 18% |
| 97200775 | Eicher Tractor Mudguard Left-5660 / 557 Green 16X9 | 20471 | 87089900 | 18% |
| 97200776 | Eicher Tractor Mudguard Right -5660 / 557 Green 16 | 20766 | 87089900 | 18% |
| 97200779 | Eicher Tractor Bonnet Assy - 368 A Line Red        | 13995 | 87089900 | 18% |
| 97200780 | Eicher Tractor Bonnet Assy - 368 A Line Silver     | 13590 | 87089900 | 18% |
| 97200781 | Eicher Tractor Bonnet Assy - 380 R Line Blue       | 15181 | 87089900 | 18% |
| 97200782 | Eicher Tractor Bonnet Assy - 380 R Line Silver     | 15616 | 87089900 | 18% |
| 97200783 | Eicher Tractor Bonnet Assy - 380 Super + Blue      | 15014 | 87089900 | 18% |
| 97200784 | Eicher Tractor Bonnet Assy - 380 Super + Silver    | 13179 | 87089900 | 18% |
| 97200785 | Eicher Tractor Bonnet Assy - 480 Super + Blue      | 16519 | 87089900 | 18% |
| 97200786 | Eicher Tractor Bonnet Assy - 480 Super + Silver    | 16515 | 87089900 | 18% |
| 97200787 | Eicher Tractor Bonnet Assy - 371 Super + Blue      | 15392 | 87089900 | 18% |
| 97200788 | Eicher Tractor Bonnet Assy - 371 Super + Silver    | 12856 | 87089900 | 18% |
| 97200789 | Eicher Tractor Hydraulic Linkage Assy (Hydromatic) | 4647  | 87089900 | 18% |
| 97200790 | Eicher Tractor Spur Pinion+Sliding Gear Kit (93625 | 3584  | 87084000 | 18% |
| 97200791 | Eicher Tractor Connecting Pipe+Air Inlet Hose Kit( | 1285  | 40093100 | 18% |
| 97200792 | Eicher Tractor Clutch Brg Sleeve Assy Single Clutc | 1676  | 87089300 | 18% |
| 97200793 | Eicher Tractor Filter Kit 322Es B-Check            | 387   | 84212300 | 18% |
| 97200794 | Eicher Tractor Filter Kit 322Es C-Check            | 1160  | 84212300 | 18% |
| 97200795 | Eicher Tractor Mudguard Left Big Top - White       | 15110 | 87089900 | 18% |
| 97200796 | Eicher Tractor Mudguard Left Big Top - Silver      | 15678 | 87089900 | 18% |
| 97200797 | Eicher Tractor Mudguard Right Big Top - White      | 15103 | 87089900 | 18% |
| 97200798 | Eicher Tractor Mudguard Right Big Top - Silver     | 15672 | 87089900 | 18% |
| 97200799 | Eicher Tractor Mudguard Left Small Top - White     | 14528 | 87089900 | 18% |
| 97200800 | Eicher Tractor Mudguard Right Small Top - White    | 11479 | 87089900 | 18% |
| 97200801 | Eicher Tractor Battery Box Assy. 551               | 4930  | 85079090 | 28% |
| 97200802 | Eicher Tractor Kit For Valve Seat Nc               | 446   | 84099941 | 28% |
| 97200803 | Eicher Tractor Kit For Valve Guide (Multi)         | 137   | 84099941 | 28% |
| 97200804 | Eicher Tractor Kit For Valve Seat (E-Multi)        | 369   | 84099941 | 28% |
| 97200805 | Eicher Tractor Bonnet Assy 551 (Blue)              | 15389 | 87089900 | 18% |
| 97200806 | Eicher Tractor Cover Assy Fuel Tank 551 Blue       | 7704  | 87089900 | 18% |
| 97200807 | Eicher Tractor Mudguard Right Big Top 551- White   | 11230 | 87089900 | 18% |
| 97200810 | Eicher Tractor 322-Top Overhauling Kit             | 24235 | 84099941 | 28% |
| 97200811 | Eicher Tractor 322-Major Overhauling Kit           | 32039 | 84099941 | 28% |
| 97200812 | Eicher Tractor 422-Top Overhauling Kit             | 32064 | 84099941 | 28% |
| 97200813 | Eicher Tractor 422-Major Overhauling Kit           | 40697 | 84099941 | 28% |
| 97200814 | Eicher Tractor Decal Kit For 380 R Line            | 1835  | 39199090 | 18% |
| 97200815 | Eicher Tractor Decal Kit For 551                   | 1740  | 39199090 | 18% |
| 97200817 | Eicher Tractor Metal Fuel Tank Kit - 333/371/380/4 | 11898 | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200818 | Eicher Tractor Metal Fuel Tank Kit - 380/480 Ps    | 13186 | 87089900 | 18% |
| 97200819 | Eicher Tractor Metal Fuel Tank Kit-368/485/548 /56 | 11837 | 87089900 | 18% |
| 97200820 | Eicher Tractor Metal Fuel Tank Kit-368/485/548/566 | 13119 | 87089900 | 18% |
| 97200822 | Eicher Tractor Mudguard Right- Red 548 Export 14X9 | 14767 | 87089900 | 18% |
| 97200823 | Eicher Tractor Bonnet Assy - 333 Super + Silver    | 15568 | 87089900 | 18% |
| 97200824 | Eicher Tractor Bonnet Assy 551 (Silver)            | 17346 | 87089900 | 18% |
| 97200825 | Eicher Tractor Hyd. Distributor Seal Kit - Chotu   | 689   | 87089900 | 18% |
| 97200826 | Eicher Tractor Hyd. Piston Seal Kit(Dia-63) - Chot | 490   | 87089900 | 18% |
| 97200827 | Eicher Tractor B-Check-Kit-621-Es 40/45 Kva-Eicher | 520   | 84212300 | 18% |
| 97200828 | Eicher Tractor C-Check-Kit-621-Es-40/45 Kva-Eicher | 1210  | 84212300 | 18% |
| 97200829 | Eicher Tractor B-Check-Kit-222-Es 7.5/10 Kva       | 330   | 84212300 | 18% |
| 97200830 | Eicher Tractor C-Check-Kit-222-Es-7.5/10 Kva       | 1020  | 84212300 | 18% |
| 97200831 | Eicher Tractor Bonnet Assy 188 (Chottu) Red        | 13368 | 87089900 | 18% |
| 97200832 | Eicher Tractor Cover Assy Fuel Tank 188 (Chottu) R | 9118  | 87089900 | 18% |
| 97200833 | Eicher Tractor Mudguard Left 188 (Chottu) Red      | 8659  | 87089900 | 18% |
| 97200834 | Eicher Tractor Mudguard Right 188 (Chottu) Red     | 8658  | 87089900 | 18% |
| 97200835 | Eicher Tractor Crown+Pinion Kit-188 (93613550+9361 | 7675  | 87084000 | 18% |
| 97200840 | Eicher Tractor Decal Kit 380 Face Lift             | 2435  | 39199090 | 18% |
| 97200841 | Eicher Tractor Decal Kit 480 Face Lift             | 2363  | 39199090 | 18% |
| 97200842 | Eicher Tractor Decal Kit 485 Face Lift             | 2437  | 39199090 | 18% |
| 97200843 | Eicher Tractor Mudgud Rt 380/480/485 Big Top Hyd R | 17570 | 87089900 | 18% |
| 97200844 | Eicher Tractor Mudgud Lt 380/480/485 Big Top Hyd R | 14645 | 87089900 | 18% |
| 97200845 | Eicher Tractor Bonnet Assy - 485 Face Lift Red     | 20263 | 87089900 | 18% |
| 97200846 | Eicher Tractor Bonnet Assy - 485 Face Lift Silver  | 17926 | 87089900 | 18% |
| 97200847 | Eicher Tractor Bonnet Assy - 380 Face Lift Silver  | 16071 | 87089900 | 18% |
| 97200848 | Eicher Tractor Bonnet Assy - 380 Face Lift Red     | 17160 | 87089900 | 18% |
| 97200849 | Eicher Tractor Bonnet Assy - 480 Face Lift Blue    | 17142 | 87089900 | 18% |
| 97200850 | Eicher Tractor Bonnet Assy - 480 Face Lift Silver  | 18479 | 87089900 | 18% |
| 97200851 | Eicher Tractor Mudguard Left - 241/ 242 (White)    | 16655 | 87089900 | 18% |
| 97200852 | Eicher Tractor Mudguard Right - 241/ 242 (White)   | 16638 | 87089900 | 18% |
| 97200853 | Eicher Tractor Bonnet Assy - 333 Super + Blue      | 15396 | 87089900 | 18% |
| 97200854 | Eicher Tractor Bonnet Assy - 380 Super + Red       | 19601 | 87089900 | 18% |
| 97200855 | Eicher Tractor Bonnet Assy - 485 Hd Red            | 17173 | 87089900 | 18% |
| 97200856 | Eicher Tractor Bonnet Assy - 485 Hd Silver         | 18108 | 87089900 | 18% |
| 97200857 | Eicher Tractor Oib Conversion Kit For 241          | 69499 | 87083000 | 18% |
| 97200858 | Eicher Tractor Oib Conversion Kit For 242          | 69299 | 87083000 | 18% |
| 97200859 | Eicher Tractor Bonnet Assy - 650 Silver            | 16174 | 87089900 | 18% |
| 97200860 | Eicher Tractor Axle Tube Lh W/ Ring Gear Kit - 557 | 29834 | 87084000 | 18% |
| 97200861 | Eicher Tractor Axle Tube Rh W/ Ring Gear Kit - 557 | 29834 | 87084000 | 18% |
| 97200862 | Eicher Tractor Decal Kit 368 Red And Yellow Graphi | 1472  | 39199090 | 18% |
| 97200863 | Eicher Tractor Mudgud Lt 380/480/485 Big Top Hyd B | 16148 | 87089900 | 18% |
| 97200864 | Eicher Tractor Mudgud Rt 380 Big Top Hyd Blue      | 13667 | 87089900 | 18% |
| 97200865 | Eicher Tractor Crown+Pinion Kit-188 4Wd (93613550+ | 7206  | 87084000 | 18% |
| 97200866 | Eicher Tractor Decal Kit 333 Red And Yellow Graphi | 1472  | 39199090 | 18% |
| 97200867 | Eicher Tractor Bonnet Assy - 380 Face Lift Blue    | 17160 | 87089900 | 18% |
| 97200869 | Eicher Tractor Bonnet Assy - 480 Face Lift Red     | 15541 | 87089900 | 18% |
| 97200870 | Eicher Tractor Bonnet Assy. - Red 551              | 15682 | 87089900 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200871 | Eicher Tractor Fuel Tank Cover Assy. - Red Hydroma | 8255  | 87089900 | 18% |
| 97200872 | Eicher Tractor Fuel Tank Cover Assy. - Blue Hydrom | 6693  | 87089900 | 18% |
| 97200873 | Eicher Tractor Fuel Tank Cover Assy. - Silver Hydr | 7581  | 87089900 | 18% |
| 97200874 | Eicher Tractor Fuel Tank Cover Assy. - Green Hydro | 8263  | 87089900 | 18% |
| 97200875 | Eicher Tractor Fuel Tank Cover Assy. - Red Non Hyd | 8513  | 87089900 | 18% |
| 97200876 | Eicher Tractor Fuel Tank Cover Assy. - Blue Non Hy | 6597  | 87089900 | 18% |
| 97200877 | Eicher Tractor Fuel Tank Cover Assy. - Silver Non  | 9186  | 87089900 | 18% |
| 97200878 | Eicher Tractor Fuel Tank Cover Assy. - Green Non H | 6053  | 87089900 | 18% |
| 97200879 | Eicher Tractor Retro Kit For Rane Steering (934221 | 12208 | 87089400 | 18% |
| 97200881 | Eicher Tractor Bonnet Assy - 330 Blue              | 17079 | 87089900 | 18% |
| 97200882 | Eicher Tractor Bonnet Assy - 650 Silver            | 26173 | 87089900 | 18% |
| 97200883 | Eicher Tractor Bonnet Assy - 650 Green             | 21367 | 87089900 | 18% |
| 97200884 | Eicher Tractor Bonnet Assy - 650 Red               | 21492 | 87089900 | 18% |
| 97200890 | Eicher Tractor Bonnet Assy - 485 Super + Silver    | 15468 | 87089900 | 18% |
| 97200891 | Eicher Tractor Fuel Tank Cover Assy 650 - Silver   | 11314 | 87089900 | 18% |
| 97200892 | Eicher Tractor Fuel Tank Cover Assy 650 - Green    | 8309  | 87089900 | 18% |
| 97200893 | Eicher Tractor Fuel Tank Cover Assy 650 - Red      | 8434  | 87089900 | 18% |
| 97200894 | Eicher Tractor Kit For Front Weights-650           | 44366 | 87089900 | 18% |
| 97200895 | Eicher Tractor Mudguard Left Big Top - Green       | 14941 | 87089900 | 18% |
| 97200896 | Eicher Tractor Mudguard Right Big Top - Green      | 12451 | 87089900 | 18% |
| 97200897 | Eicher Tractor Bonnet Assy - 551 Hydromatic Silver | 16564 | 87089900 | 18% |
| 97200898 | Eicher Tractor Bonnet Assy - 551 Hydromatic Blue   | 19661 | 87089900 | 18% |
| 97200899 | Eicher Tractor Bonnet Assy - 560 Green             | 15589 | 87089900 | 18% |
| 97200900 | Eicher Tractor Bonnet Assy - 560 Silver            | 15775 | 87089900 | 18% |
| 97200901 | Eicher Tractor Closed Loop Breather Kit            | 9479  | 84099941 | 28% |
| 97200904 | Eicher Tractor New Engine O/H Kit For 485 Trem- li | 19200 | 84099941 | 28% |
| 97200905 | Eicher Tractor New Engine O/H Kit For 485 Trem- li | 19200 | 84099941 | 28% |
| 97200906 | Eicher Tractor New 485 Engine Gasket Kit           | 783   | 84099941 | 28% |
| 97200907 | Eicher Tractor New Engine Gasket Kit (398 Eng)     | 783   | 84099941 | 28% |
| 97200908 | Eicher Tractor New Engine O/H Kit 485 Trem- 3 W/O  | 19200 | 84099941 | 28% |
| 97200909 | Eicher Tractor New Engine O/H Kit For 485 Trem- li | 27282 | 84099941 | 28% |
| 97200910 | Eicher Tractor New Engine O/H Kit 485 Trem - 3 New | 27641 | 84099941 | 28% |
| 97200911 | Eicher Tractor New Engine Overhauling Kit For 548  | 27182 | 84099941 | 28% |
| 97200912 | Eicher Tractor Decal Kit For 241 New               | 1886  | 39199090 | 18% |
| 97200913 | Eicher Tractor Decal Kit For 242 Jbm New           | 2093  | 39199090 | 18% |
| 97200914 | Eicher Tractor Decal Kit For 333 New               | 1701  | 39199090 | 18% |
| 97200915 | Eicher Tractor Decal Kit For 368 New               | 1930  | 39199090 | 18% |
| 97200916 | Eicher Tractor Decal Kit For 380 New               | 1820  | 39199090 | 18% |
| 97200917 | Eicher Tractor Decal Kit For 480 New               | 2067  | 39199090 | 18% |
| 97200918 | Eicher Tractor Decal Kit For 5600 New              | 1935  | 39199090 | 18% |
| 97200919 | Eicher Tractor Decal Kit For 557 New               | 1682  | 39199090 | 18% |
| 97200920 | Eicher Tractor Decal Kit For 548 New               | 1678  | 39199090 | 18% |
| 97200921 | Eicher Tractor Decal Kit For 312 New               | 2177  | 39199090 | 18% |
| 97200922 | Eicher Tractor Decal Kit For 364 New               | 2151  | 39199090 | 18% |
| 97200923 | Eicher Tractor Decal Kit For 485 New               | 2271  | 39199090 | 18% |
| 97200924 | Eicher Tractor Decal Kit For 380 R Line New        | 1575  | 39199090 | 18% |
| 97200925 | Eicher Tractor Decal Kit For 551 New               | 1678  | 39199090 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200926 | Eicher Tractor Decal Kit 380 Face Lift New         | 2475  | 39199090 | 18% |
| 97200927 | Eicher Tractor Decal Kit 480 Face Lift New         | 2571  | 39199090 | 18% |
| 97200928 | Eicher Tractor Decal Kit 485 Face Lift New         | 2643  | 39199090 | 18% |
| 97200929 | Eicher Tractor Decal Kit 368 Red And Yellow Graphi | 1476  | 39199090 | 18% |
| 97200930 | Eicher Tractor Decal Kit 333 Red And Yellow Graphi | 1458  | 39199090 | 18% |
| 97200931 | Eicher Tractor Decal Kit For 188 New               | 380   | 39199090 | 18% |
| 97200932 | Eicher Tractor Decal Kit For 242 Rsm New           | 2505  | 39199090 | 18% |
| 97200933 | Eicher Tractor Decal Kit 380 Red And Yellow Graphi | 1378  | 39199090 | 18% |
| 97200934 | Eicher Tractor Decal Kit For 650 New               | 2102  | 39199090 | 18% |
| 97200935 | Eicher Tractor Bonnet Assy - 557 FI2 Green         | 15343 | 87089900 | 18% |
| 97200936 | Eicher Tractor Bonnet Assy - 557 FI2 Silver        | 18925 | 87089900 | 18% |
| 97200937 | Eicher Tractor Bonnet Assy - 551 FI2 Blue          | 16966 | 87089900 | 18% |
| 97200938 | Eicher Tractor Bonnet Assy - 551 FI2 Silver        | 16325 | 87089900 | 18% |
| 97200939 | Eicher Tractor Bonnet Assy - 548 FI2 Red           | 15634 | 87089900 | 18% |
| 97200940 | Eicher Tractor Bonnet Assy - 548 FI2 Silver        | 19327 | 87089900 | 18% |
| 97200941 | Eicher Tractor Liner Oring Kit Valtra              | 752   | 40169320 | 18% |
| 97200942 | Eicher Tractor Main,Contg Rod,Thrust Brg 0.03"     | 1939  | 73182100 | 18% |
| 97200943 | Eicher Tractor Main,Contg Rod,Thrust Brg 0.02"     | 1939  | 73182100 | 18% |
| 97200944 | Eicher Tractor Main,Contg Rod,Thrust Brg 0.01"     | 1985  | 84099941 | 28% |
| 97200945 | Eicher Tractor Main,Contg Rod,Thrust Brg Std       | 1872  | 84099941 | 28% |
| 97200946 | Eicher Tractor 3 Point Linkage Hardware Kit        | 1960  | 73182100 | 18% |
| 97200947 | Eicher Tractor Conv Kit Non Jer Wt. To Jer Wt.     | 43994 | 87089900 | 18% |
| 97200948 | Eicher Tractor Transmission Gasket Kit Hyd         | 1969  | 68129090 | 18% |
| 97200949 | Eicher Tractor Transmission Gasket Kit 557 & 650   | 4742  | 68129090 | 18% |
| 97200950 | Eicher Tractor Filter Kit 333/380/480              | 1530  | 84212300 | 18% |
| 97200951 | Eicher Tractor Filter Kit 551/557/5660/650         | 1719  | 84212300 | 18% |
| 97200952 | Eicher Tractor Filter Kit 312/364/368/485/548      | 1669  | 84212300 | 18% |
| 97200953 | Eicher Tractor Fuse Box Kit                        | 133   | 85369090 | 18% |
| 97200954 | Eicher Tractor Gear Box Grub Screw Balls & Spring  | 251   | 73202000 | 18% |
| 97200955 | Eicher Tractor Stub Axle Repair Kit - South        | 2460  | 84822011 | 18% |
| 97200956 | Eicher Tractor Stub Axle Repair Kit - North        | 2092  | 84822011 | 18% |
| 97200957 | Eicher Tractor Stub Axle Repair Kit - South Heavy  | 2218  | 84822011 | 18% |
| 97200958 | Eicher Tractor Conv Kit - Front Tyre 6"To7.5" Sil  | 15597 | 87087000 | 18% |
| 97200959 | Eicher Tractor Conv Kit - Front Tyre 6"To7.5" Wt   | 13868 | 87087000 | 18% |
| 97200960 | Eicher Tractor Conv Kit - Front Tyre 6"To7.5" Sil  | 17738 | 87087000 | 18% |
| 97200961 | Eicher Tractor Conv Kit - Front Tyre 6"To7.5" Wt   | 16009 | 87087000 | 18% |
| 97200962 | Eicher Tractor Conv Kit - Front Tyre 6"To7.5" Orn  | 16718 | 87087000 | 18% |
| 97200963 | Eicher Tractor Conv Kit - 35' To 32' Track Width - | 34810 | 87085000 | 18% |
| 97200964 | Eicher Tractor Conv Kit - 241 & 242 Ddb To Oib     | 48488 | 87083000 | 18% |
| 97200965 | Eicher Tractor Conv Kit - Seperate Resrv. To Cor   | 33205 | 84138190 | 18% |
| 97200966 | Eicher Tractor Conv Kit - 551/557/5660/650 Sc-Dc   | 53818 | 87089300 | 18% |
| 97200967 | Eicher Tractor Conv Kit - Center Pin To Cover      | 48840 | 84099941 | 28% |
| 97200968 | Eicher Tractor Conv Kit - Jerry To Non Jerry Wt.   | 11341 | 87081010 | 18% |
| 97200969 | Eicher Tractor Conv Kit -Chain To Stabilizer       | 17222 | 87089900 | 18% |
| 97200970 | Eicher Tractor Conv Kit - Dry Brk To Oil Brk Hyd C | 51846 | 87083000 | 18% |
| 97200971 | Eicher Tractor Conv Kit - Non Aux To Aux Valve     | 21362 | 87089900 | 18% |
| 97200972 | Eicher Tractor Conv Kit - Non R To R Line Hyd Ss   | 64986 | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97200973 | Eicher Tractor Conv Kit - Non R To R Line Hyd Cs   | 66057 | 87084000 | 18% |
| 97200974 | Eicher Tractor Conv Kit - Non R To R Line Hyd Expo | 52861 | 87084000 | 18% |
| 97200975 | Eicher Tractor Conv Kit - Non-Mspto To Mspto       | 5741  | 87084000 | 18% |
| 97200976 | Eicher Tractor Conv Kit - Sc To Dc - 368/485/548   | 59157 | 84835010 | 18% |
| 97200977 | Eicher Tractor Conv Kit - Sc To Dc - 380/480       | 64108 | 84099941 | 28% |
| 97200978 | Eicher Tractor Conv Kit - Dry Brk To Oil Brk Hyd S | 51808 | 87083000 | 18% |
| 97200979 | Eicher Tractor Mudguard Left - 557 Silver          | 15452 | 87089900 | 18% |
| 97200980 | Eicher Tractor Mudguard Left - 557 Green           | 14869 | 87089900 | 18% |
| 97200981 | Eicher Tractor Mudguard Left - 551/548 Silver      | 12652 | 87089900 | 18% |
| 97200982 | Eicher Tractor Mudguard Left - 551/548 Red         | 13226 | 87089900 | 18% |
| 97200983 | Eicher Tractor Conv Kit - 551/557/5660/650 Sc-Dc   | 47222 | 87089300 | 18% |
| 97200984 | Eicher Tractor Conv Kit - 551/557/5660/650 Sc-Dc   | 46834 | 87089300 | 18% |
| 97200985 | Eicher Tractor Conv Kit - Ms To Ps 242             | 37000 | 87089400 | 18% |
| 97200986 | Eicher Tractor Power Steering Kit - 242            | 61549 | 87089400 | 18% |
| 97200987 | Eicher Tractor Silencer Kit For 5660 & 557         | 11601 | 84099941 | 28% |
| 97200988 | Eicher Tractor Silencer Kit - For 485 Non Face Lif | 8994  | 84099941 | 28% |
| 97200989 | Eicher Tractor Front Bumper Weight-5660/551 Ps Set | 7796  | 87081010 | 18% |
| 97200990 | Eicher Tractor Front Wheel Weight -5660/551 Ps Set | 13452 | 73259910 | 18% |
| 97200991 | Eicher Tractor Overheating Kit - 650               | 5062  | 87089100 | 18% |
| 97200992 | Eicher Tractor Crown+Pinion Kit-330 (93657425+1011 | 8328  | 87084000 | 18% |
| 97200993 | Eicher Tractor Bonnet Assy - 330 Silver            | 15335 | 87089900 | 18% |
| 97200994 | Eicher Tractor Mudguard Right -333 Hyd Silver Smal | 15122 | 87089900 | 18% |
| 97200995 | Eicher Tractor Mudguard Right - 333 White Small To | 15766 | 87089900 | 18% |
| 97200996 | Eicher Tractor Mudguard Left -333 Hyd Silver Small | 15122 | 87089900 | 18% |
| 97200997 | Eicher Tractor Mudguard Left - 333 White Small Top | 13214 | 87089900 | 18% |
| 97200998 | Eicher Tractor Mudguard Left - 551 Blue            | 15073 | 87089900 | 18% |
| 97200999 | Eicher Tractor Mudguard Right - 551 Blue           | 14438 | 87089900 | 18% |
| 97201000 | Eicher Tractor Mudguard Left - 330 Silver          | 16487 | 87089900 | 18% |
| 97201001 | Eicher Tractor Mudguard Right - 330 Silver         | 16487 | 87089900 | 18% |
| 97201002 | Eicher Tractor Bonnet Assy 188 (Chottu) Red New    | 10417 | 87089900 | 18% |
| 97201003 | Eicher Tractor Front Wheel Hub - Lh / Stub Axle    | 9039  | 87087000 | 18% |
| 97201004 | Eicher Tractor Front Wheel Hub - Rh / Stub Axle    | 9045  | 87087000 | 18% |
| 97201005 | Eicher Tractor Rane Bearing Kit                    | 1992  | 87089400 | 18% |
| 97201006 | Eicher Tractor Steel Ball Kit - 242                | 23    | 84829119 | 18% |
| 97201007 | Eicher Tractor Half Gearbox Packing Kit - 242      | 276   | 68129090 | 18% |
| 97201008 | Eicher Tractor Half Gear Box Packing Kit - 241     | 225   | 68129090 | 18% |
| 97201009 | Eicher Tractor Star Washer Kit - 242               | 711   | 73182100 | 18% |
| 97201010 | Eicher Tractor Washer Kit 3 Star                   | 915   | 73182100 | 18% |
| 97201011 | Eicher Tractor Goli Spring Kit - 380/485           | 51    | 73202000 | 18% |
| 97201012 | Eicher Tractor Radiator Hose Pipe Kit - 380        | 2075  | 40093100 | 18% |
| 97201013 | Eicher Tractor Hyd. Bush Set - 380/485             | 817   | 87089900 | 18% |
| 97201014 | Eicher Tractor Roto Glydring Kit - 551/557/548/566 | 504   | 39269099 | 18% |
| 97201015 | Eicher Tractor Lock Washer Kit Gear Box            | 87    | 73182100 | 18% |
| 97201016 | Eicher Tractor Disc Assy Kit - 241                 | 1949  | 87089300 | 18% |
| 97201025 | Eicher Tractor Eicher Rakshak Wet Disc Brake Oil(1 | 380   | 27101980 | 18% |
| 97201026 | Eicher Tractor 4 *Dif O/H Kit 93620037/93624122/93 | 6345  | 87084000 | 18% |
| 97201027 | Eicher Tractor 3 *Diffo/H Kit 93627883/93624122/93 | 5394  | 87084000 | 18% |



|          |  |       |          |     |
|----------|--|-------|----------|-----|
| 97201028 | Eicher Tractor Distributor Assy Kit (93736655+9373 | 8934  | 87089900 | 18% |
| 97201029 | Eicher Tractor Mudguard Lt Big Top White Hyd       | 13642 | 87089900 | 18% |
| 97201030 | Eicher Tractor Mudguard Lt Big Top Silver Hyd      | 13536 | 87089900 | 18% |
| 97201031 | Eicher Tractor Mudguard Lt Big Top Hyd Red Hyd     | 15408 | 87089900 | 18% |
| 97201032 | Eicher Tractor Mudguard Lt Big Top Hyd Blue Hyd    | 12901 | 87089900 | 18% |
| 97201033 | Eicher Tractor Mudguard Lt-333/368/380 Silver S To | 14902 | 87089900 | 18% |
| 97201034 | Eicher Tractor Mudguard Lt-333/368/380 White S Top | 15598 | 87089900 | 18% |
| 97201035 | Eicher Tractor Mudguard Lt Big Top White Hyd/Back  | 14938 | 87089900 | 18% |
| 97201036 | Eicher Tractor Mudguard Lt Big Top Silver Hyd/Back | 14837 | 87089900 | 18% |
| 97201037 | Eicher Tractor Mudguard Lt Big Top Hyd Red Hyd/Bac | 16616 | 87089900 | 18% |
| 97201038 | Eicher Tractor Mudguard Lt Big Top Hyd Blue Hyd/Ba | 14234 | 87089900 | 18% |
| 97201039 | Eicher Tractor Mudguard Lt Silver S Top Hyd/Back R | 16135 | 87089900 | 18% |
| 97201040 | Eicher Tractor Mudguard Lt White S Top Hyd/Back Re | 16796 | 87089900 | 18% |
| 97201041 | Eicher Tractor Heat Shield Kit 548/548/560         | 2473  | 87089900 | 18% |
| 97201042 | Eicher Tractor Auxiliary Valve Kit 5 & 6 Series    | 21362 | 87089900 | 18% |
| 97201043 | Eicher Tractor Engine Overhauling Kit - 650        | 31652 | 84099941 | 28% |
| 97201044 | Eicher Tractor Engine Gasket Kit - 650             | 3557  | 84099941 | 28% |
| 97201045 | Eicher Tractor Mudguard Left Big Top - Blue        | 17026 | 87089900 | 18% |
| 97201046 | Eicher Tractor Bonnet Assy - 480 FI3 Blue          | 17412 | 87089900 | 18% |
| 97201047 | Eicher Tractor Bonnet Assy - 480 FI3 Red           | 16484 | 87089900 | 18% |
| 97201048 | Eicher Tractor Bonnet Assy - 480 FI3 Silver        | 15012 | 87089900 | 18% |
| 97201049 | Eicher Tractor Bonnet Assy - 551 FI3 Blue          | 17412 | 87089900 | 18% |
| 97201050 | Eicher Tractor Bonnet Assy - 551 FI3 Silver        | 17245 | 87089900 | 18% |
| 97201051 | Eicher Tractor Bonnet Assy - 548 FI3 Silver        | 17245 | 87089900 | 18% |
| 97201052 | Eicher Tractor Bonnet Assy - 548 FI3 Red           | 17308 | 87089900 | 18% |
| 97201053 | Eicher Tractor Bonnet Assy - FI3 Green 557/551 Sup | 17312 | 87089900 | 18% |
| 97201054 | Eicher Tractor Bonnet Assy - FI3 Silver 557/551 Su | 17753 | 87089900 | 18% |
| 97201055 | Eicher Tractor Bonnet Assy - 485 FI3 Red           | 16484 | 87089900 | 18% |
| 97201056 | Eicher Tractor Bonnet Assy - 485 FI3 Silver        | 15012 | 87089900 | 18% |
| 97201057 | Eicher Tractor Crown Pinion Kit - 557/650 4Wd      | 28814 | 87084000 | 18% |
| 97201058 | Eicher Tractor Mudguard Kit Left - 557 Silver      | 19600 | 87089900 | 18% |
| 97201059 | Eicher Tractor Mudguard Kit Left - 557 Green       | 20811 | 87089900 | 18% |
| 97201060 | Eicher Tractor Mudguard Kit Left - 551/548 Silver  | 16257 | 87089900 | 18% |
| 97201062 | Eicher Tractor Main Wiring Harness Kit (551/557/56 | 3670  | 85443000 | 18% |
| 97201063 | Eicher Tractor Main Wiring Harness Kit (548)- FI2  | 3726  | 85123010 | 18% |
| 97201064 | Eicher Tractor Decal Kit For 480 Rf3               | 3108  | 39199090 | 18% |
| 97201065 | Eicher Tractor Decal Kit For 485 Rf3               | 3120  | 39199090 | 18% |
| 97201066 | Eicher Tractor Decal Kit For 548 Rf3               | 3085  | 39199090 | 18% |
| 97201067 | Eicher Tractor Decal Kit For 551 Rf3               | 3114  | 39199090 | 18% |
| 97201068 | Eicher Tractor Decal Kit For 557 Rf3               | 2985  | 39199090 | 18% |
| 97201091 | Eicher Tractor Bonnet Assy - 380 Super Power Blue  | 17452 | 87089900 | 18% |
| 97201092 | Eicher Tractor Bonnet Assy - 380 Super Power Silve | 17650 | 87089900 | 18% |
| 97201093 | Eicher Tractor Addc Linkage Assembly 5&6 Series    | 4297  | 87089900 | 18% |
| 97201099 | Eicher Tractor Rakshak Fastener Kit- Frp Canopy &  | 1068  | 73181500 | 18% |
| 97201100 | Eicher Tractor Crown Pinion Kit - 557/650 Creeper  | 42059 | 87084000 | 18% |
| 97201101 | Eicher Tractor Rakshak Engine Oil Ci4 10W30 1 Ltr  | 350   | 27101980 | 18% |
| 97201102 | Eicher Tractor Rakshak Engine Oil Ci4 10W30 10 Ltr | 3560  | 27101980 | 18% |





|            |   |       |          |     |
|------------|---|-------|----------|-----|
| 97201105   | Eicher Tractor Decal Kit 380 F13                    | 3231  | 39199090 | 18% |
| 97201106   | Eicher Tractor Engine O/H Kit For 188               | 9789  | 84099941 | 28% |
| 97201107   | Eicher Tractor Rakshak Engine Oil Super Plus - 6.5  | 2150  | 27101980 | 18% |
| 97201108   | Eicher Tractor Rakshak Engine Oil Super Plus - 8 L  | 2640  | 27101980 | 18% |
| 97201109   | Eicher Tractor Rakshak Engine Oil Super Plus - 10   | 3300  | 27101980 | 18% |
| 97201110   | Eicher Tractor Rakshak Fastener Kit For - 551       | 1207  | 73181500 | 18% |
| 97201111   | Eicher Tractor Scuttle (Fuel Tank Cover-Rear Open)  | 13090 | 87089900 | 18% |
| 97201112   | Eicher Tractor Scuttle (Fuel Tank Cover-Front Open) | 13053 | 87089900 | 18% |
| 97201113   | Eicher Tractor Fuel Lid Assy - Es3 Red              | 1034  | 87089900 | 18% |
| 97201114   | Eicher Tractor Bonnet Assy - 380/480/551 Es3 Red    | 36652 | 87089900 | 18% |
| 97201115   | Eicher Tractor Bonnet Assy - 380 Super Power Es3 R  | 56222 | 87089900 | 18% |
| 97201116   | Eicher Tractor Bonnet Assy - 557 Es3 Red            | 37139 | 87089900 | 18% |
| 97201118   | Eicher Tractor Crown Pinion Kit - 380/480/551 4Wd   | 11421 | 87084000 | 18% |
| 97201119   | Eicher Tractor Bonnet Assy - 368 F13 Red            | 23339 | 87089900 | 18% |
| 97201120   | Eicher Tractor Bonnet Assy - 368 F13 Silver         | 23378 | 87089900 | 18% |
| 97201121   | Eicher Tractor Bonnet Assy - 380 F13 Blue           | 23234 | 87089900 | 18% |
| 97201123   | Eicher Tractor Guard & Improved Tie Rod End Kit 4W  | 3081  | 87089400 | 18% |
| 97201145   | Eicher Tractor Fuel Lid Assy - Es3 Red              | 962   | 87089900 | 18% |
| 97201146   | Eicher Tractor Fuel Tank Lid Kit - Es3 Red          | 3977  | 87089900 | 18% |
| 97201147   | Eicher Tractor Rakshak Gear Oil Ep90 - 26 Ltr       | 7120  | 27101980 | 18% |
| 97201148   | Eicher Tractor Rakshak Gear Oil Ep90 - 5 Ltr        | 1490  | 27101980 | 18% |
| 97201153   | Eicher Tractor Rakshak Engine Oil Super Plus - 6.5  | 2210  | 27101980 | 18% |
| 97201154   | Eicher Tractor Rakshak Engine Oil Super Plus - 8 L  | 2710  | 27101980 | 18% |
| 97201155   | Eicher Tractor Rakshak Engine Oil Super Plus - 10   | 3390  | 27101980 | 18% |
| 99319945   | Eicher Tractor Mobile Charger Box                   | 1135  | 39021000 | 18% |
| 862053136  | Eicher Tractor Flywheel Housing 18Hp (2Wd) - Finis  | 14181 | 87084000 | 18% |
| 934817854  | Eicher Tractor Hook Clutch                          | 82    | 73181500 | 18% |
| 936919017  | Eicher Tractor Bracket Main Transmission            | 1348  | 87089900 | 18% |
| 938211481  | Eicher Tractor Tank Unit                            | 456   | 90261020 | 18% |
| 1000000001 | Eicher Tractor Sealing Washer                       | 8     | 84841010 | 18% |
| 1000000002 | Eicher Tractor Hex Bolt                             | 6     | 73181500 | 18% |
| 1000000003 | Eicher Tractor Hex Nut                              | 13    | 73181600 | 18% |
| 1000000004 | Eicher Tractor Hex Nut                              | 2     | 73181600 | 18% |
| 1000000005 | Eicher Tractor Hex Bolt                             | 22    | 73181500 | 18% |
| 1000000006 | Eicher Tractor Washer                               | 2     | 73182100 | 18% |
| 1000000007 | Eicher Tractor Washer                               | 1     | 73182100 | 18% |
| 1000000008 | Eicher Tractor Washer                               | 1     | 73182100 | 18% |
| 1000000009 | Eicher Tractor Washer                               | 2     | 73182100 | 18% |
| 1000000010 | Eicher Tractor Washer                               | 6     | 73182100 | 18% |
| 1000000011 | Eicher Tractor Washer                               | 4     | 73182100 | 18% |
| 1000000013 | Eicher Tractor Hex Bolt                             | 40    | 73181500 | 18% |
| 1000000014 | Eicher Tractor Circlip - Input & Output Shaft       | 20    | 73209090 | 18% |
| 1000000015 | Eicher Tractor Hex Bolt                             | 30    | 73181600 | 18% |
| 1000000016 | Eicher Tractor Sealing Washer                       | 13    | 74152100 | 18% |
| 1000000017 | Eicher Tractor Hex Bolt                             | 20    | 73181500 | 18% |
| 1000000019 | Eicher Tractor Linch Pin - Lower Link Hitch         | 20    | 87089900 | 18% |
| 1000000020 | Eicher Tractor Hex Bolt                             | 10    | 73181500 | 18% |



|           |   |       |          |     |
|-----------|---|-------|----------|-----|
| 100000021 | Eicher Tractor Grease Nipple                  | 5     | 87089900 | 18% |
| 100000024 | Eicher Tractor Sealing Washer                 | 12    | 74152100 | 18% |
| 100000025 | Eicher Tractor Breather                       | 130   | 84329090 | 12% |
| 100000026 | Eicher Tractor Hex Bolt                       | 50    | 73181500 | 18% |
| 100000027 | Eicher Tractor Cs Screw                       | 10    | 73181600 | 18% |
| 100000028 | Eicher Tractor Hex Screw                      | 10    | 73181500 | 18% |
| 100000029 | Eicher Tractor Hex Bolt                       | 10    | 73181500 | 18% |
| 100000030 | Eicher Tractor Bolt                           | 10    | 73181500 | 18% |
| 100000033 | Eicher Tractor Hex Bolt                       | 12    | 73181500 | 18% |
| 100000034 | Eicher Tractor Bolt                           | 13    | 73181500 | 18% |
| 100000036 | Eicher Tractor Hex Nut                        | 3     | 73181600 | 18% |
| 100000037 | Eicher Tractor Hex Nut                        | 5     | 73181600 | 18% |
| 100000042 | Eicher Tractor Lock Pin                       | 56    | 84329090 | 12% |
| 100000051 | Eicher Tractor Rotary Tiller-Gear 20T-5M      | 884   | 84329090 | 12% |
| 100000052 | Eicher Tractor Rotary Tiller-Gear 24T         | 1160  | 84329090 | 12% |
| 100000057 | Eicher Tractor O - Ring Jack Shaft            | 33    | 40169320 | 18% |
| 100000058 | Eicher Tractor I/P Bearing Assy Trb           | 688   | 84822011 | 18% |
| 100000059 | Eicher Tractor Seal - Stub Axle               | 70    | 84329090 | 12% |
| 100000060 | Eicher Tractor Bearing Assy Trb               | 900   | 84822011 | 18% |
| 100000061 | Eicher Tractor Bearing Idler                  | 448   | 84822011 | 18% |
| 100000062 | Eicher Tractor Ring Nut                       | 224   | 84328020 | 12% |
| 100000066 | Eicher Tractor Spacer Skid                    | 51    | 84329090 | 12% |
| 100000072 | Eicher Tractor Gasket - Grease Cup            | 23    | 84329090 | 12% |
| 100000078 | Eicher Tractor Cover Idler                    | 144   | 84329090 | 12% |
| 100000081 | Eicher Tractor Bearing Stub Axle              | 746   | 84821011 | 18% |
| 100000082 | Eicher Tractor Seal - I/P Shaft               | 60    | 4016     | 18% |
| 100000083 | Eicher Tractor Circlip                        | 49    | 4016     | 18% |
| 100000090 | Eicher Tractor Seal - Jack Shaft              | 78    | 4016     | 18% |
| 100000094 | Eicher Tractor Assy - Rotor Shaft - 36 Ms     | 15284 | 84329090 | 12% |
| 100000098 | Eicher Tractor Spacer                         | 69    | 84329090 | 12% |
| 100000099 | Eicher Tractor Hitch Pin Lower Link           | 342   | 84329090 | 12% |
| 100000102 | Eicher Tractor Assy Tail Board - 36Blades     | 4985  | 84329090 | 12% |
| 100000103 | Eicher Tractor Assy Tail Board Adjuster       | 189   | 84329090 | 12% |
| 100000106 | Eicher Tractor Lock Pin - Tail Board Adjuster | 67    | 84329090 | 12% |
| 100000107 | Eicher Tractor Spring Long                    | 59    | 84329090 | 12% |
| 100000108 | Eicher Tractor Spring Small                   | 64    | 84329090 | 12% |
| 100000109 | Eicher Tractor Support Bracket                | 124   | 84329090 | 12% |
| 100000110 | Eicher Tractor Blade - Lh - 36 Ms             | 239   | 84329090 | 12% |
| 100000111 | Eicher Tractor Blade - Rh - 36 Ms             | 239   | 84329090 | 12% |
| 100000114 | Eicher Tractor Depth Skid Shoe                | 242   | 84329090 | 12% |
| 100000115 | Eicher Tractor Hex Bolt                       | 80    | 73181500 | 18% |
| 100000120 | Eicher Tractor O - Ring Input Shaft Ms        | 32    | 40169320 | 18% |
| 100000122 | Eicher Tractor Spacer - Multi Speed           | 68    | 84329090 | 12% |
| 100000123 | Eicher Tractor Gb Cap Multi Front             | 227   | 84329090 | 12% |
| 100000127 | Eicher Tractor Assy Jack Shaft 42 Ms          | 4655  | 84329090 | 12% |
| 100000128 | Eicher Tractor Assy Flange - Ms Gearbox Mtg   | 869   | 84329090 | 12% |
| 100000129 | Eicher Tractor Jack Shaft - Multispeed        | 2023  | 84329090 | 12% |



|           |   |       |          |     |
|-----------|---|-------|----------|-----|
| 100000131 | Eicher Tractor Drive Gear                           | 1492  | 84834000 | 18% |
| 100000136 | Eicher Tractor Gasket Jackshaft                     | 19    | 48239030 | 18% |
| 100000137 | Eicher Tractor Assy - Rotor Shaft - 42 Ms           | 16574 | 84329090 | 12% |
| 100000138 | Eicher Tractor Assy Tail Board - 42Blades           | 5256  | 84329090 | 12% |
| 100000139 | Eicher Tractor Rod Tail Board - 36Blades            | 560   | 84329090 | 12% |
| 100000140 | Eicher Tractor Rod Tail Board - 42Blades            | 650   | 84329090 | 12% |
| 100000141 | Eicher Tractor Hex Bolt                             | 23    | 73181500 | 18% |
| 100000142 | Eicher Tractor Hex Nut                              | 11    | 73181600 | 18% |
| 100000143 | Eicher Tractor Cross And Bearing Kit                | 848   | 84329090 | 12% |
| 100000159 | Eicher Tractor Nyloc Nut M30                        | 100   | 84329090 | 12% |
| 100000161 | Eicher Tractor Tab Washer                           | 34    | 84329090 | 12% |
| 100000162 | Eicher Tractor Rotary Tiller-M30 Castle Nut         | 90    | 73181600 | 18% |
| 100000163 | Eicher Tractor Roto Tiller – Spring Long 42         | 255   | 73209090 | 18% |
| 100000164 | Eicher Tractor Split Pin                            | 10    | 73181500 | 18% |
| 100000165 | Eicher Tractor Rotary Tiller - Assy Jack Shaft-42   | 4100  | 84329090 | 12% |
| 100000166 | Eicher Tractor Rotary Tiller - Assy Jack Shaft -36  | 3770  | 84329090 | 12% |
| 100000167 | Eicher Tractor Rotary Tiller-Cardan Shaft           | 8822  | 84329090 | 12% |
| 100000168 | Eicher Tractor Rotary Tiller - Assy Jackshaft-48 B  | 4320  | 84329090 | 12% |
| 100000169 | Eicher Tractor Rotary Tiller - Assy Main Frme -42   | 16047 | 84329090 | 12% |
| 100000170 | Eicher Tractor Rotary Tiller - Assy Main Frme -48   | 16171 | 84329090 | 12% |
| 100000171 | Eicher Tractor Rotary Tiller-Tool Kit               | 561   | 82060090 | 18% |
| 100000172 | Eicher Tractor Rotary Tiller-Assy Main Frme -36 Bl  | 13066 | 84329090 | 12% |
| 100000173 | Eicher Tractor Rotary Tiller-Dust Cover             | 632   | 84329090 | 12% |
| 100000174 | Eicher Tractor Rotary Tiller - Gear Pair Dcl (20/2  | 1     | 49089000 | 12% |
| 100000175 | Eicher Tractor Rotary Tiller-Hair Pin               | 9     | 84329090 | 12% |
| 100000176 | Eicher Tractor Rotary Tiller- Assy Tail Board Adju  | 375   | 84329090 | 12% |
| 100000177 | Eicher Tractor Rotary Tiller - Washer - Rear Hood   | 13    | 87089900 | 18% |
| 100000179 | Eicher Tractor Rotary Tiller - Spring Small 42      | 58    | 73209090 | 18% |
| 100000182 | Eicher Tractor Rotary Tiller - Gear Pair Dcl (14/1  | 2     | 49089000 | 12% |
| 100000183 | Eicher Tractor Bottom Plate - Hitch Assy            | 684   | 84329090 | 12% |
| 100000184 | Eicher Tractor Rotary Tiller - Gear Pair Dcl (20/2  | 2     | 49089000 | 12% |
| 100000186 | Eicher Tractor Hex Bolt – M12X1.75-80L              | 30    | 73181500 | 18% |
| 100000188 | Eicher Tractor Rotary Tiller - Assembly Side Disc   | 6833  | 84329090 | 12% |
| 100000189 | Eicher Tractor Rotary Tiller - Assy Hitch Bracket   | 1573  | 84329090 | 12% |
| 100000190 | Eicher Tractor Rotary Tiller - Nyloc Nut - Flange   | 16    | 73181600 | 18% |
| 100000191 | Eicher Tractor Rotary Tiller - Flange Idler         | 1510  | 84329090 | 12% |
| 100000192 | Eicher Tractor Rotary Tiller - Gasket - Side Cover  | 384   | 40169390 | 18% |
| 100000194 | Eicher Tractor Rotary Tiller - Bearing Housing – L  | 1732  | 84329090 | 12% |
| 100000195 | Eicher Tractor Rotary Tiller - Spring Holder        | 97    | 73261990 | 18% |
| 100000196 | Eicher Tractor Rotary Tiller- U-Bolt M16X2          | 140   | 84329090 | 12% |
| 100000197 | Eicher Tractor Rotary Tiller Gasket Cover Idler     | 14    | 48239030 | 18% |
| 100000198 | Eicher Tractor Rotary Tiller - Holding Bracket      | 225   | 84329090 | 12% |
| 100000199 | Eicher Tractor Rotary Tiller-Dcl(Kp Awy Frm Rotng   | 13    | 39199090 | 18% |
| 100000200 | Eicher Tractor Rotary Tiller-Dcl(Kp Awy Frm Crdn S  | 13    | 39199090 | 18% |
| 100000201 | Eicher Tractor Rotary Tiller-Dcl(Working On The M/  | 13    | 39199090 | 18% |
| 100000202 | Eicher Tractor Rotary Tiller-Dcl(Operating Instruct | 13    | 39199090 | 18% |
| 100000203 | Eicher Tractor Rotary Tiller-Dcl(Projections)       | 13    | 39199090 | 18% |



|           |   |       |          |     |
|-----------|---|-------|----------|-----|
| 100000204 | Eicher Tractor Rotary Tiller-Dcl(Don'T Step On The  | 13    | 39199090 | 18% |
| 100000205 | Eicher Tractor Rotary Tiller-Dcl(Coupling Pnt Fr Li | 5     | 39199090 | 18% |
| 100000206 | Eicher Tractor Rotary Tiller-Dcl(Oil Filling Locat  | 4     | 39199090 | 18% |
| 100000207 | Eicher Tractor Rotary Tiller-Dcl(Pto Rated Rpm)     | 4     | 49089000 | 12% |
| 100000208 | Eicher Tractor Rotary Tiller-Dcl(Oil Level Chking   | 3     | 39199090 | 18% |
| 100000209 | Eicher Tractor Rotary Tiller-Dcl(Eicher Logo)       | 46    | 84329090 | 12% |
| 100000210 | Eicher Tractor Rotary Tiller-Dcl(Agristar Logo)     | 67    | 49089000 | 12% |
| 100000211 | Eicher Tractor Rotary Tiller- Plate Serial Number   | 26    | 83100010 | 18% |
| 100000212 | Eicher Tractor Rivet                                | 3     | 73181500 | 18% |
| 100000215 | Eicher Tractor Rotary Tiller-Side Plate Lh          | 2938  | 84329090 | 12% |
| 100000216 | Eicher Tractor Rotary Tiller-O Ring Bearing Housin  | 35    | 40169320 | 18% |
| 100000217 | Eicher Tractor Rotary Tiller-Side Plate Rh          | 2844  | 84329090 | 12% |
| 100000218 | Eicher Tractor Rotary Tiller-Gasket Grease Cap      | 24    | 48239030 | 18% |
| 100000219 | Eicher Tractor Rotary Tiller - Grease Cup           | 539   | 84329090 | 12% |
| 100000220 | Eicher Tractor Rotary Tiller - Hex Head Bolt M12 X  | 20    | 73181500 | 18% |
| 100000221 | Eicher Tractor Rotary Tiller - Side Plate Lh        | 3090  | 84329090 | 12% |
| 100000222 | Eicher Tractor Rotary Tiller-Gearcap Front          | 289   | 84329090 | 12% |
| 100000223 | Eicher Tractor Rotary Tiller - Spring Dowel Od 4.6  | 3     | 73182100 | 18% |
| 100000224 | Eicher Tractor Rotary Tiller - Gasket Rear Ms       | 30    | 48239030 | 18% |
| 100000225 | Eicher Tractor Rotary Tiller-Gasket Dummy Flange    | 20    | 48239030 | 18% |
| 100000226 | Eicher Tractor Rotary Tiller - Assy Side Plate Lh   | 2599  | 84329090 | 12% |
| 100000227 | Eicher Tractor Rotary Tiller - Jack Shaft Ms-36     | 2113  | 84329090 | 12% |
| 100000228 | Eicher Tractor Rotary Tiller-M10 Nyloc Nut          | 10    | 73181600 | 18% |
| 100000229 | Eicher Tractor Rotary Tiller - Gear Box Assy        | 16132 | 84329090 | 12% |
| 100000230 | Eicher Tractor Bearing Stub Axle Crb Hsv            | 1089  | 84825011 | 18% |
| 100000231 | Eicher Tractor Rotary Tiller-Driven Flange Lh       | 1890  | 84329090 | 12% |
| 100000232 | Eicher Tractor Rotary Tiller- Shim Spacer - I       | 78    | 84329090 | 12% |
| 100000233 | Eicher Tractor Rotary Tiller - Output Shaft         | 1191  | 84329090 | 12% |
| 100000234 | Eicher Tractor Rotary Tiller-M40 Catle Nut          | 120   | 73181600 | 18% |
| 100000235 | Eicher Tractor Split Pin - Castle Nut-6.3Dia        | 10    | 73181600 | 18% |
| 100000236 | Eicher Tractor Rotary Tiller-Driven Flange Rh       | 1891  | 84329090 | 12% |
| 100000237 | Eicher Tractor Rotary Tiller - Gear 20T-5.5M (P100  | 1300  | 84329090 | 12% |
| 100000238 | Eicher Tractor Rotary Tiller - Gear 21T-5.5M (P100  | 1246  | 84329090 | 12% |
| 100000240 | Eicher Tractor Rotary Tiller - Flange Idler         | 1962  | 84329090 | 12% |
| 100000241 | Eicher Tractor Rotary Tiller-Assy Tail Board-42 Bl  | 8563  | 84329090 | 12% |
| 100000244 | Eicher Tractor Rotary Tiller-Hitch Bracket Long To  | 1676  | 84329090 | 12% |
| 100000245 | Eicher Tractor Rotary Tiller-Hitch Bracket Long To  | 1541  | 84329090 | 12% |
| 100000246 | Eicher Tractor Rotary Tiller - Hitch Bkt - Small L  | 757   | 84329090 | 12% |
| 100000247 | Eicher Tractor Rotary Tiller- Spacer                | 68    | 84329090 | 12% |
| 100000248 | Eicher Tractor Rotary Tiller-Assy Depth Skid        | 1017  | 84329090 | 12% |
| 100000249 | Eicher Tractor Rotary Tiller-Assy Skid Adjuster     | 330   | 84329090 | 12% |
| 100000250 | Eicher Tractor Rotary Tiller- Assy Depth Skid       | 1610  | 84329090 | 12% |
| 100000252 | Eicher Tractor Rotary Tiller-Depth Skid Shoe        | 432   | 84329090 | 12% |
| 100000253 | Eicher Tractor Rotary Tiller-Spacer Skid            | 45    | 84329090 | 12% |
| 100000255 | Eicher Tractor Rotary Tiller-Assy Telescopic Leg    | 348   | 84329090 | 12% |
| 100000256 | Eicher Tractor Rotary Tiller-Hair Pin               | 29    | 84329090 | 12% |
| 100000257 | Eicher Tractor Rotary Tiller-Assy Side Cover        | 1037  | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000259 | Eicher Tractor Rotary Tiller-Assy Rotor Shaft-42 B | 16326 | 84329090 | 12% |
| 100000260 | Eicher Tractor Rotary Tiller - Gear Box Multispeed | 8966  | 84329090 | 12% |
| 100000261 | Eicher Tractor Rotary Tiller - Gear Box Cover - Co | 1220  | 84329090 | 12% |
| 100000263 | Eicher Tractor Rotary Tiller - Jack Shaft Ms-42    | 3897  | 84329090 | 12% |
| 100000264 | Eicher Tractor Rotary Tiller-Bearing Housing-Lh    | 1267  | 84329090 | 12% |
| 100000265 | Eicher Tractor Rotary Tiller-Bearing Housing-Rh    | 1405  | 84329090 | 12% |
| 100000266 | Eicher Tractor Rotary Tiller-Gb Cap Multi Front    | 285   | 84329090 | 12% |
| 100000270 | Eicher Tractor Yoke Assy Tractor Side              | 2689  | 84329090 | 12% |
| 100000271 | Eicher Tractor Yoke Assy Tiller Side               | 3251  | 84329090 | 12% |
| 100000272 | Eicher Tractor Rotary Tiller-Assy Tail Board-36 Bl | 7475  | 84329090 | 12% |
| 100000273 | Eicher Tractor Cardan Shaft Mj                     | 9482  | 84831099 | 18% |
| 100000274 | Eicher Tractor Rotary Tiller-Side Strip            | 266   | 84329090 | 12% |
| 100000275 | Eicher Tractor Plug Magnetic Drain                 | 88    | 84329090 | 12% |
| 100000276 | Eicher Tractor Rotary Tiller-Shim Clamp 3.25       | 61    | 84329090 | 12% |
| 100000277 | Eicher Tractor Profile Tubes - Inner & Outer       | 1491  | 84329090 | 12% |
| 100000278 | Eicher Tractor Quick Release Pin - 6 Spline        | 50    | 84329090 | 12% |
| 100000279 | Eicher Tractor Shear Bolt With Nut - 8.8 Grade     | 76    | 84329090 | 12% |
| 100000280 | Eicher Tractor Shear Yoke                          | 1934  | 84329090 | 12% |
| 100000281 | Eicher Tractor Simple Yoke - Inner Tube            | 1555  | 84329090 | 12% |
| 100000282 | Eicher Tractor Simple Yoke - Outer Tube            | 1562  | 84329090 | 12% |
| 100000283 | Eicher Tractor Spring Yoke                         | 1280  | 84329090 | 12% |
| 100000284 | Eicher Tractor U.J. Cross - 38Mm Dia               | 869   | 84329090 | 12% |
| 100000285 | Eicher Tractor Rotary Tiller - Hex Bolt - M14X1.5- | 30    | 73181500 | 18% |
| 100000286 | Eicher Tractor Guard                               | 1112  | 84329090 | 12% |
| 100000287 | Eicher Tractor Rotary Tiller-Gear Pair 14/19       | 2282  | 84329090 | 12% |
| 100000288 | Eicher Tractor Rotary Tiller-Gear Pair 20/24       | 2635  | 84329090 | 12% |
| 100000289 | Eicher Tractor Rotary Tiller-Gear Pair 20/21       | 2470  | 84329090 | 12% |
| 100000290 | Eicher Tractor Rotary Tiller-Gear Pair 13/23       | 3460  | 84329090 | 12% |
| 100000291 | Eicher Tractor Rotary Tiller- Assy Hitch Bracket S | 1220  | 84329090 | 12% |
| 100000292 | Eicher Tractor Rotary Tiller- Bottom Plate - Hitch | 543   | 84329090 | 12% |
| 100000293 | Eicher Tractor Rotary Tiller- Shim Spacer          | 17    | 84329090 | 12% |
| 100000294 | Eicher Tractor Rotary Tiller- Shim Spacer          | 21    | 84329090 | 12% |
| 100000295 | Eicher Tractor Jack Shaft-Multispeed 48 Blades (Ze | 4704  | 84329090 | 12% |
| 100000296 | Eicher Tractor Jack Shaft-Multispeed 48 Blades (Of | 3340  | 84329090 | 12% |
| 100000298 | Eicher Tractor Rotary Tiller-Assy Jackshaft-48 Bla | 3117  | 84329090 | 12% |
| 100000302 | Eicher Tractor Rotary Tiller-Assy Side Plate Rh Ss | 1756  | 84329090 | 12% |
| 100000303 | Eicher Tractor Rotary Tiller-Assy Tail Board- 48 B | 13197 | 84329090 | 12% |
| 100000304 | Eicher Tractor Rotary Tiller- Rod Tail Board- 48 B | 730   | 84329090 | 12% |
| 100000305 | Eicher Tractor Washer (New Addition For Pins)      | 12    | 73182100 | 18% |
| 100000306 | Eicher Tractor Rotarytiller-Assyrotorshaft-36Bl    | 14733 | 84329090 | 12% |
| 100000307 | Eicher Tractor Rotary Tiller-Assy Rotor Shaft-48 B | 16493 | 84329090 | 12% |
| 100000309 | Eicher Tractor Grease Nipple M8                    | 18    | 84329090 | 12% |
| 100000310 | Eicher Tractor Rotary Tiller - Assy Jack Shaft - 3 | 3256  | 84329090 | 12% |
| 100000311 | Eicher Tractor Rotary Tiller - Assy Jack Shaft - 4 | 3524  | 84329090 | 12% |
| 100000312 | Eicher Tractor Rotary Tiller - Assy Jack Shaft - 4 | 3708  | 84329090 | 12% |
| 100000313 | Eicher Tractor Rotary Tiller - Assy Side Cover     | 1266  | 84329090 | 12% |
| 100000314 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft-42 | 13835 | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000315 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft-48 | 22106 | 84329090 | 12% |
| 100000316 | Eicher Tractor Rotary Tiller - Driven Flange Lh    | 1700  | 84329090 | 12% |
| 100000317 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1685  | 84329090 | 12% |
| 100000318 | Eicher Tractor Rotary Tiller - Disc Assy           | 5547  | 84329090 | 12% |
| 100000319 | Eicher Tractor Main Frame -36                      | 15649 | 84329090 | 12% |
| 100000320 | Eicher Tractor Rotary Tiller - Dust Cover          | 330   | 84329090 | 12% |
| 100000321 | Eicher Tractor Main Frame -42                      | 18361 | 84329090 | 12% |
| 100000322 | Eicher Tractor Rot Tiller-Assy Main Frme -42 Blade | 14014 | 84329090 | 12% |
| 100000323 | Eicher Tractor Rotary Tiller-Assy Main Frme-48 Bld | 17057 | 84329090 | 12% |
| 100000325 | Eicher Tractor Rotary Tiller - C Bolt 50 Square    | 159   | 73181500 | 18% |
| 100000326 | Eicher Tractor Rotary Tiller - C Bolt 60 Square    | 167   | 84329090 | 12% |
| 100000327 | Eicher Tractor Rotary Tiller - Disc Holding Bracke | 2343  | 84329090 | 12% |
| 100000328 | Eicher Tractor Nut M12X1.75Xt:18Xa/F:18            | 12    | 73181600 | 18% |
| 100000329 | Eicher Tractor Hex Bolt M16X1.5X100                | 106   | 84329090 | 12% |
| 100000330 | Eicher Tractor Hex Nut M16X1.5                     | 21    | 84329090 | 12% |
| 100000331 | Eicher Tractor Rotary Tiller - Side Plate Lh Hsv   | 3749  | 84329090 | 12% |
| 100000333 | Eicher Tractor Rotary Tiller - Side Plate Lh       | 3088  | 84329090 | 12% |
| 100000334 | Eicher Tractor Rotary Tiller - Hitch Brkt long Top | 716   | 84329090 | 12% |
| 100000335 | Eicher Tractor Rotary Tiller - Assyrotorshaft-36Bl | 11972 | 84329090 | 12% |
| 100000336 | Eicher Tractor Side Disc                           | 903   | 84329090 | 12% |
| 100000337 | Eicher Tractor Disc Axle Shaft                     | 686   | 84329090 | 12% |
| 100000338 | Eicher Tractor Inner Cover                         | 196   | 84329090 | 12% |
| 100000339 | Eicher Tractor Oil Seal(72X40X10)                  | 60    | 84329090 | 12% |
| 100000340 | Eicher Tractor Side Disc Pipe Assy                 | 418   | 84329090 | 12% |
| 100000341 | Eicher Tractor Taper Roller Bearing (30208)        | 557   | 84329090 | 12% |
| 100000342 | Eicher Tractor Nut                                 | 110   | 87089900 | 18% |
| 100000343 | Eicher Tractor Outer Cover                         | 196   | 84329090 | 12% |
| 100000344 | Eicher Tractor Side Disc Pin                       | 95    | 84329090 | 12% |
| 100000345 | Eicher Tractor Linch Pin                           | 17    | 87089900 | 18% |
| 100000346 | Eicher Tractor Cotter Pin                          | 9     | 87089900 | 18% |
| 100000347 | Eicher Tractor Hex Bolt -M10 X1.5X 40L             | 13    | 73181500 | 18% |
| 100000348 | Eicher Tractor Assy Flange - Ms Gearbox Mtg-36 & 4 | 2488  | 84329090 | 12% |
| 100000349 | Eicher Tractor Assy Flange - Ms Gearbox Mtg-36 & 4 | 1440  | 84329090 | 12% |
| 100000350 | Eicher Tractor Assy Flange - Ms Gearbox Mtg-48 Bld | 3270  | 84329090 | 12% |
| 100000351 | Eicher Tractor Rotary Tiller-Gear 20T-5.5M         | 960   | 84329090 | 12% |
| 100000352 | Eicher Tractor Rotary Tiller-Gear 21T-5.5          | 1039  | 84329090 | 12% |
| 100000353 | Eicher Tractor Rotary Tiller- Agristar Plate Oran  | 120   | 83100090 | 18% |
| 100000354 | Eicher Tractor Rotary Tiller - Assy Side Plate - L | 20173 | 84329090 | 12% |
| 100000355 | Eicher Tractor Rotary Tiller-Eicher Logo           | 120   | 83100090 | 18% |
| 100000356 | Eicher Tractor Rotary Tiller - Spacer - Hitch Brac | 22    | 84329090 | 12% |
| 100000357 | Eicher Tractor Rotary Tiller-Multi Lip Seal        | 121   | 4016     | 18% |
| 100000359 | Eicher Tractor Rotary Tiller - Input Shaft Muttisp | 1620  | 84329090 | 12% |
| 100000360 | Eicher Tractor Rotary Tiller - Assy Side Cover     | 1870  | 84329090 | 12% |
| 100000361 | Eicher Tractor Rotary Tiller - Idler Gear - 35 T   | 2903  | 84834000 | 18% |
| 100000362 | Eicher Tractor Rotary Tiller - Driven Gear - 30 T  | 2693  | 84834000 | 18% |
| 100000363 | Eicher Tractor Rotary Tiller - Drive Gear - 21 T   | 1843  | 84834000 | 18% |
| 100000364 | Eicher Tractor Rotary Tiller - Hex Screw M12X1.5X3 | 17    | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000365 | Eicher Tractor Rotary Tiller - Idler Flange Kit    | 2104  | 84329090 | 12% |
| 100000366 | Eicher Tractor Rotary Tiller - Ring Nut            | 165   | 84329090 | 12% |
| 100000367 | Eicher Tractor Rotary Tiller - Assy Side Plate Rh  | 4303  | 84329090 | 12% |
| 100000368 | Eicher Tractor Rotary Tiller - Assy Side Plate Rh  | 2137  | 84329090 | 12% |
| 100000369 | Eicher Tractor Rotary Tiller-Hitch Bracket Long To | 1090  | 84329090 | 12% |
| 100000370 | Eicher Tractor Rotary Tiller - Flange Idler Coral  | 1471  | 84329090 | 12% |
| 100000371 | Eicher Tractor Rotary Tiller - Idler Flange Spacer | 63    | 84329090 | 12% |
| 100000372 | Eicher Tractor Rotary Tiller - Output Shaft        | 1224  | 84329090 | 12% |
| 100000373 | Eicher Tractor Rotary Tiller-Spacer Skid           | 43    | 84329090 | 12% |
| 100000374 | Eicher Tractor Rotary Tiller - Crown & Pinion Kit  | 3203  | 84329090 | 12% |
| 100000375 | Eicher Tractor Rotary Tiller - Crown-Pinion & Outp | 4283  | 84329090 | 12% |
| 100000376 | Eicher Tractor Rotary Tiller - Flange Kit          | 1507  | 84329090 | 12% |
| 100000377 | Eicher Tractor Rotary Tiller - Adtuster Rod        | 388   | 84329090 | 12% |
| 100000378 | Eicher Tractor Rotary Tiller - Washer - Rear Hood  | 12    | 73182100 | 18% |
| 100000379 | Eicher Tractor Rotary Tiller - Locking Pin         | 20    | 84329090 | 12% |
| 100000380 | Eicher Tractor Rotary Tiller - Assy Flange-Ms Gear | 2365  | 84329090 | 12% |
| 100000381 | Eicher Tractor Rotary Tiller - Jack Shaft Multispe | 3000  | 84329090 | 12% |
| 100000382 | Eicher Tractor Rotary Tiller - Assy Jackshaft-36 Z | 3463  | 84329090 | 12% |
| 100000383 | Eicher Tractor Rotary Tiller - Assy M Frame-36 Zer | 14219 | 84329090 | 12% |
| 100000384 | Eicher Tractor Rotary Tiller - Leg Holder Assy.    | 690   | 84329090 | 12% |
| 100000385 | Eicher Tractor Rotary Tiller - Hitch Pin Lower Lin | 341   | 84329090 | 12% |
| 100000386 | Eicher Tractor Rotary Tiller - Assy. Leg Holder    | 292   | 84329090 | 12% |
| 100000387 | Eicher Tractor Rotary Tiller-Assy Telescopic Leg   | 520   | 84329090 | 12% |
| 100000388 | Eicher Tractor Rotary Tiller - Rotary Lock Pin     | 55    | 84329090 | 12% |
| 100000389 | Eicher Tractor Rotary Tiller - Taper Roller Bearin | 477   | 84822011 | 18% |
| 100000390 | Eicher Tractor Rotary Tiller - Cs Screw            | 10    | 73181500 | 18% |
| 100000391 | Eicher Tractor Rotary Tiller - Gear Box Assy (Retr | 16660 | 84329090 | 12% |
| 100000392 | Eicher Tractor Rotary Tiller - Cardan Shaft 790    | 10831 | 84831099 | 18% |
| 100000393 | Eicher Tractor Rotary Tiller - Uj Cross Water Proo | 1168  | 87089900 | 18% |
| 100000394 | Eicher Tractor Rotary Tiller - Hex Nut M12X1.75Xt: | 5     | 73181600 | 18% |
| 100000395 | Eicher Tractor Rotary Tiller- Assy Tail Board Adju | 1430  | 84329090 | 12% |
| 100000396 | Eicher Tractor Rotary Tiller - Idler Gear - 35 T   | 3808  | 84329090 | 12% |
| 100000397 | Eicher Tractor Flange Idler New - Tafe             | 1480  | 84329090 | 12% |
| 100000398 | Eicher Tractor Rotary Tiller Assy Telescopic Leg   | 327   | 998898   | 28% |
| 100000399 | Eicher Tractor Rotary Tiller - Output Shaft        | 1240  | 84329090 | 12% |
| 100000400 | Eicher Tractor Rotary Tiller - Grease Nipple 45 De | 21    | 84329090 | 12% |
| 100000401 | Eicher Tractor Rotary Tiller - Assy Depth Skid     | 1201  | 84329090 | 12% |
| 100000402 | Eicher Tractor Rotary Tiller - Gearbox Multi Speed | 7426  | 84329090 | 12% |
| 100000403 | Eicher Tractor Rotary Tiller - Gear Box Cover      | 1026  | 84329090 | 12% |
| 100000404 | Eicher Tractor Rotary Tiller - Grease Cap          | 613   | 84329090 | 12% |
| 100000405 | Eicher Tractor Rotary Tiller - Bearing Housing Rh  | 1566  | 84329090 | 12% |
| 100000406 | Eicher Tractor Rotary Tiller - Hitch Brkt          | 470   | 84329090 | 12% |
| 100000407 | Eicher Tractor Rotary Tiller - Assy Hitch Bracket  | 1144  | 84329090 | 12% |
| 100000408 | Eicher Tractor Rotary Tiller - Bottom Plate Hitch  | 453   | 84329090 | 12% |
| 100000409 | Eicher Tractor Rotary Tiller - Depth Skid Shoe     | 316   | 84329090 | 12% |
| 100000410 | Eicher Tractor Rotary Tiller - Skid Assy Rh        | 399   | 84329090 | 12% |
| 100000411 | Eicher Tractor Rotary Tiller - Assy Depth Skid Lh  | 738   | 84329090 | 12% |



|            |  |       |          |     |
|------------|--|-------|----------|-----|
| 1000000412 | Eicher Tractor Rotary Tiller - Input Shaft Seal    | 66    | 40169320 | 18% |
| 1000000413 | Eicher Tractor Rotary Tiller - Input Shaft - Ss    | 985   | 84329090 | 12% |
| 1000000414 | Eicher Tractor Rotary Tiller - Bearing Assy Trb 30 | 850   | 84822011 | 18% |
| 1000000415 | Eicher Tractor Rotary Tiller - Jackshaft           | 1930  | 84329090 | 12% |
| 1000000416 | Eicher Tractor Rotary Tiller - Blade Lh Mini       | 192   | 84329090 | 12% |
| 1000000417 | Eicher Tractor Rotary Tiller - Blade Rh Mini       | 192   | 84329090 | 12% |
| 1000000418 | Eicher Tractor Rotary Tiller - Assy Sidecover      | 1568  | 84329090 | 12% |
| 1000000419 | Eicher Tractor Rotary Tiller - Rod Tail Board Mtg  | 294   | 84329090 | 12% |
| 1000000420 | Eicher Tractor Rotary Tiller - Spring Long         | 130   | 84329090 | 12% |
| 1000000421 | Eicher Tractor Rotary Tiller - Spring Holder Tailb | 100   | 84329090 | 12% |
| 1000000422 | Eicher Tractor Rotary Tiller - Nylloc-M16X2        | 19    | 73181600 | 18% |
| 1000000423 | Eicher Tractor Rotary Tiller - Holding Bracket     | 180   | 84329090 | 12% |
| 1000000424 | Eicher Tractor Rotary Tiller - Hex.Bolt-M12X1.75-5 | 15    | 73181600 | 18% |
| 1000000425 | Eicher Tractor Rotary Tiller - Assy Telescopic Leg | 432   | 84329090 | 12% |
| 1000000426 | Eicher Tractor Rotary Tiller - Assy Leg Holder     | 342   | 84329090 | 12% |
| 1000000427 | Eicher Tractor Rotary Tiller - Assy Hitch Brkt     | 620   | 84329090 | 12% |
| 1000000428 | Eicher Tractor Rotary Tiller - Hitch Pin Lower Lin | 250   | 84329090 | 12% |
| 1000000429 | Eicher Tractor Rotary Tiller - Rotary Tiller - Spa | 141   | 84329090 | 12% |
| 1000000430 | Eicher Tractor Rotary Tiller - Hexagon Head Bolt M | 55    | 73181600 | 18% |
| 1000000431 | Eicher Tractor Rotary Tiller - Bottom Plate Hitch  | 140   | 84329090 | 12% |
| 1000000432 | Eicher Tractor Rotary Tiller - Driven Flange Lh    | 2959  | 84329090 | 12% |
| 1000000433 | Eicher Tractor Rotary Tiller - Output Shaft        | 2530  | 84329090 | 12% |
| 1000000434 | Eicher Tractor Rotary Tiller - Bearing (Tmb 6208)  | 564   | 84822011 | 18% |
| 1000000435 | Eicher Tractor Rotary Tiller - Circlip             | 34    | 73182100 | 18% |
| 1000000436 | Eicher Tractor Rotary Tiller - O-Ring Grase Cap    | 16    | 40169320 | 18% |
| 1000000437 | Eicher Tractor Rotary Tiller - External Circlip A4 | 18    | 73182100 | 18% |
| 1000000438 | Eicher Tractor Rotary Tiller - Gasket Cover Idler  | 12    | 48239030 | 18% |
| 1000000439 | Eicher Tractor Rotary Tiller - Idler Gear 35T      | 4224  | 84329090 | 12% |
| 1000000440 | Eicher Tractor Rotary Tiller - Driven Gear 30T     | 2965  | 84329090 | 12% |
| 1000000441 | Eicher Tractor Rotary Tiller - Drive Gear 21T      | 2080  | 84329090 | 12% |
| 1000000442 | Eicher Tractor Rotary Tiller - Assy Leg Holder     | 290   | 84329090 | 12% |
| 1000000443 | Eicher Tractor Rotary Tiller - Dust Cover          | 275   | 84329090 | 12% |
| 1000000444 | Eicher Tractor Rotary Tiller - Assy Main Frme -36/ | 14488 | 84329090 | 12% |
| 1000000445 | Eicher Tractor Rotary Tiller - Side Plate - Lh     | 4257  | 84329090 | 12% |
| 1000000446 | Eicher Tractor Rotary Tiller - Bearing Housing - L | 1606  | 84329090 | 12% |
| 1000000447 | Eicher Tractor Rotary Tiller - Side Plate - Rh     | 4226  | 84329090 | 12% |
| 1000000448 | Eicher Tractor Rotary Tiller - Assy Tail Board-36  | 7939  | 84329090 | 12% |
| 1000000449 | Eicher Tractor Rotary Tiller - Rod - Tail Board Mt | 565   | 84329090 | 12% |
| 1000000450 | Eicher Tractor Rotary Tiller - Spacer - Multi Spee | 49    | 84329090 | 12% |
| 1000000451 | Eicher Tractor Rotary Tiller - Gear 20T-5.5M       | 1180  | 84834000 | 18% |
| 1000000452 | Eicher Tractor Rotary Tiller - Gear 21T-5.5M       | 1244  | 84834000 | 18% |
| 1000000453 | Eicher Tractor Rotary Tiller - Assy Flange - Ms Ge | 2754  | 84329090 | 12% |
| 1000000454 | Eicher Tractor Rotary Tiller - Assy Jackshaft - 36 | 3940  | 84329090 | 12% |
| 1000000455 | Eicher Tractor Rotary Tiller - Jack Shaft - Multi  | 3360  | 84329090 | 12% |
| 1000000456 | Eicher Tractor Rotary Tiller - Flange Idler        | 1443  | 84329090 | 12% |
| 1000000457 | Eicher Tractor Rotary Tiller - Side Plate Lh       | 4873  | 84329090 | 12% |
| 1000000458 | Eicher Tractor Rotary Tiller - Flange Idler        | 1426  | 84329090 | 12% |





|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000459 | Eicher Tractor Rotary Tiller - Flange Gb End       | 1476  | 84329090 | 12% |
| 100000460 | Eicher Tractor Rotary Tiller - Flange Lh Plate End | 1562  | 84329090 | 12% |
| 100000461 | Eicher Tractor Rotary Tiller - Bearing Housing Rh  | 1200  | 84329090 | 12% |
| 100000462 | Eicher Tractor Rotary Tiller - Side Plate Rh       | 1574  | 84329090 | 12% |
| 100000463 | Eicher Tractor Rotary Tiller - Grease Cup          | 569   | 84329090 | 12% |
| 100000464 | Eicher Tractor Rotary Tiller - Bearing Housing - L | 1406  | 84329090 | 12% |
| 100000465 | Eicher Tractor Rotary Tiller - Side Plate - Lh     | 2344  | 84329090 | 12% |
| 100000466 | Eicher Tractor Rotary Tiller - Skid Adjuster       | 1319  | 84329090 | 12% |
| 100000467 | Eicher Tractor Rotary Tiller - Gear Box - Ss Mini  | 2836  | 84329090 | 12% |
| 100000468 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 1298  | 84329090 | 12% |
| 100000469 | Eicher Tractor Rotary Tiller - Flat Washer-M12-13. | 3     | 73182100 | 18% |
| 100000470 | Eicher Tractor Rotary Tiller - Angle Plate Brkt C  | 500   | 84329090 | 12% |
| 100000471 | Eicher Tractor Rotary Tiller - Assy Mainframe -800 | 5969  | 84329090 | 12% |
| 100000472 | Eicher Tractor Rotary Tiller - Tail Board Adjuster | 855   | 84329090 | 12% |
| 100000473 | Eicher Tractor Rotary Tiller - Hex Bolt (M10X1.5-1 | 20    | 73181500 | 18% |
| 100000474 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2139  | 84329090 | 12% |
| 100000475 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 11392 | 84329090 | 12% |
| 100000476 | Eicher Tractor Rotary Tiller - Flange Idler        | 1480  | 84329090 | 12% |
| 100000477 | Eicher Tractor Rotary Tiller - Sideplate Lh        | 3783  | 84329090 | 12% |
| 100000478 | Eicher Tractor Rotary Tiller - Bearing Housing Lh  | 1562  | 84329090 | 12% |
| 100000479 | Eicher Tractor Rotary Tiller - Sideplate Rh        | 3708  | 84329090 | 12% |
| 100000480 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 6197  | 84329090 | 12% |
| 100000481 | Eicher Tractor Rotary Tiller - Rod Tail Board Mtg  | 422   | 84329090 | 12% |
| 100000482 | Eicher Tractor Rotary Tiller - Assy Hitch Brkt Top | 747   | 84329090 | 12% |
| 100000483 | Eicher Tractor Rotary Tiller - Assy Hitch Brkt Top | 743   | 84329090 | 12% |
| 100000484 | Eicher Tractor Rotary Tiller - Simple Yoke - Inner | 738   | 84329090 | 12% |
| 100000485 | Eicher Tractor Rotary Tiller - Pin - Yoke Inner    | 27    | 84329090 | 12% |
| 100000486 | Eicher Tractor Rotary Tiller - Simple Yoke - Outer | 738   | 84329090 | 12% |
| 100000487 | Eicher Tractor Rotary Tiller - Pin - Yoke Inner    | 46    | 84329090 | 12% |
| 100000488 | Eicher Tractor Rotary Tiller - Side Plate Lh Hsv   | 5380  | 84329090 | 12% |
| 100000489 | Eicher Tractor Rotary Tiller - Assy J/S Sq. Mini R | 901   | 84329090 | 12% |
| 100000490 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft -8 | 4766  | 84329090 | 12% |
| 100000491 | Eicher Tractor Rotary Tiller - Assy Tail Board 800 | 2570  | 84329090 | 12% |
| 100000492 | Eicher Tractor Rotary Tiller - Tail Board Adjuster | 270   | 84329090 | 12% |
| 100000493 | Eicher Tractor Rotary Tiller - Washer Hood Adj     | 30    | 84329090 | 12% |
| 100000494 | Eicher Tractor Rotary Tiller - Spring Small        | 93    | 84329090 | 12% |
| 100000495 | Eicher Tractor Rotary Tiller - Gear Pair Dcl(17/21 | 2     | 84329090 | 12% |
| 100000496 | Eicher Tractor Rotary Tiller - Gear Pair Dcl(18/20 | 2     | 84329090 | 12% |
| 100000497 | Eicher Tractor Rotary Tiller - Gear Pair Dcl(16/22 | 2     | 84329090 | 12% |
| 100000498 | Eicher Tractor Rotary Tiller - Blade Lh - Paddy Tw | 150   | 84329090 | 12% |
| 100000499 | Eicher Tractor Rotary Tiller - Blade Rh - Paddy Tw | 150   | 84329090 | 12% |
| 100000500 | Eicher Tractor Rotary Tiller - Crown-Pinion & Inpu | 3991  | 84329090 | 12% |
| 100000501 | Eicher Tractor Rotary Tiller - Air Breather New    | 90    | 84329090 | 12% |
| 100000502 | Eicher Tractor Rotary Tiller - C Bolt C60          | 162   | 84329090 | 12% |
| 100000503 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft -  | 17657 | 84329090 | 12% |
| 100000504 | Eicher Tractor Rotary Tiller - Bolt Hex            | 14    | 73181500 | 18% |
| 100000505 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 17517 | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000506 | Eicher Tractor Rotary Tiller - Side Plate Lh       | 4143  | 84329090 | 12% |
| 100000507 | Eicher Tractor Rotary Tiller - Side Plate Rh       | 2770  | 84329090 | 12% |
| 100000508 | Eicher Tractor Rotary Tiller - Crown & Pinion Kit  | 4145  | 84329090 | 12% |
| 100000509 | Eicher Tractor Rotary Tiller - Input Shaft Ms      | 1110  | 84329090 | 12% |
| 100000510 | Eicher Tractor Rotary Tiller - Gear 17T            | 661   | 84834000 | 18% |
| 100000511 | Eicher Tractor Rotary Tiller - Gear 21T            | 800   | 84834000 | 18% |
| 100000512 | Eicher Tractor Rotary Tiller - Gear 18T            | 673   | 84834000 | 18% |
| 100000513 | Eicher Tractor Rotary Tiller - Gear 20T            | 753   | 84834000 | 18% |
| 100000514 | Eicher Tractor Rotary Tiller - Gearcap Front       | 284   | 84329090 | 12% |
| 100000515 | Eicher Tractor Rotary Tiller - Gear 22T            | 846   | 84834000 | 18% |
| 100000516 | Eicher Tractor Rotary Tiller - Gear 16T            | 600   | 84329090 | 12% |
| 100000517 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 19710 | 84329090 | 12% |
| 100000518 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1809  | 84329090 | 12% |
| 100000519 | Eicher Tractor Rotary Tiller - Driven Flange Lh    | 2073  | 84329090 | 12% |
| 100000520 | Eicher Tractor Rotary Tiller - Gasket Side Cover   | 258   | 84329090 | 12% |
| 100000521 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1884  | 84329090 | 12% |
| 100000522 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2495  | 84329090 | 12% |
| 100000523 | Eicher Tractor Rotary Tiller - Flange Idler        | 1577  | 84329090 | 12% |
| 100000524 | Eicher Tractor Rotary Tiller - Assy Side Cover     | 1575  | 84329090 | 12% |
| 100000525 | Eicher Tractor Rotary Tiller-Assy Skid Adjuster We | 310   | 84329090 | 12% |
| 100000526 | Eicher Tractor Rotary Tiller - Bearing Housing - L | 23    | 84329090 | 12% |
| 100000527 | Eicher Tractor Rotary Tiller - Profile Tubes - Inn | 1491  | 84329090 | 12% |
| 100000528 | Eicher Tractor Rotary Tiller - Quick Release Pin - | 48    | 84329090 | 12% |
| 100000529 | Eicher Tractor Rotary Tiller - Shear Bolt With Nut | 45    | 84329090 | 12% |
| 100000530 | Eicher Tractor Rotary Tiller - Shear Yoke          | 1949  | 84329090 | 12% |
| 100000531 | Eicher Tractor Rotary Tiller - Simple Yoke - Inner | 1076  | 84329090 | 12% |
| 100000532 | Eicher Tractor Rotary Tiller - Simple Yoke - Inner | 34    | 84329090 | 12% |
| 100000533 | Eicher Tractor Rotary Tiller - Pin - Yoke Inner    | 34    | 84329090 | 12% |
| 100000534 | Eicher Tractor Rotary Tiller - Simple Yoke - Outer | 1201  | 84329090 | 12% |
| 100000535 | Eicher Tractor Rotary Tiller - Simple Yoke - Outer | 34    | 84329090 | 12% |
| 100000536 | Eicher Tractor Rotary Tiller - Pin - Yoke Inner    | 34    | 84329090 | 12% |
| 100000537 | Eicher Tractor Rotary Tiller - Spring Yoke         | 1185  | 84329090 | 12% |
| 100000538 | Eicher Tractor Rotary Tiller - U.J.Cross - 35Mm Di | 1050  | 84329090 | 12% |
| 100000539 | Eicher Tractor Rotary Tiller - Assy Jackshaft 36 C | 3176  | 84329090 | 12% |
| 100000540 | Eicher Tractor Rotary Tiller - Retainer Ring       | 80    | 84329090 | 12% |
| 100000541 | Eicher Tractor Rotary Tiller - Grease Nipple       | 22    | 84329090 | 12% |
| 100000542 | Eicher Tractor Rotary Tiller - Guard               | 109   | 84329090 | 12% |
| 100000543 | Eicher Tractor Rotary Tiller - Assy Jackshaft 42 C | 3630  | 84329090 | 12% |
| 100000544 | Eicher Tractor Rotary Tiller - Retainer Ring Tt38  | 81    | 84329090 | 12% |
| 100000545 | Eicher Tractor Rotary Tiller - Hsv-Ads360Ff/42Cent | 2723  | 84329090 | 12% |
| 100000546 | Eicher Tractor Rotary Tiller - Assy Depth Skid Lh  | 880   | 84329090 | 12% |
| 100000547 | Eicher Tractor Rotary Tiller - Depth Skid Shoe     | 437   | 84329090 | 12% |
| 100000548 | Eicher Tractor Rotary Tiller-Assy Skid Adjuster We | 249   | 84329090 | 12% |
| 100000549 | Eicher Tractor Rotary Tiller - Assy Depth Skid Rh  | 410   | 84329090 | 12% |
| 100000550 | Eicher Tractor Rotary Tiller - Rear Cover- Gear Bo | 315   | 84329090 | 12% |
| 100000551 | Eicher Tractor Rotary Tiller - Gasket              | 89    | 40169390 | 18% |
| 100000552 | Eicher Tractor Rotary Tiller - Circlip             | 9     | 73182910 | 18% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000553 | Eicher Tractor Rotary Tiller - Spacer - Multi Spee | 50    | 84329090 | 12% |
| 100000554 | Eicher Tractor Rotary Tiller - Gearbox Ms          | 5558  | 84329090 | 12% |
| 100000555 | Eicher Tractor Rotary Tiller - Ring Nut M75X1.5    | 120   | 84329090 | 12% |
| 100000556 | Eicher Tractor Rotary Tiller - Gb Cap Multi Front  | 266   | 84329090 | 12% |
| 100000557 | Eicher Tractor Rotary Tiller - O-Ring-Front-Cap    | 30    | 49110000 | 12% |
| 100000558 | Eicher Tractor Rotary Tiller - Output Shaft        | 795   | 84329090 | 12% |
| 100000560 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft-42 | 19005 | 84329090 | 12% |
| 100000561 | Eicher Tractor Rotary Tiller - Gear Box - Ss Mini  | 2838  | 84329090 | 12% |
| 100000563 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 100   | 84329090 | 12% |
| 100000564 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2042  | 84329090 | 12% |
| 100000565 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 3122  | 84329090 | 12% |
| 100000566 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2958  | 84329090 | 12% |
| 100000567 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2104  | 84329090 | 12% |
| 100000568 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 4371  | 84329090 | 12% |
| 100000569 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 4841  | 84329090 | 12% |
| 100000571 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 2154  | 84329090 | 12% |
| 100000572 | Eicher Tractor Rotary Tiller - Jack Shaft          | 4436  | 84329090 | 12% |
| 100000573 | Eicher Tractor Rotary Tiller - Jack Shaft          | 2619  | 84329090 | 12% |
| 100000574 | Eicher Tractor Rotary Tiller - Jack Shaft          | 3362  | 84329090 | 12% |
| 100000575 | Eicher Tractor Rotary Tiller - Flange Lh Plate End | 1010  | 84329090 | 12% |
| 100000576 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1274  | 84329090 | 12% |
| 100000577 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1134  | 84329090 | 12% |
| 100000578 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 2125  | 84329090 | 12% |
| 100000579 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1431  | 84329090 | 12% |
| 100000580 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1689  | 84329090 | 12% |
| 100000581 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 4125  | 84329090 | 12% |
| 100000582 | Eicher Tractor Rotary Tiller - Assy Jack Shaft     | 1642  | 84329090 | 12% |
| 100000584 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 1303  | 84329090 | 12% |
| 100000585 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 635   | 84329090 | 12% |
| 100000586 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 15329 | 84329090 | 12% |
| 100000588 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 16294 | 84329090 | 12% |
| 100000589 | Eicher Tractor Rotary Tiller-Assy Side Cover Co    | 1690  | 84329090 | 12% |
| 100000590 | Eicher Tractor Rotary Tiller - Assy Mainframe      | 1588  | 84329090 | 12% |
| 100000591 | Eicher Tractor Rotary Tiller - Gear 18T            | 658   | 84329090 | 12% |
| 100000592 | Eicher Tractor Rotary Tiller Assy Main Frame       | 1520  | 84329090 | 12% |
| 100000593 | Eicher Tractor Rotary Tiller - Assy Mainframe      | 14031 | 84329090 | 12% |
| 100000594 | Eicher Tractor Rotary Tiller - Hex Head Bolt M16X2 | 30    | 73181500 | 18% |
| 100000595 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 11532 | 84329090 | 12% |
| 100000596 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 13459 | 84329090 | 12% |
| 100000597 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 14566 | 84329090 | 12% |
| 100000598 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 17243 | 84329090 | 12% |
| 100000599 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 13712 | 84329090 | 12% |
| 100000600 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 20193 | 84329090 | 12% |
| 100000601 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft    | 12376 | 84329090 | 12% |
| 100000602 | Eicher Tractor Rotary Tiller - Blade_Lh            | 222   | 84329090 | 12% |
| 100000603 | Eicher Tractor Rotary Tiller - Blade_Rh            | 222   | 84329090 | 12% |
| 100000604 | Eicher Tractor Rotary Tiller - Hex.Bolt-M8X1.25-25 | 4     | 73181500 | 18% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000605 | Eicher Tractor Rotary Tiller - Nyloc Nut M8X1.25   | 3     | 73181500 | 18% |
| 100000606 | Eicher Tractor Rotary Tiller - Flange Idler - Spac | 70    | 84329090 | 12% |
| 100000607 | Eicher Tractor Rotary Tiller - Idler Gear 35T      | 3223  | 84834000 | 18% |
| 100000608 | Eicher Tractor Rotary Tiller - Driven Gear 31T Wet | 2320  | 84834000 | 18% |
| 100000609 | Eicher Tractor Rotary Tiller - Drive Gear 21T Wet  | 1550  | 84834000 | 18% |
| 100000610 | Eicher Tractor Rotary Tiller - Driven Flange Lh    | 1991  | 84329090 | 12% |
| 100000611 | Eicher Tractor Rotary Tiller - Plug Magnetic Drain | 53    | 73181500 | 18% |
| 100000612 | Eicher Tractor Rotary Tiller - Side Plate Lh       | 4784  | 84329090 | 12% |
| 100000613 | Eicher Tractor Rotary Tiller - Side Plate Lh       | 250   | 84329090 | 12% |
| 100000614 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1737  | 84329090 | 12% |
| 100000615 | Eicher Tractor Rotary Tiller - Assy Hitch Brkt Top | 1210  | 84329090 | 12% |
| 100000616 | Eicher Tractor Rotary Tiller - Bearing Housing Rh  | 23    | 84329090 | 12% |
| 100000617 | Eicher Tractor Rotary Tiller - Cassette Seal - 57. | 342   | 40169390 | 18% |
| 100000618 | Eicher Tractor Rotary Tiller - Side Plate Rh       | 3549  | 84329090 | 12% |
| 100000619 | Eicher Tractor Rotary Tiller - Side Plate Rh       | 268   | 84329090 | 12% |
| 100000620 | Eicher Tractor Rotary Tiller - Assy Hitch Bracket  | 1450  | 84329090 | 12% |
| 100000621 | Eicher Tractor Rotary Tiller - Bottom Plate - Hitc | 485   | 84329090 | 12% |
| 100000622 | Eicher Tractor Rotary Tiller - Assy Hitch Brckt To | 1642  | 84329090 | 12% |
| 100000623 | Eicher Tractor Rotary Tiller - Assy Hitch Brckt To | 1642  | 84329090 | 12% |
| 100000624 | Eicher Tractor Rotary Tiller - Hex Bolt- M12X1.5-4 | 68    | 73181500 | 18% |
| 100000625 | Eicher Tractor Rotary Tiller - Assy Leg Holder     | 210   | 84329090 | 12% |
| 100000627 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 8072  | 84329090 | 12% |
| 100000628 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 7973  | 84329090 | 12% |
| 100000629 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 5707  | 84329090 | 12% |
| 100000631 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 6312  | 84329090 | 12% |
| 100000632 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 7349  | 84329090 | 12% |
| 100000633 | Eicher Tractor Rotary Tiller - Rod Tail Board Mtg  | 806   | 84329090 | 12% |
| 100000634 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 10000 | 84329090 | 12% |
| 100000635 | Eicher Tractor Rotary Tiller - Rod Tail Board Mtg  | 459   | 84329090 | 12% |
| 100000636 | Eicher Tractor Rotary Tiller - Tool Kit            | 462   | 82060090 | 18% |
| 100000637 | Eicher Tractor Rotary Tiller - Bag Tool Kit        | 71    | 42029200 | 18% |
| 100000638 | Eicher Tractor Rotary Tiller - Bar_Share Long Lh T | 4377  | 84329090 | 12% |
| 100000639 | Eicher Tractor Rotary Tiller - Bar_Share Short Lh  | 2558  | 84329090 | 12% |
| 100000640 | Eicher Tractor Rotary Tiller - Bolt Guide Bar      | 86    | 73181900 | 18% |
| 100000641 | Eicher Tractor Rotary Tiller - Bar_Share Short     | 2459  | 84329090 | 12% |
| 100000642 | Eicher Tractor Rotary Tiller - Bar Share-Long      | 4108  | 84329090 | 12% |
| 100000643 | Eicher Tractor Rotary Tiller - External Circlip    | 8     | 84329090 | 12% |
| 100000644 | Eicher Tractor Rotary Tiller - Plopugh Turning Cyl | 15473 | 84329010 | 12% |
| 100000645 | Eicher Tractor Rotary Tiller - Hex Socket Head An  | 23    | 73181900 | 18% |
| 100000646 | Eicher Tractor Rotary Tiller - Cylinder_Mtg_Pin    | 747   | 84329090 | 12% |
| 100000647 | Eicher Tractor Rotary Tiller - Stopper Bolt        | 128   | 73181500 | 18% |
| 100000648 | Eicher Tractor Rotary Tiller - Hexagon Nut-Normal- | 31    | 73181900 | 18% |
| 100000649 | Eicher Tractor Rotary Tiller - Hitch_Pin_Toplink   | 234   | 84329090 | 12% |
| 100000650 | Eicher Tractor Rotary Tiller - Thinnut-M24X3       | 60    | 73181900 | 18% |
| 100000651 | Eicher Tractor Rotary Tiller - Assy Lich Pin And R | 14    | 87089900 | 18% |
| 100000652 | Eicher Tractor Rotary Tiller - Assy Stand          | 1201  | 84329090 | 12% |
| 100000653 | Eicher Tractor Rotary Tiller - Pin Stand           | 59    | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000654 | Eicher Tractor Rotary Tiller - Hexagon Head Bolt M | 177   | 84329090 | 12% |
| 100000655 | Eicher Tractor Rotary Tiller - Lock Washer-M20-4T  | 7     | 73182100 | 18% |
| 100000656 | Eicher Tractor Rotary Tiller - Assy Main Frame 2F  | 21965 | 84329090 | 12% |
| 100000657 | Eicher Tractor Rotary Tiller - Shaft-Mainframe     | 5078  | 84329090 | 12% |
| 100000659 | Eicher Tractor Rotary Tiller - Pin_Shaft           | 70    | 84329090 | 12% |
| 100000660 | Eicher Tractor Rotary Tiller - Hub Assy            | 7681  | 84329090 | 12% |
| 100000661 | Eicher Tractor Rotary Tiller - Thrust Washer       | 673   | 84329090 | 12% |
| 100000662 | Eicher Tractor Rotary Tiller - Felt_Rear           | 409   | 84329010 | 12% |
| 100000663 | Eicher Tractor Rotary Tiller - Taper Roller Bearin | 828   | 84822012 | 18% |
| 100000664 | Eicher Tractor Rotary Tiller - Head Stock          | 19977 | 84329090 | 12% |
| 100000665 | Eicher Tractor Rotary Tiller - Taper Roller Bearin | 804   | 84822012 | 18% |
| 100000666 | Eicher Tractor Rotary Tiller - Felt_Front.         | 282   | 84329010 | 12% |
| 100000667 | Eicher Tractor Rotary Tiller - Front Bearing Cap   | 299   | 84329090 | 12% |
| 100000668 | Eicher Tractor Rotary Tiller - Locknut             | 245   | 84329090 | 12% |
| 100000669 | Eicher Tractor Rotary Tiller - Hexagon Head Bolt M | 158   | 73181900 | 18% |
| 100000670 | Eicher Tractor Rotary Tiller - Bush-Hub Assy       | 79    | 84329090 | 12% |
| 100000671 | Eicher Tractor Rotary Tiller - Hex.Nut-M20X1.5-10T | 20    | 73181900 | 18% |
| 100000672 | Eicher Tractor Rotary Tiller - Hex.Nut-M24X2-21.5T | 59    | 73181900 | 18% |
| 100000673 | Eicher Tractor Rotary Tiller - Hexagon Head Bolt M | 283   | 73181900 | 18% |
| 100000674 | Eicher Tractor Rotary Tiller - Adjustable Rod      | 399   | 84329090 | 12% |
| 100000675 | Eicher Tractor Rotary Tiller - Plough Bolt M 16X1. | 95    | 73181900 | 18% |
| 100000676 | Eicher Tractor Rotary Tiller - Landside Short Lh T | 1476  | 84329010 | 12% |
| 100000677 | Eicher Tractor Rotary Tiller - Saddle Assy Lh Thro | 4651  | 84329090 | 12% |
| 100000678 | Eicher Tractor Rotary Tiller - Plough Bolt         | 68    | 73181900 | 18% |
| 100000679 | Eicher Tractor Rotary Tiller - Share Wing Lh Thro  | 2070  | 84329090 | 12% |
| 100000680 | Eicher Tractor Rotary Tiller - Clip Share          | 315   | 84329090 | 12% |
| 100000681 | Eicher Tractor Rotary Tiller - Mould Bold Lh Throw | 10312 | 84329090 | 12% |
| 100000682 | Eicher Tractor Rotary Tiller - Shin Lf Throw       | 3387  | 84329090 | 12% |
| 100000683 | Eicher Tractor Rotary Tiller - Tail Piece          | 634   | 84329090 | 12% |
| 100000684 | Eicher Tractor Rotary Tiller - Hexagon Head Bolt M | 48    | 73181900 | 18% |
| 100000685 | Eicher Tractor Rotary Tiller - Leg                 | 2386  | 84329090 | 12% |
| 100000686 | Eicher Tractor Rotary Tiller - Bracket Front Mould | 231   | 84329090 | 12% |
| 100000687 | Eicher Tractor Rotary Tiller - Landside Short      | 1503  | 84329010 | 12% |
| 100000688 | Eicher Tractor Rotary Tiller - Saddle Assy         | 4474  | 84329090 | 12% |
| 100000689 | Eicher Tractor Rotary Tiller - Shin                | 3604  | 84329090 | 12% |
| 100000690 | Eicher Tractor Rotary Tiller - Mould Board         | 10312 | 84329090 | 12% |
| 100000691 | Eicher Tractor Rotary Tiller - Share Wing          | 2675  | 84329090 | 12% |
| 100000692 | Eicher Tractor Rotary Tiller - Bracket Front Mould | 235   | 84329090 | 12% |
| 100000693 | Eicher Tractor Rotary Tiller - Landside Long Lh Th | 5230  | 84329090 | 12% |
| 100000694 | Eicher Tractor Rotary Tiller - Assy Hitch Brkt Top | 1064  | 84329090 | 12% |
| 100000695 | Eicher Tractor Rotary Tiller - Bracket Mould Boar  | 257   | 84329090 | 12% |
| 100000696 | Eicher Tractor Rotary Tiller - Heel Landside Lh Th | 785   | 84329090 | 12% |
| 100000697 | Eicher Tractor Rotary Tiller - Plough Bolt         | 66    | 73181900 | 18% |
| 100000698 | Eicher Tractor Rotary Tiller - Land Side-Long      | 5178  | 84329090 | 12% |
| 100000699 | Eicher Tractor Rotary Tiller - Bracket Mould Board | 257   | 84329090 | 12% |
| 100000700 | Eicher Tractor Rotary Tiller - Heel Land Side Rh   | 1410  | 84329090 | 12% |
| 100000701 | Eicher Tractor Rotary Tiller - Driven Flange Lh    | 2069  | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000702 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1611  | 84329090 | 12% |
| 100000703 | Eicher Tractor Rotary Tiller - Driven Flange - Rh  | 2017  | 84329090 | 12% |
| 100000704 | Eicher Tractor Rotary Tiller - Angle Plate Brkt -  | 110   | 84329090 | 12% |
| 100000705 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1840  | 84329090 | 12% |
| 100000706 | Eicher Tractor Rotary Tiller - Nut Nyloc Nut - M1  | 20    | 73181900 | 18% |
| 100000707 | Eicher Tractor Rotary Tiller - Depth Skid Shoe     | 308   | 84329090 | 12% |
| 100000708 | Eicher Tractor Rotary Tiller - Assy Tail Board Min | 3070  | 84329090 | 12% |
| 100000709 | Eicher Tractor Rotary Tiller - Assy Tail Board Min | 2903  | 84329090 | 12% |
| 100000710 | Eicher Tractor Rotary Tiller - Assy Side Cover     | 1470  | 84329090 | 12% |
| 100000711 | Eicher Tractor Rotary Tiller - Shim Spacer - 0.5Mm | 44    | 84329090 | 12% |
| 100000712 | Eicher Tractor Rotary Tiller - Side Disc Clamp Kit | 717   | 84329090 | 12% |
| 100000713 | Eicher Tractor Rotary Tiller - Gear Box-95-4 Hole  | 5870  | 84329090 | 12% |
| 100000714 | Eicher Tractor Rotary Tiller - Rear Cover -G95 4 H | 509   | 84329090 | 12% |
| 100000715 | Eicher Tractor Rotary Tiller - O Ring Gb95         | 68    | 40169320 | 18% |
| 100000716 | Eicher Tractor Rotary Tiller - Assy Main Frame 48  | 25791 | 84329090 | 12% |
| 100000717 | Eicher Tractor Rotary Tiller - Bearing Housing Lh  | 1297  | 84329090 | 12% |
| 100000718 | Eicher Tractor Rotary Tiller-Assy Side Cover Co    | 1607  | 84329090 | 12% |
| 100000719 | Eicher Tractor Assy Hitch Bracket Top - Rh         | 740   | 84329090 | 12% |
| 100000720 | Eicher Tractor Rotary Tiller - Mechanical Face Sea | 434   | 40169320 | 18% |
| 100000721 | Eicher Tractor Rotary Tiller - Bearing Housing-Rh  | 1606  | 84834000 | 28% |
| 100000722 | Eicher Tractor Rotary Tiller - Mini Cardan Shaft   | 7882  | 84831099 | 18% |
| 100000723 | Eicher Tractor Rotary Tiller - Assy Jackshaft-48 B | 4047  | 84329090 | 12% |
| 100000724 | Eicher Tractor Rotary Tiller - Assembly Jack Shaft | 4067  | 84329090 | 12% |
| 100000725 | Eicher Tractor Rotary Tiller - Dummy Jack Shaft 5. | 3000  | 84329090 | 12% |
| 100000727 | Eicher Tractor Rotary Tiller - Assy Main Frame (5. | 22264 | 84329090 | 12% |
| 100000728 | Eicher Tractor Rotary Tiller - Assy Tail Board (5. | 7984  | 84329090 | 12% |
| 100000729 | Eicher Tractor Rotary Tiller - Gasket Side Cover   | 258   | 84329090 | 12% |
| 100000730 | Eicher Tractor Rotary Tiller - Hex Bolt - M12X1.75 | 30    | 73181500 | 18% |
| 100000731 | Eicher Tractor Rotary Tiller - Spacer              | 28    | 84329090 | 12% |
| 100000732 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 11447 | 84329090 | 12% |
| 100000734 | Eicher Tractor Rotary Tiller - Driven Flange Rh    | 1672  | 84329090 | 12% |
| 100000735 | Eicher Tractor Rt - Bearing Housing Rh-Duo Cone-6  | 1380  | 84329090 | 12% |
| 100000736 | Eicher Tractor Rotary Tiller - Bearing Housing - L | 1233  | 84329090 | 12% |
| 100000737 | Eicher Tractor Rotary Tiller - Driven Flange - Lh  | 1990  | 84329090 | 12% |
| 100000738 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 5113  | 84329090 | 12% |
| 100000739 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 7295  | 84329090 | 12% |
| 100000740 | Eicher Tractor Tailboard Adjuster Kit - Mini Rt    | 968   | 84329090 | 12% |
| 100000741 | Eicher Tractor Rt - Hex Bolt-M12X1.5-95L Zn        | 116   | 84329090 | 12% |
| 100000742 | Eicher Tractor Rt - Support Plate - Side Disc      | 185   | 84329090 | 12% |
| 100000743 | Eicher Tractor Rotary Tiller - Disc Hub Assy       | 1338  | 84329090 | 12% |
| 100000744 | Eicher Tractor Rotary Tiller - Rear Cover          | 169   | 84329090 | 12% |
| 100000745 | Eicher Tractor Rotary Tiller - Cotter Pins         | 6     | 84329090 | 12% |
| 100000746 | Eicher Tractor Rotary Tiller - Oil Seal            | 50    | 84329090 | 12% |
| 100000747 | Eicher Tractor Rotary Tiller - Front Cover         | 139   | 84329090 | 12% |
| 100000748 | Eicher Tractor Rotary Tiller - Axle Shaft Assy     | 1045  | 84329090 | 12% |
| 100000749 | Eicher Tractor Rotary Tiller - Disc                | 522   | 84329090 | 12% |
| 100000750 | Eicher Tractor Rt - Cardan Shaft Assy (#Include 1  | 9047  | 84329090 | 12% |



|           |   |       |          |     |
|-----------|---|-------|----------|-----|
| 100000752 | Eicher Tractor Rotary Tiller - Support Plate      | 107   | 84329090 | 12% |
| 100000753 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 14430 | 84329090 | 12% |
| 100000754 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 19911 | 84329090 | 12% |
| 100000755 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 13554 | 84329090 | 12% |
| 100000756 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 23074 | 84329090 | 12% |
| 100000757 | Eicher Tractor Rotary Tiller - Assy Tail Board    | 6511  | 84329090 | 12% |
| 100000758 | Eicher Tractor Rotary Tiller - Assy Tail Board    | 6071  | 84329090 | 12% |
| 100000759 | Eicher Tractor Rotary Tiller - Assy Tail Board    | 5790  | 84329090 | 12% |
| 100000760 | Eicher Tractor Rotary Tiller - Assy Tail Board    | 9432  | 84329090 | 12% |
| 100000761 | Eicher Tractor Rotary Tiller - Assy Tail Board    | 7349  | 84329090 | 12% |
| 100000762 | Eicher Tractor Rt - Hex. Bolt-M12X1.5-95L Zn      | 27    | 73181500 | 18% |
| 100000763 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft   | 12864 | 84329090 | 12% |
| 100000764 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft   | 16890 | 84329090 | 12% |
| 100000765 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft   | 19170 | 84329090 | 12% |
| 100000766 | Eicher Tractor Rotary Tiller - Clamp Top- Dry Co  | 140   | 84329090 | 12% |
| 100000767 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg | 2569  | 84329090 | 12% |
| 100000768 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg | 3700  | 84329090 | 12% |
| 100000769 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg | 3257  | 84329090 | 12% |
| 100000770 | Eicher Tractor Rt - Hex. Bolt-M12X1.75-55L Zn     | 17    | 73181500 | 18% |
| 100000771 | Eicher Tractor Rotary Tiller - Top Clamp          | 117   | 84329090 | 12% |
| 100000772 | Eicher Tractor Rt - Bearing Assy Trb 30310        | 1117  | 84329090 | 12% |
| 100000773 | Eicher Tractor Rt - Jack Shaft - Multi Speed      | 2798  | 84329090 | 12% |
| 100000774 | Eicher Tractor Rt - Jack Shaft - Multi Speed      | 3076  | 84329090 | 12% |
| 100000775 | Eicher Tractor Rt - Jack Shaft - Multi Speed      | 4724  | 84329090 | 12% |
| 100000776 | Eicher Tractor Rotary Tiller - Assy Jack Shaft    | 4182  | 84329090 | 12% |
| 100000777 | Eicher Tractor Rotary Tiller - Assy Jack Shaft    | 5610  | 84329090 | 12% |
| 100000778 | Eicher Tractor Rotary Tiller - Assy Jack Shaft    | 5279  | 84329090 | 12% |
| 100000779 | Eicher Tractor Rotary Tiller - Gasket Jackshaft   | 28    | 40169390 | 18% |
| 100000780 | Eicher Tractor Rotary Tiller - Gear 14 T          | 934   | 84834000 | 18% |
| 100000781 | Eicher Tractor Rotary Tiller - Gear 20 T          | 1030  | 84834000 | 18% |
| 100000782 | Eicher Tractor Rotary Tiller - Gear 19 T          | 1285  | 84834000 | 18% |
| 100000783 | Eicher Tractor Rotary Tiller - Gear 24 T          | 1278  | 84834000 | 18% |
| 100000785 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 22819 | 84329090 | 12% |
| 100000786 | Eicher Tractor Rotary Tiller - Assy Main Frame    | 17293 | 84329090 | 12% |
| 100000787 | Eicher Tractor Rotary Tiller - Clamp Bottom       | 600   | 84329090 | 12% |
| 100000788 | Eicher Tractor Rotary Tiller - Driven Flange Rh   | 1672  | 84329090 | 12% |
| 100000789 | Eicher Tractor Rotary Tiller - Bearing Housing Rh | 1238  | 84329090 | 12% |
| 100000790 | Eicher Tractor Rotary Tiller - Circlip            | 19    | 73182910 | 18% |
| 100000791 | Eicher Tractor Rotary Tiller - Side Plate Rh      | 2969  | 84329090 | 12% |
| 100000792 | Eicher Tractor Rotary Tiller - Sideplate Lh       | 4117  | 84329090 | 12% |
| 100000793 | Eicher Tractor Rotary Tiller - Bearing Housing Lh | 1709  | 84329090 | 12% |
| 100000794 | Eicher Tractor Rotary Tiller - Seal - 57.15X85X11 | 75    | 84329090 | 12% |
| 100000795 | Eicher Tractor Rotary Tiller - Driven Flange Lh   | 1840  | 84329090 | 12% |
| 100000796 | Eicher Tractor Rt - Drive Gear 20T - Dry Rt       | 2000  | 84834000 | 18% |
| 100000797 | Eicher Tractor Rt - Idler Gear 33T - Dry Rt       | 3830  | 84834000 | 18% |
| 100000798 | Eicher Tractor Rt - Driven Gear 34T - Dry Rt      | 3340  | 84834000 | 18% |
| 100000799 | Eicher Tractor Rotary Tiller - M40X1.5 Castle Nut | 98    | 84329090 | 12% |



|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000800 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 6962  | 84329090 | 12% |
| 100000801 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 7547  | 84329090 | 12% |
| 100000802 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 9198  | 84329090 | 12% |
| 100000803 | Eicher Tractor Rotary Tiller - Hitch Brkt Long     | 1180  | 84329090 | 12% |
| 100000804 | Eicher Tractor Rt - Hex Bolt - M16 X 2 - 130L      | 59    | 73181500 | 18% |
| 100000805 | Eicher Tractor Rotary Tiller - Bottom Plate Hitch  | 452   | 84329090 | 12% |
| 100000806 | Eicher Tractor Rotary Tiller - Assy Flange Gb Mtg  | 1626  | 84329090 | 12% |
| 100000807 | Eicher Tractor Rotary Tiller - Gear 19T            | 760   | 84834000 | 18% |
| 100000808 | Eicher Tractor Rotary Tiller - Assy Main Frame     | 11552 | 84329090 | 12% |
| 100000809 | Eicher Tractor Rotary Tiller - Assy Tail Board     | 5192  | 84329090 | 12% |
| 100000810 | Eicher Tractor Rt - Dcl Genxt - Blade Clearance    | 7     | 39199090 | 18% |
| 100000811 | Eicher Tractor Rt - Dcl Genxt - Dgbb Bearings      | 13    | 39199090 | 18% |
| 100000812 | Eicher Tractor Rt - Dcl Genxt - Asli Waterproof    | 7     | 39199090 | 18% |
| 100000813 | Eicher Tractor Rt - Dcl Genxt - Rotation Direction | 7     | 39199090 | 18% |
| 100000814 | Eicher Tractor Rt - Dcl Genxt - Invoulte Gear Prof | 13    | 39199090 | 18% |
| 100000815 | Eicher Tractor Rt - Dcl Genxt - Induction Hardened | 13    | 39199090 | 18% |
| 100000816 | Eicher Tractor Rt - Dcl Genxt - Asli Duo Cone Seal | 13    | 39199090 | 18% |
| 100000817 | Eicher Tractor Rt - Dcl (Maintenance Chart)        | 47    | 49089000 | 12% |
| 100000818 | Eicher Tractor Rt - Dcl (Gear Pair Selection)      | 71    | 39199090 | 18% |
| 100000819 | Eicher Tractor Rt - Dcl Genxt - Utility Gear Pair  | 13    | 39199090 | 18% |
| 100000820 | Eicher Tractor Rt - Dcl Genxt - Wet                | 26    | 39199090 | 18% |
| 100000821 | Eicher Tractor Rt - Agristar Plate                 | 105   | 84329090 | 12% |
| 100000822 | Eicher Tractor Rt - Dcl Genxt - Asli Multispeed    | 89    | 39199090 | 18% |
| 100000823 | Eicher Tractor Rt - Dcl Genxt - Asli Boron Blades  | 7     | 39199090 | 18% |
| 100000824 | Eicher Tractor Rt - Dcl Genxt - Sq. Assy. Jackshaf | 13    | 39199090 | 18% |
| 100000825 | Eicher Tractor Rt - Dcl Genxt - Asli Powdercoated  | 7     | 39199090 | 18% |
| 100000826 | Eicher Tractor Rt - Gear Pair Dcl(18/19)           | 1     | 39199090 | 18% |
| 100000827 | Eicher Tractor Rt - Dcl (Gear Pair Selection)      | 44    | 49089000 | 12% |
| 100000828 | Eicher Tractor Rt - Dcl Genxt - Dry                | 24    | 84329090 | 12% |
| 100000829 | Eicher Tractor Rt - Agristar Plate Red & Orange    | 105   | 84329090 | 12% |
| 100000830 | Eicher Tractor Rt - Dcl (Gear Pair Selection)      | 71    | 39199090 | 18% |
| 100000831 | Eicher Tractor Rt - Dcl Genxt - Wet & Dry          | 56    | 39199090 | 18% |
| 100000832 | Eicher Tractor Rotary Tiller - Searing Nup208E     | 660   | 84822011 | 18% |
| 100000833 | Eicher Tractor Rotary Tiller - D/F Rh M14-Ssv/Hsv- | 1543  | 84329090 | 12% |
| 100000834 | Eicher Tractor Rotary Tiller - Side Disc Assy      | 6234  | 84329090 | 12% |
| 100000835 | Eicher Tractor Rotary Tiller - Assy. Jackshaft 42  | 4580  | 84329090 | 12% |
| 100000836 | Eicher Tractor Rt - Assy Flange-Ms Gearbox Mtg 36  | 3220  | 84329090 | 12% |
| 100000837 | Eicher Tractor Rt - Dry Series Gear Box Assembly   | 6460  | 84329090 | 12% |
| 100000838 | Eicher Tractor Rt - Main Frame Assy                | 8015  | 84329090 | 12% |
| 100000839 | Eicher Tractor Rt - Assy Mainframe -1200 (Co)      | 7762  | 84329090 | 12% |
| 100000840 | Eicher Tractor Rt - D/F Lh-Mini-New                | 1760  | 84329090 | 12% |
| 100000841 | Eicher Tractor Rt - D/F Rh-Mini-New-6208           | 1539  | 84329090 | 12% |
| 100000842 | Eicher Tractor Rt - Ars - 1200Mm -Mini-Black       | 7049  | 84329090 | 12% |
| 100000843 | Eicher Tractor Rt - Assy Tailboard 1200 Co         | 4070  | 84329090 | 12% |
| 100000844 | Eicher Tractor Rt - Assy Hitch Brkt-Lower-Mini     | 611   | 84329090 | 12% |
| 100000845 | Eicher Tractor Rt - Assy Hitch Brkt Top Rh Co      | 1210  | 84329090 | 12% |
| 100000846 | Eicher Tractor Rt - Gb Ss-800/1000/Wet-Co          | 2150  | 84329090 | 12% |





|           |  |       |          |     |
|-----------|--|-------|----------|-----|
| 100000847 | Eicher Tractor Rt - Gear Cap Front Ss-Mini-Co      | 140   | 84329090 | 12% |
| 100000848 | Eicher Tractor Rt - Assy Dummy Sq. 1200 Ss Mini Rt | 1528  | 84329090 | 12% |
| 100000849 | Eicher Tractor Rt - Assy Rotor Shaft 54B (Mb)      | 13482 | 84329090 | 12% |
| 100000850 | Eicher Tractor Rt - Assy Rotor Shaft 60B (Mb)      | 18210 | 84329090 | 12% |
| 100000851 | Eicher Tractor Rt - Assy Rotor Shaft 48B (Mb)      | 13827 | 84328090 | 12% |
| 100000852 | Eicher Tractor Rt - Blade Lh - Ssv / Hsv / W&D & D | 215   | 84329090 | 12% |
| 100000853 | Eicher Tractor Rt - Blade Rh - Ssv / Hsv / W&D & D | 215   | 84329090 | 12% |
| 100000854 | Eicher Tractor Rt - Blade Lh - Wet / Multi         | 215   | 84329090 | 12% |
| 100000855 | Eicher Tractor Rt - Blade Rh - Wet / Multi         | 215   | 84329090 | 12% |
| 100000856 | Eicher Tractor Rt - Gb95 Front Cap Co              | 150   | 84329090 | 12% |
| 100000857 | Eicher Tractor Rt - Tary Tiller-Gb95 Multi Front C | 102   | 84329090 | 12% |
| 100000858 | Eicher Tractor Rt - Output Shaft-36New&1200Mm      | 738   | 84329090 | 12% |
| 100000859 | Eicher Tractor Rt - Assy Dummy Sq. 1200 Ms Mini Rt | 1632  | 84329090 | 12% |
| 100000860 | Eicher Tractor Rt - Gear 12T                       | 511   | 84834000 | 18% |
| 100000861 | Eicher Tractor Rt - Gear 25T                       | 1113  | 84834000 | 18% |
| 100000862 | Eicher Tractor Rt - Rear Cover O Ring              | 62    | 40169320 | 18% |
| 100000863 | Eicher Tractor Rt - Assy Leg Mtg Plate             | 3078  | 84329090 | 12% |
| 100000864 | Eicher Tractor Rt - Eg Mtg Plate Assy - Mini Value | 3057  | 84329090 | 12% |
| 100000865 | Eicher Tractor Rt - Ads - 36B Off/42B              | 3440  | 84329090 | 12% |
| 100000866 | Eicher Tractor Rt - Ads - 48B-6Fit - Hsv - Co      | 3560  | 84329090 | 12% |
| 100000867 | Eicher Tractor Rt - Rear Cover                     | 623   | 84329090 | 12% |
| 100000868 | Eicher Tractor Rt - Assy Rotor Shaft 60B           | 21745 | 84329090 | 12% |
| 100000869 | Eicher Tractor Rt - Assy-Hitch Bkt Lower Mini      | 620   | 84329090 | 12% |
| 100000870 | Eicher Tractor Rt - Bottom Plate Mini Co           | 180   | 84329090 | 12% |
| 100000871 | Eicher Tractor Rt - Assy Rotor Shaft 54B (Mb)      | 17590 | 84329090 | 12% |
| 100000872 | Eicher Tractor Rt -Assy Flange Gearbox Mtg 36B Co  | 2842  | 84329090 | 12% |
| 100000873 | Eicher Tractor Rt - Assy Flange Gearbox Mtg 42B Co | 3810  | 84329090 | 12% |
| 100000874 | Eicher Tractor Rt - Assy Flange - Gearbox Mtg - 7  | 3298  | 84329090 | 12% |
| 100000875 | Eicher Tractor Rt - Shear Bolt With Nut – 10.9 Gra | 49    | 84328090 | 12% |
| 100000876 | Eicher Tractor Rt - Assy Rotor Shaft-42 Bl 717 Vx  | 17120 | 84329090 | 12% |
| 100000877 | Eicher Tractor Rt - Stopper Stud                   | 353   | 84329010 | 12% |
| 100000878 | Eicher Tractor Rt - Assy Tailboard-36B Co          | 5652  | 84329090 | 12% |
| 100000879 | Eicher Tractor Rt - Assy Tailboard-42B Co          | 7696  | 84329090 | 12% |
| 100000880 | Eicher Tractor Rt - Assy Tailboard-48B Co          | 8217  | 84329090 | 12% |
| 100000881 | Eicher Tractor Rt - Assy Hitch Bracket             | 1577  | 84329090 | 12% |
| 100000882 | Eicher Tractor Rt - Gb110 Front Cap Co             | 141   | 84329090 | 12% |
| 100000883 | Eicher Tractor Rt - Gb110 Multi Front Cap Co       | 160   | 84329090 | 12% |
| 100000884 | Eicher Tractor Rt - O-Ring 96 X 2.2                | 25    | 84329090 | 12% |
| 100000885 | Eicher Tractor Rt - Assy. Jackshaft 36 Co          | 4050  | 84329090 | 12% |
| 100000886 | Eicher Tractor Rt - Main Frame Assy 5F Dry Series  | 18536 | 84329090 | 12% |
| 100000887 | Eicher Tractor Rt - Hex Nut M14X2                  | 9     | 73181600 | 12% |
| 100000888 | Eicher Tractor Rt - Assy Jack Shaft - 36 Zero Offs | 4370  | 84329090 | 12% |
| 100000889 | Eicher Tractor Rt - Assy Jack Shaft - 48 Blades    | 4405  | 84329090 | 12% |
| 100000890 | Eicher Tractor Rotary Tiller - Assy Rotor Shaft-36 | 14750 | 84329090 | 12% |
| 100000891 | Eicher Tractor Rt - Main Frame -42                 | 19245 | 84329090 | 12% |
| 100000892 | Eicher Tractor Rt - Assy Dummy Shaft 36/42 Co      | 2761  | 84329090 | 12% |
| 100000893 | Eicher Tractor Rt - Assy Dummy Shaft 48 Co         | 128   | 84329090 | 12% |



|             |  |       |          |     |
|-------------|--|-------|----------|-----|
| 100000895   | Eicher Tractor Rt - Assy Dummy Shaft 5 Ft Co       | 2546  | 84329090 | 12% |
| 100000896   | Eicher Tractor Rt - Assy Dummy Shaft 5.5 Ft Co     | 123   | 84329090 | 12% |
| 100000897   | Eicher Tractor Rt - Assy Flange 30 Blade           | 1973  | 84329090 | 12% |
| 100000898   | Eicher Tractor Rt - Dry Bottom Clamp Co            | 326   | 84329090 | 12% |
| 100000899   | Eicher Tractor Rt - Flat Washer M10                | 2     | 73182100 | 18% |
| 100000900   | Eicher Tractor Rt - Spacer 13X18 - Dry             | 17    | 84329090 | 12% |
| 100000901   | Eicher Tractor Rt - Spacer - Hitch Bracket         | 19    | 84329090 | 12% |
| 100000902   | Eicher Tractor Rt - Dust Cover                     | 282   | 84329090 | 12% |
| 100000903   | Eicher Tractor Rt - Maine Frame 5 Ft Off           | 21535 | 84329090 | 12% |
| 100000904   | Eicher Tractor Rt - Maine Frame 5 Ft Cen           | 21458 | 84329090 | 12% |
| 100000905   | Eicher Tractor Rt - Bearing Housing Rh Kit         | 4797  | 84328090 | 12% |
| 100000906   | Eicher Tractor Rt - Assy Rotor Shaft Dry 36B       | 17504 | 84329090 | 12% |
| 100000907   | Eicher Tractor Rt - Assy Rotor Shaft Dry 42B       | 19497 | 84329090 | 12% |
| 100000908   | Eicher Tractor Rt - Assy Rotor Shaft Dry 48B       | 22072 | 84329090 | 12% |
| 100000909   | Eicher Tractor Rt - Bearing Housing Rh             | 1625  | 84329090 | 12% |
| 100000910   | Eicher Tractor Rt- Change Gear 14T - 1000 Rpm      | 1227  | 84834000 | 18% |
| 100000911   | Eicher Tractor Rt- Change Gear 29T - 1000 Rpm      | 3234  | 84834000 | 18% |
| 100000912   | Eicher Tractor Rt - Maine Frame Assy 36B - Co      | 18640 | 84329090 | 12% |
| 100000913   | Eicher Tractor Rt - Maine Frame Assy 42B - Co      | 21351 | 84329090 | 12% |
| 100000914   | Eicher Tractor Rt - Maine Frame Assy 48B - Co      | 22895 | 84329090 | 12% |
| 100000915   | Eicher Tractor Rt - Assy Jack Shaft 36B- Co        | 5806  | 84329090 | 12% |
| 100000916   | Eicher Tractor Rt - Assy Jack Shaft 42B -Co        | 6168  | 84329090 | 12% |
| 100000917   | Eicher Tractor Rt - Assy Jack Shaft 48B -Co        | 6664  | 84329090 | 12% |
| 100000918   | Eicher Tractor Rt - Assy Main Frame Rmb            | 11401 | 84329090 | 12% |
| 100000919   | Eicher Tractor Rt - Head Stock                     | 14944 | 84329090 | 12% |
| 1128619M    | Eicher Tractor Piston (Menon ) Old Combustion      | 3008  | 84099112 | 28% |
| 1380667R    | Eicher Tractor Startor Motor Assy.(115Es/Esg)      | 10654 | 85114000 | 28% |
| 1382196H    | Eicher Tractor Valve Stem Oil Seal H               | 85    | 40169330 | 18% |
| 1433C06201  | Eicher Tractor Decal - High Lug Tyre Caution       | 20    | 87089900 | 18% |
| 1717492H    | Eicher Tractor Valve Stem Oil Seal                 | 86    | 40169320 | 18% |
| 2410P00101  | Eicher Tractor Pto Seal 36X68X25 (Ericks Seal)     | 14377 | 87089900 | 18% |
| 77000058K   | Eicher Tractor Filter Kit (77000062-2)(93193706-1) | 362   | 84212300 | 18% |
| 77000059S   | Eicher Tractor 00026586 = Filter Kit 77000062-7700 | 354   | 84212300 | 18% |
| 77001979K   | Eicher Tractor Diesel Filter Kit (1X00026582+1X000 | 235   | 84212300 | 18% |
| 83180128S   | Eicher Tractor Valve Seat - Intake (Semi Finish)   | 290   | 84099941 | 28% |
| 83230159S   | Eicher Tractor Control Housing Assy Kit            | 8768  | 84099941 | 28% |
| 83230160S   | Eicher Tractor Governor Sleeve Assy Kit            | 3475  | 84099941 | 28% |
| 83240136R   | Eicher Tractor 63Amps 4Pole L&T Contactor Mcx12    | 5396  | 85369090 | 18% |
| 83250126R   | Eicher Tractor Static Battery Charger 10A-Smps Ba  | 2208  | 85044090 | 18% |
| 93233819R   | Eicher Tractor Procom Econ-Abt-Rel-10Kva           | 10030 | 85030010 | 18% |
| 93233819RN  | Eicher Tractor Procom Econ-Abt-Rel-10Kva           | 10620 | 85030010 | 18% |
| 93233972R   | Eicher Tractor Avr (5 To 125Kva)                   | 3317  | 85030010 | 18% |
| 93244106RJ  | Eicher Tractor Gcu Gc 2111 - Rjil                  | 10030 | 85030010 | 18% |
| 93244106RJN | Eicher Tractor Gcu Gc 2111 - Rjil                  | 10974 | 85030010 | 18% |
| 93393800/P  | Eicher Tractor Lock Pin                            | 605   | 73182100 | 18% |
| 93393811/P  | Eicher Tractor Swinging Draw Bar                   | 5442  | 87089900 | 18% |
| 93480136C   | Eicher Tractor Sealent- Hyd. Pump Assy (Anabond 61 | 32    | 32141000 | 18% |



|            |  |       |          |     |
|------------|--|-------|----------|-----|
| 93638882/P | Eicher Tractor Dual Clutch Assy.                   | 37411 | 87089300 | 18% |
| 93671306A  | Eicher Tractor 11" Clutch Cover Assy.(Am)          | 3465  | 87089300 | 18% |
| 93752010/P | Eicher Tractor Suction Pipe G2 Hsg                 | 4393  | 87089900 | 18% |
| 93752022/P | Eicher Tractor Locking Screw                       | 416   | 73181500 | 18% |
| 96150615C  | Eicher Tractor Bonded Seal M18                     | 24    | 87089900 | 18% |
| 96150615K  | Eicher Tractor Bonded Seal M18                     | 22    | 87089900 | 18% |
| 96150652C  | Eicher Tractor Bonded Seal M14                     | 27    | 40169390 | 18% |
| 97200045M  | Eicher Tractor Liner / Ring(Conf) W Piston O/M     | 5851  | 84099941 | 28% |
| 97200045P  | Eicher Tractor Eng O/H Kit With Pin And Circlip    | 6399  | 84099941 | 28% |
| 97200416E  | Eicher Tractor Eicher Rakshak Grease (0.5 Kgs)     | 280   | 27101980 | 18% |
| 97200417E  | Eicher Tractor Eicher Rakshak Grease (1 Kg)        | 550   | 27101980 | 18% |
| 97200500E  | Eicher Tractor Eicher Rakshak Grease (18 Kgs)      | 7400  | 27101980 | 18% |
| S6052086   | Eicher Tractor Cyl Hd Collet Removal Tool-Ac(St-Ac | 3844  | 82060090 | 18% |
| S6052087   | Eicher Tractor Cyl Hd Collet Removal Tool-Wc(St-Ac | 3844  | 82060090 | 18% |
| S6052088   | Eicher Tractor Gov Flange Tightening Tool (St-Agf- | 6802  | 82060090 | 18% |
| S6052089   | Eicher Tractor Puller For Crank Gear 322/422(St-Ac | 5553  | 82060090 | 18% |
| S6052090   | Eicher Tractor Mandrel For Loosening Flywheel(St-A | 1773  | 82060090 | 18% |
| S6052091   | Eicher Tractor Ring Nut Tightening Tool-222Es(St-A | 4955  | 82060090 | 18% |
| S6052092   | Eicher Tractor Ring Nut Tightening Tool-Multi(St-A | 4955  | 82060090 | 18% |
| S6052093   | Eicher Tractor Swan Neck Tube(St-Awt-8)            | 1111  | 82060090 | 18% |
| S6052094   | Eicher Tractor Fip Gear Puller For 323/422(St-Afpg | 2456  | 82060090 | 18% |
| S6052095   | Eicher Tractor Fip Gear Puller For Wc Eng (St-Wfpg | 1516  | 82060090 | 18% |
| S6052096   | Eicher Tractor Lub Oil Suction Screen Opener(St-As | 1501  | 82060090 | 18% |
| S6052097   | Eicher Tractor Cylinder Liner Puller(St-Wcl-12)    | 13242 | 82060090 | 18% |
| S6052098   | Eicher Tractor Cylinder Liner Pusher(St-Wcl-13)    | 5767  | 82060090 | 18% |
| S6052099   | Eicher Tractor Oil Seal Pusher Multi Cyl Ac(St-Aos | 4442  | 82060090 | 18% |
| S6052100   | Eicher Tractor Inj Sleeve Tightening Tool (St-Wis- | 4677  | 82060090 | 18% |
| S6052101   | Eicher Tractor Pre-Filter Service Tool(St-Wpf-16)  | 2413  | 82060090 | 18% |
| S6052102   | Eicher Tractor Wtr Collector Bowl Serv Tool(St-Wwb | 2178  | 82060090 | 18% |
| S6052103   | Eicher Tractor Feeler Gauge Set-Mm,5 Strips(St-Awt | 886   | 82060090 | 18% |
| S83180353  | Eicher Tractor Pre Filter Insert                   | 1079  | 84212900 | 18% |
| S83180354  | Eicher Tractor Main Filter Spin On                 | 2316  | 84099990 | 28% |
| S83180545  | Eicher Tractor Clamping Saddle                     | 364   | 84133010 | 28% |
| S83180546  | Eicher Tractor Sealing Ring                        | 162   | 40169390 | 18% |
| S83180547  | Eicher Tractor O-Ring                              | 133   | 40169390 | 18% |
| S83240095  | Eicher Tractor Procom Econ-Abt-Rel-20Kva           | 10030 | 85030010 | 18% |
| S83240095N | Eicher Tractor Procom Econ-Abt-Rel-20Kva           | 10620 | 85030010 | 18% |
| S83270004  | Eicher Tractor Nrv-Pre Fuel Filter 1751Es          | 123   | 84212300 | 18% |
| S83270013  | Eicher Tractor Strainer- Fuel Filter 1751Es        | 164   | 84212300 | 18% |